

ENGINEERING TOMORROW

Application Guide

PVED-CLS Start-up guide



www.danfoss.com



Revision history

Table of revisions

Date	Changed	Rev
November 2019	Corrected wording for clarity	0102
October 2018	First edition	0101



Contents

Introduction

	Overview	4
	Downloading the required software	5
	Initial steps	6
Parameter setting		
_	Hydraulic configuration	7
	Peripherals configuration	9
,	Vehicle geometry configuration	11
	SEHS protocol data	13
	Boot EE data	16
,	WAS calibration	17
	Spool calibration	18
,	Valve calibration data	20
	Production/calibration flag	22
	STW configuration	23
	AUX configuration	27
	GPS configuration	33
	Auto calibration configuration	37
Advanced parameter setting		
Troubleshooting		

Resolving safe-state mode by soft reset	41
Resolving safe-state mode with SPN and FMI codes	
SEHS error history	
Clear error history	43
SEHS error occurrence	
Status messages	
Direct output control	45



PVED-CLS overview

This application guide will detail setting parameters for configuring the PVED-CLS as well as troubleshooting when the PVED-CLS goes into safe-state mode. There are other literature references in this document and it is recommended to have them read before configuration.

Literature references

- PVED-CLS user manual (included in firmware release package /technical manuals folder)
- Communication protocol (included in firmware release package /technical manuals folder)
- PLUS+1° Service Tool user guide (found in firmware release package / Service tool folder)
- PVED-CLS safety manual (must be requested from local eSteering Product Application Engineer or sales representative)

Additional resources

PLUS+1[®] Service Tool





Introduction

Downloading the required software

- 1. Download the desired or latest firmware release package on the PVED-CLS web page
- 2. Optional: Request and download the *PLUS*+1^{*} Service Tool under Service Tool: Request heading.



Introduction

PVED-CLS initial steps

- **1.** Open the Service Tool
- 2. Optional: If changing the firmware to a different revision, flash the Main and Safety Controller (Release Package > Software)

See Section 6.2 (pages 23-27) of the PLUS+1* Service Tool user guide. When changing to a newer firmware revision, please look at the Firmware Release Note found in the Firmware Release Package of the selected revision for additional steps.

Reverting to an early revision of firmware may not be possible with the Service Tool depending on the specific revisions. Please contact the Danfoss technical representative if you have concerns about changing firmware.

3. Install Diagnostic Data Files of selected Firmware Revision (Release Package > Diagnostic data files).

See Section 6.1 (pages 21-22) of the PLUS+1° Service Tool user guide found in the Firmware Release package under / Service tool folder.

- 4. Open .*P1D* file in the Service Tool (Release Package > Service Tool)
- 5. Select OEM on the info page

Parameter Sector Access Code Level	Dealer -
Parameter Sector Access Code	Manufacturer OEM
	Dealer Edit PSAC

6. Click Edit PSAC and enter correct hexadecimal number

Parameter Sector Access Code Level	OEM -
Parameter Sector Access Code	
	Edit PSAC

7. Click OK



PVED-CLS hydraulic configuration P3072-P3097

Navigate to the hydraulic configuration section via **System Navigator** > **Configuration** > **Hydraulic Config**

Example parameter settings

Hydraulic Config

Upload parameters	New v	alues
Download parameters	MAIN	SAFETY
P3072: Cut-off valve present	Present	•
P3073: Cut-off valve control mode	Closed lo	iop -
P3074: Cut-off valve CL pull current	11	100
P3076: Cut-off valve CL hold current	5	500
P3078: Cut-off valve monitoring POST timeout	5	900
P3097: Cut-off valve PWM pre-load value	3	100
P3080: Invert flow direction	N	0 -
P3081: Valve type	OSPE/EH	i-E 👻
P3082: Turns lock-to-lock EHPS	4	50
P3084: OSP displacement	1	.20 💭
P3086: Cylinder stroke volume	5	00
P3088: Valve capacity		20
P3089: LVDT offset compensation Enable/Disable	Enab	le 👻
P3090: Absolute Spool neutral threshold range		25

If the parameter change is not described below or conditions are not met, use the default values.

Parameter settings

Parameter	Conditions for value changes
P3072	Not present if there is no cut-off valve (usually with EHPS)
P3078	Set to 0 if PVED-CLS is part of desk setup
P3097	Set to 50 if using 12V coil on a 24V system
P3080	Set to "YES" if using EHPS
P3081	Set to match the valve type used
P3082	If using EHPS, enter desired turns lock-to-lock x100 that matches the hydraulic system
P3084	Set to match OSP displacement in cubic centimeters
P3086	Set to match volume needed to turn lock-to-lock. If using unbalanced cylinder, set to average of left and right.

The default parameters are based on 12V coil. Depending on the voltage, the following parameters may need to be changed:

Parameter	12V coil	24V coil
P3074	1100mA	550mA
P3076	500mA	250mA

The pre-load parameter P3097 is a PWM signal and it must be set to scale the input voltage down to the rated current of the spool:



P3097 input voltage scaling

Input voltage	12V coil	24V coil
12V	100%	N/A
24V	50%	100%
36V	33%	67%

PVED-CLS parameter acceptance

Use the following steps to save and approve the parameters that have been set.

- 1. Press **Download** and wait for the script to complete.
- 2. Click Close.

It is mandatory to confirm that the parameters have been downloaded by the user.

3. Press Approve Parameters.

The text will change to **Approved** and the page can then be closed.

Leaving the page before parameters are accepted will cause an EEPROM fault and the PVED-CLS will go to safe-state mode.



PVED-CLS peripherals configuration P3237-P3254

Navigate to the peripherals configuration section via **System Navigator** > **Configuration** > **Peripherals Config**

Example parameter settings

Peripherals Config

Upload parameters		New	values
Download parameters		MAIN	SAFETY
— GPS config —			
P3237: GPS present		Prese	nt 👻
P3238: GPS2 present		Prese	nt 👻
— WAS config —			
P3245: Redundant WAS pres	ent	Prese	nt 👻
P3244: WAS interface		Ana	logue -
P3248: Generation of 5V sen (Deutsch connector p	sor supply voltage in 11)	E	nable 👻
P3249: AD low pass filter cut	-off frequency		100
P3246: Voltage compensatio	n for Primary analogue sensor	E	nable 👻
P3247: Voltage compensatio analogue sensor	n for Redundant	E	nable 👻
— Vehicle speed sensor loc	kout config —		
P3250: Max vehicle speed for or AUX steering devic	r engaging auto-guidance e		15 💌
P3251: Max vehicle speed for	r steering program changes		15
P3252: Lower vehicle speed a threshold	auto-guidance suspend		50 (
P3253: Safe state vehicle spe	eed threshold		25
— Safe on-road monitoring —	_		
P3243: Max COV connection to	est current		100
P3241: Road switch present (c	connected to AD3)	Presen	t 👻
P3242: Road switch resistance check Disable -		able 👻	
— AUX config —			
P3239: AUX present		Not Pre	esent 👻
P3240: AUX type		mini steering whe	el 🔻
P3254: EH-Steering disengag	e method	5	SASA -

If the parameter change is not described below or conditions are not met, use the default values.

Parameter	Conditions for value changes
P3237	Set to match presence of GPS/auto-guidance controllers in system
P3238	Set to match presence of GPS/auto-guidance controllers in system





Parameter	Conditions for value changes
P3245	Set to match presence of redundant WAS signal
P3244	Set to match type of WAS signal: Analog, CAN, or None
P3246	Enable only if using uncompensated Analog WAS
P3247	Enable only if using uncompensated Analog WAS
P3250	Vehicle speed must be below this threshold to allow auto-guidance or AUX device to be enabled (speed measured in km/h)
P3251	Vehicle speed must be below this threshold to allow for switching steering wheel programs (speed measured in km/h)
P3252	Vehicle speed must be above this threshold to use auto-guidance
P3253	PVED-CLS will go into safe-state mode if vehicle speed is above this threshold
P3241	Set to match presence of Safe On-Road Switch and electric architecture
P3239	Set to match presence of AUX device
P3240	Set to match type of AUX device
P3254	Set to IMD if using EHi-H

Approve the parameters by following the steps in *PVED-CLS parameter acceptance* on page 8.



PVED-CLS vehicle geometry configuration P3421-P3428

Navigate to the vehicle geometry configuration section via **System Navigator** > **Configuration** > **Vehicle Geometry**

Example parameter settings

Vehicle Geometry

Upload parameters	New valu	ies
Download parameters	MAIN	SAFETY
P3421: Vehicle steering type	2 Wheel Steering	ng 🔻
P3422: Wheel base A		4000
P3424: Wheel base B	1	4000
P3426: Maximum steer angle, left		35 💌
P3428: Maximum steer angle, right		35 🗭

If the parameter change is not described below or conditions are not met, use the default values.

Parameter	Conditions for value changes
P3421	Set to match type of steering
P3422	Change according to wheel base figure shown below (dimensions measured in mm)
P3424	Change according to wheel base figure shown below (dimensions measured in mm)
P3426	Change according to steer angle figure and formula shown below (measured in degrees)
P3428	Change according to steer angle figure and formula shown below (measured in degrees)

Wheel base







Approve the parameters by following the steps in *PVED-CLS parameter acceptance* on page 8.



PVED-CLS SEHS protocol data P3292-P3331

Navigate to the SEHS protocol data section via **System Navigator** > **Configuration** > **SEHS Protocol Data**

Example parameter settings

SEHS Protocol Data

Upload parameters	Newv	alues
Download parameters	MAIN	SAFETY
P3310: PVED-CLS address claim - Function instance		
P3287: SASA message monitoring - Max time difference between two messages		
P3288: Vehicle speed sensor message monitoring - Max time difference between two messages	1	
P3289: Auto-guidance message monitoring - Max time difference between two messages	2	2
P3290: Wheel angle sensor message monitoring - Max time difference between two messages		8 🗭
P3291: AUX message monitoring - Max time difference between two messages		8
- Source Addresses -		
P3297: PVED-CLS source address	19	90 🖢
P3292: GPS source address	28 戻	28 💌
P3293: GPS2 source address	29 🗭	29 💌
P3294: Vehicle speed sensor source address	251 💌	251 🗭
P3295: MMI source address	252	252
P3296: SASA sensor source address	77 💌	77 🛋
P3298: Wheel angle sensor source address	250	250
P3299:AUX device (mini steering wheel) source address	79 💌	79 🗭
P3300:AUX device (joystick) source address	78 💌	78 🛋
— Transmission rates —		
P3308: Transmission rate - Steering feedback message	5 💌	5 💌
P3309: Transmission rate - Guidance machine status message	10 💌	10
P3301: Transmission rate - Operation Status Messages	10 💌	10 💌
P3302: Transmission rate - Status message 1	0	0
P3303: Transmission rate - Status message 2	0	0
P3304: Transmission rate - Status message 3	0	0 💌
P3305: Transmission rate - Status message 4	0	0
P3306: Transmission rate - Status message 5	0	0
P3307: Transmission rate - Status message 6	0	0
P3327: Transmission rate - Status message 7	0	0
P3331: Transmission rate - Status message 8	0	0

If the parameter change is not described below or conditions are not met, use the default values.

Parameter	Condition for value change
P3292-P3300	Leave at default value unless source addresses conflict with other nodes on the CAN bus or another addressing scheme is desired
P3301	Data is sent at the rate of "value" x 10ms
P3308-P3309	Set to 0 if not using messages, otherwise data is sent at the rate of "value" x 10ms
P3302-P3307	Set to over 0 if using messages to send data at the rate of "value" x 10ms, otherwise messages are disabled
P3327	Set to over 0 if using messages to send data at the rate of "value" x 10ms, otherwise messages are disabled
P3331	Set to over 0 if using messages to send data at the rate of "value" x 10ms, otherwise messages are disabled



PVED-CLS SEHS protocol data P3311-P3333

Example parameter settings

— PGN and PGN Offsets —		
P3311: PGN offset to operation status messages	32 💌	32 💌
P3312: PGN offset to status message 1	33 🗬	33 🕷
P3313: PGN offset to status message 2	34 💌	34 💌
P3314: PGN offset to status message 3	35 💌	35 💌
P3315: PGN offset to status message 4	36 💌	36
P3316: PGN offset to status message 5	37 🗭	37 💌
P3317: PGN offset to status message 6	38 💌	38
P3328: PGN offset to status message 7	39 💌	39 🕷
P3332: PGN offset to status message 8	40 💌	40 💌
P3329: PGN for AUX Elobau joystick	64982	64982
P3318: PGN offset to vehicle speed sensor message	64 💌	65 💌
P3319: PGN offset to steering wheel sensor messages	16 💌	17 💌
P3320: PGN offset to wheel angle sensor messages	18 💌	19 💌
P3321: PGN offset to AUX mini-steering wheel messages	20 💌	21 💌
P3322: PGN offset to AUX joystick messages	22 💌	23 💌
P3323: PGN offset to steering feedback message	24	24 💌
P3324: PGN type for MMI message	Prop	A -
P3325: PGN offset to MMI message		
P3326: GMS message layout as per ISO11783	Layout according to	ISO11783-7:2009 🔻

P3333: CAN message priority of operational status message

CAN message priority 6 🔹

If the parameter change is not described below or conditions are not met, use the default values.

Parameter	Condition for value change
P3311-P3317	Leave at default unless PGN's conflict with others on the CAN bus or another addressing scheme is desired
P3328	Leave at default unless PGN's conflict with others on the CAN bus or another addressing scheme is desired
P3332	Leave at default unless PGN's conflict with others on the CAN bus or another addressing scheme is desired
P3329	Leave at default unless PGN's conflict with others on the CAN bus or another addressing scheme is desired
P3318-P3323	Leave at default unless PGN's conflict with others on the CAN bus or another addressing scheme is desired
P3324	Leave at default unless "Proprietary B" message formatting of MMI is desired. If "Proprietary B" is chosen, PGN offsets can be edited via P3325.

Approve the parameters by following the steps in PVED-CLS parameter acceptance on page 8.

PVED-CLS Boot EE data

Navigate to the boot EE data section via System Navigator > Configuration > Boot EE Data

Boot Node ID's set the Source Addresses of the Main and Safety micro-controllers which are used for Bootloader mode. These addresses are seen in the ECU list in the PLUS+1[®] Service Tool. By default, these are different than the Main and Safety Source Addresses that are set in the SEHS Protocol Data page.

If the default addresses conflict with other addresses on the bus or a different messaging scheme is desired, modify parameters as described.

Boot EE Data

Upload parameters	New v	alues
Download parameters	MAIN	SAFETY
20003: BOOT Node ID	32 🗨	33 🗬
20013: KWP DLC Validation lote -> 0: Optimized DLC 255: Frame Padding	(

Parameter	Condition for value change
P0003 (main controller)	Set to desired Bootloader Source Address for Main Controller
P0003 (safety controller)	Set to desired Bootloader Source Address for Safety Controller

Accept Boot Node ID parameters

- 1. Download the changed parameters by pressing Download parameters
- 2. After changing the Boot Node ID's, cycle power on the PVED-CLS for new ID's to take affect The new ID's will show up in the ECU list; however, the Service Tool pages are still linked to the old addresses and will produce an error.
- 3. Start to fix the address error by clicking the Replace Missing ECU icon shown below:



4. Follow the prompts and replace the default Main (32) and Safety (33) Source Addresses with the new addresses and press **OK** to complete.





PVED-CLS WAS calibration

Navigate to the WAS calibration section via **System Navigator** > **Auto-Calibration** > **WAS Calibration**

WAS Calibration

		Operation status
Coto WAS Calibration Mode	MAIN	On-road
GOLD WAS CANDI AUDITINODE	SAFETY	On-road
		Service mode state
		Information not available
		WAS interface
Reset Calibration		CAN

- 1. Select Go to WAS calibration mode
- **2.** Steer left, straight (neutral) and right (in any order) using the steering wheel and press the appropriate button when wheels are at the desired angle.
- 3. Press Accept and save

	MAIN		SAFETY
Primary WAS (CAN WAS)	2468 [m	√] Redundant WAS (CAN WAS)	2468
5V Sensor supply	5030 [m	V] 5V Sensor supply	5024
	Capture L	Capture N	Capture R
	MAIN SAFETY	MAIN SAFETY	MAIN SAFETY
Primary WAS (CAN WAS)	0 [mV] 0	0 [mV] 0	0 [mV] 0
Redundant WAS (CAN WAS)	0 [mV] 0	0 [mV] 0	0 [mV] 0
5V Sensor supply		0 [mV] 0	
P3841: Max allowable CAN W to be captured in neul	AS signal ral	04500 [mV] 0450	0 0
P3843: Min voltage needed in captured CAN WAS v	between the alues	0000 [mV] 0000	2 0
P3845: Min allowable CAN W/ to be captured in neul	AS signal ral	00500 [mV] 0050	0.0
			Accept and Save

Values will automatically change in either the Analog Sensor Calibration Data or CAN WAS Calibration Data page, based on which type of WAS was selected in the Peripherals configuration.



PVED-CLS Spool calibration

Navigate to the Spool calibration section via **System Navigator** > **Auto-Calibration** > **Spool Calibration** Calibrate closed loop spool dead-band with the following steps.

Spool Calib	ration			E
			Operation status	
	Goto Spool Calibration Mode	MAIN	On-road	
		SAFETY	On-road	
			Service mode state	
			Information not available	
	Reset Calibration			

- 1. Select Go to calibration mode
- 2. Turn the steering wheel so that Service Mode State changes to Spool Calibration Getting Armed.
- **3.** Stop turning the steering wheel and secure the wheels in a central position so that it changes to **Spool Calibration Armed**.
- **4.** Turn the wheels so that they are positioned straight ahead and within the range specified in parameter P3804. Then press **Start Calibration**.

	Operation status
Goto Spool Calibration Mode	MAIN Service mode - Spool Calibration
	SAFETY Service mode - Spool Calibration
	Service mode state
	Spool Calibration Inactive
Reset Calibration	
Max. WA	255 💮 [10IR]
Max. WA Initial Spool Setpoint	255 ♠ [10IR] 65535 ♠ [10um]
Max. WA Initial Spool Setpoint Min.time	255 ⊕ [10IR] 65535 ⊕ [10um] 255 ⊕ [0.15]
Max. WA Initial Spool Setpoint Min.time Max.time	255 💭 [10IR] 65535 💬 [10um] 255 💮 [0.1s] 255 💬 [0.1s]

Wheels will turn back and forth (or machine will articulate).



5. Watch the Left move and Right move progress info. When both have completed, press the **Accept** and **Save** button.

Max. WA Initial Spool Setpoint Min.time Max.time		255 (101R) 65535 [10um] 255 [0.1s] 255 [0.1s]
Start Calibration		
Result		
Actual Spool setpoint	Γ	-125 [10um]
Actual Spool Position		0 [10um]
Wheel Angle		-16 [IR]
		Accept and Save
Status		
Wheel movement status		
	Left move	In progress
	Right move	Information not available
Calibration progress		0 [%]
Spool setpoint during last move	-12	5 [10um]
Time needed to complete last move	No time recorded yet	[0.1s]

Values will automatically change in Valve Calibration Data page. If values need to be changed manually, go to Valve Calibration Data page.



PVED-CLS valve calibration data

Navigate to the valve calibration section via **System Navigator** > **Configuration** > **Valve Calibration Data**

Example parameter settings

Valve Calibration Data

Upload parameters	New values	
Download parameters	MAIN	SAFETY
P3162: Max spool position, left	-42	20
P3164: Max spool position, right	42	20
P3166: Closed loop dead-band edge, left	-10	05 🛋
P3168: Closed loop dead-band edge, right		95 A
P3170: Open loop dead-band edge offset		25 💌

Sector CRC

Approve parameters

Parameter	Condition for value change
P3162	If using an EHPS, set the value to -700. Otherwise, use default value.
P3164	If using an EHPS, set the value to 700. Otherwise, use default value.
P3166	Adjust toward 0 for smaller minimum flow in Closed Loop modes (auto-guidance) and vice versa. See deadband figure below.
P3168	Adjust toward 0 for smaller minimum flow in Closed Loop modes (auto-guidance) and vice versa. See deadband figure below.
P3170	Can be decreased but do not increase.





PVED-CLS parameter acceptance

Use the following steps to save and approve the parameters that have been set.

- 1. Press **Download** and wait for the script to complete.
- 2. Click Close.

It is mandatory to confirm that the parameters have been downloaded by the user.

3. Press Approve Parameters.

The text will change to **Approved** and the page can then be closed.

Leaving the page before parameters are accepted will cause an EEPROM fault and the PVED-CLS will go to safe-state mode.



PVED-CLS production/calibration flag

Navigate to the production/calibration flag section via **System Navigator** > **Configuration** > **Production/Calibration Flag**

If WAS Calibration and Spool Calibrations were used, flags will be set automatically. If flags are not set, PVED-CLS will boot into WAS Calibration mode until one of the WAS counters has been set above 0. Then the PVED-CLS will boot into Spool Calibration mode until the Spool calibration flag has been set above 0. If an analog joystick has been selected in Peripherals Config, the Joystick Calibration will need to be run to set the calibration for this, too.

Production/Calibration Flag

Upload parameters	Ne w values
Download parameters	MAIN
P3771: Calibration counter - Spool calibration	1
P3773: Calibration counter - Analogue WAS	
P3775: Calibration counter - CAN WAS	
P3777: Calibration counter - Analogue joystick	0

If the PVED-CLS is used in a desktop environment, then P3771, P3773, P3775 and P3777 must be set to 1 to avoid PVED-CLS from entering calibration mode. For more details, see the PVED-CLS User Manual.

If parameters are changed, be sure to select **Download parameters** to save parameter setting.

There is no **Approve parameters** option on this page.

Danfoss

Parameter setting

PVED-CLS STW configuration

Navigate to the STW configuration section via System Navigator > Configuration > STW Config

Example parameter settings

STW Config

Upload parameters	New	alues
Download parameters	MAIN	SAFETY
— Steering Wheel — P3521: Steering w heel no-activation threshold		5 🕢
P3570: Backlash region		5 🗭
P3583: STW in use - Velocity threshold		5 🗭
P3584: STW in use - Angle threshold	1	0

If the parameter change is not described below or conditions are not met, use the default values.

Parameter	Condition for value change
P3570	Change to 75 (7.5 degrees) to prevent amplifying re-centering of steering wheel.
P3583	Can be increased if auto-guidance or AUX devices are being disengaged too easily by the steering wheel.
P3584	Can be increased if auto-guidance or AUX devices are being disengaged too easily by the steering wheel.

There are four subsets of steering wheel configuration: *Steering Wheel Programs*, *Soft-stop*, *Anti-jerk*, and *Anti-drift*. Be sure to Download and approve parameters when complete with Steering Wheel configuration.

PVED-CLS Steering wheel programs

There are 5 steering wheel programs with identical parameters. Use the details below as a reference for all 5 programs.

Example parameter settings (only Program 1 shown)

— Steering Wheel - Program 1 —

P3522: No of turns @ Point A	800 🛋
P3524: No of turns @ Point B	800 🛋 V
P3526: No of turns @ Point C	800 🛋
P3528: Vehicle speed @ Point B	5 💌
P3529: Vehicle speed @ Point C	10

Parameter	Condition for value change
P3522	Set to desired turns lock-to-lock [x0.01] at 0 km/h (see graph below)
P3524	Set to desired turns lock-to-lock (y-axis) at desired vehicle speed in km/h (P3528)
P3526	Set to desired turns lock-to-lock (y-axis) at desired vehicle speed in km/h (P3529)
P3528	Set to desired vehicle speed in km/h (x-axis) at desired number turns lock-to-lock (P3524)
P3529	Set to desired vehicle speed in km/h (x-axis) at desired number turns lock-to-lock (P3526)







No amplification if orbital produces less than 8 turns lock-to-lock.

If all parameters for turns lock-to-lock are equal, the steering wheel program will have a fixed number of turns lock-to-lock. Steering wheel programs can be set so that the number of turns lock-to-lock changes depending on the vehicle speed.

Example of vehicle speed dependent steering wheel program







PVED-CLS soft-stop

Soft-stop can decrease flow sent from the electro-hydraulic valve the to cylinders when wheels are close to end-stop to help prevent damage and jerk.

Example parameter settings

Steering Wheel - Soft-stop	
P3562: STW soft-stop wheel angle region start	4 00 €
P3566: STW soft-stop wheel angle region end	0
P3564: STW soft-stop max flow @ cylinder end-stop	0

Parameter	Conditions for value change
P3562	Distance from end-stop flow starts to decrease [0.1%]
P3566	Distance from end-stop flow stops decreasing [0.1%]
P3564	Max allowed flow at cylinder end-stop [0.1%]

Example of soft-stop flow limitation







PVED-CLS anti-jerk

Anti-jerk can be used to decrease jerk in articulated vehicles. Changing parameters only effect jerk originating from the EH spool. Any jerk caused by the orbital will still exist, but amplified flow from variable rate steering programs will have less jerk.

Example parameter settings

Steering Wheel - Anti-jerk	
P3571: STW anti-jerk function	None 🔻
P3572: STW relative set-point change, out from spool neutral position	5 🗨
P3573: STW relative set-point change, in towards spool neutral position	5 💌
P3574: STW absolute set-point change, out from spool neutral position	15 💌
P3576: STW absolute set-point change, in towards spool neutral position	10 💌
P3578: STW anti-jerk cross-over start point	10 💭
P3580: STW anti-jerk cross-over stop point	10 💭
P3582: STW anti-jerk low pass filter cut-off frequency	100

Parameter	Conditions for value change
P3571	Change to enable anti-jerk functionality
P3572-P3582	See section 10.6 Anti-Jerk in User Manual for details on setting parameters.

Tuning of anti-jerk will take trial and error. Set values low and increase them until articulated machine feels responsive but not jerky. The cross-over start and stop points (P3578 and P3580) can stay at defaults unless extra anti-jerk functionality is required.

PVED-CLS anti-drift

Anti-drift can be used to keep the steering wheel in the same position when driving straight ahead. This is adjusted by adding a percentage of full flow when the actual steering wheel angle doesn't match the ideal steering wheel angle.

Steering Wheel - Anti-drift	
P3568: STW anti-drift - Max steering wheel drift correction	20
P3569: STW anti-drift - Max flow correction in percentage of full flow	15

Parameter	Conditions for value change
P3568	Angle at which maximum correction flow is applied
P3569	Maximum correction flow that can be applied

Default values are recommended for these parameters. See Section 10.5 in the User Manual for more details.



PVED-CLS AUX configuration

Navigate to the AUX configuration section via **System Navigator** > **Configuration** > **AUX Config** The following parameters only apply if AUX is enabled.

AUX Config

Upload parameters	New values	
Download parameters	MAIN	SAFETY
— AUX- Activation threshold —		
P3646: AUX mini-steering in use - Velocity threshold	15	
P3719: AUX mini-steering in use - Angle threshold		
P3649: AUX - Mini-steering no-activation threshold 5		
P3647: AUX joystick in use - Flow command threshold	10	
P3648: AUX - Joystick no-activation threshold	Ę	

Parameter	Conditions for value change
P3646, P3719	See PVED-CLS STW configuration on page 23
P3647	Set to minimum joystick command in 0.1% needed to switch into joystick steering.

There are seven subsets of AUX configuration that apply only if an AUX device is selected in parameter P3240 in the Peripherals Config page: AUX Mini-wheel programs, Soft-stop, Anti-jerk, Anti-drift, Flow limitation, Closed loop joystick, and Open loop joystick.

Approve the parameters by following the steps in *PVED-CLS parameter acceptance* on page 8.

PVED-CLS AUX mini-wheel programs

There are 5 AUX programs for mini steering wheels that each have a similar set of parameters. These are only used if a mini steering wheel is present.

— AUX- Program 1 —	
P3650: AUX mini-steering 1 - No of turns @ Point J	800 🛋
P3652: AUX mini-steering 1 - No of turns @ Point K	800 🗭
P3654: AUX mini-steering 1 - No of turns @ Point L	800 🛋
P3656: AUX mini-steering 1 - Vehicle speed @ Point K	5 🗭
P3657: AUX mini-steering 1 - Vehicle speed @ Point L	10

Parameter	Conditions for value change
P3650-P3657	See PVED-CLS Steering wheel programs on page 23 for configuration details.



PVED-CLS AUX— soft-stop

AUX soft-stop can decrease flow to cylinders when wheels are close to end-stop to help prevent damage and jerk. This parameter is used for mini steering wheel and open loop joystick devices.

AUX- Soft-stop	
P3708: AUX soft-stop max flow @ cylinder end-stop	200 💌
P3710: AUX soft-stop wheel angle region start	0
P3712: AUX soft-stop wheel angle region stop	0 🗭

Parameter	Conditions for value change
P3708-P3712	See PVED-CLS soft-stop on page 25 for configuration details.

Wheels may not return from end-stops or will do so slowly if flow is set too low. Do not decrease P3708 below 200.

PVED-CLS AUX— anti-jerk

Anti-jerk can be used to decrease jerk in articulated vehicles. These parameters can be applied with a mini steering wheel or open-loop joystick.

— AUX- Anti-jerk —	
P3698: AUX anti-jerk function	None +
P3699: AUX relative set-point change, in towards spool neutral position	5 💌
P3700: AUX relative set-point change, out from spool neutral position	5 💌
P3701: AUX absolute set-point change, in towards spool neutral position	10 🗭
P3703: AUX absolute set-point change, out from spool neutral position	15 💌
P3714: AUX anti-jerk cross-over start point	10 💌
P3716: AUX anti-jerk cross-over stop point	10 💭
P3718: AUX anti-jerk low pass filter cut-off frequency	100

Parameter	Conditions for value change
P3698-P3718	See Section 11.6 Open Loop Anti-Jerk in the User Manual for configuration details.

PVED-CLS AUX— anti-drift

Anti-drift can be used to keep the mini steering wheel in the same position when driving straight ahead by adding a percentage of full flow when the actual mini steering wheel angle does not match the ideal angle.

AUX- Anti-drift	
P3706: AUX anti-drift - Max steering wheel drift correction	20
P3705: AUX anti-drift - Max flow correction in percentages of full flow	15 💌
Conditions for value change	
See Section 11.5 Open Loop Mini Wheel Anti-Drift in User Manual f	or details on setting parameters.

Parameter P3706, P3705



PVED-CLS AUX— flow limitation

AUX Flow Limitation is used with Open Loop Joysticks to restrict the maximum flow to steering cylinders as the vehicle speed increases. This function scales all joystick flow commands based on vehicle speed. Don't set flow limit below 200 (20%). See Section 11.9 Open Loop Joystick – Vehicle Speed Dependent Flow Scaling in the User Manual for more info.

-AUX- Flow limitation ----

P3690: AUX joystick - Flow limit for max joystick command @ Point M	1000
P3692: AUX joystick - Flow limit for max joystick command @ Point N	50 💌
P3694: AUX joystick - Flow limit for max joystick command @ Point O	25 💌
P3696: AUX joystick - Vehicle speed @ Point N	15 🗭
P3697: AUX joystick - Vehicle speed @ Point 0	25

Parameter	Conditions for value change
P3690	Set to desired flow limit [1000 = 100%] at 0 km/h (see graph below)
P3692	Set to desired flow limit (y-axis) at desired vehicle speed in km/h (P3696)
P3694	Set to desired flow limit (y-axis) at desired vehicle speed in km/h (P3697)
P3696	Set to desired vehicle speed in km/h (x-axis) at desired flow limit (P3692)
P3697	Set to desired vehicle speed in km/h (x-axis) at desired flow limit (P3694)

Example of AUX flow limitation

-AUX- Flow limitation ----

P3690: AUX joystick - Flow limit for max joystick command @ Point M	1000 🛋
P3692: AUX joystick - Flow limit for max joystick command @ Point N	1000
P3694: AUX joystick - Flow limit for max joystick command @ Point O	300 🖨
P3696: AUX joystick - Vehicle speed @ Point N	15
P3697: AUX joystick - Vehicle speed @ Point O	25 🔿





PVED-CLS AUX— flow limitation tuning advice

- 1. Remove flow limitation (1000 for all 3 flow limits) and drive the machine first slowly and then at increasing speeds.
- **2.** On each trial, steer full left or right with the joystick.

Vehicle tipping hazard! Operate carefully to avoid tipping the vehicle.

If the machine does not feel controllable at a given vehicle speed, use the flow limitation to begin to decrease flow allowed at that speed.

3. Iterate until the operator can move the joystick as quickly as possible at any speed and avoid tipping.

CAN logging can also be implemented to monitor vehicle speed and flow set-points from the Vehicle Speed message and Status Message 4 which are described in the PVED-CLS Communication Protocol document. Scatter plotting flow set-points vs. vehicle speed should yield a curve that can be reflected with the AUX Flow Limitation.

PVED-CLS AUX— closed loop joystick

-AUX- Closed loop joystick ----

AUX Wheel Angle Limit is used with Closed Loop Joysticks to limit the maximum wheel angle as the vehicle speed increases. This function scales all joystick wheel angle commands based on vehicle speed. See Section 11.10 Closed Loop Joystick – Vehicle Speed Dependent Wheel Angle Limitation in the User Manual for more info.

P3720: AUX joystick - Max wheel angle @ Point A	15 🗭
P3721: AUX joystick - Max wheel angle @ Point B	10
P3722: AUX joystick - Max wheel angle @ Point C	5 🛋
P3723: AUX joystick - Vehicle speed limiting wheel angle @ Point B	15 🗨
P3724: AUX joystick - Vehicle speed limiting wheel angle @ Point C	25 🗬

Parameter	Conditions for value change
P3720	Set to desired wheel angle limit [degree] at 0 km/h (see graph below)
P3721	Set to desired wheel angle (y-axis) at desired vehicle speed in km/h (P3723)
P3722	Set to desired wheel angle (y-axis) at desired vehicle speed in km/h (P3724)
P3723	Set to desired vehicle speed in km/h (x-axis) at desired wheel angle (P3721)
P3724	Set to desired vehicle speed in km/h (x-axis) at desired wheel angle (P3722)

Example of AUX wheel angle limitation

-AUX- Closed loop joystick ----

P3720: AUX joystick - Max wheel angle @ Point A	35 🛋
P3721: AUX joystick - Max wheel angle @ Point B	35 💌
P3722: AUX joystick - Max wheel angle @ Point C	15 🗨
P3723: AUX joystick - Vehicle speed limiting wheel angle @ Point B	15 🗭
P3724: AUX joystick - Vehicle speed limiting wheel angle @ Point C	25 💌





Closed loop joystick tuning advice

- **1.** Remove wheel angle limitation (raise all 3 wheel angle limits to maximum angle of vehicle), then steer full left or right with the joystick and keep the wheel angle in place.
- **2.** Slowly increase the speed of the machine while driving in a circle until the machine starts to feel tipsy or unsafe.

Vehicle tipping hazard! Operate carefully to avoid tipping the vehicle.

- 3. Use the wheel angle limitation to decrease the allowed wheel angle at that speed.
- **4.** Iterate until the operator can move the joystick full left or right at any speed and avoid tipping.

CAN logging can also be used to monitor vehicle speed and wheel angle set-points from the Vehicle speed message and Status Message 5, which are described in the PVED-CLS Communication Protocol document. Scatter plotting wheel angle set-points vs. vehicle speed should yield a curve that can be mimicked with the AUX Wheel Angle Limitation function.

PVED-CLS AUX— closed loop gain

AUX Closed Loop Gain sets the gain used by the Closed Loop Joystick algorithm to a static value or to vary based on vehicle speed. See section 11.11 Closed Loop Joystick – Vehicle Speed Dependent Closed Loop Control in the User Manual for more information.

P3725: AUX joystick - CL gain @ Point A	50
P3726: AUX joystick - CL gain @ Point B	50
P3727: AUX joystick - CL gain @ Point C	50
P3728: AUX joystick - Vehicle speed @ Point B	15
P3729: AUX joystick - Vehicle speed @ Point C	25

Parameter	Conditions for value change
P3725	Set to desired closed loop gain [%] at 0 km/h
P3726	Set to desired closed loop gain (y-axis) at desired vehicle speed in hm/h (P3728)
P3727	Set to desired closed loop gain (y-axis) at desired vehicle speed in hm/h (P3729)
P3728	Set to desired vehicle speed in km/h (x-axis) at desired closed loop gain (P3726)
P3729	Set to desired vehicle speed in km/h (x-axis) at desired closed loop gain (P3727)

Tuning advice: keep gains constant and as high as possible without causing overshoot or instability.



P3730: AUX joystick - Max CL steady state error threshold	100 🗬
P3731: AUX joystick - Min time for CL steady state error threshold	50 🛋
P3732: AUX joystick - Max closed loop error for engaging closed loop joystick steering	100 🗭

Parameter	Conditions for value change
P3730	Max closed loop error [IR, 100=10%] allowed when switching device from AUX to Auto-guidance.
P3731	Minimum time [x10ms] where steady state threshold can't be exceeded to switch device from AUX to Auto-guidance.
P3732	Max closed loop error [IR, 100=10%] before closed loop joystick steering is enabled.

PVED-CLS AUX— open loop joystick transfer function

Open Loop Joystick transfer function scales the position of the open loop joystick to a requested flow.

—AUX- Open loop joystick —	
P3734: AUX joystick - Maximum deflection region offset	0
P3736: AUX joystick - Dead-band region	0
P3738: AUX joystick - Interpolation point X for open loop joystick transfer function	1000 🔍
P3740: AUX joystick - Interpolation point Y for open loop joystick transfer function	1000 🗭

Parameter	Conditions for value change
P3734-P3740	See Section 11.8 in the User Manual for more information



PVED-CLS GPS configuration

Navigate to the GPS configuration section via **System Navigator** > **Configuration** > **GPS Config**

These parameters only apply if GPS is enabled. GPS Flow Limitation is used with auto-guidance to restrict the maximum flow to steering cylinders as the vehicle speed increases. See Section 12.5 Vehicle Speed Dependent Flow Command Limitation in the User Manual for more info.

GPS Config

Upload parameters	New	Ne w values	
Download parameters	MAIN	SAFETY	
Flow limitation			
P3451: GPS - Max flow @ Point D	10	000	
P3453: GPS - Vehicle speed limiting flow @ Point E		15	
P3455: GPS - Max flow @ Point E		50 💌	
P3457: GPS - Vehicle speed limiting flow @ Point F		25	
P3459: GPS - Max flow @ Point F		25	

Parameter	Conditions for value change
P3451	Set to desired flow limit [IR, 1000=100%] at 0 km/h (see graph below)
P3453	Set to desired vehicle speed in km/h (x-axis) at desired flow limit (P3455)
P3455	Set to desired flow limit (y-axis) at desired vehicle speed in km/h (P3453)
P3457	Set to desired vehicle speed in km/h (x-axis) at desired flow limit (P3459)
P3459	Set to desired flow limit (y-axis) at desired vehicle speed in km/h (P3457)

There are three subsets of GPS tuning that will need configuring if GPS is enabled.

Approve the parameters by following the steps in *PVED-CLS parameter acceptance* on page 8.

PVED-CLS example of GPS flow limitation

— Flow limitation —	
P3451: GPS - Max flow @ Point D	1000 💭
P3453: GPS - Vehicle speed limiting flow @ Point E	25 💌
P3455: GPS - Max flow @ Point E	1000
P3457: GPS - Vehicle speed limiting flow @ Point F	45 💌
P3459: GPS - Max flow @ Point F	200





PVED-CLS GPS flow limitation—tuning advice

- 1. Remove flow limitation (1000 for all 3 flow limits) and drive the machine first slowly and then at increasing speeds.
- 2. On each trial, command full left or right.

Vehicle tipping hazard! Operate carefully to avoid tipping the vehicle.

If the machine does not feel stable steering that quickly at that speed, use the flow limitation to begin to decrease flow allowed at that speed.

3. Iterate until the auto-guidance can command full left or right at any speed and avoid tipping.

CAN logging can also be implemented to track vehicle speed and flow set-points from the Vehicle Speed message and Status Message 4, which are described in the PVED-CLS Communication Protocol document. Scatter plotting flow set-points vs. vehicle speed should yield a curve that shows the demands from the auto-guidance controller and that can be mimicked with the GPS Flow Limitation function.

PVED-CLS GPS— wheel angle limitation

GPS Wheel Angle Limitation decreases the allowed maximum wheel angle as the vehicle speed increases. See Section 12.3 Vehicle Speed Dependent Wheel Angle Limitation in the User Manual for more info.

— Wheel angle limitation —	
P3461: GPS - Max wheel angle @ Point G	35 💌
P3463: GPS - Vehicle speed limiting wheel angle @ Point H	15 🗭
P3465: GPS - Max w heel angle @ Point H	15 🗭
P3467: GPS - Vehicle speed limiting wheel angle @ Point I	25 💌
P3469: GPS - Max wheel angle @ Point I	10 💌

Parameter	Conditions for value change
P3461	Set to desired angle limit [deg] at 0 km/h (see graph below). Should be the same as max wheel angles in <i>Vehicle Geometry</i> .
P3463	Set to desired vehicle speed in km/h (x-axis) at desired wheel angle limit (P3465)
P3465	Set to desired wheel angle limit (y-axis) at desired vehicle speed in km/h (P3464)
P3467	Set to desired vehicle speed in km/h (x-axis) at desired wheel angle limit (P3469)
P3469	Set to desired wheel angle limit (y-axis) at desired vehicle speed in km/h (P3467)



Example of GPS wheel angle limitation

P3461: GPS - Max wheel angle @ Point G	45 💌
P3463: GPS - Vehicle speed limiting wheel angle @ Point H	15
P3465: GPS - Max wheel angle @ Point H	45 💌
P3467: GPS - Vehicle speed limiting wheel angle @ Point I	25 💌
P3469: GPS - Max wheel angle @ Point I	10 🗭



PVED-CLS GPS— wheel angle limitation tuning advice

- 1. Remove wheel angle limitation (raise all 3 wheel angle limits to maximum angle of vehicle), then steer full left or right with the steering wheel or auto-guidance controller and keep the wheel angle there.
- **2.** Slowly increase the speed of the machine while driving in a circle until the machine starts to feel tipsy or unsafe.

Vehicle tipping hazard! Operate carefully to avoid tipping the vehicle.

- 3. Use the wheel angle limitation to decrease the allowed wheel angle at that speed.
- 4. Iterate at faster speeds until an appropriate wheel angle limit is created for all vehicle speeds.

CAN logging can also be implemented to track vehicle speed and wheel angle set-points from the Status Messages while auto-guidance is engaged. Scatter plotting wheel angle set-points vs. vehicle speed should yield a curve that shows the demands from the auto-guidance controller and that can be mimicked with the GPS Wheel Angle Limitation function.



PVED-CLS GPS—vehicle speed dependent closed loop control

GPS Vehicle Speed Dependent Closed Loop Control sets the closed loop gain for the auto-guidance commands. There are 2 different sets of gain values, 1 for each possible auto-guidance device. It is best to keep the gain values static rather than vary them with speed.

— Gain —	
P3473: GPS - CL gain @ Point P	50 🗭
P3474: GPS - CL gain @ Point Q	50 💌
P3475: GPS - CL gain @ Point R	50 💌
P3476: GPS - CL gain @ Point S	50 🖉
P3477: GPS - CL gain @ Point T	50 🖉
P3478: GPS - CL gain @ Point U	50 🛋
P3479: GPS - Vehicle speed @ Point Q	30 💌
P3480: GPS - Vehicle speed @ Point R	31 🖉
P3481: GPS - Vehicle speed @ Point S	32 🛋
P3482: GPS - Vehicle speed @ Point T	33 🏔
P3483: GPS - Vehicle speed @ Point U	34

Condition for value change	
Set all Closed Loop gains to same desired value [%] unless speed dependent gain is desired. If that is the case then set desired gains for each point which corresponds with a vehicle speed below.	
If keeping all Closed Loop gains the same, these values can remain at defaults, otherwise match the desired vehicle speed [km/h] at each point corresponding to CL gains above.	
The vehicle speeds cannot be the same value or an EEPROM error will be triggered. Set the speeds so that they increase with increasing parameter number.	
S d lf s T	

P3484: It is highly recommended that Flow Command filter is left at the default setting.

P3496: GPS- Algorithm Type can be changed if desired. Please see Sections 12.2, 12.6 and 12.7 in the PVED-CLS User Manual for an overview of the benefits of both and how to set other parameters accordingly.

PVED-CLS GPS— CL control tuning advice

- **1.** Tuning Advice: Start with default gain.
- **2.** Using CAN logging, look at the curvature command and estimated curvature found respectively in the Guidance System Command and Guidance Machine Status messages described in the Communication Protocol.

If estimated curvature is taking too long to approach the commanded curvature, increase the gain.

If estimated curvature is overshooting the commanded curvature, decrease the gain.

The spool auto-calibration may also influence the auto-guidance performance.



Auto calibration configuration

Navigate to the Auto calibration configuration section via **System Navigator** > **Configuration** > **Auto Calibration Config**

PVED-CLS auto calibration— sensor

Sensor Calibration parameters can define a window of allowed neutral positions to be captured during Analog sensor and/or CAN WAS calibration, as well as a required voltage offset between captured neutral and left/right values.

These do not need to be changed for CLS to function.

Auto Calibration Config

Upload parameters	New values	
Download parameters	MAIN	SAFETY
— Sensor Calibration —		
P3791: Max allowable analogue sensor signal to be captured in neutral	450	
P3793: Min voltage needed in between the captured analogue sensor values		0
P3795: Min allowable analogue sensor signal to be captured in neutral	50	
P3841: Max allowable CAN WAS signal to be captured in neutral	450	0
P3843: Min voltage needed in between the captured CAN WAS values		0
P3845: Min allowable CAN WAS signal to be captured in neutral	50	0

PVED-CLS auto calibration— cylinder stroke and max steer angles

Automatically adjusted cylinder stroke and max steer angle values are used for vehicles where changing tires may affect the maximum steering angles (decreasing because larger wheels or duals may impact the vehicle if the same end-stops are used).

This is a set of parameters to map the voltage of the WAS to left/right cylinder stroke volume and max steer angle. These should be set by the OEM using the actual steering geometry to determine values. For more information on setting these parameters see Section 9.1.1 Automatic Adjustment of Maximum Steer Angles and Cylinder Stroke Volume in the User Manual.



Automatically adjusted cylinder stroke and max steer angle-values

P3815: Mapped cyl. str. vol. (steering left) at 33% VB	333 🔊
P3817: Mapped cyl. str. vol. (steering left) at 67% VB	667 A
P3819: Mapped cyl. str. vol. (steering left) at 100% VB	1000
P3821: Mapped VB for cyl. str. vol. (steering left)	2000 🕷
P3823: Mapped cyl. str. vol. (steering right) at 33% VB	333
P3825: Mapped cyl. str. vol. (steering right) at 67% VB	667 (
P3827: Mapped cyl. str. vol. (steering right) at 100% VB	1000 🔍
P3829: Mapped VB for cyl. str. vol. (steering right)	2000
P3831: Mapped max WA (steering left) at 33% VB	30 🕷
P3832: Mapped max WA (steering left) at 67% VB	60 (
P3833: Mapped max WA (steering left) at 100% VB	89 🔍
P3834: Mapped VB for max WA (steering left)	2000
P3836: Mapped max WA (steering right) at 33% VB	30 🔿
P3837: Mapped max WA (steering right) at 67% VB	60 (
P3838: Mapped max WA (steering right) at 100% VB	89 🔊
P3839: Mapped VB for max WA (steering right)	2000

PVED-CLS auto calibration— spool dead-band

If the parameter change is not described below, use the default values.

Spool Dead-band Calibration values set the behavior of the Auto Spool Calibration routine which finds the Closed Loop dead-band edges for the spool calibration.

See Section 9.4.1.1 in the User Manual for more detailed descriptions of the parameters.

Example parameter settings

300 🚔 P3797: Spool calibration - Max closed loop dead-band edge 0 P3799: Spool calibration - Min closed loop dead-band edge 20 P3801: Spool calibration - Activation timeout 125 P3802: Spool calibration - Initial spool position 25 P3804: Spool calibration - +/- turn range sweep 110 P3806: Spool calibration - Max time for acceptable CL dead-band edge 60 🚔 P3808: Spool calibration - Min time for acceptable CL dead-band edge 7 P3810: Spool calibration - Vector sample size 5 P3811: Spool calibration - Min valid samples 25 🗬 P3812: Spool calibration - +/- turn range sweep add-on 10 🗬 P3814: Spool calibration - Spool set-point increase/decrease step



Parameter	Conditions for value change
P3797	Set max value of captured Closed Loop Dead-Band edges [x10ym]
P3799	Set min value of captured Closed Loop Dead-Band edges [x10դm]
P3801	Time [sec] after turning the steering wheel before calibration can no longer be activated
P3802	Initial spool set-point [x10um] for calibration routine
P3804	Angle [0.1 deg] on both sides of neutral that wheels move through while being timed (see figure below)
P3806	Upper time limit [0.1 sec] for wheels to move through angle specified in P3804
P3808	Upper time limit [0.1 sec] for wheels to move through angle specified in P3804
P3810	Number of attempted spool set-points attempts kept in memory
P3811	Minimum number of spool set-point attempts that must match in memory to complete calibration



PVED-CLS auto calibration— spool dead-band tuning advice

- 1. During machine startup, use default Auto Spool Calibration parameters as described in the calibration section.
- 2. Manually adjust closed loop dead-band edges while tuning GPS steering.
- **3.** Change Auto Spool Calibration parameters to achieve similar closed loop dead-band edges under end-of-line conditions.
- **4.** Iterate on parameters until the Auto Spool Calibration can consistently achieve good GPS steering performance from end-of-line calibration.

The main parameters of interest are P3806 and P3808 which define the time limits for the wheels to turn through the turn range sweep set in P3804 (5 degrees by default). By increasing or decreasing the times, the closed loop dead-band edges will be smaller or larger (absolute value) respectively. By decreasing the gap between the values, the captured dead-band edges will be more consistent from machine to machine.



PVED-CLS advanced parameter setting

Read section 8 (pages 38-55) of the PLUS+1° Service Tool User Guide found in firmware release package under Service Tool to learn how to use the following pages:

- Parameter File Interface_OEM
- Parameter File Interface_VPS
- Clone PVED-CLS

These files are used to export and import parameter configurations.



Resolving safe-state mode by soft reset

If the PVED-CLS is in safe-state mode, it is possible that a soft reset will resolve the underlying issue.

1. Open the Mode switch page.

The Mode Switch page is used to change between Bootloader and Application modes. When a **Config** page is entered while in Normal View in the Service Tool, the PVED-CLS enters Bootloader mode. To return to Application mode go to the **Mode switch** page and press the "Go to application" button.

If the PVED-CLS is already in application mode (there is no red or yellow box around the Main and Safety states) the "Go to application" button does not need to be pressed.

Mode swit	ch	
Go to bootloader	Soft Reset	
Go to application		
	Contr	ollers
	MAIN	SAFETY
Application mode	STW program 1	STW program 1
Signal reception	n stopped, PVED-CLS may be in bootload	ler.

2. Press the "Soft Reset" button to reboot the PVED-CLS.

This may clear the Safe State if it was caused by exceeding a speed threshold or a temporarily missing message.

If the PVED-CLS remains in safe-state mode, proceed to the *Resolving safe-state mode with SPN and FMI codes* on page 42 section for further troubleshooting.



Resolving safe-state mode with SPN and FMI codes

In order to resolve safe-state mode with this method, SPN and FMI codes must be obtained and referred to in the User Manual. There are two ways to obtain SPN and FMI codes: through the error history pages or the error occurrence counter page.

SEHS error history

1. Go to System Navigator > Diagnostics > SEHS Error History_Main (or _Safety).

SEHS Error History(Main)

	Error Record 1	WAS CAN sensor	Firm Code 255	Spool Setpoint [0.1 mm]	Spool Position [0.1 mm]
	Error Record 2	WAS CAN sensor	Setpoint 0 [10 um]	1 0	1 0
->	Error Record 3	Demanded safe state	Demand Value 0 [10 um]	2 0	2 0
	Error Record 4	Reserved	Current Spool Position 0 [10 um]	3 0	3 0
	Error Record 5	Reserved	Battery Voltage 0.0 [V]	5 0	5 0
	Error Record 6	Reserved		6 0	6 0
	Error Record 7	Reserved	PCB Temperature 0 [deg C]	7 0	7 0
	Error Record 8	Reserved	Error Occurence 0	8 0	8 0
	Error Record 9	Reserved	Operating Time 0.0 [sec]	9 0	9 0
	Error Record 10	Reserved	Device state Unknown state	e	
	Error Record 11	Reserved	SPN 0	Reserved	
	Error Record 12	Reserved	FMI 32	Empty	
	Error Record 13	Reserved	Clear Error History		
	Error Record 14	Reserved			
	Error Record 15	Reserved			
	Error Record 16	Reserved			

The blue arrow shows the most recent error in the list.

After 16 errors are recorded, new errors are written over previous errors starting at Error Record 1.

- 2. Click the corresponding "Error Record" button to see more details on the error. This will display the Suspect Parameter Number (SPN) and the Failure Mode Identifier (FMI) of the error.
- **3.** Search the SPN in the User Manual and then look for the correct FMI to learn more about the error and find possible root causes.



PVED-CLS clear error history

Once all errors have been dealt with or it is desired to clear the history buffer.

Press the **Clear Error History** Button to clear all recorded errors in the controller's memory and press **OK** on the prompt. Each controller (Main and Safety) has its own error buffer.



Warning

Clearing the error history will erase all records of fault codes which are used for troubleshooting and for warranty purposes.

Ensure that all errors have been taken care of properly before clearing the error history.

SEHS error occurrence

The SEHS error occurrence page is the second method used to troubleshoot safe-mode in PVED-CLS.

Go to the SEHS error occurrence page via **System Navigator** > **Diagnostics** > **SEHS Error Occurrence Counter** to see the total number of each error that has occurred in both controllers.

This page can display more than the 16 errors in the error history of each controller to be displayed.

When the error history is cleared on the Main or Safety Error History pages, it clears the information in the SEHS Error Occurrence Counter as well.

SEHS Error Occurrence Counter

		Description				MAIN	SAFETY
	SPN		FMI	SPN	FMI	Error Occur	ence Counter
0	Software Initialization		Unknown root-cause	299005	11	0	0
1	Division by zero		Unknown root-cause	299004	11	0	0
2	Variable truncation		Unknown root-cause	299002	11	0	0
3	Interpolation		Unknown root-cause	298968	11	0	0
4	Vbat	Volta	ge above normal or short-circuit to high source	627	3	0	0
5	Vbat	Volt	age below normal or short-circuit to low source	627	4	0	0
6	+5V		Data erratic, intermittent or incorrect	520582	2	0	0
7	LVDT calculation		Data erratic, intermittent or incorrect	520583	2	0	0
8	Vref generation		Data erratic, intermittent or incorrect	520585	2	0	0
9	GND level	Volta	ge above normal or short-circuit to high source	520586	3	0	0
0	LVDT demod A		Data erratic, intermittent or incorrect	520588	2	0	0
1	LVDT demod B		Data erratic, intermittent or incorrect	520589	2	0	0
2	Soft error		Condition exists	520229	31	0	0
3	LVDT sinus signal	A	bnormal frequency or pulse width or period	520212	8	0	0
4	Safe ON-Road Monitoring		Stuck Closed	520206	30	0	3 🗙
5	Safe ON-Road Monitoring		Data erratic, intermittent or incorrect	520206	2	0	0
6	Safe ON-Road Monitoring		Message missing	520206	22	0	0
7	EEPROM STW config		Data erratic, intermittent or incorrect	520243	2	0	2 🗙
8	EEPROM STW config		Special instructions	520243	14	0	0
9	EEPROM AUX config		Data erratic, intermittent or incorrect	520244	2	0	0
20	Cut-off solenoid		Received network data in error	520210	19	0	0
1	Coil supply switch		Received network data in error	200022	10		



Signal reception stopped, PVED-CLS r

Troubleshooting

Status messages

Go to the status messages page via **System Navigator** > **Diagnostics** > **Status Messages** to view the contents of status messages.

Status Messages

	-	- Signal never received.		
		Controllers		
		MAIN	SAFETY	
	Operation Status Message			· ·
10 ms	Current Operation state	STW program 1	STW program 1	10 ms
100 ms	Lock-out status for steering device changes	Steering device changes allowed	Steering device changes allowed	100 ms
	Lock-out status for STW/AUX program	Program changes allowed	Program changes allowed	
	Lock-out status for EH-steering functionality	Information not available	Information not available	
	AUX Steering device lockout status	Information not available	Information not available	
	GPS receiver selection and lockout status	No GPS receiver selected	No GPS receiver selected	
	Service mode state	Information not available	Information not available	
	— Status Message 1 —			
Off	Requested spool position	0 [10	um] 0	Off
10	Actual spool position	1 [10	um] 1	10
TUMS	Data from the external analog input 1	0 [m		TUMS
100 ms	Data from the external analog input 2			100 ms

If a yellow or red box appears around any messages of interest, they are not currently being received or transmitted. Follow these sub-steps to resolve the issue:



a) Press the "10ms" or "100ms" buttons to request the messages be sent at the respective frequency.b) Press the "Off" button to request that the message stop sending.

Direct output control

Direct Output Control can be used to set the directional spool to a given set-point. This will send flow to the steering cylinders. Direct Output Control is therefore useful for verifying the hydraulic circuit is working, that the electronics can send flow, and for doing a rough spool calibration.

Go to the direct output control page via **System Navigator** > **Diagnostics** > **Direct Output Control**

Direct Output Control



Caution! Only for skilled personnel. The Controls on this service page can lead to sudden steering movements.

Goto Direct Output Control Mode	Controllers			
	MAIN	SAFETY		
Application mode	STW program 1	STW program 1		
Wheel Angle Sensor position	2000	IR] 2000		
Spool Position set point		0 🖨 [10um]		
	Request S Request Neu	Spool Position tral Spool Position		
	Request Co	ut-off valve On		
	Request Co	ut-off valve Off		

- a) Press the "Go to Direct Output Control Mode" button.
- b) Press the "Request Cut-off Valve On" button to enable the directional spool to move and flow to be sent to the steering cylinder.
- c) Enter a number into the Spool Position set point field. Negative numbers move the spool left and should steer the wheels left. Positive numbers move the spool right and should steer the wheels right
- d) Press the "Request Spool Position" button to make spool move to set point.
- e) Press the "Request Neutral Spool Position" button to make the spool move back to neutral.
- f) Press the "Request Cut-off Valve Off" button when finished with Direct Output Control Mode.



Danfoss

Products we offer:

- DCV directional control valves
- Electric converters
- Electric machines
- Electric motors
- Gear motors
- Gear pumps
- Hydrostatic motors
- Hydrostatic pumps
- Orbital motors
- PLUS+1[®] controllers
- PLUS+1[®] displays
- PLUS+1[®] joysticks and pedals
- PLUS+1[®] operator interfaces
- PLUS+1[®] sensors
- PLUS+1[®] software
- PLUS+1[®] software services, support and training
- Position controls and sensors
- PVG proportional valves
- Steering components and systems
- Telematics

Hydro-Gear

www.hydro-gear.com

Daikin-Sauer-Danfoss

www.daikin-sauer-danfoss.com

Danfoss Power Solutions is a global manufacturer and supplier of high-quality hydraulic and electric components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway market as well as the marine sector. Building on our extensive applications expertise, we work closely with you to ensure exceptional performance for a broad range of applications. We help you and other customers around the world speed up system development, reduce costs and bring vehicles and vessels to market faster.

Danfoss Power Solutions – your strongest partner in mobile hydraulics and mobile electrification.

Go to www.danfoss.com for further product information.

We offer you expert worldwide support for ensuring the best possible solutions for outstanding performance. And with an extensive network of Global Service Partners, we also provide you with comprehensive global service for all of our components.

Local address:

Danfoss Power Solutions (US) Company 2800 East 13th Street Ames, IA 50010, USA Phone: +1 515 239 6000 Danfoss Power Solutions GmbH & Co. OHG Krokamp 35 D-24539 Neumünster, Germany Phone: +49 4321 871 0 Danfoss Power Solutions ApS Nordborgvej 81 DK-6430 Nordborg, Denmark Phone: +45 7488 2222 Danfoss Power Solutions Trading (Shanghai) Co., Ltd. Building #22, No. 1000 Jin Hai Rd Jin Qiao, Pudong New District Shanghai, China 201206 Phone: +86 21 2080 6201

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.