

Operating Guide

ECL Comfort 210/296/310, application A275/A375



1.0 Table of Contents

1.0 Table of Contents	1	6.0 Common controller settings.....	145
1.1 Important safety and product information.....	2	6.1 Introduction to 'Common controller settings'	145
2.0 Installation	7	6.2 Time & Date.....	146
2.1 Before you start	7	6.3 Holiday	147
2.2 Identifying the system type.....	29	6.4 Input overview	149
2.3 Mounting	45	6.5 Log	150
2.4 Placing the temperature sensors.....	48	6.6 Output override.....	151
2.5 Electrical connections.....	50	6.7 Key functions.....	152
2.6 Inserting the ECL Application Key	59	6.8 System.....	154
2.7 Check list.....	66	7.0 Miscellaneous.....	161
2.8 Navigation, ECL Application Key A275	67	7.1 ECA 30 / 31 setup procedures	161
3.0 Daily use	79	7.2 Override function.....	169
3.1 How to navigate	79	7.3 Several controllers in the same system	172
3.2 Understanding the controller display	80	7.4 Frequently asked questions.....	175
3.3 A general overview: What do the symbols mean?	84	7.5 Definitions	179
3.4 Monitoring temperatures and system components	85	7.6 Type (ID 6001), overview	183
3.5 Influence overview	87	7.7 Automatic / manual update of firmware.....	184
3.6 Manual control	88	7.8 Parameter ID overview.....	185
3.7 Schedule	89		
4.0 Settings overview	90		
5.0 Settings.....	93		
5.1 Introduction to Settings	93		
5.2 Flow (boiler) temperature.....	94		
5.3 Tank temperature.....	98		
5.4 Room limit	101		
5.5 Return limit	103		
5.6 Optimization.....	108		
5.7 Boiler.....	114		
5.8 Control parameters.....	122		
5.9 Application	127		
5.10 Alarm	135		
5.11 Alarm overview	142		
5.12 Anti-bacteria.....	143		

Operating Guide ECL Comfort 210/296/310, application A275/A375

1.1 Important safety and product information

1.1.1 Important safety and product information

This Operating Guide is associated with ECL Application Key A275 (order code no. 087H3814).

The ECL application key A275 contains two sets of applications:

- A275 (subtypes A275.1, A275.2, A275.3)
- A375 (subtypes A375.1, A375.2, A375.3, A375.4, A375.5). A375 subtypes only run in ECL 310.

Subtypes A275.1, A275.2 and A275.3 are for 1-burner solutions.

Subtypes A375.1, A375.2 and A375.3 are for multiple burner solutions.

Subtypes A375.4 and A375.5 are for 1-burner solutions, inclusive 0 - 10 Volt control of burner temperature.

The functions can be realized in:

- ECL Comfort 210 (A275) for simple solutions or
- ECL Comfort 296 (A275) for simple solutions, but having advanced communication, such as M-bus, Modbus and Ethernet (Internet) communication or
- ECL Comfort 310 (A275 / A375) for advanced solutions, e.g. M-bus, Modbus and Ethernet (Internet) communication.

Flow or power limitation via M-bus is not used in A275 / A375.

The application A275 complies with ECL Comfort controller 210 and 310 as of software version 1.11 (visible at start-up of the controller and in 'Common controller settings' in 'System').

The Application Key A275 also complies with ECL Comfort 296 controllers as of firmware version 1.58.

Up to two Remote Control Units, ECA 30 or ECA 31, can be connected for remote monitoring and setting. The built-in room temperature sensor can be utilized.

ECL Portal, Internet based connection, allows ECL 296, 310 and 310B to be monitored and controlled remotely via standard Internet browsers (for example Internet Explorer, Google Chrome and Safari).

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

Additional documentation for ECL Comfort 210, 296 and 310 and accessories are available on <https://store.danfoss.com>.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Together with the ECL Comfort 310, the additional Internal I/O module ECA 32 (order code no. 087H3202) can be used for extra data communication to SCADA:

- Temperature, Pt 1000 (default)
- 0 - 10 volt signals
- Digital input

The set-up of input type can be done by means of the Danfoss Software "ECL Tool".

Navigation: Danfoss.com > Service and support > Downloads > Tools > Heating > ECL Tool.

The URL is:

<https://www.danfoss.com/en/service-and-support/downloads/>

The Internal I/O module ECA 32 is placed in the base part for ECL Comfort 310.

ECL Comfort 210 is available as:

- ECL Comfort 210, 230 volt a.c. (087H3020)
- ECL Comfort 210B, 230 volt a.c. (087H3030)

ECL Comfort 296 is available as:

- ECL Comfort 296, 230 volt a.c. (087H3000)

ECL Comfort 310 is available as:

- ECL Comfort 310, 230 volt a.c. (087H3040)
- ECL Comfort 310B, 230 volt a.c. (087H3050)
- ECL Comfort 310, 24 volt a.c. (087H3044)

The B-types have no display and dial. The B-types are operated by means of the Remote Control unit ECA 30 / 31:

- ECA 30 (087H3200)
- ECA 31 (087H3201)

Base parts for ECL Comfort:

- for ECL Comfort 210, 230 volt (087H3220)
- for ECL Comfort 296, 230 volt (087H3240)
- for ECL Comfort 310, 230 volt and 24 volt (087H3230)

Additional documentation for ECL Comfort 210, 296 and 310, modules and accessories is available on <http://heating.danfoss.com/> or <http://store.danfoss.com>.


Documentation for ECL Portal: See <http://ecl.portal.danfoss.com>.

A275 / A375 navigation in general:

A275.1 / A375.1 / A375.4	A275.2 / A375.2		A275.3 / A375.3 / A375.5		
Circuit	Circuit		Circuit		
1	1	2	1	2	3
					

Operating Guide ECL Comfort 210/296/310, application A275/A375

Burner control overview:



See the section 'Electrical connections' for more detailed information.




Application keys might be released before all display texts are translated. In this case the text is in English.



Automatic update of controller software (firmware):

The software of the controller is updated automatically when the key is inserted (as of controller version 1.11 (ECL 210 / 310) and version 1.58 (ECL 296)). The following animation will be shown when the software is being updated:



Progress bar

During update:

- Do not remove the KEY
If the key is removed before the hour-glass is shown, you have to start afresh.
- Do not disconnect the power
If the power is interrupted when the hour-glass is shown, the controller will not work.
- Manual update of controller software (firmware):
See the section "Automatic / manual update of firmware"



Safety Note

To avoid injury of persons and damages to the device, it is absolutely necessary to read and observe these instructions carefully.

Necessary assembly, start-up, and maintenance work must be performed by qualified and authorized personnel only.

Local legislations must be respected. This comprises also cable dimensions and type of isolation (double isolated at 230 V).

A fuse for the ECL Comfort installation is max. 10 A typically.

The ambient temperature ranges for ECL Comfort in operation are:

ECL Comfort 210 / 310: 0 - 55 °C

ECL Comfort 296: 0 - 45 °C.

Exceeding the temperature range can result in malfunctions.

Installation must be avoided if there is a risk for condensation (dew).

The warning sign is used to emphasize special conditions that should be taken into consideration.



This symbol indicates that this particular piece of information should be read with special attention.



As this Operating Guide covers several system types, special system settings will be marked with a system type. All system types are shown in the chapter: 'Identifying your system type'.



°C (degrees Celsius) is a measured temperature value whereas K (Kelvin) often is used for temperature differences.



The ID no. is unique for the selected parameter.

Example	First digit	Second digit	Last three digits
11174	1	1	174
	-	Circuit 1	Parameter no.
12174	1	2	174
	-	Circuit 2	Parameter no.

If an ID description is mentioned more than once, it means that there are special settings for one or more system types. It will be marked with the system type in question (e.g. 12174 - A266.9).



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.



Disposal Note

This symbol on the product indicates that it may not be disposed of as household waste.

It must be handed over to the applicable take-back scheme for the recycling of electrical and electronic equipment.

- Dispose of the product through channels provided for this purpose.
- Comply with all local and currently applicable laws and regulations.

Operating Guide ECL Comfort 210/296/310, application A275/A375

2.0 Installation

2.1 Before you start

The application **A275.1** is very flexible. These are the basic principles:

Heating (circuit 1):

Typically, the boiler temperature is adjusted according to your requirements. The boiler temperature sensor S3 is the most important sensor. It must be placed correctly in order to measure the boiler temperature. The desired boiler temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired boiler temperature. The boiler temperature is also the flow temperature in the direct connected heating circuit.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected in order to switch OFF the heating.

The burner is switched ON when the boiler temperature is lower than the desired boiler temperature and switched OFF when the boiler temperature is higher than the desired boiler temperature. A switching difference determines the ON / OFF control. Furthermore, the boiler protection function will only switch ON the circulation pump if the boiler temperature gets above a minimum temperature. A minimum ON-time can be set for the burner in order to increase the boiler's efficiency.


The return temperature (S5) to the boiler should not be too high (condensing boiler) or too low (oil or gas fired boiler). If so, the desired boiler temperature can be decreased or increased. Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.

If the measured room temperature (measured by S7 or the remote control unit ECA 30) does not equal the desired room temperature, the desired boiler temperature can be adjusted.

The circulation pump (P1) is ON at heat demand or at frost protection.

The heating can be switched OFF if the outdoor temperature gets higher than a set value.

Typical A275.1 application:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

- S1 Outdoor temperature sensor
- S3 (mandatory) Boiler temperature sensor
- S5 Return temperature sensor
- S7 Room temperature sensor / ECA 30
- P1 Circulation pump
- B1 Burner
- A1 Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

The application **A275.2** is very flexible. These are the basic principles:

Heating (circuit 1):

Typically, the boiler temperature is adjusted according to your requirements. The boiler temperature sensor S3 is the most important sensor. It must be placed correctly in order to measure the boiler temperature. The desired boiler temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired boiler temperature. The boiler temperature is also the flow temperature in the direct connected heating circuit.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected in order to switch OFF the heating.


The burner is switched ON when the boiler temperature is lower than the desired boiler temperature and switched OFF when the boiler temperature is higher than the desired boiler temperature. A switching difference determines the ON / OFF control. Furthermore, the boiler protection function will only switch ON the circulation pump if the boiler temperature gets above a minimum temperature. A minimum ON-time can be set for the burner in order to increase the boiler's efficiency.

The return temperature (S5) to the boiler should not be too high (condensing boiler) or too low (oil or gas fired boiler). If so, the desired boiler temperature can be decreased or increased. Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.

If the measured room temperature (measured by S7 or the remote control unit ECA 30) does not equal the desired room temperature, the desired boiler temperature can be adjusted.

The circulation pump (P1) is ON at heat demand or at frost protection.

The heating can be switched OFF if the outdoor temperature gets higher than a set value.



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

- S1 Outdoor temperature sensor
- S3 (mandatory) Boiler temperature sensor
- S5 Return temperature sensor
- S6 DHW tank temperature sensor
- S7 Room temperature sensor / ECA 30
- P1 Circulation pump, heating
- B1 Burner
- P3 DHW heating pump
- A1 Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A275.2, basic principles, continued:

DHW (circuit 2):

By means of a week schedule (up to 3 'Comfort' periods / day), the DHW circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for desired DHW temperature).

If the measured DHW temperature (S6) is lower than the desired DHW temperature, the DHW heating procedure starts:

- The circulation pump P1 in the heating circuit is switched OFF
- The DHW heating pump P3 is switched ON
- The desired boiler temperature at S3 is increased.


The desired boiler temperature is typically 10 -15 degrees higher than the desired DHW temperature.

When the measured DHW temperature (S6) gets higher than the desired DHW temperature, the DHW heating pump (P3) is switched OFF. Start and stop differences determine the ON / OFF control. A post-run time can be set.

An anti-bacteria function is available for activation on the selected days of the week.

The DHW heating has priority, i.e. pump P3 is ON and pump P1 is OFF. If the application has a changeover valve (priority valve) for the DHW heating, the circulation pump P1 is still ON during DHW heating.

Typical A275.2 application:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

- S1 Outdoor temperature sensor
- S3 (mandatory) Boiler temperature sensor
- S5 Return temperature sensor
- S6 DHW tank temperature sensor
- S7 Room temperature sensor / ECA 30
- P1 Circulation pump, heating
- B1 Burner
- P3 DHW heating pump
- A1 Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

The application **A275.3** is very flexible. These are the basic principles:

Heating (circuit 1):

Typically, the boiler temperature is adjusted according to your requirements. The boiler temperature sensor S3 is the most important sensor. It must be placed correctly in order to measure the boiler temperature. The desired boiler temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired boiler temperature. The boiler temperature is also the flow temperature in the direct connected heating circuit.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected in order to switch OFF the heating.

The burner is switched ON when the boiler temperature is lower than the desired boiler temperature and switched OFF when the boiler temperature is higher than the desired boiler temperature. A switching difference determines the ON / OFF control. Furthermore, the boiler protection function will only switch ON the circulation pump if the boiler temperature gets above a minimum temperature. A minimum ON-time can be set for the burner in order to increase the boiler's efficiency.


The return temperature (S5) to the boiler should not be too high (condensing boiler) or too low (oil or gas fired boiler). If so, the desired boiler temperature can be decreased or increased. Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.

If the measured room temperature (measured by S7 or the remote control unit ECA 30) does not equal the desired room temperature, the desired boiler temperature can be adjusted.

The circulation pump (P1) is ON at heat demand or at frost protection.

The heating can be switched OFF if the outdoor temperature gets higher than a set value.

Typical A275.3 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

- S1 Outdoor temperature sensor
- S2 Return temperature sensor, circuit 2
- S3 (mandatory) Boiler temperature sensor, circuit 1
- S4 Flow temperature sensor, circuit 2
- S5 Return temperature sensor, circuit 1
- S6 DHW tank temperature sensor
- S7 Room temperature sensor / ECA 30, circuit 1
- S8 Room temperature sensor / ECA 30, circuit 2
- M2 Motorized control valve, circuit 2
- P1 Circulation pump, circuit 1
- B1 Burner
- P3 DHW heating pump, circuit 3
- P4 Circulation pump, circuit 2



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A275.3, basic principles, continued:

Heating (circuit 2):

Typically, the flow temperature is adjusted according to your requirements. The flow temperature sensor S4 is the most important sensor. The desired flow temperature at S4 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired flow temperature.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected in order to switch OFF the heating.

The motorized control valve M2 is opened gradually when the flow temperature, S4, is lower than the desired flow temperature and vice versa.

The desired flow temperature at S4 will typically determine the desired boiler temperature (S3).

The return temperature (S2) can be limited. If so, the desired flow temperature at S4 can be decreased or increased.


Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.

If the measured room temperature (measured by S8 or the remote control unit ECA 30) does not equal the desired room temperature, the desired flow temperature can be adjusted.

The circulation pump (P4) is ON at heat demand or at frost protection.

The heating can be switched OFF when the outdoor temperature is higher than a selectable value or a DHW heating priority is present.

Typical A275.3 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

- S1 Outdoor temperature sensor
- S2 Return temperature sensor, circuit 2
- S3 (mandatory) Boiler temperature sensor, circuit 1
- S4 Flow temperature sensor, circuit 2
- S5 Return temperature sensor, circuit 1
- S6 DHW tank temperature sensor
- S7 Room temperature sensor / ECA 30, circuit 1
- S8 Room temperature sensor / ECA 30, circuit 2
- M2 Motorized control valve, circuit 2
- P1 Circulation pump, circuit 1
- B1 Burner
- P3 DHW heating pump, circuit 3
- P4 Circulation pump, circuit 2



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A275.3, basic principles, continued:

DHW (circuit 3):

By means of a week schedule (up to 3 'Comfort' periods / day), the DHW circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for desired DHW temperature).

If the measured DHW temperature (S6) is lower than the desired DHW temperature, the DHW heating procedure starts:

- The circulation pump P1 in the heating circuit is switched OFF
- The DHW heating pump P3 is switched ON
- The desired boiler temperature at S3 is increased.


The desired boiler temperature is typically 10 -15 degrees higher than the desired DHW temperature.

When the measured DHW temperature (S6) gets higher than the desired DHW temperature, the DHW heating pump (P3) is switched OFF. Start and stop differences determine the ON / OFF control. A post-run time can be set.

An anti-bacteria function is available for activation on the selected days of the week.

The DHW heating has priority, i.e. pump P3 is ON and pump P1 is OFF. If the application has a changeover valve (priority valve) for the DHW heating, the circulation pump P1 is still ON during DHW heating.

Typical A275.3 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

- S1 Outdoor temperature sensor
- S2 Return temperature sensor, circuit 2
- S3 (mandatory) Boiler temperature sensor, circuit 1
- S4 Flow temperature sensor, circuit 2
- S5 Return temperature sensor, circuit 1
- S6 DHW tank temperature sensor
- S7 Room temperature sensor / ECA 30, circuit 1
- S8 Room temperature sensor / ECA 30, circuit 2
- M2 Motorized control valve, circuit 2
- P1 Circulation pump, circuit 1
- B1 Burner
- P3 DHW heating pump, circuit 3
- P4 Circulation pump, circuit 2



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Application A275 in general:

Up to two Remote Control Units, ECA 30 / 31, can be connected to one ECL controller to control the ECL controller remotely.

Exercise of circulation pumps and control valve in periods without heating demand can be arranged.

Additional ECL Comfort controllers can be connected via the ECL 485 bus to utilize common outdoor temperature signal, time and date signals.

Several ECL controllers, internally connected via ECL 485 bus, work in Master / Slave connection. In a Master / Slave system maximum 2 ECA 30 / 31 can be present.

Unused input (from S7 and up) can, by means of an override switch, be used to override the schedule to a fixed 'Comfort' or 'Saving' mode.

Modbus communication (ECL 296 and ECL 310) to a SCADA system can be established.

ECL Portal, Internet based connection, allows ECL 296, 310 and 310B to be monitored and controlled remotely via standard Internet browsers (for example Internet Explorer, Google Chrome and Safari).

Heat-meters:

Up to 5 heat-meters can be connected to the M-bus terminals (ECL 296 / 310).

Data can be transferred to the SCADA system via Modbus and TCP / IP to the ECL Portal.

Modbus communication to a SCADA system can be established.

The M-bus data (ECL Comfort 296 / 310) can furthermore be transferred to the Modbus communication.

Alarm, A275.1 and A275.2:

Alarm A1 (relay R4) and the alarm symbol (🚨) can be activated:

- if a temperature sensor or its connection disconnects / shortcircuits.

Alarm, A275.3:

The alarm symbol (🚨) can be activated:

- if the actual flow temperature at S4 (heating circuit 2), differs from the desired flow temperature.
- if a temperature sensor or its connection disconnects / short-circuits.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Application A275 in general, continued:

Offset adjustment

A measured temperature can be offset adjusted, if needed.

(Navigation: MENU > Common controller > System > Sensor offset)

Input configuration

Inputs (as from S7 and up), which are not part of the application can be configured to be Pt 1000, 0 - 10 Volt, frequency (pulse counter) or digital input. This feature makes it possible in ECL 296 / 310 to communicate extra signals, such as temperatures, pressures, ON / OFF conditions, via Modbus and ECL Portal.

The configuration is done by means of the ECL Tool (free software for download) or directly in a dedicated menu in the ECL Portal or the connection for Modbus (BMS / SCADA).

Application upload

The application upload procedure is the following after having powered up the ECL Comfort controller:

1. Insert the application key
2. Select language, *1, *2
3. Select subtype (the Installation Guide shows subtypes)
4. Set Time and Date

The ECL Comfort controller installs the application, initializes and restarts. Output relays are activated / de-activated (click-sounds from this can be heard). This also means that, for example, circulation pumps can be switched ON and OFF shortly.

*1: See also section "Inserting the ECL Application Key".

*2: (ECL Comfort 310, 24 Volt) If language cannot be selected, the power supply is not a.c. (alternating current).

Commissioning

When the selected application has been uploaded the ECL Comfort controller starts in Manual mode. This can be used to verify correct connections of, for example, temperature, pressure and flow sensors. Also verifying the controlled components (valve actuators, pumps, burner etc.) for correct functionality can be done.

The application key is delivered with factory settings. Depending on system type, it might be necessary to change some factory settings individually for optimizing the functionality.

The application key must be inserted for changing settings.

Power-down / power-up

When the power supply to the ECL Comfort controller is disconnected (power-down), the output relays go to de-activated position.

This means that, for example, circulation pumps and burner can be switched ON.

See the electrical connection diagrams in the Installation Guide.

All relay contacts are shown in de-activated situation. Some relay contacts are closed, some relay contacts are open.

When the power supply to the ECL Comfort controller is re-established (power-up), the output relays are activated / de-activated (click-sounds from this can be heard). This also means that, for example, circulation pumps and burner can be switched ON and OFF shortly.

Important for A275.3:

- Set the correct running time "M run" of the Motorized Control Valve M2. (Circuit 2 > MENU > Settings > Control parameters > M run).



The controller is pre-programmed with factory settings that are shown in the 'Parameter ID overview' appendix.

Operating Guide ECL Comfort 210/296/310, application A275/A375

The application **A375.1** is very flexible. These are the basic principles:

The applications A375.1 / A375.2 / A375.3 can ON / OFF control up to 8 burner steps.

In application A375.1 the first 4 burner steps are controlled by relays in the ECL 310. The next, max. 4 burner steps, are controlled by relays in the extension module ECA 32 (placed in the base part of the ECL 310).

Heating (circuit 1):

Typically, the common boiler temperature is adjusted according to your requirements. The boiler temperature sensor S3 is the most important sensor. It must be placed correctly in order to measure the common boiler temperature. The desired boiler temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired boiler temperature. The boiler temperature is also the flow temperature in the direct connected heating circuit.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected in order to switch OFF the heating.

The first burner step is switched ON when the common boiler temperature is lower than the desired boiler temperature. The controller observes the common boiler temperature and switches ON the next burner step if the common boiler temperature does not increase satisfactorily. The switching OFF procedure of burner steps is vice versa. A switching difference determines the ON / OFF control.

The burners can be controlled in:

- fixed sequence (example: Always 1-2-3-4-5) or
- automatic rotating sequence (example: First period: 1-2-3-4-5, second period: 2-3-4-5-1, third period: 3-4-5-1-2 and so on)
- semi-automatic rotating sequence (example: First period: 1, 2-3-4-5, second period: 1, 3-4-5-2, third period: 1, 4-5-2-3 and so on)

Furthermore, the boiler protection function will switch ON the circulation pump when the boiler temperature gets above a minimum value. A minimum ON-time can be set for the burner in order to increase the boiler's efficiency.

The return temperature (S5) to the boiler should not be too high (condensing boiler) or too low (oil or gas fired boiler). If so, the desired boiler temperature can be decreased or increased. Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.


If the measured room temperature (S7 or Remote control unit ECA 30) does not equal the desired room temperature, the desired boiler temperature can be adjusted.

The circulation pump (P1) is ON at heat demand or at frost protection.

The heating can be switched OFF when the outdoor temperature is higher than a set value.

The desired common boiler temperature can, via S10, be controlled by means of an external voltage in the range 0-10 volt.

Typical A375.1 application:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with relay outputs
S1	Outdoor temperature sensor
S3	(mandatory) Common boiler temperature sensor
S5	Return temperature sensor
S7	Room temperature sensor / ECA 30
(S10)	(External temperature control, not illustrated)
P1	Circulation pump
B1-B8	Burner 1 ... 8
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.



Boiler sequence rotation / shift takes place at midnight.

Operating Guide ECL Comfort 210/296/310, application A275/A375

The application **A375.2** is very flexible. These are the basic principles:

The applications A375.1 / A375.2 / A375.3 can ON / OFF control up to 8 burner steps.

In application A375.2 the first 2 burner steps are controlled by relays in the ECL 310. The next, max. 4 burner steps, are controlled by relays in the extension module ECA 32 (placed in the base part of the ECL 310). The last, max. 2 burner steps are controlled by triacs in the ECL 310. Auxillary relays must be connected to the triacs.

Heating (circuit 1):

Typically, the common boiler temperature is adjusted according to your requirements. The boiler temperature sensor S3 is the most important sensor. It must be placed correctly in order to measure the common boiler temperature. The desired boiler temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired boiler temperature. The boiler temperature is also the flow temperature in the direct connected heating circuit.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected in order to switch OFF the heating.

The first burner step is switched ON when the common boiler temperature is lower than the desired boiler temperature. The controller observes the common boiler temperature and switches ON the next burner step if the common boiler temperature does not increase satisfactorily. The switching OFF procedure of burner steps is vice versa. A switching difference determines the ON / OFF control.

The burners can be controlled in:

- fixed sequence (example: Always 1-2-3-4-5) or
- automatic rotating sequence (example: First period: 1-2-3-4-5, second period: 2-3-4-5-1, third period: 3-4-5-1-2 and so on)
- semi-automatic rotating sequence (example: First period: 1, 2-3-4-5, second period: 1, 3-4-5-2, third period: 1, 4-5-2-3 and so on)

Furthermore, the boiler protection function will switch ON the circulation pump when the boiler temperature gets above a minimum value. A minimum ON-time can be set for the burner in order to increase the boiler's efficiency.

The return temperature (S5) to the boiler should not be too high (condensing boiler) or too low (oil or gas fired boiler). If so, the desired boiler temperature can be decreased or increased. Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.


If the measured room temperature (S7 or Remote control unit ECA 30) does not equal the desired room temperature, the desired boiler temperature can be adjusted.

The circulation pump (P1) is ON at heat demand or at frost protection.

The heating can be switched OFF when the outdoor temperature is higher than a set value.

The desired common boiler temperature can, via S10, be controlled by means of an external voltage in the range 0-10 volt.

Typical A375.2 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with relay outputs
S1	Outdoor temperature sensor
S3	(mandatory) Common boiler temperature sensor
S5	Return temperature sensor
S6	DHW tank temperature sensor
S7	Room temperature sensor / ECA 30
(S10)	(External temperature control, not illustrated)
P1	Circulation pump, heating
B1-B8	Burner 1 ... 8
P3	DHW heating pump
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.



Boiler sequence rotation / shift takes place at midnight.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A375.2, basic principles, continued:

DHW (circuit 2):

By means of a week schedule (up to 3 'Comfort' periods / day), the DHW circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for desired DHW temperature).

If the measured DHW temperature (S6) is lower than the desired DHW temperature, the DHW heating procedure starts:

- The circulation pump P1 in the heating circuit is switched OFF
- The DHW heating pump P3 is switched ON
- The desired boiler temperature at S3 is increased.

The desired boiler temperature is typically 10-15 degrees higher than the desired DHW temperature.


When the measured DHW temperature (S6) gets higher than the desired DHW temperature, the DHW heating pump (P3) is switched OFF. Start and stop differences determine the ON / OFF control. A post-run time can be set.

The DHW circulation pump (P4) has a week schedule for up to 3 ON periods per day.

An anti-bacteria function is available for activation on selected days of the week.

The DHW heating can have priority, i.e. pump P3 is ON and pump P1 is OFF. If the application has a changeover valve (priority valve) for the DHW heating, the circulation pump P1 is still ON during DHW heating.

Typical A375.2 application:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with relay outputs
S1	Outdoor temperature sensor
S3	(mandatory) Common boiler temperature sensor
S5	Return temperature sensor
S6	DHW tank temperature sensor
S7	Room temperature sensor / ECA 30
(S10)	(External temperature control, not illustrated)
P1	Circulation pump, heating
B1-B8	Burner 1 ... 8
P3	DHW heating pump
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

The application **A375.3** is very flexible. These are the basic principles:

The applications A375.1 / A375.2 / A375.3 can ON / OFF control up to 8 burner steps.

In application A375.3 the first 2 burner steps are controlled by relays in the ECL 310. The next, max. 4 burner steps, are controlled by relays in the extension module ECA 32 (placed in the base part of the ECL 310). The last, max. 2 burner steps are controlled by triacs in the ECL 310. Auxillary relays must be connected to the triacs.

Heating (circuit 1):

Typically, the common boiler temperature is adjusted according to your requirements. The boiler temperature sensor S3 is the most important sensor. It must be placed correctly in order to measure the common boiler temperature. The desired boiler temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired boiler temperature. The boiler temperature is also the flow temperature in the direct connected heating circuit.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected in order to switch OFF the heating.

The first burner step is switched ON when the common boiler temperature is lower than the desired boiler temperature. The controller observes the common boiler temperature and switches ON the next burner step if the common boiler temperature does not increase satisfactorily. The switching OFF procedure of burner steps is vice versa. A switching difference determines the ON / OFF control.

The burners can be controlled in:

- fixed sequence (example: Always 1-2-3-4-5) or
- automatic rotating sequence (example: First period: 1-2-3-4-5, second period: 2-3-4-5-1, third period: 3-4-5-1-2 and so on)
- semi-automatic rotating sequence (example: First period: 1, 2-3-4-5, second period: 1, 3-4-5-2, third period: 1, 4-5-2-3 and so on)

Furthermore, the boiler protection function will switch ON the circulation pump when the boiler temperature gets above a minimum value. A minimum ON-time can be set for the burner in order to increase the boiler's efficiency.

The return temperature (S5) to the boiler should not be too high (condensing boiler) or too low (oil or gas fired boiler). If so, the desired boiler temperature can be decreased or increased. Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.


If the measured room temperature (S7 or Remote control unit ECA 30) does not equal the desired room temperature, the desired boiler temperature can be adjusted.

The circulation pump (P1) is ON at heat demand or at frost protection.

The heating can be switched OFF when the outdoor temperature is higher than a set value.

The desired common boiler temperature can, via S10, be controlled by means of an external voltage in the range 0-10 volt.

Typical A375.3 application:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with relay outputs
S1	Outdoor temperature sensor
S2	Return temperature sensor, circuit 2
S3	(mandatory) Common boiler temperature sensor, circuit 1
S4	Flow temperature sensor, circuit 2
S5	Return temperature sensor, circuit 1
S7	Room temperature sensor / ECA 30, circuit 1
S8	Room temperature sensor / ECA 30, circuit 2
(S10)	(External temperature control, not illustrated)
M2	Motorized control valve, circuit 2
P1	Circulation pump, circuit 1
B1-B8	Burner 1 ... 8
P3	DHW heating pump, circuit 3
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.



Boiler sequence rotation / shift takes place at midnight.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A375.3, basic principles, continued:

Heating (circuit 2):

Typically, the flow temperature is adjusted according to your requirements. The flow temperature sensor S4 is the most important sensor. The desired flow temperature at S4 is calculated in the ECL controller, based on the outdoor temperature (S1). The lower the outdoor temperature, the higher the desired flow temperature.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected in order to switch OFF the heating.

The motorized control valve M2 is opened gradually when the flow temperature, S4, is lower than the desired flow temperature and vice versa.

The desired flow temperature at S4 will typically determine the desired boiler temperature (S3).

The return temperature (S2) can be limited. If so, the desired flow temperature at S4 can be decreased or increased.


Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.

If the measured room temperature (measured by S8 or the remote control unit ECA 30) does not equal the desired room temperature, the desired flow temperature can be adjusted.

The circulation pump (P4) is ON at heat demand or at frost protection.

The heating can be switched OFF when the outdoor temperature is higher than a selectable value or a DHW heating priority is present.

Typical A375.3 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with relay outputs
S1	Outdoor temperature sensor
S2	Return temperature sensor, circuit 2
S3	(mandatory) Common boiler temperature sensor, circuit 1
S4	Flow temperature sensor, circuit 2
S5	Return temperature sensor, circuit 1
S7	Room temperature sensor / ECA 30, circuit 1
S8	Room temperature sensor / ECA 30, circuit 2
(S10)	(External temperature control, not illustrated)
M2	Motorized control valve, circuit 2
P1	Circulation pump, circuit 1
B1-B8	Burner 1 ... 8
P3	DHW heating pump, circuit 3
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A375.3, basic principles, continued:

DHW (circuit 3):

By means of a week schedule (up to 3 'Comfort' periods / day), the DHW circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for desired DHW temperature).

If the measured DHW temperature (S6) is lower than the desired DHW temperature, the DHW heating procedure starts:

- The circulation pump P1 in the heating circuit is switched OFF
- The DHW heating pump P3 is switched ON
- The desired boiler temperature at S3 is increased.


The desired boiler temperature is typically 10-15 degrees higher than the desired DHW temperature.

When the measured DHW temperature (S6) gets higher than the desired DHW temperature, the DHW heating pump (P3) is switched OFF. Start and stop differences determine the ON / OFF control. A post-run time can be set.

An anti-bacteria function is available for activation on selected days of the week.

The DHW heating can have priority, i.e. pump P3 is ON and pump P1 is OFF. If the application has a changeover valve (priority valve) for the DHW heating, the circulation pump P1 is still ON during DHW heating.

Typical A375.3 application:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with relay outputs
S1	Outdoor temperature sensor
S2	Return temperature sensor, circuit 2
S3	(mandatory) Common boiler temperature sensor, circuit 1
S4	Flow temperature sensor, circuit 2
S5	Return temperature sensor, circuit 1
S7	Room temperature sensor / ECA 30, circuit 1
S8	Room temperature sensor / ECA 30, circuit 2
(S10)	(External temperature control, not illustrated)
M2	Motorized control valve, circuit 2
P1	Circulation pump, circuit 1
B1-B8	Burner 1 ... 8
P3	DHW heating pump, circuit 3
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

The application **A375.4** is very flexible. These are the basic principles:

Heating (circuit 1):

Typically, the boiler temperature is adjusted according to your requirements. The boiler temperature sensor S3 is the most important sensor. It must be placed correctly to measure the boiler temperature. The desired boiler temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired boiler temperature. The boiler temperature is also the flow temperature in the direct connected heating circuit.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected to switch OFF the heating.

The burner is, via relay output 2, switched ON when the boiler temperature is lower than the desired boiler temperature and switched OFF when the boiler temperature is higher than the desired boiler temperature. A switching difference determines the ON / OFF control.

Advanced boiler control:

1. A 0 - 10 Volt signal from the internal module ECA 32 can be applied to the boiler for setting the desired boiler temperature.
2. A 3-point signal, via M3, can be applied to the boiler for setting the desired boiler temperature. It is recommended to separate galvanically the ECL's M3 output from the boiler's 3-point input. Typically, this can be done by means of Solid-State relays.

See the Installation Guide for connections.

The boiler protection function will only switch ON the circulation pump if the boiler temperature gets above a minimum temperature. A minimum ON-time can be set for the burner to increase the boiler's efficiency.

The return temperature (S5) to the boiler should not be too high (condensing boiler) or too low (oil or gas fired boiler). If so, the desired boiler temperature can be decreased or increased.

Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature. If the measured room temperature (measured by S7 or the remote control unit ECA 30) does not equal the desired room temperature, the desired boiler temperature can be adjusted.


The circulation pump (P1) is ON at heat demand or at frost protection.

The heating can be switched OFF if the outdoor temperature gets higher than a set value.

A375.4 can also run the installations like A275.1, ex. a and ex. b. The difference between A375.4 and A275.1 is:

- A375.4 has advanced boiler control
- A375.4 can measure pressure via transmitter and generate alarm

Typical A375.4 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with analog outputs
S1	Outdoor temperature sensor
S3	(mandatory) Boiler temperature sensor
S5	Return temperature sensor
S7	Room temperature sensor / ECA 30
S9	Pressure sensor
P1	Circulation pump
B1	Burner, ON / OFF control
V1	Burner, 0 - 10 V temperature control
M3	(not illustrated) 3-point control of boiler temperature
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

The application **A375.5** is very flexible. These are the basic principles:

Heating (circuit 1):

Typically, the boiler temperature is adjusted according to your requirements. The boiler temperature sensor S3 is the most important sensor. It must be placed correctly to measure the boiler temperature. The desired boiler temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired boiler temperature. The boiler temperature is also the flow temperature in the direct connected heating circuit.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected to switch OFF the heating.

The burner is, via relay output 2, switched ON when the boiler temperature is lower than the desired boiler temperature and switched OFF when the boiler temperature is higher than the desired boiler temperature. A switching difference determines the ON / OFF control.

Advanced boiler control:

1. A 0 - 10 Volt signal from the internal module ECA 32 can be applied to the boiler for setting the desired boiler temperature.
2. A 3-point signal, via M3, can be applied to the boiler for setting the desired boiler temperature. It is recommended to separate galvanically the ECL's M3 output from the boiler's 3-point input. Typically, this can be done by means of Solid-State relays.

See the Installation Guide for connections.

The boiler protection function will only switch ON the circulation pump if the boiler temperature gets above a minimum temperature. A minimum ON-time can be set for the burner to increase the boiler's efficiency.

The return temperature (S5) to the boiler should not be too high (condensing boiler) or too low (oil or gas fired boiler). If so, the desired boiler temperature can be decreased or increased.


Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.

If the measured room temperature (measured by S7 or the remote control unit ECA 30) does not equal the desired room temperature, the desired boiler temperature can be adjusted.

The circulation pump (P1) is ON at heat demand or at frost protection.

The heating can be switched OFF if the outdoor temperature gets higher than a set value.

Typical A375.5 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system. All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with analog outputs
S1	Outdoor temperature sensor
S2	Return temperature sensor, circuit 2
S3	(mandatory) Boiler temperature sensor
S4	Flow temperature sensor, circuit 2
S5	Return temperature sensor
S6	DHW tank temperature sensor
S7	Room temperature sensor / ECA 30
S8	Room temperature sensor / ECA 30, circuit 2
S9	Pressure sensor
P1	Circulation pump
P3	DHW heating pump
P4	Circulation pump, circuit 2
P5	DHW circulation pump
B1	Burner, ON / OFF control
V1	Burner, 0 - 10 V temperature control
M2	Motorized control valve, circuit 2
M3	(not illustrated) 3-point control of boiler temperature
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A375.5, basic principles, continued:

Heating (circuit 2):

Typically, the flow temperature is adjusted according to your requirements. The flow temperature sensor S4 is the most important sensor. The desired flow temperature at S4 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired flow temperature.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). In 'Saving' mode a 'Total stop' function can be selected to switch OFF the heating.

The motorized control valve M2 is opened gradually when the flow temperature, S4, is lower than the desired flow temperature and vice versa.

The desired flow temperature at S4 will typically determine the desired boiler temperature (S3).

The return temperature (S2) can be limited. If so, the desired flow temperature at S4 can be decreased or increased.


Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature.

If the measured room temperature (measured by S8 or the remote control unit ECA 30) does not equal the desired room temperature, the desired flow temperature can be adjusted.

The circulation pump (P4) is ON at heat demand or at frost protection.

The heating can be switched OFF when the outdoor temperature is higher than a selectable value or a DHW heating priority is present.

Typical A375.5 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system. All named components are connected to the ECL Comfort controller.

List of components:

ECL 310	Electronic controller ECL Comfort 310
ECA 32	Internal extension module with analog outputs
S1	Outdoor temperature sensor
S2	Return temperature sensor, circuit 2
S3	(mandatory) Boiler temperature sensor
S4	Flow temperature sensor, circuit 2
S5	Return temperature sensor
S6	DHW tank temperature sensor
S7	Room temperature sensor / ECA 30
S8	Room temperature sensor / ECA 30, circuit 2
S9	Pressure sensor
P1	Circulation pump
P3	DHW heating pump
P4	Circulation pump, circuit 2
P5	DHW circulation pump
B1	Burner, ON / OFF control
V1	Burner, 0 - 10 V temperature control
M2	Motorized control valve, circuit 2
M3	(not illustrated) 3-point control of boiler temperature
A1	Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A375.5, basic principles, continued:

DHW (circuit 3):

By means of a week schedule (up to 3 'Comfort' periods / day), the DHW circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for desired DHW temperature).

If the measured DHW temperature (S6) is lower than the desired DHW temperature, the DHW heating procedure starts:

- The circulation pump P1 in the heating circuit is switched OFF
- The DHW heating pump P3 is switched ON
- The desired boiler temperature at S3 is increased.

The desired boiler temperature is typically 10 -15 degrees higher than the desired DHW temperature.

When the measured DHW temperature (S6) gets higher than the desired DHW temperature, the DHW heating pump (P3) is switched OFF. Start and stop differences determine the ON / OFF control. A post-run time can be set.

An anti-bacteria function is available for activation on the selected days of the week.


The DHW heating has priority, i.e. pump P3 is ON and pump P1 is OFF. If the application has a changeover valve (priority valve) for the DHW heating, the circulation pump P1 is still ON during DHW heating.

A375.5 can also run the installations like A275.3, ex. a. - A275.3, ex. g.

The differences between A375.5 and A275.3 are:

- A375.5 has advanced boiler control
- A375.5 has alarm output (A1)
- A375.4 can measure pressure via transmitter and generate alarm

Typical A375.5 application:



* Pressure relief valve



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system. All named components are connected to the ECL Comfort controller.

List of components:

ECL 310 Electronic controller ECL Comfort 310

ECA 32 Internal extension module with analog outputs

S1 Outdoor temperature sensor

S2 Return temperature sensor, circuit 2

S3 (mandatory) Boiler temperature sensor

S4 Flow temperature sensor, circuit 2

S5 Return temperature sensor

S6 DHW tank temperature sensor

S7 Room temperature sensor / ECA 30

S8 Room temperature sensor / ECA 30, circuit 2

S9 Pressure sensor

P1 Circulation pump

P3 DHW heating pump

P4 Circulation pump, circuit 2

P5 DHW circulation pump

B1 Burner, ON / OFF control

V1 Burner, 0 - 10 V temperature control

M2 Motorized control valve, circuit 2

M3 (not illustrated) 3-point control of boiler temperature

A1 Alarm



The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Application A375 in general:

Up to two Remote Control Units, ECA 30 / 31, can be connected to one ECL controller to control the ECL controller remotely.

Exercise of circulation pumps and control valve in periods without heating demand can be arranged.

Additional ECL Comfort controllers can be connected via the ECL 485 bus to utilize common outdoor temperature signal, time and date signals.

Several ECL controllers, internally connected via ECL 485 bus, work in Master / Slave connection. In a Master / Slave system maximum 2 ECA 30 / 31 can be present.

Unused input (from S7 and up) can, by means of an override switch, be used to override the schedule to a fixed 'Comfort' or 'Saving' mode.

Modbus communication (ECL 296 and ECL 310) to a SCADA system can be established.

ECL Portal, Internet based connection, allows ECL 296, 310 and 310B to be monitored and controlled remotely via standard Internet browsers (for example Internet Explorer, Google Chrome and Safari).

Heat-meters:

Up to 5 heat-meters can be connected to the M-bus terminals (ECL 296 / 310).

Data can be transferred to the SCADA system via Modbus and TCP / IP to the ECL Portal.

Modbus communication to a SCADA system can be established.

The M-bus data (ECL Comfort 296 / 310) can furthermore be transferred to the Modbus communication.

Alarm, A375:

Alarm A1 (relay R6) and the alarm symbol (🔔) can be activated:

- if a temperature sensor or its connection disconnects / shortcircuits.

Alarm, A375.3 and A375.5:

Alarm A1 (relay R6) and the alarm symbol (🔔) can be activated:

- if the actual flow temperature at S4 (heating circuit 2), differs from the desired flow temperature.

Alarm, A375.4, A375.5:

Alarm A1 (relay R6) and the alarm symbol (🔔) can be activated:

- if the pressure, measured by S9, gets higher or lower than set alarm values.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Application A375 in general, continued:

Offset adjustment

A measured temperature can be offset adjusted, if needed.

(Navigation: MENU > Common controller > System > Sensor offset)

Input configuration

Inputs (as from S7 and up), which are not part of the application can be configured to be Pt 1000, 0 - 10 Volt, frequency (pulse counter) or digital input. This feature makes it possible in ECL 296 / 310 to communicate extra signals, such as temperatures, pressures, ON / OFF conditions, via Modbus and ECL Portal.

The configuration is done by means of the ECL Tool (free software for download) or directly in a dedicated menu in the ECL Portal or the connection for Modbus (BMS / SCADA).

Application upload

The application upload procedure is the following after having powered up the ECL Comfort controller:

1. Insert the application key
2. Select language, *1, *2
3. Select subtype (the Installation Guide shows subtypes)
4. Set Time and Date

The ECL Comfort controller installs the application, initializes and restarts. Output relays are activated / de-activated (click-sounds from this can be heard). This also means that, for example, circulation pumps can be switched ON and OFF shortly.

*1: See also section "Inserting the ECL Application Key".

*2: (ECL Comfort 310, 24 Volt) If language cannot be selected, the power supply is not a.c. (alternating current).

Commissioning

When the selected application has been uploaded the ECL Comfort controller starts in Manual mode. This can be used to verify correct connections of, for example, temperature, pressure and flow sensors. Also verifying the controlled components (valve actuators, pumps, burner etc.) for correct functionality can be done.

The application key is delivered with factory settings.

Depending on system type, it might be necessary to change some factory settings individually for optimizing the functionality.

The application key must be inserted for changing settings.

Power-down / power-up

When the power supply to the ECL Comfort controller is disconnected (power-down), the output relays go to de-activated position.

This means that, for example, circulation pumps and burner can be switched ON.

See the electrical connection diagrams in the Installation Guide.

All relay contacts are shown in de-activated situation. Some relay contacts are closed, some relay contacts are open.

When the power supply to the ECL Comfort controller is re-established (power-up), the output relays are activated / de-activated (click-sounds from this can be heard). This also means that, for example, circulation pumps and burner can be switched ON and OFF shortly.

Important for A375.3 and A375.5:

- Set the correct running time "M run" of the Motorized Control Valve M2. (Circuit 2 > MENU > Settings > Control parameters > M run).



The controller is pre-programmed with factory settings that are shown in the 'Parameter ID overview' appendix.


Operating Guide ECL Comfort 210/296/310, application A275/A375

2.2 Identifying the system type

Sketch your application

The ECL Comfort controller series is designed for a wide range of heating, domestic hot-water (DHW) and cooling systems with different configurations and capacities. If your system differs from the diagrams shown here, you may want to make a sketch of the system about to be installed. This makes it easier to use the Operating Guide, which will guide you step-by-step from installation to final adjustments before the end-user takes over.

The ECL Comfort controller is a universal controller that can be used for various systems. Based on the shown standard systems, it is possible to configure additional systems. In this chapter you find the most frequently used systems. If your system is not quite as shown below, find the diagram which has the best resemblance with your system and make your own combinations.



See the Installation Guide (delivered with the application key) for application types / sub-types.



The circulation pump(s) in heating circuit(s) can be placed in the flow as well as the return. Place the pump according to the manufacturer's specification.

Operating Guide ECL Comfort 210/296/310, application A275/A375

A275 applications:

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.1, example a

Boiler ON / OFF control for a heating circuit.

The component marked with * is a pressure relief valve.

A275.1, example b

Boiler ON / OFF control for a heating circuit. The boiler circuit is equipped with a low loss header.

The component marked with * is a pressure relief valve.

A275.2, example a

Boiler ON / OFF control for a heating and a DHW circuit. Optional DHW priority.

The component marked with * is a pressure relief valve.

At DHW heating P3 is switched ON and the desired boiler temperature lies a number of degrees above the desired DHW temperature. P1 is switched OFF.



Special settings for type A275.2, example a:

Navigation:	ID no.:	Recommended setting:
-------------	---------	----------------------

DHW circuit (circuit 2)

DHW heating is managed by pump P3:

MENU \ Settings \ Application: 'Ch.-o. valve / P'	12051	ON
---	-------	----

The desired DHW heating temperature must influence the desired boiler temperature:

MENU \ Settings \ Application: 'Tank, sec./prim.'	12053	OFF
---	-------	-----

Please note:

If 'Ch.-o. valve / P' in 12051 is set to OFF, P3 will be switched on at DHW heating. The desired boiler temperature will still lie a number of degrees above the desired DHW temperature and P1 will remain switched ON.

A275.2, example b

Boiler ON / OFF control for a heating and a DHW circuit. DHW priority.

The component marked with * is a pressure relief valve.

At DHW heating P3 (changeover valve) is activated and the desired boiler temperature lies a number of degrees above the desired DHW temperature.

P1 is continuously switched ON.



Special settings for type A275.2, example b:

Navigation:	ID no.:	Recommended setting:
-------------	---------	----------------------

DHW circuit (circuit 2)

DHW heating is managed by changeover valve P3 / M1:

MENU \ Settings \ Application: 'Ch.-o. valve / P'	12051	OFF
---	-------	-----

The desired DHW heating temperature must influence the desired boiler temperature:

MENU \ Settings \ Application: 'Tank, sec./prim.'	12053	OFF
---	-------	-----

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.2, example c

Boiler ON / OFF control for a heating and a DHW circuit. Optional DHW priority. The boiler circuit is equipped with a low loss header. The component marked with * is a pressure relief valve.

The pump in the boiler circuit is not controlled.

At DHW heating P3 is switched ON and the desired boiler temperature lies a number of degrees above the desired DHW temperature. P1 is switched OFF.



Special settings for type A275.2, example c:

Navigation:	ID no.:	Recommended setting:
-------------	---------	----------------------

DHW circuit (circuit 2)

DHW heating is managed by pump P3:

MENU \ Settings \ Application: 'Ch.-o. valve / P'	12051	ON
---	-------	----

The desired DHW heating temperature must influence the desired boiler temperature:

MENU \ Settings \ Application: 'Tank, sec./prim.'	12053	OFF
---	-------	-----

Please note:

If 'Ch.-o. valve / P' in 12051 is set to OFF, P3 will be switched on at DHW heating. The desired boiler temperature will still lie a number of degrees above the desired DHW temperature and P1 remain switched ON.

A275.2, example d

Boiler ON / OFF control for a heating and a DHW circuit. DHW priority. The boiler circuit is equipped with a low loss header. The component marked with * is a pressure relief valve.

The pump in the boiler circuit is not controlled.

At DHW heating P3 (changeover valve) is activated and the desired boiler temperature lies a number of degrees above the desired DHW temperature.

P1 is switched ON.



Special settings for type A275.2, example d:

Navigation:	ID no.:	Recommended setting:
-------------	---------	----------------------

DHW circuit (circuit 2)

DHW heating is managed by changeover valve P3 / M1:

MENU \ Settings \ Application: 'Ch.-o. valve / P'	12051	OFF
---	-------	-----

The desired DHW heating temperature must influence the desired boiler temperature:

MENU \ Settings \ Application: 'Tank, sec./prim.'	12053	OFF
---	-------	-----

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.3, example a

Boiler ON / OFF control for a direct heating circuit (1), a mixing circuit (2) and a DHW circuit (3). Optional DHW priority. The component marked with * is a pressure relief valve.

Heating circuit 2 can alternatively be a floor heating circuit.

At DHW heating P3 is switched ON and the desired boiler temperature lies a number of degrees above the desired DHW temperature. P1 is switched OFF. Heating circuit 2 can be closed during DHW heating.



Special settings for type A275.3, example a:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Circuit 1 must be able to receive a heat demand (desired flow temperature) from circuit 2:		
MENU \ Settings \ Application: 'Demand offset'	11017	3 K**
** This value is added to the heat demand value from circuit 2		
Heating circuit (circuit 2)		
Circuit 2 must be able to send a heat demand (desired flow temperature) to circuit 1:		
MENU \ Settings \ Application: 'Send desired T'	12500	ON
Circuit 2 can be closed during the DHW heating process:		
MENU \ Settings \ Application: 'DHW priority'	12052	***
*** Set 'OFF' when not to be closed, set 'ON' when to be closed		
DHW circuit (circuit 3)		
DHW heating is managed by pump P3:		
MENU \ Settings \ Application: 'Ch.-o. valve / P'	13051	ON
The desired DHW heating temperature must influence the boiler temperature:		
MENU \ Settings \ Application: 'Tank, sec./prim.'	13053	OFF

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.3, example b

Boiler ON / OFF control for a direct heating circuit (1), a mixing circuit (2) and a DHW circuit (3). Partly DHW priority.
The component marked with * is a pressure relief valve.

Heating circuit 2 can alternatively be a floor heating circuit.

At DHW heating P3 (changeover valve) is activated and the desired boiler temperature is a number of degrees above the desired DHW temperature.

P1 is continuously switched ON.

Heating circuit 2 can be closed during DHW heating.



Special settings for type A275.3, example b:

Navigation:

ID no.:

Recommended setting:

Heating circuit (circuit 1)

Circuit 1 must be able to receive a heat demand (desired flow temperature) from circuit 2:

MENU \ Settings \ Application: 'Demand offset'

11017

3 K**

** This value is added to the heat demand value from circuit 2

Heating circuit (circuit 2)

Circuit 2 must be able to send a heat demand (desired flow temperature) to circuit 1:

MENU \ Settings \ Application: 'Send desired T'

12500

ON

Circuit 2 can be closed during the DHW heating process:

MENU \ Settings \ Application: 'DHW priority'

12052

*** Set 'OFF' when not to be closed, set 'ON' when to be closed

DHW circuit (circuit 3)

DHW heating is managed by changeover valve P3 / M1:

MENU \ Settings \ Application: 'Ch.-o. valve / P'

13051

OFF

The desired DHW heating temperature must influence the boiler temperature:

MENU \ Settings \ Application: 'Tank, sec./prim.'

13053

OFF

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.3, example c

Boiler ON / OFF control for a direct heating circuit (1), a mixing circuit (2) and a DHW circuit (3). DHW priority.
The component marked with * is a pressure relief valve.

Heating circuit 2 can alternatively be a floor heating circuit.

At DHW heating, P3 (changeover valve) is activated and the desired boiler temperature is a number of degrees above the desired DHW temperature.

P1 is continuously switched ON.

Heating circuit 2 is closed during DHW heating.



Special settings for type A275.3, example c:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Circuit 1 must be able to receive a heat demand (desired flow temperature) from circuit 2:		
MENU \ Settings \ Application: 'Demand offset'	11017	3 K**
** This value is added to the heat demand value from circuit 2		
Heating circuit (circuit 2)		
Circuit 2 must be able to send a heat demand (desired flow temperature) to circuit 1:		
MENU \ Settings \ Application: 'Send desired T'	12500	ON
Circuit 2 must be closed during the DHW heating process:		
MENU \ Settings \ Application: 'DHW priority'	12052	ON
DHW circuit (circuit 3)		
DHW heating is managed by changeover valve P3 / M1:		
MENU \ Settings \ Application: 'Ch.-o. valve / P'	13051	OFF
The desired DHW heating temperature must influence the boiler temperature:		
MENU \ Settings \ Application: 'Tank, sec./prim.'	13053	OFF

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.3, example d

Boiler ON / OFF control for a direct heating circuit (1), a mixing circuit (2) and a DHW circuit (3). Optional DHW priority. The mixing circuit (2) is controlled by means of a 4-port mixing valve

The component marked with * is a pressure relief valve.

Heating circuit 2 can alternatively be a floor heating circuit.

At DHW heating P3 is switched ON and the desired boiler temperature is a number of degrees above the desired DHW temperature.

P1 is switched OFF.

Heating circuit 2 can be closed during DHW heating.



Special settings for type A275.3, example d:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Circuit 1 must be able to receive a heat demand (desired flow temperature) from circuit 2:		
MENU \ Settings \ Application: 'Demand offset'	11017	3 K**
** This value is added to the heat demand value from circuit 2		
Heating circuit (circuit 2)		
Circuit 2 must be able to send a heat demand (desired flow temperature) to circuit 1:		
MENU \ Settings \ Application: 'Send desired T'	12500	ON
Circuit 2 can be closed during the DHW heating process:		
MENU \ Settings \ Application: 'DHW priority'	12052	***
*** Set 'OFF' when not to be closed, set 'ON' when to be closed		
DHW circuit (circuit 3)		
DHW heating is managed by pump P3:		
MENU \ Settings \ Application: 'Ch.-o. valve / P'	13051	ON
The desired DHW heating temperature must influence the boiler temperature:		
MENU \ Settings \ Application: 'Tank, sec./prim.'	13053	OFF

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.3, example e

Boiler ON / OFF control for a direct heating circuit (1), a mixing circuit (2) and a DHW circuit (3). Optional DHW priority. The boiler circuit is equipped with a low loss header.

The component marked with * is a pressure relief valve.

The pump in the boiler circuit is not controlled. Heating circuit 2 can alternatively be a floor heating circuit.

At DHW heating P3 is switched ON and the desired boiler temperature lies a number of degrees above the desired DHW temperature.

P1 is switched OFF. Heating circuit 2 can be closed during DHW heating.



Special settings for type A275.3, example e:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Circuit 1 must be able to receive a heat demand (desired flow temperature) from circuit 2:		
MENU \ Settings \ Application: 'Demand offset'	11017	3 K**
** This value is added to the heat demand value from circuit 2		
Heating circuit (circuit 2)		
Circuit 2 must be able to send a heat demand (desired flow temperature) to circuit 1:		
MENU \ Settings \ Application: 'Send desired T'	12500	ON
Circuit 2 can be closed during the DHW heating process:		
MENU \ Settings \ Application: 'DHW priority'	12052	***
*** Set 'OFF' when not to be closed, set 'ON' when to be closed		
DHW circuit (circuit 3)		
DHW heating is managed by pump P3:		
MENU \ Settings \ Application: 'Ch.-o. valve / P'	13051	ON
The desired DHW heating temperature must influence the boiler temperature:		
MENU \ Settings \ Application: 'Tank, sec./prim.'	13053	OFF

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.3, example f

Boiler ON / OFF control, a mixing circuit control and a DHW circuit control. Optional DHW priority.
The component marked with * is a pressure relief valve.

At DHW heating P3 is switched ON and the desired boiler temperature lies a number of degrees above the desired DHW temperature.
Heating circuit 2 can be closed during DHW heating.



Special settings for type A275.3, example f:

Navigation:	ID no.:	Recommended setting:
Boiler circuit (circuit 1)		
Circuit 1 must be able to receive a heat demand (desired flow temperature) from circuit 2:		
MENU \ Settings \ Application: 'Demand offset'	11017	3 K**
** This value is added to the heat demand value from circuit 2		
Heating circuit (circuit 2)		
Circuit 2 must be able to send a heat demand (desired flow temperature) to circuit 1:		
MENU \ Settings \ Application: 'Send desired T'	12500	ON
Circuit 2 can be closed during the DHW heating process:		
MENU \ Settings \ Application: 'DHW priority'	12052	***
*** Set 'OFF' when not to be closed, set 'ON' when to be closed		
DHW circuit (circuit 3)		
DHW heating is managed by pump P3:		
MENU \ Settings \ Application: 'Ch.-o. valve / P'	13051	ON
The desired DHW heating temperature must influence the boiler temperature:		
MENU \ Settings \ Application: 'Tank, sec./prim.'	13053	OFF

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A275.3, example g

Boiler ON / OFF control for a direct heating circuit (1) and a mixing circuit (2).

The component marked with * is a pressure relief valve.

Heating circuit 2 can alternatively be a floor heating circuit.



Special settings for type A275.3, example g:

Navigation:

ID no.:

Recommended setting:

Heating circuit (circuit 1)

Circuit 1 must be able to receive a heat demand (desired flow temperature) from circuit 2:

MENU \ Settings \ Application: 'Demand offset'

11017

3 K**

** This value is added to the heat demand value from circuit 2

Heating circuit (circuit 2)

Circuit 2 must be able to send a heat demand (desired flow temperature) to circuit 1:

MENU \ Settings \ Application: 'Send desired T'

12500

ON

Operating Guide ECL Comfort 210/296/310, application A275/A375

A375 applications:

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A375.1, example a

One boiler with 2 x burner ON / OFF control for a heating circuit.

The component marked with * is a pressure relief valve.

Fixed sequence: Burner 1 must be switched ON before burner 2 can be switched ON.

Burner 1 is active at low heat demand. At increased heat demand burner 2 is activated additionally.

The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example a:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Sequence type (code) for controlling the burners:		
MENU \ Settings \ Boiler: 'Sequence type'	11072	3
Number of total burner steps:		
MENU \ Settings \ Boiler: 'Steps'	11073	2

A375.1, example b

2 x boiler ON / OFF control for a heating circuit.

The component marked with * is a pressure relief valve.

Rotating sequence: Burner 1 is active before burner 2. Next day burner 2 is active before burner 1.

One burner step is active at low heat demand. At increased heat demand, the next burner step is activated additionally.

The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example b:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Sequence type (code) for controlling the burners:		
MENU \ Settings \ Boiler: 'Sequence type'	11072	0
Number of total burner steps:		
MENU \ Settings \ Boiler: 'Steps'	11073	2

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A375.1, example c

One boiler with 2 x burner ON / OFF control for a heating circuit. The boiler circuit is equipped with a low loss header. The component marked with * is a pressure relief valve.

The pump in the boiler is not controlled.

Fixed sequence: Burner 1 must be switched ON before burner 2 can be switched ON.

Burner 1 is active at low heat demand. At increased heat demand burner 2 is activated additionally.

The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example c:

Navigation:	ID no.:	Recommended setting:
-------------	---------	----------------------

Heating circuit (circuit 1)

Sequence type (code) for controlling the burners:

MENU \ Settings \ Boiler: 'Sequence type'	11072	3
---	-------	---

Number of total burner steps:

MENU \ Settings \ Boiler: 'Steps'	11073	2
-----------------------------------	-------	---

A375.1, example d

2 x boiler ON / OFF control for a heating circuit. The boiler circuit is equipped with a low loss header.

The component marked with * is a pressure relief valve.

The pumps in the boilers are not controlled.

Rotating sequence: Burner 1 is active before burner 2. Next day burner 2 is active before burner 1.

One burner step is active at low heat demand. At increased heat demand the next burner step is activated additionally.

The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example d:

Navigation:	ID no.:	Recommended setting:
-------------	---------	----------------------

Heating circuit (circuit 1)

Sequence type (code) for controlling the burners:

MENU \ Settings \ Boiler: 'Sequence type'	11072	0
---	-------	---

Number of total burner steps:

MENU \ Settings \ Boiler: 'Steps'	11073	2
-----------------------------------	-------	---

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A375.1, example e

Two boilers with 2 x burner ON / OFF control for a heating circuit.
The component marked with * is a pressure relief valve.

Fixed sequence for each boiler: Burner 1 (3) must be switched ON before burner 2 (4) can be switched ON.
Rotating sequence for the boilers: Boiler 1 is active before boiler 2. Next day boiler 2 is active before boiler 1.
Burner steps are activated according to heat demand.
The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example e:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Sequence type (code) for controlling the burners:		
MENU \ Settings \ Boiler: 'Sequence type'	11072	4
Number of total burner steps:		
MENU \ Settings \ Boiler: 'Steps'	11073	4

A375.1, example f

Up to 4 x boiler ON / OFF control for a heating circuit.
The component marked with * is a pressure relief valve.

Rotating sequence of the boilers: Boiler 1 - 2 - 3 - 4. Next day: Boiler 2 - 3 - 4 - 1. Following day: Boiler 3 - 4 - 1 - 2 and so on.

Burner steps are activated according to heat demand.

The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example f:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Sequence type (code) for controlling the burners:		
MENU \ Settings \ Boiler: 'Sequence type'	11072	0
Number of total burner steps:		
MENU \ Settings \ Boiler: 'Steps'	11073	4

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A375.1, example g

Up to 8 x boiler ON / OFF control for a heating circuit.
The component marked with * is a pressure relief valve.

The extension module ECA 32 is used to control boiler 5, 6, 7 and 8.

Rotating sequence for the boilers: Boiler 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8. Next day: Boiler 2 - 3 - 4 - 5 - 6 - 7 - 8 - 1. Following day: Boiler 3 - 4 - 5 - 6 - 7 - 8 - 1 - 2 and so on.

Burner steps are activated according to heat demand.

The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example g:

Navigation:	ID no.:	Recommended setting:
-------------	---------	----------------------

Heating circuit (circuit 1)

Sequence type (code) for controlling the burners:

MENU \ Settings \ Boiler: 'Sequence type'	11072	0
---	-------	---

Number of total burner steps:

MENU \ Settings \ Boiler: 'Steps'	11073	1 8
-----------------------------------	-------	----------

A375.1, example h

Up to 8 x boiler ON / OFF control for a heating circuit. The first boiler (high efficiency) has highest priority.
The component marked with * is a pressure relief valve.

The first boiler can be a heat pump.

The extension module ECA 32 is used to control boiler 5, 6, 7 and 8.

Sequence for the boilers: Boiler 1, 2 - 3 - 4 - 5 - 6 - 7 - 8. Next day: Boiler 1, 3 - 4 - 5 - 6 - 7 - 8 - 2. Following day: Boiler 1, 4 - 5 - 6 - 7 - 8 - 2 - 3 and so on.

Burner steps are activated according to heat demand.

The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example h:

Navigation:	ID no.:	Recommended setting:
-------------	---------	----------------------

Heating circuit (circuit 1)

Sequence type (code) for controlling the burners:

MENU \ Settings \ Boiler: 'Sequence type'	11072	1
---	-------	---

Number of total burner steps:

MENU \ Settings \ Boiler: 'Steps'	11073	1 8
-----------------------------------	-------	----------

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A375.1, example I

Up to 8 x boiler ON / OFF control for a heating circuit. The first two boilers (high efficiency) have highest priority. The component marked with * is a pressure relief valve.

The first two boilers can be heat pumps

The extension module ECA 32 is used to control boiler 5, 6, 7 and 8.

Sequence for the boilers: Boiler 1, 2, 3 - 4 - 5 - 6 - 7 - 8. Next day: Boiler 1, 2, 4 - 5 - 6 - 7 - 8 - 3. Following day: Boiler 1, 2, 5 - 6 - 7 - 8 - 3 - 4 and so on.

Burner steps are activated according to heat demand.

The last burner step can be disabled if the outdoor temperature is higher than a set value.



Special settings for type A375.1, example i:

Navigation:	ID no.:	Recommended setting:
Heating circuit (circuit 1)		
Sequence type (code) for controlling the burners:		
MENU \ Settings \ Boiler: 'Sequence type'	11072	2
Number of total burner steps:		
MENU \ Settings \ Boiler: 'Steps'	11073	1 8

A375.2, example a

Up to 8 x boiler ON / OFF control for a heating circuit and a DHW circuit.

The component marked with * is a pressure relief valve.

The application drawing shows a general and basic installation.

The ECL Comfort 310 controller controls the boilers 1 and 2. The extension module ECA 32 controls boiler 3, 4, 5 and 6. The ECL Comfort 310 controller controls boiler 7 and 8 via auxillary relays.

The burners / boilers are controlled as described in the A375.1, examples a - i.

The DHW circuit is controlled as described in the A275.2 examples.

Operating Guide ECL Comfort 210/296/310, application A275/A375

See the Installation Guide (delivered with the application key) for application examples and electrical connections.

A375.3, example a

Up to 8 x boiler ON / OFF control for a direct heating circuit (1), a mixing circuit (2) and a DHW circuit (3). Optional DHW priority.
The component marked with * is a pressure relief valve.

The application drawing shows a general and basic installation.

The ECL Comfort 310 controller controls the boilers 1 and 2. The extension module ECA 32 controls boiler 3, 4, 5 and 6. The ECL Comfort 310 controller controls boiler 7 and 8 via auxiliary relays.

The mixing circuit (2) is controlled as described in the A275.3 examples.

The DHW circuit (3) is controlled as described in the A275.2 examples.

A375.4, example a

Boiler ON / OFF control for a heating circuit.

The component marked with * is a pressure relief valve.

In addition, the boiler can be controlled by means of a 0 - 10 Volt signal (from ECA 32) for setting the boiler temperature.

Based on a measured pressure, S9, an alarm can be activated.

Settings for pressure related alarm are found (Navigation):

Heating circuit (circuit 1) \ MENU \ Alarm

A375.5, example a

Boiler ON / OFF control for a heating circuit.

The component marked with * is a pressure relief valve.

In addition, the boiler can be controlled by means of a 0 - 10 Volt signal (from ECA 32) for setting the boiler temperature.

Based on a measured pressure, S9, an alarm can be activated.

Settings for pressure related alarm are found (Navigation):

Heating circuit (circuit 1) \ MENU \ Alarm

Special settings for type A375.5: See special settings for A275.3, ex. a - A275.3, ex. g.

Operating Guide ECL Comfort 210/296/310, application A275/A375

2.3 Mounting

2.3.1 Mounting the ECL Comfort controller

See the Installation Guide which is delivered together with the ECL Comfort controller.

For easy access, you should mount the ECL Comfort controller near the system.

ECL Comfort 210 / 296 / 310 can be mounted

- on a wall
- on a DIN rail (35 mm)

ECL Comfort 296 can be mounted

- in a panel cut-out

ECL Comfort 210 can be mounted in an ECL Comfort 310 base part (for future upgrade).

Screws, PG cable glands and rawlplugs are not supplied.

Locking the ECL Comfort 210 / 310 controller

In order to fasten the ECL Comfort controller to its base part, secure the controller with the locking pin.



To prevent injuries to persons or the controller, the controller has to be securely locked into the base. For this purpose, press the locking pin into the base until a click is heard and the controller no longer can be removed from the base.




If the controller is not securely locked into the base part, there is a risk that the controller during operation can unlock from the base and the base with terminals (and also the 230 V a.c. connections) are exposed. To prevent injuries to persons, always make sure that the controller is securely locked into its base. If this is not the case, the controller should not be operated!



The easy way to lock the controller to its base or unlock it is to use a screw driver as lever.


Mounting on a wall

Mount the base part on a wall with a smooth surface. Establish the electrical connections and position the controller in the base part. Secure the controller with the locking pin.




Mounting on a DIN rail (35 mm)

Mount the base part on a DIN rail. Establish the electrical connections and position the controller in the base part. Secure the controller with the locking pin.



Dismounting the ECL Comfort controller

In order to remove the controller from the base part, pull out the locking pin by means of a screwdriver. The controller can now be removed from the base part.



The easy way to lock the controller to its base or unlock it is to use a screw driver as lever.



Before removing the ECL Comfort controller from the base part, ensure that the supply voltage is disconnected.

2.3.2 Mounting the Remote Control Units ECA 30 / 31


Select one of the following methods:

- Mounting on a wall, ECA 30 / 31
- Mounting in a panel, ECA 30

Screws and rawlplugs are not supplied.

Mounting on a wall


Mount the base part of the ECA 30 / 31 on a wall with a smooth surface. Establish the electrical connections. Place the ECA 30 / 31 in the base part.



Mounting in a panel

Mount the ECA 30 in a panel using the ECA 30 frame kit (order code no. 087H3236). Establish the electrical connections. Secure the frame with the clamp. Place the ECA 30 in the base part. The ECA 30 can be connected to an external room temperature sensor.

The ECA 31 must not be mounted in a panel if the humidity function is to be used.



2.4 Placing the temperature sensors

2.4.1 Placing the temperature sensors

It is important that the sensors are mounted in the correct position in your system.

The temperature sensor mentioned below are sensors used for the ECL Comfort 210 / 296 / 310 series which not all will be needed for your application!

Outdoor temperature sensor (ESMT)

The outdoor sensor should be mounted on that side of the building where it is less likely to be exposed to direct sunshine. It should not be placed close to doors, windows or air outlets.


Flow temperature sensor (ESMU, ESM-11 or ESMC)

Place the sensor max. 15 cm from the mixing point. In systems with heat exchanger, Danfoss recommends that the ESMU-type to be inserted into the exchanger flow outlet.

Make sure that the surface of the pipe is clean and even where the sensor is mounted.

Return temperature sensor (ESMU, ESM-11 or ESMC)


The return temperature sensor should always be placed so that it measures a representative return temperature.



Room temperature sensor

(ESM-10, ECA 30 / 31 Remote Control Unit)

Place the room sensor in the room where the temperature is to be controlled. Do not place it on outside walls or close to radiators, windows or doors.



Boiler temperature sensor (ESMU, ESM-11 or ESMC)

Place the sensor according to the boiler manufacturer's specification.

Air duct temperature sensor (ESMB-12 or ESMU types)

Place the sensor so that it measures a representative temperature.

DHW temperature sensor (ESMU or ESMB-12)

Place the DHW temperature sensor according to the manufacturer's specification.

Slab temperature sensor (ESMB-12)

Place the sensor in a protection tube in the slab.



ESM-11: Do not move the sensor after it has been fastened in order to avoid damage to the sensor element.



ESM-11, ESMC and ESMB-12: Use heat conducting paste for quick measurement of the temperature.




ESMU and ESMB-12: Using a sensor pocket to protect the sensor will, however, result in a slower temperature measurement.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Pt 1000 temperature sensor (IEC 751B, 1000 Ω / 0 °C)

Relationship between temperature and ohmic value:



2.5 Electrical connections

2.5.1 Electrical connections 230 V a.c.

**Warning**

Electric conductors on PCB (**P**rinted **C**ircuit **B**oard) for supply voltage, relay contacts and triac outputs do not have mutual safety distance of minimum 6 mm. The outputs are not allowed to be used as galvanic separated (volt free) outputs.

If a galvanic separated output is needed, an auxiliary relay is recommended.

24 Volt controlled units, for example actuators, are to be controlled by means of ECL Comfort 310, 24 Volt version.

**Safety Note**

Necessary assembly, start-up, and maintenance work must be performed by qualified and authorized personnel only.

Local legislations must be respected. This comprises also cable size and isolation (reinforced type).

A fuse for the ECL Comfort installation is max. 10 A typically.


The ambient temperature range for the ECL Comfort in operation is 0 - 55 °C. Exceeding this temperature range can result in malfunctions.

Installation must be avoided if there is a risk for condensation (dew).


Operating Guide ECL Comfort 210/296/310, application A275/A375

The common ground terminal is used for connection of relevant components (pumps, motorized control valves).

ECL 210 / 310



ECL 296



See also the Installation Guide (delivered with the application key) for application specific connections.

Operating Guide ECL Comfort 210/296/310, application A275/A375



Wire cross section: 0.5 - 1.5 mm²
 Incorrect connection can damage the electronic outputs.
 Max. 2 x 1.5 mm² wires can be inserted into each screw terminal.

Maximum load ratings:

R 	Relay terminals	4 (2) A / 230 V a.c. (4 A for ohmic load, 2 A for inductive load)
Tr 	Triac (= electronic relay) terminals	0,2 A / 230 V a.c.

2.5.2 Electrical connections 24 V a.c.

See also the Installation Guide (delivered with the application key) for application specific connections.

Maximum load ratings:

R 	Relay terminals	4 (2) A / 24 V a.c. (4 A for ohmic load, 2 A for inductive load)
Tr 	Triac (= electronic relay) terminals	1 A / 24 V a.c.



Do not connect 230 V a.c. powered components to a 24 V a.c. power supplied controller directly. Use auxilliary relays (K) to separate 230 V a.c. from 24 V a.c.

Operating Guide ECL Comfort 210/296/310, application A275/A375

2.5.3 Electrical connections, safety thermostats, in general

See also the Installation Guide (delivered with the application key) for application specific connections.

The connection diagrams show various solutions / examples:

Safety thermostat, 1-step closing:
Motorized control valve without safety function

Safety thermostat, 1-step closing:
Motorized control valve with safety function

Safety thermostat, 2-step closing:
Motorized control valve with safety function



When ST is activated by a high temperature, the safety circuit in the motorized control valve closes the valve immediately.



When ST1 is activated by a high temperature (the TR temperature), the motorized control valve is closed gradually. At a higher temperature (the ST temperature), the safety circuit in the motorized control valve closes the valve immediately.


Operating Guide ECL Comfort 210/296/310, application A275/A375

2.5.4 Electrical connections, Pt 1000 temperature sensors and signals

See also the Installation Guide (delivered with the application key) for application specific connections.

A275:

Sensor / description	Type (recomm.)
S1 Outdoor temperature sensor*	ESMT
S2 A275.3: Return temperature sensor, circuit 2	ESM-11 / ESMB / ESMC / ESMU
S3 Boiler temperature sensor**, circuit 1	ESMU / ESMB
S4 A275.3: Flow temperature sensor**, circuit 2	ESM-11 / ESMB / ESMC / ESMU
S5 Return temperature sensor, circuit 1	ESM-11 / ESMB / ESMC / ESMU
S6 A275.2: DHW tank temperature sensor, circuit 2. A275.3: DHW tank temperature sensor, circuit 3.	ESM-11 / ESMB / ESMC / ESMU
S7 Room temperature sensor***, circuit 1	ESM-10
S8 A275.3: Room temperature sensor***, circuit 2	ESM-10



* If the outdoor temperature sensor is not connected or the cable is short-circuited, the controller assumes that the outdoor temperature is 0 (zero) °C.

** The boiler / flow temperature sensor must always be connected in order to have the desired functionality.


- If the boiler sensor is not connected, or the cable is short-circuited, the boiler will be switched OFF (safety function).
- If the flow sensor is not connected, or the cable is short-circuited, the motorized control valve closes (safety function).

*** Only for room temperature sensor connection. The room temperature signal can also be available from a Remote Control Unit (ECA 30 / 31). See 'Electrical connections, ECA 30 / 31'.

Operating Guide ECL Comfort 210/296/310, application A275/A375


A375:

Sensor / description		Type (recomm.)
S1	Outdoor temperature sensor*	ESMT
S2	A375.3, A375.5: Return temperature sensor, circuit 2	ESM-11 / ESMB / ESMC / ESMU
S3	Boiler temperature sensor**, circuit 1	ESMU / ESMB
S4	A375.3, A375.5: Flow temperature sensor**, circuit 2	ESM-11 / ESMB / ESMC / ESMU
S5	Return temperature sensor, circuit 1	ESM-11 / ESMB / ESMC / ESMU
S6	A375.2: DHW tank temperature sensor, circuit 2. A375.3, A375.5: DHW tank temperature sensor, circuit 3.	ESM-11 / ESMB / ESMC / ESMU
S7	Room temperature sensor***, circuit 1	ESM-10
S8	A375.3, A375.5 Room temperature sensor***, circuit 2	ESM-10
S9	A375.4, A375.5: Pressure transmitter, 0 - 10 V.	
S10	Voltage signal (0-10 V) for external control of desired boiler temperature, circuit 1.	



- * If the outdoor temperature sensor is not connected or the cable is short-circuited, the controller assumes that the outdoor temperature is 0 (zero) °C.
- ** The boiler / flow temperature sensor must always be connected in order to have the desired functionality.
 - If the boiler sensor is not connected, or the cable is short-circuited, the boiler will be switched OFF (safety function).
 - If the flow sensor is not connected, or the cable is short-circuited, the motorized control valve closes (safety function).
- *** Only for room temperature sensor connection. The room temperature signal can also be available from a Remote Control Unit (ECA 30 / 31). See 'Electrical connections, ECA 30 / 31'.

Subtypes A375.1, A375.2 and A375.3 only: Connection of voltage signal (0-10 V) for external control of desired boiler temperature



Operating Guide ECL Comfort 210/296/310, application A275/A375

A375.4, A375.5

Connection of pressure transmitter.

See the Installation Guide (delivered with the application key).

Scale for conversion of voltage to pressure is set in the ECL Comfort (navigation: Circuit 1 > MENU > Alarm > S9 pressure).

The pressure transmitter is powered with 12 - 24 V d.c.

Output type: 0 - 10 V.

2.5.5 Electrical connections, ECA 30 / 31

Terminal ECL	Terminal ECA 30 / 31	Description	Type (recomm.)
30	4	Twisted pair	Cable 2 x twisted pair
31	1		
32	2	Twisted pair	Cable 2 x twisted pair
33	3		
	4	Ext. room temperature sensor*	ESM-10
	5		


* After an external room temperature sensor has been connected, ECA 30 / 31 must be repowered.

The communication to the ECA 30 / 31 must be set up in the ECL Comfort controller in 'ECA addr.'

The ECA 30 / 31 must be set up accordingly.

After application setup the ECA 30 / 31 is ready after 2-5 min. A progress bar in the ECA 30 / 31 is displayed.

Connection of switch for external override



Using an input for override requires a volt free contact / switch.

If S1... S6 is chosen as override input, the override switch must have gold-plated contacts.

If S7 ... S16 is chosen as override input, the override switch can be a standard contact.



Wire cross section for sensor connections: Min. 0.4 mm².
Total cable length: Max. 200 m (all sensors incl. internal ECL 485 communication bus)
Cable lengths of more than 200 m may cause noise sensibility (EMC).



If the actual application contains two heating circuits, it is possible to connect an ECA 30 / 31 to each circuit. The electrical connections are done in parallel.



Max. 2 ECA 30 / 31 can be connected to an ECL Comfort 310 controller or to ECL Comfort 210 / 296 / 310 controllers in a master-slave system.



ECA information message:
'Application req. newer ECA':
The software (firmware) of your ECA does not comply with the software (firmware) of your ECL Comfort controller. Please contact your Danfoss sales office.



Total cable length: Max. 200 m (all sensors incl. internal ECL 485 communication bus).
Cable lengths of more than 200 m may cause noise sensibility (EMC).



Max. two ECA 30 / 31 can be connected to an ECL Comfort controller or to master / slave systems with several ECL Comfort controllers.

Operating Guide ECL Comfort 210/296/310, application A275/A375

2.5.6 Electrical connections, master / slave systems

The controller can be used as master or slave in master / slave systems via the internal ECL 485 communication bus (2 x twisted pair cable).

The ECL 485 communication bus is not compatible with the ECL bus in ECL Comfort 110, 200, 300 and 301!

Terminal	Description	Type (recomm.)
30	Common terminal	Cable 2 x twisted pair
31	+12 V*, ECL 485 communication bus * Only for ECA 30 / 31 and master / slave communication	
32	B, ECL 485 communication bus	
33	A, ECL 485 communication bus	



ECL 485 bus cable

Maximum recommended length of the ECL 485 bus is calculated like this:

Subtract "Total length of all input cables of all ECL controllers in the master - slave system" from 200 m.

Simple example for total length of all input cables, 3 x ECL:

1 x ECL	Outdoor temp. sensor:	15 m
3 x ECL	Flow temp. sensor:	18 m
3 x ECL	Return temp. sensor:	18 m
3 x ECL	Room temp. sensor:	30 m
Total:		81 m

Maximum recommended length of the ECL 485 bus:
200 - 81 m = 119 m

Electrical connections, Modbus

ECL Comfort 210: Non-galvanic isolated Modbus connections

ECL Comfort 296: Galvanic isolated Modbus connections

ECL Comfort 310: Galvanic isolated Modbus connections

2.5.7 Electrical connections, communication

Electrical connections, M-bus

ECL Comfort 210: Not implemented

ECL Comfort 296: On board, non-galvanic isolated. Max. cable length 50 m.

ECL Comfort 310: On board, non-galvanic isolated. Max. cable length 50 m.

Operating Guide ECL Comfort 210/296/310, application A275/A375

2.6 Inserting the ECL Application Key

2.6.1 Inserting the ECL Application Key


The ECL Application Key contains

- the application and its subtypes,
- currently available languages,
- factory settings: e.g. schedules, desired temperatures, limitation values etc. It is always possible to recover the factory settings,
- memory for user settings: special user / system settings.


After having powered-up the controller, different situations might be existing:

1. The controller is new from the factory, the ECL Application Key is not inserted.
2. The controller already runs an application. The ECL Application Key is inserted, but the application needs to be changed.
3. A copy of the controllers settings is needed for configuring another controller.


ECL Comfort 210 / 310



ECL Comfort 210 / 310



ECL Comfort 296




User settings are, among others, desired room temperature, desired DHW temperature, schedules, heat curve, limitation values etc.

System settings are, among others, communication set-up, display brightness etc.



Automatic update of controller software (firmware):

The software of the controller is updated automatically when the key is inserted (as of controller version 1.11 (ECL 210 / 310) and version 1.58 (ECL 296)). The following animation will be shown when the software is being updated:



Progress bar

During update:

- Do not remove the KEY
If the key is removed before the hour-glass is shown, you have to start afresh.
- Do not disconnect the power
If the power is interrupted when the hour-glass is shown, the controller will not work.
- Manual update of controller software (firmware):
See the section "Automatic / manual update of firmware"

Operating Guide ECL Comfort 210/296/310, application A275/A375

Application Key: Situation 1

The controller is new from the factory, the ECL Application Key is not inserted.

An animation for the ECL Application Key insertion is displayed. Insert the Application Key.

Application Key name and Version is indicated (example: A266 Ver. 1.03).

If the ECL Application Key is not suitable for the controller, a "cross" is displayed over the ECL Application Key-symbol.

Action:	Purpose:	Examples:
	Select language	
	Confirm	
	Select application (subtype)	
	Some keys have only one application.	
	Confirm with 'Yes'	
	Set 'Time & Date'	
	Turn and push the dial to select and change 'Hours', 'Minutes', 'Date', 'Month' and 'Year'.	
	Choose "Next"	
	Confirm with 'Yes'	
	Go to 'Aut. daylight'	
	Choose whether 'Aut. daylight' * should be active or not	YES or NO

* 'Aut. daylight' is the automatic changeover between summer and winter time.

Depending on the contents of the ECL Application Key, procedure A or B is taking place:

A

The ECL Application key contains factory settings:

The controller reads / transfers data from the ECL Application Key to ECL controller.

The application is installed, and the controller resets and starts up.

B

The ECL Application key contains changed system settings:

Push the dial repeatedly.

'NO': Only factory settings from the ECL Application Key will be copied to the controller.

'YES*': Special system settings (differing from the factory settings) will be copied to the controller.

If the key contains user settings:


Push the dial repeatedly.

'NO': Only factory settings from the ECL Application Key will be copied to the controller.

'YES*': Special user settings (differing from the factory settings) will be copied to the controller.

* If 'YES' cannot be chosen, the ECL Application Key does not contain any special settings.

Choose 'Start copying' and confirm with 'Yes'.



Operating Guide ECL Comfort 210/296/310, application A275/A375


Application Key: Situation 2

The controller already runs an application. The ECL Application Key is inserted, but the application needs to be changed.

To change to another application on the ECL Application Key, the current application in the controller must be erased (deleted).

Be aware that the Application Key must be inserted.

Action:	Purpose:	Examples:
	Choose 'MENU' in any circuit	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose 'Common controller settings'	
	Confirm	
	Choose 'Key functions'	
	Confirm	
	Choose 'Erase application'	
	Confirm with 'Yes'	



The controller resets and is ready to be configured.

Follow the procedure described in situation 1.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Application Key: Situation 3

A copy of the controllers settings is needed for configuring another controller.

This function is used

- for saving (backup) of special user and system settings
- when another ECL Comfort controller of the same type (210, 296 or 310) must be configured with the same application but user / system settings differ from the factory settings.

How to copy to another ECL Comfort controller:

Action:	Purpose:	Examples:
	Choose 'MENU'	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose 'Common controller settings'	
	Confirm	
	Go to 'Key functions'	
	Confirm	
	Choose 'Copy'	
	Confirm	
	Choose 'To: 'ECL' or 'KEY' will be indicated. Choose 'ECL' or 'KEY'	* 'ECL' or 'KEY'
	Push the dial repeatedly to choose copy direction	
	Choose 'System settings' or 'User settings'	** 'NO' or 'YES'
	Push the dial repeatedly to choose 'Yes' or 'No' in 'Copy'. Push to confirm.	
	Choose 'Start copying'	
	The Application Key or the controller is updated with special system or user settings.	




*

'ECL': Data will be copied from the Application Key to the ECL Controller.

'KEY': Data will be copied from the ECL Controller to the Application Key.

**

'NO': The settings from the ECL controller will not be copied to the Application Key or to the ECL Comfort controller. Special settings (differing from the factory settings) will be copied to the Application Key or to the ECL Comfort controller. If YES can not be chosen, there are no special settings to be copied.



Operating Guide ECL Comfort 210/296/310, application A275/A375

Language

At application upload, a language must be selected.*
 If another language than English is selected, the selected language **AND** English will be uploaded into the ECL controller.
 This makes service easy for English speaking service people, just because the English language menus can be visible by changing the actual set language into English.
 (Navigation: MENU > Common controller > System > Language)

If the uploaded language is not suitable, the application must be erased. User and System settings can be saved on the application key before erasing.
 After new upload with preferred language, the existing User and System settings can be uploaded.

*)
 (ECL Comfort 310, 24 Volt) If language cannot be selected, the power supply is not a.c. (alternating current).

2.6.2 ECL Application Key, copying data

General principles

When the controller is connected and operating, you can check and adjust all or some of the basic settings. The new settings can be stored on the Key.

How to update the ECL Application Key after settings have been changed?

All new settings can be stored on the ECL Application Key.

How to store factory setting in the controller from the Application Key?

Please read the paragraph concerning Application Key, Situation 1: The controller is new from the factory, the ECL Application Key is not inserted.

How to store personal settings from the controller to the Key?

Please read the paragraph concerning Application Key, Situation 3: A copy of the controllers settings is needed for configuring another controller

As a main rule, the ECL Application Key should always remain in the controller. If the Key is removed, it is not possible to change settings.



Factory settings can always be restored.



Make a note of new settings in the 'Settings overview' table.



Do not remove the ECL Application Key while copying. The data on the ECL Application Key can be damaged!



It is possible to copy settings from one ECL Comfort controller to another controller provided that the two controllers are from the same series (210 or 310).
 Furthermore, when the ECL Comfort controller has been uploaded with an application key, minimum version 2.44, it is possible to upload personal settings from application keys, minimum version 2.14.



The "Key overview" does not inform — through ECA 30 / 31 — about the subtypes of the application key.



Key inserted / not inserted, description:

ECL Comfort 210 / 310, controller versions lower than 1.36:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; for 20 minutes settings can be changed.

ECL Comfort 210 / 310, controller versions 1.36 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

ECL Comfort 296 , controller versions 1.58 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

2.7 Check list



Is the ECL Comfort controller ready for use?

- ☐ Make sure that the correct power supply is connected to terminals 9 and 10 (230 V or 24 V).
- ☐ Make sure the correct phase conditions are connected:
230 V: Live = terminal 9 and Neutral = terminal 10
24 V: SP = terminal 9 and SN = terminal 10
- ☐ Check that the required controlled components (actuator, pump etc.) are connected to the correct terminals.
- ☐ Check that all sensors / signals are connected to the correct terminals (see 'Electrical connections').
- ☐ Mount the controller and switch on the power.
- ☐ Is the ECL Application Key inserted (see 'Inserting the Application Key').
- ☐ Does the ECL Comfort controller contain an existing application (see 'Inserting the Application Key').
- ☐ Is the correct language chosen (see 'Language' in 'Common controller settings').
- ☐ Is the time & date set correctly (see 'Time & Date' in 'Common controller settings').
- ☐ Is the right application chosen (see 'Identifying the system type').
- ☐ Check that all settings in the controller (see 'Settings overview') are set or that the factory settings comply with your requirements.
- ☐ Choose manual operation (see 'Manual control'). Check that valves open and close, and that required controlled components (pump etc.) start and stop when operated manually.
- ☐ Check that the temperatures / signals shown in the display match the actual connected components.
- ☐ Having completed the manual operation check, choose controller mode (scheduled, comfort, saving or frost protection).

Operating Guide ECL Comfort 210/296/310, application A275/A375

2.8 Navigation, ECL Application Key A275

Navigation, A275, circuits 1, 2 and 3

Home				Application A275							
				A275.1	A275.2		A275.3				
				Circuit	Circuit		Circuit				
MENU		ID nos.		Function		1	1	2	1	2	3
Schedule						●	●	●	●	●	●
Settings	Flow temperature			Heat curve		●	●		●	●	
		11178	12178	Temp. max.		●	●		●	●	
		11177	12177	Temp. min.		●	●		●	●	
	Tank temperature	12193	13193	Charge difference				●			●
		12195	13195	Start difference				●			●
		12194	13194	Stop difference				●			●
	Room limit	11182	12182	Infl. - max.		●	●		●	●	
		11183	12183	Infl. - min.		●	●		●	●	
		11015	12015	Adapt. time		●	●		●	●	
	Return limit	11031	12031	High T out X1		●	●		●	●	
		11032	12032	Low limit Y1		●	●		●	●	
		11033	12033	Low T out X2		●	●		●	●	
		11034	12034	High limit Y2		●	●		●	●	
		11035	12035	Infl. - max.		●	●		●	●	
		11036	12036	Infl. - min.		●	●		●	●	
		11037	12037	Adapt. time		●	●		●	●	
		11085	12085	Priority		●	●		●	●	
	Optimization	11011	12011	Auto saving		●	●		●	●	
		11012	12012	Boost		●	●		●	●	
			12013	Ramp						●	
		11014	12014	Optimizer		●	●		●	●	
		11026	12026	Pre-stop		●	●		●	●	
		11020	12020	Based on		●	●		●	●	
		11021	12021	Total stop		●	●		●	●	
		11179	12179	Summer, Cut-out		●	●		●	●	
	Control par.		12174	Motor pr.						●	
			12184	Xp						●	
			12185	Tn						●	
			12186	M run						●	
			12187	Nz						●	
			12189	Min. act. time						●	
	Boiler	11046	Difference		●	●		●			
		11049	Max. T limit		●	●		●			
		11071	Min. ON time		●	●		●			
		11038	Stop at T out		●	●		●			
		11047	Protection		●	●		●			

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, A275, circuits 1, 2 and 3, continued

Home				Application A275							
				A275.1	A275.2		A275.3				
				Circuit	Circuit		Circuit				
MENU		ID nos.	Function		1	1	2	1	2	3	
Settings	Application	11010	12010	ECA addr.	●	●		●	●		
		11017		Demand offset	●	●		●			
		11050		P demand	●	●		●			
			12051	13051	Ch.-o. valve / P			●			●
			12053	13053	Tank, sec. / prim.			●			●
			12041	13041	DHW P post-run			●			●
		11500	12500	13500	Send desired T	●	●	●	●	●	●
		11022	12022	P exercise	●	●		●	●		
			12023		M exercise					●	
			12052		DHW priority					●	
			12076		Circ. P frost T			●			
		11077	12077	P frost T	●	●		●	●		
		11078	12078	P heat T	●	●		●	●		
		11040	12040	P post-run	●	●		●	●		
		11093	12093	13093	Frost pr. T	●	●	●	●	●	●
		11141	12141	13141	Ext. input	●	●	●	●	●	●
11142	12142	13142	Ext. mode	●	●	●	●	●	●		
Holiday				●	●	●	●	●	●		
Alarm	Temp. monitor.	12147	Upper difference					●			
		12148	Lower difference					●			
		12149	Delay					●			
		12150	Lowest temp.					●			
	Alarm overview							●			
Anti-bacteria						●			●		
Influence overview											
Des. flow T				●	●		●	●			
Des. DHW T						●			●		

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, application A275, Common controller settings

Home MENU		Application A275, Common controller settings				
		ID no.	Function	A275.1	A275.2	A275.3
Time & Date			Selectable	●	●	●
Holiday			Selectable	●	●	●
Input overview 1			Outdoor T	●	●	●
			Outdoor acc. T	●	●	●
			Room T	●	●	●
			Boiler T	●	●	●
			Return T	●	●	●
Input overview 2			Outdoor T			●
			Outdoor acc. T			●
			Room T			●
			Flow T			●
			Return T			●
			Tank T		●	
Input overview 3			Tank T			●
Log 1 (sensors)	Outdoor T		Log today	●	●	●
	Room T		Log yesterday	●		●
	Room T & desired		Log 2 days	●	●	
	Boiler T & desired		Log 4 days	●	●	●
	Return T & limit			●	●	●
Log 2 (sensors)	Outdoor T		Log today			●
	Room T		Log yesterday			●
	Flow T & desired		Log 2 days			●
	Return T & limit		Log 4 days			●
	Tank T & desired				●	
Log 3 (sensors)	Tank T & desired		Log today			●
			Log yesterday			
			Log 2 days			
			Log 4 days			
Output override			P1	●	●	●
			B1	●	●	●
			M2			●
			P4			●
			P3		●	●
			A1	●	●	

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, application A275, Common controller settings, continued

Home MENU		Application A275, Common controller settings				
		ID no.	Function	A275.1	A275.2	A275.3
Key functions	New application		Erase application	●	●	●
	Application			●	●	●
	Factory setting		System settings	●	●	●
			User settings	●	●	●
			Go to factory	●	●	●
	Copy		To	●	●	●
			System settings	●	●	●
			User settings	●	●	●
		Start copying	●	●	●	
Key overview			●	●	●	
System	ECL version		Code no.	●	●	●
			Hardware	●	●	●
			Software	●	●	●
			Build no.	●	●	●
			Serial no.	●	●	●
			Production date	●	●	●
	Extension			●	●	●
	Ethernet			●	●	●
	Portal config			●	●	●
	M-bus config			●	●	●
	Energy Meters			●	●	●
	Raw input overview			●	●	●
	Sensor offset			●	●	●
	Alarm		32: T sensor defekt	●	●	●
	Display	60058	Backlight	●	●	●
		60059	Contrast	●	●	●
	Communication	38	Modbus addr.	●	●	●
		39	Baud	●	●	●
		2048	ECL 485 addr.	●	●	●
		2150	Service pin	●	●	●
		2151	Ext. reset	●	●	●
	Language	2050	Language	●	●	●

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, A375.1, A375.2 and A375.3, circuits 1, 2 and 3

Home			Application A375					
			A375.1	A375.2		A375.3		
			Circuit	Circuit		Circuit		
MENU	ID nos.	Function	1	1	2	1	2	3
Schedule			•	•	•	•	•	•
Schedule circ. P					•			
Settings	Flow temperature	Heat curve	•	•		•	•	
	11178 12178	Temp. max.	•	•		•	•	
	11177 12177	Temp. min.	•	•		•	•	
		Ext. desired T	•	•		•		
	Tank temperature	Charge difference			•			•
		Start difference			•			•
		Stop difference			•			•
	Room limit	Infl. - max.	•	•		•	•	
		Infl. - min.	•	•		•	•	
		Adapt. time	•	•		•	•	
	Return limit	High T out X1	•	•		•	•	
		Low limit Y1	•	•		•	•	
		Low T out X2	•	•		•	•	
		High limit Y2	•	•		•	•	
		Infl. - max.	•	•		•	•	
		Infl. - min.	•	•		•	•	
		Adapt. time	•	•		•	•	
		Priority	•	•		•	•	
	Optimization	Auto saving	•	•		•	•	
		Boost	•	•		•	•	
		Ramp					•	
		Optimizer	•	•		•	•	
		Pre-stop	•	•		•	•	
		Based on	•	•		•	•	
		Total stop	•	•		•	•	
		Summer, cut-out	•	•		•	•	
	Control par.	Motor pr.					•	
		Xp					•	
		Tn					•	
		M run					•	
		Nz					•	
		Min. act. time					•	
		Actuator					•	
	Boiler	Difference	•	•		•		
		Max. T limit	•	•		•		
		Min. ON time	•	•		•		
		Sequence type	•	•		•		
		Stop at T out	•	•		•		
		Protection	•	•		•		
		Band limit	•	•		•		
		Reaction, o. band	•	•		•		
		Reaction, in band	•	•		•		
		Steps	•	•		•		

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, A375.1, A375.2 and A375.3, circuits 1, 2 and 3, continued

Home				Application A375							
				A375.1	A375.2		A375.3				
				Circuit	Circuit		Circuit				
MENU		ID nos.	Function	1	1	2	1	2	3		
Settings	Application	11010	12010	ECA addr.	●	●		●	●		
		11017		Demand offset	●	●		●			
		11050		P demand	●	●		●			
			12051	13051	Ch.-o. valve / P			●			●
			12053	13053	Tank, sec. / prim.			●			●
			12055		Circ. P priority			●			
			12041	13041	DHW P post-run			●			●
		11500	12500	13500	Send desired T	●	●	●	●	●	●
		11022	12022		P exercise	●	●		●	●	
			12023		M exercise					●	
			12052		DHW priority					●	
			12076		Circ. P frost T			●			
		11077	12077		P frost T	●	●		●	●	
		11078	12078		P heat T	●	●		●	●	
			11040	12040	P post-run	●	●		●	●	
		11093	12093	13093	Frost pr. T	●	●	●	●	●	●
		11141	12141	13141	Ext. input	●	●	●	●	●	●
		11142	12142	13142	Ext. mode	●	●	●	●	●	●
Holiday				●	●	●	●	●	●		
Alarm	Temp. monitor.	12147	Upper difference					●			
		12148	Lower difference					●			
		12149	Delay					●			
		12150	Lowest temp.					●			
	Alarm overview							●			
Anti-bacteria						●			●		
Influence overview				●	●		●	●			
Des. flow T				●	●		●	●			
Des. DHW T						●			●		

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, application A375.1, A375.2 and A375.3, Common controller settings

Home MENU		Application A375, Common controller settings				
		ID no.	Function	A375.1	A375.2	A375.3
Time & Date			Selectable	●	●	●
Holiday			Selectable	●	●	●
Input overview 1			Outdoor T	●	●	●
			Outdoor acc. T	●	●	●
			Room T	●	●	●
			Boiler T	●	●	●
			Return T	●	●	●
			Ext. desired T	●	●	●
Input overview 2			Outdoor T			●
			Outdoor acc. T			●
			Room T			●
			Flow T			●
			Return T			●
			Tank T		●	
Input overview 3			Tank T			●
Log 1 (sensors)	Outdoor T		Log today	●	●	●
	Room T		Log yesterday			●
	Room T & desired		Log 2 days	●	●	
	Boiler T & desired		Log 4 days	●	●	●
	Return T & limit			●	●	●
Log 2 (sensors)	Outdoor T		Log today			●
	Room T & desired		Log yesterday			●
	Flow T & desired		Log 2 days			●
	Return T & limit		Log 4 days			●
	Tank T & desired				●	
Log 3 (sensors)	Tank T & desired		Log today			●
			Log yesterday			●
			Log 2 days			●
			Log 4 days			●
Output override			P1	●	●	●
			B1	●	●	●
			B2	●	●	●
			B3	●	●	●
			B4	●	●	●
			B5	●	●	●
			B6	●	●	●
			B7	●	●	●
			B8	●	●	●
			M2			●
			P4		●	●
			P3		●	●
			A1	●	●	●

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, application A375.1, A375.2 and A375.3, Common controller settings, continued

Home MENU		Application A375, Common controller settings					
		ID no.	Function	A375.1	A375.2	A375.3	
Key functions	New application		Erase application	●	●	●	
	Application			●	●	●	
	Factory setting		System settings	●	●	●	
			User settings	●	●	●	
			Go to factory	●	●	●	
	Copy		To	●	●	●	
			System settings	●	●	●	
		User settings	●	●	●		
		Start copying	●	●	●		
	Key overview			●	●	●	
System	ECL version		Code no.	●	●	●	
			Hardware	●	●	●	
			Software	●	●	●	
			Build no.	●	●	●	
			Serial no.	●	●	●	
			Production date	●	●	●	
	Extension			●	●	●	
	Ethernet			●	●	●	
	Portal config			●	●	●	
	M-bus config			●	●	●	
	Energy Meters			●	●	●	
	Raw input overview			●	●	●	
	Sensor offset			●	●	●	
	Alarm		32: T sensor defekt	●	●	●	
	Display	60058	Backlight	●	●	●	
		60059	Contrast	●	●	●	
	Communication		38	Modbus addr.	●	●	●
			39	Baud	●	●	●
			2048	ECL 485 addr.	●	●	●
			2150	Service pin	●	●	●
			2151	Ext. reset	●	●	●
	Language		2050	Language	●	●	●

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, A375.4 and A375.5, circuits 1, 2 and 3

Home			Application A375			
			A375.4	A375.5		
			Circuit	Circuit		
MENU	ID nos.	Function	1	1	2	3
Schedule			•	•	•	•
Schedule circ. P						•
Settings	Flow temperature	Heat curve	•	•	•	
		11178 12178 Temp. max.	•	•	•	
		11177 12177 Temp. min.	•	•	•	
		11004 Desired T	•	•		
	Tank temperature	13193 Charge difference				•
		13195 Start difference				•
		13194 Stop difference				•
	Room limit	11182 12182 Infl. - max.	•	•	•	
		11183 12183 Infl. - min.	•	•	•	
		11015 12015 Adapt. time	•	•	•	
	Return limit	11031 12031 High T out X1	•	•	•	
		11032 12032 Low limit Y1	•	•	•	
		11033 12033 Low T out X2	•	•	•	
		11034 12034 High limit Y2	•	•	•	
		11035 12035 Infl. - max.	•	•	•	
		11036 12036 Infl. - min.	•	•	•	
		11037 12037 Adapt. time	•	•	•	
		11085 12085 Priority	•	•	•	
		11029 DHW, ret. T limit	•	•		
		11028 Con. T, ret. T lim.	•	•		
	Optimization	11011 12011 Auto saving	•	•	•	
		11012 12012 Boost	•	•	•	
		12013 Ramp			•	
		11014 12014 Optimizer	•	•	•	
		11026 12026 Pre-stop	•	•	•	
		11020 12020 Based on	•	•	•	
		11021 12021 Total stop	•	•	•	
		11179 12179 Summer, cut-out	•	•	•	
	Control par.	12174 Motor pr.			•	
		12184 Xp			•	
		12185 Tn			•	
		12186 M run			•	
		12187 Nz			•	
		12189 Min. act. time			•	
	Boiler	12024 Actuator			•	
		Control voltage	•	•		
		11607 Low X	•	•		
		11608 High X	•	•		
		11424 Min. off time	•	•		
		11046 Difference	•	•		
		11364 Control, delay	•	•		
		11184 Xp	•	•		
		11185 Tn	•	•		
		11186 M run	•	•		
		11187 Nz	•	•		
		11189 Min. act. time	•	•		

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, A375.4 and A375.5, circuits 1, 2 and 3, continued

Home				Application A375			
				A375.4	A375.5		
				Circuit	Circuit		
MENU	ID nos.	Function	1	1	2	3	
Settings	Application		11010 12010	ECA addr.	●	●	●
			11017	Demand offset	●	●	
			11050	P demand	●	●	
				13051 Ch.-o. valve / P			●
				13053 Tank, sec. / prim.			●
				Circ. P priority			
				13041 DHW P post-run			●
	11500 12500	13500	Send desired T	●	●	●	●
	11022 12022		P exercise	●	●	●	
			12023 M exercise			●	
			12052 DHW priority			●	
			12076 Circ. P frost T				
	11077 12077		P frost T	●	●	●	
	11078 12078		P heat T	●	●	●	
	11040 12040		P post-run	●	●	●	
	11093 12093	13093	Frost pr. T	●	●	●	●
11141 12141	13141	Ext. input	●	●	●	●	
11142 12142	13142	Ext. mode	●	●	●	●	
Holiday			●	●	●	●	
Alarm	S9 pressure			Pressure	●	●	
				13607 Low X	●	●	
				13608 High X	●	●	
				13614 Alarm high	●	●	
				13615 Alarm low	●	●	
				13617 Alarm time-out	●	●	
	Temp. monitor.	12147	Upper difference			●	
		12148	Lower difference			●	
		12149	Delay			●	
		12150	Lowest temp.			●	
	Alarm overview				●	●	●
	Anti-bacteria						●
	Influence overview						
Des. flow T			●	●	●		
Des. DHW T						●	

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, application A375.4 and A375.5, Common controller settings

Home MENU		Application A375, Common controller settings		
		ID no.	Function	
Time & Date			Selectable	● ●
Holiday			Selectable	● ●
Input overview 1			Outdoor T	● ●
			Outdoor acc. T	● ●
			Room T	● ●
			Boiler T	● ●
			Return T	● ●
			Pressure	● ●
Input overview 2			Outdoor T	
			Outdoor acc. T	●
			Room T	●
			Flow T	●
			Return T	●
Input overview 3			Tank T	
Log 1 (sensors)			Log today	● ●
			Log yesterday	● ●
			Log 2 days	● ●
			Log 4 days	● ●
				● ●
Log 2 (sensors)			Log today	
			Log yesterday	●
			Log 2 days	●
			Log 4 days	●
Log 3 (sensors)			Log today	
			Log yesterday	●
			Log 2 days	●
			Log 4 days	●
Output override			P1	● ●
			B1	● ●
			M2	● ●
			M3	● ●
			P4	● ●
			P3	● ●
			P5	● ●
			A1	● ●
			V1	● ●

Operating Guide ECL Comfort 210/296/310, application A275/A375

Navigation, application A375.4 and A375.5, Common controller settings, continued

Home MENU		Application A375, Common controller settings			
		ID no.	Function	A375.4	A375.5
Key functions	New application		Erase application	●	●
	Application			●	●
	Factory setting		System settings	●	●
			User settings	●	●
			Go to factory	●	●
	Copy		To	●	●
			System settings	●	●
			User settings	●	●
		Start copying	●	●	
Key overview			●	●	
System	ECL version		Code no.	●	●
			Hardware	●	●
			Software	●	●
			Build no.	●	●
			Serial no.	●	●
			Production date	●	●
	Extension			●	●
	Ethernet			●	●
	Portal config			●	●
	M-bus config			●	●
	Energy Meters			●	●
	Raw input overview			●	●
	Sensor offset			●	●
	Alarm		32: T sensor defekt	●	●
	Display	60058	Backlight	●	●
		60059	Contrast	●	●
	Communication	38	Modbus addr.	●	●
		39	Baud	●	●
		2048	ECL 485 addr.	●	●
		2150	Service pin	●	●
2151		Ext. reset	●	●	
Language	2050	Language	●	●	

Operating Guide ECL Comfort 210/296/310, application A275/A375

3.0 Daily use

3.1 How to navigate

You navigate in the controller by turning the dial left or right to the desired position (◂◃).


The dial has a built-in accelerator. The faster you turn the dial, the faster it reaches the limits of any wide setting range.

The position indicator in the display (▶) will always show you where you are.


Push the dial to confirm your choices (Ⓜ).

The display examples are from a two-circuit application: One heating circuit (Ⓜ) and one domestic hot-water (DHW) circuit (Ⓜ). The examples might differ from your application.


Example shows ECL 210 / 310



Heating circuit (Ⓜ):



DHW circuit (Ⓜ):



Some general settings which apply to the entire controller are located in a specific part of the controller.

To enter 'Common controller settings':

Action:	Purpose:	Examples:
◂◃	Choose 'MENU' in any circuit	MENU
Ⓜ	Confirm	
◂◃	Choose the circuit selector at the top right corner in the display	
Ⓜ	Confirm	
◂◃	Choose 'Common controller settings'	Ⓜ
Ⓜ	Confirm	

Circuit selector



3.2 Understanding the controller display

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

Choosing a favorite display

Your favorite display is the display you have chosen as the default display. The favorite display will give you a quick overview of the temperatures or units that you want to monitor in general.

If the dial has not been activated for 20 min., the controller will revert to the overview display you have chosen as favorite.



To shift between displays: Turn the dial until you reach the display selector (a---) at the bottom right side of the display. Push the dial and turn to choose your favorite overview display. Push the dial again.

Heating circuit

Overview display 1 informs about:
actual outdoor temperature, controller mode,
actual room temperature, desired room temperature.

Overview display 2 informs about:
actual outdoor temperature, trend in outdoor temperature,
controller mode, max. and min. outdoor temperatures since
midnight as well as desired room temperature.

Overview display 3 informs about:
date, actual outdoor temperature, controller mode, time, desired
room temperature as well as shows the comfort schedule of the
current day.

Overview display 4 informs about:
state of the controlled components, actual flow temperature,
(desired flow temperature), controller mode, return temperature
(limitation value), influence on desired flow temperature.

The value above the V2 symbol indicates 0–100% of the analogue
signal (0–10 V).


Note:

An actual flow temperature value must be present, otherwise the
circuit's control valve will close.


Dependent on the chosen display, the overview displays for the
heating circuit inform you about:

- actual outdoor temperature (-0.5)
- controller mode (☼)
- actual room temperature (24.5)
- desired room temperature (20.7 °C)
- trend in outdoor temperature (↗ → ↘)
- min. and max. outdoor temperatures since midnight (☺)
- date (23.02.2010)
- time (7:43)
- comfort schedule of the current day (0 - 12 - 24)
- state of the controlled components (M2, P2)
- actual flow temperature (49 °C), (desired flow temperature (31))
- return temperature (24 °C) (limitation temperature (50))


Overview display 1:




Overview display 2:




Overview display 3:




Overview display 4:



Example of overview display with
Influence indication:



Example, favorite display 1 in
A230.3, where min. desired room
temperature is indicated (22.7):





The setting of the desired room temperature is important even if a room temperature sensor / Remote Control Unit is not connected.



If the temperature value is displayed as

"- -" the sensor in question is not connected.

"- - -" the sensor connection is short-circuited.

DHW circuit


Overview display 1 informs about:
actual DHW temperature, controller mode, desired DHW temperature as well as the comfort schedule of the current day.

Overview display 2 informs about:
state of the controlled components, actual DHW temperature, (desired DHW temperature), controller mode, return temperature (limitation value), influence on desired DHW temperature.


Dependent on chosen display, the overview displays for the DHW circuit inform you about:

- actual DHW temperature (50.3)
- controller mode (M1)
- desired DHW temperature (50 °C)
- comfort schedule of the current day (0 - 12 - 24)
- state of the controlled components (M1, P1)
- actual DHW temperature (50 °C), (desired DHW temperature (50))
- return temperature (- - °C) (limitation temperature (30))


Overview display 1:



Overview display 2:



Example of overview display with Influence indication:



Setting the desired temperature


Depending on the chosen circuit and mode, it is possible to enter all daily settings directly from the overview displays (see also the next page concerning symbols).

Operating Guide ECL Comfort 210/296/310, application A275/A375

Setting the desired room temperature

The desired room temperature can easily be adjusted in the overview displays for the heating circuit.

Action:	Purpose:	Examples:
	Desired room temperature	20.5
	Confirm	
	Adjust the desired room temperature	21.0
	Confirm	



This overview display informs about outdoor temperature, actual room temperature as well as desired room temperature.

The display example is for comfort mode. If you want to change the desired room temperature for saving mode, choose the mode selector and select saving.




The setting of the desired room temperature is important even if a room temperature sensor / Remote Control Unit is not connected.

Setting the desired DHW temperature

The desired DHW temperature can easily be adjusted in the overview displays for the DHW circuit.

Action:	Purpose:	Examples:
	Desired DHW temperature	50
	Confirm	
	Adjust the desired DHW temperature	55
	Confirm	



In addition to the information about desired and actual DHW temperature, the today's schedule is visible.

The display example indicates that the controller is in scheduled operation and in comfort mode.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Setting the desired room temperature, ECA 30 / ECA 31

The desired room temperature can be set exactly as in the controller. However, other symbols can be present in the display (please see 'What do the symbols mean?').



With the ECA 30 / ECA 31 you can override the desired room temperature set in the controller temporarily by means of the override functions: 

Operating Guide ECL Comfort 210/296/310, application A275/A375

3.3 A general overview: What do the symbols mean?

Symbol	Description	
	Outdoor temp.	Temperature
	Relative humidity indoor	
	Room temp.	
	DHW temp.	
	Position indicator	
	Scheduled mode	Mode
	Comfort mode	
	Saving mode	
	Frost protection mode	
	Manual mode	
	Standby	
	Cooling mode	
	Active output override	
	Optimized start or stop time	
	Heating	Circuit
	Cooling	
	DHW	
	Common controller settings	
	Pump ON	Controlled component
	Pump OFF	
	Fan ON	
	Fan OFF	
	Actuator opens	
	Actuator closes	
	Actuator, analogue control signal	
	Pump / fan speed	
	Damper ON	
	Damper OFF	

Symbol	Description
	Alarm
	Letter
	Event
	Monitoring temperature sensor connection
	Display selector
	Max. and min. value
	Trend in outdoor temperature
	Wind speed sensor
	Sensor not connected or not used
	Sensor connection short-circuited
	Fixed comfort day (holiday)
	Active influence
	Heating active (+) Cooling active (-)
	Number of heat exchangers

Additional symbols, ECA 30 / 31:

Symbol	Description
	ECA Remote Control Unit
	Connection address (master: 15, slaves: 1 - 9)
	Day off
	Holiday
	Relaxing (extended comfort period)
	Going out (extended saving period)

In ECA 30 / 31 only the symbols that are relevant to the application in the controller are displayed.

Operating Guide ECL Comfort 210/296/310, application A275/A375

3.4 Monitoring temperatures and system components

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.


Boiler circuit

The overview display in the boiler circuit ensures a quick overview of the actual and (desired) temperatures as well as the actual state of the system components.

Display example:

49 °C	Boiler temperature
(45)	Desired boiler temperature
25 °C	Return temperature
(35)	Return temperature limitation

The display example is from an A375 application with 4 boilers. In the A275 applications, the display will only show 1 boiler.




Heating circuit

The overview display in the heating circuit ensures a quick overview of the actual and (desired) temperatures as well as the actual state of the system components.

Display example:

49 °C	Flow temperature
(31)	Desired flow temperature
24 °C	Return temperature
(50)	Return temperature limitation




DHW circuit

The overview display in the DHW circuit ensures a quick overview of the actual and (desired) temperatures as well as the actual state of the system components.

Display example (heat exchanger):

50 °C	Flow temperature
(50)	Desired flow temperature
- -	Return temperature: sensor not connected
(30)	Return temperature limitation

Display example with heat exchanger:



Input overview

Another option to get a quick overview of measured temperatures is the 'Input overview' which is visible in the common controller settings (how to enter the common controller settings, see 'Introduction to common controller settings')

As this overview (see display example) only states the measured actual temperatures, it is read-only.

MENU 	
Input overview:	
► Outdoor T	7.0 °C
Outdoor acc. T	5.8 °C
Heat return T	35.5 °C
Heat flow T	67.9 °C
DHW flow T	68.6 °C

3.5 Influence overview

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The menu gives an overview of the influences on the desired flow temperature. It differs from application to application which parameters are listed. It can be helpful in a service situation to explain unexpected conditions or temperatures among others.

If the desired flow temperature is influenced (corrected) by one or more parameters, it is indicated by a small line with arrow-down, arrow-up or double-arrow:

Arrow-down:

The parameter in question reduces the desired flow temperature.

Arrow-up:

The parameter in question increases the desired flow temperature.

Double-arrow:




The parameter in question creates an override (e.g. Holiday).

Straight line:

No active influence.

In the example, the arrow in the symbol points downwards for 'Room lim.'. This means that the actual room temperature is higher than the desired room temperature which again results in a decrease of the desired flow temperature.

Example of overview display with Influence indication:



Operating Guide ECL Comfort 210/296/310, application A275/A375


3.6 Manual control

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

It is possible to manually control the installed components.

Manual control can only be selected in favorite displays in which the symbols for the controlled components (valve, pump etc.) are visible.

Action:	Purpose:	Examples:
	Choose mode selector	
	Confirm	
	Choose manual mode	
	Confirm	
	Choose pump	
	Confirm	
	Switch ON the pump	
	Switch OFF the pump.	
	Confirm pump mode	
	Choose motorized control valve	
	Confirm	
	Open the valve	
	Stop opening the valve	
	Close the valve	
	Stop closing the valve	
	Confirm valve mode	



During manual operation:

- All control functions are deactivated
- Output override is not possible
- Frost protection is not active



When manual control is selected for one circuit, it is automatically selected for all circuits!

To leave manual control, use the mode selector to select the desired mode. Push the dial.

Manual control is typically used when commissioning the installation. The controlled components, valve, pump etc., can be controlled for correct function.

Operating Guide ECL Comfort 210/296/310, application A275/A375

3.7 Schedule

3.7.1 Set your schedule

This section describes the schedule in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application. In some applications, however, there might be more than one schedule. Additional schedules can be found in 'Common controller settings'.

The schedule consists of a 7-day week:

M = Monday
T = Tuesday
W = Wednesday
T = Thursday
F = Friday
S = Saturday
S = Sunday

The schedule will day-by-day show you the start and stop times of your comfort periods (heating / DHW circuits).




Changing your schedule:

Action:	Purpose:	Examples:
	Choose 'MENU' in any of the overview displays	MENU
	Confirm	
	Confirm the choice 'Schedule'	
	Choose the day to change	▶
	Confirm*	T
	Go to Start1	
	Confirm	
	Adjust the time	
	Confirm	
	Go to Stop1, Start2 etc. etc.	
	Return to 'MENU'	MENU
	Confirm	
	Choose 'Yes' or 'No' in 'Save'	
	Confirm	

* Several days can be marked

The chosen start and stop times will be valid for all the chosen days (in this example Thursday and Saturday).

You can set max. 3 comfort periods a day. You can delete a comfort period by setting start and stop times to the same value.



Each circuit has its own schedule. To change to another circuit, go to 'Home', turn the dial and choose the desired circuit.



The start and stop times can be set in half-hourly (30 min.) intervals.

Operating Guide ECL Comfort 210/296/310, application A275/A375

4.0 Settings overview

For factory settings and setting range, see appendix "Parameter ID overview".

Parameters indicated with an ID no. like "1x607" mean a universal parameter. x stands for circuit / parameter group.

Setting	ID	Page	Factory settings in circuit(s)		
			1	2	3
Heat curve		94			
Ext. desired T — (ECL Comfort 310)		96			
Day		143			
Start time		143			
Duration		144			
Desired T		144			
Control, delay	11364	120			
Min. off time	11424	120			
Low X	11607	121			
High X	11608	121			
Low X	13607	138			
High X	13608	138			
Desired T (Desired flow temperature)	1x004	96			
ECA addr. (ECA address, choice of Remote Control Unit)	1x010	127			
Auto saving (saving temp. dependent on outdoor temp.)	1x011	108			
Boost	1x012	109			
Ramp (reference ramping)	1x013	110			
Optimizer (optimizing time constant)	1x014	110			
Adapt. time (adaption time)	1x015	101			
Demand offset	1x017	127			
Based on (optimization based on room / outdoor temp.)	1x020	111			
Total stop	1x021	111			
P exercise (pump exercise)	1x022	127			
M exercise (valve exercise)	1x023	127			
Actuator	1x024	123			
Pre-stop (optimized stop time)	1x026	112			
Con.T, re. T lim. (Constant temperature mode, return temperature limitation)	1x028	104			
DHW, ret. T limit	1x029	104			
High T out X1 (return temp. limitation, high limit, X-axis)	1x031	105			
Low limit Y1 (return temp. limitation, low limit, Y-axis)	1x032	105			
Low T out X2 (return temp. limitation, low limit, X-axis)	1x033	105			
High limit Y2 (return temp. limitation, high limit, Y-axis)	1x034	105			
Infl. - max. (return temp. limitation - max. influence)	1x035	106			
Infl. - min. (return temp. limitation - min. influence)	1x036	106			
Adapt. time (adaptation time)	1x037	106			
Stop at T out	1x038	114			
P post-run	1x040	128			
DHW P post-run (DHW pump, post-run)	1x041	128			

Operating Guide ECL Comfort 210/296/310, application A275/A375

Setting	ID	Page	Factory settings in circuit(s)		
			1	2	3
Difference	1x046	114			
Protection	1x047	114			
Band limit (subtypes A375.1, A375.2 and A375.3)	1x048	115			
Max. T limit	1x049	115			
P demand	1x050	128			
Ch.-o. valve / P (changeover valve / pump)	1x051	128			
DHW priority (closed valve / normal operation)	1x052	129			
Tank, sec. / prim. (Tank secondarily or primarily connected)	1x053	129			
Circ. P priority	1x055	129			
Min. ON time	1x071	116			
Sequence type (subtypes A375.1, A375.2, A375.3)	1x072	116			
Steps (subtypes A375.1, A375.2, A375.3)	1x073	117			
Reaction, o. band (outside band) (subtypes A375.1, A375.2, A375.3)	1x074	117			
Reaction, in band (subtypes A375.1, A375.2, A375.3)	1x075	118			
Circ. P frost T	1x076	130			
P frost T (circulation pump, frost protection temp.)	1x077	130			
P heat T (heat demand)	1x078	130			
Priority (priority for return temp. limitation)	1x085	106			
Frost pr. T (frost protection temp.)	1x093	130			
Ext. input (external override)	1x141	131			
Ext. mode (external override mode)	1x142	131			
Upper difference	1x147	139			
Lower difference	1x148	139			
Delay, example	1x149	141			
Lowest temp.	1x150	141			
Motor pr. (motor protection)	1x174	123			
Temp. min.	1x177	96			
Temp. max.	1x178	96			
Summer, cut-out (limit for heating cut-out)	1x179	112			
Infl. - max. (room temp. limitation, max.)	1x182	101			
Infl. - min. (room temp. limitation, min.)	1x183	102			
Xp (proportional band)	1x184	119			
Xp (proportional band)	1x184	124			
Tn (integration time constant)	1x185	119			
Tn (integration time constant)	1x185	124			
M run (running time of the motorized control valve)	1x186	119			
M run (running time of the motorized control valve)	1x186	124			
Nz (neutral zone)	1x187	120			
Nz (neutral zone)	1x187	124			
Min. act. time (min. activation time gear motor)	1x189	120			
Min. act. time (min. activation time gear motor)	1x189	125			
Charge difference	1x193	98			

Operating Guide ECL Comfort 210/296/310, application A275/A375

Setting	ID	Page	Factory settings in circuit(s)		
			1	2	3
Stop difference	1x194	98			
Start difference	1x195	99			
Send desired T	1x500	133			
Alarm high	1x614	138			
Alarm low	1x615	138			
Alarm time-out	1x617	139			

5.0 Settings

5.1 Introduction to Settings

Descriptions of settings (parameter's functions) are divided into groups as used in the ECL Comfort 210 / 296 / 310 controller's menu structure. Examples: "Flow temperature", "Room limit" and so on. Each group starts with a general explanation.

The descriptions of each parameter are in numeric order, related to the parameter's ID numbers. You might come across differences between the order in this Operating Guide and the ECL Comfort 210 / 296 / 310 controllers.

Some parameter descriptions are related to specific application subtypes. This means that you might not see the related parameter in the actual subtype in the ECL controller.

The note "See Appendix ..." refers to the Appendix at the end of this Operating Guide, where parameter's setting ranges and factory settings are listed.

The navigation hints (for example MENU > Settings > Return limit ...) cover multiple subtypes.

Operating Guide ECL Comfort 210/296/310, application A275/A375

5.2 Flow (boiler) temperature

The ECL Comfort controller determines and controls the flow temperature related to the outdoor temperature. This relationship is called the heat curve.

The heat curve is set by means of 6 coordinate points. The desired flow temperature is set at 6 pre-defined outdoor temperature values.

The shown value for the heat curve is an average value (slope), based on the actual settings.

Outdoor temp.	Desired flow temp.			Your settings
	A	B	C	
-30 °C	45 °C	75 °C	95 °C	
-15 °C	40 °C	60 °C	90 °C	
-5 °C	35 °C	50 °C	80 °C	
0 °C	32 °C	45 °C	70 °C	
5 °C	30 °C	40 °C	60 °C	
15 °C	25 °C	28 °C	35 °C	

Adjust the desired flow temperature at -30, -15, -5, 0, 5, and 15 °C, if required.

A: Example for floor heating

B: Factory settings

C: Example for radiator heating (high demand)

MENU > Settings > Flow (boiler) temperature

Heat curve		
Circuit	Setting range	Factory setting
2	0.1 ... 4.0	1.0

The heat curve can be changed in two ways:

1. The value of the slope is changed (see heat curve examples on next page)
2. The coordinates of the heat curve are changed

Change the value of the slope:

Push the dial to enter / change the slope value of the heat curve (example: 1.0).

When the slope of the heat curve is changed by means of the slope value, the common point for all heat curves will be a desired flow temperature = 24.6 °C at an outdoor temperature = 20 °C

Change the coordinates:

Push the dial to enter / change the coordinates of the heat curve (example: -30,75).



The heat curve represents the desired flow temperatures at different outdoor temperatures and at a desired room temperature of 20 °C.

If the desired room temperature is changed, the desired flow temperature also changes:


$(\text{Desired room } T - 20) \times HC \times 2.5$

where "HC" is the Heat Curve slope and "2.5" is a constant.


Desired flow temperature



Slope changes



Coordinate changes



The calculated flow temperature can be influenced by the 'Boost' and 'Ramp' functions etc.


Example:

Heat curve: 1.0
 Desired flow temp.: 50 °C
 Desired room temp.: 22 °C
 Calculation $(22 - 20) \times 1.0 \times 2.5 = 5$
 Result:
 The desired flow temperature will be corrected from 50 °C to 55 °C.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Choosing a heat curve slope

The heat curves represent the desired flow temperature at different outdoor temperatures and at a desired room temperature of 20 °C.




The small arrows (▲) indicate 6 different outdoor temperature values at which you can change the heat curve.

The ECL Comfort 210 / 296 / 310 controls the DHW temperature according to the desired flow temperature for example under the influence of the return temperature.

The desired DHW temperature is set in the overview display.

50.3: Actual DHW temperature

50: Desired DHW temperature



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Flow (boiler) temperature

Desired T (Desired flow temperature)	1x004
---	--------------

When the ECL Comfort is in override mode, type "Const. T", the desired flow temperature can be set.
A "Const. T" related return temperature limitation can also be set. See MENU > Settings > Return limit > 'Con. T, ret. T lim.'

See Appendix "Parameter ID overview"



Override mode

When ECL Comfort is in Scheduled mode, a contact (switch) signal can be applied to an input in order to override to Comfort, Saving, Frost Protection or Constant temperature. As long as the contact (switch) signal is applied, the override is active.



The "Desired T" value can be influenced by:

- temp. max.
- temp. min.
- room temp. limit
- return temp. limit
- flow / power limit

MENU > Settings > Flow (boiler) temperature

Temp. min.	1x177
-------------------	--------------

See Appendix "Parameter ID overview"

Set the min. flow temperature for the system. The desired flow temperature will not be lower than this setting. Adjust the factory setting, if required.



'Temp. min.' is overruled if 'Total stop' is active in Saving mode or 'Cut-out' is active.

'Temp. min.' can be overruled by the influence from the return temperature limitation (see 'Priority').



The setting for 'Temp. max.' has higher priority than 'Temp. min.'

MENU > Settings > Flow (boiler) temperature

Temp. max.	1x178
-------------------	--------------

See Appendix "Parameter ID overview"

Set the max. flow temperature for the system. The desired temperature will not be higher than this setting. Adjust the factory setting, if required.



The setting of 'heat curve' is possible for heating circuits only.



The setting for 'Temp. max.' has higher priority than 'Temp. min.'

Operating Guide ECL Comfort 210/296/310, application A275/A375

External signal for desired flow temperature

A voltage (0 - 10 V) can be applied to the input terminal S10 in order to determine the desired flow temperature.

The measured voltage on input S10 must be converted to a temperature value by the controller. When the voltage gets higher, the desired flow temperature increases.

The following settings set up the scaling.

MENU > Settings > Flow (boiler) temperature

Ext. desired T — (ECL Comfort 310)		
Circuit	Setting range	Factory setting
1	Read-out only	
The actual desired flow temperature is indicated by the unit °C.		

Read-out:

- : External voltage signal is not connected..
- °C: External voltage signal converted to desired flow temperature.


Push the dial to see the graph and enter the value sets for the input voltage (1 and 10 volt) and displayed desired flow temperature.

Desired flow temperature: 10 ... 120 °C
 Fixed voltage settings: 1 V and 10 V
 Factory settings: (1,10) and (10,100)


This means that the 'Desired flow temperature' is 10 °C at 1.0 V and 100 °C at 10 V.

Typically, the higher the voltage, the higher the displayed desired flow temperature.

Example: Relationship between input voltage and displayed desired flow temperature



This example shows that 1 volt corresponds to 10.0 °C and 10 volt correspond to 100 °C.



The external voltage signal must be higher than 1.0 V in order to activate the override.

5.3 Tank temperature



Parameters indicated with an ID no. like "1x607" mean a universal parameter.

x stands for circuit / parameter group.

MENU > Settings > Tank temperature


Charge difference

1x193

Set the number of degrees above the desired DHW temperature that will result in the DHW heating (charging) temperature.

See Appendix "Parameter ID overview"

Value: Number of degrees to be added to the desired DHW temperature to obtain the DHW heating (charging) temperature.



- X = Time
- # 1 # = Charging difference (ID 1x193)
- # 2 # = Desired DHW temperature
- # 3 # = Start difference (ID 1x195)
- # 4 # = Actual DHW temperature
- # 5 # = DHW heating / charging activity



The desired DHW temperature is related to the tank temperature sensor.

If two tank temperature sensors are installed, the relation is to the upper tank temperature sensor.

Operating Guide ECL Comfort 210/296/310, application A275/A375


MENU > Settings > Tank temperature

Stop difference	1x194
<i>Set the number of degrees above or below the desired DHW temperature that will stop the DHW heating / charging.</i>	

See Appendix "Parameter ID overview"


Value: Set the number of degrees.

One DHW tank temperature sensor (example with positive 'Stop difference' value):



- X = Time
- # 1 # = Stop difference (ID 1x194)
- # 2 # = Desired DHW temperature
- # 3 # = Actual DHW temperature
- # 4 # = DHW heating / charging activity

One DHW tank temperature sensor (example with negative 'Stop difference' value):



- X = Time
- # 1 # = Stop difference (ID 1x194)
- # 2 # = Desired DHW temperature
- # 3 # = Actual DHW temperature
- # 4 # = DHW heating / charging activity

Operating Guide ECL Comfort 210/296/310, application A275/A375


MENU > Settings > Tank temperature

Start difference **1x195**

Set the number of degrees below the desired DHW temperature that will start the DHW heating (charging).

See Appendix "Parameter ID overview"

Value: Set the number of degrees.



- X = Time
- # 1 # = Charging difference (ID 1x193)
- # 2 # = Desired DHW temperature
- # 3 # = Start difference (ID 1x195)
- # 4 # = Actual DHW temperature
- # 5 # = DHW heating / charging activity

Example:

Desired DHW temp.: 55 °C

Start difference: -3 K

Result:

The DHW heating starts when the temperature measured by the tank temperature sensor (upper) is lower than 52 °C.

Operating Guide ECL Comfort 210/296/310, application A275/A375

5.4 Room limit

The following section is a general description for Room temperature limitation.
The actual application might not have both limitation types.

This section is only relevant if you have installed a room temperature sensor or a Remote Control Unit for utilizing the room temperature signal.

In the following description is referred to "flow temperature" in general.

The controller adjusts the desired flow temperature to compensate for the difference between the desired and the actual room temperature.

If the room temperature is higher than the desired value, the desired flow temperature can be reduced.

The 'Infl. -max.' (Influence, max. room temp.) determines how much the desired flow temperature should be reduced.

Use this influence type to avoid a too high room temperature. The controller will allow for free heat gains, i.e. solar radiation or heat from a fire place etc.

If the room temperature is lower than the desired value, the desired flow temperature can be increased.

The 'Infl. -min.' (Influence, min. room temperature) determines how much the desired flow temperature should be increased.

Use this influence type to avoid a too low room temperature. This could e.g. be caused by windy surroundings.

A typical setting will be -4.0 for 'Infl. -max.' and 4.0 for 'Infl. -min.'



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.

MENU > Settings > Room limit

Adapt. time (adaption time)	1x015
<i>Controls how fast the actual room temperature adapts to the desired room temperature (I control).</i>	



The adaptation function can correct the desired room temperature with max. 8 K x heat curve slope value.

See Appendix "Parameter ID overview"

OFF: The control function is not influenced by the 'Adapt. time'.

Minor value: The desired room temperature is adapted quickly.

Major value: The desired room temperature is adapted slowly.

Operating Guide ECL Comfort 210/296/310, application A275/A375


MENU > Settings > Room limit

Infl. - max. (room temp. limitation, max.) **1x182**

Determines how much the desired flow temperature will be influenced (decreased) if the actual room temperature is higher than the desired room temperature (P control).

See Appendix "Parameter ID overview"

0.0:	No influence
-2.0:	Minor influence
-5.0:	Medium influence
-9.9:	Maximum influence



The 'Infl. - max.' and 'Infl. - min.' determine how much the room temperature should influence the desired flow temperature.



If the 'Infl.' factor is too high and / or the 'Adapt. time' too low, there is a risk of unstable control.

Example

The actual room temperature is 2 degrees too high.
The 'Infl. - max.' is set to -4.0.
The heat curve slope is 1.8 (see 'Heat curve' in 'Flow temperature').
Result:
The desired flow temperature is changed by $(2 \times -4.0 \times 1.8)$
-14.4 degrees.

In application subtypes, where a heat curve slope value is **not** present, the heat curve slope value is set to 1:

Result:
The desired flow temperature is changed by $(2 \times -4.0 \times 1)$:
-8.0 degrees.

MENU > Settings > Room limit

Infl. - min. (room temp. limitation, min.) **1x183**

Determines how much the desired flow temperature will be influenced (increased) if the actual room temperature is lower than the desired room temperature (P control).

See Appendix "Parameter ID overview"

9.9:	Maximum influence
5.0:	Medium influence
2.0:	Minor influence
0.0:	No influence

Example

The actual room temperature is 2 degrees too low.
The 'Infl. - min.' is set to 4.0.
The heat curve slope is 1.8 (see 'Heat curve' in 'Flow temperature').
Result:
The desired flow temperature is changed by $(2 \times 4.0 \times 1.8)$
14.4 degrees.

In application subtypes, where a heat curve slope value is **not** present, the heat curve slope value is set to 1:


Result:
The desired flow temperature is changed by $(2 \times 4.0 \times 1)$:
8.0 degrees.

5.5 Return limit

The return temperature limitation is based on the outdoor temperature. Typically in district heating systems a higher return temperature is accepted at a decrease in outdoor temperature. The relationship between the return temperature limits and outdoor temperature is set in two coordinates.


The outdoor temperature coordinates are set in 'High T out X1' and 'Low T out X2'. The return temperature coordinates are set in 'High limit Y2' and 'Low limit Y1'.

The controller automatically changes the desired flow temperature to obtain an acceptable return temperature when the return temperature falls below or gets higher than the calculated limit. This limitation is based on a PI regulation where P ('Infl.' factor) responds quickly to deviations and I ('Adapt. time') responds slower and over time removes the small offsets between the desired and actual values. This is done by changing the desired flow temperature.




The calculated limit is shown in brackets () in the monitoring display. See the section "Monitoring temperatures and system components".

Example, maximum return temperature limitation; return temperature gets higher than limit



Operating Guide ECL Comfort 210/296/310, application A275/A375

Example, minimum return temperature limitation;
return temperature gets lower than limit



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.

MENU > Settings > Return limit

Con.T, re. T lim. (Constant temperature mode, return temperature limitation) **1x028**

The "Con. T, re. T limit" is the return temperature limitation value when the circuit is set to override mode type "Const. T" (= Constant temperature).

See Appendix "Parameter ID overview"

Value: Set the return temperature limitation



Override mode

When ECL Comfort is in Scheduled mode, a contact (switch) signal can be applied to an input in order to override to Comfort, Saving, Frost Protection or Constant temperature. As long as the contact (switch) signal is applied, the override is active.

Operating Guide ECL Comfort 210/296/310, application A275/A375


MENU > Settings > Return limit

DHW, ret. T limit	1x029
When an addressed slave is active in DHW-tank heating / charging, the return temperature limitation in the master can be set. Notes: - The master circuit must be set to react on the desired flow temperature in the slave(s). See "Demand offset" (ID 11017). - The slave(s) must be set to send its / their desired flow temperature to the master. See "Send desired T" (ID 1x500).	

See Appendix "Parameter ID overview"

OFF: No influence from slaves. The return temperature limitation is related to settings in "Return limit".

Value: Return temperature limitation value when slave is in DHW tank heating / charging operation.



Some examples of applications with DHW-tank heating / charging are:

- A217, A237, A247, A367, A377

MENU > Settings > Return limit

High T out X1 (return temp. limitation, high limit, X-axis)	1x031
Set the outdoor temperature value for the low return temperature limitation.	

See Appendix "Parameter ID overview"

The corresponding Y coordinate is set in 'Low limit Y1'.

MENU > Settings > Return limit

Low limit Y1 (return temp. limitation, low limit, Y-axis)	1x032
Set the return temperature limitation referring to the outdoor temperature value set in 'High T out X1'.	

See Appendix "Parameter ID overview"

The corresponding X coordinate is set in 'High T out X1'.

MENU > Settings > Return limit

Low T out X2 (return temp. limitation, low limit, X-axis)	1x033
Set the outdoor temperature value for the high return temperature limitation.	

See Appendix "Parameter ID overview"

The corresponding Y coordinate is set in 'High limit Y2'.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Return limit

High limit Y2 (return temp. limitation, high limit, Y-axis)	1x034
--	--------------

<i>Set the return temperature limitation referring to the outdoor temperature value set in 'Low T out X2'.</i>	
--	--

See Appendix "Parameter ID overview"

The corresponding X coordinate is set in 'Low T out X2'.

MENU > Settings > Return limit

Infl. - max. (return temp. limitation - max. influence)	1x035
--	--------------

<i>Determines how much the desired flow temperature will be influenced if the return temperature is higher than the set limit.</i>	
--	--

See Appendix "Parameter ID overview"

Influence higher than 0:

The desired flow temperature is increased, when the return temperature gets higher than the set limit.

Influence lower than 0:

The desired flow temperature is decreased, when the return temperature gets higher than the set limit.

Example

The return limit is active above 50 °C.

The influence is set to 0.5.

The actual return temperature is 2 degrees too high.

Result:

The desired flow temperature is changed by $0.5 \times 2 = 1.0$ degree.

MENU > Settings > Return limit

Infl. - min. (return temp. limitation - min. influence)	1x036
--	--------------

<i>Determines how much the desired flow temperature will be influenced if the return temperature is lower than the calculated limit.</i>	
--	--

See Appendix "Parameter ID overview"

Influence higher than 0:

The desired flow temperature is increased, when the return temperature gets below the calculated limit.

Influence lower than 0:

The desired flow temperature is decreased, when the return temperature gets below the calculated limit.

Example

The return limit is active below 50 °C.

The influence is set to -3.0.

The actual return temperature is 2 degrees too low.

Result:

The desired flow temperature is changed by $-3.0 \times 2 = -6.0$ degrees.



Normally, this setting is 0 in district heating systems because a lower return temperature is acceptable.

Typically, this setting is higher than 0 in boiler systems to avoid a too low return temperature (see also 'Infl. - max').

MENU > Settings > Return limit

Adapt. time (adaptation time)	1x037
--------------------------------------	--------------

<i>Controls how fast the return temperature adapts to the desired return temperature limit (Integration control).</i>	
---	--

See Appendix "Parameter ID overview"

OFF: The control function is not influenced by the 'Adapt. time'.

Minor value: The desired temperature is adapted quickly.

Major value: The desired temperature is adapted slowly.



The adaptation function can correct the desired flow temperature with max. 8 K.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Return limit

Priority (priority for return temp. limitation)	1x085
<i>Choose whether the return temperature limitation should overrule the set min. flow temperature 'Temp. min.'.</i>	

See Appendix "Parameter ID overview"

OFF: The min. flow temperature limit is not overruled.

ON: The min. flow temperature limit is overruled.



If you have a DHW application:
Please also see 'Parallel operation' (ID 11043).



If you have a DHW application:
When dependent parallel operation is in function:

- Desired flow temperature for the heating circuit will be minimum limited, when "Priority for return temperature" (ID 1x085) is set to OFF.
- Desired flow temperature for the heating circuit will not be minimum limited, when "Priority for return temperature" (ID 1x085) is set to ON.

5.6 Optimization

The section "Optimization" describes specific application related issues.

The parameters 'Auto saving', 'Boost', 'Optimizer', 'Total stop' are all related to heating mode only.

'Summer, cut-out' determine, at rising outdoor temperature, the stop of heating.



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Optimization

Auto saving (saving temp. dependent on outdoor temp.) 1x011

Below the set value for the outdoor temperature, the saving temperature setting has no influence. Above the set value for the outdoor temperature, the saving temperature relates to the actual outdoor temperature. The function is relevant in district heating installations in order to avoid a big change in the desired flow temperature after a saving period.

See Appendix "Parameter ID overview"


OFF: The saving temperature does not depend on the outdoor temperature; the reduction is 100%.

Value: The saving temperature depends on the outdoor temperature. When the outdoor temperature is above 10 °C, the reduction is 100%. The lower the outdoor temperature, the less the temperature reduction. Below the set value, the saving temperature setting has no influence.

Comfort temperature: The desired room temperature in Comfort mode

Saving temperature: The desired room temperature in Saving mode

The desired room temperatures for Comfort and Saving modes are set in the display overviews.



X = Outdoor temperature (°C)
Y = Desired room temperature (°C)
1 # = Desired room temperature (°C), Comfort mode
2 # = Desired room temperature (°C), Saving mode
3 # = Auto saving temperature (°C), ID 11011


Example:

Actual outdoor temperature (T.out): -5 °C
Desired room temperature setting in Comfort mode: 22 °C
Desired room temperature setting in Saving mode: 16 °C
Setting in 'Auto saving': -15 °C

The condition for the outdoor temperature influence:

$$\text{T.out.influence} = (10 - \text{T.out}) / (10 - \text{setting}) = (10 - (-5)) / (10 - (-15)) = 15 / 25 = 0,6$$

The corrected desired room temperature in Saving mode:
 $\text{T.room.ref.Saving} + (\text{T.out.influence} \times (\text{T.room.ref.Comfort} - \text{T.room.ref.Saving}))$
 $16 + (0,6 \times (22 - 16)) = 19,6 \text{ °C}$



X = Outdoor temperature (°C)
Y = Desired room temperature (°C)

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Optimization

Boost	1x012
<i>Shortens the heating-up period by increasing the desired flow temperature by the percentage you set.</i>	

See Appendix "Parameter ID overview"

OFF: The boost function is not active.

Value: The desired flow temperature is increased temporarily with the set percentage.

In order to shorten the heating-up period after a saving temperature period, the desired flow temperature can be increased temporarily (max. 1 hour). At optimizing the boost is active in the optimization period ('Optimizer').
If a room temperature sensor or an ECA 30 / 31 is connected, the boost stops when the room temperature is reached.

MENU > Settings > Optimization


Ramp (reference ramping)	1x013
<i>The time (minutes) in which the desired flow temperature increases gradually to avoid load peaks in the heat supply.</i>	

See Appendix "Parameter ID overview"

OFF: The ramping function is not active.

Value: The desired flow temperature is increased gradually with the set minutes.

In order to avoid load peaks in the supply network, the flow temperature can be set to increase gradually after a period with saving temperature. This causes the valve to open gradually.



Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Optimization

Optimizer (optimizing time constant)	1x014
Optimizes the start and stop times for the comfort temperature period to obtain the best comfort at the lowest energy consumption. The lower the outdoor temperature, the earlier the heating cut-in. The lower the outdoor temperature, the later the heating cut-out. The optimized heating cut-out time can be automatic or disabled. The calculated start and stop times are based on the setting of the optimizing time constant.	

See Appendix "Parameter ID overview"

Adjust the optimizing time constant.

The value consists of a two digit number. The two digits have the following meaning (digit 1 = Table I, digit 2 = Table II).

OFF: No optimization. The heating starts and stops at the times set in the schedule.

10 ... 59: See tables I and II.

Table I:

Left digit	Heat accumulation of the building	System type
1-	light	Radiator systems
2-	medium	
3-	heavy	
4-	medium	Floor heating systems
5-	heavy	

Table II:

Right digit	Dimensioning temperature	Capacity
-0	-50 °C	large
-1	-45 °C	.
.	.	.
-5	-25 °C	normal
.	.	.
-9	-5 °C	small

Dimensioning temperature:

The lowest outdoor temperature (usually determined by your system designer in connection with the design of the heating system) at which the heating system can maintain the designed room temperature.

Example

The system type is radiator, and the heat accumulation of the building is medium.

The left digit is 2.

The dimensioning temperature is -25 °C, and the capacity is normal.

The right digit is 5.

Result:

The setting is to be changed to 25.

MENU > Settings > Optimization

Based on (optimization based on room / outdoor temp.)	1x020
The optimized start and stop time can be based on either room or outdoor temperature.	

See Appendix "Parameter ID overview"

OUT: Optimization based on outdoor temperature. Use this setting if the room temperature is not measured.

ROOM: Optimization based on room temperature, if measured.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Optimization

Total stop **1x021**

Decide whether you want a total stop during the saving temperature period.


See Appendix "Parameter ID overview"

OFF: No total stop. The desired flow temperature is reduced according to:


- desired room temperature in saving mode
- auto saving

ON: The desired flow temperature is lowered to the set value in 'Frost pr.'. The circulation pump is stopped but frost protection is still active, see 'P frost T'.

Total stop = OFF



Total stop = ON



X = Time
Y = Desired flow temperature
☀ = Comfort temperature
☾ = Saving temperature
❄ = Frost protection



The min. flow temperature limitation ('Temp. min.') is overruled when 'Total stop' is ON.

MENU > Settings > Optimization

Pre-stop (optimized stop time) **1x026**


Disable the optimized stop time.

See Appendix "Parameter ID overview"

OFF: The optimized stop time is disabled.

ON: The optimized stop time is enabled.

Example: Optimization of Comfort from 07:00 - 22:00



X = Time
1# = Schedule
2# = Prestop = OFF
3# = Prestop = ON
4# = Optimized start
5# = Optimized stop

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Optimization

Summer, cut-out (limit for heating cut-out)

1x179

See Appendix "Parameter ID overview"


The heating can be switched OFF when the outdoor temperature is higher than the set value. The valve closes and after the post-run time, the heating circulation pump stops. 'Temp. min.' will be overruled.

The heating system switches ON again when the outdoor temperature and the accumulated (filtered) outdoor temperature become lower than the set limit.

This function can save energy.

Set the value for outdoor temperature at which you want the heating system to switch OFF.

Summer, cut-out



The heating cut-out is only active when the controller mode is in scheduled operation. When the cut-out value is set to OFF, there is no heating cut-out.

5.7 Boiler



Parameters indicated with an ID no. like "1x607" mean a universal parameter.

x stands for circuit / parameter group.

MENU > Settings > Boiler

Stop at T out

1x038

Subtypes A275.1, A275.2, A275.3, A375.4 and A375.5:

If the outdoor temperature is higher than the set value, the burner will not be cut-in.

Subtypes A375.1, A375.2 and A375.3:

If the outdoor temperature is higher than the set value, the last burner step will not be cut-in.



The 'Stop at T out' can be used in connection with alternative heat supply sources such as heat pumps and solar systems.

See Appendix "Parameter ID overview"

-49 ... 49: Set the value for heat-stop or blocking the last burner step.

OFF: The 'Stop at T out' function is not active.

MENU > Settings > Boiler

Difference

1x046


The burner is switched ON and OFF to maintain the desired boiler temperature. Set the difference between the cut-in and cut-out temperature.

See Appendix "Parameter ID overview"

OFF: (Only in A275 applications):
The boiler temperature difference is set automatically according to the momentary load of the boiler and the temperature conditions in the heating system.

1 ... 50 K: The boiler temperature difference is set to a fixed value according to the boiler manufacturer specification.

Temp.



The boiler temperature difference is symmetrical around the desired boiler temperature, i.e. half the value is above and half the value is below this temperature.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Boiler

Protection	1x047
<i>Choose whether the circulation pump for the boiler circuit (P1) should be stopped to prevent condensation in the boiler during the heating-up period.</i>	

See Appendix "Parameter ID overview"

- OFF:** The circulation pump is controlled according to demand.
- The circulation pump is switched ON when:
- the desired flow (boiler) temperature is higher than the set value in ID no. 11078 'P heat T' or
 - the outdoor temperature is lower than the set value in ID no. 11077 'P frost T'.
- ON:** The circulation pump is switched OFF until the desired min. flow (boiler) temperature is reached.
- The min. flow (boiler) temperature is set in ID no. 11177 'Temp. min.'.



Typically, the heating-up period of an oil fired boiler must be as short as possible. This will reduce condensation in the furnace.

To obtain the best conditions for the boiler, the circulation pump (P1) can be switched OFF during the heating-up period.

The circulation pump will be switched ON when the actual flow (boiler) temperature is higher than the min. desired flow (boiler) temperature set in ID no. 11177 'Temp. min.' + half the boiler temperature difference in ID no. 11046 'Difference'.


The circulation pump will be switched OFF again if the actual flow (boiler) temperature is lower than the min. desired flow (boiler) temperature set in ID no. 11177 'Temp. min.'.

Example:

'Temp. min.' = 45 °C and 'Difference' = 8 K

The circulation pump will be switched ON when the actual flow (boiler) temperature is higher than $45 + 0.5 \times 8 = 49$ °C.

The circulation pump will be switched OFF when the flow (boiler) temperature gets lower than 45 °C.




MENU > Settings > Boiler

Band limit (subtypes A375.1, A375.2 and A375.3)	1x048
<i>The band limit determines when burners are cut-in and cut-out if there is a temperature difference between the desired and the actual flow (boiler) temperature.</i>	
<i>If the difference is more than the set value, the setting in ID 11074 'Reaction, o. band' determines the control of burner steps. If the difference is less than the set value, the setting in ID no. 11075 'Reaction in band' determines the control of burner steps.</i>	

See Appendix "Parameter ID overview"

5 ... 80 K: Set the band limit.



Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Boiler

Max. T limit	1x049
A275 applications: If the boiler / flow temperature exceeds the set value, the burner is cut-out. A375 applications (subtypes A375.1, A375.2 and A375.3): If the boiler / flow temperature exceeds the set value, burner steps are cut-out in intervals of 5 sec.	



'Max. T limit' overrules 'Min. ON time'.

See Appendix "Parameter ID overview"

40 ... 150: Set the limitation temperature.

MENU > Settings > Boiler

Min. ON time	1x071
Set the minimum operation time (minutes) for the burner.	



'Min. ON time' is overruled by 'Max. T limit'.

See Appendix "Parameter ID overview"

1 ... 9 m: The boiler can be protected against condensation / corrosion caused by insufficient heat-up time at each burner start. The protection is obtained by a minimum operation time of the burner. With this setting the boiler temperature difference (ID no. 11046 'Difference') is overruled.








Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Boiler

Sequence type (subtypes A375.1, A375.2, A375.3)	1x072
<i>Set the sequence type for the boiler system by means of a code.</i>	

See Appendix "Parameter ID overview"

Code:



The changeover takes place after midnight. However, the changeover to the next main boiler is carried out at a natural cut-out of a boiler (see example).

The symbol 'η' in the sequence type examples indicates the number of burner steps in the system.



A375.1:
B1 — B4 are controlled by the ECL Comfort controller
B5 — B8 are controlled by ECA 32

A375.2 / A375.3:
B1 — B2 are controlled by the ECL Comfort controller
B3 — B6 are controlled by ECA 32
B7 — B8 are controlled by the ECL Comfort controller

MENU > Settings > Boiler

Steps (subtypes A375.1, A375.2, A375.3)	1x073
<i>Number of burner steps to be controlled. See also 'Sequence type'.</i>	

See Appendix "Parameter ID overview"

1 ... 8: Set the number of burner steps.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Boiler

Reaction, o. band (outside band) (subtypes A375.1, A375.2, A375.3) 1x074

The set time (in seconds) determines the burner cut-in / cut-out when the boiler / flow temperature is outside the 'Band limit' ID no. 11048.

Two conditions must be met in order to cut-in / cut-out the next burner step:

- the set time has elapsed after the latest burner cut-in / cut-out
- the boiler / flow temperature is outside the band limit



See Appendix "Parameter ID overview"

5 ... 6000: Set the desired time.

The upper illustration shows a typical situation for burner step cut-in after a saving period. The temperature difference between the desired and the actual boiler / flow temperature is relatively large, i.e. outside the band limit.

The lower illustration shows a typical situation for burner step cut-out. The temperature difference between the desired and the actual boiler / flow temperature is relatively large, i.e. outside the band limit.

If the 'Max. T limit' (ID no. 11049) has been exceeded, the cut-out of the burner steps takes place every 5 seconds.



Operating Guide ECL Comfort 210/296/310, application A275/A375



MENU > Settings > Boiler

Reaction, in band (subtypes A375.1, A375.2, A375.3)	1x075
The set time (in seconds) determines the burner cut-in / cut-out when the boiler / flow temperature is inside the 'Band limit' ID no. 11048. Three conditions must be met in order to cut-in / cut-out the next burner step: - the set time has elapsed after the latest burner cut-in / cut-out - the boiler / flow temperature is inside the band limit - the change in boiler / flow temperature has been less than 1 K / minute (the temperature gradient is less than 1 K / minute)	

See Appendix "Parameter ID overview"

5 ... 6000: Set the desired time.

The illustration shows a typical situation where the actual boiler / flow temperature is relatively close to the desired boiler / flow temperature, i.e. inside the band limit.



MENU > Settings > Boiler

Xp (proportional band)	1x184
-------------------------------	--------------

See Appendix "Parameter ID overview"

Set the proportional band. A higher value will result in a stable but slow control of the flow temperature.

MENU > Settings > Boiler

Tn (integration time constant)	1x185
---------------------------------------	--------------

See Appendix "Parameter ID overview"

Set a high integration time constant (in seconds) to obtain a slow but stable reaction to deviations.

A low integration time constant will make the controller react fast but with less stability.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Boiler

M run (running time of the motorized control valve)	1x186
<i>'M run' is the time in seconds it takes the controlled component to move from fully closed to fully open position.</i>	

See Appendix "Parameter ID overview"

Set the 'M run' according to the examples or measure the running time by means of a stop watch.

How to calculate the running time of a motorized control valve

The running time of the motorized control valve is calculated using the following methods:

Seated valves

Running time = Valve stroke (mm) x actuator speed (sec. / mm)

Example: $5.0 \text{ mm} \times 15 \text{ sec. / mm} = 75 \text{ sec.}$

Rotating valves

Running time = Turning degrees x actuator speed (sec. / degr.)

Example: $90 \text{ degr.} \times 2 \text{ sec. / degr.} = 180 \text{ sec.}$

MENU > Settings > Boiler

Nz (neutral zone)	1x187
<i>When the actual flow temperature is within the neutral zone, the controller does not activate the motorized control valve.</i>	

See Appendix "Parameter ID overview"

Set the acceptable flow temperature deviation.

Set the neutral zone to a high value if you can accept a high variation in flow temperature.



The neutral zone is symmetrical around the desired flow temperature value, i.e. half the value is above and half the value is below this temperature.

MENU > Settings > Boiler

Min. act. time (min. activation time gear motor)	1x189
<i>The min. pulse period of 20 ms (milliseconds) for activation of the gear motor.</i>	

See Appendix "Parameter ID overview"

Setting example	Value x 20 ms
2	40 ms
10	200 ms
50	1000 ms



The setting should be kept as high as acceptable to increase the lifetime of the actuator (gear motor).

MENU > Settings > Boiler

Control, delay	11364
<i>Set the delay (minutes) for activating the 3-point output.</i>	

See Appendix "Parameter ID overview"

After the boiler is switched ON, the set time must elapse before the 3-point output is activated. The 3-point output of the ECL 310 (M3) can be connected to the boiler for setting the boiler temperature.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Boiler

Min. off time	11424
<i>Set the minimum OFF time (minutes) for the burner.</i>	


See Appendix "Parameter ID overview"

The boiler can be protected against too many burner-starts. The protection is obtained by a set OFF time of the burner. With this setting the boiler temperature difference (ID no. 11046 "Difference") is overruled.

MENU > Settings > Boiler

Low X	11607
<i>Definition of which temperature value corresponds to which output voltage value. The temperature value is calculated in the ECL 310 and is converted to a voltage signal (0 - 10 volt). The relationship between temperature values and voltage signal is set in the scaling menu (Control voltage). "Low X" relates to a low temperature value. See also "Control voltage" and "High X".</i>	

See Appendix "Parameter ID overview"




X = Temperature
Y = Output voltage
1 # = Low X

MENU > Settings > Boiler

High X	11608
<i>Definition of which temperature value corresponds to which output voltage value. The temperature value is calculated in the ECL 310 and is converted to a voltage signal (0 - 10 volt). The relationship between temperature values and voltage signal is set in the scaling menu (Control voltage). "High X" relates to a high temperature value. See also "Control voltage" and "Low X".</i>	

See Appendix "Parameter ID overview"



X = Temperature
Y = Output voltage
1 # = High X

5.8 Control parameters

Control of valves

The motorized control valves are controlled by means of 3-point control signal.

Valve control:

The motorized control valve is opened gradually when the flow temperature is lower than the desired flow temperature and vice versa.

The water flow through the control valve is managed by means of an electric actuator. The combination "actuator" and "control valve" is also called motorized control valve. The actuator can in this way gradually increase or decrease the flow in order to change the supplied energy. Different types of actuators are available.

3-point controlled actuator:

The electric actuator contains a reversible gear-motor. Electric "open" and "close" signals come from the electronic outputs of the ECL Comfort controller in order to manage the control valve. The signals are in the ECL Comfort controller expressed as "Arrow-up" (open) and "Arrow-down" (close) and displayed at the valve symbol.

When the flow temperature (for example at S3) is lower than the desired flow temperature, short open-signals come from the ECL Comfort controller in order to gradually increase the flow. By this, the flow temperature will align with the desired temperature.

Oppositely, when the flow temperature is higher than the desired flow temperature, short close-signals come from the ECL Comfort controller in order to gradually reduce the flow. Again, the flow temperature aligns with the desired temperature.

Neither open-signals nor close-signals will come as long as the flow temperature corresponds to the desired temperature.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Thermo-hydraulic actuator, ABV

Danfoss thermo-actuator type ABV is a slow acting valve actuator. Inside the ABV an electric heat coil will heat a thermostatic element when an electric signal is applied. When heating the thermostatic element it expands in order to manage the control valve.

Two basic types are available: ABV NC (Normal Closed) and ABV NO (normal open). For example, ABV NC keeps a 2-port control valve closed when no open-signals are applied.

Electric open-signals come from the electronic output of the ECL Comfort controller in order to manage the control valve. When open-signals are applied to the ABV NC, the valve gradually opens.

Open-signals are in the ECL Comfort controller expressed as "Arrow-up" (open) and displayed at the valve symbol.

When the flow temperature (for example at S3) is lower than the desired flow temperature, relatively long open-signals come from the ECL Comfort controller in order to increase the flow. By this, the flow temperature will over time be aligned with the desired temperature.

Oppositely, when the flow temperature is higher than the desired flow temperature, relatively short open-signals come from the ECL Comfort controller in order to reduce the flow. Again, the flow temperature aligns, over time, with the desired temperature.

The control of the Danfoss thermo-actuator type ABV uses a unique designed algorithm and is based on the PWM principle (Pulse Width Modulation), where the duration of the pulse determines the management of the control valve. The pulses are repeated each 10 sec.

As long as the flow temperature corresponds to the desired temperature, the duration of the open-signals will remain constant.



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.

MENU > Settings > Control parameters

Actuator		1x024
	ABV / GEAR	GEAR

Selection of valve actuator type.

ABV: Danfoss type ABV (thermo actuator).

GEAR: Gear motor based actuator.



When selecting "ABV", the control parameters:

- Motor protection (ID 1x174)
 - Xp (ID 1x184)
 - Tn (ID 1x185)
 - M run (ID 1x186)
 - Nz (ID 1x187)
 - Min. act. time (ID 1x189)
- are not considered.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Control parameters

Motor pr. (motor protection)	1x174
<i>Prevents the controller from unstable temperature control (and resulting actuator oscillations). This can occur at very low load. The motor protection increases the lifetime of all involved components.</i>	



Recommended for duct systems with variable load.

See Appendix "Parameter ID overview"

OFF: Motor protection is not activated.

Value: Motor protection is activated after the set activation delay in minutes.

MENU > Settings > Control parameters

Xp (proportional band)	1x184
-------------------------------	--------------

See Appendix "Parameter ID overview"

Set the proportional band. A higher value will result in a stable but slow control of the flow temperature.

MENU > Settings > Control parameters

Tn (integration time constant)	1x185
---------------------------------------	--------------

See Appendix "Parameter ID overview"

Set a high integration time constant (in seconds) to obtain a slow but stable reaction to deviations.

A low integration time constant will make the controller react fast but with less stability.

MENU > Settings > Control parameters

M run (running time of the motorized control valve)	1x186
<i>'M run' is the time in seconds it takes the controlled component to move from fully closed to fully open position.</i>	

See Appendix "Parameter ID overview"

Set the 'M run' according to the examples or measure the running time by means of a stop watch.

How to calculate the running time of a motorized control valve

The running time of the motorized control valve is calculated using the following methods:

Seated valves

Running time = Valve stroke (mm) x actuator speed (sec. / mm)

Example: $5.0 \text{ mm} \times 15 \text{ sec. / mm} = 75 \text{ sec.}$

Rotating valves

Running time = Turning degrees x actuator speed (sec. / degr.)

Example: $90 \text{ degr.} \times 2 \text{ sec. / degr.} = 180 \text{ sec.}$

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Control parameters

Nz (neutral zone)	1x187
<i>When the actual flow temperature is within the neutral zone, the controller does not activate the motorized control valve.</i>	



The neutral zone is symmetrical around the desired flow temperature value, i.e. half the value is above and half the value is below this temperature.

See Appendix "Parameter ID overview"

Set the acceptable flow temperature deviation.

Set the neutral zone to a high value if you can accept a high variation in flow temperature.

MENU > Settings > Control parameters

Min. act. time (min. activation time gear motor)	1x189
<i>The min. pulse period of 20 ms (milliseconds) for activation of the gear motor.</i>	

Setting example	Value x 20 ms
2	40 ms
10	200 ms
50	1000 ms




The setting should be kept as high as acceptable to increase the lifetime of the actuator (gear motor).

See Appendix "Parameter ID overview"

If you want to tune the PI regulation precisely, you can use the following method:

- Set the 'Tn' (integration time constant) to its max. value (999 sec.).
- Decrease the value for the 'Xp' (proportional band) until the system starts hunting (i.e. gets unstable) with a constant amplitude (it might be necessary to force the system by setting an extreme low value).
- Find the critical time period on the temperature recorder or use a stop watch.



This critical time period will be characteristic for the system, and you can evaluate the settings from this critical period.

'Tn' = 0.85 x critical time period

'Xp' = 2.2 x proportional band value in the critical time period

If the regulation seems to be too slow, you can decrease the proportional band value by 10%. Make sure there is a consumption when you set the parameters.

Operating Guide ECL Comfort 210/296/310, application A275/A375

5.9 Application

The section "Application" describes specific application related issues.

Some of the parameter descriptions are universal for different application keys.



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.

MENU > Settings > Application

ECA addr. (ECA address, choice of Remote Control Unit)	1x010
<i>Decides the room temperature signal transfer and communication with the Remote Control Unit.</i>	



The Remote Control Unit must be set accordingly (A or B).

See Appendix "Parameter ID overview"


- OFF:** No Remote Control Unit. Only room temperature sensor, if any.
- A:** Remote Control Unit ECA 30 / 31 with address A.
- B:** Remote Control Unit ECA 30 / 31 with address B.

MENU > Settings > Application

Demand offset	1x017
<i>The desired flow temperature in heating circuit 1 can be influenced by the demand for a desired flow temperature from another controller (slave) or another circuit.</i>	

See Appendix "Parameter ID overview"

- OFF:** The desired flow temperature in circuit 1 is not influenced by the demand of any other controller (slave or circuit 2).
- Value:** The desired flow temperature is increased by the set value in 'Demand offset', if the demand of the slave / circuit 2 is higher.



The function of 'Demand offset' can compensate for heat losses between master and slave controlled systems.

MENU > Settings > Application

P exercise (pump exercise)	1x022
<i>Exercises the pump to avoid blocking in periods without heat demand.</i>	

See Appendix "Parameter ID overview"

- OFF:** The pump exercise is not active.
- ON:** The pump is switched ON for 1 minute every third day at noon (12:14 hours).

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Application

M exercise (valve exercise)	1x023
<i>Exercises the valve to avoid blocking in periods without heat demand.</i>	

See Appendix "Parameter ID overview"

- OFF:** The valve exercise is not active.
- ON:** The valve opens for 7 minutes and closes for 7 minutes every third day at noon (12:00 hours).

MENU > Settings > Application

P post-run	1x040
<i>The circulation pump in the heating circuit can be ON for a number of minutes (m) after heating stop. Heating stop is when the desired flow temperature gets lower than the setting in 'P heat T' (ID no. 1x078).</i>	

See Appendix "Parameter ID overview"

- 0:** The circulation pump stops immediately after heating stop.
- Value:** The circulation pump is ON for the set time after heating stop.

MENU > Settings > Application

DHW P post-run (DHW pump, post-run)	1x041
<i>Set the DHW pump post-run time (minutes). The DHW pump can continue to be switched ON after the DHW heating procedure in order to utilize the remaining heat in the heat exchanger / boiler.</i>	

See Appendix "Parameter ID overview"

- Value:** Set the number of minutes for the post-run.

MENU > Settings > Application

P demand	1x050
<i>The circulation pump in the master circuit can be controlled in relation to the master circuit's demand or slave circuit's demand.</i>	

See Appendix "Parameter ID overview"

- OFF:** The circulation pump is ON when the desired flow temperature in the heating circuit is higher than the value set in 'P heat T'.
- ON:** The circulation pump is ON when the desired flow temperature from slaves is higher than the value set in 'P heat T'.



The circulation pump is always controlled according to frost protection conditions.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Application

Ch.-o. valve / P (changeover valve / pump)	1x051
<i>Choose whether the DHW heating control is based on a changeover valve or a pump.</i>	



When the changeover valve is chosen, pump P1 is ON at heating as well as at DHW heating demand.

See Appendix "Parameter ID overview"

OFF: Changeover valve

ON: Pump



When the pump is chosen, pump P1 is ON at heating and OFF at DHW heating demand.

A parallel option (heating and DHW heating in parallel) exists, based on the setting 'Parallel operation'.

MENU > Settings > Application

DHW priority (closed valve / normal operation)	1x052
<i>The heating circuit can be closed when the controller acts as slave and when DHW heating / charging is active in the master.</i>	



This setting must be considered if this controller is a slave.

See Appendix "Parameter ID overview"

OFF: The flow temperature control remains unchanged during active DHW heating / charging in the master controller.

ON: The valve in the heating circuit is closed* during active DHW heating / charging in the master controller.

* The desired flow temperature is set to the value set in 'Frost pr. T'

MENU > Settings > Application

Tank, sec. / prim. (Tank secondarily or primarily connected)	1x053
<i>Choose whether the heating of the DHW tank is dependent on the flow temperature at S3.</i>	

See Appendix "Parameter ID overview"

OFF: The DHW tank is placed on the secondary side of the heat exchanger and the S3 temperature determines the DHW heating.

ON: The DHW tank is placed on the primary side of the heat exchanger and the S3 temperature has no influence on the DHW heating.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Application

Circ. P priority	1x055
<i>Choose whether the DHW circulation pump should be ON during DHW heating.</i>	



When the 'Circ. P priority' is set to OFF, the schedule for the DHW circulation pump is overruled.

See Appendix "Parameter ID overview"

OFF: The DHW circulation pump is switched OFF during DHW heating.

ON: The DHW circulation pump is not switched OFF during DHW heating.

MENU > Settings > Application

Circ. P frost T	1x076
<i>Set the outdoor temperature value at which the DHW circulation pump is to be active to protect the DHW circuit against frost.</i>	

See Appendix "Parameter ID overview"

OFF: The DHW circulation pump is not active.

Value: The DHW circulation pump is active when the outdoor temperature is lower than the set value.

MENU > Settings > Application

P frost T (circulation pump, frost protection temp.)	1x077
<i>Frost protection, based on the outdoor temperature. When the outdoor temperature gets below the set temperature value in 'P frost T', the controller automatically switches ON the circulation pump (for example P1 or X3) to protect the system.</i>	



Under normal conditions, your system is not frost protected if your setting is below 0 °C or OFF.
For water-based systems, a setting of 2 °C is recommended.

See Appendix "Parameter ID overview"

OFF: No frost protection.

Value: Circulation pump is ON when the outdoor temperature is below the set value.



If the outdoor temperature sensor is not connected and the factory setting has not been changed to 'OFF', the circulation pump is always ON.

MENU > Settings > Application

P heat T (heat demand)	1x078
<i>When the desired flow temperature is above the set temperature in 'P heat T', the controller automatically switches ON the circulation pump.</i>	



The valve is fully closed as long as the pump is not switched on.

See Appendix "Parameter ID overview"

Value: The circulation pump is switched ON when the desired flow temperature is above the set value.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Application

Frost pr. T (frost protection temp.)	1x093
Set the desired flow temperature at temperature sensor S3 to protect the system against frost (at heating cut-out, total stop etc.). When the temperature at S3 gets lower than the setting, the motorized control valve opens gradually.	



The frost protection temperature can also be set in your favorite display when the mode selector is in frost protection mode.

See Appendix "Parameter ID overview"

Override mode functions:

The following settings describe the function in general for the ECL Comfort 210 / 296 / 310 series. The explained modes are typical and not application related. They might differ from the override modes in your application.

MENU > Settings > Application

Ext. input (external override)	1x141
Choose the input for 'Ext. input' (external override). By means of a switch the controller can be overridden to 'Comfort', 'Saving', 'Frost protection' or 'Constant temperature' mode.	

See Appendix "Parameter ID overview"

OFF: No inputs have been selected for external override.

S1 ... S16: Input selected for external override.

If S1... S6 is chosen as override input, the override switch must have gold-plated contacts.

If S7 ... S16 is chosen as override input, the override switch can be a standard contact.


See the drawings for connection examples of override switch and override relay to input S8.

S7...S16 are recommended for override switch.


If ECA 32 is mounted, also S11... S16 can be used.

If ECA 35 is mounted, also S11 or S12 can be used.

Example: Connection of an override switch



Example: Connection of an override relay



Choose only an unused input for override. If an already used input is applied for override, the functionality of this input is also neglected.



See also 'Ext. mode'.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Application

Ext. mode (external override mode) **1x142**

The mode override can be activated for Saving, Comfort, Frost pr. or Constant T mode.
For override, the controller mode must be in scheduled mode.

See Appendix "Parameter ID overview"

Choose an override mode:

- SAVING:** The circuit in question is in saving mode when the override switch is closed.
- COMFORT:** The circuit in question is in comfort mode when the override switch is closed.
- FROST PR.:** The heating or DHW circuit closes, but is still frost protected.
- CONSTANT T:** The circuit in question controls a constant temperature *)


*) See also 'Desired T' (1x004), setting of desired flow temperature (MENU > Settings > Flow temperature)
See also 'Con. T, ret. T lim.' (1x028), setting of return temperature limitation (MENU > Settings > Return limit)

The process diagrams show the functionality.




See also 'Ext. input'.

Example: Override to Comfort mode




Example: Override to Saving mode




The result of override to 'Saving' mode depends on the setting in 'Total stop'.

Total stop = OFF: Heating reduced
Total stop = ON: Heating stopped

Example: Override to Frost protection mode



Example: Override to Constant temperature mode



The "Const. T" value can be influenced by:

- temp. max.
- temp. min.
- room temp. limit
- return temp. limit
- flow / power limit

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Application

Send desired T

1x500

When the controller acts as a slave controller in a master / slave system, information about the desired flow temperature can be sent to the master controller via the ECL 485 bus.

Stand-alone controller:

Sub-circuits can send the desired flow temperature to the master circuit.



In the master controller, 'Demand offset' must be set to a value in order to react on a desired flow temperature from a slave controller.



When the controller acts as a slave, its address must be 1, 2, 3 ... 9 in order to send the desired temperature to the master (see the section 'Miscellaneous', 'Several controllers in the same system').

See Appendix "Parameter ID overview"

OFF: Information about the desired flow temperature is not sent to the master controller.

ON: Information about the desired flow temperature is sent to the master controller.

Operating Guide ECL Comfort 210/296/310, application A275/A375

5.10 Alarm

The section "Alarm" describes specific application related issues.
Application A275 offers two types of alarms:

Type:	Description:
1	A275.3, A375.3, A375.5: Actual flow temperature differs from the desired flow temperature.
1	A375.4, A375.5: Actual pressure is outside the set pressure range
2	All subtypes: Disconnection or short-circuiting of a temperature sensor or its connection

The alarm functions activate the alarm bell symbol. (🔔)
A275.1, A275.2: The alarm functions activate A1 (Relay 4).
A375.1, A375.2, A375.3, A375.4, A375.5: The alarm functions activate A1 (Relay 6).

The alarm relay can activate a lamp, a horn, an input to an alarm transmitting device etc.

The alarm symbol / relay is activated:

- (type 1) as long as the alarm reason is present (automatic reset).
- (type 2) even if the alarm reason disappears again (manual reset).

Alarm type 1:

If the flow temperature deviates more than the set differences from the desired flow temperature, the alarm symbol / relay will be activated.

If the flow temperature becomes acceptable, the alarm symbol / relay will be de-activated.

If the pressure S9 gets higher than a set value (bar) or gets lower than another set value (bar), the alarm symbol / relay will be activated.

If the pressure becomes acceptable, the alarm symbol / relay will be de-activated.

Alarm type 2:

Selected temperature sensors can be monitored.
Should the connection to the temperature sensor be disconnected, short-circuited or the sensor gets defective, the alarm symbol / relay will be activated. In the "Raw input overview" (MENU > Common controller settings > System > Raw input overview) the sensor in question is marked and the alarm can be reset.

When an alarm is activated, the bell-symbol appears in the right favorite display.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Monitoring and alarm related to connected temperature sensors:

At start-up, the ECL controller detects which temperature sensors are connected.

Should the connection to a temperature sensor be disconnected or short-circuited after start-up, the sensor alarm function can be activated.

This function is helpful at service situations where periodic malfunctions can occur.

The following procedure describes the function:

1. Go to "Raw input overview" (MENU > Common controller settings > System > Raw input overview).
2. Place the cursor at the sensor number, which could be suspicious for correct connection and click the dial; a symbol for a magnifying glass appears.
3. Repeat step 2 if other temperature sensor connections are to be monitored.
4. The selected temperature sensor(s) is / are now being monitored and you can leave the menu.
5. Should the connection to the temperature sensor for a short while (more than 3 seconds) be disconnected or short-circuited, the sensor alarm function is activated. An alarm bell symbol appears in the display and the alarm relay is activated.
6. Verification which sensor connection has activated the alarm:

Go to "Raw input overview" (MENU > Common controller settings > System > Raw input overview).

Look for (by moving the cursor down) the sensor line which is marked with a magnifying glass and a bell-symbol (alarm).

7. Resetting the alarm:

Mark the line by means of the cursor and click the dial. The symbols for alarm and magnifying glass disappears.

Reset of sensor alarm can also be made in Alarm overview (MENU > Alarm > Alarm overview: Alarm number 32: T sensor defect). Click the dial and the alarm bell symbol disappears.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Alarm overview, list:

Alarm no.:	Description:	Alarm type:	Sensor ref.:
3	A275.3, A375.3, A375.5: Temp. monitor, circuit 2	1	S4
4	A375.4, A375.5: Pressure (See section 'Pressure measuring')	1	S9
32	All subtypes: T sensor defect (Temperature sensor defect)	2	all

To find the reason for an alarm:

- select MENU
- select 'Alarm'
- select 'Alarm overview'. A "bell" (🔔) will be shown at the alarm in question.

Alarm overview (example):

3: Temp. monitor

32: T sensor defect

The numbers in the 'Alarm overview' refer to the alarm number in the Modbus communication.

To reset an alarm:

When the "bell" (🔔) is present to the right of the alarm line, place the cursor at the alarm line in question and press the dial.

To reset alarm 32:

MENU > Common controller settings > System > Raw input overview: The sensor in question is marked and the alarm can be reset.




Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.

5.10.1 S9 pressure

MENU > Settings > Alarm

Low X	13607
Definition of which pressure value corresponds to which voltage value. The pressure value is in the pressure transmitter converted to a voltage signal (0 - 10 volt). The relationship between pressure values and voltage signal is set in the scaling menu (Pressure). "Low X" relates to a low temperature value. See also "Pressure" and "High X".	

See Appendix "Parameter ID overview"



X = Volt


Y = Pressure (bar)

1 # = Low X

MENU > Settings > Alarm

High X	13608
Definition of which temperature value corresponds to which output voltage value. The pressure value is in the pressure transmitter converted to a voltage signal (0 - 10 volt). The relationship between pressure values and voltage signal is set in the scaling menu (Pressure). "High X" relates to a high temperature value. See also "Control voltage" and "Low X".	

See Appendix "Parameter ID overview"



X = Volt

Y = Pressure (bar)

1 # = High X

MENU > Settings > Alarm

Alarm high	1x614
When the measured value gets higher than the set value, the alarm will be activated.	

See Appendix "Parameter ID overview"

Value: Set the alarm value

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Alarm

Alarm low	1x615
<i>When the measured value gets lower than the set value, the alarm will be activated.</i>	

See Appendix "Parameter ID overview"

Value: Set the alarm value

MENU > Settings > Alarm

Alarm time-out	1x617
<i>The alarm is activated when the alarm reason has been present for a longer time (in seconds) than the set value.</i>	

See Appendix "Parameter ID overview"

Value: Set the alarm time-out

5.10.2 Temp. monitor.


MENU > Settings > Alarm

Upper difference	1x147
<i>The alarm is activated if the actual flow temperature increases more than the set difference (acceptable temperature difference above the desired flow temperature). See also 'Delay'.</i>	

See Appendix "Parameter ID overview"

OFF: The related alarm function is not active.

Value: The alarm function is active if the actual temperature gets above the acceptable difference.



X = Time
Y = Temperature
1 # = Upper difference
2 # = Desired flow temperature


MENU > Settings > Alarm

Lower difference	1x148
The alarm is activated if the actual flow temperature decreases more than the set difference (acceptable temperature difference below the desired flow temperature). See also 'Delay'.	

See Appendix "Parameter ID overview"

OFF: The related alarm function is not active.

Value: The alarm function is active if the actual temperature gets below the acceptable difference.



X = Time
 Y = Temperature
 # 1 # = Lower difference
 # 2 # = Desired flow temperature


Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Settings > Alarm

Delay, example	1x149
If an alarm condition from either 'Upper difference' or 'Lower difference' is present for a longer time than the set delay (in minutes), the alarm function is activated.	

See Appendix "Parameter ID overview"

Value: The alarm function will be activated if the alarm condition remains after the set delay.



- X = Time
- Y = Temperature
- # 1 # = Lower difference
- # 2 # = Desired flow temperature
- # 3 # = Actual flow temperature
- # 4 # = Delay (ID 1x149)

MENU > Settings > Alarm

Lowest temp.	1x150
The alarm function will not be activated if the desired flow temperature is lower than the set value.	

See Appendix "Parameter ID overview"

If the cause of the alarm disappears, the alarm indication and output also disappear.

5.11 Alarm overview

MENU > Alarm > Alarm overview

This menu shows the alarm types, for example:

- "2: Temp. monitor"
- "32: T sensor defect"

The alarm has been activated if the alarm symbol (a bell) (🔔) is present to the right of the alarm type.



Resetting an alarm, in general:

MENU > Alarm > Alarm overview:
Look for alarm symbol in specific line.

(Example: "2: Temp. monitor")
Move cursor to the line in question.
Push dial.



Alarm overview:

Alarm sources are listed in this overview menu.

Some examples:
"2: Temp. monitor"
"5: Pump 1"
"10: Digital S12"
"32: T sensor defect"

Related to the examples, the numbers 2, 5 and 10 are used in the alarm communication to the BMS / SCADA system.


Related to the examples, "Temp. monitor", "Pump 1" and "Digital S12" are the alarm points.

Related to the examples, "32: T sensor defect" indicates the monitoring of connected sensors.

Alarm numbers and alarm points might differ depending on actual application.

5.12 Anti-bacteria

On selected days during the week the DHW temperature can be increased in order to neutralize bacteria in the DHW system. The desired DHW temperature 'Desired T' (typically 80 °C) will be present for the selected day(s) and duration. The anti-bacteria function is not active in frost protection mode.



X = Time
Y = Desired DHW temperature
1 # = Duration
2 # = Desired Anti-bacteria temperature value
3 # = Desired Anti-bacteria temperature
4 # = Desired DHW temperature value
5 # = Start time



During the anti-bacteria process, the return temperature limitation is not active.

MENU > Settings > Anti-bacteria

Day
Select (mark) the day(s) of the week where the anti-bacteria function must be active.

M = Monday
T = Tuesday
W = Wednesday
T = Thursday
F = Friday
S = Saturday
S = Sunday

MENU > Settings > Anti-bacteria

Start time
<i>Set the start time for the anti-bacteria function.</i>

MENU > Settings > Anti-bacteria

Duration
<i>Set the duration (minutes) for the anti-bacteria function.</i>

MENU > Settings > Anti-bacteria

Desired T
<i>Set the desired DHW temperature for the anti-bacteria function.</i>

See Appendix "Parameter ID overview"

OFF: The anti-bacteria function is not active.

Value: Desired DHW temperature during the anti-bacteria function period.

6.0 Common controller settings

6.1 Introduction to 'Common controller settings'

Some general settings which apply to the entire controller are located in a specific part of the controller.

To enter 'Common controller settings':

Action:	Purpose:	Examples:
	Choose 'MENU' in any circuit	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose 'Common controller settings'	
	Confirm	

Circuit selector



6.2 Time & Date

It is only necessary to set the correct date and time in connection with the first use of the ECL Comfort controller or after a power break of more than 72 hours.


The controller has a 24 hour clock.

Aut. daylight (Daylight saving time changeover)

- YES:** The controller's built-in clock automatically changes + / - one hour on the standardized days for daylight saving time changeover for Central Europe.
- NO:** You change manually between summer and winter time by setting the clock backward or forward.

How to set time and date:

Action:	Purpose:	Examples:
	Choose 'MENU'	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose 'Common controller settings'	
	Confirm	
	Go to 'Time & Date'	
	Confirm	
	Place the cursor at the position to be changed	
	Confirm	
	Enter the desired value	
	Confirm	
	Move the cursor to the next position to be changed. Continue until 'Time & Date' has been set.	
	Finally move the cursor to 'MENU'	
	Confirm	
	Move the cursor to 'HOME'	
	Confirm	



When controllers are connected as slaves in a master / slave system (via ECL 485 communication bus), they will receive 'Time & Date' from the master.

Operating Guide ECL Comfort 210/296/310, application A275/A375

6.3 Holiday

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

There is a holiday program for each circuit and a holiday program for the common controller.

Each holiday program contains one or more schedules. Each schedule can be set to a start date and an end date. The set period starts on the start date at 00.00 and stops on the end date at 00.00.

Selectable modes are Comfort, Saving, Frost protection or Comfort 7-23 (before 7 and after 23, the mode is scheduled).

How to set your holiday schedule:




Action:	Purpose:	Examples:
	Choose 'MENU'	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose a circuit or 'Common controller settings'	
	Heating	
	DHW	
	Common controller settings	
	Confirm	
	Go to 'Holiday'	
	Confirm	
	Choose a schedule	
	Confirm	
	Confirm choice of mode selector	
	Choose mode	
	· Comfort	
	· Comfort 7-23	
	· Saving	
	· Frost protection	
	Confirm	
	Enter the start time first and then the end time	
	Confirm	
	Go to 'Menu'	
	Confirm	
	Choose 'Yes' or 'No' in 'Save'. Choose the next schedule, if required	



The holiday program in the 'Common controller settings' is valid for all circuits. The holiday program can also be set individually in the heating or DHW circuits.



The end date must be at least be one day later than the start date.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Holiday, specific circuit / Common Controller

When setting one holiday program in specific circuit and another holiday program in Common Controller, a priority will be taken into account:

1. Comfort
2. Comfort 7 - 23
3. Saving
4. Frost protection

Holiday, deleting a set period:

- Choose the Schedule in question
- Change the mode to "Clock"
- Confirm

Example 1:

Circuit 1:
Holiday set to "Saving"

Common Controller:
Holiday set to "Comfort"

Result:
As long as "Comfort" is active in Common Controller, circuit 1 will be in "Comfort".

Example 2:

Circuit 1:
Holiday set to "Comfort"

Common Controller:
Holiday set to "Saving"

Result:
As long as "Comfort" is active in circuit 1, it will be in "Comfort".

Example 3:

Circuit 1:
Holiday set to "Frost protection"

Common Controller:
Holiday set to "Saving"

Result:
As long as "Saving" is active in Common Controller, circuit 1 will be in "Saving".

The ECA 30 / 31 cannot override the holiday schedule of the controller temporarily.

However, it is possible to make use of the following options from the ECA 30 / 31 when the controller is in scheduled mode:

-  Day off
-  Holiday
-  Relaxing (extended comfort period)
-  Going out (extended saving period)



Energy-saving trick:
Use 'Going out' (the extended saving period) for airing purposes (e.g. for ventilating the rooms by means of fresh air from open windows).



Connections and setup procedures for ECA 30 / 31:
See section 'Miscellaneous'.



Quick guide "ECA 30 / 31 to override mode":

1. Go to ECA MENU
2. Move cursor to "Clock" symbol
3. Select the "Clock" symbol
4. Choose and select one of 4 override functions
5. Below the override symbol: Set hours or date
6. Below hours / date: Set desired room temperature for the override period

Operating Guide ECL Comfort 210/296/310, application A275/A375

6.4 Input overview

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The input overview is located in the common controller settings.

This overview will always show you the actual temperatures in the system (read-only).

MENU ⏏	
Input overview:	
▶ Outdoor T	7.0 °C
Outdoor acc. T	5.8 °C
Heat return T	35.5 °C
Heat flow T	67.9 °C
DHW flow T	68.6 °C



"Outdoor acc. T" means "Accumulated outdoor temperature" and is a calculated value in the ECL Comfort controller.

6.5 Log

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The log function (temperature history) allows you to monitor the logs of today, yesterday, the past 2 days as well as the past 4 days for the connected sensors.

There is a log display for the relevant sensor, showing the measured temperature.


The log function is only available in the 'Common controller settings'.

```

MENU ⏏
Log:
▶ Outdoor T
Room T & desired
Heating flow & des.
DHW flow & des.
Heat return T & limit
    
```

```

Log ⏏
Outdoor T:
▶ Log today
Log yesterday
Log 2 days
Log 4 days
    
```




Example 1:

1 day log for yesterday showing the development in outdoor temperature during the past 24 hours.


Example 2:

Today's log for the actual heating flow temperature as well as the desired temperature.



Example 3:

Yesterday's log for the DHW flow temperature as well as the desired temperature.



Operating Guide ECL Comfort 210/296/310, application A275/A375

6.6 Output override

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The output override is used to disable one or more of the controlled components. This could among others be useful in a service situation.

Action:	Purpose:	Examples:
	Choose 'MENU' in any of the overview displays	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose common controller settings	
	Confirm	
	Choose 'Output override'	
	Confirm	
	Choose a controlled component	M1, P1 etc.
	Confirm	
	Adjust the status of the controlled component: Motorized control valve: AUTO, STOP, CLOSE, OPEN Pump: AUTO, OFF, ON	
	Confirm status change	

Remember to change the status back again as soon as an override is not required any longer.

Controlled components	Circuit selector
MENU	
Output override:	
M1	AUTO
P1	AUTO
M2	OPEN
P2	AUTO
A1	AUTO



"Manual control" has higher priority than "Output override".




When the selected controlled component (output) is not 'AUTO', the ECL Comfort controller does not control the component in question (pump or motorized control valve e.g.). Frost protection is not active.



When output override of a controlled component is active the symbol '!' is shown to the right of the mode indicator in the enduser displays.

6.7 Key functions

New application	Erase application: Removes the existing application. As soon as the ECL key is inserted, another application can be chosen.
Application	Gives an overview over the actual application in the ECL controller. Push the dial again to exit the overview.
Factory setting	System settings: System settings are, among others, communication set-up, display brightness etc. User settings: User settings are, among others, desired room temperature, desired DHW temperature, schedules, heat curve, limitation values etc. Go to factory: Restores the factory settings.
Copy	To: Copy direction System settings User settings Start copying
Key overview	Gives an overview over the inserted ECL key. (Example: A266 Ver. 2.30). Turn the dial to see the subtypes. Push the dial again to exit the overview.



A more detailed description of how to use the individual 'Key functions' can also be seen in 'Inserting the ECL application key'.



The "Key overview" does not inform — through ECA 30 / 31 — about the subtypes of the application key.



Key inserted / not inserted, description:

ECL Comfort 210 / 310, controller versions lower than 1.36:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; for 20 minutes settings can be changed.

ECL Comfort 210 / 310, controller versions 1.36 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

ECL Comfort 296 , controller versions 1.58 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

Operating Guide ECL Comfort 210/296/310, application A275/A375

6.8 System

6.8.1 ECL version

In 'ECL version' you will always be able to find an overview of the data related to your electronic controller.

Please have this information available if you need to contact your Danfoss sales organization concerning the controller.

Information about your ECL Application Key can be found in 'Key functions' and 'Key overview'.

Code no.:	The Danfoss sales and order no. for the controller
Hardware:	Hardware version of the controller
Software:	Software (firmware) version of the controller
Serial no.:	Unique number for the individual controller
Production week:	Week no. and year (WW.YYYY)

Example, ECL version

System	□□□
ECL version:	
▶ Code no.	087H3040
Hardware	B
Software	10.50
Build no.	7475
Serial no.	5335

6.8.2 Extension

ECL Comfort 310 / 310B:
'Extension' will offer you information about additional modules, if any. An example could be the ECA 32 module.

6.8.3 Ethernet

ECL Comfort 296 / 310 / 310B have a Modbus/TCP communication interface that allows the ECL controller to be connected to an Ethernet network. This allows remote access to the ECL 296 / 310 / 310B controller based on standard communication infrastructures.

In 'Ethernet' it is possible to set up the required IP addresses.

6.8.4 Portal config

ECL Comfort 296 / 310 / 310B have a Modbus/TCP communication interface that allows the ECL controller to be monitored and controlled via the ECL Portal.

ECL Portal related parameters are set here.

Documentation for ECL Portal: See <https://ecl.portal.danfoss.com>

6.8.5 M-bus config

ECL Comfort 296 / 310 / 310B have an M-bus communication interface that allows energy meters to be connected as slaves.

M-bus related parameters are set here.

Operating Guide ECL Comfort 210/296/310, application A275/A375

6.8.6 Energy meter and M-bus, general information

ECL Comfort 296 / 310 / 310B only

When using the Application Key in the ECL Comfort 296 / 310 / 310B, up to 5 energy meters can be connected to the M-bus connections.

Connection of energy meter can:

- limit the flow
- limit the power
- transfer energy meter data to the ECL Portal, via Ethernet, and / or a SCADA system, via Modbus.

Many applications with control of heating, DHW or cooling circuit have the possibility to react on energy meter data.

To verify if actual application key can be set to react on energy meter data:

See Circuit > MENU > Settings > Flow / power.

The ECL Comfort 296 / 310 / 310B can always be used for monitoring purpose of up to 5 energy meters.

The ECL Comfort 296 / 310 / 310B act as an M-bus master and must be set to communicate with connected energy meter(s).

See MENU > Common controller > System > M-bus config.

Technical info:

- The M-bus data are based on standard EN-1434.
- Danfoss recommends AC supplied energy meters in order to avoid battery draining.



Energy meter data acquisition from ECL Portal is possible without setting up the M-bus configuration.

MENU > Common controller > System > M-bus config.

State		Read-out
Circuit	Setting range	Factory setting
-	-	-
Information about the current M-bus activity.		



The ECL Comfort 296 / 310 / 310B will return to IDLE when commands have been completed.
Gateway is used for read-out of energy meter via ECL Portal.

IDLE: Normal state

INIT: The command for initialization has been activated

SCAN: The command for scanning has been activated

GATEW: The command Gateway has been activated

MENU > Common controller > System > M-bus config.

Baud (bits per second)		5997
Circuit	Setting range	Factory setting
-	300 / 600 / 1200 / 2400	300
The communication speed between ECL Comfort 296 / 310 / 310B and the connected energy meter(s).		



Typically, 300 or 2400 baud is used.
If ECL Comfort 296 / 310 / 310B are connected to the ECL Portal, a baud rate of 2400 is recommendable, provided the energy meter allows this.

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Common controller > System > M-bus config.

Command		5998
Circuit	Setting range	Factory setting
-	NONE / INIT / SCAN / GATEW	NONE

The ECL Comfort 296 / 310 / 310B are M-bus masters. In order to verify connected energy meters, different commands can be activated.



Scan time can take up to 12 minutes.
When all energy meters are found, the command can be changed to INIT or NONE.

NONE: No command activated

INIT: Initialization is activated

SCAN: Scanning is activated in order to search for connected energy meters. The ECL Comfort 296 / 310 / 310B detect the M-bus addresses of up to 5 connected energy meters and place these automatically in the "Energy meters" section. The verified address is placed after "Energy meter 1 (2, 3, 4, 5)"

GATEW: The ECL Comfort 296 / 310 / 310B act as a gateway between energy meters and ECL Portal. Used only for service.

MENU > Common controller > System > M-bus config.

M-bus address Energy meter 1 (2, 3, 4, 5)		6000
Circuit	Setting range	Factory setting
-	0 - 255	255

The set or verified address of energy meter 1 (2, 3, 4, 5).

0: Normally not used

1 - 250: Valid M-bus addresses

251 - 254: Special functions. Use only M-bus address 254 when one energy meter is connected.

255: Not used

MENU > Common controller > System > M-bus config.

Type Energy meter 1 (2, 3, 4, 5)		6001
Circuit	Setting range	Factory setting
-	0 - 4	0

Selecting data range from the M-bus telegram..

0: Small data set, small units

1: Small data set, large units

2: Large data set, small units

3: Large data set, large units

4: Volume and energy data only
(example: HydroPort Pulse)



Data examples:

0:
Flow temp., return temp., flow, power, acc. volume, acc. energy.

3:
Flow temp., return temp., flow, power, acc. volume, acc. energy, tariff 1, tariff 2.

See also the "Instructions, ECL Comfort 210 / 310, communication description" for further details.

See also Appendix for detailed description of "Type".

Operating Guide ECL Comfort 210/296/310, application A275/A375

MENU > Common controller > System > M-bus config.

Scan time		6002
Energy meter 1 (2, 3, 4, 5)		
Circuit	Setting range	Factory setting
-	1 - 3600 sec	60 sec
Setting the scanning time for acquiring data of connected energy meter(s).		



If the energy meter is battery powered, the scan time should be set to a high value to prevent a too fast battery draining.
Oppositely, if the flow / power limitation function is used in the ECL Comfort 310, the scan time should be set to a low value in order to have quick limitation.

MENU > Common controller > System > M-bus config.

ID		Read-out
Energy meter 1 (2, 3, 4, 5)		
Circuit	Setting range	Factory setting
-	-	-
Information about the energy meter's serial no.		

MENU > Common controller > System > Energy meters

Energy meter 1 (2, 3, 4, 5)		Read-out
Circuit	Setting range	Factory setting
-	0 - 4	0
Information from actual energy meter about, for example, ID, temperatures, flow / volume, power / energy. The shown information depends on the settings made in the "M-bus config." menu.		

6.8.7 Raw input overview

Measured temperatures, input status and voltages are displayed.

In addition, a detection of malfunctions can be chosen for activated temperature inputs.

Monitoring the sensors:

Choose the sensor which measures a temperature, for example the S5. When the dial is pressed, a magnifying glass appears in the selected line. The S5 temperature is now being monitored.

Alarm indication:

Should the connection to the temperature sensor be disconnected, short-circuited or the sensor itself be defective, the alarm function is activated.

In the "Raw input overview" an alarm symbol is shown at the defective temperature sensor in question.

Resetting the alarm:

Choose the sensor (S number) for which you want to clear the alarm. Press the dial. The magnifying glass and alarm symbols disappear.

When the dial is pressed again, the monitoring function is reactivated.



The temperature sensor inputs have a measuring range from -60 ... 150 °C.

If a temperature sensor or its connection breaks, the value indication is " - - ".

If a temperature sensor or its connection is short-circuited, the value indication is " - - - ".

Operating Guide ECL Comfort 210/296/310, application A275/A375

6.8.8 Sensor offset (new functionality as from firmware 1.59)

The measured temperature can be offset adjusted in order to compensate for cable resistance or a not-optimum place for the temperature sensor. The adjusted temperature can be seen in "Raw input overview" and "Input overview".

Common controller > System > Sensor offset

Sensor 1 . . . (temperature sensor)		
Circuit	Setting range	Factory setting
	*	*
Setting the offset of the measured temperature.		

Positive offset The temperature value is increased

value:

Negative offset The temperature value is decreased

value:

6.8.9 Display

Backlight (display brightness)		60058
Circuit	Setting range	Factory setting
	0 ... 10	5
Adjust the brightness of the display.		

0: Weak backlight.

10: Strong backlight.

Contrast (display contrast)		60059
Circuit	Setting range	Factory setting
	0 ... 10	3
Adjust the contrast of the display.		

0: Low contrast.

10: High contrast.

6.8.10 Communication

Modbus addr.		38
Circuit	Setting range	Factory setting
	1 ... 247	1
Set the Modbus address if the controller is part of a Modbus network.		

1 ... 247: Assign the Modbus address within the stated setting range.

Operating Guide ECL Comfort 210/296/310, application A275/A375

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Factory setting
☐ ☐	0 ... 15	15
<i>This setting is relevant if more controllers are working in the same ECL Comfort system (connected via the ECL 485 communication bus) and / or Remote Control Units (ECA 30 / 31) are connected.</i>		

- 0:** The controller works as slave.
The slave receives information about the outdoor temperature (S1), system time, and signal for DHW demand in the master.
- 1 ... 9:** The controller works as slave.
The slave receives information about the outdoor temperature (S1), system time, and signal for DHW demand in the master. The slave sends information about the desired flow temperature to the master.
- 10 ... 14:** Reserved.
- 15:** The ECL 485 communication bus is active.
The controller is master. The master sends information about the outdoor temperature (S1) and system time. Connected Remote Control Units (ECA 30 / 31) are powered.

The ECL Comfort controllers can be connected via the ECL 485 communication bus to perform a larger system (the ECL 485 communication bus can connect to max. 16 devices).

Each slave must be configured with its own address (1 ... 9).

However, more slaves can have the address 0 if they only have to receive information about outdoor temperature and system time (listeners).



The total cable length of max. 200 m (all devices incl. the internal ECL 485 communication bus) should not be exceeded.
Cable lengths of more than 200 m may cause noise sensibility (EMC).



In a system with MASTER / SLAVE controllers, only one MASTER controller with address 15 is allowed.

If by mistake more MASTER controllers are present in an ECL 485 communication bus system, decide which controller is to be MASTER. Change the address in the remaining controllers. However, the system will operate but not be stable with more than one MASTER controller.



In the MASTER controller, the address in 'ECL 485 addr. (master / slave address)', ID no. 2048, must always be 15.

Service Pin		2150
Circuit	Setting range	Factory setting
☐ ☐	0 / 1	0
<i>This setting is only used in connection with set-up of Modbus communication.</i>		
Not applicable for the time being and reserved for future use!		

Ext. reset		2151
Circuit	Setting range	Factory setting
☐ ☐	0 / 1	0
<i>This setting is only used in connection with set-up of Modbus communication.</i>		

- 0:** Reset not activated.
- 1:** Reset.

6.8.11 Language

Language		2050
Circuit	Setting range	Factory setting
	English / 'Local'	English
Choose your language.		



Local language is selected during installation. If you want to change to another local language, the application must be reinstalled. However, it is always possible to change between the local language and English.

Operating Guide ECL Comfort 210/296/310, application A275/A375

7.0 Miscellaneous

7.1 ECA 30 / 31 setup procedures

ECA 30 (code no. 087H3200) is a remote control unit with built-in room temperature sensor.

ECA 31 (code no. 087H3201) is a remote control unit with built-in room temperature sensor and humidity sensor (relative humidity).

An external room temperature sensor can be connected to both types to substitute the built-in sensor.

An external room temperature sensor will be recognized at ECA 30 / 31 power-up.

Connections: See the section 'Electrical connections'.

Max. two ECA 30 / 31 can be connected to one ECL controller or a system (master-slave) consisting of several ECL controllers connected on the same ECL 485 bus. In the master-slave system only one of the ECL controllers is master. The ECA 30 / 31 can, among others, be set to:

- monitor and set the ECL controller remotely
- measure the room temperature and (ECA 31) humidity
- extend comfort / saving period temporarily

After application upload in the ECL Comfort controller, the remote control unit ECA 30 / 31 will after approx. one minute ask to 'Copy application'.

Confirm this in order to upload the application to the ECA 30 / 31.

Menu structure

The menu structure of ECA 30 / 31 is an "ECA MENU" and the ECL menu, copied from the ECL Comfort controller.

The ECA MENU contains:

- ECA settings
- ECA system
- ECA factory

ECA settings: Offset adjustment of the measured room temperature.

Offset adjustment of relative humidity (ECA 31 only).

ECA system: Display, communication, override settings and version info.

ECA factory: Erase of all applications in the ECA 30 / 31, restore to factory settings, reset of ECL address and firmware update.

Part of the ECA 30 / 31 display in ECL mode:

MENU

— □ — — —

Danfoss
087H3200 v.1

Part of the ECA 30 / 31 display in ECA mode:

ECA MENU

□ — — — —

Danfoss
087H3201 v.1



If only the "ECA MENU" is shown, it can indicate that the ECA 30 / 31 is not having correct communication address.

See ECA MENU > ECA system > ECA communication: ECL address.
In most cases the ECL address setting must be "15".



Regarding ECA settings:

When ECA 30 / 31 is not used as remote unit, the offset adjustments menu(s) are not present.

Operating Guide ECL Comfort 210/296/310, application A275/A375

The ECL menus are as described for the ECL controller.

Most of the settings done directly in the ECL controller can be done via the ECA 30 / 31 too.



All settings can be seen even if the application key is not inserted in the ECL controller.
For changing settings, the application key must be inserted.

The Key overview (MENU > 'Common controller settings' > 'Key functions') does not show the applications of the key.




The ECA 30 / 31 will display this information (an X on the ECA 30 / 31 symbol) if the application in the ECL controller does not comply with the ECA 30 / 31:



In the example 1.10 is current version and 1.42 is desired version.



Display part of ECA 30 / 31:



This display indicates that an application has not been uploaded or the communication to the ECL controller (master) is not working properly.
An X on the ECL controller symbol indicates wrong setup of communication addresses.



Display part of ECA 30 / 31:



Newer versions of ECA 30 / 31 indicate the address number of the connected ECL Comfort controller.

Address number can be changed in the ECA MENU.

A stand-alone ECL Controller has the address 15.

Operating Guide ECL Comfort 210/296/310, application A275/A375

When ECA 30 / 31 is in ECA MENU mode, the date and measured room temperature is displayed.

ECA MENU > ECA settings > ECA sensor

Room T Offset	
Setting range	Factory setting
-10.0 ... 10.0 K	0.0 K
The measured room temperature can be corrected with a number of Kelvin. The corrected value is used by the heating circuit in the ECL controller.	

Minus value: The indicated room temperature is lower.

0.0 K: No correction of the measured room temperature.

Plus value: The indicated room temperature is higher.

ECA MENU > ECA settings > ECA sensor

RH offset (ECA 31 only)	
Setting range	Factory setting
-10.0 ... 10.0 %	0.0 %
The measured relative humidity can be corrected with a number of %-values. The corrected value is used by the application in the ECL controller.	

Minus value: The indicated relative humidity is lower.

0.0 %: No correction of the measured relative humidity.

Plus value: The indicated relative humidity is higher.

ECA MENU > ECA system > ECA display

Backlight (display brightness)	
Setting range	Factory setting
0 ... 10	5
Adjust the brightness of the display.	

0: Weak backlight.

10: Strong backlight.

Example:

Room T offset:	0.0 K
Displayed room temperature:	21.9 °C
Room T offset:	1.5 K
Displayed room temperature:	23.4 °C

Example:

RH offset:	0.0 %
Displayed relative humidity:	43.4 %
RH offset:	3.5 %
Displayed relative humidity:	46.9 %

Operating Guide ECL Comfort 210/296/310, application A275/A375

ECA MENU > ECA system > ECA display

Contrast (display contrast)	
Setting range	Factory setting
0 ... 10	3
Adjust the contrast of the display.	

0: Low contrast.

10: High contrast.

ECA MENU > ECA system > ECA display

Use as remote	
Setting range	Factory setting
OFF / ON	*)
ECA 30 / 31 can act as a simple or normal remote control for the ECL controller.	

OFF: Simple remote control, no room temperature signal.

ON: Remote control, room temperature signal is available.

***):** Differently, depending on chosen application.



When set to OFF: The ECA menu shows date and time.

When set to ON: The ECA menu shows date and room temperature (and for ECA 31 relative humidity).

ECA MENU > ECA system > ECA communication

Slave addr. (Slave address)	
Setting range	Factory setting
A / B	A
The setting of 'Slave addr.' is related to the setting 'ECA address' in the ECL controller. In the ECL controller it is selected from which ECA 30 / 31 unit the room temperature signal is received.	

A: The ECA 30 / 31 has the address A.

B: The ECA 30 / 31 has the address B.



For installation of an application in an ECL Comfort 210 / 296 / 310 controller the 'Slave addr.' must be A.



If two ECA 30 / 31 are connected in the same ECL 485 bus system, the 'Slave addr.' must be "A" in the one ECA 30 / 31 unit and "B" in the other.

Operating Guide ECL Comfort 210/296/310, application A275/A375

ECA MENU > ECA system > ECA communication

Connection addr. (Connection address)	
Setting range	Factory setting
1 ... 9 / 15	15
Setting of the address to which ECL controller the communication must run.	

1 .. 9: Slave controllers.

15: Master controller.



An ECA 30 / 31 can in an ECL 485 bus system (master – slave) be set to communicate, one by one, with all addressed ECL controllers.



Example:

Connection addr. = 15:	The ECA 30 / 31 communicates with the ECL master controller.
Connection addr. = 2:	The ECA 30 / 31 communicates with the ECL controller with address 2.



There must be a master controller present in order to broadcast time and date information.



An ECL Comfort controller 210 / 310, type B (without display and dial) cannot be assigned to the address 0 (zero).

ECA MENU > ECA system > ECA override

Override addr. (Override address)	
Setting range	Factory setting
OFF / 1 ... 9 / 15	OFF
The feature 'Override' (to extended comfort or saving period or holiday) must be addressed to the ECL controller in question.	

OFF: Override not possible.

1 .. 9: Address of slave controller for override.

15: Address of master controller for override.



Override functions:	Extended saving mode:	
	Extended comfort mode:	
	Holiday away from home:	
	Holiday at home:	



Override by means of settings in ECA 30 / 31 are cancelled if the ECL Comfort controller goes into holiday mode or is changed to another mode than scheduled mode.



The circuit in question for override in the ECL controller must be in scheduled mode.
See also the parameter 'Override circuit'.

Operating Guide ECL Comfort 210/296/310, application A275/A375

ECA MENU > ECA system > ECA override

Override circuit	
Setting range	Factory setting
OFF / 1 ... 4	OFF
The feature 'Override' (to extended comfort or saving period or holiday) must be addressed to the heating circuit in question.	

OFF: No heating circuit is selected for override.

1 ... 4: The heating circuit number in question.



The circuit in question for override in the ECL controller must be in scheduled mode.
See also the parameter 'Override addr.'.



Example 1:

(One ECL controller and one ECA 30 / 31)		
Override of heating circuit 2:	Set 'Connection addr.' to 15	Set 'Override circuit' to 2

Example 2:

(Several ECL controllers and one ECA 30 / 31)		
Override of heating circuit 1 in ECL controller with the address 6:	Set 'Connection addr.' to 6	Set 'Override circuit' to 1



Quick guide "ECA 30 / 31 to override mode":

1. Go to ECA MENU
2. Move cursor to "Clock" symbol
3. Select the "Clock" symbol
4. Choose and select one of 4 override functions
5. Below the override symbol: Set hours or date
6. Below hours / date: Set desired room temperature for the override period

ECA MENU > ECA system > ECA version

ECA version (read-out only), examples	
Code no.	087H3200
Hardware	A
Software	1.42
Build no.	5927
Serial no.	13579
Production week	23.2012



ECA 30 / 31:



15

Connection address (master: 15, slaves: 1 - 9)

The ECA version information is useful in service situations.

Operating Guide ECL Comfort 210/296/310, application A275/A375

ECA MENU > ECA factory > ECA clear apps.

Erase all apps. (Erase all applications)

*Erase all applications which are in the ECA 30 / 31.
After erasing, the application can be uploaded again.*



After the erase procedure, a pop-up in the display indicates "Copy application". Choose "Yes". Hereafter the application is uploaded from the ECL controller. An upload bar is shown.

NO: The erase procedure is not done.

YES: The erase procedure is done (await 5 sec.).

ECA MENU > ECA factory > ECA default

Restore factory

The ECA 30 / 31 is set back to factory settings.

Affected settings by the restore procedure:

- Room T offset
- RH offset (ECA 31)
- Backlight
- Contrast
- Use as remote
- Slave addr.
- Connection addr.
- Override addr.
- Override circuit
- Override mode
- Override mode end time

NO: The restore procedure is not done.

YES: The restore procedure is done.

Operating Guide ECL Comfort 210/296/310, application A275/A375

ECA MENU > ECA factory > Reset ECL addr.

Reset ECL addr. (Reset ECL address)

If none of the connected ECL Comfort controllers has the address 15, the ECA 30 / 31 can set all connected ECL controllers on the ECL 485 bus back to address 15.

NO: The reset procedure is not done.

YES: The reset procedure is done (await 10 sec.).



The ECL 485 bus related address of the ECL controller is found:
MENU > 'Common controller settings' > 'System' > 'Communication' > 'ECL 485 addr.'



The "Reset ECL addr." cannot be activated if one or more of the connected ECL Comfort controllers has the address 15.



In a system with MASTER / SLAVE controllers, only one MASTER controller with address 15 is allowed.

If by mistake more MASTER controllers are present in an ECL 485 communication bus system, decide which controller is to be MASTER. Change the address in the remaining controllers. However, the system will operate but not be stable with more than one MASTER controller.

ECA MENU > ECA factory > Update firmware

Update firmware

*The ECA 30 / 31 can be updated with new firmware (software). The firmware comes with the ECL application key, when the key version is at least 2.xx.
If no new firmware is available, a symbol of the application key is displayed with an X.*

NO: The updating procedure is not done.

YES: The updating procedure is done.



The ECA 30 / 31 automatically verifies if a new firmware is present on the application key in the ECL Comfort controller.
The ECA 30 / 31 is automatically updated at new application upload in the ECL Comfort controller.

The ECA 30 / 31 is not automatically updated when connected to an ECL Comfort controller with uploaded application. A manual update is always possible.



Quick guide "ECA 30 / 31 to override mode":

1. Go to ECA MENU
2. Move cursor to "Clock" symbol
3. Select the "Clock" symbol
4. Choose and select one of 4 override functions
5. Below the override symbol: Set hours or date
6. Below hours / date: Set desired room temperature for the override period

Operating Guide ECL Comfort 210/296/310, application A275/A375

7.2 Override function

The ECL 210 / 296 / 310 controllers can receive a signal in order to override the existing schedule. The override signal can be a switch or a relay contact.

Different override modes can be selected, depending on application key type.

Override modes: Comfort, Saving, Constant temperature and Frost protection.

"Comfort" is also called normal heating temperature.


"Saving" can be reduced heating or heating stopped.

"Constant temperature" is a desired flow temperature, set in the menu "Flow temperature".


"Frost protection" stops the heating totally.

Override by means of override switch or relay contact is possible when the ECL 210 / 296 / 310 is in scheduled mode (clock).

Example, override switch connected to S8:



Example, override relay connected to S8:



Operating Guide ECL Comfort 210/296/310, application A275/A375

Example 1

ECL in Saving mode, but in Comfort mode at override.


Choose an unused input, for example S8. Connect the override switch or override relay contact.

Settings in ECL:

1. Select circuit > MENU > Settings > Application > Ext. input:
Select the input S8 (the wiring example)
2. Select circuit > MENU > Settings > Application > Ext. mode:
Select COMFORT
3. Select circuit > MENU > Schedule:
Select all weekdays
Set "Start1" to 24.00 (this disables Comfort mode)
Exit menu and confirm by "Save"
4. Remember to set the circuit in question in scheduled mode ("clock").

Result: When the override switch (or the relay contact) is ON, the ECL 210 / 296 / 310 will operate in Comfort mode.

When the override switch (or the relay contact) is OFF, the ECL 210 / 296 / 310 will operate in Saving mode.



Example 2

ECL in Comfort mode, but in Saving mode at override.


Choose an unused input, for example S8. Connect the override switch or override relay contact.

Settings in ECL:

1. Select circuit > MENU > Settings > Application > Ext. input:
Select the input S8 (the wiring example)
2. Select circuit > MENU > Settings > Application > Ext. mode:
Select SAVING
3. Select circuit > MENU > Schedule:
Select all weekdays
Set "Start1" to 00.00
Set "Stop1" to 24.00
Exit menu and confirm by "Save"
4. Remember to set the circuit in question in scheduled mode ("clock").

Result: When the override switch (or the relay contact) is ON, the ECL 210 / 296 / 310 will operate in Saving mode.

When the override switch (or the relay contact) is OFF, the ECL 210 / 296 / 310 will operate in Comfort mode.



Operating Guide ECL Comfort 210/296/310, application A275/A375

Example 3

The week schedule for the building is set with comfort periods Monday - Friday: 07.00 - 17.30. Sometimes, a team meeting takes place in the evening or in the week-end.

An override switch is installed and heating must be ON (Comfort mode) as long as the switch is ON.


Choose an unused input, for example S8. Connect the override switch.

Settings in ECL:

1. Select circuit > MENU > Settings > Application > Ext. input:
Select the input S8 (the wiring example)
2. Select circuit > MENU > Settings > Application > Ext. mode:
Select COMFORT
3. Remember to set the circuit in question in scheduled mode ("clock").

Result: When the override switch (or a relay contact) is ON, the ECL 210 / 296 / 310 will operate in Comfort mode.

When the override switch is OFF, the ECL 210 / 296 / 310 will operate according to the schedule.



Example 4

The week schedule for the building is set with comfort periods all weekdays: 06.00 - 20.00. Sometimes, the desired flow temperature must be constant on 65 °C.

An override relay is installed and the flow temperature must be 65 °C as long as the override relay is activated.


Choose an unused input, for example S8. Connect the contacts of the override relay.

Settings in ECL:

1. Select circuit > MENU > Settings > Application > Ext. input:
Select the input S8 (the wiring example)
2. Select circuit > MENU > Settings > Application > Ext. mode:
Select CONST. T
3. Select circuit > MENU > Settings > Flow temperature >
Desired T (ID 1x004):
Set to 65 °C
4. Remember to set the circuit in question in scheduled mode ("clock").

Result: When the override relay is activated, the ECL 210 / 296 / 310 will operate in Const. temp. mode and control a flow temperature of 65 °C.

When the override relay is not activated, the ECL 210 / 296 / 310 will operate according to the schedule.



7.3 Several controllers in the same system

When ECL Comfort controllers are interconnected by means of the ECL 485 communication bus (cable type: 2 x twisted pair), the master controller will broadcast the following signals to the slave controllers:

- Outdoor temperature (measured by S1)
- Time and date
- DHW tank heating / charging activity

Furthermore, the master controller can receive information about:

- the desired flow temperature (demand) from slave controllers
- and (as from ECL controller version 1.48) DHW tank heating / charging activity in slave controllers

Situation 1:

SLAVE controllers: How to make use of the outdoor temperature signal sent from the MASTER controller


The slave controllers only receive information about outdoor temperature and date / time.

SLAVE controllers:

Change the factory set address from 15 to address 0.

- In , go to System > Communication > ECL 485 addr.

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Choose
	0 ... 15	0



ECL 485 bus cable

Maximum recommended length of the ECL 485 bus is calculated like this:

Subtract "Total length of all input cables of all ECL controllers in the master - slave system" from 200 m.

Simple example for total length of all input cables, 3 x ECL:

1 x ECL	Outdoor temp. sensor:	15 m
3 x ECL	Flow temp. sensor:	18 m
3 x ECL	Return temp. sensor:	18 m
3 x ECL	Room temp. sensor:	30 m
Total:		81 m

Maximum recommended length of the ECL 485 bus:
200 - 81 m = 119 m



In a system with MASTER / SLAVE controllers, only one MASTER controller with address 15 is allowed.

If by mistake more MASTER controllers are present in an ECL 485 communication bus system, decide which controller is to be MASTER. Change the address in the remaining controllers. However, the system will operate but not be stable with more than one MASTER controller.



In the MASTER controller, the address in 'ECL 485 addr. (master / slave address)', ID no. 2048, must always be 15.
Navigation:

- In , go to System > Communication > ECL 485 addr.

SLAVE controllers must be set to another address than 15:

Navigation:

- In , go to System > Communication > ECL 485 addr.



'Demand offset' with a value is to be used in the Master controller only.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Situation 2:

SLAVE controller: How to react on a DHW tank heating / charging activity sent from the MASTER controller

The slave receives information about a DHW tank heating / charging activity in the master controller and can be set to close the selected heating circuit.

ECL controller versions 1.48 (as from August 2013):

The master receives information about DHW tank heating / charging activity in the master controller itself and also slaves in the system.

This status is broadcasted to all ECL controllers in the system and each heating circuit can be set to close the heating.

SLAVE controller:

Set the desired function:

- In circuit 1 / circuit 2, go to 'Settings' > 'Application' > 'DHW priority':

DHW priority (closed valve / normal operation)		11052 / 12052
Circuit	Setting range	Choose
1 / 2	OFF / ON	OFF / ON

OFF: The flow temperature control remains unchanged during active DHW heating / charging in the master / slave system.

ON: The valve in the heating circuit is closed during active DHW heating / charging in the master / slave system.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Situation 3:

SLAVE controller: How to make use of the outdoor temperature signal and send information about the desired flow temperature back to the MASTER controller

The slave controller receives information about outdoor temperature and date / time. The master controller receives information about the desired flow temperature from slave controllers with an address from 1 ... 9:

SLAVE controller:

- In , go to System > Communication > ECL 485 addr.
- Change the factory set address from 15 to an address (1 ... 9). Each slave must be configured with its own address.

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Choose
	0 ... 15	1 ... 9

Furthermore, each slave can send information about the desired flow temperature (demand) in each circuit back to the master controller.

SLAVE controller:

- In the circuit in question, go to Settings > Application > Send desired T
- Choose ON or OFF.

Send desired T		11500 / 12500
Circuit	Setting range	Choose
1 / 2	OFF / ON	ON or OFF

OFF: Information about the desired flow temperature is not sent to the master controller.

ON: Information about the desired flow temperature is sent to the master controller.



In the MASTER controller, the address in 'ECL 485 addr. (master / slave address)', ID no. 2048, must always be 15.

7.4 Frequently asked questions



The definitions apply to the ECL Comfort 210 / 296 / 310 series. Consequently, you might come across expressions that are not mentioned in your guide.

Circulation pump (heating) does not stop as expected

It is in operation at frost protection (outdoor temperature lower than "P frost T" value) and at heat demand (desired flow temperature higher than "P heat T" value)

The time shown in the display is one hour off?

See 'Time and Date'.

The time shown in the display is not correct?

The internal clock may have been reset, if there has been a power break for more than 72 hours.

Go to the 'Common controller settings' and 'Time & Date' to set the correct time.

The ECL Application Key is lost?

Switch the power off and on again to see the ECL controller type, version code (e.g. 1.52), code no. and application (e.g. A266.1) or go to 'Common controller settings' > 'Key functions' > 'Application'. The system type (e.g. TYPE A266.1) and the system diagram is displayed.

Order a replacement from your Danfoss representative (e.g. ECL Application Key A266).

Insert the new ECL Application Key and copy your personal settings from the controller to the new ECL Application Key, if required.

The room temperature is too low?

Make sure that the radiator thermostat does not limit the room temperature.

If you still cannot obtain the desired room temperature by adjusting the radiator thermostats, the flow temperature is too low. Increase the desired room temperature (display with desired room temperature). If this does not help, adjust the 'Heat curve' ('Flow temp').

The room temperature is too high during saving periods?

Make sure that the min. flow temperature limitation ('Temp. min.') is not too high.

The temperature is unstable?

Check that the flow temperature sensor is correctly connected and in the right place. Adjust the control parameters ('Control par').

If the controller has a room temperature signal, see 'Room limit'.

The controller does not operate and the control valve is closed?

Check that the flow temperature sensor is measuring the correct value, see 'Daily use' or 'Input overview'.

Check the influence from other measured temperatures.

How to make an extra comfort period in the schedule?

You can set an additional comfort period by adding new 'Start' and 'Stop' times in 'Schedule'.

How to remove a comfort period in the schedule?

You can remove a comfort period by setting start and stop times to the same value.

How to restore your personal settings?

Please read the chapter concerning 'Inserting the ECL Application Key'.

How to restore the factory settings?

Please read the chapter concerning 'Inserting the ECL Application Key'.

Why can't the settings be changed?

The ECL Application Key has been removed.

Why can't an application be selected when inserting the ECL application key into the controller?

The actual application in the ECL Comfort controller must be deleted before a new application (subtype) can be selected.

How to react on alarms?

An alarm indicates that the system is not operating satisfactorily. Please contact your installer.

What does P and PI control mean?

P control: Proportional control.

By using a P control, the controller will change the flow temperature proportional to the difference between a desired and an actual temperature, e.g. a room temperature.

A P control will always have an offset which not will disappear over time.

PI control: Proportional and Integrating control.

A PI control does the same as a P control, but the offset will disappear over time.

A long 'Tn' will give a slow but stable control, and a short 'Tn' will result in a fast control but with a higher risk of instability.

What does the "i" in the upper right corner of the display mean?

When uploading an application (subtype) from the application key into the ECL Comfort controller, the "i" in the upper right corner indicates that - besides the factory settings - the subtype also contains special user / systems settings.

Why can't the ECL 485 Bus (used in ECL 210 / 296 / 310) and the ECL Bus (used in ECL 100 / 110 / 200 / 300) communicate?

These two communication busses (Danfoss proprietary) are different in connection form, telegram form and speed.

Why can't I select a language when uploading an application?

Reason can be that the ECL 310 is powered with 24 Volt d.c.

Language

At application upload, a language must be selected.*

If another language than English is selected, the selected language

AND English will be uploaded into the ECL controller.

This makes service easy for English speaking service people, just because the English language menus can be visible by changing the actual set language into English.

(Navigation: MENU > Common controller > System > Language)

If the uploaded language is not suitable, the application must be erased. User and System settings can be saved on the application key before erasing.

After new upload with preferred language, the existing User and System settings can be uploaded.

*)

(ECL Comfort 310, 24 Volt) If language cannot be selected, the power supply is not a.c. (alternating current).

Operating Guide ECL Comfort 210/296/310, application A275/A375

How to set a correct heat curve?

Short answer:

Set the heat curve to the lowest possible value, but still having comfortable room temperature.


The table shows some recommendations:

House with radiators:	Needed flow temp. when the outdoor temp. is -10 °C:	Recommended heat curve value:
Older than 20 years:	65 °C	1.4
Between 10 and 20 years old:	60 °C	1.2
Rather new:	50 °C	0.8
Floor heating systems need, in general, a lower heat curve value		

Technical answer:

In order to save energy, the flow temperature should be as low as possible, but still considering a comfortable room temperature. This means the heat curve slope should have a low value.

See the heat curve slope diagram.



Choose the desired flow temperature (vertical axis) for your heating system at the expected lowest outdoor temperature (horizontal axis) for your area. Pick the heat curve closest to the common point of these two values.

Example: Desired flow temperature: 60 (°C) at outdoor temperature: -10 (°C)

Result: Heat curve slope value = 1.2 (mid-way between 1.4 and 1.0).

In general:

- Smaller radiators in your heating system might require a higher heat curve slope. (Example: Desired flow temperature 70 °C resulting in heat curve = 1.5).
- Floor heating systems require a lower heat curve slope. (Example: Desired flow temperature 35 °C resulting in heat curve = 0.4).
- Corrections of the heat curve slope should be done in small steps when having outdoor temperatures below 0 °C; one step pr. day.
- If required, adjust the heat curve in the six coordinate points.
- Setting of the desired **room** temperature has an influence on the desired flow temperature even if a room temperature sensor / Remote Control Unit is not connected. An example: Increasing the desired **room** temperature results in a higher flow temperature.
- Typically, the desired **room** temperature should be adjusted when having outdoor temperatures above 0 °C.

Operating Guide ECL Comfort 210/296/310, application A275/A375

Pressure measuring


Pressure is measured by means of a pressure transmitter, generating 0 - 10 Volt in relation to measured pressure.

Voltage (0 - 10 V) converted to a displayed Pressure (Bar) (A375.4, A375.5).

The conversion scale for applied voltage (to terminal S9) into Bar is found:

(Navigation: Circuit 1 > MENU > Alarm > Pressure > Pressure)

Click the Pressure line and the scale diagram appears.



The pressure at "Low X" and "High X" can be set.

In the example (screen dump to the right) the pressure at 2.0 Volt is 0.0 bar and at 10.0 Volt the pressure is 15.0 bar.

Setting the voltage values (X values):

(Navigation: Circuit 1 > MENU > Alarm > Pressure > Low X, High X)

Low X (ID 13607) is set (example 2.0 Volt)

High X (ID 13608) is set (example 10.0 Volt)

Setting the related pressure at the X-values:

(Navigation: Circuit 1 > MENU > Alarm > Pressure > Pressure)

In the scale diagram, move cursor to 2.0 Volt:

- Set the pressure value at 2.0 Volt (example 0.0 bar)

Move cursor to 10.0 Volt:

- Set the pressure value at 10.0 Volt

7.5 Definitions



The definitions apply to the ECL Comfort 210 / 296 / 310 series. Consequently, you might come across expressions that are not mentioned in your guide.

Accumulated temperature value

A filtered (dampened) value, typically for room and outdoor temperatures. Is calculated in the ECL controller and is used to express the heat stored in the walls of the house. The accumulated value does not change so rapidly as the actual temperature.

Air duct temperature

Temperature measured in the air duct where the temperature is to be controlled.

Alarm function

Based on the alarm settings, the controller can activate an output.

Anti-bacteria function

For a defined period, the DHW temperature is increased in order to neutralize dangerous bacteria, e.g. Legionella.

Balance temperature

This setpoint is the basis for the flow / air duct temperature. The balance temperature can be adjusted by the room temperature, the compensation temperature and the return temperature. The balance temperature is only active if a room temperature sensor is connected.

BMS

Building Management System. A supervisory system for remote control and monitoring.

Comfort operation

Normal temperature in the system controlled by the schedule. During heating the flow temperature in the system is higher to maintain the desired room temperature. During cooling the flow temperature in the system is lower to maintain the desired room temperature.

Comfort temperature

Temperature maintained in the circuits during comfort periods. Normally during daytime.

Compensation temperature

A measured temperature influencing the flow temperature reference / balance temperature.

Desired flow temperature

Temperature calculated by the controller on basis of the outdoor temperature and influences from the room and / or return temperatures. This temperature is used as a reference for the control.

Desired room temperature

Temperature which is set as the desired room temperature. The temperature can only be controlled by the ECL Comfort controller if a room temperature sensor is installed. If a sensor is not installed, the set desired room temperature however still influences the flow temperature. In both cases the room temperature in each room is typically controlled by radiator thermostats / valves.

Desired temperature

Temperature based on a setting or a controller calculation.

Dew point temperature

Temperature at which the humidity in the air condensates.

DHW circuit

The circuit for heating the domestic hot water (DHW).

Duct temperature

Temperature measured in the air duct where the temperature is to be controlled.

ECL 485 Bus

This communication bus is Danfoss proprietary and used for internal communication between ECL 210, ECL 210B, ECL 296, ECL 310, ECL 310B, ECA 30 and ECA 31.

Communication with "ECL Bus", used in ECL 100, ECL 110, ECL 200, ECL 300 and ECL 301, is not possible.

ECL Portal

A supervisory system for remote control and monitoring, locally and via Internet.

EMS

Energy Management System. A supervisory system for remote control and monitoring.

Factory settings

Settings stored on the ECL Application Key to simplify the set up of your controller the first time.

Firmware

is used by the ECL Comfort controller and ECA 30 / 31 to manage display, dial and program execution.

Flow temperature

Temperature measured in the water flow where the temperature is to be controlled.

Flow temperature reference

Temperature calculated by the controller on basis of the outdoor temperature and influences from the room and / or return temperatures. This temperature is used as a reference for the control.

Heat curve

A curve showing the relationship between actual outdoor temperature and desired flow temperature.

Heating circuit

The circuit for heating the room / building.

Holiday schedule

Selected days can be programmed to be in comfort, saving or frost protection mode. Besides this, a day schedule with comfort period from 07.00 to 23.00 can be selected.

Humidistat

A device, which reacts on the air's humidity. A switch can go ON if the measured humidity gets above a set point.

Humidity, relative

This value (stated in %) refers to the indoor moisture content compared to the max. moisture content. The relative humidity is measured by the ECA 31 and is used for the calculation of the dew point temperature.

Inlet temperature

Temperature measured in the inlet air flow where the temperature is to be controlled.

Limitation temperature

Temperature that influences the desired flow / balance temperature.

Log function

The temperature history is displayed.

Master / slave

Two or more controllers are interconnected on the same bus, the master sends out e.g. time, date and outdoor temperature. The slave receives data from master and sends e.g. desired flow temperature value.

Modulating control (0 - 10 V control)

Positioning (by means of a 0 - 10 V control signal) of the actuator for the motorized control valve in order to control the flow.

Optimization

The controller optimizes the start time of the scheduled temperature periods. Based on the outdoor temperature, the controller automatically calculates when to start in order to reach the comfort temperature at the set time. The lower the outdoor temperature, the earlier the start time.

Outdoor temperature trend

The arrow indicates the tendency, i.e. whether the temperature rises or falls.

Override mode

When ECL Comfort is in Scheduled mode, a switch or contact signal can be applied to an input in order to override to Comfort, Saving, Frost protection or Constant temperature. As long as the switch or contact signal is applied, the override is active.

Pt 1000 sensor

All sensors used with the ECL Comfort controller are based on the Pt 1000 type (IEC 751B). The resistance is 1000 ohm at 0 °C and it changes with 3.9 ohm / degree.

Pump control

One circulation pump is working and the other is the spare circulation pump. After a set time, the roles are exchanged.

Refill water function

If the measured pressure in the heating system is too low (e.g. due to a leakage), water can be supplemented.

Return temperature

The temperature measured in the return influences the desired flow temperature.

Room temperature

Temperature measured by the room temperature sensor or the Remote Control Unit. The room temperature can only be controlled directly if a sensor is installed. The room temperature influences the desired flow temperature.

Room temperature sensor

Temperature sensor placed in the room (reference room, typically the living room) where the temperature is to be controlled.

Saving temperature

Temperature maintained in the heating / DHW circuit during saving temperature periods. Typically, the Saving temperature is lower than the Comfort temperature in order to save energy.

SCADA

Supervisory Control And Data Acquisition. A supervisory system for remote control and monitoring.

Schedule

Schedule for periods with comfort and saving temperatures. The schedule can be made individually for each week day and may consist of up to 3 comfort periods per day.

Software

is used in the ECL Comfort controller to do the application related processes.

Weather compensation

Flow temperature control based on the outdoor temperature. The control is related to a user-defined heat curve.

2-point control

ON / OFF control, e.g. circulation pump, ON / OFF valve, change-over valve or damper control.

3-point control

Actuator positioning by means of Opening, Closing or No-action signals for the motorized control valve in order to control the flow. No-action means that the actuator remains in its current position.

Operating Guide ECL Comfort 210/296/310, application A275/A375

7.6 Type (ID 6001), overview

	Type 0	Type 1	Type 2	Type 3	Type 4
Address	✓	✓	✓	✓	✓
Type	✓	✓	✓	✓	✓
Scan time	✓	✓	✓	✓	✓
ID / Serial	✓	✓	✓	✓	✓
Reserved	✓	✓	✓	✓	✓
Flow temp. [0.01 °C]	✓	✓	✓	✓	-
Return temp. [0.01 °C]	✓	✓	✓	✓	-
Flow [0.1 l/h]	✓	✓	✓	✓	-
Power [0.1 kW]	✓	✓	✓	✓	-
Acc. Volume	[0.1 m3]	[0.1 m3]	[0.1 m3]	[0.1 m3]	-
Acc. Energy	[0.1 kWh]	[0.1 MWh]	[0.1 kWh]	[0.1 MWh]	-
Tariff1 Acc. Energy	-	-	[0.1 kWh]	[0.1 MWh]	-
Tariff2 Acc. Energy	-	-	[0.1 kWh]	[0.1 MWh]	-
Up time [days]	-	-	✓	✓	-
Current time [M-bus defined structure]	-	-	✓	✓	✓
Error status [energy meter defined bitmask]	-	-	✓	✓	-
Acc. Volume	-	-	-	-	[0.1 m3]
Acc. Energy	-	-	-	-	[0.1 kWh]
Acc. Volume2	-	-	-	-	[0.1 m3]
Acc. Energy2	-	-	-	-	[0.1 kWh]
Acc. Volume3	-	-	-	-	[0.1 m3]
Acc. Energy3	-	-	-	-	[0.1 kWh]
Acc. Volume4	-	-	-	-	[0.1 m3]
Acc. Energy4	-	-	-	-	[0.1 kWh]
Flow MAX	[0.1 l/h]	[0.1 l/h]	[0.1 l/h]	[0.1 l/h]	-
Power MAX	[0.1 kW]	[0.1 kW]	[0.1 kW]	[0.1 kW]	-
Max T forward	✓	✓	✓	✓	-
Max T return	✓	✓	✓	✓	-
Storage * Acc. Energy	[0.1 kWh]	[0.1 kWh]	[0.1 kWh]	[0.1 kWh]	-

7.7 Automatic / manual update of firmware

Info:

- Firmware and application software are on the application key
- ECL Comfort has firmware implemented
- Firmware with Encryption has version 2.00 and up

Situation 1:

ECL Comfort controller, new (= no application installed), from before 10th of July 2018, to be installed:

1. Insert application key.
2. If the firmware on application key is newer than the firmware in the ECL, an update will be done automatically.
3. Hereafter the application can be uploaded.
4. If the firmware in the ECL is newer than the firmware on application key, the application can be uploaded.

Situation 2:

ECL Comfort controller is installed and runs an application.

1. Store all settings on the existing application key *.
2. Erase actual application in the ECL **.
3. Insert an application key with new firmware. The firmware update will be done automatically.
4. When ECL requires language selection, then remove application key.
5. Insert "old" application key.
6. Select language, select application subtype and see an "i" in upper right corner.
7. Set time / date if needed.
8. Choose "Next".
9. In Copy menu, choose YES at System and User settings; then choose "Next".
10. "Old" application is uploaded, ECL restarts and is ready again.

* Navigation: MENU > Common controller settings > Key functions > Copy > "To KEY", System settings = YES, User settings = YES, Start copying: Push dial.
Within 1 sec the settings are stored on the application key.

** Navigation: MENU > Common controller settings > Key functions > New application > Erase application: Push dial.

NOTE: You might come in a situation where the update will not elapse. This is typically when one or two ECA 30 are connected.

Remedy: Disconnect (remove from its base) the ECA 30. If ECL 310B, then only one ECA 30 should be connected.

Operating Guide ECL Comfort 210/296/310, application A275/A375

7.8 Parameter ID overview

A275.x or A375.x — x refers to the subtypes listed in the column.

ID	Parameter Name	A275.x	A375.x	Setting range	Factory	Unit	Own settings	
11004	Desired T		4, 5	5 ... 150	50	°C		96
11010	ECA addr.	1, 2, 3	1, 2, 3, 4, 5	OFF ; A ; B	OFF			127
11011	Auto saving	1, 2, 3	1, 2, 3, 4, 5	OFF, -29 ... 10	-15	°C		108
11012	Boost	1, 2, 3	1, 2, 3, 4, 5	OFF, 1 ... 99	OFF	%		109
11014	Optimizer	1, 2, 3	1, 2, 3, 4, 5	OFF, 10 ... 59	OFF			110
11015	Adapt. time	1, 2, 3	1, 2, 3, 4, 5	OFF, 1 ... 50	OFF	Sec		101
11017	Demand offset	1, 2, 3	1, 2, 3, 4, 5	OFF, 1 ... 20	OFF	K		127
11020	Based on	1, 2, 3	1, 2, 3, 4, 5	OUT ; ROOM	OUT			111
11021	Total stop	1, 2, 3	1, 2, 3, 4, 5	OFF ; ON	OFF			111
11022	P exercise	1, 2, 3	1, 2, 3, 4, 5	OFF ; ON	ON			127
11026	Pre-stop	1, 2, 3	1, 2, 3, 4, 5	OFF ; ON	ON			112
11028	Con. T, ret. T lim.		4, 5	10 ... 110	70	°C		104
11029	DHW, ret. T limit		4, 5	OFF, 10 ... 110	OFF	°C		104
11031	High T out X1	1, 2, 3	1, 2, 3, 4, 5	-60 ... 20	15	°C		105
11032	Low limit Y1	1, 2, 3	1, 2, 3, 4, 5	10 ... 150	35	°C		105
11033	Low T out X2	1, 2, 3	1, 2, 3, 4, 5	-60 ... 20	-15	°C		105
11034	High limit Y2	1, 2, 3	1, 2, 3, 4, 5	10 ... 150	35	°C		105
11035	Infl. - max.	1, 2, 3	1, 2, 3, 4, 5	-9.9 ... 9.9	0.0			106
11036	Infl. - min.	1, 2, 3	1, 2, 3, 4, 5	-9.9 ... 9.9	0.0			106
11037	Adapt. time	1, 2, 3	1, 2, 3, 4, 5	OFF, 1 ... 50	25	Sec		106
11038	Stop at T out	1, 2, 3	1, 2, 3	-49 ... 49, OFF	OFF	°C		114
11040	P post-run	1, 2, 3	1, 2, 3, 4, 5	0 ... 99	3	Min		128
11046	Difference	1, 2, 3		OFF, 1 ... 50	8	K		114
	- -		1, 2, 3, 4, 5	1 ... 50	8	K		
11047	Protection	1, 2, 3	1, 2, 3	OFF ; ON	OFF			114
11048	Band limit		1, 2, 3	5 ... 80	20	K		115
11049	Max. T limit	1, 2, 3	1, 2, 3	40 ... 150	90	°C		115
11050	P demand	1, 2, 3	1, 2, 3, 4, 5	OFF ; ON	OFF			128
11071	Min. ON time	1, 2, 3	1, 2, 3	0 ... 9	0	Min		116
11072	Sequence type		1, 2, 3	0 ... 5	3			116
11073	Steps		1, 2, 3	1 ... 8	1			117
11074	Reaction, o. band		1, 2, 3	5 ... 6000	60	Sec		117
11075	Reaction, in band		1, 2, 3	5 ... 6000	120	Sec		118
11077	P frost T	1, 2, 3	1, 2, 3, 4, 5	OFF, -10 ... 20	2	°C		130

Operating Guide ECL Comfort 210/296/310, application A275/A375

ID	Parameter Name	A275.x	A375.x	Setting range	Factory	Unit	Own settings	
11078	P heat T	1, 2, 3	1, 2, 3, 4, 5	5 ... 40	20	°C		130
11085	Priority	1, 2, 3	1, 2, 3, 4, 5	OFF ; ON	OFF			106
11093	Frost pr. T	1, 2, 3	1, 2, 3, 4, 5	5 ... 40	10	°C		130
11141	Ext. input	1, 2, 3		OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8	OFF			131
	- -		1, 2, 3	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10	OFF			
	- -		4, 5	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10 ; S11 ; S12 ; S13 ; S14 ; S15 ; S16	OFF			
11142	Ext. mode	1, 2, 3	1, 2, 3	COMFORT ; SAVING	COMFORT			131
	- -		4, 5	COMFORT ; SAVING ; FROST PR. ; CONST. T	COMFORT			
11177	Temp. min.	1, 2, 3	1, 2, 3, 4, 5	10 ... 150	10	°C		96
11178	Temp. max.	1, 2, 3	1, 2, 3, 4, 5	10 ... 150	90	°C		96
11179	Summer, cut-out	1, 2, 3	1, 2, 3, 4, 5	OFF, 1 ... 50	20	°C		112
11182	Infl. - max.	1, 2, 3	1, 2, 3, 4, 5	-9.9 ... 0.0	-4.0			101
11183	Infl. - min.	1, 2, 3	1, 2, 3, 4, 5	0.0 ... 9.9	0.0			102
11184	Xp		4, 5	5 ... 250	120	K		
11185	Tn		4, 5	1 ... 999	50	Sec		
11186	M run		4, 5	5 ... 250	60	Sec		
11187	Nz		4, 5	1 ... 9	3	K		
11189	Min. act. time		4, 5	2 ... 50	10			
11364	Control, delay		4, 5	0 ... 15	2	Min		
11424	Min. off time		4, 5	0 ... 30	1	Min		
11500	Send desired T	1, 2, 3	1, 2, 3, 4, 5	OFF ; ON	OFF			133
11607	Low X		4, 5	10 ... 150	20	°C		
11608	High X		4, 5	10 ... 150	100	°C		
11609	Low Y		1, 2, 3	10 ... 150	10	°C		
	- -		4, 5	0.0 ... 10.0	0.0	V		
11610	High Y		1, 2, 3	10 ... 150	100	°C		
	- -		4, 5	0.0 ... 10.0	10.0	V		
12010	ECA addr.	3	3, 5	OFF ; A ; B	OFF			127
12011	Auto saving	3	3, 5	OFF, -29 ... 10	-15	°C		108
12012	Boost	3	3, 5	OFF, 1 ... 99	OFF	%		109

Operating Guide ECL Comfort 210/296/310, application A275/A375


ID	Parameter Name	A275.x	A375.x	Setting range	Factory	Unit	Own settings	
12013	Ramp	3	3, 5	OFF, 1 ... 99	OFF	Min		110
12014	Optimizer	3	3, 5	OFF, 10 ... 59	OFF			110
12015	Adapt. time	3	3, 5	OFF, 1 ... 50	OFF	Sec		101
12020	Based on	3	3, 5	OUT ; ROOM	OUT			111
12021	Total stop	3	3, 5	OFF ; ON	OFF			111
12022	P exercise	3	3, 5	OFF ; ON	ON			127
12023	M exercise	3	3, 5	OFF ; ON	OFF			127
12024	Actuator	3	3, 5	ABV ; GEAR	GEAR			123
12026	Pre-stop	3	3, 5	OFF ; ON	ON			112
12031	High T out X1	3	3, 5	-60 ... 20	15	°C		105
12032	Low limit Y1	3	3, 5	10 ... 150	40	°C		105
12033	Low T out X2	3	3, 5	-60 ... 20	-15	°C		105
12034	High limit Y2	3	3, 5	10 ... 150	60	°C		105
12035	Infl. - max.	3	3, 5	-9.9 ... 9.9	0.0			106
12036	Infl. - min.	3	3, 5	-9.9 ... 9.9	0.0			106
12037	Adapt. time	3	3, 5	OFF, 1 ... 50	25	Sec		106
12040	P post-run	3	3, 5	0 ... 99	3	Min		128
12041	DHW P post-run	2	2	0 ... 30	0	Min		128
12051	Ch.-o. valve / P	2	2	OFF ; ON	ON			128
12052	DHW priority	3	3, 5	OFF ; ON	OFF			129
12053	Tank, sec. / prim.	2	2	OFF ; ON	OFF			129
12055	Circ. P priority		2	OFF ; ON	OFF			129
12076	Circ. P frost T		2	OFF, -10 ... 20	2	°C		130
12077	P frost T	3	3, 5	OFF, -10 ... 20	2	°C		130
12078	P heat T	3	3, 5	5 ... 40	20	°C		130
12085	Priority	3	3, 5	OFF ; ON	OFF			106
12093	Frost pr. T	2, 3	2, 3, 5	5 ... 40	10	°C		130
12122	Day:	2	2	0 ... 127	0			
12123	Start time	2	2	0 ... 47	0			
12124	Duration	2	2	10 ... 600	120	Min		
12125	Desired T	2	2	OFF, 10 ... 110	OFF	°C		
12141	Ext. input	2, 3		OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8	OFF			131
	- -		2, 3	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10	OFF			

Operating Guide ECL Comfort 210/296/310, application A275/A375

ID	Parameter Name	A275.x	A375.x	Setting range	Factory	Unit	Own settings	
	- -		5	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10 ; S11 ; S12 ; S13 ; S14 ; S15 ; S16	OFF			
12142	Ext. mode	2, 3	2, 3, 5	COMFORT ; SAVING	COMFORT			131
12147	Upper difference	3	3, 5	OFF, 1 ... 30	OFF	K		139
12148	Lower difference	3	3, 5	OFF, 1 ... 30	OFF	K		139
12149	Delay	3	3, 5	1 ... 99	10	Min		141
12150	Lowest temp.	3	3, 5	10 ... 50	30	°C		141
12174	Motor pr.	3	3, 5	OFF, 10 ... 59	OFF	Min		123
12177	Temp. min.	3	3, 5	10 ... 150	10	°C		96
12178	Temp. max.	3	3, 5	10 ... 150	45	°C		96
12179	Summer, cut-out	3	3, 5	OFF, 1 ... 50	20	°C		112
12182	Infl. - max.	3	3, 5	-9.9 ... 0.0	-4.0			101
12183	Infl. - min.	3	3, 5	0.0 ... 9.9	0.0			102
12184	Xp	3	3, 5	5 ... 250	80	K		
12185	Tn	3	3, 5	1 ... 999	30	Sec		
12186	M run	3	3, 5	5 ... 250	50	Sec		
12187	Nz	3	3, 5	1 ... 9	3	K		
12189	Min. act. time	3	3, 5	2 ... 50	10			
12193	Charge difference	2	2	1 ... 50	15	K		98
12194	Stop difference	2	2	-50 ... 50	3	K		98
12195	Start difference	2	2	-50 ... -1	-3	K		99
12500	Send desired T	2, 3	2, 3, 5	OFF ; ON	ON			133
13041	DHW P post-run	3	1, 3, 5	0 ... 30	0	Min		128
13051	Ch.-o. valve / P	3	1, 3, 5	OFF ; ON	ON			128
13053	Tank, sec. / prim.	3	1, 3, 5	OFF ; ON	OFF			129
13093	Frost pr. T	3	3, 5	5 ... 40	10	°C		130
13122	Day:	3	3, 5	0 ... 127	0			
13123	Start time	3	3, 5	0 ... 47	0			
13124	Duration	3	3, 5	10 ... 600	120	Min		
13125	Desired T	3	3, 5	OFF, 10 ... 110	OFF	°C		

Operating Guide ECL Comfort 210/296/310, application A275/A375

ID	Parameter Name	A275.x	A375.x	Setting range	Factory	Unit	Own settings	
13141	Ext. input	3		OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8	OFF			131
	- -		3	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10	OFF			
	- -		5	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10 ; S11 ; S12 ; S13 ; S14 ; S15 ; S16	OFF			
13142	Ext. mode	3	3, 5	COMFORT ; SAVING	COMFORT			131
13193	Charge difference	3	3, 5	1 ... 50	15	K		98
13194	Stop difference	3	3, 5	-50 ... 50	3	K		98
13195	Start difference	3	3, 5	-50 ... -1	-3	K		99
13500	Send desired T	3	3, 5	OFF ; ON	ON			133
13607	Low X		4, 5	0.0 ... 10.0	2.0	V		
13608	High X		4, 5	0.0 ... 10.0	10.0	V		
13609	Low Y		4, 5	0.0 ... 15.0	0.0	Bar		
13610	High Y		4, 5	0.0 ... 15.0	20.0	Bar		
13614	Alarm high		4, 5	0.0 ... 15.0	2.3	Bar		138
13615	Alarm low		4, 5	0.0 ... 15.0	0.0	Bar		138
13617	Alarm time-out		4, 5	0 ... 240	30	Sec		139



Installer:

By:

Date:

Operating Guide ECL Comfort 210/296/310, application A275/A375



Danfoss A/S

Heating Segment • danfoss.com • +45 7488 2222 • E-Mail: heating@danfoss.com

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.
All trademarks in this material are property of the respective companies. Danfoss and all Danfoss logotypes are trademarks of Danfoss A/S. All rights reserved.