

Installation Guide

Pack controller Type **AK-PC 651A**




080R9349



AN373527611165en-000201

Identification




080G0336




UL file: E31024

IP 20
CE: -20 – +60 °C, UL: 0 – 50 °C
(CE: 0 – 140 °F, UL: 32 – 122 °F)
RH max. 90% non condensing

External display





MMIGRS2: 080G0294



Termination!
H-R

Danfoss
080G0294

Principle




ENGLISH

Connection, lower level

Warning

The supply voltage of AI may not share the signal with other controllers.



DO	DO1	DO2	DO3	DO4	DO5	DO6	DO7	DO8	DO9	DO10	DO11	DO12	DO13	DO14	DO15
I Max.	Res: 5A (100k cycles) Ind: 3A (100k cycles)		0.5 A, min. 50 mA loff < 1,5 mA				Res: 5A (100k cycles) Ind: 3A (100k cycles)							Res: 16A (50k cycles) Ind: 3.5A (230k cycles)	
U	All 24 V or all 230 V AC						All 24 V or all 230 V AC							All 24 V or all 230 V AC	

DO - Digital outputs, 15 pcs. DO1 - DO15

Relays from DO3 to DO6 are solid state relays.
The relays are de-rated to the specified values.
It is possible to use up to two SSR simultaneously.

AI - Analogue inputs, 6 pcs. AI1 - AI6

Temperature sensor

- Pt 1000 ohm, AKS 11 or AKS 21.
- NTC 86K ohm @ 25 °C, from digital scroll.

Pressure transmitters

- Current: 0 - 20 mA / 4 - 20 mA, AKS 33 (supply = 12 V)

AI - Analogue inputs, 4 pcs. AI7 - AI10

Pressure transmitters

- Ratiometric: 10 - 90 % of supply, AKS 32R
- Signal: 1 - 5 V, AKS 32
- PT1000

Factory settings: AI7=Po, AI8=Pc

Temperature sensor

See above

Supply Voltage.

21 - 265 V AC, 50/60 Hz
40 - 230 V DC

AO - Analogue output, 4 pcs. AO1 - AO4

Can be used when using frequency converter or EC Motor.
Analog outputs 0 - 10 V are self-powered: no need of an additional power supply.
Analog Outputs are opto-isolated.


Modbus

It is important that the installation of the data communication cable be done correctly. Cf. separate literature No. RC8AC.
Remember termination at the bus termination.


Termination

(Only if an external display is connected)


Insert a jumper between the two connections on the left (R120-CANH).



Connection, upper level





Dimensions




For DIN rail mounting only (IP 20)

The capacity from the digital scroll compressor



The capacity is divided into period times as "PWM per". 100% capacity is delivered when cooling takes place for the whole period. An off time is required by the bypass valve within the period and an on time is also permitted. There is "no cooling" when the valve is on.

The controller itself calculates the capacity needed and will then vary it according to the cut-in time of the capacity control valve. A limit is introduced if low capacity is needed so that the cooling does not go below 10%. This is because the compressor can cool itself. This value can be increased if necessary.



Copeland Stream compressor

The PWM signal can also be used to control one stream compressor with one unloader valve (Stream 4) or one with two unloaders (Stream 6).


Stream 4: The compressor capacity is distributed by up to 50% for one relay and the remaining 50-100% for the unloader. The unloader is connected to SSR outputs (DO3-6).

Stream 6: The compressor capacity is distributed by up to 33% for one relay and the remaining 33-100% for the unloader. The unloaders are connected to SSR outputs (DO3-6).

Bitzer CRII Ecoline

CRII 4: The pulse signal can also be used to control one CRII with two unloaders (4-cylinder version).

The compressor capacity can be controlled from 10 to 100%, depending on the pulsation of the unloaders. The compressor start signal is connected to a relay output, and the unloaders are connected to SSR outputs (DO3-6).



CRII 6: The pulse signal can also be used to control one CRII with three unloaders (6-cylinder version).

The compressor signal is connected to one relay output.

The three unloaders can be connected to DO3, 4, 5 and 6.

The compressor capacity can be controlled from 10 to 67%, depending on the pulse of the unloaders.

The relay is then connected to the third unloader. When this relay is off, the capacity will be controlled between 33 and 100%.