

Operating Guide

ECL Comfort 310, application P330



1.0 Table of Contents

1.0 Table of Contents	1
1.1 Important safety and product information.....	2
2.0 Installation	5
2.1 Before you start	5
2.2 Identifying the system type	12
2.3 Mounting	28
2.4 Placing the temperature sensors.....	32
2.5 Electrical connections.....	34
2.6 Inserting the ECL Application Key	47
2.7 Check list	54
2.8 Navigation, ECL Application Key P330	55
3.0 Daily use	60
3.1 How to navigate	60
3.2 Understanding the controller display	61
3.3 A general overview: What do the symbols mean?	65
3.4 Monitoring temperatures and system components	66
3.5 Influence overview	67
3.6 Manual control	68
3.7 Schedule	69
4.0 Settings overview	70
5.0 Settings.....	72
5.1 Introduction to Settings	72
5.2 Flow temperature.....	73
5.3 Room limit	76
5.4 Return limit	78
5.5 Flow / power limit	82
5.6 Optimization.....	85
5.7 Control parameters.....	90
5.8 Application	93
5.9 Tank temperature.....	100
5.10 Anti-bacteria.....	106
5.11 Alarm	108
6.0 Common controller settings.....	110
6.1 Introduction to 'Common controller settings'	110
6.2 Time & Date.....	112
6.3 Holiday	113
6.4 Input overview	115
6.5 Log	116
6.6 Output override.....	117
6.7 Key functions.....	118
6.8 System.....	120
7.0 Miscellaneous	127
7.1 ECA 30 / 31 setup procedures	127
7.2 Override function.....	135
7.3 Several controllers in the same system	138
7.4 Frequently asked questions.....	141
7.5 Definitions	144
7.6 Type (ID 6001), overview	148
7.7 Automatic / manual update of firmware.....	149
7.8 Parameter ID overview.....	150

1.1 Important safety and product information

1.1.1 Important safety and product information

This Operating Guide is associated with ECL Application Key P330 (order code no. 087H3840).

The functions are realized in ECL Comfort 310 for advanced solutions, e.g. M-bus, Modbus and Ethernet (Internet) communication.

P330 applications can communicate (via Modbus connections) with the DECS 2.0 system (Danfoss Energy Control System). Please see DECS 2.0 related literature on the Danfoss website: <http://danfoss.com> Search for 'DECS 2.0'.

The application P330 complies with ECL Comfort controllers 310 as of software version 1.40 (visible at start-up of the controller and in 'Common controller settings' in 'System').

Additional documentation for ECL Comfort 310, modules and accessories is available on www.danfoss.com.



Application keys might be released before all display texts are translated. In this case the text is in English.



Safety Note

To avoid injury of persons and damages to the device, it is absolutely necessary to read and observe these instructions carefully.

Necessary assembly, start-up, and maintenance work must be performed by qualified and authorized personnel only.

Local legislations must be respected. This comprises also cable dimensions and type of isolation (double isolated at 230 V).

A fuse for the **ECL Comfort 296 / 210 / 310** installation is max. 10 A typically.

A fuse for the **ECL Comfort 120** installation is **max. 6 A.**

The ambient temperature ranges for ECL Comfort in operation are:

ECL Comfort 120: -5-50 °C

ECL Comfort 210 / 310: 0-50 °C

ECL Comfort 296: 0 - 45 °C.

Exceeding the temperature range can result in malfunctions.

Installation must be avoided if there is a risk for condensation (dew).

The warning sign is used to emphasize special conditions that should be taken into consideration.




Automatic update of controller software (firmware):

The software of the controller is updated automatically when the key is inserted:

- ECL 210 / 310, as of controller version 1.11
- ECL 296, as of controller version 1.58

The following animation will be shown when the software is being updated:



Progress bar

During update:

- Do not remove the KEY
If the key is removed before the hour-glass is shown, you have to start afresh.
- Do not disconnect the power
If the power is interrupted when the hour-glass is shown, the controller will not work.
- Manual update of controller software (firmware):
See the section "Automatic / manual update of firmware"



This symbol indicates that this particular piece of information should be read with special attention.



As this Operating Guide covers several system types, special system settings will be marked with a system type. All system types are shown in the chapter: 'Identifying your system type'.



°C (degrees Celsius) is a measured temperature value whereas K (Kelvin) often is used for temperature differences.




The ID no. is unique for the selected parameter.

Example	First digit	Second digit	Last three digits
11174	1	1	174
	-	Circuit 1	Parameter no.
12174	1	2	174
	-	Circuit 2	Parameter no.

If an ID description is mentioned more than once, it means that there are special settings for one or more system types. It will be marked with the system type in question (e.g. 12174 - A266.9).



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.



Disposal Note

This symbol on the product indicates that it may not be disposed of as household waste.
It must be handed over to the applicable take-back scheme for the recycling of electrical and electronic equipment.

- Dispose of the product through channels provided for this purpose.
- Comply with all local and currently applicable laws and regulations.

2.0 Installation

2.1 Before you start

The 14 different applications **P330.1 ...P330.14** are heating and DHW applications in various combinations.

The basic principles for a heating circuit

(example referring to P330.1)

Typically, the flow temperature is adjusted according to your requirements.

The flow temperature sensor S3 is the most important sensor. The desired flow temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired flow temperature.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature). The motorized control valve M1 is opened gradually when the flow temperature is lower than the desired flow temperature and vice versa.

The return temperature (S5) can be limited, for example not to be too high. If so, the desired flow temperature at S3 can be adjusted (typically to a lower value), thus resulting in a gradual closing of the motorized control valve. Furthermore, the return temperature limitation can be dependent on the outdoor temperature.

Typically, the lower the outdoor temperature, the higher the accepted return temperature. In boiler-based heating supply the return temperature should not be too low (same adjustment procedure as above).

A flow / power limitation can be arranged by using an M-bus based signal from a flow / heat meter. Furthermore, the limitation can be in relation to the outdoor temperature.

If the measured room temperature, S13 or via the remote control unit ECA 30 does not equal the desired room temperature, the desired flow temperature can be adjusted.

General information:

In 'Saving' mode the heating can be reduced or totally switched off. The 'Frost protection' mode maintains a selectable flow temperature, for example 10 °C.


The circulation pump (P2) is ON at heat demand or at frost protection.

The heating can be switched OFF when the outdoor temperature is higher than a selectable value.

The desired flow temperature of heating circuit 1 can, via S8, be controlled by means of an external voltage in the range 0-10 volt.

Exercise of circulation pump and control valve can be arranged.

Application P330.1:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components, for example heating circuit 1 (P330.1):

- S1 Outdoor temperature sensor
- S3 Flow temperature sensor
- S5 (Optional) Return temperature sensor
- S8 (Optional) External temperature control, not illustrated
- S13 (Optional) Room temperature sensor
- M1 Motorized control valve
- P2 Circulation pump
- A1 Alarm

Operating Guide ECL Comfort 310, application P330

The basic principles for a DHW circuit, type 1

(example referring to P330.4)

By means of a week schedule (up to 3 'Comfort' periods / day), the DHW circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired DHW temperature at S10).

The DHW heating temperature sensor S9 is the most important sensor. If the measured DHW temperature (S10) gets lower than the desired DHW temperature, the DHW heating pump (P7) is switched ON. The motorized control valve (M3) is controlled in order to maintain the DHW heating temperature at S9. The DHW heating temperature is determined by the desired DHW temperature at S10 plus the charging difference. When the DHW heating temperature is reached, the DHW charging pump P5 is switched ON. The DHW heating temperature at S9 is typically 5–10 degrees higher than the desired DHW temperature.

DHW tank with 1 temperature sensor (S10):

When the measured DHW temperature (S10) gets higher than the desired DHW temperature, the DHW heating pump (P7) and the DHW charging pump (P5) are switched OFF. The post-run time can be set individually.

DHW tank with 2 temperature sensors (S10, upper and S2, lower):

If the measured DHW temperature (S10) gets higher than the desired DHW temperature and the temperature (at S2) gets higher than the cut-out temperature, the DHW heating pump (P7) and the DHW charging pump (P5) are switched OFF. The post-run time can be set individually.

The DHW circulation can be through the DHW tank (connection A) or through the heat-exchanger (connection B). The solution with connection A results in closing of the motorized control valve after the DHW tank charging procedure. The solution with connection B is used to compensate for the heat loss in the DHW circulation pipe. Furthermore, after DHW tank charging, the DHW heating temperature (at S9) is controlled according to the desired DHW temperature.

The return temperature (S7) can be limited, for example not to be too high. If so, the desired flow temperature at S9 can be adjusted (typically to a lower value), thus resulting in a gradual closing of the motorized control valve. In boiler-based heating supply the return temperature should not be too low (same adjustment procedure as above).

A flow / power limitation can be arranged by using an M-bus based signal from a flow / heat meter.

General information:


The 'Frost protection' mode maintains a selectable temperature, for example 10 °C.

An anti-bacteria function is available for activation on selected days of the week.

The outdoor temperature sensor S1 is used to protect the circulation circuit against frost.

The DHW circulation pump (P8) has a week schedule for up to 3 ON periods per day.

Application P330.4:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components, for example DHW circuit, type 1 (P330.4):

- S1 Outdoor temperature sensor
- S2 (Optional) Lower DHW tank temperature sensor
- S7 (Optional) Return temperature sensor
- S9 Flow temperature sensor
- S10 Upper DHW tank temperature sensor
- M3 Motorized control valve
- P5 DHW charging pump
- P7 DHW heating pump
- P8 DHW circulation pump
- A1 Alarm

Operating Guide ECL Comfort 310, application P330

The basic principles for a DHW circuit, type 2

(example referring to P330.5)

By means of a week schedule (up to 3 'Comfort' periods / day), the DHW circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired DHW temperature at S10).

When the measured DHW temperature (S10) gets lower than the desired DHW temperature, the DHW heating pump (P7) and the DHW charging pump (P5) are switched ON.

DHW tank with 1 temperature sensor (S10):

When the measured DHW temperature (S10) gets higher than the desired DHW temperature, the DHW heating pump (P7) and the DHW charging pump (P5) are switched OFF. The post-run time can be set individually.

DHW tank with 2 temperature sensors (S10, upper and S2, lower):

When the measured DHW temperature (S10) gets higher than the desired DHW temperature and the temperature (at S2) gets higher than the cut-out temperature, the DHW heating pump (P7) and the DHW charging pump (P5) are switched OFF. The post-run time can be set individually.

The DHW circulation can be through the DHW tank (connection A) or through the heat-exchanger (connection B). The solution with connection A results in closing of the motorized control valve after the DHW tank charging procedure. The solution with connection B is used to compensate for the heat loss in the DHW circulation pipe. After DHW tank charging, the DHW charging pump P5 stops. The heating pump P7 continues being switched ON.

An anti-bacteria function is available for activation on selected days of the week.


The outdoor temperature sensor S1 is used to protect the circulation circuit against frost.

The DHW circulation pump (P8) has a week schedule for up to 3 ON periods per day.

General information:

The 'Frost protection' mode maintains a selectable temperature, for example 10 °C.

Application P330.5:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components, for example DHW circuit, type 2 (P330.5):

S1 Outdoor temperature sensor

S2 (Optional) Lower DHW tank temperature sensor

S10 Upper DHW tank temperature sensor

P5 DHW charging pump

P7 DHW heating pump

P8 DHW circulation pump

A1 Alarm

Operating Guide ECL Comfort 310, application P330

The basic principles for the master circuit

(example referring to P330.10)

The desired flow temperature at S3 is adjusted according to the demand from the sub-circuits (heating and DHW circuits). The flow temperature sensor S3 is the most important sensor.

The motorized control valve M1 is opened gradually when the flow temperature is lower than the desired flow temperature and vice versa.

The return temperature (S5) can be limited, for example not to be too high. If so, the desired flow temperature at S3 can be adjusted (typically to a lower value), thus resulting in a gradual closing of the motorized control valve. Furthermore, the return temperature limitation can be dependent on the outdoor temperature.

Typically, the lower the outdoor temperature, the higher the accepted return temperature.


In boiler-based heating supply the return temperature should not be too low (same adjustment procedure as above).

The circulation pump (P1) is ON at heat demand or at frost protection.

General information:

The desired flow temperature of the master circuit can, via S8, be controlled by means of an external voltage in the range 0-10 volt.

Application P330.10:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components, for example master circuit (P330.10):

- S1 Outdoor temperature sensor
- S3 Flow temperature sensor
- S5 (Optional) Return temperature sensor
- S8 (Optional) External temperature control, not illustrated
- M1 Motorized control valve
- P1 Circulation pump
- A1 Alarm

Operating Guide ECL Comfort 310, application P330

The basic principles for the master circuit with buffer (example referring to P330.14)

The highest demand from the sub-circuits (heating and DHW circuits) plus a difference ('Demand offset') determine the desired buffer tank temperature at S11.

When the measured buffer tank temperature (S11) gets lower than the desired buffer tank temperature, the charging pump (P1) is switched ON.

The motorized control valve (M1) is controlled in order to maintain the buffer tank heating temperature at S3. The motorized control valve is opened gradually when the flow temperature is lower than the desired flow temperature and vice versa.

The flow temperature sensor S3 is the most important sensor.

The desired temperature at S3 is determined by the desired buffer tank temperature at S11 plus a charging temperature difference. The buffer tank heating temperature at S3 is typically 5–10 degrees higher than the desired buffer tank temperature.

Buffer tank with 1 temperature sensor (S11):

When the measured buffer tank temperature (S11) gets higher than the desired buffer tank temperature, the charging pump (P1) is switched OFF. The post-run time can be set.

Buffer tank with 2 temperature sensors (S11, upper and S12, lower):

When the measured upper buffer tank temperature (S11) gets higher than the desired buffer tank temperature **and** the measured lower buffer tank temperature (S12) gets higher than the cut-out temperature, the charging pump (P1) is switched OFF. The post-run time can be set.

If S12 is not connected, S11 will be used for ON and OFF control of the charging pump.


The return temperature (S5) can be limited, for example not to be too high. If so, the desired flow temperature at S3 can be adjusted (typically to a lower value), thus resulting in a gradual closing of the motorized control valve. Furthermore, the return temperature limitation can be dependent on the outdoor temperature.

Typically, the lower the outdoor temperature, the higher the accepted return temperature.

In boiler-based heating supply the return temperature should not be too low (same adjustment procedure as above).

When the measured buffer temperature (S11) gets higher than the desired buffer temperature, the desired temperature at S3 is lowered to typically 10 °C. Hereafter the charging pump (P1) is switched OFF. The post-run time can be set.

Application P330.14:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components, for example master circuit with buffer (P330.14):

S1 Outdoor temperature sensor

S3 Flow temperature sensor

S5 (Optional) Return temperature sensor

S8 (Optional) External temperature control, not illustrated

S11 Upper buffer tank temperature sensor

S12 (Optional) Lower buffer tank temperature sensor

M1 Motorized control valve

P1 Buffer tank charging pump

A1 Alarm

Application P330.14:

In order to avoid a discharging of the DHW circuit (a higher DHW temperature goes to a lower buffer tank temperature) two parameters can be set:

- * The parameter ("Tank start diff.", ID no 13192) determines an acceptable temperature difference between S10 and S11 in order to start the DHW charging.
- * The parameter ("Tank stop diff.", ID no 13196) determines an acceptable temperature drop of the difference between S10 and S11 in order to stop the DHW charging.

General information:

The desired flow temperature of the master circuit can, via S8, be controlled by means of an external voltage in the range 0-10 volt.

Application P330.1 – P330.5:

Heating circuits 2, 3, 4 and DHW circuits can be connected after heating circuit 1. Circuit 1 acts as master and can react on the sub-circuits demand. If so, the desired flow temperature at S3 can be influenced by the desired flow temperature at S4, S9, S10 and DHW charging temperature respectively.

The desired flow temperature of heating circuit 1 can, via S8, be controlled by means of an external voltage in the range 0 - 10 volt.

Application P330.6 – P330.15:

Heating circuits and DHW circuits are typically connected after the master controlled circuit (M). When so, the desired flow temperature at S3 can be influenced by the desired flow temperature at S4, S9, S10 and DHW charging temperatures.

The desired flow temperature of the master circuit can, via S8, be controlled by means of an external voltage in the range 0 - 10 volt.

Application P330 in general:

Up to two Remote Control Units, the ECA 30 (one for each heating circuit) can be connected to one ECL controller in order to measure the room temperature and control the ECL controller remotely.

When the DHW circuit is active during the charging procedure, selected heating circuits can be closed in order to give higher priority to the DHW charging.

One or more connected flow or energy meters (based on M-bus signal) can limit the flow or energy to a set maximum (DHW circuits) and in relation to the outdoor temperature (heating and master circuits).

Unused input can, by means of an override switch, be used to override the schedule to a fixed 'Comfort' or 'Saving' mode.

Input S8 can be used to control the desired flow temperature of heating circuit 1 or the master circuit. The applied voltage signal in the range 0-10 volt is converted in the ECL controller to the desired flow temperature.

Modbus communication to a SCADA system can be established. The M-bus data can furthermore be transferred to the Modbus communication.

Alarm relay (R6) can be activated:

- if the actual flow temperature differs from the desired flow temperature.
- if a temperature sensor or its connection disconnects / short circuits. (See: Common controller settings > System > Raw input overview).




The controller is pre-programmed with factory settings that are shown in the 'Parameter ID overview' appendix.

2.2 Identifying the system type

Sketch your application

The ECL Comfort controller series is designed for a wide range of heating, domestic hot-water (DHW) and cooling systems with different configurations and capacities. If your system differs from the diagrams shown here, you may want to make a sketch of the system about to be installed. This makes it easier to use the Operating Guide, which will guide you step-by-step from installation to final adjustments before the end-user takes over.


The ECL Comfort controller is a universal controller that can be used for various systems. Based on the shown standard systems, it is possible to configure additional systems. In this chapter you find the most frequently used systems. If your system is not quite as shown below, find the diagram which has the best resemblance with your system and make your own combinations.



See the Installation Guide (delivered with the application key) for application types / sub-types.

P330.1

Two heating circuits



Special settings for type P330.1:

Navigation:

ID no.:

Recommended setting:

Heating circuit (circuit 2)

Settings for sub-circuit in order to send demand to circuit 1:

MENU \ Settings \ Application: 'Send desired T'

1x500

ON

Heating circuit (circuit 1)

Heating circuit can be a sub-circuit of heating circuit 1:

Setting for circuit 1 to respond to sub circuit demand:

MENU\Settings\Application: "Demand offset"


1x017

OFF*

* This value is added to the heat demand value from sub-circuit

P330.2

Three heating circuits



Special settings for type P330.2:

Navigation:

ID no.:

Recommended setting:

Heating circuit (circuit 2 and 3)

Settings for sub-circuit(s) in order to send demand to circuit 1:

MENU \ Settings \ Application: 'Send desired T'

1x500

ON

Heating circuit (circuit 1)

Heating circuits 2 and 3 can be partial circuits of heating circuit 1:

Setting for circuit 1 to respond to sub circuit(s) demand:

MENU\Settings\Application: "Demand offset"

1x017


OFF*

* This value is added to the heat demand value from sub-circuit(s)

Operating Guide ECL Comfort 310, application P330

P330.3

Four heating circuits. The MCV in circuit 4 is controlled by 0 – 10 V.



Special settings for type P330.3

Navigation:

ID no.:

Recommended setting:

Heating circuit (circuit 2, 3 and 4)

Settings for sub-circuit(s) in order to send demand to circuit 1:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Heating circuit (circuit 1)

Heating circuits 2, 3 and 4 can be partial circuits of heating circuit 1:


Setting for circuit 1 to respond to sub circuit(s) demand:

MENU \ Settings \ Application: 'Demand offset' 1x017 OFF*

* This value is added to the heat demand value from sub-circuit(s)

P330.4

Two heating circuits and one DHW charging circuit with controlled heating temperature.



Special settings for type P330.4:

Navigation:

ID no.:

Recommended setting:

Heating circuit 2 and DHW circuit

Settings for sub-circuit(s) in order to send demand to circuit 1:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Heating circuit (circuit 1)

Heating circuit 2 and the DHW circuit can be sub-circuits of heating circuit 1:

Setting for circuit 1 to respond to sub circuit(s) demand

MENU \ Settings \ Application: 'Demand offset' 1x017 OFF*

* This value is added to the heat demand value from sub-circuit(s)

DHW circulation pipe

The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.


(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 OFF

(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 ON

Operating Guide ECL Comfort 310, application P330

P330.5

Three heating circuits and one DHW charging circuit.



Special settings for type P330.5

Navigation:

ID no.:

Recommended setting:

Heating circuit 2 and 3 and DHW circuit

Settings for sub-circuit(s) in order to send demand to circuit 1:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Heating circuit (circuit 1)

Heating circuits 2 and 3 and the DHW circuit can be sub-circuits of heating circuit 1:
Setting for circuit 1 to respond to sub circuit(s) demand:

MENU\Settings\Application: "Demand offset" 1x017 OFF*

* This value is added to the heat demand value from sub-circuit(s)

DHW circulation pipe


The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.

(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 OFF

(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 ON

P330.6

One master circuit and one heating circuit as sub-circuit.



Special settings for type P330.6:

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit.

Sub-circuit

Settings for sub-circuit in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Master circuit

Settings for master circuit in order to react on demand in sub-circuit:


MENU \ Settings (M) \ Application: 'Demand offset' 1x017 3 K*

* This value is added to the heat demand value from sub-circuit

Operating Guide ECL Comfort 310, application P330

P330.7

One master circuit and two heating circuits as sub-circuits.



Special settings for type P330.7

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T' 1x500

ON

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):


MENU \ Settings (M) \ Application: 'Demand offset' 1x017

3 K*

* This value is added to the heat demand value from sub-circuit(s)

P330.8

One master circuit and three heating circuits as sub-circuits. The MCV in circuit 3 is controlled by 0 – 10 V.



Special settings for type P330.8

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):


MENU \ Settings (M) \ Application: 'Demand offset' 1x017 3 K*

* This value is added to the heat demand value from sub-circuit(s)

Operating Guide ECL Comfort 310, application P330

P330.9

One master circuit, a heating circuit and a DHW charging circuit with controlled heating temperature as sub-circuits.



Special settings for type P330.9

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):

MENU \ Settings (M) \ Application: 'Demand offset' 1x017 3 K*

* This value is added to the heat demand value from sub-circuit(s)

DHW circulation pipe


The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.

(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 OFF

(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 ON

P330.10

One master circuit, one heating circuit, one DHW charging circuit with controlled heating temperature and one DHW charging circuit as sub-circuits.



Special settings for type P330.10

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T'	1x500	ON
---	-------	----

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):

MENU \ Settings (M) \ Application: 'Demand offset'	1x017	3 K*
--	-------	------

* This value is added to the heat demand value from sub-circuit(s)

DHW circulation pipe


The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.

(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control'	1x054	OFF
(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control'	1x054	ON

Operating Guide ECL Comfort 310, application P330

P330.11

One master circuit, two heating circuits and one DHW charging circuit as sub-circuits.



Special settings for type P330.11

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):

MENU \ Settings (M) \ Application: 'Demand offset' 1x017 3 K*

* This value is added to the heat demand value from sub-circuit(s)

DHW circulation pipe


The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.

(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 OFF

(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 ON

P330.12

One master circuit, three heating circuits and one DHW charging circuit as sub-circuits. The MCV in circuit 4 is controlled by 0 – 10 V.



Special settings for type P330.12

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T'	1x500	ON
---	-------	----

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):

MENU \ Settings (M) \ Application: 'Demand offset'	1x017	3 K*
--	-------	------

* This value is added to the heat demand value from sub-circuit(s)

DHW circulation pipe


The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.

(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control'	1x054	OFF
(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control'	1x054	ON

Operating Guide ECL Comfort 310, application P330

P330.13

One master circuit, two heating circuits and two DHW charging circuits as sub-circuits.



Special settings for type P330.13

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):

MENU \ Settings (M) \ Application: 'Demand offset' 1x017 3 K*

* This value is added to the heat demand value from sub-circuit(s)


DHW circulation pipe

The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.

(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control'	1x054	OFF
(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control'	1x054	ON

P330.14

One master circuit with buffer tank, two heating circuits and one DHW charging circuits as sub-circuits.



Special settings for type P330.14

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):

MENU \ Settings (M) \ Application: 'Demand offset' 1x017 3 K*

* This value is added to the heat demand value from sub-circuit(s)

DHW circulation pipe


The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.

(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control'	1x054	OFF
(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control'	1x054	ON

Operating Guide ECL Comfort 310, application P330

P330.15

One master circuit. One heating circuit and one DHW charging circuits as sub-circuits.



Special settings for type P330.15

Navigation:

ID no.:

Recommended setting:

The master circuit reacts on demand in the sub-circuit(s).

Sub-circuit(s)

Settings for sub-circuit(s) in order to send demand to master circuit:

MENU \ Settings \ Application: 'Send desired T' 1x500 ON

Master circuit

Settings for master circuit in order to react on demand in sub-circuit(s):

MENU \ Settings (M) \ Application: 'Demand offset' 1x017 3 K*

* This value is added to the heat demand value from sub-circuit(s)

DHW circulation pipe

The DHW circulation pipe can be connected to the DHW tank at 'A' for internal circulation or to the heat exchanger at 'B' for external circulation.

(Internal DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 OFF

(External DHW circulation) MENU \ Settings \ Application: 'Cont. T control' 1x054 ON

2.3 Mounting

2.3.1 Mounting the ECL Comfort controller

See the Installation Guide which is delivered together with the ECL Comfort controller.

For easy access, you should mount the ECL Comfort controller near the system.

ECL Comfort 210 / 296 / 310 can be mounted

- on a wall
- on a DIN rail (35 mm)

ECL Comfort 296 can be mounted

- in a panel cut-out

ECL Comfort 210 can be mounted in an ECL Comfort 310 base part (for future upgrade).

Screws, PG cable glands and rawlplugs are not supplied.

Locking the ECL Comfort 210 / 310 controller

In order to fasten the ECL Comfort controller to its base part, secure the controller with the locking pin.



To prevent injuries to persons or the controller, the controller has to be securely locked into the base. For this purpose, press the locking pin into the base until a click is heard and the controller no longer can be removed from the base.




If the controller is not securely locked into the base part, there is a risk that the controller during operation can unlock from the base and the base with terminals (and also the 230 V a.c. connections) are exposed. To prevent injuries to persons, always make sure that the controller is securely locked into its base. If this is not the case, the controller should not be operated!



The easy way to lock the controller to its base or unlock it is to use a screw driver as lever.


Mounting on a wall

Mount the base part on a wall with a smooth surface. Establish the electrical connections and position the controller in the base part. Secure the controller with the locking pin.




Mounting on a DIN rail (35 mm)

Mount the base part on a DIN rail. Establish the electrical connections and position the controller in the base part. Secure the controller with the locking pin.



Dismounting the ECL Comfort controller

In order to remove the controller from the base part, pull out the locking pin by means of a screwdriver. The controller can now be removed from the base part.



The easy way to lock the controller to its base or unlock it is to use a screw driver as lever.



Before removing the ECL Comfort controller from the base part, ensure that the supply voltage is disconnected.

2.3.2 Mounting the Remote Control Units ECA 30 / 31


Select one of the following methods:

- Mounting on a wall, ECA 30 / 31
- Mounting in a panel, ECA 30

Screws and rawlplugs are not supplied.

Mounting on a wall


Mount the base part of the ECA 30 / 31 on a wall with a smooth surface. Establish the electrical connections. Place the ECA 30 / 31 in the base part.



Mounting in a panel

Mount the ECA 30 in a panel using the ECA 30 frame kit (order code no. 087H3236). Establish the electrical connections. Secure the frame with the clamp. Place the ECA 30 in the base part. The ECA 30 can be connected to an external room temperature sensor.


The ECA 31 must not be mounted in a panel if the humidity function is to be used.




Operating Guide ECL Comfort 310, application P330

2.3.3 Mounting the internal I/O module ECA 32 or ECA 35


The ECA 32 module (order code no. 087H3202) or ECA 35 module (order code no. 087H3205) can be inserted into the ECL Comfort 310 / 310B base part for additional input and output signals in relevant applications.



ECA 32



ECA 35



2.4 Placing the temperature sensors


2.4.1 Placing the temperature sensors

It is important that the sensors are mounted in the correct position in your system.

The temperature sensor mentioned below are sensors used for the ECL Comfort 210 / 296 / 310 series which not all will be needed for your application!

Outdoor temperature sensor (ESMT)

The outdoor sensor should be mounted on that side of the building where it is less likely to be exposed to direct sunshine. It should not be placed close to doors, windows or air outlets.



Flow temperature sensor (ESMU, ESM-11 or ESMC)

Place the sensor max. 15 cm from the mixing point. In systems with heat exchanger, Danfoss recommends that the ESMU-type to be inserted into the exchanger flow outlet.


Make sure that the surface of the pipe is clean and even where the sensor is mounted.

Return temperature sensor (ESMU, ESM-11 or ESMC)

The return temperature sensor should always be placed so that it measures a representative return temperature.

Room temperature sensor (ESM-10, ECA 30 / 31 Remote Control Unit)

Place the room sensor in the room where the temperature is to be controlled. Do not place it on outside walls or close to radiators, windows or doors.



Boiler temperature sensor (ESMU, ESM-11 or ESMC)

Place the sensor according to the boiler manufacturer's specification.

Air duct temperature sensor (ESMB-12 or ESMU types)




Place the sensor so that it measures a representative temperature.

DHW temperature sensor (ESMU or ESMB-12)

Place the DHW temperature sensor according to the manufacturer's specification.

Slab temperature sensor (ESMB-12)


Place the sensor in a protection tube in the slab.



Operating Guide ECL Comfort 310, application P330

Pt 1000 temperature sensor (IEC 751B, 1000 Ω / 0 °C)

Relationship between temperature and ohmic value:



2.5 Electrical connections

2.5.1 Electrical connections 230 V a.c.



Warning

Electric conductors on PCB (Printed Circuit Board) for supply voltage, relay contacts and triac outputs do not have mutual safety distance of minimum 6 mm. The outputs are not allowed to be used as galvanic separated (volt free) outputs.

If a galvanic separated output is needed, an auxiliary relay is recommended.

24 Volt controlled units, for example actuators, are to be controlled by means of ECL Comfort 310, 24 Volt version.



Safety Note

Necessary assembly, start-up, and maintenance work must be performed by qualified and authorized personnel only.


Local legislations must be respected. This comprises also cable size and isolation (reinforced type).

A fuse for the ECL Comfort installation is max. 10 A typically.

The ambient temperature range for the ECL Comfort in operation is 0 - 55 °C. Exceeding this temperature range can result in malfunctions.

Installation must be avoided if there is a risk for condensation (dew).

The common ground terminal is used for connection of relevant components (pumps, motorized control valves).



See also the Installation Guide (delivered with the application key) for application specific connections.


Operating Guide ECL Comfort 310, application P330

2.5.2 Electrical connections, 230 V a.c., power supply, pumps, dampers, motorized control valves etc.

Connections for P330, in general:

See also the Installation Guide (delivered with the application key) for application specific connections.

Application P330



Terminal	Description	Max. load
19	Phase for circulation pump / DHW charging pump / Alarm	
18 A1	Alarm	4 (2) A / 230 V a.c.*
17 P5	Circulation pump / DHW charging pump	4 (2) A / 230 V a.c.*
16	Phase for circulation pump / charging pump	
15 P4	Circulation pump / DHW charging pump	4 (2) A / 230 V a.c.*
14	Phase for circulation pump / charging pump	
13 P3	Circulation pump	4 (2) A / 230 V a.c.*
12 P2	Circulation pump	4 (2) A / 230 V a.c.*
11 P1	Circulation pump / charging pump	4 (2) A / 230 V a.c.*
10	Supply voltage 230 V a.c. - neutral (N)	
9	Supply voltage 230 V a.c. - live (L)	
8	Phase for motorized control valve output	
7 M1	Motorized control valve - opening	0.2 A / 230 V a.c.
6 M1	Motorized control valve - closing	0.2 A / 230 V a.c.
5	Phase for motorized control valve output	
4 M2	Motorized control valve - opening	0.2 A / 230 V a.c.
3 M2	Motorized control valve - closing	0.2 A / 230 V a.c.
2 M3	Motorized control valve - opening	0.2 A / 230 V a.c.
1 M3	Motorized control valve - closing	0.2 A / 230 V a.c.

* Relay contacts: 4 A for ohmic load, 2 A for inductive load

Factory established jumpers:

5 to 8, 9 to 14, L to 5 and L to 9, N to 10



Wire cross section: 0.5 - 1.5 mm²


Incorrect connection can damage the electronic outputs.

Max. 2 x 1.5 mm² wires can be inserted into each screw terminal.

2.5.3 ECA 32, relay outputs in general

Connections for P330, in general:


See also the Installation Guide (delivered with the application key) for application specific connections.



ECA 32, 0 - 10 V output

Connections for P330, in general:



See also the Installation Guide (delivered with the application key) for application specific connections.



2.5.4 Electrical connections, safety thermostats, 230 V a.c.


With safety thermostat, 1-step closing:

Motorized control valve without safety function




With safety thermostat, 1-step closing:

Motorized control valve with safety function





Operating Guide ECL Comfort 310, application P330



With safety thermostat, 2-step closing:

With safety thermostat, 2-step closing.



When ST is activated by a high temperature, the safety circuit in the motorized control valve closes the valve immediately.



When ST1 is activated by a high temperature (the TR temperature), the motorized control valve is closed gradually. At a higher temperature (the ST temperature), the safety circuit in the motorized control valve closes the valve immediately.



Wire cross section: 0.5 - 1.5 mm²

Incorrect connection can damage the electronic outputs.

Max. 2 x 1.5 mm² wires can be inserted into each screw terminal.


2.5.5 Electrical connections, Pt 1000 temperature sensors and signals

See the Installation Guide (delivered with the application key) for sensor and input connections.

Connections for P330, in general:

See also the Installation Guide (delivered with the application key) for application specific connections.

Terminal	Sensor / description	Type (recomm.)
29 and 30	S1 Outdoor temperature sensor*	ESMT
28 and 30	S2 Temperature sensor	ESM-11 / ESMB / ESMC / ESMU
27 and 30	S3 Flow temperature sensor**	ESM-11 / ESMB / ESMC / ESMU
26 and 30	S4 Flow temperature sensor**	ESM-11 / ESMB / ESMC / ESMU
25 and 30	S5 (Optional) Return temperature sensor	ESM-11 / ESMB / ESMC / ESMU
24 and 30	S6 (Optional) Return temperature sensor	ESM-11 / ESMB / ESMC / ESMU
23 and 30	S7 (Optional) Return temperature sensor	ESM-11 / ESMB / ESMC / ESMU
22 and 30	S8 Voltage signal (0-10 V) for external control of desired flow temperature, heating circuit 1 or Master circuit.	
21 and 30	S9 Flow temperature sensor **	ESM-11 / ESMB / ESMC / ESMU
20 and 30	S10 Upper DHW tank temperature sensor *** / flow temperature sensor **	ESMB / ESMU ESM-11 / ESMB / ESMC / ESMU



* If the outdoor temperature sensor is not connected or the cable is short-circuited, the controller assumes that the outdoor temperature is 0 (zero) °C.

** The sensor must always be connected in order to have the desired functionality. If the sensor is not connected or the cable is short-circuited, the motorized control valve closes (safety function).

*** This sensor is used if only one tank temperature sensor is required.


Factory established jumper:
30 to common terminal.



Wire cross section for sensor connections: Min. 0.4 mm².
Total cable length: Max. 200 m (all sensors incl. internal ECL 485 communication bus)
Cable lengths of more than 200 m may cause noise sensibility (EMC).

Operating Guide ECL Comfort 310, application P330

Connection of voltage signal (0–10 V) to S8 for external control of desired flow temperature




Electrical connections, ECA 32

Connections for P330, in general:

See also the Installation Guide (delivered with the application key) for application specific connections.

Terminal	Sensor / description	Type (recomm.)
50 and 49	S11	Upper tank / buffer tank temperature sensor
51 and 49	S12	Lower tank / buffer tank temperature
52 and 49	S13	(Optional) Room temperature sensor
53 and 49	S14	(Optional) Room temperature sensor
54 and 49	S15	(Optional) Room temperature sensor
55 and 49	S16	(Optional) Room temperature sensor



Operating Guide ECL Comfort 310, application P330

2.5.6 Electrical connections, ECA 30 / 31



Terminal ECL	Terminal ECA 30 / 31	Description	Type (recomm.)
30	4	Twisted pair	
31	1		Cable 2 x twisted pair
32	2	Twisted pair	
33	3		Cable 2 x twisted pair
	4	Ext. room temperature sensor*	ESM-10
	5		

* After an external room temperature sensor has been connected, ECA 30 / 31 must be repowered.

The communication to the ECA 30 / 31 must be set up in the ECL Comfort controller in 'ECA addr'.

The ECA 30 / 31 must be set up accordingly.

After application setup the ECA 30 / 31 is ready after 2–5 min. A progress bar in the ECA 30 / 31 is displayed.



If the actual application contains two heating circuits, it is possible to connect an ECA 30 / 31 to each circuit. The electrical connections are done in parallel.



Max. 2 ECA 30 / 31 can be connected to an ECL Comfort 310 controller or to ECL Comfort 210 / 296 / 310 controllers in a master-slave system.



Setup procedures for ECA 30 / 31: See section 'Miscellaneous'.



ECA information message:

'Application req. newer ECA':

The software (firmware) of your ECA does not comply with the software (firmware) of your ECL Comfort controller. Please contact your Danfoss sales office.



Some applications do not contain functions related to actual room temperature. The connected ECA 30 / 31 will only function as remote control.



Total cable length: Max. 200 m (all sensors incl. internal ECL 485 communication bus).

Cable lengths of more than 200 m may cause noise sensibility (EMC).

2.5.7 Electrical connections, master / slave systems

The controller can be used as master or slave in master / slave systems via the internal ECL 485 communication bus (2 x twisted pair cable).

The ECL 485 communication bus is not compatible with the ECL bus in ECL Comfort 110, 200, 300 and 301!

Terminal	Description	Type (recomm.)
30	Common terminal	Cable 2 x twisted pair
31	+12 V*, ECL 485 communication bus * Only for ECA 30 / 31 and master / slave communication	
32	B, ECL 485 communication bus	
33	A, ECL 485 communication bus	



ECL 485 bus cable

Maximum recommended length of the ECL 485 bus is calculated like this:

Subtract "Total length of all input cables of all ECL controllers in the master - slave system" from 200 m.

Simple example for total length of all input cables, 3 x ECL:

1 x ECL	Outdoor temp. sensor:	15 m
3 x ECL	Flow temp. sensor:	18 m
3 x ECL	Return temp. sensor:	18 m
3 x ECL	Room temp. sensor:	30 m
Total:		81 m

Maximum recommended length of the ECL 485 bus:
200 - 81 m = 119 m

2.5.8 Electrical connections, communication

Electrical connections, Modbus

ECL Comfort 210: Non-galvanic isolated Modbus connections
ECL Comfort 296: Galvanic isolated Modbus connections
ECL Comfort 310: Galvanic isolated Modbus connections

2.5.9 Electrical connections, communication

Electrical connections, M-bus

ECL Comfort 210: Not implemented

ECL Comfort 296: On board, non-galvanic isolated. Max. cable length 50 m.

ECL Comfort 310: On board, non-galvanic isolated. Max. cable length 50 m.

Operating Guide ECL Comfort 310, application P330

2.6 Inserting the ECL Application Key

2.6.1 Inserting the ECL Application Key


The ECL Application Key contains

- the application and its subtypes,
- currently available languages,
- factory settings: e.g. schedules, desired temperatures, limitation values etc. It is always possible to recover the factory settings,
- memory for user settings: special user / system settings.


After having powered-up the controller, different situations might be existing:

1. The controller is new from the factory, the ECL Application Key is not inserted.
2. The controller already runs an application. The ECL Application Key is inserted, but the application needs to be changed.
3. A copy of the controllers settings is needed for configuring another controller.

ECL Comfort 210 / 310



ECL Comfort 210 / 310



User settings are, among others, desired room temperature, desired DHW temperature, schedules, heat curve, limitation values etc.

System settings are, among others, communication set-up, display brightness etc.




Automatic update of controller software (firmware):

The software of the controller is updated automatically when the key is inserted:

- ECL 210 / 310, as of controller version 1.11
- ECL 296, as of controller version 1.58

The following animation will be shown when the software is being updated:



Progress bar

During update:

- Do not remove the KEY
If the key is removed before the hour-glass is shown, you have to start afresh.
- Do not disconnect the power
If the power is interrupted when the hour-glass is shown, the controller will not work.
- Manual update of controller software (firmware):
See the section "Automatic / manual update of firmware"



The "Key overview" does not inform — through ECA 30 / 31 — about the subtypes of the application key.



Key inserted / not inserted, description:

ECL Comfort 210 / 310, controller versions lower than 1.36:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; for 20 minutes settings can be changed.

ECL Comfort 210 / 310, controller versions 1.36 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

ECL Comfort 296, controller versions 1.58 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

Operating Guide ECL Comfort 310, application P330

Application Key: Situation 1

The controller is new from the factory, the ECL Application Key is not inserted.

An animation for the ECL Application Key insertion is displayed. Insert the Application Key.

Application Key name and Version is indicated (example: A266 Ver. 1.03).

If the ECL Application Key is not suitable for the controller, a "cross" is displayed over the ECL Application Key-symbol.

Action:

- Select language
- Confirm
- Select application (subtype)
- Some keys have only one application.

Confirm with 'Yes'

Set 'Time & Date'
Turn and push the dial to select and change 'Hours', 'Minutes', 'Date', 'Month' and 'Year'.
Choose "Next"

Confirm with 'Yes'

Go to 'Aut. daylight'

Choose whether 'Aut. daylight' * should be active or not

Examples:

A266 Ver. 1.03

ECL Comfort 310
Ver. 9.02



◀

A266 Ver. 1.03

▶ English
Suomi
Dansk
Русский
Polski




ECL Comfort 310
Ver. 9.02




◀

A266 Ver. 1.03


▶ English
Suomi
Dan
▶ Yes
No
Русский
Polski



TYPE A266.1



TYPE A266.1



Next

Time & Date:

14:07

17.06.2010

Aut. daylight

YES

Application A266.1
installed

* 'Aut. daylight' is the automatic changeover between summer and winter time.

Depending on the contents of the ECL Application Key, procedure A or B is taking place:

A

The ECL Application key contains factory settings:

The controller reads / transfers data from the ECL Application Key to ECL controller.

The application is installed, and the controller resets and starts up.

B

The ECL Application key contains changed system settings:

Push the dial repeatedly.

'NO': Only factory settings from the ECL Application Key will be copied to the controller.

'YES*': Special system settings (differing from the factory settings) will be copied to the controller.

If the key contains user settings:

Push the dial repeatedly.

'NO': Only factory settings from the ECL Application Key will be copied to the controller.

'YES*': Special user settings (differing from the factory settings) will be copied to the controller.

* If 'YES' cannot be chosen, the ECL Application Key does not contain any special settings.

Choose 'Start copying' and confirm with 'Yes'!

Key functions

Copy:

To KEY
System settings NO
User settings NO
Start copying

Key functions

Copy:

To KEY
System settings YES
User settings NO
Start copying

Key functions


Copy:

To KEY
System settings YES
User settings NO
Start copying

Application A266.1
installed

(Example):

The "i" in the upper right corner indicates that - besides the factory settings - the subtype also contains special user / systems settings.




Application Key: Situation 2


The controller already runs an application. The ECL Application Key is inserted, but the application needs to be changed.

To change to another application on the ECL Application Key, the current application in the controller must be erased (deleted).

Be aware that the Application Key must be inserted.



Action:	Purpose:	Examples:
Ⓐ	Choose 'MENU' in any circuit	MENU
Ⓑ	Confirm	
Ⓐ	Choose the circuit selector at the top right corner in the display	
Ⓑ	Confirm	
Ⓐ	Choose 'Common controller settings'	□○
Ⓑ	Confirm	
Ⓐ	Choose 'Key functions'	
Ⓑ	Confirm	
Ⓐ	Choose 'Erase application'	
Ⓑ	Confirm with 'Yes'	



The controller resets and is ready to be configured.

Follow the procedure described in situation 1.

Operating Guide ECL Comfort 310, application P330

Application Key: Situation 3

A copy of the controllers settings is needed for configuring another controller.

This function is used

- for saving (backup) of special user and system settings
- when another ECL Comfort controller of the same type (210, 296, or 310) must be configured with the same application but user / system settings differ from the factory settings.

How to copy to another ECL Comfort controller:


Action:	Purpose:	Examples:
Ⓐ	Choose 'MENU'	MENU
Ⓑ	Confirm	
Ⓐ	Choose the circuit selector at the top right corner in the display	
Ⓑ	Confirm	
Ⓐ	Choose 'Common controller settings'	□○
Ⓑ	Confirm	
Ⓐ	Go to 'Key functions'	
Ⓑ	Confirm	
Ⓐ	Choose 'Copy'	
Ⓑ	Confirm	
Ⓐ	Choose 'To': 'ECL' or 'KEY' will be indicated. Choose 'ECL' or 'KEY'.	*
Ⓑ	Push the dial repeatedly to choose copy direction	
Ⓐ	Choose 'System settings' or 'User settings'	**
Ⓑ	Push the dial repeatedly to choose 'Yes' or 'No' in 'Copy'. Push to confirm.	
Ⓐ	Choose 'Start copying'	
Ⓑ	The Application Key or the controller is updated with special system or user settings.	

*

'ECL': Data will be copied from the Application Key to the ECL Controller.
'KEY': Data will be copied from the ECL Controller to the Application Key.

**

'NO': The settings from the ECL controller will not be copied to the Application Key or to the ECL Comfort controller. Special settings (differing from the factory settings) will be copied to the Application Key or to the ECL Comfort controller. If YES can not be chosen, there are no special settings to be copied.
'YES':



The figure consists of four vertically stacked screenshots of the ECL Comfort controller's menu system. Each screenshot shows a menu with a highlighted item. The menus are as follows:

- Home**: Shows a list of menu items: MENU, Log, Output override, Key functions (highlighted), and System.
- MENU**: Shows a list of menu items: Key functions (highlighted), New application, Application, Factory setting, Copy, and Key overview.
- Key functions**: Shows a list of menu items: Copy (highlighted), To, System settings, User settings, and Start copying.
- Copy**: Shows a sub-menu with options: To ECL, System settings YES, User settings NO, and Start copying.

Language

At application upload, a language must be selected.*
If another language than English is selected, the selected language **AND** English will be uploaded into the ECL controller.
This makes service easy for English speaking service people, just because the English language menus can be visible by changing the actual set language into English.
(Navigation: MENU > Common controller > System > Language)

If the uploaded language is not suitable, the application must be erased. User and System settings can be saved on the application key before erasing.
After new upload with preferred language, the existing User and System settings can be uploaded.

*)

(ECL Comfort 310, 24 Volt) If language cannot be selected, the power supply is not a.c. (alternating current).

2.6.2 ECL Application Key, copying data

General principles

When the controller is connected and operating, you can check and adjust all or some of the basic settings. The new settings can be stored on the Key.



Factory settings can always be restored.

How to update the ECL Application Key after settings have been changed?

All new settings can be stored on the ECL Application Key.



Make a note of new settings in the 'Settings overview' table.

How to store factory setting in the controller from the Application Key?

Please read the paragraph concerning Application Key, Situation 1: The controller is new from the factory, the ECL Application Key is not inserted.



Do not remove the ECL Application Key while copying. The data on the ECL Application Key can be damaged!

How to store personal settings from the controller to the Key?

Please read the paragraph concerning Application Key, Situation 3: A copy of the controllers settings is needed for configuring another controller

As a main rule, the ECL Application Key should always remain in the controller. If the Key is removed, it is not possible to change settings.



It is possible to copy settings from one ECL Comfort controller to another controller provided that the two controllers are from the same series (210 or 310).
Furthermore, when the ECL Comfort controller has been uploaded with an application key, minimum version 2.44, it is possible to upload personal settings from application keys, minimum version 2.14.



The "Key overview" does not inform — through ECA 30 / 31 — about the subtypes of the application key.



Key inserted / not inserted, description:

ECL Comfort 210 / 310, controller versions lower than 1.36:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; for 20 minutes settings can be changed.

ECL Comfort 210 / 310, controller versions 1.36 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

ECL Comfort 296, controller versions 1.58 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

2.7 Check list



Is the ECL Comfort controller ready for use?

- Make sure that the correct power supply is connected to terminals 9 and 10 (230 V or 24 V).
- Make sure the correct phase conditions are connected:
230 V: Live = terminal 9 and Neutral = terminal 10
24 V: SP = terminal 9 and SN = terminal 10
- Check that the required controlled components (actuator, pump etc.) are connected to the correct terminals.
- Check that all sensors / signals are connected to the correct terminals (see 'Electrical connections').
- Mount the controller and switch on the power.
- Is the ECL Application Key inserted (see 'Inserting the Application Key').
- Does the ECL Comfort controller contain an existing application (see 'Inserting the Application Key').
- Is the correct language chosen (see 'Language' in 'Common controller settings').
- Is the time & date set correctly (see 'Time & Date' in 'Common controller settings').
- Is the right application chosen (see 'Identifying the system type').
- Check that all settings in the controller (see 'Settings overview') are set or that the factory settings comply with your requirements.
- Choose manual operation (see 'Manual control'). Check that valves open and close, and that required controlled components (pump etc.) start and stop when operated manually.
- Check that the temperatures / signals shown in the display match the actual connected components.
- Having completed the manual operation check, choose controller mode (scheduled, comfort, saving or frost protection).

2.8 Navigation, ECL Application Key P330

Parameter list, application P330, Heating

Home MENU	Heating	P330 all applications (P330.1, P330.2, P330.3 etc.)															
		ID nos.	Function	.1	.2	.3	.4	.5	.6	.7	.8	.9	.10	.11	.12	.13	.14
Sche- dule		Schedule		●	●	●	●	●	●	●	●	●	●	●	●	●	●
Set- tings	Flow tempera- ture	1x178	Heat curve	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x179	Temp. max.	●	●	●	●	●	●	●	●	●	●	●	●	●	●
			Temp. min.	●	●	●	●	●	●	●	●	●	●	●	●	●	●
			Ext. desired T	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	Room limit	1x182	Infl. - max.	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x183	Infl. - min.	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x015	Adapt. time	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	Return limit	1x031	High T out X1	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x032	Low limit Y1	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x033	Low T out X2	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x034	High limit Y2	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x035	Infl. - max.	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x036	Infl. - min.	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x037	Adapt. time	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x085	Priority	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x029	DHW, ret. T limit	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	Flow/ power limit		Actual	●	●	●	●	●	●	●	●	●	●	●	●	●	●
			Actual limit	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x119	High T out X1	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x117	Low limit Y1	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x118	Low T out X2	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x116	High limit Y2	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x112	Adapt. time	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x113	Filter constant	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x109	Input type	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x115	Units	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	Optimi- zation	1x011	Auto saving	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x012	Boost	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x013	Ramp	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x014	Optimizer	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x026	Pre-stop	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x020	Based on	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x021	Total stop	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x179	Summer, cut-out	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	Control par.	1x174	Motor pr.	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x184	Xp	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x185	Tn	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x186	M run	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x187	Nz	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		1x189	Min. act. time	●	●	●	●	●	●	●	●	●	●	●	●	●	●

Parameter list, application P330, Heating, continued

Home		P330 all applications (P330.1, P330.2, P330.3 etc.)																
MENU	Heating	ID nos.	Function	.1	.2	.3	.4	.5	.6	.7	.8	.9	.10	.11	.12	.13	.14	.15
Settings	Application	1x010	ECA addr.	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x017	Demand offset	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x050	P demand	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x500	Send desired T	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x022	P exercise	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x023	M exercise	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x052	DHW priority	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x077	P frost T	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x078	P heat T	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x040	P post-run	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x093	Frost pr. T	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x141	Ext. input	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x142	Ext. mode	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Holiday		Holiday		●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Alarm	Temp. monitor.	1x147	Upper diff.	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x148	Lower diff.	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x149	Delay	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		1x150	Lowest temp.	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
		Alarm overview		●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Influence overview	Des. flow T	Influence source		●	●	●	●	●	●	●	●	●	●	●	●	●	●	

Operating Guide ECL Comfort 310, application P330

Parameter list, application P330, DHW

Home MENU	DHW	P330 all applications (P330.1, P330.2, P330.3 etc.)															
		ID nos.	Function	.1	.2	.3	.4	.5	.6	.7	.8	.9	.10	.11	.12	.13	.14
Sche- dule		Schedule					●	●				●	●	●	●	●	●
Sche- dule Circ. pu.		Schedule					●	●				●	●	●	●	●	●
Settings	Tank tem- perature	1x193	Charge difference				●	●				●	●	●	●	●	●
		1x195	Start difference				●	●				●	●	●	●	●	●
		1x194	Stop difference				●	●				●	●	●	●	●	●
		1x152	Max. charge T				●	●				●	●	●	●	●	●
		1x192	Tank start diff.									●	●	●	●	●	●
		1x196	Tank stop diff.									●	●	●	●	●	●
Return limit		1x030	Limit				●					●	●				
		1x035	Infl. - max.				●					●	●				
		1x036	Infl. - min.				●					●	●				
		1x037	Adapt. time				●					●	●				
Flow/ power limit			Actual				●					●	●				
		1x111	Limit				●					●	●				
		1x112	Adapt. time				●					●	●				
		1x113	Filter constant				●					●	●				
		1x109	Input type				●					●	●				
		1x115	Units				●					●	●				
Control par.		1x174	Motor pr.				●					●	●				
		1x184	Xp				●					●	●				
		1x185	Tn				●					●	●				
		1x186	M run				●					●	●				
		1x187	Nz				●					●	●				
		1x189	Min. act. time				●					●	●				
Application		1x055	Circ. P priority				●	●				●	●	●	●	●	●
		1x054	Cont. T control				●	●				●	●	●	●	●	●
		1x041	DHW P post-run				●	●				●	●	●	●	●	●
		1x042	Char. P post-run				●	●				●	●	●	●	●	●
		1x500	Send desired T				●	●				●	●	●	●	●	●
		1x076	Circ. P frost T				●	●				●	●	●	●	●	●
		1x093	Frost pr. T				●	●				●	●	●	●	●	●
		1x141	Ext. input				●	●				●	●	●	●	●	●
		1x142	Ext. mode				●	●				●	●	●	●	●	●
Anti- bacteria			Day, days				●	●				●	●	●	●	●	●
			Start time				●	●				●	●	●	●	●	●
			Duration				●	●				●	●	●	●	●	●
			Desired T				●	●				●	●	●	●	●	●
Holiday		Holiday					●	●				●	●	●	●	●	●
Alarm	Temp. monitor.	1x147	Upper diff.				●					●	●				
		1x148	Lower diff.				●					●	●				
		1x149	Delay				●					●	●				
		1x150	Lowest temp.				●					●	●				
In- fluence over- view	Des. DHW T		Influence source				●	●				●	●	●	●	●	●

Parameter list, application P330, Common controller

Home MENU	Com- mon control- ler	P330 all applications (P330.1, P330.2, P330.3 etc.)															
		ID nos.	Function	.1	.2	.3	.4	.5	.6	.7	.8	.9	.10	.11	.12	.13	.14
Set- tings			Time & date	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Set- tings (M)	Flow tempe- rature	1x193 1x194 1x195 1x178 1x179	Charge difference Stop difference Start difference Temp. max. Temp. min. Ext. desired T					●	●	●	●	●	●	●	●	●	●
	Return limit		See settings for Heating					●	●	●	●	●	●	●	●	●	●
		1x029	DHW, ret. T limit					●	●	●	●	●	●	●	●	●	●
	Flow/ power limit		See settings for Heating					●	●	●	●	●	●	●	●	●	●
	Control par.		See settings for Heating					●	●	●	●	●	●	●	●	●	●
	Application	1x017 1x022 1x023 1x052 1x077 1x078 1x040 1x141	Demand offset P exercise M exercise DHW priority P frost T P heat T P post-run Ext. input					●	●	●	●	●	●	●	●	●	●
Alarm (M)			See settings for Heating					●	●	●	●	●	●	●	●	●	●
Holiday			Holiday	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Input over- view				●	●	●	●	●	●	●	●	●	●	●	●	●	●
Input over- view (M)								●	●	●	●	●	●	●	●	●	●
Log				●	●	●	●	●	●	●	●	●	●	●	●	●	●
Log (M)								●	●	●	●	●	●	●	●	●	●
Output over- ride				●	●	●	●	●	●	●	●	●	●	●	●	●	●
Key func- tions				●	●	●	●	●	●	●	●	●	●	●	●	●	●
System				●	●	●	●	●	●	●	●	●	●	●	●	●	●

Parameter list, application P330, Common controller

Home MENU	Com- mon control- ler	P330 all applications (P330.1, P330.2, P330.3 etc.)															
		ID nos.	Function	.1	.2	.3	.4	.5	.6	.7	.8	.9	.10	.11	.12	.13	.14
Key func- tions		New application	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Application	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Factory setting	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Copy	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Key overview	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
System		ECL version	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Extension	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Ethernet	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Portal config.	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		M-bus config.	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Energy meters	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Raw input overview	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Alarm	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Display	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Communication	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
		Language	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

3.0 Daily use

3.1 How to navigate



You navigate in the controller by turning the dial left or right to the desired position (○).

The dial has a built-in accelerator. The faster you turn the dial, the faster it reaches the limits of any wide setting range.

The position indicator in the display (►) will always show you where you are.

Push the dial to confirm your choices (◎).

The display examples are from a two-circuit application: One heating circuit (H) and one domestic hot-water (DHW) circuit (W). The examples might differ from your application.



Some general settings which apply to the entire controller are located in a specific part of the controller.

To enter 'Common controller settings':

Action:	Purpose:	Examples:
○	Choose 'MENU' in any circuit	MENU
◎	Confirm	
○	Choose the circuit selector at the top right corner in the display	
◎	Confirm	
○	Choose 'Common controller settings'	□○
◎	Confirm	

Circuit selector



3.2 Understanding the controller display

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

Choosing a favorite display

Your favorite display is the display you have chosen as the default display. The favorite display will give you a quick overview of the temperatures or units that you want to monitor in general.

If the dial has not been activated for 20 min., the controller will revert to the overview display you have chosen as favorite.



To shift between displays: Turn the dial until you reach the display selector (---) at the bottom right side of the display. Push the dial and turn to choose your favorite overview display. Push the dial again.

Heating circuit III

Overview display 1 informs about:
actual outdoor temperature, controller mode,
actual room temperature, desired room temperature.

Overview display 2 informs about:
actual outdoor temperature, trend in outdoor temperature,
controller mode, max. and min. outdoor temperatures since
midnight as well as desired room temperature.

Overview display 3 informs about:
date, actual outdoor temperature, controller mode, time, desired
room temperature as well as shows the comfort schedule of the
current day.

Overview display 4 informs about:
state of the controlled components, actual flow temperature,
(desired flow temperature), controller mode, return temperature
(limitation value), influence on desired flow temperature.

The value above the V2 symbol indicates 0–100% of the analogue
signal (0–10 V).


Note:

An actual flow temperature value must be present, otherwise the
circuit's control valve will close.


Dependent on the chosen display, the overview displays for the
heating circuit inform you about:

- actual outdoor temperature (-0.5)
- controller mode (※)
- actual room temperature (24.5)
- desired room temperature (20.7 °C)
- trend in outdoor temperature (↗ → ↘)
- min. and max. outdoor temperatures since midnight (◊)
- date (23.02.2010)
- time (7:43)
- comfort schedule of the current day (0 - 12 - 24)
- state of the controlled components (M2, P2)
- actual flow temperature (49 °C), (desired flow temperature (31))
- return temperature (24 °C) (limitation temperature (50))


Overview display 1:




Overview display 2:




Overview display 3:




Overview display 4:




Example of overview display with
Influence indication:



Example, favorite display 1 in
A230.3, where min. desired room
temperature is indicated (22.7):



Example of overview display with
state of controlled components,
actual state of diverting valve
X3 on master circuit, limitations,
input request, tank temperature.
The value above the V2 symbol
indicates 0–100% of the analogue
signal (0–10 V).



The setting of the desired room temperature is important even if a
room temperature sensor / Remote Control Unit is not connected.



If the temperature value is displayed as

"- -" the sensor in question is not connected.

"- - -" the sensor connection is short-circuited.

DHW circuit


Overview display 1 informs about:
actual DHW temperature, controller mode, desired DHW temperature as well as the comfort schedule of the current day.

Overview display 2 informs about:
state of the controlled components, actual DHW temperature, (desired DHW temperature), controller mode, return temperature (limitation value), influence on desired DHW temperature.


Dependent on chosen display, the overview displays for the DHW circuit inform you about:

- actual DHW temperature (50.3)
- controller mode (※)
- desired DHW temperature (50 °C)
- comfort schedule of the current day(0 - 12 - 24)
- state of the controlled components (M1, P1)
- actual DHW temperature (50 °C), (desired DHW temperature (50))
- return temperature (- - °C) (limitation temperature (30))


Overview display 1:



Overview display 2:



Example of overview display with
Influence indication:




Setting the desired temperature

Depending on the chosen circuit and mode, it is possible to enter all daily settings directly from the overview displays (see also the next page concerning symbols).

Setting the desired room temperature

The desired room temperature can easily be adjusted in the overview displays for the heating circuit.

Action:	Purpose:	Examples:
	Desired room temperature	20.5
	Confirm	
	Adjust the desired room temperature	21.0
	Confirm	



This overview display informs about outdoor temperature, actual room temperature as well as desired room temperature.

The display example is for comfort mode. If you want to change the desired room temperature for saving mode, choose the mode selector and select saving.




The setting of the desired room temperature is important even if a room temperature sensor / Remote Control Unit is not connected.

Setting the desired DHW temperature

The desired DHW temperature can easily be adjusted in the overview displays for the DHW circuit.

Action:	Purpose:	Examples:
 	Desired DHW temperature	50
	Confirm	
 	Adjust the desired DHW temperature	55
	Confirm	



In addition to the information about desired and actual DHW temperature, the today's schedule is visible.

The display example indicates that the controller is in scheduled operation and in comfort mode.

Setting the desired room temperature, ECA 30 / ECA 31

The desired room temperature can be set exactly as in the controller. However, other symbols can be present in the display (please see 'What do the symbols mean?').



With the ECA 30 / ECA 31 you can override the desired room temperature set in the controller temporarily by means of the override functions: 

3.3 A general overview: What do the symbols mean?

Symbol	Description	
	Outdoor temp.	
	Relative humidity indoor	Temperature
	Room temp.	
	DHW temp.	
	Position indicator	
	Scheduled mode	
	Comfort mode	
	Saving mode	
	Frost protection mode	
	Manual mode	Mode
	Standby	
	Cooling mode	
	Active output override	
	Optimized start or stop time	
	Heating	
	Cooling	
	DHW	Circuit
	Common controller settings	
	Pump ON	
	Pump OFF	
	Fan ON	
	Fan OFF	
	Actuator opens	Controlled component
	Actuator closes	
	Actuator, analogue control signal	
	Pump / fan speed	
	Damper ON	
	Damper OFF	

Symbol	Description
	Alarm
	Letter
!	Event
	Monitoring temperature sensor connection
----	Display selector
△	Max. and min. value
↗ ↘	Trend in outdoor temperature
	Wind speed sensor
--	Sensor not connected or not used
---	Sensor connection short-circuited
 7-23	Fixed comfort day (holiday)
↑ ↓	Active influence
	Heating active (+) Cooling active (-)
	Number of heat exchangers

Additional symbols, ECA 30 / 31:

Symbol	Description
	ECA Remote Control Unit
 15	Connection address (master: 15, slaves: 1 - 9)
	Day off
	Holiday
	Relaxing (extended comfort period)
	Going out (extended saving period)



In ECA 30 / 31 only the symbols that are relevant to the application in the controller are displayed.

3.4 Monitoring temperatures and system components


This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

Heating circuit

The overview display in the heating circuit ensures a quick overview of the actual and (desired) temperatures as well as the actual state of the system components.

Display example:

49 °C	Flow temperature
(31)	Desired flow temperature
24 °C	Return temperature
(50)	Return temperature limitation




DHW circuit

The overview display in the DHW circuit ensures a quick overview of the actual and (desired) temperatures as well as the actual state of the system components.

Display example (heat exchanger):

50 °C	Flow temperature
(50)	Desired flow temperature
--	Return temperature: sensor not connected
(30)	Return temperature limitation


Display example with heat exchanger:



Input overview

Another option to get a quick overview of measured temperatures is the 'Input overview' which is visible in the common controller settings (how to enter the common controller settings, see 'Introduction to common controller settings').

As this overview (see display example) only states the measured actual temperatures, it is read-only.



3.5 Influence overview

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The menu gives an overview of the influences on the desired flow temperature. It differs from application to application which parameters are listed. It can be helpful in a service situation to explain unexpected conditions or temperatures among others.

If the desired flow temperature is influenced (corrected) by one or more parameters, it is indicated by a small line with arrow-down, arrow-up or double-arrow:

Arrow-down:

The parameter in question reduces the desired flow temperature.

Arrow-up:

The parameter in question increases the desired flow temperature.

Double-arrow:




The parameter in question creates an override (e.g. Holiday).

Straight line:

No active influence.

In the example, the arrow in the symbol points downwards for 'Room lim.'. This means that the actual room temperature is higher than the desired room temperature which again results in a decrease of the desired flow temperature.

Example of overview display with Influence indication:






3.6 Manual control

It is possible to manually control the installed components.

Manual control can only be selected in favorite displays in which the symbols for the controlled components (valve, pump etc.) are visible.

Action:	Purpose:	Examples:
↻	Choose mode selector	Ⓐ
钥匙	Confirm	
↻	Choose manual mode	Ⓑ
钥匙	Confirm	
↻	Choose pump	Ⓐ
钥匙	Confirm	
↻	Switch ON the pump	Ⓑ
↻	Switch OFF the pump.	Ⓐ
钥匙	Confirm pump mode	
↻	Choose motorized control valve	Ⓑ
钥匙	Confirm	
↻	Open the valve	Ⓑ
↻	Stop opening the valve	Ⓑ
↻	Close the valve	Ⓑ
↻	Stop closing the valve	Ⓑ
钥匙	Confirm valve mode	



To leave manual control, use the mode selector to select the desired mode. Push the dial.

Manual control is typically used when commissioning the installation. The controlled components, valve, pump etc., can be controlled for correct function.


3.7 Schedule

3.7.1 Set your schedule

This section describes the schedule in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application. In some applications, however, there might be more than one schedule. Additional schedules can be found in 'Common controller settings'.

The schedule consists of a 7-day week:

M = Monday
 T = Tuesday
 W = Wednesday
 T = Thursday
 F = Friday
 S = Saturday
 S = Sunday



The schedule will day-by-day show you the start and stop times of your comfort periods (heating / DHW circuits).



Changing your schedule:

Action:	Purpose:	Examples:
Ⓐ	Choose 'MENU' in any of the overview displays	MENU
Ⓑ	Confirm	
Ⓒ	Confirm the choice 'Schedule'	
Ⓓ	Choose the day to change	▶
Ⓔ	Confirm*	T
Ⓕ	Go to Start1	
Ⓖ	Confirm	
Ⓗ	Adjust the time	
Ⓘ	Confirm	
Ⓛ	Go to Stop1, Start2 etc. etc.	
Ⓜ	Return to 'MENU'	MENU
Ⓝ	Confirm	
Ⓞ	Choose 'Yes' or 'No' in 'Save'	
Ⓟ	Confirm	

* Several days can be marked

The chosen start and stop times will be valid for all the chosen days (in this example Thursday and Saturday).

You can set max. 3 comfort periods a day. You can delete a comfort period by setting start and stop times to the same value.



⚠
 Each circuit has its own schedule. To change to another circuit, go to 'Home', turn the dial and choose the desired circuit.

⚠
 The start and stop times can be set in half-hourly (30 min.) intervals.

4.0 Settings overview

All parameters related to heating and DHW are listed as circuit 1.
It is recommendable to make a note of any changed settings in the empty columns.

Setting	ID	Page	Factory settings in circuit(s)	
			1	2
Heat curve		73		
Ext. desired T		74		
Day		106		
Start time		106		
Duration		107		
Desired T		107		
ECA addr. (choice of Remote Control Unit)	1x010	93		
Auto saving (saving temp. dependent on outdoor temp.)	1x011	85		
Boost	1x012	85		
Ramp (reference ramping)	1x013	86		
Optimizer (optimizing time constant)	1x014	86		
Adapt. time (adaption time)	1x015	76		
Demand offset	1x017	93		
Based on (optimization based on room / outdoor temp.)	1x020	87		
Total stop	1x021	87		
P exercise (pump exercise)	1x022	93		
M exercise (valve exercise)	1x023	93		
Pre-stop (optimized stop time)	1x026	88		
DHW, ret. T limit	1x029	78		
High T out X1 (return temp. limitation, high limit, X-axis)	1x031	78		
Low limit Y1 (return temp. limitation, low limit, Y-axis)	1x032	78		
Low T out X2 (return temp. limitation, low limit, X-axis)	1x033	79		
High limit Y2 (return temp. limitation, high limit, Y-axis)	1x034	79		
Infl. - max. (return temp. limitation - max. influence)	1x035	79		
Infl. - min. (return temp. limitation - min. influence)	1x036	80		
Adapt. time (adaptation time)	1x037	80		
P post-run	1x040	94		
DHW P post-run	1x041	100		
Char. P post-run	1x042	100		
P demand (P330.1 - P330.5)	1x050	94		
DHW priority (closed valve / normal operation)	1x052	94		
Cont. T control	1x054	100		
Circ. P priority	1x055	100		
Circ. P frost T	1x076	100		
P frost T	1x077	95		
P heat T (heat demand)	1x078	95		
Priority (priority for return temp. limitation)	1x085	81		
Frost pr. T (frost protection temperature)	1x093	95		
Frost pr. T (frost protection temperature)	1x093	101		

Setting	ID	Page	Factory settings in circuit(s)	
			1	2
Input type	1x109	82		
Actual (actual flow or power)	1x110	82		
Actual limit (limitation value)	1x111	82		
Adapt. time (adaptation time)	1x112	83		
Filter constant	1x113	83		
Units	1x115	83		
High limit Y2 (flow / power limitation, high limit, Y-axis)	1x116	83		
Low limit Y1 (flow / power limitation, low limit, Y-axis)	1x117	83		
Low T out X2 (flow / power limitation, low limit, X-axis)	1x118	84		
High T out X1 (flow / power limitation, high limit, X-axis)	1x119	84		
Ext. input (external override)	1x141	95		
Ext. mode (external override mode)	1x142	96		
Upper difference	1x147	108		
Lower difference	1x148	108		
Delay	1x149	108		
Lowest temp.	1x150	108		
Max. charge T	1x152	101		
Motor pr. (motor protection)	1x174	90		
Temp. min. (flow temp. limit, min.)	1x177	74		
Temp. max. (flow temp. limit, max.)	1x178	74		
Summer, cut-out (limit for heating cut-out)	1x179	88		
Infl. - max. (room temp. limitation, max.)	1x182	76		
Infl. - min. (room temp. limitation, min.)	1x183	77		
Xp (proportional band)	1x184	90		
Tn (integration time constant)	1x185	90		
M run (running time of the motorized control valve)	1x186	90		
Nz (neutral zone)	1x187	91		
Min. act. time (min. activation time gear motor)	1x189	91		
Tank start diff. (P330.14)	1x192	101		
Charge difference	1x193	102		
Stop difference	1x194	102		
Start difference	1x195	103		
Tank stop diff. (P330.14)	1x196	104		
Send desired T	1x500	98		
Send desired T	1x500	104		

5.0 Settings

5.1 Introduction to Settings

Descriptions of settings (parameter's functions) are divided into groups as used in the ECL Comfort 210 / 296 / 310 controller's menu structure. Examples: "Flow temperature", "Room limit" and so on. Each group starts with a general explanation.

The descriptions of each parameter are in numeric order, related to the parameter's ID numbers. You might come across differences between the order in this Operating Guide and the ECL Comfort 210 / 296 / 310 controllers.

Some parameter descriptions are related to specific application subtypes. This means that you might not see the related parameter in the actual subtype in the ECL controller.

The note "See Appendix ..." refers to the Appendix at the end of this Operating Guide, where parameter's setting ranges and factory settings are listed.

The navigation hints (for example MENU > Settings > Return limit ...) cover multiple subtypes.

5.2 Flow temperature

The ECL Comfort controller determines and controls the flow temperature related to the outdoor temperature. This relationship is called the heat curve.

The heat curve is set by means of 6 coordinate points. The desired flow temperature is set at 6 pre-defined outdoor temperature values.

The shown value for the heat curve is an average value (slope), based on the actual settings.


Outdoor temp.	Desired flow temp.			Your settings
	A	B	C	
-30 °C	45 °C	75 °C	95 °C	
-15 °C	40 °C	60 °C	90 °C	
-5 °C	35 °C	50 °C	80 °C	
0 °C	32 °C	45 °C	70 °C	
5 °C	30 °C	40 °C	60 °C	
15 °C	25 °C	28 °C	35 °C	

A: Example for floor heating

B: Factory settings

C: Example for radiator heating (high demand)

Desired flow temperature



Settings III1
Flow temperature:
 ▶ Heat curve 1.0
 Temp. max. 90 °C
 Temp. min. 10 °C
 Desired T 50 °C

MENU > Settings > Flow temperature

Heat curve		
1	0.1 ... 4.0	1.0

The heat curve can be changed in two ways:

1. The value of the slope is changed (see heat curve examples on next page)
2. The coordinates of the heat curve are changed

Change the value of the slope:

Push the dial to enter / change the slope value of the heat curve (example: 1.0).

When the slope of the heat curve is changed by means of the slope value, the common point for all heat curves will be a desired flow temperature = 24.6 °C at an outdoor temperature = 20 °C and a desired room temperature = 20.0 °C.

Change the coordinates:

Push the dial to enter / change the coordinates of the heat curve (example: -30,75).


The heat curve represents the desired flow temperatures at different outdoor temperatures and at a desired room temperature of 20 °C.

If the desired room temperature is changed, the desired flow temperature also changes:


(Desired room T - 20) × HC × 2.5

where "HC" is the Heat Curve slope and "2.5" is a constant.

Slope changes



Coordinate changes



The calculated flow temperature can be influenced by the 'Boost' and 'Ramp' functions etc.

Example:


Heat curve: 1.0
 Desired flow temp.: 50 °C
 Desired room temp.: 22 °C
 Calculation (22-20) × 1.0 × 2.5 = 5

Result:

The desired flow temperature will be corrected from 50 °C to 55 °C.

Choosing a heat curve slope

The heat curves represent the desired flow temperature at different outdoor temperatures and at a desired room temperature of 20 °C.



The small arrows (▲) indicate 6 different outdoor temperature values at which you can change the heat curve.

MENU > Settings > Flow temperature

Temp. min. (flow temp. limit, min.)

1x177

See Appendix "Parameter ID overview"

Set the min. flow temperature for the system. The desired flow temperature will not be lower than this setting. Adjust the factory setting, if required.



'Temp. min.' is overruled if 'Total stop' is active in Saving mode or 'Cut-out' is active.
'Temp. min.' can be overruled by the influence from the return temperature limitation (see 'Priority').



The setting for 'Temp. max.' has higher priority than 'Temp. min.'

MENU > Settings > Flow temperature

Temp. max. (flow temp. limit, max.)

1x178

See Appendix "Parameter ID overview"

Set the max. flow temperature for the system. The desired flow temperature will not be higher than this setting. Adjust the factory setting, if required.



The setting of 'heat curve' is possible for heating circuits only.



The setting for 'Temp. max.' has higher priority than 'Temp. min.'

Operating Guide ECL Comfort 310, application P330

External signal for desired flow temperature

The circuit 1 in the applications P330.1 - P330.5 and the Master Circuit in the applications P330.6 - P330.14 can be controlled by an external signal for desired flow temperature.

A voltage (0 - 10 V) can be applied to the input terminal S8 in order to determine the desired flow temperature.

The measured voltage on input S8 must be converted to a temperature value by the controller. When the voltage gets higher, the desired flow temperature increases.

The following settings set up the scaling.

MENU > Settings > Flow temperature

Ext. desired T		
Circuit	Setting range	Factory setting
	Read-out only	None
The actual desired flow temperature is indicated by the unit °C.		

Read-out:

- : External voltage signal is not connected.
- °C: External voltage signal converted to desired flow temperature.

Push the dial to see the graph and enter the value sets for the input voltage (1 and 10 volt) and displayed desired flow temperature.

Desired flow temperature: 10 ... 120 °C

Fixed voltage settings: 1 V and 10 V


Factory settings: (1,10) and (10,100)

This means that the 'Desired flow temperature' is 10 °C at 1.0 V and 100 °C at 10 V.



Typically, the higher the voltage, the higher the displayed desired flow temperature.

Example: Relationship between input voltage and displayed desired flow temperature

Desired flow temp. (°C)



This example shows that 1 volt corresponds to 10.0 °C and 10 volt correspond to 100 °C.



5.3 Room limit

This section is only relevant if you have installed a duct / room temperature sensor or a Remote Control Unit.

The controller adjusts the desired flow temperature to compensate for the difference between the desired and the actual duct / room temperature.

If the duct / room temperature is higher than the desired value, the desired flow temperature can be reduced.

The 'Infl. -max' (Influence, max. duct / room temp.) determines how much the desired flow temperature should be reduced.

Use this influence type to avoid a too high duct / room temperature. The controller will allow for free heat gains, i.e. solar radiation or heat from a fire place etc.

If the duct / room temperature is lower than the desired value, the desired flow temperature can be increased.

The 'Infl. -min' (Influence, min. duct / room temperature) determines how much the desired flow temperature should be increased.

Use this influence type to avoid a too low duct / room temperature. This could e.g. be caused by windy surroundings.

A typical setting will be -4.0 for 'Infl. -max' and 4.0 for 'Infl. -min'.



Parameters indicated with an ID no. like "1x607" mean a universal parameter.
x stands for circuit / parameter group.

MENU > Settings > Room limit

Adapt. time (adaption time)	1x015
<i>Controls how fast the actual room temperature adapts to the desired room temperature (I control).</i>	



The adaptation function can correct the desired flow temperature with max. 8 K x heat curve value.

See Appendix "Parameter ID overview"

OFF: The control function is not influenced by the 'Adapt. time'.

1: The desired room temperature is adapted quickly.

50: The desired room temperature is adapted slowly.


Operating Guide ECL Comfort 310, application P330

MENU > Settings > Room limit

Infl. - max. (room temp. limitation, max.)	1x182
<p>Determines how much the desired flow temperature will be influenced (decreased) if the actual room temperature is higher than the desired room temperature (P control).</p>	

See Appendix "Parameter ID overview"

- 9.9: The room temperature has a big influence.
- 0.0: The room temperature has no influence.



The 'Infl. - max.' and 'Infl. - min.' determine how much the room temperature should influence the desired flow temperature.



If the 'Infl.' factor is too high and / or the 'Adapt. time' too low, there is a risk of unstable control.

Example 1:

The actual room temperature is 2 degrees too high.
 The 'Infl. - max.' is set to -4.0.
 The 'Infl. - min.' is set to 0.0.
 The slope is 1.8 (see 'Heat curve' in 'Flow temperature').
 Result:
 The desired flow temperature is changed by $(2 \times -4.0 \times 1.8) -14.4$ degrees.

Example 2:

The actual room temperature is 3 degrees too low.
 The 'Infl. - max.' is set to 4.0.
 The 'Infl. - min.' is set to 2.0.
 The slope is 1.8 (see 'Heat curve' in 'Flow temperature').
 Result:
 The desired flow temperature is changed by $(3 \times 2.0 \times 1.8) 10.8$ degrees.

MENU > Settings > Room limit

Infl. - min. (room temp. limitation, min.)	1x183	
	0.0 9.9	0.0
<p>Determines how much the desired flow temperature will be influenced (increased) if the actual room temperature is lower than the desired room temperature (P control).</p>		

See Appendix "Parameter ID overview"

- 0.0: The room temperature has no influence.
- 9.9: The room temperature has a big influence.


5.4 Return limit

The return temperature limitation is based on the outdoor temperature. Typically in district heating systems a higher return temperature is accepted at a decrease in outdoor temperature. The relationship between the return temperature limits and outdoor temperature is set in two coordinates.

The outdoor temperature coordinates are set in 'High T out X1' and 'Low T out X2'. The return temperature coordinates are set in 'High limit Y2' and 'Low limit Y1'.

The controller automatically changes the desired flow temperature to obtain an acceptable return temperature when the return temperature falls below or gets higher than the calculated limit.

This limitation is based on a PI regulation where P ('Infl' factor) responds quickly to deviations and I ('Adapt. time') responds slower and over time removes the small offsets between the desired and actual values. This is done by changing the desired flow temperature.




The calculated limit is shown in brackets () in the monitoring display. See the section "Monitoring temperatures and system components".

MENU > Settings > Return limit


DHW, ret. T limit	1x029
When an addressed slave is active in DHW-tank heating / charging, the return temperature limitation in the master can be set.	
Notes:	
<ul style="list-style-type: none"> The master circuit must be set to react on the desired flow temperature in the slave(s). See "Demand offset" (ID 11017). The slave(s) must be set to send its / their desired flow temperature to the master. See "Send desired T" (ID 1x500). 	

See Appendix "Parameter ID overview"



Some examples of applications with DHW-tank heating / charging are:

- A217, A237, A247, A367, A377



Sub-circuits are considered as slaves too.
P330.1 . . . P330.5: Parameter 1x029 is present in circuit 1.
P330.6 . . . P330.15: Parameter 1x029 is present in Master circuit (M).

MENU > Settings > Return limit

High T out X1 (return temp. limitation, high limit, X-axis)	1x031
Set the outdoor temperature for the low return temperature limitation.	

See Appendix "Parameter ID overview"

The corresponding Y coordinate is set in 'Low limit Y1'.

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Return limit

Low limit Y1 (return temp. limitation, low limit, Y-axis)	1x032
<i>Set the return temperature limitation referring to the outdoor temperature set in 'High T out X1'.</i>	

See Appendix "Parameter ID overview"

The corresponding X coordinate is set in 'High T out X1'.

MENU > Settings > Return limit

Low T out X2 (return temp. limitation, low limit, X-axis)	1x033
<i>Set the outdoor temperature for the high return temperature limitation.</i>	

See Appendix "Parameter ID overview"

The corresponding Y coordinate is set in 'High limit Y2'.

MENU > Settings > Return limit

High limit Y2 (return temp. limitation, high limit, Y-axis)	1x034
<i>Set the return temperature limitation referring to the outdoor temperature set in 'Low T out X2'.</i>	

See Appendix "Parameter ID overview"

The corresponding X coordinate is set in 'Low T out X2'.

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Return limit

Infl. - max. (return temp. limitation - max. influence) 1x035

Determines how much the desired flow temperature will be influenced if the return temperature is higher than the calculated limit.


See Appendix "Parameter ID overview"

Influence higher than 0:

The desired flow temperature is increased, when the return temperature gets higher than the calculated limit.

Influence lower than 0:

The desired flow temperature is decreased, when the return temperature gets higher than the calculated limit.



If the 'Infl.' factor is too high and / or the 'Adapt. time' too low, there is a risk of unstable control.

Example

The return limit is active above 50 °C.

The influence is set to -2.0.

The actual return temperature is 2 degrees too high.

Result:

The desired flow temperature is changed by $-2.0 \times 2 = -4.0$ degrees.



Normally, this setting is lower than 0 in district heating systems to avoid a too high return temperature.

Typically, this setting is 0 in boiler systems because a higher return temperature is acceptable (see also 'Infl. - min.').

MENU > Settings > Return limit

Infl. - min. (return temp. limitation - min. influence) 1x036

Determines how much the desired flow temperature will be influenced if the return temperature is lower than the calculated limit.

See Appendix "Parameter ID overview"

Influence higher than 0:

The desired flow temperature is increased, when the return temperature gets below the calculated limit.

Influence lower than 0:

The desired flow temperature is decreased, when the return temperature gets below the calculated limit.

Example

The return limit is active below 50 °C.

The influence is set to -3.0.

The actual return temperature is 2 degrees too low.

Result:

The desired flow temperature is changed by $-3.0 \times 2 = -6.0$ degrees.



Normally, this setting is 0 in district heating systems because a lower return temperature is acceptable.

Typically, this setting is higher than 0 in boiler systems to avoid a too low return temperature (see also 'Infl. - max.').

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Return limit

Adapt. time (adaptation time)	1x037
<i>Controls how fast the return temperature adapts to the desired return temperature limit (I control).</i>	



The adaptation function can correct the desired flow temperature with max. 8 K.

See Appendix "Parameter ID overview"

OFF: The control function is not influenced by the 'Adapt. time'.

1: The desired temperature is adapted quickly.

50: The desired temperature is adapted slowly.

MENU > Settings > Return limit

Priority (priority for return temp. limitation)	1x085
<i>Choose whether the return temperature limitation should overrule the set min. flow temperature 'Temp. min.'</i>	

See Appendix "Parameter ID overview"

OFF: The min. flow temperature limit is not overruled.

ON: The min. flow temperature limit is overruled.

5.5 Flow / power limit

A flow or energy meter can be connected (M-bus signal) to the ECL controller in order to limit the flow or consumed power.



The flow / power limitation can be based on the outdoor temperature. Typically, in district heating systems a higher flow or power is accepted at lower outdoor temperatures.

The relationship between the flow or power limits and the outdoor temperature is set in two coordinates.

The outdoor temperature coordinates are set in 'High T out X1' and 'Low T out X2'.

The flow or power coordinates are set in 'Low limit Y1' and 'High limit Y2'. Based on these settings, the controller calculates the limitation value.

When the flow / power gets higher than the calculated limit, the controller gradually reduces the desired flow temperature to obtain an acceptable max. flow or power consumption.



If the 'Adapt. time' is too high, there is a risk of unstable control.

MENU > Settings > Flow / power limit

Input type	1x109
Choice of M-bus signal from energy meter number 1 ... 5. Only possible in ECL Comfort 310.	

Flow or power limitation is based on M-bus signal (ECL Comfort 310 controllers only).

See Appendix "Parameter ID overview"

OFF: No M-bus signal acquired.

EM1 ... EM5: Energy meter number.

MENU > Settings > Flow / power limit

Actual (actual flow or power)	1x110
The value is the actual flow or power based on the signal from flow / energy meter.	

See Appendix "Parameter ID overview"

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Flow / power limit

Actual limit (limitation value)	1x111
<i>The value is the calculated limitation value.</i>	

See Appendix "Parameter ID overview"

MENU > Settings > Flow / power limit

Adapt. time (adaptation time)	1x112
<i>Controls how fast the flow / power limitation adapts to the desired limitation.</i>	



If the 'Adapt. time' is too low, there is a risk of unstable control.

See Appendix "Parameter ID overview"

OFF: The control function is not influenced by the 'Adapt. time'.

1: The desired temperature is adapted quickly.

50: The desired temperature is adapted slowly.

MENU > Settings > Flow / power limit

Filter constant	1x113
<i>The actual filter dampens the flow / power input data by the set factor.</i>	

See Appendix "Parameter ID overview"

1: Minor dampening (low filter constant)

50: Major dampening (high filter constant)

MENU > Settings > Flow / power limit

Units	1x115
<i>Choice of units for measured values.</i>	



List for setting range of 'Units':

l/h

m³/h

kW

MW

GW

See Appendix "Parameter ID overview"

Flow values are expressed as l/h or m³/h

Power values are expressed as kW, MW or GW.

MENU > Settings > Flow / power limit

High limit Y2 (flow / power limitation, high limit, Y-axis)	1x116
<i>Set the flow / power limitation referring to the outdoor temperature set in 'Low T out X2'.</i>	

See Appendix "Parameter ID overview"

The corresponding X coordinate is set in 'Low T out X2'.

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Flow / power limit

Low limit Y1 (flow / power limitation, low limit, Y-axis)	1x117
<i>Set the flow / power limitation referring to the outdoor temperature set in 'High T out X1'.</i>	



The limitation function can overrule the set 'Temp. min' of the desired flow temperature.

See Appendix "Parameter ID overview"

The corresponding X coordinate is set in 'High T out X1'.

MENU > Settings > Flow / power limit

Low T out X2 (flow / power limitation, low limit, X-axis)	1x118
<i>Set the outdoor temperature value for the high flow / power limitation.</i>	

See Appendix "Parameter ID overview"

The corresponding Y coordinate is set in 'High limit Y2'.

MENU > Settings > Flow / power limit

High T out X1 (flow / power limitation, high limit, X-axis)	1x119
<i>Set the outdoor temperature value for the low flow / power limitation.</i>	

See Appendix "Parameter ID overview"

The corresponding Y coordinate is set in 'Low limit Y1'.

5.6 Optimization

MENU > Settings > Optimization

Auto saving (saving temp. dependent on outdoor temp.) 1x011

Below the set value for the outdoor temperature, the saving temperature setting has no influence. Above the set value for the outdoor temperature, the saving temperature relates to the actual outdoor temperature. The function is relevant in district heating installations in order to avoid a big change in the desired flow temperature after a saving period.

See Appendix "Parameter ID overview"


OFF: The saving temperature does not depend on the outdoor temperature; the reduction is 100%.

-29 ... 10: The saving temperature depends on the outdoor temperature. When the outdoor temperature is above 10 °C, the reduction is 100%. The lower the outdoor temperature, the less the temperature reduction. Below the set value, the saving temperature setting has no influence.

Comfort temperature: The desired room temperature in Comfort mode

Saving temperature: The desired room temperature in Saving mode

The desired room temperatures for Comfort and Saving modes are set in the display overviews.



X = Outdoor temperature (°C)
 Y = Desired room temperature (°C)
 $\#1\#$ = Desired room temperature (°C), Comfort mode
 $\#2\#$ = Desired room temperature (°C), Saving mode
 $\#3\#$ = Auto saving temperature (°C), ID 1x011

Example:

Actual outdoor temperature (T.out): -5 °C

Desired room temperature setting in Comfort mode: 22 °C

Desired room temperature setting in Saving mode: 16 °C


Setting in 'Auto saving': -15 °C

The condition for the outdoor temperature influence:

$$\begin{aligned} T.out.influence &= (10 - T.out) / (10 - \text{setting}) = \\ (10 - (-5)) / (10 - (-15)) &= \\ 15 / 25 &= 0.6 \end{aligned}$$

The corrected desired room temperature in Saving mode:

$$\begin{aligned} T.room.ref.Saving + (T.out.influence \times (T.room.ref.Comfort - \\ T.room.ref.Saving)) & \\ 16 + (0.6 \times (22 - 16)) &= 19.6\text{ °C} \end{aligned}$$



X = Outdoor temperature (°C)
 Y = Desired room temperature (°C)

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Optimization

Boost	1x012
<i>Shortens the heating-up period by increasing the desired flow temperature by the percentage you set.</i>	

See Appendix "Parameter ID overview"

OFF: The boost function is not active.

1-99%: The desired flow temperature is increased temporarily with the set percentage.

In order to shorten the heating-up period after a saving temperature period, the desired flow temperature can be increased temporarily (max. 1 hour). At optimizing the boost is active in the optimization period ('Optimizer').

If a room temperature sensor or an ECA 30 / 31 is connected, the boost stops when the room temperature is reached.

MENU > Settings > Optimization


Ramp (reference ramping)	1x013
<i>The time (minutes) in which the desired flow temperature increases gradually to avoid load peaks in the heat supply.</i>	

See Appendix "Parameter ID overview"

OFF: The ramping function is not active.

1-99 m: The desired flow temperature is increased gradually with the set minutes.

In order to avoid load peaks in the supply network, the flow temperature can be set to increase gradually after a period with saving temperature. This causes the valve to open gradually.



Operating Guide ECL Comfort 310, application P330

MENU > Settings > Optimization

Optimizer (optimizing time constant)	1x014
<p>Optimizes the start and stop times for the comfort temperature period to obtain the best comfort at the lowest energy consumption. The lower the outdoor temperature, the earlier the heating cut-in. The lower the outdoor temperature, the later the heating cut-out. The optimized heating cut-out time can be automatic or disabled. The calculated start and stop times are based on the setting of the optimizing time constant.</p>	

See Appendix "Parameter ID overview"

Adjust the optimizing time constant.

The value consists of a two digit number. The two digits have the following meaning (digit 1 = Table I, digit 2 = Table II).

OFF: No optimization. The heating starts and stops at the times set in the schedule.

10 ... 59: See tables I and II.

Table I:

Left digit	Heat accumulation of the building	System type
1-	light	Radiator systems
2-	medium	
3-	heavy	
4-	medium	Floor heating systems
5-	heavy	

Table II:

Right digit	Dimensioning temperature	Capacity
-0	-50 °C	large
-1	-45 °C	.
.	.	.
-5	-25 °C	normal
.	.	.
-9	-5 °C	small

Dimensioning temperature:

The lowest outdoor temperature (usually determined by your system designer in connection with the design of the heating system) at which the heating system can maintain the designed room temperature.

Example

The system type is radiator, and the heat accumulation of the building is medium.

The left digit is 2.

The dimensioning temperature is -25 °C, and the capacity is normal.
The right digit is 5.

Result:

The setting is to be changed to 25.

MENU > Settings > Optimization

Based on (optimization based on room / outdoor temp.)	1x020
<p>The optimized start and stop time can be based on either room or outdoor temperature.</p>	

See Appendix "Parameter ID overview"

OUT: Optimization based on outdoor temperature. Use this setting if the room temperature is not measured.

ROOM: Optimization based on room temperature, if measured.

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Optimization



Total stop	1x021
Decide whether you want a total stop during the saving temperature period.	

See Appendix "Parameter ID overview"

OFF: No total stop. The desired flow temperature is reduced according to:

- desired room temperature in saving mode
- auto saving

ON: The desired flow temperature is lowered to the set value in 'Frost pr.'. The circulation pump is stopped but frost protection is still active, see 'P frost T'.





The min. flow temperature limitation ('Temp. min.') is overruled when 'Total stop' is ON.


MENU > Settings > Optimization

Pre-stop (optimized stop time)	1x026
Disable the optimized stop time.	

See Appendix "Parameter ID overview"

OFF: The optimized stop time is disabled.

ON: The optimized stop time is enabled.



Operating Guide ECL Comfort 310, application P330

MENU > Settings > Optimization

Summer, cut-out (limit for heating cut-out)

1x179


See Appendix "Parameter ID overview"

The heating can be switched OFF when the outdoor temperature is higher than the set value. The valve closes and after the post-run time, the heating circulation pump stops. 'Temp. min.' will be overruled.

The heating system switches ON again when the outdoor temperature and the accumulated (filtered) outdoor temperature become lower than the set limit.

This function can save energy.

Set the value for outdoor temperature at which you want the heating system to switch OFF.



The heating cut-out is only active when the controller mode is in scheduled operation. When the cut-out value is set to OFF, there is no heating cut-out.

5.7 Control parameters

MENU > Settings > Control parameters

Motor pr. (motor protection)	1x174
<i>Prevents the controller from unstable temperature control (and resulting actuator oscillations). This can occur at very low load. The motor protection increases the lifetime of all involved components.</i>	



Recommended for heating systems with variable load.

See Appendix "Parameter ID overview"

OFF: Motor protection is not activated.

10 ... 59: Motor protection is activated after the set activation delay in minutes.

MENU > Settings > Control parameters

Xp (proportional band)	1x184
-------------------------------	--------------

See Appendix "Parameter ID overview"

Set the proportional band. A higher value will result in a stable but slow control of the flow temperature.

*) Differently, depending on chosen application.

MENU > Settings > Control parameters

Tn (integration time constant)	1x185
---------------------------------------	--------------

See Appendix "Parameter ID overview"

Set a high integration time constant (in seconds) to obtain a slow but stable reaction to deviations.

A low integration time constant will make the controller react fast but with less stability.

*) Differently, depending on chosen application.

MENU > Settings > Control parameters

M run (running time of the motorized control valve)	1x186
--	--------------

See Appendix "Parameter ID overview"

'M run' is the time in seconds it takes the controlled component to move from fully closed to fully open position. Set the 'M run' according to the examples or measure the running time by means of a stop watch.

*) Differently, depending on chosen application.

How to calculate the running time of a motorized control valve

The running time of the motorized control valve is calculated using the following methods:

Seated valves

Running time = Valve stroke (mm) x actuator speed (sec. / mm)

Example: 5.0 mm x 15 sec. / mm = 75 sec.

Rotating valves

Running time = Turning degrees x actuator speed (sec. / degr.)

Example: 90 degr. x 2 sec. / degr. = 180 sec.



The setting "M run" is not present when the valve is controlled by means of a 0 - 10 volt signal.

MENU > Settings > Control parameters

Nz (neutral zone)	1x187
--------------------------	--------------

See Appendix "Parameter ID overview"

*) Differently, depending on chosen application.

Set the acceptable flow temperature deviation.

Set the neutral zone to a high value if you can accept a high variation in flow temperature. When the actual flow temperature is within the neutral zone, the controller does not activate the motorized control valve.



The neutral zone is symmetrical around the desired flow temperature value, i.e. half the value is above and half the value is below this temperature.

MENU > Settings > Control parameters

Min. act. time (min. activation time gear motor)	1x189
<i>The min. pulse period of 20 ms (milliseconds) for activation of the gear motor.</i>	

Setting example	Value x 20 ms
2	40 ms
10	200 ms
50	1000 ms

See Appendix "Parameter ID overview"

*) Differently, depending on chosen application.




The setting should be kept as high as acceptable to increase the lifetime of the actuator (gear motor).



The setting "Min act. time" is not present when the valve is controlled by means of a 0 - 10 volt signal.

If you want to tune the PI regulation precisely, you can use the following method:

- Set the 'Tn' (integration time constant) to its max. value (999 sec.).
- Decrease the value for the 'Xp' (proportional band) until the system starts hunting (i.e. gets unstable) with a constant amplitude (it might be necessary to force the system by setting an extreme low value).
- Find the critical time period on the temperature recorder or use a stop watch.



This critical time period will be characteristic for the system, and you can evaluate the settings from this critical period.

'Tn' = 0.85 x critical time period

'Xp' = 2.2 x proportional band value in the critical time period

If the regulation seems to be too slow, you can decrease the proportional band value by 10%. Make sure there is a consumption when you set the parameters.

Operating Guide ECL Comfort 310, application P330

5.8 Application

MENU > Settings > Application

ECA addr. (choice of Remote Control Unit)	1x010
Decides the communication with the Remote Control Unit.	



The Remote Control Unit has no influence on the DHW control.

See Appendix "Parameter ID overview"

OFF: No Remote Control Unit. Only room temperature sensor, if any.

A: Remote Control Unit ECA 30 / 31 with address A.

B: Remote Control Unit ECA 30 / 31 with address B.




The Remote Control Unit must be set accordingly (A or B).

MENU > Settings > Application

Demand offset	1x017
<i>The desired flow temperature in heating circuit 1 or the master circuit can be influenced by the demand for a desired flow temperature from another controller (slave) or another circuit.</i>	

Temp.

Setting in
'Demand offset'



Des. flow temp.,
circuit 1
Des. flow temp.,
circuit 2
Time

See Appendix "Parameter ID overview"

OFF: The desired flow temperature in circuit 1 or the master circuit is not influenced by the demand of any other controller (slave or other circuits).

1 ... 20: The desired flow temperature in circuit 1 or the master circuit is increased by the set value in 'Demand offset', if the demand of the slave or another circuit is higher.



The function of 'Demand offset' can compensate for heat losses between master and slave controlled systems.

*) Differently, depending on chosen application



The "Demand offset" is present in circuit 1 in the applications P330.1 - P330.5.

The "Demand offset" is present in the Master Circuit in the applications P330.6 - P330.14.

MENU > Settings > Application

P exercise (pump exercise)	1x022
<i>Exercises the pump to avoid blocking in periods without cooling demand.</i>	



The pump exercise is related to circulation pumps in cooling circuits.

See Appendix "Parameter ID overview"

OFF: The pump exercise is not active.

ON: The pump is switched ON for 1 minute every third day at noon (12:14 hours).

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Application

M exercise (valve exercise)	1x023
<i>Exercises the valve to avoid blocking in periods without cooling demand.</i>	



The valve exercise is related to motorized control valves (MCV) in cooling circuits.

See Appendix "Parameter ID overview"

OFF: The valve exercise is not active.

ON: The valve opens for 7 minutes and closes for 7 minutes every third day at noon (12:00 hours).

MENU > Settings > Application

P post-run	1x040
<i>The circulation pump in the cooling circuit can be ON for a number of minutes (m) after cooling stop (the desired flow temperature gets higher than the setting in 'P cool T' (ID no. 1x070)). This function can utilize the remaining cooling in for example a heat exchanger.</i>	

See Appendix "Parameter ID overview"

0: The circulation pump stops immediately after the cooling stop.

1 ... 99: The circulation pump is ON for the set time after the cooling stop.

MENU > Settings > Application

P demand (P330.1 - P330.5)	1x050
<i>Choose conditions for the circulation pump in the heating circuit 1.</i>	



The circulation pump is always controlled according to frost protection conditions.

See Appendix "Parameter ID overview"

OFF: The circulation pump is ON when the desired flow temperature in the heating circuit is higher than the value set in 'P heat T'.

ON: The circulation pump is ON when the desired flow temperature from slaves is higher than the value set in 'P heat T'.

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Application

DHW priority (closed valve / normal operation)	1x052
<i>The heating circuit can be closed when the controller acts as slave and when DHW heating / charging is active in the master.</i>	



This setting must be considered if this controller is a slave.

See Appendix "Parameter ID overview"

OFF: The flow temperature control remains unchanged during active DHW heating / charging in the master controller.

ON: The valve in the heating circuit is closed* during active DHW heating / charging in the master controller.

* *The desired flow temperature is set to the value set in 'Frost pr. T'*

STOP: The circulation pump stops when there is an active DHW charging ongoing. The pump will stop at once (without post-run) and the frost protection in the heating circuit is overruled.



The heating circuit can also be closed when the DHW heating is active in the same ECL controller.

MENU > Settings > Application

P frost T	1x077
<i>When the outdoor temperature is below the set temperature in 'P frost T', the controller automatically switches ON the circulation pump to protect the system.</i>	



Under normal conditions, your system is not frost protected if your setting is below 0 °C or OFF. For water-based systems, a setting of 2 °C is recommended.

See Appendix "Parameter ID overview"

OFF: No frost protection.

-10 ... 20: The circulation pump is ON when the outdoor temperature is below the set value.

MENU > Settings > Application

P heat T (heat demand)	1x078
<i>When the desired flow temperature is above the set temperature in 'P heat T', the controller automatically switches ON the circulation pump.</i>	



The valve is fully closed as long as the pump is not switched on.

See Appendix "Parameter ID overview"

5 ... 40: The circulation pump is switched ON when the desired flow temperature is above the set value.

MENU > Settings > Application

Frost pr. T (frost protection temperature)	1x093
<i>Set the desired flow temperature for example at heating cut-out, total stop etc. to protect the system against frost.</i>	

See Appendix "Parameter ID overview"

5 ... 40: Desired frost protection temperature.

Override mode functions:

The following settings describe the function in general for the ECL Comfort 210 / 310 series. The explained modes are typical and not application related. They might differ from the override modes in your application.

MENU > Settings > Application

Ext. input (external override)	1x141
<i>Choose the input for 'Ext. input' (external override). By means of a switch the controller can be overridden to 'Comfort', 'Saving', 'Frost protection' or 'Constant temperature' mode.</i>	

See Appendix “Parameter ID overview”

OFF: No inputs have been selected for external override.


S1 ... S16: Input selected for external override.

If S1... S6 is chosen as override input, the override switch must have gold-plated contacts.


If S7 ... S16 is chosen as override input, the override switch can be a standard contact.

See the drawings for connection examples of override switch and override relay to input S8.

Example: Connection of an override switch



Example: Connection of an override relay



Choose only an unused input for override. If an already used input is applied for override, the functionality of this input is also neglected.

See also 'Ext. mode'

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Application

Ext. mode (external override mode)	1x142
<i>The mode override can be activated for Saving, Comfort, Frost pr. or Constant T mode.</i>	
<i>For override, the controller mode must be in scheduled mode.</i>	

See Appendix "Parameter ID overview"

Choose an override mode:

SAVING: The circuit in question is in saving mode when the override switch is closed.

COMFORT: The circuit in question is in comfort mode when the override switch is closed.

FROST PR.: The heating or DHW circuit closes, but is still frost protected.

CONSTANT T: The circuit in question controls a constant temperature *)

*) See also 'Desired T' (1x004), setting of desired flow temperature (MENU > Settings > Flow temperature)


See also 'Con. T, ret. T lim.' (1x028), setting of return temperature limitation (MENU > Settings > Return limit)

The process diagrams show the functionality.



See also 'Ext. input'.

Example: Override to Comfort mode




1 # = Override switch (not activated / activated)

2 # = Function mode (Schedule / Comfort)

3 # = Time

Example: Override to Saving mode



1 # = Override switch (not activated / activated)

2 # = Function mode (Schedule / Saving)

3 # = Time




The result of override to 'Saving' mode depends on the setting in 'Total stop'.


Total stop = OFF: Heating reduced

Total stop = ON: Heating stopped

Example: Override to Frost protection mode



Example: Override to Constant temperature mode



The "Const. T" value can be influenced by:

- temp. max.
- temp. min.
- room temp. limit
- return temp. limit
- flow / power limit



Subtype P330.14:
At override, the master circuit can be overridden to Frost protection mode only.

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Application

Send desired T	1x500
Sub-circuit in the same ECL controller: Information about the desired flow temperature can be sent to circuit 1.	
The ECL controller acts as a slave controller in a master / slave system: Information about the desired flow temperature can be sent to the master controller via the ECL 485 bus.	

See Appendix "Parameter ID overview"

OFF: Information about the desired flow temperature is not sent to circuit 1 / the master controller.

ON: Information about the desired flow temperature is sent to circuit 1 / the master controller.



Slave circuits are circuits in other ECL controllers.
Sub-circuits are circuits besides the master or circuit 1 in the ECL controller.



In the master controller, 'Demand offset' must be set to a value in order to react on a desired flow temperature from a slave controller.



When the controller acts as a slave, its address must be 1, 2, 3 ... 9 in order to send the desired temperature to the master (see the section 'Miscellaneous', 'Several controllers in the same system').

5.9 Tank temperature

MENU > Settings > Tank temperature

DHW P post-run	1x041
<i>Set the DHW heating pump post-run time (minutes). The pump can continue to be switched ON after the DHW heating procedure in order to utilize a remaining heat in the heat supply system.</i>	

See Appendix "Parameter ID overview"

0 ... 30: Set the number of minutes for the post-run.

MENU > Settings > Tank temperature

Char. P post-run	1x042
<i>Set the DHW charging pump post-run time (minutes). The pump can continue to be switched ON after the DHW heating procedure in order to utilize a remaining heat in the heat-exchanger.</i>	

See Appendix "Parameter ID overview"

0 ... 30: Set the number of minutes for the post-run.

MENU > Settings > Tank temperature

Cont. T control	1x054
<i>Depending on the DHW circulation pipe connection, the desired DHW heating / charging temperature can be lowered when the DHW heating procedure has elapsed.</i>	

See Appendix "Parameter ID overview"

OFF: The desired DHW heating temperature is lowered to 10 °C. Typically, the DHW is circulated through the DHW tank.

ON: The desired DHW heating temperature is lowered to the desired DHW temperature. Typically, the DHW is circulated through the heat exchanger in order to compensate for the heat loss in the DHW circulation pipe.

MENU > Settings > Tank temperature

Circ. P priority	1x055
<i>Choose whether the DHW circulation pump should be ON during DHW heating.</i>	



When the 'Circ. P priority' is set to OFF, the schedule for the DHW circulation pump is overruled.

See Appendix "Parameter ID overview"

OFF: The DHW circulation pump is switched OFF during DHW heating.

ON: The DHW circulation pump is not switched OFF during DHW heating.

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Tank temperature

Circ. P frost T	1x076
<i>Set the outdoor temperature value at which the DHW circulation pump is to be active to protect the DHW circuit against frost.</i>	

See Appendix "Parameter ID overview"

OFF: The DHW circulation pump is not active.

-10 ... 20: The DHW circulation pump is active when the outdoor temperature is lower than the set value.

MENU > Settings > Tank temperature

Frost pr. T (frost protection temperature)	1x093
<i>Set the desired DHW temperature to protect the system against frost.</i>	

See Appendix "Parameter ID overview"

5 ... 40: Desired frost protection temperature.

'Ext. input' (ID 1x141) and 'Ext. mode' (ID 1x142):

The functions are the same as for the heating circuits.

MENU > Settings > Tank temperature

Max. charge T	1x152
<i>Set the max. desired DHW charging temperature.</i>	



The setting of 'Max. charge T' is protecting against a too high DHW heating temperature.

See Appendix "Parameter ID overview"

10 ... 110: Set the temperature.

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Tank temperature

Tank start diff. (P330.14) 1x192

The temperature difference above the DHW temperature S10 to ensure an acceptable buffer tank temperature S11.

When the buffer tank temperature is acceptable, the DHW charging pump P5 will be switched ON.



The "Tank start diff." avoids a discharge of the DHW tank.



See also "Tank stop diff." (ID 13196)

See Appendix "Parameter ID overview"

1 - 25 K: Set the number of degrees.

Example:

Desired DHW temperature: 50 °C

"Start difference" (ID 13195) = -3 K

Setting "Tank start diff." (ID 13192) = 10 K

When DHW tank temperature S10 falls below 47 °C, the DHW heating pump P7 is switched ON.

The DHW charging pump P5 is switched ON when the buffer tank temperature S11 is 10 degrees higher than the DHW temperature (S10).


MENU > Settings > Tank temperature

Charge difference 1x193

Set the number of degrees above the desired DHW temperature that will result in the DHW heating (charging) temperature.

See Appendix "Parameter ID overview"

1... 50: Number of degrees to be added to the desired DHW temperature to obtain the DHW heating (charging) temperature.



The desired DHW temperature is related to the tank temperature sensor.

If two tank temperature sensors are installed, the relation is to the upper tank temperature sensor.

Operating Guide ECL Comfort 310, application P330


MENU > Settings > Tank temperature

Stop difference	1x194
One DHW tank temperature sensor: Set the number of degrees above the desired DHW temperature that will stop the DHW heating (charging).	
Two DHW tank temperature sensors: Set the number of degrees above the desired DHW temperature but measured by the lower tank temperature sensor that will stop the DHW heating (charging).	


See Appendix "Parameter ID overview"

-50 ... 50: Set the number of degrees.


One DHW tank temperature sensor (example with positive 'Stop difference' value):



One DHW tank temperature sensor (example with negative 'Stop difference' value):



Two DHW tank temperature sensors, upper and lower:



Operating Guide ECL Comfort 310, application P330

MENU > Settings > Tank temperature

Start difference	1x195
Set the number of degrees below the desired DHW temperature that will start the DHW heating (charging).	

See Appendix "Parameter ID overview"

Example:


Desired DHW temp.: 55 °C

Start difference: -3 K

Result:

The DHW heating starts when the temperature measured by the tank temperature sensor (upper) is lower than 52 °C.

-50 ... -1: Set the number of degrees.



MENU > Settings > Tank temperature

Tank stop diff. (P330.14)	1x196
The maximum number of degrees reduction of the temperature difference that enables the DHW charging.	
If the temperature difference between S11 and S10 is "set value" lower than acceptable temperature difference ("Tank start diff.") the DHW charging pump (P5) will be switched OFF.	

See Appendix "Parameter ID overview"

1 - 10 K: Set the number of degrees.



The "Tank stop diff." avoids a discharge of the DHW tank.



See also "Tank start diff." (ID 13192)

Example:

Desired DHW temperature: 50 °C

"Start difference" (ID 13195) = -3 K

Setting "Tank start diff." (ID 13192) = 10 K

Setting "Tank stop diff." (ID 13196) = 2K

When DHW tank temperature S10 falls below 47 °C, the DHW heating pump P5 is switched ON.

The DHW charging pump P5 is switched ON when the buffer tank temperature S11 is 10 degrees higher than the DHW temperature (S10).

The DHW charging pump P5 is switched OFF if the buffer tank temperature S11 is less than 8 degrees higher than the DHW temperature (S10).

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Tank temperature

Send desired T	1x500
<i>Sub-circuit in the same ECL controller, applications P330.4 and P330.5: Information about the desired DHW heating temperature can be sent to circuit 1.</i>	
<i>Sub-circuit in the same ECL controller, applications P330.9 - P330.14: Information about the desired DHW heating temperature can be sent to the Master circuit.</i>	



In circuit 1 or the master circuit, 'Demand offset' must be set to a value in order to react on a desired DHW heating temperature from a sub-circuit.
Furthermore, in the DHW circuit the setting 'Send desired T' must be 'ON'.

See Appendix "Parameter ID overview"

OFF: Information about the desired DHW heating temperature is not sent.

ON: Information about the desired DHW heating temperature is sent.

Return limit

(Includes the applications P330.4, P330.9, P330.10 only)

The functions are the same as for the heating circuits. In DHW circuits the limitation value is a set value.

Flow / power limit

(Includes the applications P330.4, P330.9, P330.10 only)

The functions are the same as for the heating circuits. In DHW circuits the limitation value is a set value.


Control parameters

(Includes the applications P330.4, P330.9, P330.10 only)



The functions are the same as for the heating circuits.

5.10 Anti-bacteria

On selected days during the week the DHW temperature can be increased in order to neutralize bacteria in the DHW system. The desired DHW temperature 'Desired T' (typically 80 °C) will be present for the selected day(s) and duration. The anti-bacteria function is not active in frost protection mode.



X = Time
 Y = Desired DHW temperature
1 # = Duration
2 # = Desired Anti-bacteria temperature value
3 # = Desired Anti-bacteria temperature
4 # = Desired DHW temperature value
5 # = Start time



MENU > Settings > Anti-bacteria

Day
Select (mark) the day(s) of the week where the anti-bacteria function must be active.

M = Monday

T = Tuesday

W = Wednesday

T = Thursday

F = Friday

S = Saturday

S = Sunday

Operating Guide ECL Comfort 310, application P330

MENU > Settings > Anti-bacteria

Start time
<i>Set the start time for the anti-bacteria function.</i>

MENU > Settings > Anti-bacteria

Duration
<i>Set the duration (minutes) for the anti-bacteria function.</i>

MENU > Settings > Anti-bacteria

Desired T
<i>Set the desired DHW temperature for the anti-bacteria function.</i>

See Appendix "Parameter ID overview"

OFF: The anti-bacteria function is not active.

Value: Desired DHW temperature during the anti-bacteria function period.

5.11 Alarm

Many applications in the ECL Comfort 210 and 310 series have an alarm function. The alarm function typically activates relay 4 (ECL Comfort 210) or relay 6 (ECL Comfort 310).

The alarm relay can activate a lamp, a horn, an input to an alarm transmitting device etc.

The relay in question is activated as long as the alarm condition is present.

Typical alarms:

- Actual flow temperature differs from the desired flow temperature.

5.11.1 Temp. monitor.


MENU > Settings > Alarm

Upper difference	1x147
<i>The alarm is activated if the actual flow temperature increases more than the set difference (acceptable temperature difference above the desired flow temperature). See also 'Delay'!</i>	

See Appendix "Parameter ID overview"

OFF: The alarm function is not active.

1 ... 30 K: The alarm function is active if the actual temperature gets above the acceptable difference.




MENU > Settings > Alarm

Lower difference	1x148
<i>The alarm is activated if the actual flow temperature decreases more than the set difference (acceptable temperature difference below the desired flow temperature). See also 'Delay'!</i>	

See Appendix "Parameter ID overview"

OFF: The alarm function is not active.

1 ... 30 K: The alarm function is active if the actual temperature gets below the acceptable difference.




MENU > Settings > Alarm

Delay	1x149
<i>If an alarm condition from either 'Upper difference' or 'Lower difference' is present for a longer time than the set delay (in min.), the alarm function is activated.</i>	

See Appendix "Parameter ID overview"

1 ... 99 m: The alarm function will be activated if the alarm condition remains after the set delay.



Operating Guide ECL Comfort 310, application P330

MENU > Settings > Alarm

Lowest temp.	1x150
<i>The alarm function will not be activated if the desired flow / duct temperature is lower than the set value.</i>	



If the cause of the alarm disappears, the alarm indication and output also disappear.

See Appendix "Parameter ID overview"

6.0 Common controller settings

6.1 Introduction to 'Common controller settings'

Some general settings which apply to the entire controller are located in a specific part of the controller.

To enter 'Common controller settings':

Action:	Purpose:	Examples:
	Choose 'MENU' in any circuit	
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose 'Common controller settings'	
	Confirm	

Applications P330.1 - P330.5

Circuit selector




Settings related to applications P330.6–P330.15

Settings (M) and Alarm (M) are related to the master circuit in the applications P330.6 - P330.15.

Applications P330.6 - P330.15

Circuit selector




Settings (M) contains:

Flow temperature
Return limit
Flow / power limit
Control parameter
Application

The functions are the same as for heating circuits.

Applications P330.6 - P330.15

Circuit selector




In addition, the application P330.14 contains the following settings (M):

Charge difference
Stop difference
Start difference

The functions are the same as for DHW circuits.

Application P330.14

Circuit selector



Operating Guide ECL Comfort 310, application P330


P330: Applications 6–15

Circuit selector

Alarm (M) contains:

Temp. monitor.
Alarm overview

The functions are the same as for heating circuits.




P330: Applications 6–15

Circuit selector

Input overview (M) contains:

Flow T
Return T
Ext. desired T

The functions are the same as for heating circuits.




P330: Application 14–15

Circuit selector

Log (M) contains:

Flow T & desired
Return T & limit

The functions are the same as for heating circuits.



6.2 Time & Date



It is only necessary to set the correct date and time in connection with the first use of the ECL Comfort controller or after a power break of more than 72 hours.

The controller has a 24 hour clock.

Aut. daylight (Daylight saving time changeover)

YES: The controller's built-in clock automatically changes + / - one hour on the standardized days for daylight saving time changeover for Central Europe.

NO: You change manually between summer and winter time by setting the clock backward or forward.



6.3 Holiday

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

There is a holiday program for each circuit and a holiday program for the common controller.

Each holiday program contains one or more schedules. Each schedule can be set to a start date and an end date. The set period starts on the start date at 00.00 and stops on the end date at 00.00.

Selectable modes are Comfort, Saving, Frost protection or Comfort 7-23 (before 7 and after 23, the mode is scheduled).

How to set your holiday schedule:



Action:	Purpose:	Examples:
	Choose 'MENU'	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose a circuit or 'Common controller settings'	
	Heating	
	DHW	
	Common controller settings	
	Confirm	
	Go to 'Holiday'	
	Confirm	
	Choose a schedule	
	Confirm	
	Confirm choice of mode selector	
	Choose mode	
· 	Comfort	
· 	Comfort 7-23	
· 	Saving	
· 	Frost protection	
	Confirm	
	Enter the start time first and then the end time	
	Confirm	
	Go to 'Menu'	
	Confirm	
	Choose 'Yes' or 'No' in 'Save'. Choose the next schedule, if required	



The holiday program in the 'Common controller settings' is valid for all circuits. The holiday program can also be set individually in the heating or DHW circuits.



The end date must be at least be one day later than the start date.



Operating Guide ECL Comfort 310, application P330

Holiday, specific circuit / Common Controller

When setting one holiday program in specific circuit and another holiday program in Common Controller, a priority will be taken into account:

1. Comfort
2. Comfort 7 - 23
3. Saving
4. Frost protection

Holiday, deleting a set period:

- Choose the Schedule in question
- Change the mode to "Clock"
- Confirm

Example 1:

Circuit 1:
Holiday set to "Saving"

Common Controller:
Holiday set to "Comfort"

Result:
As long as "Comfort" is active in Common Controller, circuit 1 will be in "Comfort".

Example 2:

Circuit 1:
Holiday set to "Comfort"

Common Controller:
Holiday set to "Saving"

Result:
As long as "Comfort" is active in circuit 1, it will be in "Comfort".

Example 3:

Circuit 1:
Holiday set to "Frost protection"

Common Controller:
Holiday set to "Saving"

Result:
As long as "Saving" is active in Common Controller, circuit 1 will be in "Saving".

The ECA 30 / 31 cannot override the holiday schedule of the controller temporarily.

However, it is possible to make use of the following options from the ECA 30 / 31 when the controller is in scheduled mode:



Day off



Holiday



Relaxing (extended comfort period)



Going out (extended saving period)



Energy-saving trick:
Use 'Going out' (the extended saving period) for airing purposes (e.g. for ventilating the rooms by means of fresh air from open windows).



Connections and setup procedures for ECA 30 / 31:
See section 'Miscellaneous'.

6.4 Input overview

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The input overview is located in the common controller settings.

This overview will always show you the actual temperatures in the system (read-only).

MENU	
Input overview	
▶ Outdoor T	7.0 °C
Outdoor acc. T	5.8 °C
Heat return T	35.5 °C
Heat flow T	67.9 °C
DHW flow T	68.6 °C


"Outdoor acc. T" means "Accummulated outdoor temperature" and is a calculated value in the ECL Comfort controller.



6.5 Log

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.


The log function (temperature history) allows you to monitor the logs of today, yesterday, the past 2 days as well as the past 4 days for the connected sensors.

There is a log display for the relevant sensor, showing the measured temperature.


The log function is only available in the 'Common controller settings'.




Example 1:
1 day log for yesterday showing the development in outdoor temperature during the past 24 hours.



Example 2:
Today's log for the actual heating flow temperature as well as the desired temperature.



Example 3:
Yesterday's log for the DHW flow temperature as well as the desired temperature.



6.6 Output override

This section describes the function in general for the ECL Comfort 210 / 296 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The output override is used to disable one or more of the controlled components. This could among others be useful in a service situation.

Action:	Purpose:	Examples:
Ⓐ	Choose 'MENU' in any of the overview displays	MENU
Ⓑ	Confirm	
Ⓐ	Choose the circuit selector at the top right corner in the display	
Ⓑ	Confirm	
Ⓐ	Choose common controller settings	□○
Ⓑ	Confirm	
Ⓐ	Choose 'Output override'	
Ⓑ	Confirm	
Ⓐ	Choose a controlled component	M1, P1 etc.
Ⓑ	Confirm	
Ⓐ	Adjust the status of the controlled component: Motorized control valve: AUTO, STOP, CLOSE, OPEN Pump: AUTO, OFF, ON	
Ⓑ	Confirm status change	

Remember to change the status back again as soon as an override is not required any longer.

Controlled components	Circuit selector
MENU	□○
Output override!	
► M1	AUTO
P1	AUTO
M2	OPEN
P2	AUTO
A1	AUTO


⚠
When the selected controlled component (output) is not 'AUTO', the ECL Comfort controller does not control the component in question (pump or motorized control valve e.g.). Frost protection is not active.

⚠
When output override of a controlled component is active the symbol '!' is shown to the right of the mode indicator in the enduser displays.

⚠
Applications P330.3, P330.8 and P330.12: The motorized control valve M4 is controlled by a 0–10 volt (0–100%) signal. It can be set to AUTO or ON. AUTO: Normal control (0–100%) ON: The 0–10 volt signal is set to the %-value, set below the indication 'ON'.

6.7 Key functions

New application	Erase application: Removes the existing application. As soon as the ECL key is inserted, another application can be chosen.
Application	Gives an overview over the actual application in the ECL controller. Push the dial again to exit the overview.
Factory setting	System settings: System settings are, among others, communication set-up, display brightness etc. User settings: User settings are, among others, desired room temperature, desired DHW temperature, schedules, heat curve, limitation values etc. Go to factory: Restores the factory settings.
Copy	To: Copy direction System settings User settings Start copying
Key overview	Gives an overview over the inserted ECL key. (Example: A266 Ver. 2.30). Turn the dial to see the subtypes. Push the dial again to exit the overview.



A more detailed description of how to use the individual 'Key functions' can also be seen in 'Inserting the ECL application key'.



The "Key overview" does not inform — through ECA 30 / 31 — about the subtypes of the application key.



Key inserted / not inserted, description:

ECL Comfort 210 / 310, controller versions lower than 1.36:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; for 20 minutes settings can be changed.

ECL Comfort 210 / 310, controller versions 1.36 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

ECL Comfort 296, controller versions 1.58 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

6.8 System

6.8.1 ECL version

In 'ECL version' you will always be able to find an overview of the data related to your electronic controller.

Please have this information available if you need to contact your Danfoss sales organization concerning the controller.

Information about your ECL Application Key can be found in 'Key functions' and 'Key overview'.

Code no.:	The Danfoss sales and order no. for the controller
Hardware:	Hardware version of the controller
Software:	Software (firmware) version of the controller
Serial no.:	Unique number for the individual controller
Production week:	Week no. and year (WW.YYYY)

Example, ECL version

System	
ECL version:	<input checked="" type="checkbox"/>
► Code no.	087H3040
Hardware	B
Software	10.50
Build no.	7475
Serial no.	5335

6.8.2 Extension

ECL Comfort 310 / 310B:

'Extension' will offer you information about additional modules, if any. An example could be the ECA 32 module.

6.8.3 Ethernet

ECL Comfort 296 / 310 / 310B have a Modbus/TCP communication interface that allows the ECL controller to be connected to an Ethernet network. This allows remote access to the ECL 296 / 310 / 310B controller based on standard communication infrastructures.

In 'Ethernet' it is possible to set up the required IP addresses.

6.8.4 Portal config

ECL Comfort 296 / 310 / 310B have a Modbus/TCP communication interface that allows the ECL controller to be monitored and controlled via the ECL Portal.

ECL Portal related parameters are set here.

Documentation for ECL Portal: See <https://ecl.portal.danfoss.com>

6.8.5 M-bus config

ECL Comfort 296 / 310 / 310B have an M-bus communication interface that allows energy meters to be connected as slaves.

M-bus related parameters are set here.

Operating Guide ECL Comfort 310, application P330

6.8.6 Energy meter and M-bus, general information

ECL Comfort 296 / 310 / 310B only

When using the Application Key in the ECL Comfort 296 / 310 / 310B, up to 5 energy meters can be connected to the M-bus connections.



Energy meter data acquisition from ECL Portal is possible without setting up the M-bus configuration.

Connection of energy meter can:

- limit the flow
- limit the power
- transfer energy meter data to the ECL Portal, via Ethernet, and / or a SCADA system, via Modbus.

Many applications with control of heating, DHW or cooling circuit have the possibility to react on energy meter data.

To verify if actual application key can be set to react on energy meter data:

See Circuit > MENU > Settings > Flow / power.

The ECL Comfort 296 / 310 / 310B can always be used for monitoring purpose of up to 5 energy meters.

The ECL Comfort 296 / 310 / 310B act as an M-bus master and must be set to communicate with connected energy meter(s).

See MENU > Common controller > System > M-bus config.

Technical info:

- The M-bus data are based on standard EN-1434.
- Danfoss recommends AC supplied energy meters in order to avoid battery draining.

MENU > Common controller > System > M-bus config.

State		Read-out
Circuit	Setting range	Factory setting
-	-	-
Information about the current M-bus activity.		



The ECL Comfort 296 / 310 / 310B will return to IDLE when commands have been completed.
Gateway is used for read-out of energy meter via ECL Portal.

IDLE: Normal state

INIT: The command for initialization has been activated

SCAN: The command for scanning has been activated

GATEW: The command Gateway has been activated

MENU > Common controller > System > M-bus config.

Baud (bits per second)		5997
Circuit	Setting range	Factory setting
-	300 / 600 / 1200 / 2400	300
The communication speed between ECL Comfort 296 / 310 / 310B and the connected energy meter(s).		



Typically, 300 or 2400 baud is used.
If ECL Comfort 296 / 310 / 310B are connected to the ECL Portal, a baud rate of 2400 is recommendable, provided the energy meter allows this.

Operating Guide ECL Comfort 310, application P330

MENU > Common controller > System > M-bus config.

Command		5998
Circuit	Setting range	Factory setting
-	NONE / INIT / SCAN / GATEW	NONE

The ECL Comfort 296 / 310 / 310B are M-bus masters. In order to verify connected energy meters, different commands can be activated.



Scan time can take up to 12 minutes.
When all energy meters are found, the command can be changed to INIT or NONE.

NONE: No command activated

INIT: Initialization is activated

SCAN: Scanning is activated in order to search for connected energy meters. The ECL Comfort 296 / 310 / 310B detect the M-bus addresses of up to 5 connected energy meters and place these automatically in the "Energy meters" section. The verified address is placed after "Energy meter 1 (2, 3, 4, 5)"

GATEW: The ECL Comfort 296 / 310 / 310B act as a gateway between energy meters and ECL Portal. Used only for service.

MENU > Common controller > System > M-bus config.

M-bus address		6000
Energy meter 1 (2, 3, 4, 5)		
Circuit	Setting range	Factory setting
-	0 - 255	255

The set or verified address of energy meter 1 (2, 3, 4, 5).



0: Normally not used

1 - 250: Valid M-bus addresses

251 - 254: Special functions. Use only M-bus address 254 when one energy meter is connected.

255: Not used

MENU > Common controller > System > M-bus config.

Type		6001
Energy meter 1 (2, 3, 4, 5)		
Circuit	Setting range	Factory setting
-	0 - 4	0

Selecting data range from the M-bus telegram..



Data examples:

0:
Flow temp., return temp., flow, power, acc. volume, acc. energy.

3:
Flow temp., return temp., flow, power, acc. volume, acc. energy, tariff 1, tariff 2.

See also the "Instructions, ECL Comfort 210 / 310, communication description" for further details.

See also Appendix for detailed description of "Type".

0: Small data set, small units

1: Small data set, large units

2: Large data set, small units

3: Large data set, large units

4: Volume and energy data only
(example: HydroPort Pulse)

Operating Guide ECL Comfort 310, application P330

MENU > Common controller > System > M-bus config.

Scan time	6002	
Energy meter 1 (2, 3, 4, 5)		
<i>Circuit</i>	<i>Setting range</i>	<i>Factory setting</i>
-	1 - 3600 sec	60 sec
<i>Setting the scanning time for acquiring data of connected energy meter(s).</i>		



If the energy meter is battery powered, the scan time should be set to a high value to prevent a too fast battery draining.

Oppositely, if the flow / power limitation function is used in the ECL Comfort 310, the scan time should be set to a low value in order to have quick limitation.

MENU > Common controller > System > M-bus config.

ID	Read-out	
Energy meter 1 (2, 3, 4, 5)		
<i>Circuit</i>	<i>Setting range</i>	<i>Factory setting</i>
-	-	-
<i>Information about the energy meter's serial no.</i>		

MENU > Common controller > System > Energy meters

Energy meter 1 (2, 3, 4, 5)	Read-out	
<i>Circuit</i>	<i>Setting range</i>	<i>Factory setting</i>
-	0 - 4	0
<i>Information from actual energy meter about, for example, ID, temperatures, flow / volume, power / energy.</i>		
<i>The shown information depends on the settings made in the "M-bus config." menu.</i>		

6.8.7 Raw input overview

Measured temperatures, input status and voltages are displayed.

In addition, a detection of malfunctions can be chosen for activated temperature inputs.

Monitoring the sensors:

Choose the sensor which measures a temperature, for example the S5. When the dial is pressed, a magnifying glass  appears in the selected line. The S5 temperature is now being monitored.

Alarm indication:

Should the connection to the temperature sensor be disconnected, short-circuited or the sensor itself be defective, the alarm function is activated.

In the "Raw input overview" an alarm symbol  is shown at the defective temperature sensor in question.

Resetting the alarm:

Choose the sensor (S number) for which you want to clear the alarm. Press the dial. The magnifying glass  and alarm symbols  disappear.

When the dial is pressed again, the monitoring function is reactivated.



The temperature sensor inputs have a measuring range from -60 ... 150 °C.

If a temperature sensor or its connection breaks, the value indication is " --- ".

If a temperature sensor or its connection is short-circuited, the value indication is " - - - ".

6.8.8 Sensor offset (new functionality as from firmware 1.59)

The measured temperature can be offset adjusted in order to compensate for cable resistance or a not-optimum place for the temperature sensor. The adjusted temperature can be seen in "Raw input overview" and "Input overview".

Common controller > System > Sensor offset

Sensor 1 . . . (temperature sensor)		
Circuit	Setting range	Factory setting
<input type="checkbox"/>	*	*
Setting the offset of the measured temperature.		

Positive offset value: The temperature value is increased

Negative offset value: The temperature value is decreased

6.8.9 Display

Backlight (display brightness)		
Circuit	Setting range	Factory setting
<input type="checkbox"/>	0 ... 10	5
Adjust the brightness of the display.		

0: Weak backlight.

10: Strong backlight.

Contrast (display contrast)		
Circuit	Setting range	Factory setting
<input type="checkbox"/>	0 ... 10	3
Adjust the contrast of the display.		

0: Low contrast.

10: High contrast.

6.8.10 Communication

Modbus addr.		
Circuit	Setting range	Factory setting
<input type="checkbox"/>	1 ... 247	1
Set the Modbus address if the controller is part of a Modbus network.		

1 ... 247: Assign the Modbus address within the stated setting range.

Operating Guide ECL Comfort 310, application P330

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Factory setting
<input type="checkbox"/>	0 ... 15	15

This setting is relevant if more controllers are working in the same ECL Comfort system (connected via the ECL 485 communication bus) and / or Remote Control Units (ECA 30 / 31) are connected.

0: The controller works as slave.
The slave receives information about the outdoor temperature (S1), system time, and signal for DHW demand in the master.

1 ... 9: The controller works as slave.
The slave receives information about the outdoor temperature (S1), system time, and signal for DHW demand in the master. The slave sends information about the desired flow temperature to the master.

10 ... 14: Reserved.

15: The ECL 485 communication bus is active.
The controller is master. The master sends information about the outdoor temperature (S1) and system time. Connected Remote Control Units (ECA 30 / 31) are powered.



The total cable length of max. 200 m (all devices incl. the internal ECL 485 communication bus) should not be exceeded.
Cable lengths of more than 200 m may cause noise sensibility (EMC).



In a system with MASTER / SLAVE controllers, only one MASTER controller with address 15 is allowed.

If by mistake more MASTER controllers are present in an ECL 485 communication bus system, decide which controller is to be MASTER. Change the address in the remaining controllers. However, the system will operate but not be stable with more than one MASTER controller.



In the MASTER controller, the address in 'ECL 485 addr. (master / slave address); ID no. 2048, must always be 15.

The ECL Comfort controllers can be connected via the ECL 485 communication bus to perform a larger system (the ECL 485 communication bus can connect to max. 16 devices).

Each slave must be configured with its own address (1 ... 9).

However, more slaves can have the address 0 if they only have to receive information about outdoor temperature and system time (listeners).

Service Pin		2150
Circuit	Setting range	Factory setting
<input type="checkbox"/>	0 / 1	0

This setting is only used in connection with set-up of Modbus communication.

Not applicable for the time being and reserved for future use!

Ext. reset		2151
Circuit	Setting range	Factory setting
<input type="checkbox"/>	0 / 1	0

This setting is only used in connection with set-up of Modbus communication.

0: Reset not activated.

1: Reset.

6.8.11 Language

Language		2050
Circuit	Setting range	Factory setting
<input checked="" type="checkbox"/>	English / 'Local'	English
<i>Choose your language.</i>		



Local language is selected during installation. If you want to change to another local language, the application must be reinstalled. However, it is always possible to change between the local language and English.

7.0 Miscellaneous

7.1 ECA 30 / 31 setup procedures

ECA 30 (code no. 087H3200) is a remote control unit with built-in room temperature sensor.

ECA 31 (code no. 087H3201) is a remote control unit with built-in room temperature sensor and humidity sensor (relative humidity).

An external room temperature sensor can be connected to both types to substitute the built-in sensor.

An external room temperature sensor will be recognized at ECA 30 / 31 power-up.

Connections: See the section 'Electrical connections'!

Max. two ECA 30 / 31 can be connected to one ECL controller or a system (master-slave) consisting of several ECL controllers connected on the same ECL 485 bus. In the master-slave system only one of the ECL controllers is master. The ECA 30 / 31 can, among others, be set to:

- monitor and set the ECL controller remotely
- measure the room temperature and (ECA 31) humidity
- extend comfort / saving period temporarily

After application upload in the ECL Comfort controller, the remote control unit ECA 30 / 31 will after approx. one minute ask to 'Copy application'.

Confirm this in order to upload the application to the ECA 30 / 31.

Menu structure

The menu structure of ECA 30 / 31 is an "ECA MENU" and the ECL menu, copied from the ECL Comfort controller.

The ECA MENU contains:

- ECA settings
- ECA system
- ECA factory


ECA settings: Offset adjustment of the measured room temperature.

Offset adjustment of relative humidity (ECA 31 only).


ECA system: Display, communication, override settings and version info.

ECA factory: Erase of all applications in the ECA 30 / 31, restore to factory settings, reset of ECL address and firmware update.

Part of the ECA 30 / 31 display in ECL mode:



Part of the ECA 30 / 31 display in ECA mode:



If only the "ECA MENU" is shown, it can indicate that the ECA 30 / 31 is not having correct communication address.

See ECA MENU > ECA system > ECA communication: ECL address. In most cases the ECL address setting must be "15".



Regarding ECA settings:

When ECA 30 / 31 is not used as remote unit, the offset adjustments menu(s) are not present.

Operating Guide ECL Comfort 310, application P330

The ECL menus are as described for the ECL controller.

Most of the settings done directly in the ECL controller can be done via the ECA 30 / 31 too.




All settings can be seen even if the application key is not inserted in the ECL controller.
For changing settings, the application key must be inserted.

The Key overview (MENU > 'Common controller settings' > 'Key functions') does not show the applications of the key.



The ECA 30 / 31 will display this information (an X on the ECA 30 / 31 symbol) if the application in the ECL controller does not comply with the ECA 30 / 31:



In the example 1.10 is current version and 1.42 is desired version.



Display part of ECA 30 / 31:



This display indicates that an application has not been uploaded or the communication to the ECL controller (master) is not working properly. An X on the ECA controller symbol indicates wrong setup of communication addresses.



Display part of ECA 30 / 31:



Newer versions of ECA 30 / 31 indicate the address number of the connected ECL Comfort controller.
Address number can be changed in the ECA MENU.
A stand-alone ECL Controller has the address 15.

Operating Guide ECL Comfort 310, application P330

When ECA 30 / 31 is in ECA MENU mode, the date and measured room temperature is displayed.

ECA MENU > ECA settings > ECA sensor

Room T Offset	
Setting range	Factory setting
-10.0 ... 10.0 K	0.0 K
<i>The measured room temperature can be corrected with a number of Kelvin. The corrected value is used by the heating circuit in the ECL controller.</i>	

Minus value: The indicated room temperature is lower.

0.0 K: No correction of the measured room temperature.

Plus value: The indicated room temperature is higher.

Example:

Room T offset:	0.0 K
Displayed room temperature:	21.9 °C
Room T offset:	1.5 K
Displayed room temperature:	23.4 °C

ECA MENU > ECA settings > ECA sensor

RH offset (ECA 31 only)	
Setting range	Factory setting
-10.0 ... 10.0 %	0.0 %
<i>The measured relative humidity can be corrected with a number of %-values. The corrected value is used by the application in the ECL controller.</i>	

Minus value: The indicated relative humidity is lower.

0.0 %: No correction of the measured relative humidity.

Plus value: The indicated relative humidity is higher.

Example:

RH offset:	0.0 %
Displayed relative humidity:	43.4 %
RH offset:	3.5 %
Displayed relative humidity:	46.9 %

ECA MENU > ECA system > ECA display

Backlight (display brightness)	
Setting range	Factory setting
0 ... 10	5
<i>Adjust the brightness of the display.</i>	

0: Weak backlight.

10: Strong backlight.

Operating Guide ECL Comfort 310, application P330

ECA MENU > ECA system > ECA display

Contrast (display contrast)	
Setting range	Factory setting
0 ... 10	3
<i>Adjust the contrast of the display.</i>	

0: Low contrast.

10: High contrast.

ECA MENU > ECA system > ECA display

Use as remote	
Setting range	Factory setting
OFF / ON	*)
<i>ECA 30 / 31 can act as a simple or normal remote control for the ECL controller.</i>	



When set to OFF: The ECA menu shows date and time.

When set to ON: The ECA menu shows date and room temperature (and for ECA 31 relative humidity).

OFF: Simple remote control, no room temperature signal.

ON: Remote control, room temperature signal is available.

***):** Differently, depending on chosen application.

ECA MENU > ECA system > ECA communication

Slave addr. (Slave address)	
Setting range	Factory setting
A / B	A
<i>The setting of 'Slave addr.' is related to the setting 'ECA address' in the ECL controller.</i>	
<i>In the ECL controller it is selected from which ECA 30 / 31 unit the room temperature signal is received.</i>	



For installation of an application in an ECL Comfort 210 / 296 / 310 controller the 'Slave addr.' must be A.



If two ECA 30 / 31 are connected in the same ECL 485 bus system, the 'Slave addr.' must be "A" in the one ECA 30 / 31 unit and "B" in the other.

A: The ECA 30 / 31 has the address A.

B: The ECA 30 / 31 has the address B.

Operating Guide ECL Comfort 310, application P330

ECA MENU > ECA system > ECA communication

Connection addr. (Connection address)	
Setting range	Factory setting
1 ... 9 / 15	15
<i>Setting of the address to which ECL controller the communication must run.</i>	

1 .. 9: Slave controllers.

15: Master controller.



An ECA 30 / 31 can in an ECL 485 bus system (master – slave) be set to communicate, one by one, with all addressed ECL controllers.



Example:

Connection addr. = 15:	The ECA 30 / 31 communicates with the ECL master controller.
Connection addr. = 2:	The ECA 30 / 31 communicates with the ECL controller with address 2.



There must be a master controller present in order to broadcast time and date information.



An ECL Comfort controller 210 / 310, type B (without display and dial) cannot be assigned to the address 0 (zero).

ECA MENU > ECA system > ECA override

Override addr. (Override address)	
Setting range	Factory setting
OFF / 1 ... 9 / 15	OFF
<i>The feature 'Override' (to extended comfort or saving period or holiday) must be addressed to the ECL controller in question.</i>	

OFF: Override not possible.

1 .. 9: Address of slave controller for override.

15: Address of master controller for override.



Override functions:	Extended saving mode:	
	Extended comfort mode:	
	Holiday away from home:	
	Holiday at home:	



Override by means of settings in ECA 30 / 31 are cancelled if the ECL Comfort controller goes into holiday mode or is changed to another mode than scheduled mode.



The circuit in question for override in the ECL controller must be in scheduled mode.
See also the parameter 'Override circuit'.

Operating Guide ECL Comfort 310, application P330

ECA MENU > ECA system > ECA override

Override circuit	
Setting range	Factory setting
OFF / 1 ... 4	OFF
<i>The feature 'Override' (to extended comfort or saving period or holiday) must be addressed to the heating circuit in question.</i>	

OFF: No heating circuit is selected for override.

1 ... 4: The heating circuit number in question.



The circuit in question for override in the ECL controller must be in scheduled mode.
See also the parameter 'Override addr'.



Example 1:

(One ECL controller and one ECA 30 / 31)		
Override of heating circuit 2:	Set 'Connection addr.' to 15	Set 'Override circuit' to 2

Example 2:

(Several ECL controllers and one ECA 30 / 31)		
Override of heating circuit 1 in ECL controller with the address 6:	Set 'Connection addr.' to 6	Set 'Override circuit' to 1



Quick guide "ECA 30 / 31 to override mode":

1. Go to ECA MENU
2. Move cursor to "Clock" symbol
3. Select the "Clock" symbol
4. Choose and select one of 4 override functions
5. Below the override symbol: Set hours or date
6. Below hours / date: Set desired room temperature for the override period

ECA MENU > ECA system > ECA version

ECA version (read-out only), examples	
Code no.	087H3200
Hardware	A
Software	1.42
Build no.	5927
Serial no.	13579
Production week	23.2012



ECA 30 / 31:

<input type="checkbox"/> 15	Connection address (master: 15, slaves: 1 - 9)
-----------------------------	--

The ECA version information is useful in service situations.

Operating Guide ECL Comfort 310, application P330

ECA MENU > ECA factory > ECA clear apps.

Erase all apps. (Erase all applications)

*Erase all applications which are in the ECA 30 / 31.
After erasing, the application can be uploaded again.*

NO: The erase procedure is not done.

YES: The erase procedure is done (await 5 sec.).



After the erase procedure, a pop-up in the display indicates "Copy application". Choose "Yes".
Hereafter the application is uploaded from the ECL controller. An upload bar is shown.

ECA MENU > ECA factory > ECA default

Restore factory

The ECA 30 / 31 is set back to factory settings.

Affected settings by the restore procedure:

- Room T offset
- RH offset (ECA 31)
- Backlight
- Contrast
- Use as remote
- Slave addr.
- Connection addr.
- Override addr.
- Override circuit
- Override mode
- Override mode end time

NO: The restore procedure is not done.

YES: The restore procedure is done.

Operating Guide ECL Comfort 310, application P330

ECA MENU > ECA factory > Reset ECL addr.

Reset ECL addr. (Reset ECL address)

If none of the connected ECL Comfort controllers has the address 15, the ECA 30 / 31 can set all connected ECL controllers on the ECL 485 bus back to address 15.

NO: The reset procedure is not done.



The ECL 485 bus related address of the ECL controller is found: MENU > 'Common controller settings' > 'System' > 'Communication' > 'ECL 485 addr.'

YES: The reset procedure is done (await 10 sec.).



The "Reset ECL addr." cannot be activated if one or more of the connected ECL Comfort controllers has the address 15.



In a system with MASTER / SLAVE controllers, only one MASTER controller with address 15 is allowed.

If by mistake more MASTER controllers are present in an ECL 485 communication bus system, decide which controller is to be MASTER. Change the address in the remaining controllers. However, the system will operate but not be stable with more than one MASTER controller.

ECA MENU > ECA factory > Update firmware

Update firmware

The ECA 30 / 31 can be updated with new firmware (software). The firmware comes with the ECL application key, when the key version is at least 2.xx. If no new firmware is available, a symbol of the application key is displayed with an X.



The ECA 30 / 31 automatically verifies if a new firmware is present on the application key in the ECL Comfort controller. The ECA 30 / 31 is automatically updated at new application upload in the ECL Comfort controller.

The ECA 30 / 31 is not automatically updated when connected to an ECL Comfort controller with uploaded application. A manual update is always possible.

NO: The updating procedure is not done.



Quick guide "ECA 30 / 31 to override mode":

1. Go to ECA MENU
2. Move cursor to "Clock" symbol
3. Select the "Clock" symbol
4. Choose and select one of 4 override functions
5. Below the override symbol: Set hours or date
6. Below hours / date: Set desired room temperature for the override period

YES: The updating procedure is done.

7.2 Override function

The ECL 210 / 296 / 310 controllers can receive a signal in order to override the existing schedule. The override signal can be a switch or a relay contact.

Different override modes can be selected, depending on application key type.

Override modes: Comfort, Saving, Constant temperature and Frost protection.

"Comfort" is also called normal heating temperature.


"Saving" can be reduced heating or heating stopped.

"Constant temperature" is a desired flow temperature, set in the menu "Flow temperature".


"Frost protection" stops the heating totally.

Override by means of override switch or relay contact is possible when the ECL 210 / 296 / 310 is in scheduled mode (clock).

Example, override switch connected to S8:



Example, override relay connected to S8:



Example 1

ECL in Saving mode, but in Comfort mode at override.


Choose an unused input, for example S8. Connect the override switch or override relay contact.

Settings in ECL:

1. Select circuit > MENU > Settings > Application > Ext. input:
Select the input S8 (the wiring example)
2. Select circuit > MENU > Settings > Application > Ext. mode:
Select COMFORT
3. Select circuit > MENU > Schedule:
Select all weekdays
Set "Start1" to 24.00 (this disables Comfort mode)
Exit menu and confirm by "Save"
4. Remember to set the circuit in question in scheduled mode ("clock").

Result: When the override switch (or the relay contact) is ON, the ECL 210 / 296 / 310 will operate in Comfort mode.

When the override switch (or the relay contact) is OFF, the ECL 210 / 296 / 310 will operate in Saving mode.



Example 2

ECL in Comfort mode, but in Saving mode at override.


Choose an unused input, for example S8. Connect the override switch or override relay contact.

Settings in ECL:

1. Select circuit > MENU > Settings > Application > Ext. input:
Select the input S8 (the wiring example)
2. Select circuit > MENU > Settings > Application > Ext. mode:
Select SAVING
3. Select circuit > MENU > Schedule:
Select all weekdays
Set "Start1" to 00.00
Set "Stop1" to 24.00
Exit menu and confirm by "Save"
4. Remember to set the circuit in question in scheduled mode ("clock").

Result: When the override switch (or the relay contact) is ON, the ECL 210 / 296 / 310 will operate in Saving mode.

When the override switch (or the relay contact) is OFF, the ECL 210 / 296 / 310 will operate in Comfort mode.



Operating Guide ECL Comfort 310, application P330

Example 3

The week schedule for the building is set with comfort periods Monday - Friday: 07.00 - 17.30. Sometimes, a team meeting takes place in the evening or in the week-end.

An override switch is installed and heating must be ON (Comfort mode) as long as the switch is ON.


Choose an unused input, for example S8. Connect the override switch.

Settings in ECL:

1. Select circuit > MENU > Settings > Application > Ext. input:
Select the input S8 (the wiring example)
2. Select circuit > MENU > Settings > Application > Ext. mode:
Select COMFORT
3. Remember to set the circuit in question in scheduled mode ("clock").

Result: When the override switch (or a relay contact) is ON, the ECL 210 / 296 / 310 will operate in Comfort mode.

When the override switch is OFF, the ECL 210 / 296 / 310 will operate according to the schedule.



Example 4

The week schedule for the building is set with comfort periods all weekdays: 06.00 - 20.00. Sometimes, the desired flow temperature must be constant on 65 °C.

An override relay is installed and the flow temperature must be 65 °C as long as the override relay is activated.


Choose an unused input, for example S8. Connect the contacts of the override relay.

Settings in ECL:

1. Select circuit > MENU > Settings > Application > Ext. input:
Select the input S8 (the wiring example)
2. Select circuit > MENU > Settings > Application > Ext. mode:
Select CONST. T
3. Select circuit > MENU > Settings > Flow temperature >
Desired T (ID 1x004):
Set to 65 °C
4. Remember to set the circuit in question in scheduled mode ("clock").

Result: When the override relay is activated, the ECL 210 / 296 / 310 will operate in Const. temp. mode and control a flow temperature of 65 °C.

When the override relay is not activated, the ECL 210 / 296 / 310 will operate according to the schedule.




7.3 Several controllers in the same system

When ECL Comfort controllers are interconnected by means of the ECL 485 communication bus (cable type: 2 x twisted pair), the master controller will broadcast the following signals to the slave controllers:

- Outdoor temperature (measured by S1)
- Time and date
- DHW tank heating / charging activity

Furthermore, the master controller can receive information about:

- the desired flow temperature (demand) from slave controllers
- and (as from ECL controller version 1.48) DHW tank heating / charging activity in slave controllers



Situation 1:

SLAVE controllers: How to make use of the outdoor temperature signal sent from the MASTER controller

The slave controllers only receive information about outdoor temperature and date / time.

SLAVE controllers:

Change the factory set address from 15 to address 0.

- In go to System > Communication > ECL 485 addr.

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Choose
	0 ... 15	0



ECL 485 bus cable

Maximum recommended length of the ECL 485 bus is calculated like this:

Subtract "Total length of all input cables of all ECL controllers in the master - slave system" from 200 m.

Simple example for total length of all input cables, 3 x ECL:

1 x ECL	Outdoor temp. sensor:	15 m
3 x ECL	Flow temp. sensor:	18 m
3 x ECL	Return temp. sensor:	18 m
3 x ECL	Room temp. sensor:	30 m
Total:		81 m

Maximum recommended length of the ECL 485 bus:
200 - 81 m = 119 m



In a system with MASTER / SLAVE controllers, only one MASTER controller with address 15 is allowed.

If by mistake more MASTER controllers are present in an ECL 485 communication bus system, decide which controller is to be MASTER. Change the address in the remaining controllers. However, the system will operate but not be stable with more than one MASTER controller.



In the MASTER controller, the address in 'ECL 485 addr. (master / slave address)', ID no. 2048, must always be 15.

Navigation:

- In go to System > Communication > ECL 485 addr.

SLAVE controllers must be set to another address than 15:
Navigation:

- In go to System > Communication > ECL 485 addr.



'Demand offset' with a value is to be used in the Master controller only.

Operating Guide ECL Comfort 310, application P330

Situation 2:

SLAVE controller: How to react on a DHW tank heating / charging activity sent from the MASTER controller

The slave receives information about a DHW tank heating / charging activity in the master controller and can be set to close the selected heating circuit.

ECL controller versions 1.48 (as from August 2013):

The master receives information about DHW tank heating / charging activity in the master controller itself and also slaves in the system.

This status is broadcasted to all ECL controllers in the system and each heating circuit can be set to close the heating.

SLAVE controller:

Set the desired function:

- In circuit 1 / circuit 2, go to 'Settings' > 'Application' >'DHW priority':

DHW priority (closed valve / normal operation)		11052 / 12052
Circuit	Setting range	Choose
1 / 2	OFF / ON	OFF / ON

OFF: The flow temperature control remains unchanged during active DHW heating / charging in the master / slave system.

ON: The valve in the heating circuit is closed during active DHW heating / charging in the master / slave system.

Operating Guide ECL Comfort 310, application P330

Situation 3:

SLAVE controller: How to make use of the outdoor temperature signal and send information about the desired flow temperature back to the MASTER controller



In the MASTER controller, the address in 'ECL 485 addr. (master / slave address)', ID no. 2048, must always be 15.

The slave controller receives information about outdoor temperature and date / time. The master controller receives information about the desired flow temperature from slave controllers with an address from 1 ... 9:

SLAVE controller:

- In  go to System > Communication > ECL 485 addr.
- Change the factory set address from 15 to an address (1 ... 9). Each slave must be configured with its own address.

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Choose
	0 ... 15	1 ... 9

Furthermore, each slave can send information about the desired flow temperature (demand) in each circuit back to the master controller.

SLAVE controller:

- In the circuit in question, go to Settings > Application > Send desired T
- Choose ON or OFF.

Send desired T		11500 / 12500
Circuit	Setting range	Choose
1 / 2	OFF / ON	ON or OFF

OFF: Information about the desired flow temperature is not sent to the master controller.

ON: Information about the desired flow temperature is sent to the master controller.

7.4 Frequently asked questions



The definitions apply to the ECL Comfort 210 / 296 / 310 series. Consequently, you might come across expressions that are not mentioned in your guide.

Circulation pump (heating) does not stop as expected

It is in operation at frost protection (outdoor temperature lower than "P frost T" value) and at heat demand (desired flow temperature higher than "P heat T" value)

The time shown in the display is one hour off?

See 'Time and Date'.

The time shown in the display is not correct?

The internal clock may have been reset, if there has been a power break for more than 72 hours.

Go to the 'Common controller settings' and 'Time & Date' to set the correct time.

The ECL Application Key is lost?

Switch the power off and on again to see the ECL controller type, version code (e.g. 1.52), code no. and application (e.g. A266.1) or go to 'Common controller settings' >'Key functions' > 'Application'. The system type (e.g. TYPE A266.1) and the system diagram is displayed.

Order a replacement from your Danfoss representative (e.g. ECL Application Key A266).

Insert the new ECL Application Key and copy your personal settings from the controller to the new ECL Application Key, if required.

The room temperature is too low?

Make sure that the radiator thermostat does not limit the room temperature.

If you still cannot obtain the desired room temperature by adjusting the radiator thermostats, the flow temperature is too low. Increase the desired room temperature (display with desired room temperature). If this does not help, adjust the 'Heat curve' ('Flow temp.').

The room temperature is too high during saving periods?

Make sure that the min. flow temperature limitation ('Temp. min.') is not too high.

The temperature is unstable?

Check that the flow temperature sensor is correctly connected and in the right place. Adjust the control parameters ('Control par.').

If the controller has a room temperature signal, see 'Room limit'.

The controller does not operate and the control valve is closed?

Check that the flow temperature sensor is measuring the correct value, see 'Daily use' or 'Input overview'.

Check the influence from other measured temperatures.

How to make an extra comfort period in the schedule?

You can set an additional comfort period by adding new 'Start' and 'Stop' times in 'Schedule'.

How to remove a comfort period in the schedule?

You can remove a comfort period by setting start and stop times to the same value.

How to restore your personal settings?

Please read the chapter concerning 'Inserting the ECL Application Key'.

How to restore the factory settings?

Please read the chapter concerning 'Inserting the ECL Application Key'.

Why can't the settings be changed?

The ECL Application Key has been removed.

Why can't an application be selected when inserting the ECL application key into the controller?

The actual application in the ECL Comfort controller must be deleted before a new application (subtype) can be selected.

How to react on alarms?

An alarm indicates that the system is not operating satisfactorily. Please contact your installer.

What does P and PI control mean?

P control: Proportional control.

By using a P control, the controller will change the flow temperature proportional to the difference between a desired and an actual temperature, e.g. a room temperature.

A P control will always have an offset which not will disappear over time.

PI control: Proportional and Integrating control.

A PI control does the same as a P control, but the offset will disappear over time.

A long 'Tn' will give a slow but stable control, and a short 'Tn' will result in a fast control but with a higher risk of instability.

What does the "i" in the upper right corner of the display mean?

When uploading an application (subtype) from the application key into the ECL Comfort controller, the "i" in the upper right corner indicates that - besides the factory settings - the subtype also contains special user / systems settings.

Why can't the ECL 485 Bus (used in ECL 210 / 296 / 310) and the ECL Bus (used in ECL 100 / 110 / 200 / 300) communicate?

These two communication busses (Danfoss proprietary) are different in connection form, telegram form and speed.

Why can't I select a language when uploading an application?

Reason can be that the ECL 310 is powered with 24 Volt d.c.

Language

At application upload, a language must be selected.*

If another language than English is selected, the selected language **AND** English will be uploaded into the ECL controller.

This makes service easy for English speaking service people, just because the English language menus can be visible by changing the actual set language into English.

(Navigation: MENU > Common controller > System > Language)

If the uploaded language is not suitable, the application must be erased. User and System settings can be saved on the application key before erasing.

After new upload with preferred language, the existing User and System settings can be uploaded.

*)

(ECL Comfort 310, 24 Volt) If language cannot be selected, the power supply is not a.c. (alternating current).

How to set a correct heat curve?

Short answer:

Set the heat curve to the lowest possible value, but still having comfortable room temperature.


The table shows some recommendations:

House with radiators:	Needed flow temp. when the outdoor temp. is -10 °C:	Recommended heat curve value:
Older than 20 years:	65 °C	1.4
Between 10 and 20 years old:	60 °C	1.2
Rather new:	50 °C	0.8
Floor heating systems need, in general, a lower heat curve value		

Technical answer:

In order to save energy, the flow temperature should be as low as possible, but still considering a comfortable room temperature. This means the heat curve slope should have a low value.

See the heat curve slope diagram.



Choose the desired flow temperature (vertical axis) for your heating system at the expected lowest outdoor temperature (horizontal axis) for your area. Pick the heat curve closest to the common point of these two values.

Example: Desired flow temperature: 60 (°C) at outdoor temperature: -10 (°C)

Result: Heat curve slope value = 1.2 (mid-way between 1.4 and 1.0).

In general:

- Smaller radiators in your heating system might require a higher heat curve slope. (Example: Desired flow temperature 70 °C resulting in heat curve = 1.5).
- Floor heating systems require a lower heat curve slope. (Example: Desired flow temperature 35 °C resulting in heat curve = 0.4).
- Corrections of the heat curve slope should be done in small steps when having outdoor temperatures below 0 °C; one step pr. day.
- If required, adjust the heat curve in the six coordinate points.
- Setting of the desired **room** temperature has an influence on the desired flow temperature even if a room temperature sensor / Remote Control Unit is not connected. An example: Increasing the desired **room** temperature results in a higher flow temperature.
- Typically, the desired **room** temperature should be adjusted when having outdoor temperatures above 0 °C.

7.5 Definitions



The definitions apply to the ECL Comfort 210 / 296 / 310 series. Consequently, you might come across expressions that are not mentioned in your guide.

Accumulated temperature value

A filtered (damped) value, typically for room and outdoor temperatures. Is calculated in the ECL controller and is used to express the heat stored in the walls of the house. The accumulated value does not change so rapidly as the actual temperature.

Air duct temperature

Temperature measured in the air duct where the temperature is to be controlled.

Alarm function

Based on the alarm settings, the controller can activate an output.

Anti-bacteria function

For a defined period, the DHW temperature is increased in order to neutralize dangerous bacteria, e.g. Legionella.

Balance temperature

This setpoint is the basis for the flow / air duct temperature. The balance temperature can be adjusted by the room temperature, the compensation temperature and the return temperature. The balance temperature is only active if a room temperature sensor is connected.

BMS

Building Management System. A supervisory system for remote control and monitoring.

Comfort operation

Normal temperature in the system controlled by the schedule. During heating the flow temperature in the system is higher to maintain the desired room temperature. During cooling the flow temperature in the system is lower to maintain the desired room temperature.

Comfort temperature

Temperature maintained in the circuits during comfort periods. Normally during daytime.

Compensation temperature

A measured temperature influencing the flow temperature reference / balance temperature.

Desired flow temperature

Temperature calculated by the controller on basis of the outdoor temperature and influences from the room and / or return temperatures. This temperature is used as a reference for the control.

Desired room temperature

Temperature which is set as the desired room temperature. The temperature can only be controlled by the ECL Comfort controller if a room temperature sensor is installed. If a sensor is not installed, the set desired room temperature however still influences the flow temperature. In both cases the room temperature in each room is typically controlled by radiator thermostats / valves.

Desired temperature

Temperature based on a setting or a controller calculation.

Dew point temperature

Temperature at which the humidity in the air condenses.

DHW circuit

The circuit for heating the domestic hot water (DHW).

Duct temperature

Temperature measured in the air duct where the temperature is to be controlled.

ECL 485 Bus

This communication bus is Danfoss proprietary and used for internal communication between ECL 210, ECL 210B, ECL 296, ECL 310, ECL 310B, ECA 30 and ECA 31.

Communication with "ECL Bus", used in ECL 100, ECL 110, ECL 200, ECL 300 and ECL 301, is not possible.

ECL Portal

A supervisory system for remote control and monitoring, locally and via Internet.

EMS

Energy Management System. A supervisory system for remote control and monitoring.

Factory settings

Settings stored on the ECL Application Key to simplify the set up of your controller the first time.

Firmware

is used by the ECL Comfort controller and ECA 30 / 31 to manage display, dial and program execution.

Flow temperature

Temperature measured in the water flow where the temperature is to be controlled.

Flow temperature reference

Temperature calculated by the controller on basis of the outdoor temperature and influences from the room and / or return temperatures. This temperature is used as a reference for the control.

Heat curve

A curve showing the relationship between actual outdoor temperature and desired flow temperature.

Heating circuit

The circuit for heating the room / building.

Holiday schedule

Selected days can be programmed to be in comfort, saving or frost protection mode. Besides this, a day schedule with comfort period from 07.00 to 23.00 can be selected.

Humidistat

A device, which reacts on the air's humidity. A switch can go ON if the measured humidity gets above a set point.

Humidity, relative

This value (stated in %) refers to the indoor moisture content compared to the max. moisture content. The relative humidity is measured by the ECA 31 and is used for the calculation of the dew point temperature.

Inlet temperature

Temperature measured in the inlet air flow where the temperature is to be controlled.

Limitation temperature

Temperature that influences the desired flow / balance temperature.

Log function

The temperature history is displayed.

Master / slave

Two or more controllers are interconnected on the same bus, the master sends out e.g. time, date and outdoor temperature. The slave receives data from master and sends e.g. desired flow temperature value.

Modulating control (0 - 10 V control)

Positioning (by means of a 0 - 10 V control signal) of the actuator for the motorized control valve in order to control the flow.

Optimization

The controller optimizes the start time of the scheduled temperature periods. Based on the outdoor temperature, the controller automatically calculates when to start in order to reach the comfort temperature at the set time. The lower the outdoor temperature, the earlier the start time.

Outdoor temperature trend

The arrow indicates the tendency, i.e. whether the temperature rises or falls.

Override mode

When ECL Comfort is in Scheduled mode, a switch or contact signal can be applied to an input in order to override to Comfort, Saving, Frost protection or Constant temperature. As long as the switch or contact signal is applied, the override is active.

Pt 1000 sensor

All sensors used with the ECL Comfort controller are based on the Pt 1000 type (IEC 751B). The resistance is 1000 ohm at 0 °C and it changes with 3.9 ohm / degree.

Pump control

One circulation pump is working and the other is the spare circulation pump. After a set time, the roles are exchanged.

Refill water function

If the measured pressure in the heating system is too low (e.g. due to a leakage), water can be supplemented.

Return temperature

The temperature measured in the return influences the desired flow temperature.

Room temperature

Temperature measured by the room temperature sensor or the Remote Control Unit. The room temperature can only be controlled directly if a sensor is installed. The room temperature influences the desired flow temperature.

Room temperature sensor

Temperature sensor placed in the room (reference room, typically the living room) where the temperature is to be controlled.

Saving temperature

Temperature maintained in the heating / DHW circuit during saving temperature periods. Typically, the Saving temperature is lower than the Comfort temperature in order to save energy.

SCADA

Supervisory Control And Data Acquisition. A supervisory system for remote control and monitoring.

Schedule

Schedule for periods with comfort and saving temperatures. The schedule can be made individually for each week day and may consist of up to 3 comfort periods per day.

Software

is used in the ECL Comfort controller to do the application related processes.

Weather compensation

Flow temperature control based on the outdoor temperature. The control is related to a user-defined heat curve.

2-point control

ON / OFF control, e.g. circulation pump, ON / OFF valve, change-over valve or damper control.

3-point control

Actuator positioning by means of Opening, Closing or No-action signals for the motorized control valve in order to control the flow. No-action means that the actuator remains in its current position.

7.6 Type (ID 6001), overview

	Type 0	Type 1	Type 2	Type 3	Type 4
Address	✓	✓	✓	✓	✓
Type	✓	✓	✓	✓	✓
Scan time	✓	✓	✓	✓	✓
ID / Serial	✓	✓	✓	✓	✓
Reserved	✓	✓	✓	✓	✓
Flow temp. [0.01 °C]	✓	✓	✓	✓	-
Return temp. [0.01 °C]	✓	✓	✓	✓	-
Flow [0.1 l/h]	✓	✓	✓	✓	-
Power [0.1 kW]	✓	✓	✓	✓	-
Acc. Volume	[0.1 m3]	[0.1 m3]	[0.1 m3]	[0.1 m3]	-
Acc. Energy	[0.1 kWh]	[0.1 MWh]	[0.1 kWh]	[0.1 MWh]	-
Tariff1 Acc. Energy	-	-	[0.1 kWh]	[0.1 MWh]	-
Tariff2 Acc. Energy	-	-	[0.1 kWh]	[0.1 MWh]	-
Up time [days]	-	-	✓	✓	-
Current time [M-bus defined structure]	-	-	✓	✓	✓
Error status [energy meter defined bitmask]	-	-	✓	✓	-
Acc. Volume	-	-	-	-	[0.1 m3]
Acc. Energy	-	-	-	-	[0.1 kWh]
Acc. Volume2	-	-	-	-	[0.1 m3]
Acc. Energy2	-	-	-	-	[0.1 kWh]
Acc. Volume3	-	-	-	-	[0.1 m3]
Acc. Energy3	-	-	-	-	[0.1 kWh]
Acc. Volume4	-	-	-	-	[0.1 m3]
Acc. Energy4	-	-	-	-	[0.1 kWh]
Flow MAX	[0.1 l/h]	[0.1 l/h]	[0.1 l/h]	[0.1 l/h]	-
Power MAX	[0.1 kW]	[0.1 kW]	[0.1 kW]	[0.1 kW]	-
Max T forward	✓	✓	✓	✓	-
Max T return	✓	✓	✓	✓	-
Storage * Acc. Energy	[0.1 kWh]	[0.1 kWh]	[0.1 kWh]	[0.1 kWh]	-

7.7 Automatic / manual update of firmware

Info:

- Firmware and application software are on the application key
- ECL Comfort has firmware implemented
- Firmware with Encryption has version 2.00 and up

Situation 1:

ECL Comfort controller, new (= no application installed), from before 10th of July 2018, to be installed:

1. Insert application key.
2. If the firmware on application key is newer than the firmware in the ECL, an update will be done automatically.
3. Hereafter the application can be uploaded.
4. If the firmware in the ECL is newer than the firmware on application key, the application can be uploaded.

Situation 2:

ECL Comfort controller is installed and runs an application.

1. Store all settings on the existing application key *.
2. Erase actual application in the ECL **.
3. Insert an application key with new firmware. The firmware update will be done automatically.
4. When ECL requires language selection, then remove application key.
5. Insert "old" application key.
6. Select language, select application subtype and see an "i" in upper right corner.
7. Set time / date if needed.
8. Choose "Next".
9. In Copy menu, choose YES at System and User settings; then choose "Next".
10. "Old" application is uploaded, ECL restarts and is ready again.

* Navigation: MENU > Common controller settings > Key functions > Copy > "To KEY", System settings = YES, User settings = YES, Start copying: Push dial.
Within 1 sec the settings are stored on the application key.

** Navigation: MENU > Common controller settings > Key functions > New application > Erase application: Push dial.

NOTE: You might come in a situation where the update will not elapse. This is typically when one or two ECA 30 are connected.

Remedy: Disconnect (remove from its base) the ECA 30. If ECL 310B, then only one ECA 30 should be connected.

7.8 Parameter ID overview

P330.x — x refers to the subtypes listed in the column.

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
11010	ECA addr.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; A ; B	OFF			93
11011	Auto saving	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, -29 ... 10	-15	°C		85
11012	Boost	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 99	OFF	%		85
11013	Ramp	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 99	OFF	Min		86
11014	Optimizer	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 10 ... 59	OFF			86
11015	Adapt. time	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 50	OFF	Sec		76
11017	Demand offset	1, 2, 3, 4, 5	OFF, 1 ... 20	OFF	K		93
11020	Based on	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OUT ; ROOM	OUT			87
11021	Total stop	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	OFF			87
11022	P exercise	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	ON			93
11023	M exercise	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	OFF			93
11026	Pre-stop	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	ON			88
11029	DHW, ret. T limit	1, 2, 3, 4, 5	OFF, 10 ... 110	OFF	°C		78
11031	High T out X1	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-60 ... 20	15	°C		78
11032	Low limit Y1	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 150	40	°C		78
11033	Low T out X2	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-60 ... 20	-15	°C		79
11034	High limit Y2	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 150	60	°C		79
11035	Infl. - max.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-9.9 ... 9.9	-2.0			79
11036	Infl. - min.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-9.9 ... 9.9	0.0			80
11037	Adapt. time	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 50	25	Sec		80
11040	P post-run	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	0 ... 99	3	Min		94
11050	P demand	1, 2, 3, 4, 5	OFF ; ON	OFF			94
11052	DHW priority	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON ; STOP	OFF			94
11077	P frost T	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, -10 ... 20	2	°C		95
11078	P heat T	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	5 ... 40	20	°C		95

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
11085	Priority	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	OFF			81
11093	Frost pr. T	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	5 ... 40	10	°C		
11109	Input type	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	EM1 ; EM2 ; EM3 ; EM4 ; EM5 ; OFF	OFF			82
11112	Adapt. time	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 50	OFF	Sec		83
11113	Filter constant	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	1 ... 50	10			83
11115	Units	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	ml, l/h ; l, l/h ; ml, m ³ /h ; l, m ³ /h ; Wh, kW ; kWh, kW ; kWh, MW ; MW, MW ; MWh, GW ; GWh, GW	ml, l/h			83
11116	High limit Y2	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	0.0 ... 999.9	999.9			83
11117	Low limit Y1	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	0.0 ... 999.9	999.9			83
11118	Low T out X2	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-60 ... 20	-15	°C		84
11119	High T out X1	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-60 ... 20	15	°C		84
11141	Ext. input	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10 ; S11 ; S12 ; S13 ; S14 ; S15 ; S16	OFF			95
11142	Ext. mode	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	COMFORT ; SAVING ; FROST PR.	COMFORT			96
11147	Upper difference	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 30	OFF	K		108
11148	Lower difference	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 30	OFF	K		108
11149	Delay	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	1 ... 99	10	Min		108
11150	Lowest temp.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 50	30	°C		108
11174	Motor pr.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 10 ... 59	OFF	Min		90
11177	Temp. min.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 150	10	°C		74
11178	Temp. max.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 150	90	°C		74
11179	Summer, cut-out	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 50	20	°C		88
11182	Infl. - max.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-9.9 ... 0.0	-4.0			76
11183	Infl. - min.	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	0.0 ... 9.9	0.0			77

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
11184	Xp	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	5 ... 250	80	K		90
11185	Tn	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	1 ... 999	30	Sec		90
11186	M run	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	5 ... 250	30	Sec		90
11187	Nz	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	1 ... 9	3	K		91
11189	Min. act. time	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	2 ... 50	10			91
11500	Send desired T	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	ON			
11609	Low Y	1, 2, 3, 4, 5	10 ... 120	10	°C		
11610	High Y	1, 2, 3, 4, 5	10 ... 120	100	°C		
12010	ECA addr.	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF ; A ; B	OFF			93
12011	Auto saving	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF, -29 ... 10	-15	°C		85
12012	Boost	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF, 1 ... 99	OFF	%		85
12013	Ramp	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF, 1 ... 99	OFF	Min		86
12014	Optimizer	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF, 10 ... 59	OFF			86
12015	Adapt. time	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF, 1 ... 50	OFF	Sec		76
12020	Based on	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OUT ; ROOM	OUT			87
12021	Total stop	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF ; ON	OFF			87
12022	P exercise	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF ; ON	ON			93
12023	M exercise	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF ; ON	OFF			93
12026	Pre-stop	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF ; ON	ON			88
12030	Limit	9, 10	10 ... 110	40	°C		
12031	High T out X1	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	-60 ... 20	15	°C		78
12032	Low limit Y1	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	10 ... 150	40	°C		78
12033	Low T out X2	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	-60 ... 20	-15	°C		79
12034	High limit Y2	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	10 ... 150	60	°C		79
12035	Infl. - max.	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	-9.9 ... 9.9	-2.0			79
12036	Infl. - min.	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	-9.9 ... 9.9	0.0			80
12037	Adapt. time	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	OFF, 1 ... 50	25	Sec		80

Operating Guide ECL Comfort 310, application P330

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
12040	P post-run	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	0 ... 99	3	Min		94
12041	DHW P post-run	9, 10, 15	0 ... 30	0	Min		100
12042	Char. P post-run	9, 10, 15	0 ... 30	1	Min		100
12052	DHW priority	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF ; ON ; STOP	OFF			94
12054	Cont. T control	9, 10, 15	OFF ; ON	OFF			100
12055	Circ. P priority	9, 10, 15	OFF ; ON	OFF			100
12076	Circ. P frost T	9, 10, 15	OFF, -10 ... 20	OFF	°C		100
12077	P frost T	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF, -10 ... 20	2	°C		95
12078	P heat T	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	5 ... 40	20	°C		95
12085	Priority	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF ; ON	OFF			81
12093	Frost pr. T	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14, 15	5 ... 40	10	°C		
12109	Input type	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	EM1 ; EM2 ; EM3 ; EM4 ; EM5 ; OFF	OFF			82
12111	Limit	9, 10	0.0 ... 999.9	999.9			82
12112	Adapt. time	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	OFF, 1 ... 50	OFF	Sec		83
12113	Filter constant	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	1 ... 50	10			83
12115	Units	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	ml, l/h ; l, l/h ; ml, m ³ /h ; l, m ³ /h ; Wh, kW ; kWh, kW ; kWh, MW ; MWh, MW ; MWh, GW ; GWh, GW	ml, l/h			83
12116	High limit Y2	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	0.0 ... 999.9	999.9			83
12117	Low limit Y1	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	0.0 ... 999.9	999.9			83
12118	Low T out X2	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	-60 ... 20	-15	°C		84
12119	High T out X1	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	-60 ... 20	15	°C		84
12122	Day:	9, 10, 15	0 ... 127	0			
12123	Start time	9, 10, 15	0 ... 47	0			
12124	Duration	9, 10, 15	10 ... 600	120	Min		
12125	Desired T	9, 10, 15	OFF, 10 ... 110	OFF	°C		
12141	Ext. input	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10 ; S11 ; S12 ; S13 ; S14 ; S15 ; S16	OFF			95
12142	Ext. mode	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14, 15	COMFORT ; SAVING ; FROST PR.	COMFORT			96

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
12147	Upper difference	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	OFF, 1 ... 30	OFF	K		108
12148	Lower difference	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	OFF, 1 ... 30	OFF	K		108
12149	Delay	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	1 ... 99	10	Min		108
12150	Lowest temp.	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	10 ... 50	30	°C		108
12152	Max. charge T	9, 10, 15	10 ... 110	80	°C		101
12174	Motor pr.	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	OFF, 10 ... 59	OFF	Min		90
12177	Temp. min.	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	10 ... 150	10	°C		74
12178	Temp. max.	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	10 ... 150	90	°C		74
12179	Summer, cut-out	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	OFF, 1 ... 50	20	°C		88
12182	Infl. - max.	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	-9.9 ... 0.0	-4.0			76
12183	Infl. - min.	1, 2, 3, 4, 5, 7, 8, 11, 12, 13, 14	0.0 ... 9.9	0.0			77
12184	Xp	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	5 ... 250	80	K		90
12185	Tn	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	1 ... 999	30	Sec		90
12186	M run	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	5 ... 250	30	Sec		90
12187	Nz	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	1 ... 9	3	K		91
12189	Min. act. time	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14	2 ... 50	10			91
12193	Charge difference	9, 10, 15	1 ... 50	15	K		102
12194	Stop difference	9, 10, 15	-50 ... 50	3	K		102
12195	Start difference	9, 10, 15	-50 ... -1	-3	K		103
12500	Send desired T	1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	ON			
13010	ECA addr.	2, 3, 5, 8, 12	OFF ; A ; B	OFF			93
13011	Auto saving	2, 3, 5, 8, 12	OFF, -29 ... 10	-15	°C		85
13012	Boost	2, 3, 5, 8, 12	OFF, 1 ... 99	OFF	%		85
13013	Ramp	2, 3, 5, 8, 12	OFF, 1 ... 99	OFF	Min		86
13014	Optimizer	2, 3, 5, 8, 12	OFF, 10 ... 59	OFF			86
13015	Adapt. time	2, 3, 5, 8, 12	OFF, 1 ... 50	OFF	Sec		76
13020	Based on	2, 3, 5, 8, 12	OUT ; ROOM	OUT			87
13021	Total stop	2, 3, 5, 8, 12	OFF ; ON	OFF			87
13022	P exercise	2, 3, 5, 8, 12	OFF ; ON	ON			93
13023	M exercise	2, 3, 5, 8, 12	OFF ; ON	OFF			93
13026	Pre-stop	2, 3, 5, 8, 12	OFF ; ON	ON			88
13030	Limit	4	10 ... 110	40	°C		

Operating Guide ECL Comfort 310, application P330

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
13031	High T out X1	2, 3, 5, 8, 12	-60 ... 20	15	°C		78
13032	Low limit Y1	2, 3, 5, 8, 12	10 ... 150	40	°C		78
13033	Low T out X2	2, 3, 5, 8, 12	-60 ... 20	-15	°C		79
13034	High limit Y2	2, 3, 5, 8, 12	10 ... 150	60	°C		79
13035	Infl. - max.	2, 3, 4, 5, 8, 12	-9.9 ... 9.9	-2.0			79
13036	Infl. - min.	2, 3, 4, 5, 8, 12	-9.9 ... 9.9	0.0			80
13037	Adapt. time	2, 3, 4, 5, 8, 12	OFF, 1 ... 50	25	Sec		80
13040	P post-run	2, 3, 5, 8, 12	0 ... 99	3	Min		94
13041	DHW P post-run	4, 10, 11, 13, 14	0 ... 30	0	Min		100
13042	Char. P post-run	4, 10, 11, 13, 14	0 ... 30	1	Min		100
13052	DHW priority	2, 3, 5, 8, 12	OFF ; ON ; STOP	OFF			94
13054	Cont. T control	4, 10, 11, 13, 14	OFF ; ON	OFF			100
13055	Circ. P priority	4, 10, 11, 13, 14	OFF ; ON	OFF			100
13076	Circ. P frost T	4, 10, 11, 13, 14	OFF, -10 ... 20	OFF	°C		100
13077	P frost T	2, 3, 5, 8, 12	OFF, -10 ... 20	2	°C		95
13078	P heat T	2, 3, 5, 8, 12	5 ... 40	20	°C		95
13085	Priority	2, 3, 5, 8, 12	OFF ; ON	OFF			81
13093	Frost pr. T	2, 3, 4, 5, 8, 10, 11, 12, 13, 14	5 ... 40	10	°C		
13109	Input type	2, 3, 4, 5, 8, 12	EM1 ; EM2 ; EM3 ; EM4 ; EM5 ; OFF	OFF			82
13111	Limit	4	0.0 ... 999.9	999.9			82
13112	Adapt. time	2, 3, 4, 5, 8, 12	OFF, 1 ... 50	OFF	Sec		83
13113	Filter constant	2, 3, 4, 5, 8, 12	1 ... 50	10			83
13115	Units	2, 3, 4, 5, 8, 12	ml, l/h ; l, l/h ; ml, m ³ /h ; l, m ³ /h ; Wh, kW ; kWh, kW ; kWh, MW ; MWh, MW ; MWh, GW ; GWh, GW	ml, l/h			83
13116	High limit Y2	2, 3, 5, 8, 12	0.0 ... 999.9	999.9			83
13117	Low limit Y1	2, 3, 5, 8, 12	0.0 ... 999.9	999.9			83
13118	Low T out X2	2, 3, 5, 8, 12	-60 ... 20	-15	°C		84
13119	High T out X1	2, 3, 5, 8, 12	-60 ... 20	15	°C		84
13122	Day:	4, 10, 11, 13, 14	0 ... 127	0			
13123	Start time	4, 10, 11, 13, 14	0 ... 47	0			
13124	Duration	4, 10, 11, 13, 14	10 ... 600	120	Min		
13125	Desired T	4, 10, 11, 13, 14	OFF, 10 ... 110	OFF	°C		
13141	Ext. input	2, 3, 4, 5, 8, 10, 11, 12, 13, 14	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10 ; S11 ; S12 ; S13 ; S14 ; S15 ; S16	OFF			95
13142	Ext. mode	2, 3, 4, 5, 8, 10, 11, 12, 13, 14	COMFORT ; SAVING ; FROST PR.	COMFORT			96

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
13147	Upper difference	2, 3, 4, 5, 8, 12	OFF, 1 ... 30	OFF	K		108
13148	Lower difference	2, 3, 4, 5, 8, 12	OFF, 1 ... 30	OFF	K		108
13149	Delay	2, 3, 4, 5, 8, 12	1 ... 99	10	Min		108
13150	Lowest temp.	2, 3, 4, 5, 8, 12	10 ... 50	30	°C		108
13152	Max. charge T	4, 10, 11, 13, 14	10 ... 110	80	°C		101
13174	Motor pr.	2, 3, 4, 5, 8, 12	OFF, 10 ... 59	OFF	Min		90
13177	Temp. min.	2, 3, 5, 8, 12	10 ... 150	10	°C		74
13178	Temp. max.	2, 3, 5, 8, 12	10 ... 150	90	°C		74
13179	Summer, cut-out	2, 3, 5, 8, 12	OFF, 1 ... 50	20	°C		88
13182	Infl. - max.	2, 3, 5, 8, 12	-9.9 ... 0.0	-4.0			76
13183	Infl. - min.	2, 3, 5, 8, 12	0.0 ... 9.9	0.0			77
13184	Xp	2, 3, 4, 5, 8, 12	5 ... 250	80	K		90
13185	Tn	2, 3, 4, 5, 8, 12	1 ... 999	30	Sec		90
13186	M run	2, 3, 4, 5, 8	5 ... 250	30	Sec		90
13187	Nz	2, 3, 4, 5, 8, 12	1 ... 9	3	K		91
13189	Min. act. time	2, 3, 4, 5	2 ... 50	10			91
13192	Tank start diff.	14	1 ... 25	10	K		101
13193	Charge difference	4, 10, 11, 13, 14	1 ... 50	15	K		102
13194	Stop difference	4, 10, 11, 13, 14	-50 ... 50	3	K		102
13195	Start difference	4, 10, 11, 13, 14	-50 ... -1	-3	K		103
13196	Tank stop diff.	14	1 ... 10	2	K		104
13500	Send desired T	2, 3, 4, 5, 8, 10, 11, 12, 13, 14	OFF ; ON	ON			
14010	ECA addr.	3	OFF ; A ; B	OFF			93
14011	Auto saving	3	OFF, -29 ... 10	-15	°C		85
14012	Boost	3	OFF, 1 ... 99	OFF	%		85
14013	Ramp	3	OFF, 1 ... 99	OFF	Min		86
14014	Optimizer	3	OFF, 10 ... 59	OFF			86
14015	Adapt. time	3	OFF, 1 ... 50	OFF	Sec		76
14020	Based on	3	OUT ; ROOM	OUT			87
14021	Total stop	3	OFF ; ON	OFF			87
14022	P exercise	3	OFF ; ON	ON			93
14023	M exercise	3	OFF ; ON	OFF			93
14026	Pre-stop	3	OFF ; ON	ON			88
14031	High T out X1	3	-60 ... 20	15	°C		78
14032	Low limit Y1	3	10 ... 150	40	°C		78
14033	Low T out X2	3	-60 ... 20	-15	°C		79
14034	High limit Y2	3	10 ... 150	60	°C		79
14035	Infl. - max.	3	-9.9 ... 9.9	-2.0			79
14036	Infl. - min.	3	-9.9 ... 9.9	0.0			80
14037	Adapt. time	3	OFF, 1 ... 50	25	Sec		80
14040	P post-run	3	0 ... 99	3	Min		94


Operating Guide ECL Comfort 310, application P330

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
14041	DHW P post-run	5, 12, 13	0 ... 30	0	Min		100
14042	Char. P post-run	5, 12, 13	0 ... 30	1	Min		100
14052	DHW priority	3	OFF ; ON ; STOP	OFF			94
14054	Cont. T control	5, 12, 13	OFF ; ON	OFF			100
14055	Circ. P priority	5, 12, 13	OFF ; ON	OFF			100
14076	Circ. P frost T	5, 12, 13	OFF, -10 ... 20	OFF	°C		100
14077	P frost T	3	OFF, -10 ... 20	2	°C		95
14078	P heat T	3	5 ... 40	20	°C		95
14085	Priority	3	OFF ; ON	OFF			81
14093	Frost pr. T	3, 5, 12, 13	5 ... 40	10	°C		
14109	Input type	3	EM1 ; EM2 ; EM3 ; EM4 ; EM5 ; OFF	OFF			82
14112	Adapt. time	3	OFF, 1 ... 50	OFF	Sec		83
14113	Filter constant	3	1 ... 50	10			83
14115	Units	3	ml, l/h ; l, l/h ; ml, m ³ /h ; l, m ³ /h ; Wh, kW ; kWh, kW ; kWh, MW ; MWh, MW ; MWh, GW ; GWh, GW	ml, l/h			83
14116	High limit Y2	3	0.0 ... 999.9	999.9			83
14117	Low limit Y1	3	0.0 ... 999.9	999.9			83
14118	Low T out X2	3	-60 ... 20	-15	°C		84
14119	High T out X1	3	-60 ... 20	15	°C		84
14122	Day:	5, 12, 13	0 ... 127	0			
14123	Start time	5, 12, 13	0 ... 47	0			
14124	Duration	5, 12, 13	10 ... 600	120	Min		
14125	Desired T	5, 12, 13	OFF, 10 ... 110	OFF	°C		
14141	Ext. input	3, 5, 12, 13	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10 ; S11 ; S12 ; S13 ; S14 ; S15 ; S16	OFF			95
14142	Ext. mode	3, 5, 12, 13	COMFORT ; SAVING ; FROST PR.	COMFORT			96
14147	Upper difference	3	OFF, 1 ... 30	OFF	K		108
14148	Lower difference	3	OFF, 1 ... 30	OFF	K		108
14149	Delay	3	1 ... 99	10	Min		108
14150	Lowest temp.	3	10 ... 50	30	°C		108
14152	Max. charge T	5, 12, 13	10 ... 110	80	°C		101
14174	Motor pr.	3	OFF, 10 ... 59	OFF	Min		90
14177	Temp. min.	3	10 ... 150	10	°C		74
14178	Temp. max.	3	10 ... 150	90	°C		74
14179	Summer, cut-out	3	OFF, 1 ... 50	20	°C		88

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
14182	Infl. - max.	3	-9.9 ... 0.0	-4.0			76
14183	Infl. - min.	3	0.0 ... 9.9	0.0			77
14184	Xp	3	5 ... 250	80	K		90
14185	Tn	3	1 ... 999	30	Sec		90
14187	Nz	3	1 ... 9	3	K		91
14193	Charge difference	5, 12, 13	1 ... 50	15	K		102
14194	Stop difference	5, 12, 13	-50 ... 50	3	K		102
14195	Start difference	5, 12, 13	-50 ... -1	-3	K		103
14500	Send desired T	3, 5, 12, 13	OFF ; ON	ON			
15017	Demand offset	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 20	5	K		93
15022	P exercise	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	ON			93
15023	M exercise	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	OFF			93
15029	DHW, ret. T limit	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 10 ... 110	OFF	°C		78
15031	High T out X1	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-60 ... 20	15	°C		78
15032	Low limit Y1	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 150	40	°C		78
15033	Low T out X2	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-60 ... 20	-15	°C		79
15034	High limit Y2	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 150	60	°C		79
15035	Infl. - max.	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-9.9 ... 9.9	-2.0			79
15036	Infl. - min.	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-9.9 ... 9.9	0.0			80
15037	Adapt. time	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 50	25	Sec		80
15040	P post-run	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	0 ... 99	3	Min		94
15052	DHW priority	10, 11, 12, 13, 14, 15	OFF ; ON	ON			94
15077	P frost T	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, -10 ... 20	2	°C		95
15078	P heat T	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	5 ... 40	20	°C		95
15085	Priority	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; ON	OFF			81
15103	Desired flow T	14	10 ... 110	10	°C		
15109	Input type	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	EM1 ; EM2 ; EM3 ; EM4 ; EM5 ; OFF	OFF			82
15112	Adapt. time	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 50	OFF	Sec		83
15113	Filter constant	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	1 ... 50	10			83

Operating Guide ECL Comfort 310, application P330

ID	Parameter Name	P330.x	Setting range	Factory	Unit	Own settings	
15115	Units	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	ml, l/h ; l, l/h ; ml, m3/h ; l, m3/h ; Wh, kW ; kWh, kW ; kWh, MW ; MWh, MW ; MWh, GW ; GWh, GW	ml, l/h			83
15116	High limit Y2	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	0.0 ... 999.9	999.9			83
15117	Low limit Y1	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	0.0 ... 999.9	999.9			83
15118	Low T out X2	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-60 ... 20	-15	°C		84
15119	High T out X1	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	-60 ... 20	15	°C		84
15141	Ext. input	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF ; S1 ; S2 ; S3 ; S4 ; S5 ; S6 ; S7 ; S8 ; S9 ; S10 ; S11 ; S12 ; S13 ; S14 ; S15 ; S16	OFF			95
15147	Upper difference	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 30	OFF	K		108
15148	Lower difference	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 1 ... 30	OFF	K		108
15149	Delay	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	1 ... 99	10	Min		108
15150	Lowest temp.	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 50	30	°C		108
15174	Motor pr.	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	OFF, 10 ... 59	OFF	Min		90
15177	Temp. min.	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 150	10	°C		74
15178	Temp. max.	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 150	90	°C		74
15184	Xp	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	5 ... 250	80	K		90
15185	Tn	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	1 ... 999	30	Sec		90
15186	M run	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	5 ... 250	30	Sec		90
15187	Nz	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	1 ... 9	3	K		91
15189	Min. act. time	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	2 ... 50	10			91
15193	Charge difference	14	1 ... 50	10	K		102
15194	Stop difference	14	-50 ... 50	3	K		102
15195	Start difference	14	-50 ... -1	-3	K		103
15609	Low Y	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 120	10	°C		
15610	High Y	6, 7, 8, 9, 10, 11, 12, 13, 14, 15	10 ... 120	100	°C		



Installer:

By:

Date:

Operating Guide ECL Comfort 310, application P330



Danfoss A/S

Climate Solutions • danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.