VACON[®] NX AC DRIVES

OPTC3/C5 PROFIBUS DP OPTION BOARD USER MANUAL



INDEX

		Document code:	DPD00892B
1.		GENERAL	
2		PROFIBILS OF OPTION BOARD TECHNICAL DATA	3
2.	21	General	o
	2.2	Profibus cable	4
3.		PROFIBUS DP	6
	3.1	Introduction	6
	3.2	Profiles	7 7
Л		BOEIBLIS EIEL DBUS BOARD LAYOUT AND CONNECTIONS	، ع
ч.	11	Profibus OPT-C3 option board	۰۵
	4.1	4.1.1 Grounding of bus cable shield in OPT-C3	
	4.2	Profibus OPT-C5 option board	16
	4.0	4.2.1 Grounding of a D-connector:	
	4.3 4.4	Bus terminal resistors	19 19
5.		INSTALLATION OF VACON NX PROFIBUS BOARD	
6		COMMISSIONING	24
0.	61		
	6.2	Start-up test	24
7.		PROFIBUS-VACON NX INTERFACE	27
	7.1	General	27
	7.2	Operation mode	27
	7.3	PPOtypes	28
	7.4	Process data	29
		7.4.1 Control word	
		7.4.2 Status word	
		7.4.4 Reference 1	
		7.4.5 Actual value 1	
		7.4.6 PD1PD8	33
	7.5	Parameter data	
	70	7.5.1 Parameter field	
Q	7.0		
0.			
9.			41
	9.1	GSD-file ("Profibus Support Disk" files: vac29500.GSD, vac29500.GSE)	41
10)_	APPENDIX	42

1. GENERAL

The Vacon NX AC drives can be connected to the Profibus DP using a fieldbus board. The drive can then be controlled, monitored and programmed from the Host system.

The Profibus fieldbus board is installed in slot E on the control board of the AC drive.



Internal components and circuit boards are at high potential when the AC drive is connected to the power source. This voltage is extremely dangerous and may cause death or severe injury if you come into contact with it.

NOTE! You can download the English and French product manuals with applicable safety, warning and caution information from

http://drives.danfoss.com/knowledge-center/technical-documentation/.

REMARQUE Vous pouvez télécharger les versions anglaise et française des manuels du produit contenant l'emsemble des information de sécurité, avertissements et mises en garde applicables sur le site http://drives.danfoss.com/knowledge-center/technical-documentation/.

2. PROFIBUS DP OPTION BOARD TECHNICAL DATA

2.1 General

Profibus DP con-	Interface	OPTC3: Pluggable connector (5.08mm)
nections		OPTC5: 9-pin DSUB connector (female)
	Data transfer	RS-485, half-duplex
	method	
	Transfer cable	Twisted pair (1 pair and shield)
	Electrical isolation	500 VDC
Communications	Profibus DP	As described in document "Profibus Profile for variable
		speed drives, Profidrive"
	PPOtypes	1, 2, 3, 4, 5
	Baud rate	9.6 kbaud to 12 Mbaud
	Addresses	2 to 126
Environment	Ambient operating	–10°C55°C
	temperature	
	Storing tempera-	–40°C70°C
	ture	
	Humidity	<95%, no condensation allowed
	Altitude	Max. 1000 m
	Vibration	0.5 Gat 9200 Hz
Safety		Fulfils EN50178 standard

Table 2-1. Profibus technical data

2.2 Profibus cable

 Profibus devices are connected in a bus structure. Up to 32 stations (master or slaves) can be connected in one segment. The bus is terminated by an active bus terminator at the beginning and end of each segment (see *Figure 2-1*). To ensure error-free operation, both bus terminations must always be powered. When more than 32 stations are used, repeaters (line amplifiers) must be used to connect the individual bus segments.

The maximum cable length depends on the transmission speed and cable type (see *Table 2-3*). The specified cable length can be increased using the repeaters. The use of more than 3 repeaters in series is not recommended.

Parameter	Line A	Line B
Impedance	135 165 Ω	100 130 Ω
	(3 to 20 Mhz)	(f > 100kHz)
Capacity	< 30 pF/m	< 60 pF/m
Resistance	$<$ 110 Ω / km	-
Wire gauge	> 0.64 mm	> 0.53 mm
Conductor area	> 0.34 mm ²	> 0.22 mm ²

Table 2-2. Line parameters

Baud rate (kbit/s)	9.6	19.2	93.75	187.5	500	1500	3000- 12000
Length line A (m)	1200	1200	1200	1000	400	200	100
Length line B (m)	1200	1200	1200	600	200	-	-

3079A 21702xx

6XV1 830-0AH10

Table 2-3. Line length for different transmission speeds

E.g. following cables can be used:

Belden	Profibus Data Cable
Olflex	Profibus Cable
Siemens	SINEC L2 LAN cable for Profibus

NOTE!

- 2. Minimum distance between power and bus cables is 30 cm.
- 3. Minimum cable length of 1 m between two stations is recommended.



Figure 2-1. Cabling and bus termination

3. PROFIBUS DP

3.1 Introduction

Profibus is a vendor-independent, open fieldbus standard for a wide range of applications in manufacturing, process and building automation. Vendor independence and openness are guaranteed by the Profibus standard EN 50 170. With Profibus, devices of different manufacturers can communicate without special interface adjustments. Profibus can be used for both high-speed time critical data transmission and extensive complex communication tasks. The Profibus family consists of three compatible versions.

Profibus DP

Optimized for high speed and inexpensive hookup, this Profibus version is designed especially for communication between automation control systems and distributed I/O at the device level. Profibus-DP can be used to replace parallel signal transmission with 24 V or 0 to 20 mA.

Profibus PA

Profibus PA is designed especially for process automation. It permits sensors and actuators to be connected on one common bus line even in intrinsically-safe areas. Profibus PA permits data communication and power over the bus using a 2-wire technology according to the international standard IEC 1158-2.

Profibus FMS

Profibus FMS is the general-purpose solution for communication tasks at the cell level. Powerful FMS services open up a wide range of applications and provide great flexibility. Profibus FMS can also be used for extensive and complex communication tasks.

Profibus specifies the technical and functional characteristics of a serial fieldbus system with which decentralized digital controllers can be networked together from the field level to the cell level. Profibus distinguishes between master devices and slave devices.

Master devices determine the data communication on the bus. A master can send messages without an external request when it holds the bus access rights (the token). Masters are also called 'active stations' in the Profibus protocol.

Slave devices are peripheral devices. Typical slave devices include input/output devices, valves, drives and measuring transmitters. They do not have bus access rights and they can only acknowledge received messages or send messages to the master when requested to do so. Slaves are also called 'passive stations'.

3.2 Profiles

The Profibus DP protocol defines how user data are to be transmitted between the stations over the bus. User data are not evaluated by the Profibus DP transmission protocol. The meaning is specified in the profiles. In addition, the profiles specify how Profibus DP is to be used in the application area. The following Profibus DP profile is used in VACON NX Profibus Fieldbus board.

3.2.1 Variable Speed Drive Profile (3.071)

Leading manufacturers of drive technology have jointly defined the PROFIDRIVE profile. The profile specifies how the drives are to be parameterized and how the setpoints and actual values are to be transmitted. This enables drives from different vendors to be exchanged. The profile contains necessary specifications for speed control and positioning. It specifies the basic drive functions while leaving sufficient freedom for application-specific expansions and further developments. The profile describes the mapping of the application functions for DP or FMS.

4. PROFIBUS FIELDBUS BOARD LAYOUT AND CONNECTIONS

The Vacon Profibus Fieldbus Board is connected to the fieldbus through either a 5-pin pluggable bus connector (board OPT-C3) or a 9-pin female sub-D-connector (board OPT-C5). The communication with the control board takes place through the standard Vacon Interface Board Connector.

NOTE! The OPT-C3/C5 option board has two hardware versions. These two hardware versions have different layout, grounding settings, firmware packages and they use different tools for firmware up-dating. The OPT-C3/C5 hardware version number can be read from the bottom side on the bottom left of the option board PCB (see Figure 4-1).



Figure 4-1Hardware version text position

11685_uk

Correct firmware must be used for different hardware, incorrect firmware cannot be loaded into unsupported hardware. See Table 4-1 for firmware support on different hardware.

Hardware version	Firmware name	Package	Load tool
PC00257	10502 Vxxx	.VCN	NCLoad
PC01294	FW0232 Vxxx	.VCX	Vacon Loader

Table 4-1 Supported firmware for OPT-C3/C5 hardware

NOTE! FW0232 is designed to be compatible with the 10502 firmware. Only difference is that Vacon Loader must be used for firmware update.

Vacon Loader is supported in the NX products which use firmware mentioned in Table 4-2. Older NX firmware versions support only the NCLoad tool, and therefore updating of the PC01294 OPT-C3/C5 firmware is not possible unless the NX firmware is updated.

Product	Board ID	Loader support
NXP (version 3)	761	>=NXP00002 V185
NXP (version 2)	661	>=NXP00002 V189
NXS	752	>=NXS00002 V177

Table 4-2 NX Vacon Loader support

NX product board ID can be read using NC Drive:

- Drive -> Info -> "Control Card Serial Nr:" -> 761.../ 661.../ 752...
- NX firmware version can be read using NC Drive or keypad:
 - NCDrive: Drive -> Info -> "VCN name"
 - Keypad: 6.8.3.1 System menu -> System info -> Software -> Software package

4.1 Profibus OPT-C3 option board



11686_uk

Figure 4-2. Vacon Profibus option board OPT-C3

Signal	Connector	Description
Shield	1	Cable shield
VP	2	Supply voltage – plus (5V)
RxD/TxD –P	3	Receive/Transmit data – plus (B)
RxD/TxD –N	4	Receive/Transmit data – minus (A)
DGND	5	Data ground (reference potential for VP)

Table 4-3. OPT-C3 bus connector signals

4.1.1 Grounding of bus cable shield in OPT-C3

The bus cable shield can be grounded in three different ways:

- a) directly to the AC drive frame
- b) to the frame of the AC drive through an RC filter
- c) clamping the cable to the converter frame (recommended)

NOTE! Normally, the option board has already been installed in slot E of the control board. It is not necessary to detach the whole board for the grounding of the bus cable shield. Just detach the terminal block.

4.1.1.1 Grounding the bus cable shield directly to the AC drive frame

- 1 Set jumper settings depending on the used hardware version:
 - a) PC00257: Set jumper X1: Cable shield is connected directly to PE



- Upper row: GND connected to cable shield
- Lower row: Cable shield is connected directly to PE



Figure 4-4. PC01294 grounding jumpers

2 Strip about 5 cm of the Profibus cable as shown in the picture.

NOTE! Do the same for both bus cables (except for the last device). However, since the grounding is done on one cable only, cut off the exposed part of the other grounding cable.



Figure 4-5.

3 Leave no more than 1 cm of the red and green data cable outside the terminal block and strip the data cables at about 0.5 cm to fit in the terminals. See pictures below. NOTE! Do this for both bus cables.



Figure 4-6.





4 We recommend you to use an Abico connector to fit the grounding cable into the grounding terminal (#1).

Insert the red and green data cables of both Profibus cables into terminals #3 (red) and #4 (green).





Figure 4-8.

5 Place the Profibus board into slot E of the control board (see board installation on page 22) and fix both the Profibus cables on the frame with the clamp.



Figure 4-9.

4.1.1.2 Grounding the bus cable shield directly to the AC drive frame using an RC-filter

We recommend you to do the grounding in this manner when the distance between the devices exceeds 50 meters (55 yds.). When the distance between the devices is long, disturbances (e.g. voltage spikes) are more likely to appear. In this grounding method, the disturbances are filtered out. Even if the ground planes of A, B and C are different (which is very typical e.g. in construction) there is no current between them because the points do not have a ground connection.

NOTE:

If a potential difference occurs between the grounding points, equalization current can flow through a shield connected at both ends. In this case, install an additional potential equalization line and set this jumper X1 in ON position.



Figure 4-10. Grounding with RC filter

1 Set jumper settings depending on used hardware version:

a) PC00257: Set jumper X1: Cable shield is connected to PE through RC



Figure 4-11. PC00257 grounding jumper

11688_00

- b) PC01294: Set jumper X14
 - Upper row: GND connected to cable shield
 - Lower row: Cable shield is connected to PE through RC



Figure 4-12. PC01294 grounding jumpers

2 Carry out the grounding in the same way as advised in Chapter 4.1.1.1.

4.1.1.3 Grounding by clamping the cable to the converter frame

This manner of grounding is the most effective and especially recommended when the distances between the devices are relatively short (see 4.1.1.2).

In this manner of grounding, the position of jumper X1 or X13/14 is of no importance.



Figure 4-13. Grounding by clamping the cable to the converter frame

1. Strip about 5 cm of the Profibus cable in the same way as shown in *Figure 4-5* but **cut off the grey cable shield**.

Remember to do this for both bus cables (except for the last device).

- Leave no more than 1 cm of the red and green data cable outside the terminal block and strip the data cables at about 0.5 cm to fit in the terminals. See Figure 4-6 and *Figure 4-7*. NOTE! Do this for both bus cabels.
- 3. Insert the red and green data cables of both Profibus cables into terminals #3 (red) and #4 (green). See *Figure 4-8*.
- 4. Strip the Profibus cable at such a distance from the terminal that you can fix it to the frame with the grounding clamp. See *Figure 4-14*.
- 5. Ground the cable shield at both ends and on all loads by **360° connection**.



Figure 4-14a.

Figure 4-11b.



4.2 Profibus OPT-C5 option board

Figure 4-15. Vacon Profibus option board OPT-C5

Signal	Connector	Description
Shield	1	Cable shield
RxD/TxD-P	3	Receive/Transmit data - plus (B), RED
DGND	5	Data Ground (reference potential for VP)
VP	6	Supply voltage – plus (5V)
RxD/TxD-N	8	Receive/ Transmit data - minus (A), GREEN

Table 4-4. OPT-C5 bus connector signals

E.g. following connectors can be used (180° cable outlet):

Phoenix	SUBCON-PLUS-PROFIB/AX/SC	27 44 38 0
Siemens	Profibus connector	6GK1 500-0EA02

4.2.1 Grounding of a D-connector:



Figure 4-16. Remove the screw of the grounding clamp



Figure 4-17. Strip the cable according to the picture



Figure 4-18. Attach the D-connector and tighten the grounding plate

4.3 Bus terminal resistors

If Vacon is the last device of the PROFIBUS line, the bus termination must be set. Use jumper X6/X13 (ON position) or external termination resistors (e.g. in DSUB-9 connector). See Figure 4-19 or Figure 4-20 depending on the used OPT-C3/C5 hardware.

NOTE! Termination works properly when the drive has power (active termination) connected.



Figure 4-19. PC00257 termination resistor jumper X6



Figure 4-20 PC01294 termination resistor jumper X13

4.4 LED indications

The LED indications next to the connector show the present status of different modules:

- PS: PROFIBUS communication status (red led)
 - BS: PROFIBUS board status (yellow led)
 - FS: Fieldbus status (green led)

The LEDs are orientated differently between hardware versions. See Figure 4-21 or Figure 4-22 depending on the used hardware.



11692_00

Figure 4-21. LED indications on the PC00257 Profibus board



Figure 4-22 LED indications on the PC01294 Profibus board

Profibus status LED	(PS)	RED
	(

LED is:	Meaning:	
OFF	Profibus communicates normally.	
	 Data exchange between Master and Slave 	
ON	Profibus communication is broken or not started.	
	Bus cable broken or incorrectly connected	
	Wrong configuration or parametrization data of Master	
	Master is off line or shut down	

Profibus board status LED (BS) YELLOW

LED is:	Meaning:
OFF	Option board not activated
ON	Option board in initialisation state waiting for activation
	command from the AC drive
Blinking fast	Option board is activated and in RUN state
(once/sec)	Option board is ready for external communication
Blinking	Option board is activated and in FAULT state
slow	 Internal fault of option board
(once/5 secs)	

LED is:	Meaning:
OFF	Fieldbus module is waiting for parameters from the AC
	drive
	No external communication
ON	Fieldbus module is activated
	Parameters received and module activated
	Module is waiting for messages from the bus
Blinking fast	Module is activated and receiving messages from the bus
(once/sec)	
Blinking	Module is in FAULT state
slow	No messages from Master within the watchdog time
(once/5 secs)	Bus broken, cable loose or Master off line

Fieldbus status LED (FS) GREEN

5. INSTALLATION OF VACON NX PROFIBUS BOARD



It is **not allowed** to add or replace option boards or fieldbus boards on an AC drive with the power switched on! This may damage the boards.

A	Vacon NX AC drive
В	Remove the cable cover.
С	Open the cover of the control unit.
D	Install Profibus DP option board in slot E on the control board of the AC drive. Make sure that the grounding plate (see below) fits tightly in the clamp.

Ш	Make a sufficiently wide opening for your cable by cutting the grid as wide as necessary.
F	Close the cover of the control unit and the cable cover.

6. COMMISSIONING

First, read the chapter 8, Commissioning and additional instructions in Vacon NXS/P User Manual.

6.1 Fieldbus board parameters

The Vacon Profibus board is commissioned with the control keypad by giving values to appropriate parameters in menu **M7** (for locating the expander board menu see Vacon NXS/P User Manual, Chapter 7).

Expander board menu (M7)

The *Expander board menu* makes it possible for the user 1) to see what expander boards are connected to the control board and 2) to reach and edit the parameters associated with the expander board.

Enter the following menu level (G#) with the *Menu button right*. At this level, you can browse through slots A to E with the *Browser buttons* to see what expander boards are connected. On the lower most line of the display you also see the number of parameter groups associated with the board. If you still press the *Menu button right* once you will reach the parameter group level where there are two groups: Editable parameters and Monitored values. A further press on the *Menu button right* takes you to either of these groups.

Profibus parameters

To commission the Profibus board, enter the level G7.5.1.# from the *Parameters* group (G7.5.1). Give desired values to all Profibus parameters (see Figure 6-1 and Table 6-1).



Figure 6-1. Changing the Profibus board commissioning parameter values

#	Name	Default	Range	Description
1	SLAVE ADDRESS	126	2126	
2	BAUD RATE	10 (=AUTO)	1 - 9.6 kBaud 2 - 19.2 kBaud 3 - 93.75 kBaud 4 - 187.5 kBaud 5 - 500 kBaud 6 - 1.5 Mbaud 7 - 3 MBaud 8 - 6 Mbaud 9 - 12 Mbaud 10 – AUTOMATIC	Communication speed in baud
3	PPOTYPE		1 - PPO1 2 - PPO2 3 - PPO3 4 - PPO4 5 - PPO5	Parameter, CW/SW, Ref/Act Parameter, CW/SW, Ref/Act, PD1-PD4 CW/SW, Ref/Act CW/SW, Ref/Act, PD1-PD4 Parameter, CW/SW, Ref/Act, PD1-PD8
4	OPERATE MODE		1 – PROFIDRIVE 2 – BYPASS 3 – ECHO	Use mode "PROFIDRIVE" with standard applications

Table 6-1. Profibus parameters

The parameters of every device must be set before connecting to the bus. Especially the parameters "SLAVE ADDRESS" and "PPO TYPE" must be the same as in the master configuration.

Profibus status

To see the present status of the Profibus fieldbus, enter the *Profibus status* page from *Monitor* menu (G7.5.2). See *Figure 6-2* and *Table 6-2* below.



Figure 6-2. Profibus status

Profibus status									
0	Waiting parameter from Master								
1	Waiting configuration from Master								
2	Communication established								

Table 6-2. Profibus status indications

6.2 Start-up test

ACdrive application

Choose Fieldbus (Bus/Comm) as the active control place (see Vacon NXS/P User Manual, Chapter 7.6).

Master software

- 1. Set Control Word value to **0hex**.
- 2. Set Control Word value to 47Fhex.
- 3. AC drive status is RUN
- 4. Set Reference value to **5000** (=50.00%).
- 5. The Actual value is 5000 and the AC drive output frequency is 25.00 Hz
- 6. Set Control Word value to 477hex.
- 7. AC drive status is STOP

If Status Word bit 3 = 1 Status of AC drive is FAULT.

7. PROFIBUS-VACON NX INTERFACE

Features of the Profibus-Vacon NX interface:

- Direct control of Vacon NX (e.g. Run, Stop, Direction, Speed reference, Fault reset)
- Full access to all Vacon NX parameters
- Monitor Vacon NX status (e.g. Output frequency, Output current, Fault code)

7.1 General

Data transfer between Profibus DP master and slave takes place via the input/output data field. The Master writes to Slave's output data and the Slave answers by sending the contents of its input data to the Master. The contents of the input/output data is defined in the device profile. The device profile for AC drives is PROFIDRIVE.

The Vacon NX AC drive can be controlled by Profibus DP Master using the PPO-types defined in Profidrive (see Chapter 7.3). When fieldbus has been selected as the AC drive's active control place, the AC drive's operation can be controlled from the Profibus DP Master. Whether or not the active control place is fieldbus, the AC drive can be monitored and its parameters set by the Profibus DP Master.



Figure 7-1. Data transfer between Profibus Master and Slaves

7.2 Operation mode

The parameter Operation mode (G7.5.1.4, see above) defines how the input/output data is handled on the option board.

PROFIDRIVE

• Data transfer follows the document Profibus Profile for variable speed drives, PROFIDRIVE.

BYPASS

- The information of the Process Data field is transferred to the application interface without handling
- Parameter setting takes place according to the Profidrive definition

ECHO

- The OUTPUT data written by the Master is echoed back to the Master in the INPUT field
- The data is not shown in the AC drive but the echoing is carried out on the option board
- This mode can be used when the function of the bus connection is tested

7.3 PPO types

PPOs (Parameter/Process Data Object) are the communication objects in PROFIBUS DP.

The PPOs in Vacon NX:

	Parameter Field								Pro	cess	Data	Fiel	d														
	ID		INE)	VAL	UE			CW		REF		PD1	PD2	2	PD3	1	PD4		PD5		PD6	6	PD7	,	PD	8
									SW		ACT	•	PD1	PD2	2	PD3	•	PD4	1	PD	5	PD	6	PD	7	PD	8
PPO 1																											
PPO2																											
PPO3																											
PPO4																											
PPO5																											

Descriptions:

	Byte
ID	Parameter type and number
IND	Parameter subindex
VALUE	Parameter value
CW	Control Word
SW	Status Word
REF	Reference Value 1
ACT	Actual Value 1
PD	Process Data

7.4 Process data

The process data field is used to control the device (e.g. Run, Stop, Reference, Fault Reset) and in reading quick actual values (e.g. Output frequency, Output current, Fault code). The size of the field varies between 2..20 bytes. The field is structured as follows:

Process Data Master -> Slave(max 20 bytes)

CW	REF	PD1	PD2	PD3	PD4	PD5	PD6	PD7	PD8	

Process Data Slave -> Master (max 20 bytes)

SW	ACT		PD1		PD2		PD3		PD4		PD5		PD6		PD7		PD8	

The use of process data depends on the application. In a typical situation the device is started and stopped via the Control Word (CW) written by the Master and the Rotating speed is set with Reference (REF). Via PD1.. PD8 the device can be given other reference values (e.g. Torque reference). With the help of the StatusWord (SW) read by the Master, the status of the device can be seen. Actual Value (ACT) and PD1.. PD8 show the other actual values. See *Figure 7-2*.



Figure 7-2. Control of the AC drive through Profibus

7.4.1 Control word

CW	REF	PD1	PD2	PD3	PD4	PD5	PD6	PD7	PD8	

The Control command for the state machine (see *Figure 7-3.*) The state machine describes the device status and the possible control sequence of the AC drive.

The control word is composed of 16 bits that have the following meanings:

Bit	Description	
	Value = 0	Value = 1
0	STOP 1 (by ramp)	ON 1
1	STOP 2 (by coast)	ON 2
2	STOP 3 (by ramp)	ON 3
3	RUN DISABLE	ENABLE
4	No Action	START
5	No Action	START
6	No Action	START
7	No Action	FAULT RESET (0 -> 1)
8	No Action	No Action
9	No Action	No Action
10	Disable Profibus control	Enable Profibus control
11	Fieldbus DIN1=OFF	Fieldbus DIN1=ON
12	Fieldbus DIN2=OFF	Fieldbus DIN2=ON
13	Fieldbus DIN3=OFF	Fieldbus DIN3=ON
14	Fieldbus DIN4=OFF	Fieldbus DIN4=ON
15	Fieldbus DIN5=OFF	Fieldbus DIN5=ON

Table 7-1. Control word bit descriptions

With the help of the control word, start and stop commands can be given to the device. Also a fault can be acknowledged.

Command	Control Word	Description
RUN	047Fhex	Start motor if "Fieldbus" is active control source
STOP 1	047Ehex	Stop by Ramp
STOP 2	047Dhex	Stop by Coast
STOP 3	047Bhex	Stop by Ramp
RUN DISABLE	0477hex	Stop by Coast
FAULT RESET (step 1)	bit 7 = 0	Rising edge to bit 7
FAULT RESET (step 2)	bit 7 = 1	

Table 7-2. Commands with control word

As shown above, there are several stop modes. It depends on the operating situation, which mode is selected.

NOTE! In Vacon NX AC drive STOP1 and STOP3 are identical. Also STOP2 and RUN DISABLE are identical.

Commands STOP1 and STOP3 can be used only with either one of the motor control modes (P2.6.1) *Frequency control* or *Speed control* selected **and** the fieldbus selected as the control place.

7.4.2 Status word

SW	ACT	PD1	PD2	PD3	PD4	PD5	PD6	PD7	PD8	

Information about the status of the device and messages is indicated in the *Status word*. The Status word is composed of 16 bits that have the following meanings:

Bit	Description	
	Value = 0	Value = 1
0	Not Ready (initial)	READY1 **
1	Not Ready	READY2**
2	DISABLE	ENABLE **
3	NOFAULT	FAULT ACTIVE *
4	STOP 2	NO STOP 2 **
5	STOP 3	NO STOP 3 **
6	START ENABLE	START DISABLE **
7	No Warning	Warning *
8	Reference ≠ Actual value	Reference = Actual value *
9	Fieldbus control OFF	Fieldbus control ON *
10	Not used	Not used
11	Not used	Not used
12	FC stopped	Running *
13	FC not ready	FC ready *
14	Not used	Not used
15	Not used	Not used

Table 7-3. Status word bit descriptions

* Comes straight from the AC drive

** Bits of the State Machine

7.4.3 State machine

The state machine describes the device status and the possible control sequence of the AC drive. The state transitions can be generated by using the "Control word". The "Status word" indicates the current status of the state machine. The modes *INIT, STOP, RUN* and *FAULT* (see *Figure 7-3.*) correspond to the actual mode of the AC drive.





7

7.4.4 Reference 1

CW	REF	PD1	PD2	PD3	PD4	PD5	PD6	PD7	PD8	

This is the reference 1 to the AC drive. Used normally as Speed reference.

The allowed scaling is -10000...10000. In the application, the value is scaled in percentage of the frequency area between set minimum and maximum frequency.

> -10000 = 100.00 % (Direction reverse) 0 = 0.00 % (Direction forward) 10000 = 100.00 % (Direction forward)

7.4.5 Actual value 1

SW	ACT	PD1	PD2	PD3	PD4	PD5	PD6	PD7	PD8	

This is the actual value from the AC drive. Used normally as Speed reference, with the value between –10000...10000. In the application, the value is scaled in percentage of frequency area between set minimum and maximum frequency.

- 10000	=	100.00 %	(Direction reverse)
0	=	0.00 %	(Direction forward)
10000	=	100.00 %	(Direction forward)

7.4.6 **PD1..PD8**

ProcessData Master -> Slave

CW	REF	PD1	PD2	PD3	PD4	PD5	PD6	PD7	PD8	

The Master can write a maximum of 8 additional setting values to the device with the help of the Process Data. How these setting values are used is totally dependent on the application in use.

ProcessData Slave -> Master

SW	ACT	PD1	PD2	PD3	PD4	PD5	PD6	PD7	PD8	

The master can read the AC drive's actual values using the process data variables. Depending on the used application, the contents are either standard or can be selected with a param-

eter.

7



Figure 7-4. Control of Process data (see APPENDIX)

7.5 Parameter data

The Vacon variables and fault codes as well as the parameters can be read and written using PPO types 1, 2 and 5. The reading and writing can be done via the parameter field of the profibus message frame. The device parameters can be read and written and the actual values read with the help of the parameter field. The size of the parameter field is 8 bytes and it is divided into three parts, ID, Index and Value.



Figure 7-5. Transfer of parameter data

The parameter addresses are determined in the application. Every parameter and actual value has been given an ID number in the application. The ID numbering of the parameter as well as the parameter ranges and steps can be found in the application manual in question. The parameter value must be given without decimals. The ID numbers of each parameter/actual value are found in the application manual. The ID numbers are grouped as follows:

Group	Description
Not used	
Actual Values	
Active Fault Code	
Not Used	
Parameter	
Reserved	Reserved for Profibus internal usage
Not Used	
Parameter	
	Group Not used Actual Values Active Fault Code Not Used Parameter Reserved Not Used Parameter

Table 7-4. Grouping of ID numbers

7.5.1 Parameter field

Task and parameter ID

ID	IN	D	VALU	Ξ											
ID by	te1							ID by	te2						
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

SM: Spontaneous bit (not used)

Request/Response types

7

Request	Function
0	No request
1	Read parameter value (word)
2	Write parameter value (word)

Fault Numbers (if response = 7)

Response	Function
0	Noresponse
1	Parameter value ready (word)
7	Request rejected (+fault code)

Fault Number	Description
0	Illegal Parameter
1	Parameter is read only (e.g. actual
	values)
2	Parameter value is out of limits
17	Request temporarily rejected (e.g.
	can be changed only for STOP state)
18	Other fault
101	Unknown request type

Index

ID	INE)	VAL	_UE	

Not in use

Data Value

ID		IND)	VAL	.UE]			
		*****	******		· · · · · · · · · · · · · · · · · · ·	*****	······	 		
*******	*****						and the second s			
Dat	a wo	rd 1	(HIC	H)				Data word 2 (LOW	V)	
byte	e 0				byte 1			byte 2		byte3

In writing mode the data to be written is placed in the field "Data word 2".

In reading mode the answer is in the field "Data word 2".

"Data word 1" is normally zero.

7.6 Example messages

Example1, (PPO1 mode):

Read parameter number 102 (ID=102). Start AC drive and set speed reference 50.00%.

Command Master - Slave:

ID	1066 hex	1 - Read parameter value
IND	0000 hex	0000 - No meaning
VALUE	0000 0000 hex	0000 0000 - No meaning
CW	047F hex	04 7F- Start command (see chapter control word and state ma- chine)
REF	1388 hex	Speed ref. 50.00% (= 25.00 Hz if parameter min. frequency 0 Hz and max. frequency 50 Hz)

PPO1 frame (Parameter Field as Bold text):

|--|

Answer Slave - Master:

7

ID	1066 hex	1 - Parameter value ready
		066 - Parameter 102 (= Maximum frequency)
IND	0000 hex	0000 - No meaning
VALUE	0000 1388 hex	0000 1388 - Parameter value = 1388hex (50.00 Hz)
SW	0000 hex	0000 – AC drive status (see chapter status word and state ma- chine)
ACT	0000 hex	Current speed 0.00% (= 0,00 Hz if parameter min. frequency 0 Hz and max. frequency 50 Hz)

PPO1 frame (Parameter Field as Bold text):

10 66 00 00 00 00 13 88 00 00 00 00	· .	• · · · •	e (. a. a				•)•						
		10	66	00	00	00	00	13	88	00	00	00	00

Example 2, (PPO1 mode):

Write to parameter number 700 (par. 2.7.1) value 2. Keep Run mode on and Send speed reference 75.00%.

Command Master - Slave:

ID	22BC hex	2 - Write parameter value
		2BC - Parameter 700
IND	0000 hex	0000 - No meaning
VALUE	0000 0002 hex	0000 0002 - Parameter value
CW	047F hex	04 7F- Start command (see chapter control word and state machine)
REF	1D4C hex	Speed ref. 75.00% (= 37.50 Hz if parameter min. frequency 0 Hz and max. frequency 50 Hz)

PPO1 frame (Parameter Field as Bold text)::

							1				
22	BC	00	00	00	00	00	02	04	7F	1D	4C

Answer Slave - Master:

ID	12BC hex	1 - Parameter value ready
		2BC - Parameter 700 (= Response to reference fault)
IND	0000 hex	0000 - No meaning
VALUE	0000 0032 hex	0000 0000 – No meaning
SW	0337 hex	0337- AC drive status (see chapter status word and state ma- chine)
ACT	09C4 hex	Current speed 25.00% (= 12.50 Hz if parameter min. frequency 0 Hz and max. frequency 50 Hz)

PPO1 frame	Parameter	Field as	Bold text	١.
		i iciu as	DUIGICAL	.,

			1010 03	Doid to	<i></i>						
12	BD	00	00	00	00	00	00	03	37	09	C4

8. FAULT TRACKING

The table below presents the faults related to the Profibus option board. For more information, see also Vacon NXS/P User Manual, Chapter 10.

The Profibus option board status LEDs have been described in more detail in Chapter 4.4.

Fault code	Fault	Possible cause	Correcting measures
37	Device change	Option board changed.	Reset
38	Device added	Option board added.	Reset
39	Device removed	Option board removed.	Reset
40	Device un- known	Unknown option board.	
53	Fieldbus fault	The data connection between the Profibus Master and the Profibus option board is broken	Check the installation. If installation is correct contact the nearest Vacon distributor.
54	Slot fault	Defective option board or slot	Check the board and slot. Contact the nearest Vacon distributor.

Table 8-1. Profibus option board faults

You can define with parameters how the AC drive reacts to certain faults:

Code	Parameter	Min	Max	Unit	Step	Default	ID	Note
P2.7.22	Response to fieldbus fault	0	3		1	0	733	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.23	Response to slot fault	0	3		1	0	734	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting

Table 8-2. AC drive responses to faults

9. TYPE FILES

9.1 GSD-file ("Profibus Support Disk" files: vac29500.GSD, vac29500.GSE)

#Profibus_DP		Sync_Mode_supp	= 1
GSD_Revision	= 1	Auto_Baud_supp	= 1
Vendor_Name	= "Vaasa Control"	Set_Slave_Add_supp	= 0
Model_Name	= "Vacon NX"	Min_Slave_Intervall	= 20
Revision	= "1.0"	Modular_Station	= 1
Ident_Number	= 0x9500	Max_Module	= 5
Protocol_Ident	= 0	Max_Input_Len	= 28
Station_Type	= 0	Max_Output_Len	= 28
FMS_supp	= 0	Max_Data_Len	= 56
Hardware_Release	= "HW1.0"	Modul_Offset	= 0
Software_Release	= "SW1.0"	Slave_Family	= 1
9.6_supp	= 1	Fail_Safe	= 1
19.2_supp	= 1	Max_Diag_Data_Len	= 6
93.75_supp	= 1	Module = "VACON PPO	1" 0xF3, 0xF1
187.5_supp	= 1	EndModule;	
500_supp	= 1	Module = "VACON PPO	2" 0xF3, 0xF5
1.5M_supp	= 1	EndModule;	
3M_supp	= 1	Module = "VACON PPO	3" 0xF1
6M_supp	= 1	EndModule;	
12M_supp	= 1	Module = "VACON PPO	4" 0xF5
MaxTsdr_9.6	= 60	EndModule;	
MaxTsdr_19.2	= 60	Module = "VACON PPO	5" 0xF3, 0xF9
MaxTsdr_93.75	= 60	EndModule;	
MaxTsdr_187.5	= 60		
MaxTsdr_500	= 100		
MaxTsdr_1.5M	= 150	Module = "	special" 0x00
MaxTsdr_3M	= 250	EndModule	
MaxTsdr_6M	= 450	Module = "PPO 2" 0x	F3, 0xF1, 0xF1, 0xF1
MaxTsdr_12M	= 800	EndModule	
Redundancy	= 0	Module = "PPO 4" 0x	F1, 0xF1, 0xF1
Repeater_Ctrl_Sig	= 0	EndModule	
24V_Pins	= 0	Module = "PPO 5" 0x	F3, 0xF1, 0xF1, 0xF1, 0xF1,
Implementation_Type	= "SPC3"	Uxr1 EndModule	
Freeze_Mode_supp	= 1		

10. APPENDIX

Process Data OUT (Slave → Master)

The fieldbus master can read the AC drive's actual values using process data variables. *Basic, Standard, Local/Remote, Multi-Step, PID control and Pump and fan control* applications use process data as follows:

Data	Value	Unit	Accuracy
Process data OUT 1	Output Frequency	Hz	0.01 Hz
Process data OUT 2	Motor Speed	rpm	1 rpm
Process data OUT 3	Motor Current	А	0.1 A
Process data OUT 4	Motor Torque	%	0.1 %
Process data OUT 5	Motor Power	%	0.1 %
Process data OUT 6	Motor Voltage	V	0.1 V
Process data OUT 7	DC link voltage	V	1 V
Process data OUT 8	Active Fault Code	-	-

The *Multipurpose* application has a selector parameter for every Process Data. The monitoring values and drive parameters can be selected using the ID number (see NX All in One Application Manual, Tables for monitoring values and parameters). Default selections are as in the table above.

Process Data IN (Master -> Slave)

ControlWord, Reference and Process Data are used with All-in One applications as follows:

Basic, Standard, Local/Remote, Multi-Step applications

Data	Value	Unit	Scale
Reference	Speed Reference	%	0.01%
ControlWord	Start/Stop Com- mand Fault reset Com- mand	-	-
PD1 – PD8	Not used	-	-

Data	Value	Unit	Scale
Reference	Speed Reference	%	0.01%
Control Word	Start/Stop Command	-	-
	Fault reset Command		
Process Data IN1	Torque Reference	%	0.1%
Process Data IN2	Free Analogue INPUT	%	0.01%
Process Data IN3	Adjust Input	%	0.01%
PD3 – PD8	Not Used	-	-

Multipurpose control application

PID control and Pump and fan control applications

Data	Value	Unit	Scale
Reference	Speed Reference	%	0.01%
Control Word	Start/Stop Command Fault reset Command	-	-
Process Data IN1	Reference for PID control- ler	%	0.01%
Process Data IN2	Actual Value 1 to PID con- troller	%	0.01%
Process Data IN3	Actual Value 2 to PID con- troller	%	0.01%
PD4–PD8	Not Used	-	-

VACON®

www.danfoss.com

Vacon Ltd Member of the Danfoss Group Runsorintie 7 65380 Vaasa Finland



Rev. B

Sales code: DOC-OPTC3/C5+DLUK