

# VLT® Micro Drive FC 51

## 1 Introduction

This Operating Guide provides necessary information for qualified personnel to install and commission the AC drive. Read and follow the instructions to use the drive safely and professionally. VLT® is a registered trademark for Danfoss A/S.



**Do not dispose of equipment containing electrical components together with domestic waste. Collect it separately in accordance with local and currently valid legislation.**

## 2 Safety

Pay particular attention to the safety instructions and general warnings to avoid the risk of death, serious injury, and equipment or property damage.

### WARNING

#### HIGH VOLTAGE

AC drives contain high voltage when connected to AC mains input, DC supply, or load sharing.

#### UNINTENDED START

The motor may start from LCP, I/O inputs, fieldbus, or MCT 10 Set-up software at any time, when the drive is connected to the AC mains, DC supply, or load sharing.

#### DISCHARGE TIME

The drive contains DC-link capacitors, which can remain charged even when the drive is not powered. High voltage can be present even when the warning indicator lights are off.

- Stop the motor, and disconnect AC mains, permanent magnet type motors, and remote DC-link supplies, including battery back-ups, UPS, and DC-link connections to other drives.
- Wait for the capacitors to discharge fully and measure it before performing any service or repair work.
- The minimum waiting time is 4 minutes for M1, M2, and M3 drives, and 15 minutes for M4 and M5 drives.

#### LEAKAGE CURRENT

Leakage currents of the drive exceed 3.5 mA. Make sure that the drive is properly grounded with at least 10 mm<sup>2</sup> (8 AWG) grounding wire and use RCDs of type B with an inrush delay.

## 3 Installation

### 3.1 Mechanical Dimensions

Enclosure size	Height [mm (in)]			Width [mm (in)]		Depth [mm (in)] <sup>(2)</sup>	Mounting holes [mm (in)]	D
	A	A <sup>(1)</sup>	a	B	b			
M1	150 (5.9)	205 (8.1)	140.4 (5.5)	70 (2.8)	55 (2.2)	148 (5.8)	7 (0.28)	
M2	176 (6.9)	230 (9.1)	166.4 (6.6)	75 (3.0)	59 (2.3)	168 (6.6)	7 (0.28)	
M3	239 (9.4)	294 (11.6)	226 (8.9)	90 (3.5)	69 (2.7)	194 (7.6)	5.5 (0.22)	
M4	292 (11.5)	347.5 (13.7)	272.4 (10.7)	125 (4.9)	97 (3.8)	241 (9.5)	4.5 (0.18)	
M5	335 (13.2)	387.5 (15.3)	315 (12.4)	165 (6.5)	140 (5.5)	248 (9.8)	4.5 (0.18)	

Enclosure size	Power [kW (hp)]			Maximum weight [kg (lb)]
	1x200–240 V	3x200–240 V	3x380–480 V	
M1	0.18–0.75 (0.24–1.0)	0.25–0.75 (0.34–1.0)	0.37–0.75 (0.5–1.0)	1.1 (2.4)
M2	1.5 (2.0)	1.5 (2.0)	1.5–2.2 (2.0–3.0)	1.6 (3.5)
M3	2.2 (3.0)	2.2–3.7 (3.0–5.0)	3.0–7.5 (4.0–10)	3.0 (6.6)
M4	–	–	11.0–15.0 (15–20)	6.0 (13.2)
M5	–	–	18.5–22.0 (25–30)	9.5 (20.9)

(1) Including decoupling plate. (2) For LCP with potentiometer, add 7.6 mm (0.3 in).

### 3.2 Connecting to Mains and Motor

- Mount the ground wires to the PE terminal.
- Connect motor to terminals U, V, and W.
- Mount mains supply to terminals L1/L, L2, and L3/N (3-phase) or L1/L and L3/N (single-phase) and tighten.

### 3.3 Load Sharing/Brake

Use 6.3 mm (0.25 in) insulated Faston plugs designed for high voltage for DC (load sharing and brake).

Contact Danfoss or see Load sharing instruction VLT® 5000 for load sharing and VLT® 2800/5000/5000 FLUX/FCD 300 Brake for brake.

**Load sharing:** Connect terminals -UDC and +UDC/+BR.

**Brake:** Connect terminals -BR and +UDC/+BR (not applicable to enclosure size M1).




Illustration 1: Mounting of Ground Cable, Mains, and Motor Wires

### NOTICE

Voltage levels of up to 850 V DC may occur between terminals +UDC/+BR and -UDC. Not short-circuit protected.

### 3.4 Control Terminals

All control cable terminals are located underneath the terminal cover in front of the drive. Remove the terminal cover using a screwdriver.




Illustration 2: Removing Terminal Cover

**NOTICE**

- See the back of the terminal cover for outlines of control terminals and switches.
- Do not operate switches with power on the drive.
- Set parameter 6-19 Terminal 53 Mode according to Switch 4 position.

Switch	Setting
Switch 1	Off=PNP terminals 29 <sup>(1)</sup> On=NPN terminals 29
Switch 2	Off=PNP terminal 18, 19, 27, and 33 <sup>(1)</sup> On=NPN terminal 18, 19, 27, and 33
Switch 3	No function
Switch 4	Off=Terminal 53 0–10 V <sup>(1)</sup> On=Terminal 53 0/4–20 mA

(1) This is the default setting.



Illustration 3: S200 Switches 1–4

Table 1: Settings for S200 Switches 1–4

The following illustration shows all control terminals of the drive. Applying start (terminal 18) and an analog reference (terminal 53 or 60) make the drive run.




Illustration 4: Overview of Control Terminals in PNP Configuration with Factory Setting

## 4 Programming

### 4.1 Local Control Panel (LCP)




Illustration 5: Description of LCP Keys and Display

Press [Menu] to select 1 of the following menus:	
<b>Status</b>	For readouts only.
<b>Quick Menu</b>	For access to Quick Menus 1 and 2.
<b>Main Menu</b>	For access to all parameters.
<b>Navigation keys</b>	
[Back]	For moving to the previous step or layer in the navigation structure.
[▲] [▼]	For manoeuvring between parameter groups, parameters, and within parameters.
[OK]	For selecting a parameter and for accepting changes to parameter settings.
<b>Operation keys</b>	
[Hand On]	Starts the motor and enables control of drive via LCP.
[Off/Reset]	The motor stops. If in alarm mode, the motor resets.
[Auto On]	The drive is controlled either via control terminals or serial communication.
LCP12 is another LCP with potentiometer.	

### 4.2 Programming on Automatic Motor Tuning (AMT)

Run AMT to optimize compatibility between the drive and the motor in VVC<sup>+</sup> mode. The drive builds a mathematical model of the motor for regulating output motor current thus enhancing motor performance.

1. Enter the main menu.
2. Set parameter group 1-\*\*\* Load and Motor, parameter group 1-2\* Motor Data, and parameter 1-29 Automatic Motor Tuning (AMT).
3. Press [OK]. The test runs automatically and indicates when it is complete.

## 5 Parameter Overview

<b>0-*** Operation/Display</b>	2-00 DC Hold Current	Digital Output
<b>0-0* Basic Settings</b>	2-01 DC Brake Current	<b>5-4* Relays</b>
0-03 Regional Settings	2-02 DC Braking Time	5-40 Function Relay
0-04 Operating State at Power-up (Hand)	2-04 DC Brake Cut In Speed	5-41 On Delay, Relay
<b>0-1* Set-up Operations</b>	<b>2-1* Brake Energy Funct.</b>	5-42 Off Delay, Relay
0-10 Active Set-up	2-10 Brake Function	<b>5-5* Pulse Input</b>
0-11 Edit Set-up	2-11 Brake Resistor (ohm)	5-55 Terminal 33 Low Frequency
0-12 Link Setups	2-14 Brake Voltage Reduce	5-56 Terminal 33 High Frequency
<b>0-3* LCP Readout</b>	2-16 AC Brake, Max Current	5-57 Terminal 33 Low Ref./
0-31 Custom Readout Min Value	2-17 Overvoltage Control	Feedb. Value
0-32 Custom Readout Max Value	<b>2-2* Mechanical Brake</b>	5-58 Terminal 33 High Ref./
<b>0-4* LCP Keypad</b>	2-20 Release Brake Current	Feedb. Value
0-40 [Hand on] Key on LCP	2-22 Activate Brake Speed [Hz]	<b>6-*** Analog In/Out</b>
0-41 [Off/Reset] Key on LCP	<b>3-*** Reference/Ramps</b>	<b>6-0* Analog I/O Mode</b>
0-42 [Auto on] Key on LCP	<b>3-0* Reference Limits</b>	6-00 Live Zero Timeout Time
<b>0-5* Copy/Save</b>	3-00 Reference Range	6-01 Live Zero Timeout Function
0-50 LCP Copy	3-02 Minimum Reference	<b>6-1* Analog Input 1</b>
0-51 Set-up Copy	3-03 Maximum Reference	6-10 Terminal 53 Low Voltage
<b>0-6* Password</b>	<b>3-1* References</b>	6-11 Terminal 53 High Voltage
0-60 Main/Quick Menu Password	3-10 Preset Reference	6-12 Terminal 53 Low Current
0-61 Access to Main/Quick Menu w/o Password	3-11 Jog Speed [Hz]	6-13 Terminal 53 High Current
<b>1-*** Load and Motor</b>	3-12 Catch Up/Slow Down Value	6-14 Terminal 53 Low Ref./
<b>1-0* General Settings</b>	3-14 Preset Relative Reference	Feedb. Value
1-00 Configuration Mode	3-15 Reference Resource 1	6-15 Terminal 53 High Ref./
1-01 Motor Control Principle	3-16 Reference Resource 2	Feedb. Value
1-03 Torque Characteristics	3-17 Reference Resource 3	6-16 Terminal 53 Filter Time
1-05 Hand Mode Configuration	3-18 Relative Scaling Reference Resource	Constant
<b>1-2* Motor Data</b>	<b>3-4* Ramp 1</b>	<b>6-2* Analog Input 2</b>
1-20 Motor Power	3-40 Ramp 1 Type	6-21 Reserved for Testing
1-22 Motor Voltage	3-41 Ramp 1 Ramp Up Time	6-22 Terminal 60 Low Current
1-23 Motor Frequency	3-42 Ramp 1 Ramp Down Time	6-23 Terminal 60 High Current
1-24 Motor Current	<b>3-5* Ramp 2</b>	6-24 Terminal 60 Low Ref./
1-25 Motor Nominal Speed	3-50 Ramp 2 Type	Feedb. Value
1-29 Automatic Motor Tuning (AMT)	3-51 Ramp 2 Ramp Up Time	6-25 Terminal 60 High Ref./
<b>1-3* Adv. Motor Data</b>	3-52 Ramp 2 Ramp Down Time	Feedb. Value
1-30 Stator Resistance (Rs)	<b>3-8* Other Ramps</b>	6-26 Terminal 60 Filter Time
1-33 Stator Leakage Reactance (X1)	3-80 Jog Ramp Time	Constant
1-35 Main Reactance (Xh)	3-81 Quick Stop Ramp Time	<b>6-8* LCP potmeter</b>
<b>1-5* Load Indep. Setting</b>	<b>4-*** Limits/Warnings</b>	6-80 LCP Potmeter Enable
1-50 Motor Magnetisation at Zero Speed	<b>4-1* Motor Limits</b>	6-81 LCP Potmeter Low Ref.
1-52 Min Speed Normal Magnetising [Hz]	4-10 Motor Speed Direction	6-82 LCP Potmeter High Ref.
1-55 U/f Characteristic - U	4-12 Motor Speed Low Limit [Hz]	<b>6-9* Analog Output xx</b>
1-56 U/f Characteristic - F	4-14 Motor Speed High Limit [Hz]	6-90 Terminal 42 Mode
<b>1-6* Load Depen. Setting</b>	4-16 Torque Limit Motor Mode	6-91 Terminal 42 Analog Output
1-60 Low Speed Load Compensation	4-17 Torque Limit Generator Mode	6-92 Terminal 42 Digital Output
1-61 High Speed Load Compensation	<b>4-4* Adj. Warnings 2</b>	6-93 Terminal 42 Output Min Scale
1-62 Slip Compensation	4-40 Warning Freq. Low	6-94 Terminal 42 Output Max Scale
1-63 Slip Compensation Time Constant	4-41 Warning Freq. High	6-98 Drive Type
<b>1-7* Start Adjustments</b>	<b>4-5* Adj. Warnings</b>	<b>7-*** Controllers</b>
1-71 Start Delay	4-50 Warning Current Low	<b>7-2* Process Ctrl. Feedb</b>
1-72 Start Function	4-51 Warning Current High	7-20 Process CL Feedback 1 Resource
1-73 Flying Start	4-54 Warning Reference Low	<b>7-3* Process PI Ctrl.</b>
<b>1-8* Stop Adjustments</b>	4-55 Warning Reference High	7-30 Process PI Normal/
1-80 Function at Stop	4-56 Warning Feedback Low	Inverse Control
1-82 Min Speed for Function at Stop [Hz]	4-57 Warning Feedback High	7-31 Process PI Anti Windup
<b>1-9* Motor Temperature</b>	4-58 Missing Motor Phase Function	7-32 Process PI Start Speed
1-90 Motor Thermal Protection	<b>4-6* Speed Bypass</b>	7-33 Process PI Proportional Gain
1-93 Thermistor Resource	4-61 Bypass Speed From [Hz]	7-34 Process PI Integral Time
<b>2-*** Brakes</b>	4-63 Bypass Speed To [Hz]	7-38 Process PI Feed Forward Factor
<b>2-0* DC-Brake</b>	<b>5-*** Digital In/Out</b>	7-39 On Reference Bandwidth
	5-10 Terminal 18 Digital Input	8-*** Comm. and Options
	5-11 Terminal 19 Digital Input	<b>8-0* Comm. General Settings</b>
	5-12 Terminal 27 Digital Input	8-01 Control Site
	5-13 Terminal 29 Digital Input	8-02 Control Word Source
	<b>5-3* Digital Outputs</b>	8-03 Control Word Timeout Time
	Digital Output	8-04 Control Word Timeout Function
	5-35 Off Delay, Terminal 42	

