



# Operating Instructions

## VLT<sup>®</sup> HVAC Drive FC 102 Low Harmonic Drive





**Danfoss A/S**6430 Nordborg  
Denmark  
CVR nr.: 20 16 57 15Telephone: +45 7488 2222  
Fax: +45 7449 0949**EU DECLARATION OF CONFORMITY****Danfoss A/S****Danfoss Drives A/S**

declares under our sole responsibility that the

**Product category:** Frequency Converter**Type designation(s):** FC-102XYYYZZ\*\*\*\*\*

Character X: N or P

Character YYY: K37, K75, 1K1, 1K5, 2K2, 3K0, 3K7, 4K0, 5K5, 7K5, 11K, 15K, 18K, 22K, 30K, 37K, 45K, 55K, 75K, 90K, 110, 132, 150, 160, 200, 250, 315, 355, 400, 450, 500, 560, 630, 710, 800, 900, 1M0, 1M2, 1M4

Character ZZ: T2, T4, T6, T7

\* may be any number or letter indicating drive options which do not impact this DoC.

The meaning of the 39 characters in the type code string can be found in appendix 00729776.

Covered by this declaration is in conformity with the following directive(s), standard(s) or other normative document(s), provided that the product is used in accordance with our instructions.

**Low Voltage Directive 2014/35/EU**

EN61800-5-1:2007 + A1:2017

Adjustable speed electrical power drive systems – Part 5-1:  
Safety requirements – Electrical, thermal and energy.**EMC Directive 2014/30/EU**

EN61800-3:2004 + A1:2012

Adjustable speed electrical power drive systems – Part 3: EMC  
requirements and specific test methods.**RoHS Directive 2011/65/EU including amendment 2015/863.**

EN63000:2018

Technical documentation for the assessment of electrical and  
electronic products with respect to the restriction of  
hazardous substances

|                                     |   |                                     |   |
|-------------------------------------|---|-------------------------------------|---|
| Date: 2020.09.02<br>Place of issue: | Issued by<br><br><b>Signature:</b><br><b>Name: Gert Kjær</b><br><b>Title: Senior Director, GDE</b> | Date: 2020.09.02<br>Place of issue: | Approved by<br><br><b>Signature:</b><br><b>Name: Michael Termansen</b><br><b>Title: VP, PD Center Denmark</b> |
| Graasten, DK                        |   | Graasten, DK                        |   |

Danfoss only vouches for the correctness of the English version of this declaration. In the event of the declaration being translated into any other language, the translator concerned shall be liable for the correctness of the translation



For products including available Safe Torque Off (STO) function according to unit typecode on the nameplate: **T or U at character 18 of the typecode.**

#### Machine Directive 2006/42/EC

EN/IEC 61800-5-2:2007

(Safe Stop function conforms with STO – Safe Torque Off, SIL 2 Capability)

Adjustable speed electrical power drive systems –  
Part 5-2: Safety requirements – Functional

#### Other standards considered:

EN ISO 13849-1:2015

(Safe Stop function, PL d

(MTTFd=14000 years, DC=90%, Category 3)

EN/IEC 61508-1:2011, EN/IEC 61508-2:2011

(Safe Stop function, SIL 2 (PFH = 1E-10/h, 1E-8/h for specific variants, PFD = 1E-10, 1E-4 for specific variants, SFF>99%, HFT=0))

EN/IEC 62061:2005 + A1:2013

(Safe Stop function, SILCL 2)

EN/IEC 60204-1:2006 + A1:2009

(Stop Category 0)

Safety of machinery - Safety-related parts of control systems - Part 1: General principles for design

Functional safety of electrical/electronic/ programmable electronic safety-related systems

Part 1: General requirements

Part 2: Requirements for electrical/ electronic / programmable electronic safety-related systems

Safety of machinery - Functional safety of safety-related electrical, electronic and programmable electronic control systems

Safety of machinery - Electrical equipment of machines - Part 1: General requirements


For products including ATEX option, it requires STO function in the products. The products can have the VLT PTC Thermistor Card MCB112 installed from factory (**2 at character 32 in the typecode**), or it can be separately installed as an additional part.

#### 2014/34/EU - Equipment for explosive atmospheres (ATEX)

Based on EU harmonized standard:

EN 50495: 2010

Safety devices required for safe functioning of equipment with respect to explosion risks.



#### Notified Body:

PTB Physikalisch-Technische Bundesanstalt, Bundesallee 100, 38116 Braunschweig, has assessed the conformity of the "ATEX certified motor thermal protection systems" of Danfoss FC VLT Drives with Safe Torque Off function and has issued the certificate PTB 14 ATEX 3009.



## Contents

|  |           |
|--|-----------|
| <b>1 Introduction</b>                                    | <b>5</b>  |
| 1.1 Purpose of the Manual                                | 5         |
| 1.2 Additional Resources                                 | 5         |
| 1.3 Product Overview                                     | 5         |
| 1.3.1 Intended Use                                       | 5         |
| 1.3.2 Working Principle                                  | 6         |
| 1.3.3 Exploded View Drawings                             | 7         |
| 1.4 Enclosure Sizes and Power Ratings                    | 15        |
| 1.5 Approvals and Certifications                         | 15        |
| 1.5.1 Approvals  | 15        |
| 1.5.2 Compliance with ADN                                | 15        |
| 1.6 Harmonics Overview                                   | 15        |
| 1.6.1 Harmonics  | 15        |
| 1.6.2 Harmonic Analysis                                  | 15        |
| 1.6.3 Effect of Harmonics in a Power Distribution System | 16        |
| 1.6.4  | 17        |
| 1.6.5 IEC Harmonic Standards                             | 17        |
| 1.6.6 IEEE Harmonic Standards                            | 19        |
| <b>2 Safety</b>  | <b>20</b> |
| 2.1 Safety Symbols                                       | 20        |
| 2.2 Qualified Personnel                                  | 20        |
| 2.3 Safety Precautions                                   | 20        |
| <b>3 Mechanical Installation</b>                         | <b>21</b> |
| 3.1 Equipment Pre-Installation Checklist                 | 21        |
| 3.2 Unpacking  | 22        |
| 3.2.1 Items Supplied                                     | 22        |
| 3.3 Mounting   | 23        |
| 3.3.1 Cooling and Airflow                                | 23        |
| 3.3.2 Lifting  | 24        |
| 3.3.3 Cable Entry and Anchoring                          | 26        |
| 3.3.4 Terminal Locations for Enclosure Size D1n/D2n      | 30        |
| 3.3.5 Terminal Locations for Enclosure Size E9           | 32        |
| 3.3.6 Terminal Locations for Enclosure Size F18          | 33        |
| 3.3.7 Torque   | 35        |
| <b>4 Electrical Installation</b>                         | <b>36</b> |
| 4.1 Safety Instructions                                  | 36        |
| 4.2 EMC Compliant Installation                           | 36        |

|  |           |
|--|-----------|
| 4.3 Power Connections                                | 36        |
| 4.4 Grounding  | 37        |
| 4.5 Input Options                                    | 38        |
| 4.5.1 Extra Protection (RCD)                         | 38        |
| 4.5.2 RFI Switch                                     | 38        |
| 4.5.3 Shielded Cables                                | 38        |
| 4.6 Motor Connection                                 | 38        |
| 4.6.1 Motor Cable                                    | 38        |
| 4.6.2 Brake Cable                                    | 39        |
| 4.6.3 Motor Insulation                               | 39        |
| 4.6.4 Motor Bearing Currents                         | 40        |
| 4.7 AC Mains Connection                              | 40        |
| 4.7.1 Mains Connection                               | 40        |
| 4.7.2 External Fan Supply                            | 40        |
| 4.7.3 Power and Control Wiring for Unscreened Cables | 41        |
| 4.7.4 Mains Disconnects                              | 42        |
| 4.7.5 F-Frame Circuit Breakers                       | 42        |
| 4.7.6 F-Frame Mains Contactors                       | 42        |
| 4.8 Control Wiring                                   | 42        |
| 4.8.1 Control Cable Routing                          | 42        |
| 4.8.2 Access to Control Terminals                    | 44        |
| 4.8.3 Electrical Installation, Control Terminals     | 44        |
| 4.8.4 Electrical Installation, Control Cables        | 46        |
| 4.8.5 Safe Torque Off (STO)                          | 48        |
| 4.9 Additional Connections                           | 48        |
| 4.9.1 Serial Communication                           | 48        |
| 4.9.2 Mechanical Brake Control                       | 48        |
| 4.9.3 Parallel Connection of Motors                  | 49        |
| 4.9.4 Motor Thermal Protection                       | 49        |
| 4.9.5 Voltage/Current Input Selection (Switches)     | 49        |
| 4.10 Final Set-up and Test                           | 50        |
| 4.11 F-frame Options                                 | 51        |
| <b>5 Commissioning</b>                               | <b>53</b> |
| 5.1 Safety Instructions                              | 53        |
| 5.2 Applying Power                                   | 55        |
| 5.3 Local Control Panel Operation                    | 55        |
| 5.3.1 Local Control Panel                            | 55        |
| 5.3.2 LCP Layout                                     | 55        |
| 5.3.3 Parameter Settings                             | 56        |
| 5.3.4 Uploading/Downloading Data to/from the LCP     | 57        |

|   |           |
|---|-----------|
| 5.3.5 Changing Parameter Settings                         | 57        |
| 5.3.6 Restoring Default Settings                          | 57        |
| 5.4 Basic Programming                                     | 58        |
| 5.4.1 VLT® Low Harmonic Drive Programming                 | 58        |
| 5.4.2 Commissioning with SmartStart                       | 58        |
| 5.4.3 Commissioning via [Main Menu]                       | 58        |
| 5.4.4 Asynchronous Motor Set-up                           | 59        |
| 5.4.5 Permanent Magnet Motor Set-up                       | 59        |
| 5.4.6 Automatic Energy Optimization (AEO)                 | 60        |
| 5.4.7 Automatic Motor Adaptation (AMA)                    | 61        |
| 5.5 Checking Motor Rotation                               | 61        |
| 5.6 Local-control Test                                    | 61        |
| 5.7 System Start-up                                       | 61        |
| <b>6 Application Examples</b>                             | <b>62</b> |
| 6.1 Introduction  | 62        |
| 6.2 Application Examples                                  | 62        |
| <b>7 Diagnostics and Troubleshooting</b>                  | <b>66</b> |
| 7.1 Status Messages                                       | 66        |
| 7.2 Warning and Alarm Types                               | 66        |
| 7.2.1 Warnings  | 66        |
| 7.2.2 Alarm Trip  | 66        |
| 7.2.3 Alarm Trip-lock                                     | 66        |
| 7.3 Warning and Alarm Definitions for Frequency Converter | 66        |
| 7.4 Warnings and Alarm Definitions - Active Filter        | 75        |
| 7.5 Troubleshooting                                       | 80        |
| <b>8 Specifications</b>                                   | <b>83</b> |
| 8.1 Power-Dependent Specifications                        | 83        |
| 8.1.1 Mains Supply 3x380–480 V AC                         | 83        |
| 8.1.2 Derating for Temperature                            | 86        |
| 8.2 Mechanical Dimensions                                 | 87        |
| 8.3 General Technical Data                                | 90        |
| 8.4 Fuses   | 95        |
| 8.4.1 Non-UL compliance                                   | 96        |
| 8.4.2 Fuse Tables   | 96        |
| 8.4.3 Supplementary Fuses                                 | 96        |
| 8.5 General Torque Tightening Values                      | 98        |
| <b>9 Appendix A - Parameters</b>                          | <b>99</b> |
| 9.1 Description of Parameters                             | 99        |



|   |            |
|---|------------|
| 9.2 Frequency Converter Parameter Lists | 99         |
| 9.3 Active Filter Parameter Lists       | 104        |
| <b>10 Appendix B</b>                    | <b>111</b> |
| 10.1 Abbreviations and Conventions      | 111        |
| <b>Index</b>                            | <b>112</b> |

# 1 Introduction

## 1.1 Purpose of the Manual

The purpose of this manual is to provide information for the installation and operation of a VLT® HVAC Drive FC 102 Low Harmonic Drive. The manual includes relevant safety information for installation and operation.

*Chapter 1 Introduction, chapter 2 Safety, chapter 3 Mechanical Installation, and chapter 4 Electrical Installation* introduce the unit functions and cover proper mechanical and electrical installation procedures. There are chapters on start-up and commissioning, applications, and basic troubleshooting. *Chapter 8 Specifications* provides a quick reference for ratings and dimensions, and other operating specifications. This manual provides a basic knowledge of the unit and explains set-up and basic operation.

VLT® is a registered trademark.

## 1.2 Additional Resources

Other resources are available to understand advanced functions and programming.

- The *VLT® HVAC Drive FC 102 Programming Guide* provides greater detail on working with parameters and many application examples.
- The *VLT® HVAC Drive FC 102 Design Guide* provides detailed capabilities and functionality to design motor control systems.
- Supplemental publications and manuals are available from Danfoss.  
See [vlt-drives.danfoss.com/Support/Technical-Documentation/](http://vlt-drives.danfoss.com/Support/Technical-Documentation/) for listings.
- Optional equipment may change some of the procedures described. Reference the instructions supplied with those options for specific requirements. Contact the local Danfoss supplier or visit the Danfoss website: [vlt-drives.danfoss.com/Support/Technical-Documentation/](http://vlt-drives.danfoss.com/Support/Technical-Documentation/) for downloads or additional information.
- The *VLT® Active Filter AAF 006 Operating Instructions* provide additional information about the filter portion of the low harmonic drive.

## 1.3 Product Overview

### 1.3.1 Intended Use

A frequency converter is an electronic motor controller that converts AC mains input into a variable AC waveform output. The frequency and voltage of the output are regulated to control the motor speed or torque. The frequency converter can vary the speed of the motor in response to system feedback, such as with position sensors on a conveyor belt. The frequency converter can also regulate the motor by responding to remote commands from external controllers.

The frequency converter:

- Monitors the system and motor status.
- Issues warnings or alarms for fault conditions.
- Starts and stops the motor.
- Optimizes energy efficiency.

Operation and monitoring functions are available as status indications to an outside control system or serial communication network.

A low harmonic drive (LHD) is a single unit that combines the frequency converter with an advanced active filter (AAF) for harmonic mitigation. The frequency converter and filter are packaged together in an integrated system, but each function independently. In this manual, there are separate specifications for the frequency converter and the filter. Since the frequency converter and filter are in the same enclosure, the unit is transported, installed, and operated as a single entity.

### 1.3.2 Working Principle

The low harmonic drive is a high-power frequency converter with an integrated active filter. An active filter is a device that actively monitors harmonic distortion levels and injects compensative harmonic current onto the line to cancel the harmonics.





Illustration 1.1 Basic Layout for the Low Harmonic Drive

Low harmonic drives are designed to draw an ideal sinusoidal current waveform from the supply grid with a power factor of 1. Where traditional non-linear load draws pulse-shaped currents, the low harmonic drive compensates that via the parallel filter path, lowering the stress on the supply grid. The low harmonic drive meets the highest harmonic standards with a THDi less than 5% at full load for <3% pre-distortion on a 3% unbalanced 3-phase grid.




### 1.3.3 Exploded View Drawings



130BE136.10

|   |                           |   |                                |
|---|---------------------------|---|--------------------------------|
| 1 | Local control panel (LCP) | 5 | Input/output terminal assembly |
| 2 | Control card assembly     | 6 | Capacitor bank assembly        |
| 3 | Power card assembly       | 7 | D1/D2 assembly                 |
| 4 | Terminal cover sheet      | 8 | EOC assembly                   |


Illustration 1.2 Enclosure Size D1n/D2n, Frequency Converter Enclosure



130BE110.10

|    |  |    |                              |
|----|--|----|------------------------------|
| 1  | Local control panel (LCP)                  | 13 | Mains fuses                  |
| 2  | Active filter card (AFC)                   | 14 | Mains disconnect             |
| 3  | Metal oxide varistor (MOV)                 | 15 | Mains terminals              |
| 4  | Soft charge resistors                      | 16 | Heat sink fan                |
| 5  | AC capacitors discharge board              | 17 | DC capacitor bank            |
| 6  | Mains contactor                            | 18 | Current transformer          |
| 7  | LC inductor                                | 19 | RFI differential mode filter |
| 8  | AC capacitors                              | 20 | RFI common mode filter       |
| 9  | Mains bus bar to frequency converter input | 21 | HI inductor                  |
| 10 | IGBT fuses                                 | 22 | Power card                   |
| 11 | RFI filter                                 | 23 | Gatedrive card               |
| 12 | Fuses                                      |    |                              |


Illustration 1.3 Enclosure Size D1n/D2n, Filter Enclosure



|    |                               |    |                                 |
|----|-------------------------------|----|---------------------------------|
| 1  | Control card                  | 14 | SCR and diode                   |
| 2  | Control input terminals       | 15 | Fan inductor (not on all units) |
| 3  | Local control panel (LCP)     | 16 | Soft charge resistor assembly   |
| 4  | Control card C option         | 17 | IGBT output bus bar             |
| 5  | Mounting bracket              | 18 | Fan assembly                    |
| 6  | Power card mounting plate     | 19 | Output motor terminals          |
| 7  | Power card                    | 20 | Current sensor                  |
| 8  | IGBT gatedrive card           | 21 | Mains AC power input terminals  |
| 9  | Upper capacitor bank assembly | 22 | Input terminal mounting plate   |
| 10 | Soft charge fuses             | 23 | AC input bus bar                |
| 11 | DC inductor                   | 24 | Soft charge card                |
| 12 | Fan transformer               | 25 | Lower capacitor bank assembly   |
| 13 | IGBT module                   |    |                                 |


Illustration 1.4 Enclosure Size E9, Frequency Converter Enclosure






|    |                                |    |                                  |
|----|--------------------------------|----|----------------------------------|
| 1  | Local control panel (LCP)      | 12 | AC capacitor current transducers |
| 2  | Active filter card (AFC)       | 13 | Heat sink fan                    |
| 3  | Mains contactors               | 14 | Mains terminals                  |
| 4  | Soft charge resistors          | 15 | Mains disconnect                 |
| 5  | RFI differential mode filter   | 16 | Mains fuses                      |
| 6  | RFI common mode filter         | 17 | LC inductor                      |
| 7  | Current transformer (CT)       | 18 | HI inductor                      |
| 8  | Mains bus bars to drive output | 19 | Power card                       |
| 9  | AC capacitors                  | 20 | Control card                     |
| 10 | RFI                            | 21 | LCP cradle                       |
| 11 | Lower DC capacitor bank        |    |                                  |

Illustration 1.5 Enclosure Size E9, Filter Enclosure




|   |                                |   |  |
|---|--------------------------------|---|--|
| 1 | Contactor                      | 4 | Circuit breaker or disconnect (if purchased) |
| 2 | RFI filter                     | 5 | AC mains/line fuses (if purchased)           |
| 3 | Mains AC power input terminals | 6 | Mains disconnect                             |

Illustration 1.6 Enclosure Size F18, Input Options Cabinet




|   |                               |    |   |
|---|-------------------------------|----|---|
| 1 | Local control panel (LCP)     | 10 | Mains bus bars to frequency converter input             |
| 2 | Active filter card (AFC)      | 11 | Heat sink fans  |
| 3 | Soft charge resistors         | 12 | Mains terminals (R/L1, S/L2, T/L3) from options cabinet |
| 4 | Metal oxide varistor (MOV)    | 13 | RFI differential mode filter                            |
| 5 | AC capacitors discharge board | 14 | RFI common mode filter                                  |
| 6 | LC inductor                   | 15 | Mains contactor   |
| 7 | HI inductor                   | 16 | Power card  |
| 8 | Mixing fan                    | 17 | Control card  |
| 9 | IGBT fuses                    | 18 | LCP cradle  |

Illustration 1.7 Enclosure Size F18, Filter Cabinet



|   |  |    |                      |
|---|--|----|----------------------|
| 1 | Rectifier module                                       | 8  | Module heat sink fan |
| 2 | DC bus bar   | 9  | Fan door cover       |
| 3 | SMPS fuse  | 10 | SMPS fuse            |
| 4 | (Optional) back AC fuse mounting bracket               | 11 | Power card           |
| 5 | (Optional) middle AC fuse mounting bracket             | 12 | Panel connectors     |
| 6 | (Optional) front AC fuse mounting bracket              | 13 | Control card         |
| 7 | Module lifting eye bolts (mounted on a vertical strut) |    |                      |

Illustration 1.8 Enclosure Size F18, Rectifier Cabinet



|   |                        |    |                      |
|---|------------------------|----|----------------------|
| 1 | Fan transformer        | 9  | Fan door cover       |
| 2 | DC-link inductor       | 10 | Module heat sink fan |
| 3 | Top cover plate        | 11 | Inverter module      |
| 4 | MDCIC board            | 12 | Panel connectors     |
| 5 | Control card           | 13 | DC fuse              |
| 6 | SMPS fuse and fan fuse | 14 | Mounting bracket     |
| 7 | Motor output bus bar   | 15 | (+) DC bus bar       |
| 8 | Brake output bus bar   | 16 | (-) DC bus bar       |

Illustration 1.9 Enclosure Size F18, Inverter Cabinet

## 1.4 Enclosure Sizes and Power Ratings

| Enclosure size                           |                 | D1n            | D2n            | E9             | F18            |
|--|-----------------|----------------|----------------|----------------|----------------|
| Enclosure protection                     | IP              | 21/54          | 21/54          | 21/54          | 21/54          |
|  | NEMA            | Type 1/Type 12 | Type 1/Type 12 | Type 1/Type 12 | Type 1/Type 12 |
| Frequency converter dimensions [mm (in)] | Height          | 1740 (69)      | 1740 (69)      | 2000.7 (79)    | 2278.4 (90)    |
|  | Width           | 915 (36)       | 1020 (40)      | 1200 (47)      | 2792 (110)     |
|  | Depth           | 380 (15)       | 380 (15)       | 493.5 (19)     | 605.8 (24)     |
| Frequency converter weights [kg (lb)]    | Maximum weight  | 353 (777)      | 413 (910)      | 676 (1490)     | 1900 (4189)    |
|  | Shipping weight | 416 (917)      | 476 (1050)     | 840 (1851)     | 2345 (5171)    |

Table 1.1 Mechanical Dimensions, Enclosure Sizes D, E, and F

## 1.5 Approvals and Certifications

### 1.5.1 Approvals



Table 1.2 Compliance Marks: CE, UL, and C-Tick

### 1.5.2 Compliance with ADN

For compliance with the European Agreement concerning International Carriage of Dangerous Goods by Inland Waterways (ADN), refer to *ADN-compliant Installation* in the *design guide*.

#### **NOTICE**

#### **IMPOSED LIMITATIONS ON THE OUTPUT FREQUENCY**

From software version 3.92, the output frequency of the frequency converter is limited to 590 Hz (due to export control regulations):.

## 1.6 Harmonics Overview

### 1.6.1 Harmonics

Non-linear loads such as found with 6-pulse frequency converters do not draw current uniformly from the power line. This non-sinusoidal current has components which are multiples of the fundamental current frequency. These components are referred to as harmonics. It is important to control the total harmonic distortion on the mains supply. Although the harmonic currents do not directly affect electrical energy consumption, they generate heat in wiring and transformers and can impact other devices on the same power line.

### 1.6.2 Harmonic Analysis

Since harmonics increase heat losses, it is important to design systems with harmonics in mind to prevent overloading the transformer, inductors, and wiring.

When necessary, perform an analysis of the system harmonics to determine equipment effects.

A non-sinusoidal current is transformed with a Fourier series analysis into sine-wave currents at different frequencies, that is, different harmonic currents  $I_n$  with 50 Hz or 60 Hz as the fundamental frequency.

| Abbreviation | Description                                       |
|--------------|---|
| $f_1$        | Fundamental frequency (50 Hz or 60 Hz)            |
| $I_1$        | Current at the fundamental frequency              |
| $U_1$        | Voltage at the fundamental frequency              |
| $I_n$        | Current at the $n^{\text{th}}$ harmonic frequency |
| $U_n$        | Voltage at the $n^{\text{th}}$ harmonic frequency |
| $n$          | Harmonic order                                    |

Table 1.3 Harmonics-related Abbreviations

|                | Fundamental current ( $I_1$ ) | Harmonic current ( $I_n$ ) |       |          |
|----------------|-------------------------------|----------------------------|-------|----------|
| Current        | $I_1$                         | $I_5$                      | $I_7$ | $I_{11}$ |
| Frequency [Hz] | 50                            | 250                        | 350   | 550      |

Table 1.4 Fundamental and Harmonic Currents

| Current       | Harmonic current |       |       |       |             |
|---------------|------------------|-------|-------|-------|-------------|
|               | $I_{\text{RMS}}$ | $I_1$ | $I_5$ | $I_7$ | $I_{11-49}$ |
| Input current | 1.0              | 0.9   | 0.5   | 0.2   | <0.1        |

Table 1.5 Harmonic Currents Compared to the RMS Input Current


The voltage distortion on the mains supply voltage depends on the size of the harmonic currents multiplied

by the mains impedance for the frequency in question. The total voltage distortion (THDi) is calculated based on the individual voltage harmonics using this formula:

$$THDi = \frac{\sqrt{U_{25}^2 + U_{27}^2 + \dots + U_{2n}^2}}{U}$$

### 1.6.3 Effect of Harmonics in a Power Distribution System

In *Illustration 1.10*, a transformer is connected on the primary side to a point of common coupling PCC1, on the medium voltage supply. The transformer has an impedance  $Z_{xfr}$  and feeds several loads. The point of common coupling where all loads are connected is PCC2. Each load is connected through cables that have an impedance  $Z_1$ ,  $Z_2$ ,  $Z_3$ .



|           |  |
|-----------|--|
| PCC       | Point of common coupling                         |
| MV        | Medium voltage                                   |
| LV        | Low voltage                                      |
| $Z_{xfr}$ | Transformer impedance                            |
| $Z_{\#}$  | Modeling resistance and inductance in the wiring |

Illustration 1.10 Small Distribution System

Harmonic currents drawn by non-linear loads cause distortion of the voltage because of the voltage drop on the impedances of the distribution system. Higher impedances result in higher levels of voltage distortion.

Current distortion relates to apparatus performance and it relates to the individual load. Voltage distortion relates to system performance. It is not possible to determine the voltage distortion in the PCC knowing only the harmonic performance of the load. To predict the distortion in the PCC, the configuration of the distribution system and relevant impedances must be known.

A commonly used term for describing the impedance of a grid is the short circuit ratio  $R_{scc}$ .  $R_{scc}$  is defined as the ratio between the short circuit apparent power of the supply at the PCC ( $S_{sc}$ ) and the rated apparent power of the load ( $S_{equ}$ ).

$$R_{scc} = \frac{S_{sc}}{S_{equ}}$$

where  $S_{sc} = \frac{U^2}{Z_{supply}}$  and  $S_{equ} = U \times I_{equ}$

#### Negative effects of harmonics

- Harmonic currents contribute to system losses (in cabling and transformer).
- Harmonic voltage distortion causes disturbance to other loads and increases losses in other loads.



## 1.6.5 IEC Harmonic Standards

The mains voltage is rarely a uniform sinusoidal voltage with constant amplitude and frequency because loads that draw non-sinusoidal currents from the mains have non-linear characteristics.

Harmonics and voltage fluctuations are two forms of low-frequency mains interference. They have a different appearance at their origin than at any other point in the mains system when a load is connected. So, a range of influences must be determined collectively when assessing the effects of mains interference. These influences include the mains feed, structure, and loads.

### Undervoltage warnings

Mains interference can cause the following:

- Incorrect voltage measurements due to distortion of the sinusoidal mains voltage.
- Cause incorrect power measurements because only RMS-true measuring takes harmonic content into account.

### Higher functional losses

- Harmonics reduce the active power, apparent power, and reactive power.
- Distort electrical loads resulting in audible interference in other devices, or in worst case, even destruction.
- Shorten the lifetime of devices as a result of heating.

In most of Europe, the basis for the objective assessment of the quality of mains power is the Electromagnetic Compatibility of Devices Act (EMVG). Compliance with these regulations ensures that all devices and networks connected to electrical distribution systems fulfill their intended purpose without generating problems.

| Standard                             | Definition   |
|--------------------------------------|--|
| EN 61000-2-2, EN 61000-2-4, EN 50160 | Define the mains voltage limits required for public and industrial power grids       |
| EN 61000-3-2, 61000-3-12             | Regulate mains interference generated by connected devices in lower current products |
| EN 50178                             | Monitors electronic equipment for use in power installations                         |

**Table 1.6 EN Design Standards for Mains Power Quality**

There are 2 European standards that address harmonics in the frequency range from 0 Hz to 9 kHz:

EN 61000–2–2 (Compatibility Levels for Low-Frequency Conducted Disturbances and Signaling in Public Low-Voltage Power Supply Systems) states the requirements for compatibility levels for PCC (point of common coupling) of low voltage AC systems on a public supply network. Limits are specified only for harmonic voltage and total harmonic distortion of the voltage. EN 61000–2–2 does not define limits for harmonic currents. In situations where the total harmonic distortion THD(V)=8%, PCC limits are identical to those limits specified in the EN 61000–2–4 Class 2.

EN 61000–2–4 (Compatibility Levels for Low-Frequency Conducted Disturbances and Signaling in Industrial Plants) states the requirements for compatibility levels in industrial and private networks.

The standard further defines the following 3 classes of electromagnetic environments:

- Class 1 relates to compatibility levels that are less than the public supply network, which affects equipment sensitive to disturbances (lab equipment, some automation equipment, and certain protection devices).
- Class 2 relates to compatibility levels that are equal to the public supply network. The class applies to PCCs on the public supply network and to IPCs (internal points of coupling) on industrial or other private supply networks. Any equipment designed for operation on a public supply network is allowed in this class.
- Class 3 relates to compatibility levels greater than the public supply network. This class applies only to IPCs in industrial environments. Use this class where the following equipment is found:
  - Large converters
  - Welding machines
  - Large motors starting frequently
  - Loads that change quickly

Typically, a class cannot be defined ahead of time without taking into account the intended equipment and processes to be used in the environment. VLT® HVAC Drive FC 102 Low Harmonic Drive observes the limits of Class 3 under typical supply system conditions ( $R_{SC} > 10$  or  $V_k \text{ Line} < 10\%$ ).

| Harmonic order (h) | Class 1 ( $V_h\%$ )         | Class 2 ( $V_h\%$ )         | Class 3 ( $V_h\%$ )       |
|--------------------|-----------------------------|-----------------------------|---------------------------|
| 5                  | 3                           | 6                           | 8                         |
| 7                  | 3                           | 5                           | 7                         |
| 11                 | 3                           | 3.5                         | 5                         |
| 13                 | 3                           | 3                           | 4.5                       |
| 17                 | 2                           | 2                           | 4                         |
| $17 < h \leq 49$   | $2.27 \times (17/h) - 0.27$ | $2.27 \times (17/h) - 0.27$ | $4.5 \times (17/h) - 0.5$ |

Table 1.7 Compatibility Levels for Harmonics

|        | Class 1 | Class 2 | Class 3 |
|--------|---------|---------|---------|
| THD(V) | 5%      | 8%      | 10%     |

Table 1.8 Compatibility Levels for the Total Harmonic Voltage Distortion THD(V)

## 1.6.6 IEEE Harmonic Standards

The IEEE 519 standard (Recommended Practices and Requirements for Harmonic Control in Electrical Power Systems) provides specific limits for harmonic voltages and currents for individual components within the supply network. The standard also provides limits for the sum of all loads at the point of common coupling (PCC).

To determine permissible harmonic voltage levels, IEEE 519 uses a ratio between the supply short circuit current and the maximum current of the individual load. For permissible harmonic voltage levels for individual loads, see *Table 1.9*. For permissible levels for all loads connected to the PCC, see *Table 1.10*.

| $I_{sc}/I_L (R_{sCE})$ | Permissible individual harmonic voltages | Typical areas            |
|------------------------|--|--------------------------|
| 10                     | 2.5–3%                                   | Weak grid                |
| 20                     | 2.0–2.5%                                 | 1–2 large loads          |
| 50                     | 1.0–1.5%                                 | A few high-output loads  |
| 100                    | 0.5–1%                                   | 5–20 medium-output loads |
| 1000                   | 0.05–0.1%                                | Strong grid              |

**Table 1.9 Permissible Voltage THD at the PCC for Each Individual Load**

| Voltage at the PCC            | Permissible individual harmonic voltages | Permissible THD(V) |
|-------------------------------|--|--------------------|
| $V_{Line} \leq 69 \text{ kV}$ | 3%                                       | 5%                 |

**Table 1.10 Permissible Voltage THD at the PCC for all Loads**

Limit harmonic currents to specified levels, as shown in *Table 1.11*. IEEE 519 utilizes a ratio between the supply short circuit current and the maximum current consumption at the PCC, averaged over 15 minutes or 30 minutes. In certain instances when dealing with harmonic limits containing low harmonic numbers, the IEEE 519 limits are lower than the 61000-2-4 limits. Low harmonic drives observe the total harmonic distortion as defined in IEEE 519 for all  $R_{sCE}$ . Each individual harmonic current fulfills table 10-3 in IEEE 519 for  $R_{sCE} \geq 20$ .

| $I_{sc}/I_L (R_{sCE})$ | $h < 11$ | $11 \leq h < 17$ | $17 \leq h < 23$ | $23 \leq h < 35$ | $35 \leq h$ | Total demand distortion TDD |
|------------------------|----------|------------------|------------------|------------------|-------------|-----------------------------|
| $< 20$                 | 4%       | 2.0%             | 1.5%             | 0.6%             | 0.3%        | 5%                          |
| $20 < 50$              | 7%       | 3.5%             | 2.5%             | 1.0%             | 0.5%        | 8%                          |
| $50 < 100$             | 10%      | 4.5%             | 4.0%             | 1.5%             | 0.7%        | 12%                         |
| $100 < 1000$           | 12%      | 5.5%             | 5.0%             | 2.0%             | 1.0%        | 15%                         |
| $> 1000$               | 15%      | 7.0%             | 6.0%             | 2.5%             | 1.4%        | 20%                         |

**Table 1.11 Permissible Harmonic Currents at the PCC**

The VLT® HVAC Drive FC 102 Low Harmonic Drive complies with the following standards:

- IEC61000-2-4
- IEC61000-3-4
- IEEE 519
- G5/4

# 2

## 2 Safety

### 2.1 Safety Symbols

The following symbols are used in this document:

#### **⚠ WARNING**

Indicates a potentially hazardous situation which could result in death or serious injury.

#### **⚠ CAUTION**

Indicates a potentially hazardous situation which could result in minor or moderate injury. It may also be used to alert against unsafe practices.

#### **NOTICE**

Indicates important information, including situations that may result in damage to equipment or property.

### 2.2 Qualified Personnel

Correct and reliable transport, storage, installation, operation, and maintenance are required for the safe operation of the frequency converter. Only qualified personnel are allowed to install or operate this equipment.

Qualified personnel is defined as trained staff, who are authorized to install, commission, and maintain equipment, systems, and circuits in accordance with pertinent laws and regulations. Additionally, qualified personnel are familiar with the instructions and safety measures described in this document.

### 2.3 Safety Precautions

#### **⚠ WARNING**

##### **HIGH VOLTAGE**

Frequency converters contain high voltage when connected to AC mains input power. Qualified personnel only should perform installation, start up, and maintenance. Failure to perform installation, start up, and maintenance by qualified personnel could result in death or serious injury.

#### **⚠ WARNING**

##### **UNINTENDED START**

When the frequency converter is connected to AC mains, the motor may start at any time. The frequency converter, motor, and any driven equipment must be in operational readiness. Failure to be in operational readiness when the frequency converter is connected to AC mains could result in death, serious injury, equipment, or property damage.

#### **⚠ WARNING**

##### **DISCHARGE TIME**

The frequency converter contains DC-link capacitors, which can remain charged even when the frequency converter is not powered. High voltage can be present even when the warning LED indicator lights are off. Failure to wait the specified time after power has been removed before performing service or repair work can result in death or serious injury.

- Stop the motor.
- Disconnect AC mains and remote DC-link power supplies, including battery back-ups, UPS, and DC-link connections to other frequency converters.
- Disconnect or lock PM motor.
- Wait for the capacitors to discharge fully. The minimum duration of waiting time is specified in *Table 2.1*.
- Before performing any service or repair work, use an appropriate voltage measuring device to make sure that the capacitors are fully discharged.

| Voltage [V] | Power ranges for normal overload operation [kW/(hp)] | Minimum waiting time (minutes) |
|-------------|--|--------------------------------|
| 380–480     | 160–250<br>(250–350)                                 | 20                             |
|             | 315–710<br>(450–1000)                                | 40                             |

Table 2.1 Discharge Times

## 3 Mechanical Installation

### 3.1 Equipment Pre-Installation Checklist

#### 3.1.1 Planning the Installation Site

#### **CAUTION**

**It is important to plan the installation of the frequency converter. Neglecting to plan may result in extra work during and after installation.**

Select the best possible operation site by considering the following:

- Ambient operating temperature.
- Installation method.
- How to cool the unit.
- Position of the frequency converter.
- Cable routing.
- Ensure that the power source supplies the correct voltage and necessary current.
- Ensure that the motor current rating is within the maximum current from the frequency converter.
- If the frequency converter is without built-in fuses, ensure that the external fuses are rated correctly.

### 3.1.2 Equipment Pre-Installation Checklist


- Before unpacking the frequency converter, examine the packaging for signs of damage. If the unit is damaged, refuse delivery, and immediately contact the shipping company to claim the damage.
- Before unpacking the frequency converter, locate it as close as possible to the final installation site.
- Compare the model number on the nameplate to what was ordered to verify the proper equipment.
- Ensure that each of the following are rated for the same voltage:
  - Mains (power)
  - Frequency converter
  - Motor
- Ensure that the output current rating is equal to or greater than the motor full load current for peak motor performance.
  - Motor size and frequency converter power must match for proper overload protection.
  - If the frequency converter rating is less than that of the motor, full motor output is impossible.

## 3.2 Unpacking

### 3.2.1 Items Supplied

Items supplied may vary according to product configuration.

- Make sure that the items supplied and the information on the nameplate correspond to the order confirmation.
- Check the packaging and the frequency converter visually for damage caused by inappropriate handling during shipment. File any claim for damage with the carrier. Retain damaged parts for clarification.



|    |   |
|----|---|
| 1  | Type code   |
| 2  | Code number   |
| 3  | Serial number   |
| 4  | Power rating  |
| 5  | Input voltage, frequency, and current (at low/high voltages)  |
| 6  | Output voltage, frequency, and current (at low/high voltages) |
| 7  | Enclosure type and IP rating                                  |
| 8  | Maximum ambient temperature                                   |
| 9  | Certifications  |
| 10 | Discharge time (Warning)                                      |

Illustration 3.1 Product Nameplate (Example)

### NOTICE

Do not remove the nameplate from the frequency converter (loss of warranty).

### 3.3 Mounting

#### 3.3.1 Cooling and Airflow

##### Cooling

Obtain cooling by taking air in through the plinth in the front and out of the top, in and out the back of the unit, or by combining the cooling possibilities.

##### Back cooling

The backchannel air can also be ventilated in and out the back. This offers a solution where the backchannel could take air from outside the facility and return the heat losses outside the facility, thus reducing air-conditioning requirements.

##### Airflow

Secure the necessary airflow over the heat sink. The flow rate is shown in *Table 3.1*.

| Enclosure protection        | Enclosure size | Door fan/top fan airflow<br>Total airflow of multiple fans       | Heat sink fan<br>Total airflow for multiple fans  |
|-----------------------------|----------------|--|---|
| IP21/NEMA 1<br>IP54/NEMA 12 | D1n            | 3 door fans, 442 m <sup>3</sup> /h<br>2+1=2x170+102              | 2 heat sink fans, 1185 m <sup>3</sup> /h<br>(1+1=765+544)                               |
|                             | D2n            | 3 door fan, 544 m <sup>3</sup> /h<br>2+1=2x170+204               | 2 heat sink fans, 1605 m <sup>3</sup> /h<br>(1+1=765+840)                               |
|                             | E9             | 4 door fans, 680 m <sup>3</sup> /h (400 cfm)<br>(2+2, 4x170=680) | 2 heat sink fans, 2675 m <sup>3</sup> /h<br>(1574 cfm)<br>(1+1, 1230+1445=2675)         |
|                             | F18            | 6 door fans, 3150 m <sup>3</sup> /h (1854 cfm)<br>(6x525=3150)   | 5 heat sink fans, 4485 m <sup>3</sup> /h<br>(2639 cfm)<br>2+1+2, ((2x765)+(3x985)=4485) |

Table 3.1 Heat Sink Air Flow

#### **NOTICE**

For the frequency converter section, the fan runs for the following reasons:

- AMA.
- DC hold.
- Pre-mag.
- DC brake.
- 60% of nominal current is exceeded.
- Specific heat sink temperature exceeded (power size dependent).
- Specific power card ambient temperature exceeded (power size dependent).
- Specific control card ambient temperature exceeded.

Once the fan is started, it runs for minimum 10 minutes.

#### **NOTICE**

For the active filter, the fan runs for the following reasons:


- Active filter running.
- Active filter not running, but mains current exceeding the limit (power size dependent).
- Specific heat sink temperature exceeded (power size dependent).
- Specific power card ambient temperature exceeded (power size dependent).
- Specific control card ambient temperature exceeded.

Once the fan is started, it runs for minimum 10 minutes.




### External ducts


If additional duct work is added externally to the Rittal cabinet, calculate the pressure drop in the ducting. Use *Illustration 3.2*, *Illustration 3.3*, and *Illustration 3.4* to derate the frequency converter according to the pressure drop.



**Illustration 3.2 D-Enclosure Derating vs. Pressure Change**  
Frequency Converter Air Flow: 450 cfm (765 m³/h)




**Illustration 3.3 E-Enclosure Derating vs. Pressure Change**  
Frequency Converter Air Flow: 850 cfm (1445 m³/h)




**Illustration 3.4 F-Enclosure Derating vs. Pressure Change**  
Frequency Converter Air Flow: 580 cfm (985 m³/h)

### 3.3.2 Lifting

Lift the frequency converter using the dedicated lifting eyes. For all D-frames, use a bar to avoid bending the lifting holes of the frequency converter.




**Illustration 3.5 Recommended Lifting Method, Enclosure Size D1n/D2n**



**Illustration 3.6 Recommended Lifting Method, Enclosure Size E9**

### ⚠ WARNING

The lifting bar must be able to handle the weight of the frequency converter. See *chapter 8.2 Mechanical Dimensions* for the weight of the different enclosure sizes. Maximum diameter for the bar is 2.5 cm (1 in). The angle from the top of the frequency converter to the lifting cable should be 60° or greater.



|   |   |
|---|---|
| 1 | Lifting holes for the filter              |
| 2 | Lifting holes for the frequency converter |

Illustration 3.7 Recommended Lifting Method, Enclosure Size F18

### **NOTICE**

A spreader bar is also an acceptable way to lift the F-frame.

### **NOTICE**


The F18 pedestal is packaged separately and included in the shipment. Mount the frequency converter on the pedestal in its final location. The pedestal allows proper airflow and cooling.

### 3.3.3 Cable Entry and Anchoring

Cables enter the unit through gland plate openings in the bottom. *Illustration 3.8*, *Illustration 3.9*, *Illustration 3.10*, and *Illustration 3.11* show gland entry locations and detailed views of anchoring hole dimensions.


3

#### Bottom view, D1n/D2n



130BET12.10


Illustration 3.8 Cable Entry Diagram, Enclosure Size D1n



|   |                       |
|---|-----------------------|
| 1 | Cable entry locations |
|---|-----------------------|

Illustration 3.9 Cable Entry Diagram, Enclosure Size D2n


Bottom view, enclosure size E9



|   |                       |
|---|-----------------------|
| 1 | Cable entry locations |
|---|-----------------------|

Illustration 3.10 Cable Entry Diagram, E9

Bottom view, F18



|   |                   |   |                     |
|---|-------------------|---|---------------------|
| 1 | Mains cable entry | 4 | Motor cable entry   |
| 2 | Option enclosure  | 5 | Inverter enclosure  |
| 3 | Filter enclosure  | 6 | Rectifier enclosure |

Illustration 3.11 Cable Entry Diagram, F18

### 3.3.4 Terminal Locations for Enclosure Size D1n/D2n




Illustration 3.12 Terminal Locations, Enclosure Size D1n






Illustration 3.13 Terminal Locations, Enclosure Size D2n

Allow for bend radius of heavy power cables.

**NOTICE**

All D-frames are available with standard input terminals, fuse, or disconnect switch.

### 3.3.5 Terminal Locations for Enclosure Size E9

3




Illustration 3.14 Terminal Locations, Enclosure Size E9

Allow for bend radius of heavy power cables.

#### **NOTICE**

All E-frames are available with standard input terminals, fuse, or disconnect switch.




Illustration 3.15 Close-up Terminal Diagrams


### 3.3.6 Terminal Locations for Enclosure Size F18

Consider the position of the terminals when designing the cable access.

F-frame units have 4 interlocked cabinets:

- Input options cabinet (not optional for LHD)
- Filter cabinet
- Rectifier cabinet
- Inverter cabinet

See *chapter 1.3.3 Exploded View Drawings* for exploded views of each cabinet. Mains inputs are located in the input option cabinet, which conducts power to the rectifier via interconnecting bus bars. Output from the unit is from the inverter cabinet. No connection terminals are located in the rectifier cabinet. Interconnecting bus bars are not shown.




|   |                     |   |                    |
|---|---------------------|---|--------------------|
| 1 | Right side cut-away | 3 | Left side cut-away |
| 2 | Front view          | 4 | Ground bar         |

Illustration 3.16 Input Option Cabinet, Enclosure Size F18 - Fuses Only

The gland plate is 42 mm below the 0 level. Shown are the left side view, front, and right.


3



|  | 500 kW <sup>1)</sup> (mm (in)) | 560–710 kW <sup>1)</sup> (mm (in)) |
|--|--------------------------------|------------------------------------|
| 1  | Ground bar                     |                                    |
| 2  | 34.9 (1.4)                     | 46.3 (1.8)                         |
| 3  | 86.9 (3.4)                     | 98.3 (3.9)                         |
| 4  | 122.2 (4.8)                    | 119 (4.7)                          |
| 5  | 174.2 (6.9)                    | 171 (6.7)                          |
| 1) Disconnect location and related dimensions vary with kW rating. |                                |                                    |

Illustration 3.17 Input Option Cabinet with Circuit Breaker, Enclosure Size F18

The gland plate is 42 mm below the 0 level. Shown are the left side view, front, and right.



|   |                 |
|---|-----------------|
| 1 | Front view      |
| 2 | Left side view  |
| 3 | Right side view |

Illustration 3.18 Inverter Cabinet, Enclosure Size F18

The gland plate is 42 mm below the 0 level. Shown are the left side view, front, and right.

### 3.3.7 Torque

Correct torque is imperative for all electrical connections. The correct values are listed in *Table 3.2*. Incorrect torque results in a bad electrical connection. Use a torque wrench to ensure correct torque.

| Enclosure size | Terminal          | Torque [Nm] (in-lbs) | Bolt size |
|----------------|-------------------|----------------------|-----------|
| D              | Mains Motor       | 19–40<br>(168–354)   | M10       |
|                | Regen Brake       | 8.5–20.5<br>(75–181) | M8        |
| E              | Mains Motor Regen | 19–40<br>(168–354)   | M10       |
|                | Brake             | 8.5–20.5<br>(75–181) | M8        |
| F              | Mains Motor       | 19–40<br>(168–354)   | M10       |
|                | Brake             | 8.5–20.5<br>(75–181) | M8        |
|                | Regen             | 8.5–20.5<br>(75–181) | M8        |

Table 3.2 Torque for Terminals

## 4 Electrical Installation

### 4.1 Safety Instructions

See *chapter 2 Safety* for general safety instructions.

4

#### **WARNING**

##### INDUCED VOLTAGE

Induced voltage from output motor cables that run together can charge equipment capacitors, even with the equipment turned off and locked out. Failure to run output motor cables separately or to use shielded cables could result in death or serious injury.

- Run output motor cables separately, or
- Use shielded cables.

#### **CAUTION**

##### SHOCK HAZARD

The frequency converter can cause a DC current in the PE conductor. Failure to follow the recommendation may lead to the RCD not providing the intended protection.

- When a residual current-operated protective device (RCD) is used for protection against electrical shock, only an RCD of Type B is permitted on the supply side.

##### Overcurrent protection

- Extra protective equipment, such as short-circuit protection or motor thermal protection between frequency converter and motor, is required for applications with multiple motors.
- Input fusing is required to provide short circuit and overcurrent protection. If not factory-supplied, the installer must provide fuses. See maximum fuse ratings in *chapter 8.4 Fuses*.

##### Wire type and ratings

- All wiring must comply with local and national regulations regarding cross-section and ambient temperature requirements.
- Power connection wire recommendation: Minimum 75 °C rated copper wire.

See *chapter 8.3 General Technical Data* and *chapter 8.1 Power-Dependent Specifications* for recommended wire sizes and types.

### 4.2 EMC Compliant Installation

To obtain an EMC-compliant installation, follow the instructions provided in *chapter 4.3 Power Connections*, *chapter 4.4 Grounding*, *chapter 4.6 Motor Connection*, and *chapter 4.8 Control Wiring*.

### 4.3 Power Connections

#### **NOTICE**

##### Cables, general information

All cabling must comply with national and local regulations on cable cross-sections and ambient temperature. UL applications require 75 °C copper conductors. For non-UL applications, 75 and 90 °C copper conductors are thermally acceptable.

The power cable connections are located as shown in *Illustration 4.1*. Dimension cable cross-section in accordance with the current ratings and local legislation. See *chapter 8.3.1 Cable lengths and cross-sections* for details.

For protection of the frequency converter, use the recommended fuses if there are no built-in fuses. Fuse recommendations are provided in *chapter 8.4 Fuses*. Ensure that proper fusing is made according to local regulation.

If included, the mains connection is fitted to the mains switch.




Illustration 4.1 Power Cable Connections

#### **NOTICE**

To comply with EMC emission specifications, screened/armoured cables are recommended. If an unscreened/unarmoured cable is used, see *chapter 4.7.3 Power and Control Wiring for Unscreened Cables*.

See *chapter 8 Specifications* for correct dimensioning of motor cable cross-section and length.

##### Screening of cables

Avoid installation with twisted shield ends (pigtails). They spoil the screening effect at higher frequencies. If breaking the shield is necessary to install a motor isolator or contactor, continue the shield at the lowest possible HF impedance.

Connect the motor cable screen to both the decoupling plate of the frequency converter and to the metal housing of the motor.

Make the shield connections with the largest possible surface area (cable clamp). Use the installation devices within the frequency converter.

#### Cable length and cross-section

The frequency converter has been EMC-tested with a given cable length. To reduce the noise level and leakage currents, keep the motor cable as short as possible.

#### Switching frequency

When frequency converters are used with sine-wave filters to reduce the acoustic noise from a motor, set the switching frequency according to *parameter 14-01 Switching Frequency*.

| Terminal number | 96 | 97 | 98 | 99               |  |
|-----------------|----|----|----|------------------|--|
|                 | U  | V  | W  | PE <sup>1)</sup> | Motor voltage 0–100% of mains voltage.<br>3 wires out of motor               |
|                 | U1 | V1 | W1 | PE <sup>1)</sup> | Delta-connected  |
|                 | W2 | U2 | V2 |                  | 6 wires out of motor   |
|                 | U1 | V1 | W1 | PE <sup>1)</sup> | Star-connected U2, V2, W2<br>U2, V2, and W2 to be interconnected separately. |

Table 4.1 Terminal Connections

1) Protective earth connection




Illustration 4.2 Y and Delta Terminal Configurations

## 4.4 Grounding

### ⚠ WARNING

#### GROUNDING HAZARD!

For operator safety, it is important to ground the frequency converter properly in accordance with national and local electrical codes and instructions contained within this document. Do not use conduit connected to the frequency converter as a replacement for proper grounding. Ground currents are higher than 3.5 mA. Failure to ground the frequency converter properly could result in death or serious injury.

### NOTICE

It is the responsibility of the user or certified electrical installer to ensure correct grounding of the equipment in accordance with national and local electrical codes and standards.

- Follow all local and national electrical codes to ground electrical equipment properly.
- Establish proper protective earthing for equipment with ground currents higher than 3.5 mA, see *chapter 4.4.1 Leakage Current (>3.5 mA)*.
- A dedicated ground wire is required for input power, motor power, and control wiring.
- Use the clamps provided with the equipment for proper ground connections.
- Do not ground one frequency converter to another in a "daisy chain" fashion.
- Keep the ground wire connections as short as possible.
- Using high-strand wire to reduce electrical noise is recommended.
- Follow motor manufacturer wiring requirements.

### 4.4.1 Leakage Current (>3.5 mA)

Follow national and local codes regarding protective earthing of equipment with a leakage current >3.5 mA. Frequency converter technology implies high frequency switching at high power. This generates a leakage current in the ground connection. A fault current in the frequency converter at the output power terminals might contain a DC component, which can charge the filter capacitors and cause a transient ground current. The ground leakage current depends on various system configurations including RFI filtering, shielded motor cables, and frequency converter power.



EN/IEC61800-5-1 (Power Drive System Product Standard) requires special care if the leakage current exceeds 3.5 mA. Grounding must be reinforced in 1 of the following ways:

- Ground wire of at least 10 mm<sup>2</sup> (8 AWG).
- 2 separate ground wires both complying with the dimensioning rules.

See EN 60364-5-54 § 543.7 for further information.

## 4.5 Input Options

### 4.5.1 Extra Protection (RCD)

ELCB relays, multiple protective earthing, or standard grounding provide extra protection, if local safety regulations are followed.

In the case of a ground fault, a DC component develops in the fault current.

If using ELCB relays, observe local regulations. Relays must be suitable for protection of 3-phase equipment with a bridge rectifier and for a brief discharge on power-up.

### 4.5.2 RFI Switch

#### Mains supply isolated from ground

If the frequency converter is supplied from an isolated mains source or TT/TN-S mains with grounded leg, turn off the RFI switch via *parameter 14-50 RFI Filter* on both frequency converter and the filter. For further reference, see IEC 364-3. When optimum EMC performance is needed, parallel motors are connected, or the motor cable length is above 25 m, set *parameter 14-50 RFI Filter* to [ON]. In OFF, the internal RFI capacitors (filter capacitors) between the enclosure and the DC link are cut off to avoid damage to the DC link and reduce ground capacity currents (IEC 61800-3).

Refer to the application note *VLT on IT mains*. It is important to use isolation monitors that work together with power electronics (IEC 61557-8).

### 4.5.3 Shielded Cables

It is important to connect shielded cables properly to ensure high EMC immunity and low emissions.

Connection can be made using either cable glands or clamps:

- EMC cable glands: Generally available cable glands can be used to ensure an optimum EMC connection.
- EMC cable clamp: Clamps allowing easy connection are supplied with the unit.

## 4.6 Motor Connection

### 4.6.1 Motor Cable

Connect the motor to terminals U/T1/96, V/T2/97, W/T3/98, on the far right of the unit. Ground to terminal 99. All types of 3-phase asynchronous standard motors can be used with a frequency converter. The factory setting is for clockwise rotation with the frequency converter output connected as follows:

| Terminal number | Function               |
|-----------------|------------------------|
| 96, 97, 98      | Mains U/T1, V/T2, W/T3 |
| 99              | Ground                 |

Table 4.2 Terminal Functions

- Terminal U/T1/96 connected to U-phase.
- Terminal V/T2/97 connected to V-phase.
- Terminal W/T3/98 connected to W-phase.

The direction of rotation can be changed by switching 2 phases in the motor cable or by changing the setting of *parameter 4-10 Motor Speed Direction*.

To check motor rotation, select *parameter 1-28 Motor Rotation Check* and follow the steps on the display.




Illustration 4.3 Motor Rotation Check

#### F-frame requirements

Use motor phase cables in quantities of 2, resulting in 2, 4, 6, or 8 to obtain an equal number of wires on both inverter module terminals. The cables are required to be of equal length within 10% between the inverter module terminals and the first common point of a phase. The recommended common point is the motor terminals.

#### Output junction box requirements

The length, minimum 2.5 m (8 ft), and quantity of cables must be equal from each inverter module to the common terminal in the junction box.

### NOTICE

If a retrofit application requires an unequal number of wires per phase, consult the factory or use the top/bottom entry side cabinet option instruction.

## 4.6.2 Brake Cable

Frequency converters with factory installed brake chopper option.

(Only standard with letter B in position 18 in the type code).

The connection cable to the brake resistor must be shielded, and the maximum length from frequency converter to the DC bar is limited to 25 m (82 ft).

| Terminal number | Function                 |
|-----------------|--------------------------|
| 81, 82          | Brake resistor terminals |

Table 4.3 Terminal Functions

Connect the shield with cable clamps to the conductive backplate of the frequency converter and the metal cabinet of the brake resistor. Size the brake cable cross-section to match the brake torque.

### WARNING

Note that voltages up to 790 V DC, depending on the supply voltage, are possible on the terminals.

#### F-frame requirements

Connect the brake resistors to the brake terminals in each inverter module.

## 4.6.3 Motor Insulation

For motor cable lengths  $\leq$  the maximum cable length, the motor insulation ratings listed in Table 4.4 are recommended. The peak voltage can be twice the DC-link voltage or 2.8 times mains voltage, due to transmission line effects in the motor cable. If a motor has lower insulation rating, use a dU/dt or sine-wave filter.

| Nominal mains voltage      | Motor insulation           |
|----------------------------|----------------------------|
| $U_N \leq 420$ V           | Standard $U_{LL}=1300$ V   |
| $420$ V $< U_N \leq 500$ V | Reinforced $U_{LL}=1600$ V |

Table 4.4 Recommended Motor Insulation Ratings

#### 4.6.4 Motor Bearing Currents

Motors with a rating of 110 kW or higher combined with frequency converters are best with NDE (non-drive end) insulated bearings to eliminate circulating bearing currents caused by motor size.

To minimize DE (drive end) bearing and shaft currents, proper grounding is required for:

- The frequency converter.
- The motor.
- Motor-driven machine.
- Motor to the driven machine.

Although failure due to bearing currents is infrequent, use the following strategies to reduce the likelihood:

- Use an insulated bearing.
- Apply rigorous installation procedures.
- Ensure that the motor and load motor are aligned.
- Strictly follow the EMC installation guideline.
- Reinforce the PE so the high frequency impedance is lower in the PE than the input power leads.
- Provide a good high frequency connection between the motor and the frequency converter.
- Ensure that the impedance from frequency converter to building ground is lower than the grounding impedance of the machine. Make a direct ground connection between the motor and load motor.
- Apply conductive lubrication.
- Balance the mains voltage to ground.
- Use an insulated bearing as recommended by the motor manufacturer.

#### **NOTICE**

**Motors from reputable manufacturers typically have insulated bearings as standard in motors of this size.**

If necessary, and after consultation with Danfoss:

- Lower the IGBT switching frequency.
- Modify the inverter waveform, 60° AVM vs. SFAVM.
- Install a shaft grounding system or use an isolating coupling between motor and load.
- Use minimum speed settings if possible.
- Use a dU/dt or sine-wave filter.

#### 4.7 AC Mains Connection

##### 4.7.1 Mains Connection

Connect mains to terminals 91, 92, and 93 on the far left of the unit. Ground is connected to the terminal on the right of terminal 93.

| Terminal number | Function               |
|-----------------|------------------------|
| 91, 92, 93      | Mains R/L1, S/L2, T/L3 |
| 94              | Ground                 |

Table 4.5 Terminal Functions

Ensure sufficient current supply to the frequency converter.

If the unit is without built-in fuses, ensure that the appropriate fuses have the correct current rating.

##### 4.7.2 External Fan Supply

#### **NOTICE**

**Applicable for E and F enclosures only.**

If the frequency converter is supplied by DC, or the fan must run independently of the supply, use an external supply. Make the connection on the power card.

| Terminal number | Function              |
|-----------------|-----------------------|
| 100, 101        | Auxiliary supply S, T |
| 102, 103        | Internal supply S, T  |

Table 4.6 Terminal Functions

The connector on the power card provides the connection of mains voltage for the cooling fans. The fans are connected from the factory to be supplied from a common AC line (jumpers between 100–102 and 101–103). If external supply is needed, remove the jumpers and connect the supply to terminals 100 and 101. Protect with a 5 A fuse. In UL applications, use a Littelfuse KLK-5 or equivalent.

### 4.7.3 Power and Control Wiring for Unscreened Cables

#### **⚠ WARNING**

##### INDUCED VOLTAGE

Induced voltage from coupled output motor cables charges equipment capacitors even with the equipment turned off and locked out. Run motor cables from multiple frequency converters separately. Failure to run output cables separately could result in death or serious injury.

#### **⚠ CAUTION**

##### COMPROMISED PERFORMANCE


The frequency converter runs less efficiently if wiring is not isolated properly.

To isolate high frequency noise, place the following in separate metallic conduits:

- Power wiring
- Motor wiring
- Control wiring

Failure to isolate these connections could result in less than optimum controller and associated equipment performance.

Because the power wiring carries high frequency electrical pulses, it is important to run input power and motor power in separate conduit. If incoming power wiring is in the same conduit as motor wiring, these pulses can couple electrical noise back onto the power grid. Isolate control wiring from high voltage power wiring. See *Illustration 4.4*. When screened/armoured cable is not used, at least 3 separate conduits are connected to the panel options cabinet.



**Illustration 4.4 Example of Proper Electrical Installation Using Conduit**

## 4.7.4 Mains Disconnects

| Enclosure size | Power/Voltage                          | Type                          |
|----------------|--|-------------------------------|
| D              | 160–250 kW (250–350 hp)<br>/380–480 V  | OT400U12-9 or ABB OETL-NF400A |
| E              | 315 kW (450 hp)<br>/380–480 V          | ABB OETL-NF600A               |
| E              | 355–450 kW (500–600 hp)<br>/380–480 V  | ABB OETL-NF800A               |
| F              | 500 kW (650 hp)<br>/380–480 V          | Merlin Gerin NPJF36000S12AAYP |
| F              | 560–710 kW (750–1000 hp)<br>/380–480 V | Merlin Gerin NRK36000S20AAYP  |

Table 4.7 Recommended Mains Disconnects

## 4.7.5 F-Frame Circuit Breakers

| Enclosure size | Power/Voltage                          | Type                             |
|----------------|--|----------------------------------|
| F              | 500 kW (650 hp)<br>/380–480 V          | Merlin Gerin NPJF36120U31AABSCYP |
| F              | 560–710 kW (750–1000 hp)<br>/380–480 V | Merlin Gerin NRJF36200U31AABSCYP |

Table 4.8 Recommended Circuit Breakers

## 4.7.6 F-Frame Mains Contactors

| Enclosure size | Power/Voltage                          | Type              |
|----------------|--|-------------------|
| F              | 500–560 kW (650–750 hp)/380–480 V      | Eaton XTCE650N22A |
| F              | 630–710 kW (900–1000 hp)<br>/380–480 V | Eaton XTCEC14P22B |

Table 4.9 Recommended Contactors

## 4.8 Control Wiring

### 4.8.1 Control Cable Routing

Tie down all control wires to the designated control cable routing as shown in *Illustration 4.5*, *Illustration 4.6*, *Illustration 4.7*, and *Illustration 4.8*. Remember to connect the shields in a proper way to ensure optimum electrical immunity.

#### Fieldbus connection

Connections are made to the relevant options on the control card. For details, see the relevant fieldbus instruction. The cable must either be entered through the access point in the top or be placed in the provided path inside the frequency converter and tied down with other control wires (see *Illustration 4.5*, *Illustration 4.6*, and *Illustration 4.7*).




Illustration 4.5 Control Card Wiring Path for Enclosure Size D1n




Illustration 4.7 Control Card Wiring Path for Enclosure Size E9





Illustration 4.6 Control Card Wiring Path for Enclosure Size D2n

4



1 Routing path for the control card wiring inside the frequency converter enclosure.

Illustration 4.8 Control Card Wiring Path for Enclosure Size F18

## 4.8.2 Access to Control Terminals

All terminals for the control cables are located beneath the LCP (both filter and frequency converter LCPs). They are accessed by opening the door of the unit.

## 4.8.3 Electrical Installation, Control Terminals

To connect the cable to the terminal:

1. Strip insulation by about 9–10 mm (0.5 in).




Illustration 4.9 Length to Strip the Insulation

2. Insert a screwdriver (maximum 0.4 x 2.5 mm (0.016 x 0.1 in)) in the square hole.
3. Insert the cable in the adjacent circular hole.




Illustration 4.10 Inserting the Cable in the Terminal Block

4. Remove the screwdriver. The cable is now mounted in the terminal.

**To remove the cable from the terminal:**

1. Insert a screwdriver (maximum 0.4 x 2.5 mm (0.016 x 0.1 in)) in the square hole.
2. Pull out the cable.




Illustration 4.11 Removing the Screwdriver after Cable Insertion





Illustration 4.12 Control Terminal Locations



#### 4.8.4 Electrical Installation, Control Cables



130BE195.10

Illustration 4.13 Terminal Diagram for the Frequency Converter Side




Illustration 4.14 Terminal Diagram for the Filter Side

### 4.8.5 Safe Torque Off (STO)

To run STO, extra wiring for the frequency converter is required. Refer to *VLT® Frequency Converters Safe Torque Off Operating Instructions* for further information.

## 4.9 Additional Connections

### 4.9.1 Serial Communication

RS485 is a 2-wire bus interface compatible with multi-drop network topology, that is nodes can be connected as a bus, or via drop cables from a common trunk line. A total of 32 nodes can be connected to 1 network segment. Repeaters divide networks.

#### **NOTICE**

**Each repeater functions as a node within the segment in which it is installed. Each node connected within a given network must have a unique node address across all segments.**

Terminate each segment at both ends, using either the termination switch (S801) of the frequency converters or a biased termination resistor network. Always use shielded twisted pair (STP) cable for bus cabling, and always follow good common installation practice.

Low-impedance ground connection of the shield at every node is important, including at high frequencies. Thus, connect a large surface of the shield to ground, for example with a cable clamp or a conductive cable gland. It may be necessary to apply potential-equalizing cables to maintain the same ground potential throughout the network, particularly in installations with long cables. To prevent impedance mismatch, always use the same type of cable throughout the entire network. When connecting a motor to the frequency converters, always use shielded motor cable.

|              |                                     |
|--------------|-------------------------------------|
| Cable        | Shielded twisted pair (STP)         |
| Impedance    | 120 $\Omega$                        |
| Cable length | Maximum 1200 (including drop lines) |
| [m]          | Maximum 500 station-to-station      |

Table 4.10 Cable Recommendations

### 4.9.2 Mechanical Brake Control

In hoisting/lowering applications, it is necessary to be able to control an electro-mechanical brake:

- Control the brake using any relay output or digital output (terminal 27 or 29).
- Keep the output closed (voltage-free) as long as the frequency converter is unable to support the motor, due to the load being too heavy, for example.
- Select [32] *Mechanical brake control* in parameter group 5-4\* *Relays* for applications with an electro-mechanical brake.
- The brake is released when the motor current exceeds the preset value in *parameter 2-20 Release Brake Current*.
- The brake engages when the output frequency is less than the frequency set in *parameter 2-21 Activate Brake Speed [RPM]* or *parameter 2-22 Activate Brake Speed [Hz]*, only if the frequency converter completes a stop command.

If the frequency converter is in alarm mode or in an overvoltage situation, the mechanical brake immediately cuts in.

### 4.9.3 Parallel Connection of Motors

The frequency converter can control several parallel-connected motors. The total current consumption of the motors must not exceed the rated output current  $I_{M,N}$  for the frequency converter.

#### NOTICE

Installations with cables connected in a common joint as in *Illustration 4.15* are only recommended for short cable lengths.

#### NOTICE

When motors are connected in parallel, *parameter 1-29 Automatic Motor Adaptation (AMA)* cannot be used.

#### NOTICE

The electronic thermal relay (ETR) of the frequency converter cannot be used as motor overload protection for the individual motor in systems with parallel-connected motors. Provide further motor overload protection with thermistors in each motor or individual thermal relays. Circuit breakers are not suitable as protection.




Illustration 4.15 Installations with Cables Connected in a Common Joint

Problems are possible at start and at low RPM values if motor sizes vary widely. The relatively high ohmic resistance in the stator of small motors calls for a higher voltage at start and at low RPM values.

### 4.9.4 Motor Thermal Protection

The electronic thermal relay in the frequency converter has received UL-approval for single motor overload protection, when *parameter 1-90 Motor Thermal Protection* is set for [4] *ETR Trip 1* and *parameter 1-24 Motor Current* is set to the rated motor current (see motor nameplate).

For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.

For motor thermal protection, it is also possible to use the VLT® PTC Thermistor Card MCB 112. This card provides ATEX certification to protect motors in explosion hazardous areas, Zone 1/21, and Zone 2/22. When *parameter 1-90 Motor Thermal Protection* is set to [20] *ATEX ETR* and MCB 112 are combined, it is possible to control an Ex-e motor in explosion hazardous areas. Consult the *programming guide* for details on how to set up the frequency converter for safe operation of Ex-e motors.

### 4.9.5 Voltage/Current Input Selection (Switches)

The analog mains terminals 53 and 54 allow setting of input signal to voltage (0–10 V) or current (0/4–20 mA). See *Illustration 4.13* and *Illustration 4.14* for the location of the control terminals within the low harmonic drive.

Default parameter settings:


- Terminal 53: Speed reference signal in open loop (see *parameter 16-61 Terminal 53 Switch Setting*).
- Terminal 54: Feedback signal in closed loop (see *parameter 16-63 Terminal 54 Switch Setting*).

#### NOTICE

##### REMOVE POWER


Remove power to the low harmonic drive before changing switch positions.

1. Remove the LCP (see *Illustration 4.16*).
2. Remove any optional equipment covering the switches.
3. Set switches A53 and A54 to select the signal type. U selects voltage, I selects current.



|   |                        |
|---|------------------------|
| 1 | Bus termination switch |
| 2 | A54 switch             |
| 3 | A53 switch             |

Illustration 4.16 Bus Termination Switch, A53, and A54 Switch Locations



| BAUER D-7 3734 ESLINGEN   |       |       |     |    |
|---------------------------|-------|-------|-----|----|
| 3~ MOTOR NR. 1827421 2003 |       |       |     |    |
| S/E005A9                  |       |       |     |    |
|                           | 1,5   | KW    |     |    |
| n <sub>2</sub> 31,5       | /min. | 400   | Y   | V  |
| n <sub>1</sub> 1400       | /min. |       | 50  | Hz |
| COS $\theta$ 0,80         |       |       | 3,6 | A  |
| 1,7L                      |       |       |     |    |
| B                         | IP 65 | H1/1A |     |    |

Illustration 4.17 Motor Nameplate

## 4.10 Final Set-up and Test

Before operating the frequency converter, perform a final test of the installation:

1. Locate the motor nameplate to find out whether the motor is star- (Y) or delta- connected ( $\Delta$ ).
2. Enter the motor nameplate data in the parameter list. Access the list by pressing the [Quick Menu] key and selecting Q2 Quick Set-up. See Table 4.11.

|    |  |
|----|--|
| 1. | Parameter 1-20 Motor Power [kW]<br>Parameter 1-21 Motor Power [HP] |
| 2. | Parameter 1-22 Motor Voltage                                       |
| 3. | Parameter 1-23 Motor Frequency                                     |
| 4. | Parameter 1-24 Motor Current                                       |
| 5. | Parameter 1-25 Motor Nominal Speed                                 |

Table 4.11 Quick Set-up Parameters

3. Perform an automatic motor adaptation (AMA) to ensure optimum performance.
  - 3a Connect terminal 27 to terminal 12 or set *parameter 5-12 Terminal 27 Digital Input* to [0] No operation.
  - 3b Activate the AMA in *parameter 1-29 Automatic Motor Adaptation (AMA)*.
  - 3c Select either complete or reduced AMA. If an LC filter is mounted, run only the reduced AMA, or remove the LC filter during the AMA procedure.
  - 3d Press [OK]. The display shows *Press [Hand On] to start*.
  - 3e Press [Hand On]. A progress bar indicates whether the AMA is in progress.
  - 3f Press [Off] - the frequency converter enters alarm mode and the display shows that the user terminated AMA.

## Stop the AMA during operation

### Successful AMA

- The display shows *Press [OK] to finish AMA.*
- Press [OK] to exit the AMA state.

### Unsuccessful AMA

- The frequency converter enters into alarm mode. Find a description of the alarm in *chapter 7 Diagnostics and Troubleshooting.*
- Report value in the alarm log shows the last measuring sequence carried out by the AMA before the frequency converter entered alarm mode. This number, along with the description of the alarm, helps with troubleshooting. Mention the number and alarm description when contacting Danfoss service personnel.

Unsuccessful AMA is the result of incorrectly registered motor nameplate data or too large a difference between the motor power size and the frequency converter power size.

### Set up the desired limits for speed and ramp time

|                   |   |
|-------------------|---|
| Minimum reference | <i>Parameter 3-02 Minimum Reference</i> |
| Maximum reference | <i>Parameter 3-03 Maximum Reference</i> |

**Table 4.12 Reference Parameters**

|                        |  |
|------------------------|--|
| Motor speed low limit  | <i>Parameter 4-11 Motor Speed Low Limit [RPM] or parameter 4-12 Motor Speed Low Limit [Hz]</i>   |
| Motor speed high limit | <i>Parameter 4-13 Motor Speed High Limit [RPM] or parameter 4-14 Motor Speed High Limit [Hz]</i> |

**Table 4.13 Speed Limits**

|                      |   |
|----------------------|---|
| Ramp-up time 1 [s]   | <i>Parameter 3-41 Ramp 1 Ramp Up Time</i>   |
| Ramp-down time 1 [s] | <i>Parameter 3-42 Ramp 1 Ramp Down Time</i> |

**Table 4.14 Ramp Times**

## 4.11 F-frame Options

### Space heaters and thermostat

There are space heaters mounted on the cabinet interior of F-frame frequency converters. These heaters are controlled by an automatic thermostat and help control humidity inside the enclosure. The thermostat default settings turn on the heaters at 10 °C (50 °F) and turn them off at 15.6 °C (60 °F).

### Cabinet light with power outlet

A light mounted on the cabinet interior of F-frame frequency converters increases visibility during servicing and maintenance. The housing includes a power outlet for temporarily powering tools or other devices, available in 2 voltages:

- 230 V, 50 Hz, 2.5 A, CE/ENEC
- 120 V, 60 Hz, 5 A, UL/cUL

### Transformer tap set-up

If the cabinet light, outlet, and/or the space heaters, and thermostat are installed, transformer T1 requires its taps to be set to the proper input voltage. A 380–480/500 V frequency converter is initially set to the 525 V tap to ensure that no overvoltage of secondary equipment occurs if the tap is not changed before applying power. See *Table 4.15* to set the proper tap at terminal T1 located in the rectifier cabinet.

| Input voltage range [V] | Tap to select [V] |
|-------------------------|-------------------|
| 380–440                 | 400               |
| 441–500                 | 460               |

**Table 4.15 Transformer Tap Set-up**

### NAMUR terminals

NAMUR is an international association of automation technology users in the process industries, primarily chemical and pharmaceutical industries in Germany. Selecting this option, provides terminals organized and labeled to the specifications of the NAMUR standard for frequency converters input and output terminals. This requires VLT® PTC Thermistor Card MCB 112 and VLT® Extended Relay Card MCB 113.

### RCD (residual current device)

Uses the core balance method to monitor ground fault currents in grounded and high-resistance grounded systems (TN and TT systems in IEC terminology). There is a pre-warning (50% of main alarm setpoint) and a main alarm setpoint. Associated with each setpoint is an SPDT alarm relay for external use. Requires an external window-type current transformer (supplied and installed by the customer).

- Integrated into the frequency converter safe torque off circuit.
- IEC 60755 Type B device monitors AC, pulsed DC, and pure DC ground fault currents.
- LED bar graph indicator of the ground fault current level from 10–100% of the setpoint.
- Fault memory.
- TEST/RESET key.

### Insulation resistance monitor (IRM)

Monitors the insulation resistance in ungrounded systems (IT systems in IEC terminology) between the system phase conductors and ground. There is an ohmic pre-warning and a main alarm setpoint for the insulation level. An SPDT

alarm relay for external use is associated with each setpoint.

### **NOTICE**

Only 1 insulation resistance monitor can be connected to each ungrounded (IT) system.

- Integrated into the frequency converter Safe Torque Off circuit.
- LCD display of the ohmic value of the insulation resistance.
- Fault memory.
- INFO, TEST, and RESET keys.

### **IEC emergency stop with Pilz safety relay**

Includes a redundant 4-wire emergency stop push button mounted on the front of the enclosure and a Pilz relay that monitors it in conjunction with the frequency converter STO (Safe Torque Off) circuit and the mains contactor located in the options cabinet.

### **Manual motor starters**

Provide 3-phase power for electric blowers often required for larger motors. Power for the starters is provided from the load side of any supplied contactor, circuit breaker, or disconnect switch. Power is fused before each motor starter, and is off when the incoming power to the frequency converters is off. Up to 2 starters are allowed (1 if a 30 A, fuse-protected circuit is ordered), and are integrated into the frequency converter STO circuit.

Unit features include:

- Operation switch (on/off).
- Short circuit and overload protection with test function.
- Manual reset function.

### **30 A, fuse-protected terminals**

- 3-phase power matching incoming mains voltage for powering auxiliary customer equipment.
- Not available if 2 manual motor starters are selected.
- Terminals are off when the incoming power to the frequency converter is off.
- Power for the fused protected terminals is provided from the load side of any supplied contactor, circuit breaker, or disconnect switch.

In applications where the motor is used as a brake, energy is generated in the motor and sent back into the frequency converter. If the energy cannot be transported back to the motor, it increases the voltage in the frequency converter DC line. In applications with frequent braking and/or high inertia loads, this increase may lead to an overvoltage trip in the frequency converter and finally a shutdown. Brake resistors are used to dissipate the excess energy resulting from the regenerative braking. The resistor is selected based on its ohmic value, its power dissipation

rate, and its physical size. Danfoss offers a wide variety of different resistors that are designed for Danfoss frequency converters.

## 5 Commissioning

### 5.1 Safety Instructions

See *chapter 2 Safety* for general safety instructions.

#### **⚠ WARNING**

##### **HIGH VOLTAGE**

Frequency converters contain high voltage when connected to AC mains input power. Failure to perform installation, start-up, and maintenance by qualified personnel could result in death or serious injury.

- Installation, start-up, and maintenance must be performed by qualified personnel only.

Before applying power:

1. Close the cover properly.
2. Check that all cable glands are firmly tightened.
3. Ensure that input power to the unit is off and locked out. Do not rely on the frequency converter disconnect switches for input power isolation.
4. Verify that there is no voltage on input terminals L1 (91), L2 (92), and L3 (93), phase-to-phase, and phase-to-ground.
5. Verify that there is no voltage on output terminals 96 (U), 97 (V), and 98 (W), phase-to-phase, and phase-to-ground.
6. Confirm continuity of the motor by measuring  $\Omega$  values on U–V (96–97), V–W (97–98), and W–U (98–96).
7. Check for proper grounding of the frequency converter and the motor.
8. Inspect the frequency converter for loose connections on the terminals.
9. Confirm that the supply voltage matches the voltage of the frequency converter and the motor.



### 5.1.1 Pre-start

## CAUTION

Before applying power to the unit, inspect the entire installation as detailed in *Table 5.1*. Check mark those items when completed.

| Inspect for                   | Description   | ☑ |
|-------------------------------|---|---|
| Auxiliary equipment           | <ul style="list-style-type: none"> <li>Look for auxiliary equipment, switches, disconnects, or input fuses/circuit breakers on the input power side of the frequency converter or output side to the motor. Ensure that they are ready for full speed operation.</li> <li>Check function and installation of any sensors used for feedback to the frequency converter.</li> <li>Remove power factor correction capacitors on motors, if present.</li> </ul> |   |
| Cable routing                 | <ul style="list-style-type: none"> <li>Use separate metallic conduits for each of the following: <ul style="list-style-type: none"> <li>Input power</li> <li>Motor wiring</li> <li>Control wiring</li> </ul> </li> </ul>  |   |
| Control wiring                | <ul style="list-style-type: none"> <li>Check for broken or damaged wires and loose connections.</li> <li>Check that control wiring is isolated from power and motor wiring for noise immunity.</li> <li>Check the voltage source of the signals.</li> <li>Use shielded or twisted-pair cable. Ensure that the shield is terminated correctly.</li> </ul>  |   |
| Cooling clearance             | <ul style="list-style-type: none"> <li>Measure that top and bottom clearance is adequate to ensure proper air flow for cooling.</li> </ul>  |   |
| EMC considerations            | <ul style="list-style-type: none"> <li>Check for proper installation regarding electromagnetic compatibility.</li> </ul>  |   |
| Environmental considerations  | <ul style="list-style-type: none"> <li>See equipment label for the maximum ambient operating temperature limits.</li> <li>Humidity levels must be 5–95%, non-condensing.</li> </ul>   |   |
| Fusing and circuit breakers   | <ul style="list-style-type: none"> <li>Check for proper fusing or circuit breakers.</li> <li>Check that all fuses are inserted firmly and in operational condition, and that all circuit breakers are in the open position.</li> </ul>  |   |
| Grounding                     | <ul style="list-style-type: none"> <li>The unit requires a ground wire from its enclosure to the building ground.</li> <li>Check for good ground connections that are tight and free of oxidation.</li> <li>Grounding to conduit or mounting the back panel to a metal surface is not sufficient.</li> </ul>  |   |
| Input and output power wiring | <ul style="list-style-type: none"> <li>Check for loose connections.</li> <li>Check that motor and mains are in separate conduit or separated shielded cables.</li> </ul>  |   |
| Panel interior                | <ul style="list-style-type: none"> <li>Inspect that the unit interior is free of debris and corrosion.</li> </ul>   |   |
| Switches                      | <ul style="list-style-type: none"> <li>Ensure that all switch and disconnect settings are in the proper positions.</li> </ul>   |   |
| Vibration                     | <ul style="list-style-type: none"> <li>Check that the unit is mounted solidly or that shock mounts are used as necessary.</li> <li>Check for an unusual amount of vibration.</li> </ul>   |   |

Table 5.1 Start-up Checklist

## 5.2 Applying Power

### **⚠ WARNING**

#### **HIGH VOLTAGE!**

Frequency converters contain high voltage when connected to AC mains. Installation, start-up, and maintenance should be performed by qualified personnel only. Failure to comply could result in death or serious injury.

### **⚠ WARNING**

#### **UNINTENDED START!**

When the frequency converter is connected to AC mains, the motor may start at any time. The frequency converter, motor, and any driven equipment must be in operational readiness. Failure to comply could result in death, serious injury, equipment, or property damage.

1. Confirm that the input voltage is balanced within 3%. If not, correct input voltage imbalance before proceeding.
2. Ensure that optional equipment wiring, if present, matches the installation application.
3. Ensure that all operator devices are off. Panel doors should be closed or cover-mounted.
4. Apply power to the unit. Do not start the frequency converter at this time. For units with a disconnect switch, turn the switch on to apply power.

### **NOTICE**

If the status line at the bottom of the LCP reads **AUTO REMOTE COASTING** or **alarm 60, External Interlock** is showed, the unit is ready to operate but is missing an input signal on terminal 27.

## 5.3 Local Control Panel Operation

### 5.3.1 Local Control Panel

The local control panel (LCP) is the combined display and keypad on the front of the unit. The low harmonic drive includes 2 LCPs: 1 to control the frequency converter side and 1 to control the filter side.

The LCP has several functions:

- Control speed of frequency converter when in local mode.
- Start and stop in local mode.
- Display operational data, status, warnings, and alarms.

- Program frequency converter and active filter functions.
- Manually reset the frequency converter or active filter after a fault when auto reset is inactive.

### **NOTICE**

For commissioning via PC, install the MCT 10 Set-up Software. The software is available for download (basic version) or for ordering (advanced version, code number 130B1000). For more information and downloads, see [www.danfoss.com/BusinessAreas/DrivesSolutions/Software+MCT10/MCT10+Downloads.htm](http://www.danfoss.com/BusinessAreas/DrivesSolutions/Software+MCT10/MCT10+Downloads.htm).

### 5.3.2 LCP Layout

The LCP is divided into 4 functional groups (see *Illustration 5.1*).

- Display area
- Display menu keys
- Navigation keys and indicator lights (LEDs)
- Operation keys and reset




Illustration 5.1 Local Control Panel (LCP)

#### **A. Display area**

The display area is activated when the frequency converter receives power from mains voltage, a DC bus terminal, or a 24 V DC external supply.

The information shown on the LCP can be customized for user application. Select options in the *Quick Menu Q3-13 Display Settings*.

| Callout | Display | Parameter number | Default setting |
|---------|---------|------------------|-----------------|
| 1       | 1.1     | 0-20             | Reference %     |
| 2       | 1.2     | 0-21             | Motor current   |
| 3       | 1.3     | 0-22             | Power [kW]      |
| 4       | 2       | 0-23             | Frequency       |
| 5       | 3       | 0-24             | kWh counter     |

Table 5.2 Legend to *Illustration 5.1, Display Area* (Frequency Converter Side)

## B. Display menu keys

Menu keys are used for menu access for parameter set-up, toggling through status display modes during normal operation, and viewing fault log data.

| Callout | Key        | Function  |
|---------|------------|---|
| 6       | Status     | Shows operational information.  |
| 7       | Quick Menu | Allows access to programming parameters for initial set-up instructions and many detailed application instructions. |
| 8       | Main Menu  | Allows access to all programming parameters.  |
| 9       | Alarm Log  | Shows a list of current warnings, the last 10 alarms, and the maintenance log.                                      |

Table 5.3 Legend to *Illustration 5.1, Display Menu Keys*

## C. Navigation keys and indicator lights (LEDs)

Navigation keys are used for programming functions and moving the display cursor. The navigation keys also provide speed control in local (hand) operation. There are also 3 frequency converter status indicator lights in this area.

| Callout | Key             | Function  |
|---------|-----------------|---|
| 10      | Back            | Reverts to the previous step or list in the menu structure.                     |
| 11      | Cancel          | Cancels the last change or command as long as the display mode has not changed. |
| 12      | Info            | Press for a definition of the function being shown.                             |
| 13      | Navigation keys | Press to move between items in the menu.  |
| 14      | OK              | Press to access parameter groups or to enable an option.                        |

Table 5.4 Legend to *Illustration 5.1, Navigation Keys*

| Callout | Indicator | Light  | Function   |
|---------|-----------|--------|--|
| 15      | ON        | Green  | The ON light activates when the frequency converter receives power from mains voltage, a DC bus terminal, or a 24 V external supply. |
| 16      | WARN      | Yellow | When a warning is issued, the yellow WARN light comes on and text appears in the display area identifying the problem.               |
| 17      | ALARM     | Red    | A fault condition causes the red alarm light to flash and an alarm text is shown.  |

Table 5.5 Legend to *Illustration 5.1, Indicator Lights (LEDs)*

## D. Operation keys and reset

Operation keys are located at the bottom of the LCP.

| Callout | Key     | Function   |
|---------|---------|--|
| 18      | Hand On | Starts the frequency converter in local control. <ul style="list-style-type: none"> <li>An external stop signal by control input or serial communication overrides the local hand on.</li> </ul> |
| 19      | Off     | Stops the operation but does not remove power to the frequency converter.  |
| 20      | Auto On | Puts the system in remote operational mode. <ul style="list-style-type: none"> <li>Responds to an external start command by control terminals or serial communication.</li> </ul>                |
| 21      | Reset   | Resets the frequency converter or active filter manually after a fault has been cleared.   |

Table 5.6 Legend to *Illustration 5.1, Operation Keys and Reset*

## NOTICE

The display contrast can be adjusted by pressing [Status] and [▲]/[▼] keys.

## 5.3.3 Parameter Settings

Establishing the correct programming for applications often requires setting functions in several related parameters. Details for parameters are provided in *chapter 9 Appendix A - Parameters*.

Programming data is stored internally in the frequency converter.

- For back-up, upload data into the LCP memory.
- To download data to another frequency converter, connect the LCP to that unit and download the stored settings.

- Restoring factory default settings does not change data stored in the LCP memory.

### 5.3.4 Uploading/Downloading Data to/from the LCP

- Press [Off] to stop operation before uploading or downloading data.
- Press [Main Menu] *parameter 0-50 LCP Copy* and press [OK].
- Select [1] *All to LCP* to upload data to the LCP or select [2] *All from LCP* to download data from the LCP.
- Press [OK]. A progress bar shows the uploading or downloading progress.
- Press [Hand On] or [Auto On] to return to normal operation.

### 5.3.5 Changing Parameter Settings

Access and change parameter settings from the *Quick Menu* or from the *Main Menu*. The *Quick Menu* only gives access to a limited number of parameters.

- Press [Quick Menu] or [Main Menu] on the LCP.
- Press [▲] [▼] to browse through the parameter groups, press [OK] to select a parameter group.
- Press [▲] [▼] to browse through the parameters, press [OK] to select a parameter.
- Press [▲] [▼] to change the value of a parameter setting.
- Press [◀] [▶] to shift digit when a decimal parameter is in the editing state.
- Press [OK] to accept the change.
- Press either [Back] twice to enter *Status*, or press [Main Menu] once to enter the *Main Menu*.

#### View changes

*Quick Menu Q5 - Changes Made* lists all parameters changed from default settings.

- The list only shows parameters, which are changed in the current edit set-up.
- Parameters, which were reset to default values, are not listed.
- The message *Empty* indicates that no parameters are changed.

### 5.3.6 Restoring Default Settings

#### NOTICE

**Risk of losing programming and monitoring records by restoration of default settings. To provide a back-up, upload data to the LCP before initialization.**

Restoring the default parameter settings is done by initialization of the frequency converter. Initialization is carried out through *parameter 14-22 Operation Mode* (recommended) or manually.

- Initialization using *parameter 14-22 Operation Mode* does not reset frequency converter settings, such as operating hours, serial communication selections, personal menu settings, fault log, alarm log, and other monitoring functions.
- Manual initialization erases all motor, programming, localization, and monitoring data, and restores factory default settings.

#### Recommended initialization procedure, via *parameter 14-22 Operation Mode*

- Press [Main Menu] twice to access parameters.
- Scroll to *parameter 14-22 Operation Mode* and press [OK].
- Scroll to [2] *Initialisation* and press [OK].
- Remove power to the unit and wait for the display to turn off.
- Apply power to the unit.

Default parameter settings are restored during start-up. This may take slightly longer than normal.

- Alarm 80 is shown.
- Press [Reset] to return to operation mode.

#### Manual initialization procedure

- Remove power to the unit and wait for the display to turn off.
- Press and hold [Status], [Main Menu], and [OK] at the same time while applying power to the unit (approximately 5 s or until audible click and fan starts).

Factory default parameter settings are restored during start-up. This may take slightly longer than normal.

Manual initialization does not reset the following frequency converter information:

- Parameter 15-00 Operating hours*
- Parameter 15-03 Power Up's*
- Parameter 15-04 Over Temp's*
- Parameter 15-05 Over Volt's*

## 5.4 Basic Programming

### 5.4.1 VLT® Low Harmonic Drive Programming

The low harmonic drive includes 2 LCPs: 1 to control the frequency converter side and 1 to control the filter side. Because of this unique design, the detailed parameter information for the product is found in 2 places.

Detailed programming information for the frequency converter portion can be found in the relevant *programming guide*. Detailed programming information for the filter can be found in the *VLT® Active Filter AAF 006 Operating Instructions*.

The remaining sections in this chapter apply to the frequency converter side. The active filter of the low harmonic drives is pre-configured for optimal performance and must only be turned on by pressing its [Hand On] key after the frequency converter side is commissioned.

### 5.4.2 Commissioning with SmartStart

The SmartStart wizard enables fast configuration of basic motor and application parameters.

- SmartStart starts automatically at first power-up or after initialization of the frequency converter.
- Follow the on-screen instructions to complete the commissioning of the frequency converter. Always reactivate SmartStart by selecting *Quick Menu Q4 - SmartStart*.
- For commissioning without use of the SmartStart wizard, refer to *chapter 5.4.3 Commissioning via [Main Menu]* or the programming guide.

#### NOTICE

Motor data is required for the SmartStart set-up. The required data is normally available on the motor nameplate.

### 5.4.3 Commissioning via [Main Menu]

Recommended parameter settings are intended for start-up and check-out purposes. Application settings may vary.

Enter data with power ON, but before operating the frequency converter.

1. Press [Main Menu] on the LCP.
2. Press the navigation keys to scroll to parameter group 0-\*\* Operation/Display and press [OK].




Illustration 5.2 Main Menu

3. Press the navigation keys to scroll to parameter group 0-0\* Basic Settings and press [OK].




Illustration 5.3 Operation/Display

4. Press the navigation keys to scroll to parameter 0-03 Regional Settings and press [OK].




Illustration 5.4 Basic Settings

5. Press the navigation keys to select [0] International or [1] North America as appropriate and press [OK]. (This changes the default settings for several basic parameters).
6. Press [Main Menu] on the LCP.
7. Press the navigation keys to scroll to parameter 0-01 Language.
8. Select the language and press [OK].
9. If a jumper wire is in place between control terminals 12 and 27, leave parameter 5-12 Terminal 27 Digital Input at factory default. Otherwise, select [0] No Operation in parameter 5-12 Terminal 27 Digital Input.

10. Make the application-specific settings in the following parameters:
  - 10a *Parameter 3-02 Minimum Reference.*
  - 10b *Parameter 3-03 Maximum Reference.*
  - 10c *Parameter 3-41 Ramp 1 Ramp Up Time.*
  - 10d *Parameter 3-42 Ramp 1 Ramp Down Time.*
  - 10e *Parameter 3-13 Reference Site.* Linked to Hand/Auto Local Remote.

#### 5.4.4 Asynchronous Motor Set-up

Enter the following motor data. Find the information on the motor nameplate.

1. *Parameter 1-20 Motor Power [kW] or parameter 1-21 Motor Power [HP].*
2. *Parameter 1-22 Motor Voltage.*
3. *Parameter 1-23 Motor Frequency.*
4. *Parameter 1-24 Motor Current.*
5. *Parameter 1-25 Motor Nominal Speed.*

When running in flux control principle, or for optimum performance in VVC<sup>+</sup> mode, extra motor data is required to set up the following parameters. Find the data in the motor datasheet (this data is typically not available on the motor nameplate). Run a complete automatic motor adaptation (AMA) using *parameter 1-29 Automatic Motor Adaptation (AMA) [1] Enable Complete AMA* or enter the parameters manually. *Parameter 1-36 Iron Loss Resistance (Rfe)* is always entered manually.

1. *Parameter 1-30 Stator Resistance (Rs).*
2. *Parameter 1-31 Rotor Resistance (Rr).*
3. *Parameter 1-33 Stator Leakage Reactance (X1).*
4. *Parameter 1-34 Rotor Leakage Reactance (X2).*
5. *Parameter 1-35 Main Reactance (Xh).*
6. *Parameter 1-36 Iron Loss Resistance (Rfe).*

#### Application-specific adjustment when running VVC<sup>+</sup>

VVC<sup>+</sup> is the most robust control mode. In most situations, it provides optimum performance without further adjustments. Run a complete AMA for best performance.

#### Application-specific adjustment when running flux

Flux control principle is the preferred control principle for optimum shaft performance in dynamic applications. Perform an AMA since this control mode requires precise motor data. Depending on the application, further adjustments may be required.

See *Table 5.7* for application-related recommendations.

| Application                            | Settings   |
|--|--|
| Low-inertia applications               | Keep calculated values.  |
| High-inertia applications              | <i>Parameter 1-66 Min. Current at Low Speed.</i><br>Increase current to a value between default and maximum depending on the application.<br>Set ramp times matching the application. Too fast ramp up causes an overcurrent or overtorque. Too fast ramp down causes an overvoltage trip.   |
| High load at low speed                 | <i>Parameter 1-66 Min. Current at Low Speed.</i><br>Increase current to a value between default and maximum depending on the application.  |
| No-load application                    | Adjust <i>parameter 1-18 Min. Current at No Load</i> to achieve smoother motor operation by reducing torque ripple and vibration.  |
| Flux Sensorless control principle only | Adjust <i>parameter 1-53 Model Shift Frequency.</i><br>Example 1: If the motor oscillates at 5 Hz, and dynamics performance is required at 15 Hz, set <i>parameter 1-53 Model Shift Frequency</i> to 10 Hz.<br>Example 2: If the application involves dynamic load changes at low speed, reduce <i>parameter 1-53 Model Shift Frequency.</i> Observe the motor behavior to make sure that the model shift frequency is not reduced too much. Symptoms of inappropriate model shift frequency are motor oscillations or frequency converter tripping. |

Table 5.7 Recommendations for Flux Applications

#### 5.4.5 Permanent Magnet Motor Set-up

#### NOTICE

Only use permanent magnet (PM) motor with fans and pumps.

#### Initial programming steps

1. Activate PM motor operation in *parameter 1-10 Motor Construction*, select *[1] PM, non-salient SPM.*
2. Set *parameter 0-02 Motor Speed Unit* to *[0] RPM.*

### Programming motor data

After selecting *PM motor* in *parameter 1-10 Motor Construction*, the PM motor-related parameters in parameter groups *1-2\* Motor Data*, *1-3\* Adv. Motor Data*, and *1-4\** are active.

Find the necessary data on the motor nameplate and in the motor datasheet.

Program the following parameters in the listed order:

1. *Parameter 1-24 Motor Current.*
2. *Parameter 1-26 Motor Cont. Rated Torque.*
3. *Parameter 1-25 Motor Nominal Speed.*
4. *Parameter 1-39 Motor Poles.*
5. *Parameter 1-30 Stator Resistance (Rs).*  
Enter line-to-common stator winding resistance (Rs). If only line-line data are available, divide the line-line value with 2 to achieve the line to common (starpoint) value.  
It is also possible to measure the value with an ohmmeter, which takes the resistance of the cable into account. Divide the measured value by 2 and enter the result.
6. *Parameter 1-37 d-axis Inductance (Ld).*  
Enter line-to-common direct axis inductance of the PM motor.  
If only line-line data are available, divide the line-line value with 2 to achieve the line-common (starpoint) value.  
It is also possible to measure the value with an inductancemeter, which takes the inductance of the cable into account. Divide the measured value by 2 and enter the result.
7. *Parameter 1-40 Back EMF at 1000 RPM*  
Enter line-line back EMF of PM Motor at 1000 RPM mechanical speed (RMS value). Back EMF is the voltage generated by a PM motor when no frequency converter is connected and the shaft is turned externally. Back EMF is normally specified for nominal motor speed or for 1000 RPM measured between 2 lines. If the value is not available for a motor speed of 1000 RPM, calculate the correct value as follows: If back EMF is for example 320 V at 1800 RPM, it can be calculated at 1000 RPM as follows: Back EMF = (Voltage/RPM)x1000 = (320/1800)x1000 = 178. Program this value for *parameter 1-40 Back EMF at 1000 RPM*.

### Test motor operation

1. Start the motor at low speed (100–200 RPM). If the motor does not turn, check installation, general programming, and motor data.
2. Check if start function in *parameter 1-70 PM Start Mode* fits the application requirements.

### Rotor detection

This function is the recommended choice for applications where the motor starts from standstill, for example pumps or conveyors. On some motors, a sound is heard when the impulse is sent out. This does not harm the motor.

### Parking

This function is the recommended choice for applications where the motor is rotating at slow speed for example windmilling in fan applications. *Parameter 2-06 Parking Current* and *parameter 2-07 Parking Time* can be adjusted. Increase the factory setting of these parameters for applications with high inertia.

Start the motor at nominal speed. If the application does not run well, check the VVC+ PM settings. *Table 5.7* shows recommendations in different applications.

| Application   | Settings   |
|---|--|
| Low-inertia applications<br>$I_{Load}/I_{Motor} < 5$      | Increase <i>parameter 1-17 Voltage filter time const.</i> by factor 5–10<br>Reduce <i>parameter 1-14 Damping Gain</i> .<br>Reduce <i>parameter 1-66 Min. Current at Low Speed</i> (<100%). |
| Low-inertia applications<br>$50 > I_{Load}/I_{Motor} > 5$ | Keep the calculated values.  |
| High-inertia applications<br>$I_{Load}/I_{Motor} > 50$    | Increase <i>parameter 1-14 Damping Gain</i> , <i>parameter 1-15 Low Speed Filter Time Const.</i> , and <i>parameter 1-16 High Speed Filter Time Const.</i>                                 |
| High load at low speed<br><30% (rated speed)              | Increase <i>parameter 1-17 Voltage filter time const.</i> .<br>Increase <i>parameter 1-66 Min. Current at Low Speed</i> (>100% for a prolonged time can overheat the motor).               |

Table 5.8 Recommendations in Different Applications

If the motor starts oscillating at a certain speed, increase *parameter 1-14 Damping Gain*. Increase the value in small steps. Depending on the motor, a good value for this parameter can be 10% or 100% higher than the default value.

Adjust starting torque in *parameter 1-66 Min. Current at Low Speed*. 100% provides nominal torque as starting torque.

## 5.4.6 Automatic Energy Optimization (AEO)

### NOTICE

AEO is not relevant for permanent magnet motors.

AEO is a procedure which minimizes voltage to the motor, as a result of that reducing energy consumption, heat, and noise.

To activate AEO, set *parameter 1-03 Torque Characteristics* to [2] *Auto Energy Optim. CT* or [3] *Auto Energy Optim. VT*.

### 5.4.7 Automatic Motor Adaptation (AMA)

AMA is a procedure which optimizes compatibility between the frequency converter and the motor.

- The frequency converter builds a mathematical model of the motor for regulating output motor current. The procedure also tests the input phase balance of electrical power. It compares the motor characteristics with the entered nameplate data.
- The motor shaft does not turn and no harm is done to the motor while running the AMA.
- Some motors may be unable to run the complete version of the test. In that case, select [2] *Enable reduced AMA*.
- If an output filter is connected to the motor, select [2] *Enable reduced AMA*.
- If warnings or alarms occur, see *chapter 7 Diagnostics and Troubleshooting*.
- Run this procedure on a cold motor for best results.

#### To run AMA

1. Press [Main Menu] to access parameters.
2. Scroll to parameter group 1-\*\* *Load and Motor* and press [OK].
3. Scroll to parameter group 1-2\* *Motor Data* and press [OK].
4. Scroll to *parameter 1-29 Automatic Motor Adaptation (AMA)* and press [OK].
5. Select [1] *Enable complete AMA* and press [OK].
6. Follow the on-screen instructions.
7. The test runs automatically and indicates when it is complete.
8. The advanced motor data is entered in parameter group 1-3\* *Adv. Motor Data*.

### 5.5 Checking Motor Rotation

#### NOTICE

**Risk of damage to pumps/compressors caused by motor running in wrong direction. Before running the frequency converter, check the motor rotation.**

The motor runs briefly at 5 Hz or the minimum frequency set in *parameter 4-12 Motor Speed Low Limit [Hz]*.

1. Press [Main Menu].
2. Scroll to *parameter 1-28 Motor Rotation Check* and press [OK].
3. Scroll to [1] *Enable*.

The following text appears: *Note! Motor may run in wrong direction.*

4. Press [OK].
5. Follow the on-screen instructions.

#### NOTICE

**To change the direction of rotation, remove power to the frequency converter and wait for power to discharge. Reverse the connection of any 2 of the 3 motor wires on the motor or frequency converter side of the connection.**

5

### 5.6 Local-control Test

1. Press [Hand On] to provide a local start command to the frequency converter.
2. Accelerate the frequency converter by pressing [▲] to full speed. Moving the cursor left of the decimal point provides quicker input changes.
3. Note any acceleration problems.
4. Press [Off]. Note any deceleration problems.

In the event of acceleration or deceleration problems, see *chapter 7.5 Troubleshooting*. See *chapter 7.4 Warnings and Alarm Definitions - Active Filter* for resetting the frequency converter after a trip.

### 5.7 System Start-up

The procedure in this section requires wiring and application programming to be completed. The following procedure is recommended after application set-up is completed.

1. Press [Auto On].
2. Apply an external run command.
3. Adjust the speed reference throughout the speed range.
4. Remove the external run command.
5. Check the sound and vibration levels of the motor to ensure that the system is working as intended.

If warnings or alarms occur, see *chapter 7.3 Warning and Alarm Definitions for Frequency Converter* or *chapter 7.4 Warnings and Alarm Definitions - Active Filter*.



## 6 Application Examples

### 6.1 Introduction

The examples in this section are intended as a quick reference for common applications.

- Parameter settings are the regional default values unless otherwise indicated (selected in *parameter 0-03 Regional Settings*).
- Parameters associated with the terminals and their settings are shown next to the drawings.
- Required switch settings for analog terminals A53 or A54 are also shown.

#### NOTICE

When using the optional STO feature, a jumper wire may be required between terminal 12 (or 13) and terminal 37 for the frequency converter to operate with factory default programming values.

#### NOTICE

The following examples refer only to the frequency converter control card (right LCP), *not* the filter.

|       |    | Parameters  |         |
|-------|----|---|---------|
| FC    |    | Function  | Setting |
| +24 V | 12 | Parameter 6-12 Terminal 53 Low Current            | 4 mA*   |
| +24 V | 13 | Parameter 6-13 Terminal 53 High Current           | 20 mA*  |
| D IN  | 18 | Parameter 6-14 Terminal 53 Low Ref./Feedb. Value  | 0 Hz    |
| D IN  | 19 | Parameter 6-15 Terminal 53 High Ref./Feedb. Value | 50 Hz   |
| COM   | 20 | * = Default value                                 |         |
| D IN  | 27 | Notes/comments:<br>D IN 37 is an option.          |         |
| D IN  | 29 |   |         |
| D IN  | 32 |   |         |
| D IN  | 33 |   |         |
| D IN  | 37 |   |         |
| +10 V | 50 |   |         |
| A IN  | 53 |   |         |
| A IN  | 54 |   |         |
| COM   | 55 |   |         |
| A OUT | 42 |   |         |
| COM   | 39 |   |         |

Table 6.2 Analog Speed Reference (Current)

### 6.2 Application Examples

#### 6.2.1 Speed

|       |    | Parameters  |         |
|-------|----|---|---------|
| FC    |    | Function  | Setting |
| +24 V | 12 | Parameter 6-10 Terminal 53 Low Voltage            | 0.07 V* |
| +24 V | 13 | Parameter 6-11 Terminal 53 High Voltage           | 10 V*   |
| D IN  | 18 | Parameter 6-14 Terminal 53 Low Ref./Feedb. Value  | 0 Hz    |
| D IN  | 19 | Parameter 6-15 Terminal 53 High Ref./Feedb. Value | 50 Hz   |
| COM   | 20 | * = Default value                                 |         |
| D IN  | 27 | Notes/comments:<br>D IN 37 is an option.          |         |
| D IN  | 29 |   |         |
| D IN  | 32 |   |         |
| D IN  | 33 |   |         |
| D IN  | 37 |   |         |
| +10 V | 50 |   |         |
| A IN  | 53 |   |         |
| A IN  | 54 |   |         |
| COM   | 55 |   |         |
| A OUT | 42 |   |         |
| COM   | 39 |   |         |

Table 6.1 Analog Speed Reference (Voltage)

|       |    | Parameters  |         |
|-------|----|---|---------|
| FC    |    | Function  | Setting |
| +24 V | 12 | Parameter 6-10 Terminal 53 Low Voltage            | 0.07 V* |
| +24 V | 13 | Parameter 6-11 Terminal 53 High Voltage           | 10 V*   |
| D IN  | 18 | Parameter 6-14 Terminal 53 Low Ref./Feedb. Value  | 0 Hz    |
| D IN  | 19 | Parameter 6-15 Terminal 53 High Ref./Feedb. Value | 1500 Hz |
| COM   | 20 | * = Default value                                 |         |
| D IN  | 27 | Notes/comments:<br>D IN 37 is an option.          |         |
| D IN  | 29 |   |         |
| D IN  | 32 |   |         |
| D IN  | 33 |   |         |
| D IN  | 37 |   |         |
| +10 V | 50 |   |         |
| A IN  | 53 |   |         |
| A IN  | 54 |   |         |
| COM   | 55 |   |         |
| A OUT | 42 |   |         |
| COM   | 39 |   |         |

Table 6.3 Speed Reference (Using a Manual Potentiometer)

|       |    | Parameters                               |                       |
|-------|----|--|-----------------------|
| FC    |    | Function                                 | Setting               |
| +24 V | 12 | Parameter 5-10 Terminal 18               | [8] Start*            |
| +24 V | 13 | Digital Input                            |                       |
| D IN  | 18 | Parameter 5-12 Terminal 27               | [19] Freeze Reference |
| D IN  | 19 | Digital Input                            |                       |
| COM   | 20 | Parameter 5-13 Terminal 29               | [21] Speed Up         |
| D IN  | 27 | Digital Input                            |                       |
| D IN  | 29 | Parameter 5-14 Terminal 32               | [22] Speed Down       |
| D IN  | 32 | Digital Input                            |                       |
| D IN  | 33 |  |                       |
| D IN  | 37 |  |                       |
| +10 V | 50 | * = Default value                        |                       |
| A IN  | 53 | Notes/comments:<br>D IN 37 is an option. |                       |
| A IN  | 54 |  |                       |
| COM   | 55 |  |                       |
| A OUT | 42 |  |                       |
| COM   | 39 |  |                       |

Table 6.4 Speed Up/Speed Down




Illustration 6.1 Speed Up/Speed Down

## 6.2.2 Start/Stop

|       |    | Parameters  |                  |
|-------|----|---|------------------|
| FC    |    | Function  | Setting          |
| +24 V | 12 | Parameter 5-10 Terminal 18  | [8] Start        |
| +24 V | 13 | Digital Input   |                  |
| D IN  | 18 | Parameter 5-12 Terminal 27  | [0] No operation |
| D IN  | 19 | Digital Input   |                  |
| COM   | 20 | Parameter 5-19 Terminal 37 Safe Stop  | [1] Safe Alarm   |
| D IN  | 27 | Digital Input   |                  |
| D IN  | 29 |   |                  |
| D IN  | 32 |   |                  |
| D IN  | 33 |   |                  |
| D IN  | 37 |   |                  |
| +10 V | 50 | * = Default value   |                  |
| A IN  | 53 | Notes/comments:<br>If parameter 5-12 Terminal 27 Digital Input is set to [0] No operation, a jumper wire to terminal 27 is not needed.<br>D IN 37 is an option. |                  |
| A IN  | 54 |   |                  |
| COM   | 55 |   |                  |
| A OUT | 42 |   |                  |
| COM   | 39 |   |                  |

Table 6.5 Start/Stop Command with Safe Torque Off Option




Illustration 6.2 Start/Stop Command with Safe Torque Off

|       |    | Parameters  |                   |
|-------|----|---|-------------------|
| FC    |    | Function  | Setting           |
| +24 V | 12 | Parameter 5-10 Terminal 18  | [9] Latched Start |
| +24 V | 13 | Digital Input   |                   |
| D IN  | 18 | Parameter 5-12 Terminal 27  | [6] Stop Inverse  |
| D IN  | 19 | Digital Input   |                   |
| COM   | 20 |   |                   |
| D IN  | 27 |   |                   |
| D IN  | 29 |   |                   |
| D IN  | 32 |   |                   |
| D IN  | 33 |   |                   |
| D IN  | 37 |   |                   |
| +10 V | 50 | * = Default value   |                   |
| A IN  | 53 | Notes/comments:<br>If parameter 5-12 Terminal 27 Digital Input is set to [0] No operation, a jumper wire to terminal 27 is not needed.<br>D IN 37 is an option. |                   |
| A IN  | 54 |   |                   |
| COM   | 55 |   |                   |
| A OUT | 42 |   |                   |
| COM   | 39 |   |                   |

Table 6.6 Pulse Start/Stop




Illustration 6.3 Latched Start/Stop Inverse

|       |    | Parameters                               |                       |
|-------|----|--|-----------------------|
| FC    |    | Function                                 | Setting               |
| +24 V | 12 | Parameter 5-10 Terminal 18 Digital Input | [8] Start             |
| +24 V | 13 |  |                       |
| D IN  | 18 | Parameter 5-11 Terminal 19 Digital Input | [10] Reversing        |
| D IN  | 19 |  |                       |
| COM   | 20 |  |                       |
| D IN  | 27 |  |                       |
| D IN  | 29 |  |                       |
| D IN  | 32 | Parameter 5-12 Terminal 27 Digital Input | [0] No operation      |
| D IN  | 33 |  |                       |
| D IN  | 37 |  |                       |
| +10 V | 50 | Parameter 5-14 Terminal 32 Digital Input | [16] Preset ref bit 0 |
| A IN  | 53 |  |                       |
| A IN  | 54 | Parameter 5-15 Terminal 33 Digital Input | [17] Preset ref bit 1 |
| COM   | 55 |  |                       |
| A OUT | 42 |  |                       |
| COM   | 39 |  |                       |
|       |    | Parameter 3-10 Preset Reference          |                       |
|       |    | Preset reference 0                       | 25%                   |
|       |    | Preset reference 1                       | 50%                   |
|       |    | Preset reference 2                       | 75%                   |
|       |    | Preset reference 3                       | 100%                  |
|       |    | * = Default value                        |                       |
|       |    | Notes/comments:<br>D IN 37 is an option. |                       |

Table 6.7 Start/Stop with Reversing and 4 Preset Speeds

## 6.2.3 External Alarm Reset

|       |    | Parameters                               |           |
|-------|----|--|-----------|
| FC    |    | Function                                 | Setting   |
| +24 V | 12 | Parameter 5-11 Terminal 19 Digital Input | [1] Reset |
| +24 V | 13 |  |           |
| D IN  | 18 |  |           |
| D IN  | 19 |  |           |
| COM   | 20 |  |           |
| D IN  | 27 |  |           |
| D IN  | 29 |  |           |
| D IN  | 32 |  |           |
| D IN  | 33 |  |           |
| D IN  | 37 |  |           |
| +10 V | 50 | * = Default value                        |           |
| A IN  | 53 | Notes/comments:<br>D IN 37 is an option. |           |
| A IN  | 54 |  |           |
| COM   | 55 |  |           |
| A OUT | 42 |  |           |
| COM   | 39 |  |           |

Table 6.8 External Alarm Reset

## 6.2.4 RS485

|       |    | Parameters  |         |
|-------|----|---|---------|
| FC    |    | Function  | Setting |
| +24 V | 12 | Parameter 8-30 Protocol   | FC*     |
| +24 V | 13 | Parameter 8-31 Address  | 1*      |
| D IN  | 18 | Parameter 8-32 Baud Rate  | 9600*   |
| D IN  | 19 | * = Default value   |         |
| COM   | 20 | <b>Notes/comments:</b><br>Select protocol, address, and baud rate in the above-mentioned parameters.<br>D IN 37 is an option. |         |
| D IN  | 27 |   |         |
| D IN  | 29 |   |         |
| D IN  | 32 |   |         |
| D IN  | 33 |   |         |
| D IN  | 37 |   |         |
| +10 V | 50 |   |         |
| A IN  | 53 |   |         |
| A IN  | 54 |   |         |
| COM   | 55 |   |         |
| A OUT | 42 |   |         |
| COM   | 39 |   |         |
| R1    | 01 | RS-485  |         |
|       | 02 |   |         |
|       | 03 |   |         |
| R2    | 04 |   |         |
|       | 05 |   |         |
|       | 06 |   |         |
|       | 61 |   |         |
|       | 68 |   |         |
|       | 69 |   |         |
|       |    |   |         |
|       |    |   |         |
|       |    |   |         |

Table 6.9 RS485 Network Connection

## 6.2.5 Motor Thermistor

### ⚠ WARNING

#### THERMISTOR INSULATION

Risk of personal injury or equipment damage.

- Use only thermistors with reinforced or double insulation to meet PELV insulation requirements.


|       |    | Parameters   |                     |
|-------|----|--|---------------------|
| VLT   |    | Function   | Setting             |
| +24 V | 12 | Parameter 1-90 Motor Thermal Protection  | [2] Thermistor trip |
| +24 V | 13 | Parameter 1-93 Thermistor Source   | [1] Analog input 53 |
| D IN  | 18 | * = Default Value  |                     |
| D IN  | 19 | <b>Notes/comments:</b><br>If only a warning is required, set parameter 1-90 Motor Thermal Protection to [1] Thermistor warning.<br>D IN 37 is an option. |                     |
| COM   | 20 |  |                     |
| D IN  | 27 |  |                     |
| D IN  | 29 |  |                     |
| D IN  | 32 |  |                     |
| D IN  | 33 |  |                     |
| D IN  | 37 |  |                     |
| +10 V | 50 |  |                     |
| A IN  | 53 |  |                     |
| A IN  | 54 |  |                     |
| COM   | 55 |  |                     |
| A OUT | 42 |  |                     |
| COM   | 39 |  |                     |
| U - I |    | A53  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |
|       |    |  |                     |

Table 6.10 Motor Thermistor

## 7 Diagnostics and Troubleshooting

### 7.1 Status Messages

When the frequency converter is in *Status* mode, status messages are generated automatically and appear in the bottom line of the display (see *Illustration 7.1*). Refer to the *VLT® HVAC Drive FC 102 Programming Guide* for detailed descriptions of the shown status messages.



|   |                  |
|---|------------------|
| 1 | Operating mode   |
| 2 | Reference site   |
| 3 | Operation status |

Illustration 7.1 Status Display

### 7.2 Warning and Alarm Types

The frequency converter monitors the condition of its input power, output, and motor factors, and other system performance indicators. A warning or alarm does not necessarily indicate a problem internally in the frequency converter.

Often, it indicates failure conditions from:

- Input voltage.
- Motor load.
- Motor temperature.
- External signals.
- Other areas monitored by internal logic.

Investigate as indicated in the alarm or warning.

#### 7.2.1 Warnings

A warning is issued when an alarm condition is impending or when an abnormal operating condition is present and may result in the frequency converter issuing an alarm. A warning clears by itself when the abnormal condition is removed.

#### 7.2.2 Alarm Trip

An alarm is issued when the frequency converter is tripped, that is, the frequency converter suspends operation to prevent frequency converter or system damage. The motor coasts to a stop, if the alarm trip is on the frequency converter side. The frequency converter logic continues to operate and monitors the frequency converter status. After the fault condition is remedied, reset the frequency converter. It is then ready to restart operation.

A trip can be reset in any of 4 ways:

- Press [Reset] on the LCP.
- Digital reset input command.
- Serial communication reset input command.
- Auto reset.

#### 7.2.3 Alarm Trip-lock

An alarm that causes the frequency converter to trip lock requires that input power is cycled. If the alarm trip is on the frequency converter side, the motor coasts to a stop. The frequency converter logic continues to operate and monitors the frequency converter status. Remove input power to the frequency converter and correct the cause of the fault, then restore power. This action puts the frequency converter into a trip condition as described in *chapter 7.2.2 Alarm Trip* and may be reset in any of the 4 ways.

### 7.3 Warning and Alarm Definitions for Frequency Converter

The following warning/alarm information defines each warning/alarm condition, provides the probable cause for the condition, and details a remedy or troubleshooting procedure.

#### WARNING 1, 10 Volts low

The control card voltage is less than 10 V from terminal 50. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Maximum 15 mA or minimum 590 Ω.

A short circuit in a connected potentiometer or incorrect wiring of the potentiometer can cause this condition.

#### Troubleshooting

- Remove the wiring from terminal 50. If the warning clears, the problem is with the wiring. If the warning does not clear, replace the control card.

#### WARNING/ALARM 2, Live zero error

This warning or alarm only appears if programmed in *parameter 6-01 Live Zero Timeout Function*. The signal on 1 of the analog inputs is less than 50% of the minimum value programmed for that input. Broken wiring or a faulty device sending the signal can cause this condition.

##### Troubleshooting

- Check connections on all analog mains terminals.
  - Control card terminals 53 and 54 for signals, terminal 55 common.
  - VLT® General Purpose I/O MCB 101 terminals 11 and 12 for signals, terminal 10 common.
  - VLT® Analog I/O Option MCB 109 terminals 1, 3, and 5 for signals, terminals 2, 4, and 6 common.
- Check that the frequency converter programming and switch settings match the analog signal type.
- Perform an input terminal signal test.

#### WARNING/ALARM 3, No motor

No motor is connected to the output of the frequency converter.

#### WARNING/ALARM 4, Mains phase loss

A phase is missing on the supply side, or the mains voltage imbalance is too high. This message also appears for a fault in the input rectifier. Options are programmed in *parameter 14-12 Function at Mains Imbalance*.

##### Troubleshooting

- Check the supply voltage and supply currents to the frequency converter.

#### WARNING 5, DC link voltage high

The DC-link voltage (DC) is higher than the high-voltage warning limit. The limit depends on the frequency converter voltage rating. The unit is still active.

#### WARNING 6, DC link voltage low

The DC-link voltage (DC) is lower than the low voltage warning limit. The limit depends on the frequency converter voltage rating. The unit is still active.

#### WARNING/ALARM 7, DC overvoltage

If the DC-link voltage exceeds the limit, the frequency converter trips after a certain time.

##### Troubleshooting

- Connect a brake resistor.
- Extend the ramp time.
- Change the ramp type.
- Activate the functions in *parameter 2-10 Brake Function*.
- Increase *parameter 14-26 Trip Delay at Inverter Fault*.

- If the alarm/warning occurs during a power sag, use kinetic back-up (*parameter 14-10 Mains Failure*).

#### WARNING/ALARM 8, DC under voltage

If the DC-link voltage drops below the undervoltage limit, the frequency converter checks for 24 V DC back-up supply. If no 24 V DC back-up supply is connected, the frequency converter trips after a fixed time delay. The time delay varies with unit size.

##### Troubleshooting

- Check that the supply voltage matches the frequency converter voltage.
- Perform an input voltage test.
- Perform a soft-charge circuit test.

#### WARNING/ALARM 9, Inverter overload

The frequency converter has run with more than 100% overload for too long and is about to cut out. The counter for electronic thermal inverter protection issues a warning at 98% and trips at 100% with an alarm. The frequency converter cannot be reset until the counter is below 90%.

##### Troubleshooting

- Compare the output current shown on the LCP with the frequency converter rated current.
- Compare the output current shown on the LCP with the measured motor current.
- Show the thermal frequency converter load on the LCP and monitor the value. When running above the frequency converter continuous current rating, the counter increases. When running below the frequency converter continuous current rating, the counter decreases.

#### WARNING/ALARM 10, Motor overload temperature

According to the electronic thermal protection (ETR), the motor is too hot. Select whether the frequency converter issues a warning or an alarm when the counter is >90% if *parameter 1-90 Motor Thermal Protection* is set to warning options, or whether the frequency converter trips when the counter reaches 100% if *parameter 1-90 Motor Thermal Protection* is set to trip options. The fault occurs when the motor runs with more than 100% overload for too long.

##### Troubleshooting

- Check for motor overheating.
- Check if the motor is mechanically overloaded.
- Check that the motor current set in *parameter 1-24 Motor Current* is correct.
- Ensure that the motor data in *parameters 1-20 to 1-25* are set correctly.
- If an external fan is in use, check that it is selected in *parameter 1-91 Motor External Fan*.
- Running AMA in *parameter 1-29 Automatic Motor Adaptation (AMA)* tunes the frequency converter

to the motor more accurately and reduces thermal loading.

#### WARNING/ALARM 11, Motor thermistor overtemp

The thermistor may be disconnected. Select whether the frequency converter issues a warning or an alarm in *parameter 1-90 Motor Thermal Protection*.

##### Troubleshooting

- Check for motor overheating.
- Check if the motor is mechanically overloaded.
- Check that the thermistor is connected correctly between either terminal 53 or 54 (analog voltage input) and terminal 50 (+10 V supply). Also check that the terminal switch for 53 or 54 is set for voltage. Check that *parameter 1-93 Thermistor Resource* is set to terminal 53 or 54.
- When using digital inputs 18 or 19, check that the thermistor is connected correctly between either terminal 18 or 19 (digital input PNP only) and terminal 50.
- If a KTY Sensor is used, check for correct connection between terminals 54 and 55.
- If using a thermal switch or thermistor, check that the programming of *parameter 1-93 Thermistor Resource* matches sensor wiring.
- If using a KTY Sensor, check the programming of *parameter 1-95 KTY Sensor Type*, *parameter 1-96 KTY Thermistor Resource*, and *parameter 1-97 KTY Threshold level* match sensor wiring.

#### WARNING/ALARM 12, Torque limit

The torque has exceeded the value in *parameter 4-16 Torque Limit Motor Mode* or the value in *parameter 4-17 Torque Limit Generator Mode*. *Parameter 14-25 Trip Delay at Torque Limit* can change this warning from a warning-only condition to a warning followed by an alarm.

##### Troubleshooting

- If the motor torque limit is exceeded during ramp-up, extend the ramp-up time.
- If the generator torque limit is exceeded during ramp-down, extend the ramp-down time.
- If torque limit occurs while running, increase the torque limit. Make sure that the system can operate safely at a higher torque.
- Check the application for excessive current draw on the motor.

#### WARNING/ALARM 13, Over current

The inverter peak current limit (approximately 200% of the rated current) is exceeded. The warning lasts approximately 1.5 s, then the frequency converter trips and issues an alarm. Shock loading or quick acceleration with high-inertia

loads can cause this fault. If the acceleration during ramp-up is quick, the fault can also appear after kinetic back-up. If extended mechanical brake control is selected, a trip can be reset externally.

##### Troubleshooting

- Remove the power and check if the motor shaft can be turned.
- Check that the motor size matches the frequency converter.
- Check that the motor data is correct in *parameters 1-20 to 1-25*.

#### ALARM 14, Earth (ground) fault

There is current from the output phases to ground, either in the cable between the frequency converter and the motor, or in the motor itself.

##### Troubleshooting

- Remove the power to the frequency converter and repair the ground fault.
- Check for ground faults in the motor by measuring the resistance to the ground of the motor cables and the motor with a megohmmeter.
- Perform a current sensor test.

#### ALARM 15, Hardware mismatch

A fitted option is not operational with the present control board hardware or software.

Record the value of the following parameters and contact Danfoss:

- *Parameter 15-40 FC Type*.
- *Parameter 15-41 Power Section*.
- *Parameter 15-42 Voltage*.
- *Parameter 15-43 Software Version*.
- *Parameter 15-45 Actual Typecode String*.
- *Parameter 15-49 SW ID Control Card*.
- *Parameter 15-50 SW ID Power Card*.
- *Parameter 15-60 Option Mounted*.
- *Parameter 15-61 Option SW Version* (for each option slot).

#### ALARM 16, Short circuit

There is short-circuiting in the motor or motor wiring.

##### Troubleshooting

- Remove the power to the frequency converter and repair the short circuit.

#### WARNING/ALARM 17, Control word timeout

There is no communication with the frequency converter. The warning is only active when *parameter 8-04 Control Word Timeout Function* is not set to [0] Off.

If *parameter 8-04 Control Word Timeout Function* is set to [2] *Stop* and [26] *Trip*, a warning appears and the frequency converter ramps down until it trips and then shows an alarm.

#### Troubleshooting

- Check the connections on the serial communication cable.
- Increase *parameter 8-03 Control Word Timeout Time*.
- Check the operation of the communication equipment.
- Verify a proper installation based on EMC requirements.

#### WARNING/ALARM 22, Hoist mechanical brake

The value of this warning/alarm shows the type of warning/alarm.

0 = The torque reference was not reached before timeout (*parameter 2-27 Torque Ramp Up Time*).

1 = Expected brake feedback not received before timeout (*parameter 2-23 Activate Brake Delay*, *parameter 2-25 Brake Release Time*).

#### WARNING 23, Internal fan fault

The fan warning function is an extra protective function that checks if the fan is running/mounted. The fan warning can be disabled in *parameter 14-53 Fan Monitor* ([0] *Disabled*).

#### Troubleshooting

- Check the fan resistance.
- Check the soft charge fuses.

#### WARNING 24, External fan fault

The fan warning function is an extra protective function that checks if the fan is running/mounted. The fan warning can be disabled in *parameter 14-53 Fan Monitor* ([0] *Disabled*).

#### Troubleshooting

- Check the fan resistance.
- Check the soft charge fuses.

#### WARNING 25, Brake resistor short circuit

The brake resistor is monitored during operation. If a short circuit occurs, the brake function is disabled and the warning appears. The frequency converter is still operational, but without the brake function.

#### Troubleshooting

- Remove the power to the frequency converter and replace the brake resistor (refer to *parameter 2-15 Brake Check*).

#### WARNING/ALARM 26, Brake resistor power limit

The power transmitted to the brake resistor is calculated as a mean value over the last 120 s of run time. The calculation is based on the DC-link voltage and the brake resistance value set in *parameter 2-16 AC brake Max. Current*. The warning is active when the dissipated braking

is >90% of the brake resistance power. If [2] *Trip* is selected in *parameter 2-13 Brake Power Monitoring*, the frequency converter trips when the dissipated braking power reaches 100%.

### WARNING

If the brake transistor is short-circuited, there is a risk of substantial power being transmitted to the brake resistor.

#### WARNING/ALARM 27, Brake chopper fault

This alarm/warning could occur if the brake resistor overheats. Terminals 104 and 106 are available as brake resistors Klixon inputs.

### NOTICE

This signal feedback is used by LHD to monitor the temperature of the HI inductor. This fault indicates that Klixon opened on the HI inductor at the active filter side.

#### WARNING/ALARM 28, Brake check failed

The brake resistor is not connected or not working.

#### Troubleshooting

- Check *parameter 2-15 Brake Check*.

#### ALARM 29, Heat Sink temp

The maximum temperature of the heat sink has been exceeded. The temperature fault resets when the temperature falls below a defined heat sink temperature. The trip and reset points vary based on the frequency converter power size.

#### Troubleshooting

Check for the following conditions:

- Ambient temperature too high.
- Motor cables too long.
- Incorrect airflow clearance above and below the frequency converter.
- Blocked airflow around the frequency converter.
- Damaged heat sink fan.
- Dirty heat sink.

For D, E, and F enclosures, this alarm is based on the temperature measured by the heat sink sensor mounted inside the IGBT modules. For the F enclosures, the thermal sensor in the rectifier module can also cause this alarm.

#### Troubleshooting

- Check the fan resistance.
- Check the soft charge fuses.
- Check the IGBT thermal sensor.

#### ALARM 30, Motor phase U missing

Motor phase U between the frequency converter and the motor is missing.



### Troubleshooting

- Remove the power from the frequency converter and check motor phase U.

### ALARM 31, Motor phase V missing

Motor phase V between the frequency converter and the motor is missing.

### Troubleshooting

- Remove the power from the frequency converter and check motor phase V.

### ALARM 32, Motor phase W missing

Motor phase W between the frequency converter and the motor is missing.

### Troubleshooting

- Remove the power from the frequency converter and check motor phase W.

### ALARM 33, Inrush fault

Too many power-ups have occurred within a short time period.

### Troubleshooting

- Let the unit cool to operating temperature.

### WARNING/ALARM 34, Fieldbus communication fault

The fieldbus on the communication option card is not working.

### WARNING/ALARM 36, Mains failure

This warning/alarm is only active if the supply voltage to the frequency converter is lost and *parameter 14-10 Mains Failure* is not set to [0] No Function.

### Troubleshooting

- Check the fuses to the frequency converter and mains supply to the unit.

### ALARM 38, Internal fault

When an internal fault occurs, a code number defined in *Table 7.1* is shown.

### Troubleshooting

- Cycle the power.
- Check that the option is properly installed.
- Check for loose or missing wiring.

It may be necessary to contact Danfoss Service or the supplier. Note the code number for further troubleshooting directions.

| Number  | Text  |
|---------|---|
| 0       | The serial port cannot be initialized. Contact the Danfoss supplier or Danfoss Service. |
| 256–258 | The power EEPROM data is defective or too old.  |
| 512     | The control board EEPROM data is defective or too old.                                  |
| 513     | Communication timeout reading EEPROM data.  |
| 514     | Communication timeout reading EEPROM data.  |
| 515     | Application-oriented control cannot recognize the EEPROM data.                          |

| Number    | Text   |
|-----------|--|
| 516       | Cannot write to the EEPROM because a write command is in progress.   |
| 517       | The write command is under timeout.  |
| 518       | Failure in the EEPROM.   |
| 519       | Missing or invalid barcode data in EEPROM.   |
| 783       | Parameter value outside of minimum/maximum limits.   |
| 1024–1279 | A CAN telegram could not be sent.  |
| 1281      | Digital signal processor flash timeout.  |
| 1282      | Power micro software version mismatch.   |
| 1283      | Power EEPROM data version mismatch.  |
| 1284      | Cannot read digital signal processor software version.   |
| 1299      | The option software in slot A is too old.  |
| 1300      | The option software in slot B is too old.  |
| 1301      | The option software in slot C0 is too old.   |
| 1302      | The option software in slot C1 is too old.   |
| 1315      | The option software in slot A is not supported (not allowed).  |
| 1316      | The option software in slot B is not supported (not allowed).  |
| 1317      | The option software in slot C0 is not supported (not allowed).   |
| 1318      | The option software in slot C1 is not supported (not allowed).   |
| 1379      | Option A did not respond when calculating the platform version.  |
| 1380      | Option B did not respond when calculating the platform version.  |
| 1381      | Option C0 did not respond when calculating the platform version.   |
| 1382      | Option C1 did not respond when calculating the platform version.   |
| 1536      | An exception in the application-oriented control is registered. The debug information is written on the LCP. |
| 1792      | DSP watchdog is active. Debugging of power part data, motor-oriented control data not transferred correctly. |
| 2049      | Power data restarted.  |
| 2064–2072 | H081x: Option in slot x has restarted.   |
| 2080–2088 | H082x: Option in slot x has issued a power-up wait.  |
| 2096–2104 | H983x: Option in slot x has issued a legal power-up wait.  |
| 2304      | Could not read any data from the power EEPROM.   |
| 2305      | Missing software version from the power unit.  |
| 2314      | Missing power unit data from the power unit.   |
| 2315      | Missing software version from the power unit.  |
| 2316      | Missing lo_statepage from the power unit.  |
| 2324      | The power card configuration is determined to be incorrect at power-up.                                      |
| 2325      | A power card has stopped communicating while mains power is applied.   |

| Number    | Text  |
|-----------|---|
| 2326      | The power card configuration is determined to be incorrect after the delay for power cards to register. |
| 2327      | Too many power card locations have been registered as present.  |
| 2330      | The power size information between the power cards does not match.                                      |
| 2561      | No communication from DSP to ATACD.   |
| 2562      | No communication from ATACD to DSP (state running).   |
| 2816      | Stack overflow control board module.  |
| 2817      | Scheduler slow tasks.   |
| 2818      | Fast tasks.   |
| 2819      | Parameter thread.   |
| 2820      | LCP stack overflow.   |
| 2821      | Serial port overflow.   |
| 2822      | USB port overflow.  |
| 2836      | cflistMempool is too small.   |
| 3072-5122 | The parameter value is outside its limits.  |
| 5123      | Option in slot A: Hardware incompatible with the control board hardware.                                |
| 5124      | Option in slot B: Hardware incompatible with the control board hardware.                                |
| 5125      | Option in slot C0: Hardware incompatible with the control board hardware.                               |
| 5126      | Option in slot C1: Hardware incompatible with the control board hardware.                               |
| 5376-6231 | Out of memory.  |

Table 7.1 Internal Fault, Code Numbers

#### ALARM 39, Heat sink sensor

No feedback from the heat sink temperature sensor.

The signal from the IGBT thermal sensor is not available on the power card. The problem could be on the power card, on the gatedrive card, or the ribbon cable between the power card and gatedrive card.

#### WARNING 40, Overload of digital output terminal 27

Check the load connected to terminal 27 or remove the short circuit connection. Check *parameter 5-00 Digital I/O Mode* and *parameter 5-01 Terminal 27 Mode*.

#### WARNING 41, Overload of digital output terminal 29

Check the load connected to terminal 29 or remove the short circuit connection. Also check *parameter 5-00 Digital I/O Mode* and *parameter 5-02 Terminal 29 Mode*.

#### WARNING 42, Overload of digital output on X30/6 or overload of digital output on X30/7

For terminal X30/6, check the load connected to terminal X30/6 or remove the short circuit connection. Also check *parameter 5-32 Term X30/6 Digi Out (MCB 101)* (VLT® General Purpose I/O MCB 101).

For terminal X30/7, check the load connected to terminal X30/7 or remove the short circuit connection. Check

*parameter 5-33 Term X30/7 Digi Out (MCB 101)* (VLT® General Purpose I/O MCB 101).

#### ALARM 45, Earth fault 2

Ground fault.

##### Troubleshooting

- Check for proper grounding and loose connections.
- Check for proper wire size.
- Check the motor cables for short circuits or leakage currents.

#### ALARM 46, Power card supply

The supply on the power card is out of range.

There are 3 power supplies generated by the switch mode power supply (SMPS) on the power card: 24 V, 5 V, and  $\pm 18$  V. When powered with 24 V DC with the MCB 107, only the 24 V and 5 V supplies are monitored. When powered with 3-phase mains voltage, all 3 supplies are monitored.

#### WARNING 47, 24 V supply low

The supply on the power card is out of range.

There are 3 supplies generated by the switch mode supply (SMPS) on the power card:

- 24 V.
- 5 V.
- $\pm 18$  V.

##### Troubleshooting

- Check for a defective power card.

#### WARNING 48, 1.8 V supply low

The 1.8 V DC supply used on the control card is outside of the allowable limits. The supply is measured on the control card.

##### Troubleshooting

- Check for a defective control card.
- If an option card is present, check for overvoltage.

#### WARNING 49, Speed limit

The warning is shown when the speed is outside of the specified range in *parameter 4-11 Motor Speed Low Limit [RPM]* and *parameter 4-13 Motor Speed High Limit [RPM]*. When the speed is below the specified limit in *parameter 1-86 Trip Speed Low [RPM]* (except when starting or stopping), the frequency converter trips.

#### ALARM 50, AMA calibration failed

Contact the Danfoss supplier or Danfoss service department.

#### ALARM 51, AMA check $U_{nom}$ and $I_{nom}$

The settings for motor voltage, motor current, and motor power are wrong.

##### Troubleshooting

- Check the settings in *parameters 1-20 to 1-25*.

#### ALARM 52, AMA low $I_{nom}$

The motor current is too low.

##### Troubleshooting

- Check the settings in *parameter 1-24 Motor Current*.

#### ALARM 53, AMA motor too big

The motor is too large for the AMA to operate.

#### ALARM 54, AMA motor too small

The motor is too small for the AMA to operate.

#### ALARM 55, AMA parameter out of range

AMA cannot run because the parameter values of the motor are outside of the acceptable range.

#### ALARM 56, AMA interrupted by user

The AMA is manually interrupted.

#### ALARM 57, AMA internal fault

Continue to restart the AMA, until the AMA is carried out.

### NOTICE

Repeated runs may heat the motor to a level where the resistance  $R_s$  and  $R_r$  are increased. Usually, however, this behavior is not critical.

#### ALARM 58, AMA Internal fault

Contact the Danfoss supplier.

#### WARNING 59, Current limit

The current is higher than the value in *parameter 4-18 Current Limit*. Ensure that motor data in *parameters 1-20 to 1-25* is set correctly. Increase the current limit if necessary. Ensure that the system can operate safely at a higher limit.

#### WARNING 60, External interlock

External interlock has been activated. To resume normal operation, apply 24 V DC to the terminal programmed for external interlock and reset the frequency converter (via serial communication, digital I/O, or by pressing [Reset]).

#### WARNING/ALARM 61, Tracking error

An error has occurred between the calculated motor speed and the speed measurement from the feedback device. The function warning/alarm/disable is set in *parameter 4-30 Motor Feedback Loss Function*. Accepted error setting in *parameter 4-31 Motor Feedback Speed Error* and the allowed time the error occur setting in *parameter 4-32 Motor Feedback Loss Timeout*. During a commissioning procedure, the function could be effective.

#### WARNING 62, Output frequency at maximum limit

The output frequency is higher than the value set in *parameter 4-19 Max Output Frequency*.

#### ALARM 63, Mechanical brake low

The actual motor current has not exceeded the release brake current within the start delay time window.

#### ALARM 64, Voltage Limit

The load and speed combination demands a motor voltage higher than the actual DC-link voltage.

#### WARNING/ALARM 65, Control card over temperature

The cut-out temperature of the control card is 85 °C.

##### Troubleshooting

- Check that the ambient operating temperature is within the limits.
- Check for clogged filters.
- Check the fan operation.
- Check the control card.

#### WARNING 66, Heat sink temperature low

The frequency converter is too cold to operate. This warning is based on the temperature sensor in the IGBT module.

Increase the ambient temperature of the unit. Also, a trickle amount of current can be supplied to the frequency converter whenever the motor is stopped by setting *parameter 2-00 DC Hold/Preheat Current* at 5% and *parameter 1-80 Function at Stop*.

##### Troubleshooting

The heat sink temperature measured as 0 °C could indicate that the temperature sensor is defective, causing the fan speed to increase to the maximum. This warning results if the sensor wire between the IGBT and the gatedrive card is disconnected. Also, check the IGBT thermal sensor.

#### ALARM 67, Option module configuration has changed

One or more options have either been added or removed since the last power-down. Check that the configuration change is intentional and reset the unit.

#### ALARM 68, Safe Stop activated

STO has been activated. To resume normal operation, apply 24 V DC to terminal 37, then send a reset signal (via bus, digital I/O, or by pressing [Reset]).

#### ALARM 69, Power card temperature

The temperature sensor on the power card is either too hot or too cold.

##### Troubleshooting

- Check the operation of the door fans.
- Check that the filters for the door fans are not blocked.
- Check that the gland plate is properly installed on IP21/IP54 (NEMA 1/12) frequency converters.

#### ALARM 70, Illegal FC configuration

The control card and power card are incompatible. To check compatibility, contact the Danfoss supplier with the type code from the unit nameplate and the part numbers of the cards.

#### ALARM 71, PTC 1 Safe Torque Off

STO has been activated from the VLT® PTC Thermistor Card MCB 112 (motor too warm). Normal operation can resume when the VLT® PTC Thermistor Card MCB 112 applies 24 V DC to terminal 37 (when the motor temperature is acceptable) and when the digital input from the VLT® PTC Thermistor Card MCB 112 is deactivated. When that

happens, a reset signal is sent (via Bus, Digital I/O, or by pressing [Reset]).

### **NOTICE**

If automatic restart is enabled, the motor could start when the fault is cleared.

#### **ALARM 72, Dangerous failure**

STO with trip lock. Unexpected signal levels on safe torque off and digital input from the VLT® PTC Thermistor Card MCB 112.

#### **WARNING 73, Safe Stop auto restart**

STO activated. With automatic restart enabled, the motor can start when the fault is cleared.

#### **WARNING 76, Power unit setup**

The required number of power units does not match the detected number of active power units.

This warning occurs when replacing a module for an F-size enclosure if the power-specific data in the module power card does not match the rest of the frequency converter.

#### **Troubleshooting**

- Confirm that the spare part and its power card are the correct part number.

#### **WARNING 77, Reduced power mode**

The frequency converter is operating in reduced power mode (less than the allowed number of inverter sections). This warning is generated on power cycle when the frequency converter is set to run with fewer inverters and remains on.

#### **ALARM 79, Illegal power section configuration**

The scaling card has an incorrect part number or is not installed. The MK102 connector on the power card could not be installed.

#### **ALARM 80, Drive initialised to default value**

Parameter settings are initialized to default settings after a manual reset. To clear the alarm, reset the unit.

#### **ALARM 81, CSIV corrupt**

CSIV file has syntax errors.

#### **ALARM 82, CSIV parameter error**

CSIV failed to initialize a parameter.

#### **ALARM 85, Dang fail PB**

PROFIBUS/PROFIsafe error.

#### **WARNING/ALARM 104, Mixing fan fault**

The fan is not operating. The fan monitor checks that the fan is spinning at power-up or whenever the mixing fan is turned on. The mixing-fan fault can be configured as a warning or an alarm trip in *parameter 14-53 Fan Monitor*.

#### **Troubleshooting**

- Cycle power to the frequency converter to determine if the warning/alarm returns.

#### **ALARM 243, Brake IGBT**

This alarm is only for enclosure size F frequency converters. It is equivalent to Alarm 27.

The report value in the alarm log indicates which power module generated the alarm:

- 1 = Left most inverter module.
- 2 = Middle inverter module in enclosure sizes F12 or F13.
- 2 = Right inverter module in enclosure sizes F10 or F11.
- 2 = Second frequency converter from the left inverter module in enclosure size F14.
- 3 = Right inverter module in enclosure sizes F12 or F13.
- 3 = Third from the left inverter module in enclosure size F14 or F15.
- 4 = Far right inverter module in enclosure size F14.
- 5 = Rectifier module.
- 6 = Right rectifier module in enclosure size F14 or F15.

#### **ALARM 244, Heat Sink temperature**

This alarm is only for enclosure type F frequency converters. It is equivalent to Alarm 29.

The report value in the alarm log indicates which power module generated the alarm:

- 1 = Left most inverter module.
- 2 = Middle inverter module in enclosure size F12 or F13.
- 2 = Right inverter module in enclosure size F10 or F11.
- 2 = Second frequency converter from the left inverter module in enclosure size F14 or F15.
- 3 = Right inverter module in enclosure sizes F12 or F13.
- 3 = Third from the left inverter module in enclosure size F14 or F15.
- 4 = Far right inverter module in enclosure sizes F14 or F15.
- 5 = Rectifier module.
- 6 = Right rectifier module in enclosure sizes F14 or F15.

#### **ALARM 245, Heat Sink sensor**

This alarm is only for enclosure size F frequency converters. It is equivalent to Alarm 39.

The report value in the alarm log indicates which power module generated the alarm:

- 1 = Left most inverter module.
- 2 = Middle inverter module in enclosure sizes F12 or F13.
- 2 = Right inverter module in enclosure sizes F10 or F11.

- 2 = Second frequency converter from the left inverter module in enclosure size F14 or F15.
- 3 = Right inverter module in enclosure sizes F12 or F13.
- 3 = Third from the left inverter module in enclosure size F14 or F15.
- 4 = Far right inverter module in enclosure size F14 or F15.
- 5 = Rectifier module.
- 6 = Right rectifier module in enclosure size F14 or F15.

The 12-pulse frequency converter may generate this warning/alarm when one of the disconnects or circuit breakers is opened while the unit is on.

#### **ALARM 246, Power card supply**

This alarm is only for enclosure size F frequency converters. It is equivalent to Alarm 46.

The report value in the alarm log indicates which power module generated the alarm:

- 1 = Left most inverter module.
- 2 = Middle inverter module in enclosure sizes F12 or F13.
- 2 = Right inverter module in enclosure sizes F10 or F11.
- 2 = Second frequency converter from the left inverter module in enclosure size F14 or F15.
- 3 = Right inverter module in enclosure sizes F12 or F13.
- 3 = Third from the left inverter module in enclosure size F14 or F15.
- 4 = Far right inverter module in enclosure size F14 or F15.
- 5 = Rectifier module.
- 6 = Right rectifier module in enclosure size F14 or F15.

#### **ALARM 247, Power card temperature**

This alarm is only for enclosure size F frequency converters. It is equivalent to Alarm 69.

The report value in the alarm log indicates which power module generated the alarm:

- 1 = Left most inverter module.
- 2 = Middle inverter module in enclosure sizes F12 or F13.

- 2 = Right inverter module in enclosure sizes F10 or F11.
- 2 = Second frequency converter from the left inverter module in enclosure size F14 or F15.
- 3 = Right inverter module in enclosure sizes F12 or F13.
- 3 = Third from the left inverter module in enclosure size F14 or F15.
- 4 = Far right inverter module in enclosure size F14 or F15.
- 5 = Rectifier module.
- 6 = Right rectifier module in enclosure size F14 or F15.

#### **ALARM 248, Illegal power section configuration**

This alarm is only for enclosure size F frequency converters. It is equivalent to Alarm 79.

The report value in the alarm log indicates which power module generated the alarm:

- 1 = Left most inverter module.
- 2 = Middle inverter module in enclosure sizes F12 or F13.
- 2 = Right inverter module in enclosure sizes F10 or F11.
- 2 = Second frequency converter from the left inverter module in enclosure size F14 or F15.
- 3 = Right inverter module in enclosure sizes F12 or F13.
- 3 = Third from the left inverter module in enclosure sizes F14 or F15.
- 4 = Far right inverter module in enclosure sizes F14 or F15.
- 5 = Rectifier module.
- 6 = Right rectifier module in enclosure size F14 or F15.

#### **WARNING 250, New spare part**

The power or switch mode supply has been exchanged. Restore the frequency converter type code in the EEPROM. Select the correct type code in *parameter 14-23 Typecode Setting* according to the label on the frequency converter. Remember to select Save to EEPROM at the end.

#### **WARNING 251, New typecode**

The power card or other components are replaced and the type code has changed.

## 7.4 Warnings and Alarm Definitions - Active Filter

### NOTICE

After a manual reset pressing [Reset], press [Auto On] or [Hand On] to restart the unit.

| Number | Description                            | Warning | Alarm/Trip | Alarm/Trip Lock | Parameter Reference |
|--------|--|---------|------------|-----------------|---------------------|
| 1      | 10 Volts low                           | X       |            |                 |                     |
| 2      | Live zero error                        | (X)     | (X)        |                 | 6-01                |
| 4      | Mains phase loss                       | X       |            |                 |                     |
| 5      | DC link voltage high                   | X       |            |                 |                     |
| 6      | DC link voltage low                    | X       |            |                 |                     |
| 7      | DC over voltage                        | X       | X          |                 |                     |
| 8      | DC under voltage                       | X       | X          |                 |                     |
| 13     | Over current                           | X       | X          | X               |                     |
| 14     | Earth fault                            | X       | X          | X               |                     |
| 15     | Hardware mismatch                      |         | X          | X               |                     |
| 16     | Short circuit                          |         | X          | X               |                     |
| 17     | Control word timeout                   | (X)     | (X)        |                 | 8-04                |
| 23     | Internal fan fault                     | X       |            |                 |                     |
| 24     | External fan fault                     | X       |            |                 | 14-53               |
| 29     | Heatsink temp                          | X       | X          | X               |                     |
| 33     | Inrush fault                           |         | X          | X               |                     |
| 34     | Fieldbus fault                         | X       | X          |                 |                     |
| 35     | Option fault                           | X       | X          |                 |                     |
| 38     | Internal fault                         |         |            |                 |                     |
| 39     | Heatsink sensor                        |         | X          | X               |                     |
| 40     | Overload of digital output terminal 27 | (X)     |            |                 | 5-00, 5-01          |
| 41     | Overload of digital output terminal 29 | (X)     |            |                 | 5-00, 5-02          |
| 46     | Pwr. card supply                       |         | X          | X               |                     |
| 47     | 24 V supply low                        | X       | X          | X               |                     |
| 48     | 1.8 V supply low                       |         | X          | X               |                     |
| 65     | Control board over-temperature         | X       | X          | X               |                     |
| 66     | Heat sink temperature low              | X       |            |                 |                     |
| 67     | Option configuration has changed       |         | X          |                 |                     |
| 68     | Safe torque off activated              |         | X          |                 |                     |
| 69     | Pwr. card temp                         |         | X          | X               |                     |
| 70     | Illegal FC configuration               |         |            | X               |                     |
| 72     | Dangerous failure                      |         |            | X               |                     |
| 73     | Safe torque off auto restart           |         |            |                 |                     |
| 76     | Power unit setup                       | X       |            |                 |                     |
| 79     | Illegal PS config                      |         | X          | X               |                     |
| 80     | Unit initialised to default value      |         | X          |                 |                     |
| 250    | New spare part                         |         |            | X               |                     |
| 251    | New type code                          |         | X          | X               |                     |
| 300    | Mains cont. fault                      | X       |            |                 |                     |
| 301    | SC cont. fault                         | X       |            |                 |                     |
| 302    | Cap. over current                      | X       | X          |                 |                     |
| 303    | Cap. earth fault                       | X       | X          |                 |                     |
| 304    | DC over current                        | X       | X          |                 |                     |
| 305    | Mains freq. limit                      |         | X          |                 |                     |
| 306    | Compensation Limit                     |         |            |                 |                     |
| 308    | Resistor temp                          | X       |            | X               |                     |
| 309    | Mains earth fault                      | X       | X          |                 |                     |
| 311    | Switch. freq. limit                    |         | X          |                 |                     |

| Number | Description       | Warning | Alarm/Trip | Alarm/Trip Lock | Parameter Reference |
|--------|-------------------|---------|------------|-----------------|---------------------|
| 312    | CT range          |         | X          |                 |                     |
| 314    | Auto CT interrupt |         | X          |                 |                     |
| 315    | Auto CT error     |         | X          |                 |                     |
| 316    | CT location error | X       |            |                 |                     |
| 317    | CT polarity error | X       |            |                 |                     |
| 318    | CT ratio error    | X       |            |                 |                     |

**Table 7.2 Alarm/Warning Code List**

A trip is the action when an alarm has appeared. The trip disables the active filter and can be reset by pressing [Reset] or resetting via a digital input (parameter group 5-1\* *Digital Inputs [1] Reset*). The original event that caused an alarm cannot damage the active filter or cause dangerous conditions. A trip lock is an action when an alarm occurs, which may cause damage to active filter or connected parts. A trip lock situation can only be reset by a power cycling.

|             |                |
|-------------|----------------|
| Warning     | Yellow         |
| Alarm       | Flashing red   |
| Trip locked | Yellow and red |

**Table 7.3 LED Indicator Lights**

| Alarm word and extended status word |          |            |                     |                      |                      |
|-------------------------------------|----------|------------|---------------------|----------------------|----------------------|
| Bit                                 | Hex      | Dec        | Alarm word          | Warning word         | Extended status word |
| 0                                   | 00000001 | 1          | Mains cont. fault   | Reserved             | Reserved             |
| 1                                   | 00000002 | 2          | Heat sink temp      | Heat sink temp       | Auto CT running      |
| 2                                   | 00000004 | 4          | Ground fault        | Ground fault         | Reserved             |
| 3                                   | 00000008 | 8          | Ctrl.card temp      | Ctrl.card temp       | Reserved             |
| 4                                   | 00000010 | 16         | Ctrl. word TO       | Ctrl. word TO        | Reserved             |
| 5                                   | 00000020 | 32         | Over current        | Over current         | Reserved             |
| 6                                   | 00000040 | 64         | SC cont. fault      | Reserved             | Reserved             |
| 7                                   | 00000080 | 128        | Cap. over current   | Cap. over current    | Reserved             |
| 8                                   | 00000100 | 256        | Cap. earth fault    | Cap. earth fault     | Reserved             |
| 9                                   | 00000200 | 512        | Inverter overld.    | Inverter overld.     | Reserved             |
| 10                                  | 00000400 | 1024       | DC under volt       | DC under volt        | Reserved             |
| 11                                  | 00000800 | 2048       | DC over volt        | DC over volt         | Reserved             |
| 12                                  | 00001000 | 4096       | Short circuit       | DC voltage low       | Reserved             |
| 13                                  | 00002000 | 8192       | Inrush fault        | DC voltage high      | Reserved             |
| 14                                  | 00004000 | 16384      | Mains ph. loss      | Mains ph. loss       | Reserved             |
| 15                                  | 00008000 | 32768      | Auto CT error       | Reserved             | Reserved             |
| 16                                  | 00010000 | 65536      | Reserved            | Reserved             | Reserved             |
| 17                                  | 00020000 | 131072     | Internal fault      | 10 V low             | Password Time Lock   |
| 18                                  | 00040000 | 262144     | DC over current     | DC over current      | Password Protection  |
| 19                                  | 00080000 | 524288     | Resistor temp       | Resistor temp        | Reserved             |
| 20                                  | 00100000 | 1048576    | Mains earth fault   | Mains earth fault    | Reserved             |
| 21                                  | 00200000 | 2097152    | Switch. freq. limit | Reserved             | Reserved             |
| 22                                  | 00400000 | 4194304    | Fieldbus fault      | Fieldbus fault       | Reserved             |
| 23                                  | 00800000 | 8388608    | 24 V supply low     | 24 V supply low      | Reserved             |
| 24                                  | 01000000 | 16777216   | CT range            | Reserved             | Reserved             |
| 25                                  | 02000000 | 33554432   | 1.8 V supply low    | Reserved             | Reserved             |
| 26                                  | 04000000 | 67108864   | Reserved            | Low temp             | Reserved             |
| 27                                  | 08000000 | 134217728  | Auto CT interrupt   | Reserved             | Reserved             |
| 28                                  | 10000000 | 268435456  | Option change       | Reserved             | Reserved             |
| 29                                  | 20000000 | 536870912  | Unit initialised    | Unit initialised     | Reserved             |
| 30                                  | 40000000 | 1073741824 | Safe torque off     | Safe torque off      | Reserved             |
| 31                                  | 80000000 | 2147483648 | Mains freq. limit   | Extended status word | Reserved             |

Table 7.4 Description of Alarm Word, Warning Word, and Extended Status Word

The alarm words, warning words, and extended status words can be read out via serial bus or optional fieldbus for diagnosis. See also *parameter 16-90 Alarm Word*, *parameter 16-92 Warning Word*, and *parameter 16-94 Ext. Status Word*. Reserved means that the bit is not guaranteed to be any particular value. Reserved bits should not be used for any purpose.



## 7.4.1 Fault Messages for Active Filter

### WARNING 1, 10 volts low

The control card voltage is below 10 V from terminal 50. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Maximum 15 mA or minimum 590 Ω.

### WARNING/ALARM 2, Live zero error

The signal on terminal 53 or 54 is less than 50% of the value set in:

- *Parameter 6-10 Terminal 53 Low Voltage.*
- *Parameter 6-12 Terminal 53 Low Current.*
- *Parameter 6-20 Terminal 54 Low Voltage.*
- *Parameter 6-22 Terminal 54 Low Current.*

### WARNING 4, Mains phase loss

A phase is missing on the supply side, or the mains voltage imbalance is too high.

### WARNING 5, DC-link voltage high

The DC-link voltage (DC) is higher than the high-voltage warning limit. The unit is still active.

### WARNING 6, DC-link voltage low

The DC-link voltage (DC) is below the low-voltage warning limit. The unit is still active.

### WARNING/ALARM 7, DC overvoltage

If the DC-link voltage exceeds the limit, the unit trips.

### WARNING/ALARM 8, DC under voltage

If the DC-link voltage (DC) drops below the undervoltage limit, the filter checks if a 24 V back-up supply is connected. If not, the filter trips. Check that the mains voltage matches the nameplate specification.

### WARNING/ALARM 13, Overcurrent

The unit current limit has been exceeded.

### ALARM 14, Ground fault

The sum current of the IGBT CTs does not equal 0. Check if the resistance of any phase-to-ground has a low value. Check both before and after mains contactor. Ensure that IGBT current transducers, connection cables, and connectors are OK.

### ALARM 15, Incomp. Hardware

A mounted option is incompatible with the present control card SW/HW.

### ALARM 16, Short circuit

There is a short circuit in the output. Turn off the unit and correct the error.

### WARNING/ALARM 17, Control word time-out

There is no communication to the unit.

The warning is only active when *parameter 8-04 Control Word Timeout Function* is not set to off.

Possible correction: Increase *parameter 8-03 Control Word Timeout Time*. Change *parameter 8-04 Control Word Timeout Function*

### WARNING 23, Internal fan fault

Internal fans have failed due to defect hardware or fans not mounted.

### WARNING 24, External fan fault

External fans have failed due to defective hardware or fans not mounted.

### ALARM 29, Heat sink temp

The maximum temperature of the heat sink has been exceeded. The temperature fault is not reset until the temperature drops below a defined heat sink temperature.

### ALARM 33, Inrush fault

Check whether a 24 V external DC supply has been connected.

### WARNING/ALARM 34, Fieldbus communication fault

The fieldbus on the communication option card is not working.

### WARNING/ALARM 35, Option fault:

Contact Danfoss or supplier.

### ALARM 38, Internal fault

Contact Danfoss or supplier.

### ALARM 39, Heat sink sensor

No feedback from the heat sink temperature sensor.

### WARNING 40, Overload of digital output terminal 27

Check the load connected to terminal 27 or remove short circuit connection.

### WARNING 41, Overload of digital output terminal 29

Check the load connected to terminal 29 or remove short circuit connection.

### ALARM 46, Power card supply

The supply on the power card is out of range.

### WARNING 47, 24 V supply low

Contact Danfoss or supplier.

### WARNING 48, 1.8 V supply low

Contact Danfoss or supplier.

### WARNING/ALARM/TRIP 65, Control card overtemperature

Control card overtemperature: The cut-out temperature of the control card is 80 °C.

### WARNING 66, Heat sink temperature low

This warning is based on the temperature sensor in the IGBT module.

### Troubleshooting

The heat sink temperature measured as 0 °C could indicate that the temperature sensor is defective, causing the fan speed to increase to the maximum. If the sensor wire between the IGBT and the gate drive card is disconnected, this warning would result. Also, check the IGBT thermal sensor.

### ALARM 67, Option module configuration has changed

One or more options have either been added or removed since the last power-down.

#### **ALARM 68, Safe Torque Off (STO) activated**

Safe Torque Off (STO) has been activated. To resume normal operation, apply 24 V DC to terminal 37, then send a reset signal (via bus, digital I/O, or by pressing [Reset]). See *parameter 5-19 Terminal 37 Safe Stop*.

#### **ALARM 69, Power card temperature**

The temperature sensor on the power card is either too hot or too cold.

#### **ALARM 70, Illegal FC Configuration**

Actual combination of control board and power board is illegal.

#### **ALARM 79, Illegal power section configuration**

The scaling card is the incorrect part number or not installed. Also MK102 connector on the power card could not be installed.

#### **ALARM 80, Unit initialised to default value**

Parameter settings are initialised to default settings after a manual reset.

#### **ALARM 247, Power card temperature**

Power card overtemperature. A report value indicates the source of the alarm (from left):

1–4 inverter.

5–8 rectifier.

#### **ALARM 250, New spare part**

The power or switch mode supply has been exchanged. Restore the filter type code in the EEPROM. Select the correct type code in *parameter 14-23 Typecode Setting* according to the label on the unit. Remember to select *Save to EEPROM* to complete.

#### **ALARM 251, New type code**

The filter has a new type code.

#### **ALARM 300, Mains cont. fault**

The feedback from the mains contactor did not match the expected value within the allowed time frame. Contact Danfoss or supplier.

#### **ALARM 301, SC cont. fault**

The feedback from the soft charge contactor did not match the expected value within the allowed time frame. Contact Danfoss or supplier.

#### **ALARM 302, Cap. overcurrent**

Excessive current was detected through the AC capacitors. Contact Danfoss or supplier.

#### **ALARM 303, Cap. ground fault**

A ground fault was detected through the AC capacitor currents. Contact Danfoss or supplier.

#### **ALARM 304, DC overcurrent**

Excessive current through the DC-link capacitor bank was detected. Contact Danfoss or supplier.

#### **ALARM 305, Mains freq. limit**

The mains frequency was outside the limits. Verify that the mains frequency is within product specification.

#### **ALARM 306, Compensation limit**

The needed compensation current exceeds unit capability. The unit runs at full compensation.

#### **ALARM 308, Resistor temp**

Excessive resistor heat sink temperature detected.

#### **ALARM 309, Mains ground fault**

A ground fault was detected in the mains currents. Check the mains for shorts and leakage current.

#### **ALARM 310, RTDC buffer full**

Contact Danfoss or supplier.

#### **ALARM 311, Switch. freq. limit**

The average switching frequency of the unit exceeded the limit. Verify that *parameter 300-10 Active Filter Nominal Voltage* and *parameter 300-22 CT Nominal Voltage* are set correctly. If so, contact Danfoss or supplier.

#### **ALARM 312, CT range**

Current transformer measurement limitation was detected. Verify that the CTs used are an appropriate ratio.

#### **ALARM 314, Auto CT interrupt**

Auto CT detection has been interrupted.

#### **ALARM 315, Auto CT error**

An error was detected while performing auto CT detection. Contact Danfoss or supplier.

#### **WARNING 316, CT location error**

The auto CT function could not determine the correct locations of the CTs.

#### **WARNING 317, CT polarity error**

The auto CT function could not determine the correct polarity of the CTs.

#### **WARNING 318, CT ratio error**

The auto CT function could not determine the correct primary rating of the CTs.

## 7.5 Troubleshooting

| Symptom                          | Possible cause   | Test  | Solution   |
|----------------------------------|--|---|--|
| Display dark/no function         | Missing input power.   | See <i>Table 5.1</i> .  | Check the input power source.  |
|                                  | Missing or open fuses, or circuit breaker tripped.   | See <i>Open fuses and Tripped circuit breaker</i> in this table for possible causes.  | Follow the recommendations provided.   |
|                                  | No power to the LCP.   | Check the LCP cable for proper connection or damage.  | Replace the faulty LCP or connection cable.  |
|                                  | Shortcut on control voltage (terminal 12 or 50) or at control terminals.                                 | Check the 24 V control voltage supply for terminals 12/13 to 20–39 or 10 V supply for terminals 50–55.  | Wire the terminals properly.   |
|                                  | Wrong LCP (LCP from VLT® 2800 or 5000/6000/8000/ FCD or FCM).  |   | Use only LCP 101 (P/N 130B1124) or LCP 102 (P/N 130B1107).   |
|                                  | Wrong contrast setting.  |   | Press [Status] + [▲]/[▼] to adjust the contrast  |
|                                  | Display (LCP) is defective.  | Test using a different LCP.   | Replace the faulty LCP or connection cable.  |
|                                  | Internal voltage supply fault or SMPS is defective.  |   | Contact supplier.  |
| Intermittent display             | Overloaded power supply (SMPS) due to improper control wiring or a fault within the frequency converter. | To rule out a problem in the control wiring, disconnect all control wiring by removing the terminal blocks.   | If the display stays lit, then the problem is in the control wiring. Check the wiring for shorts or incorrect connections. If the display continues to cut out, follow the procedure for display dark.                       |
| Motor not running                | Service switch open or missing motor connection.   | Check if the motor is connected and the connection is not interrupted (by a service switch or other device).  | Connect the motor and check the service switch.  |
|                                  | No mains power with 24 V DC option card.   | If the display is functioning but no output, check that mains power is applied to the frequency converter.  | Apply mains power to run the unit.   |
|                                  | LCP Stop.  | Check if [Off] has been pressed.  | Press [Auto On] or [Hand On] (depending on operation mode) to run the motor.   |
|                                  | Missing start signal (Standby).  | Check <i>parameter 5-10 Terminal 18 Digital Input</i> for correct setting for terminal 18 (use default setting).  | Apply a valid start signal to start the motor.   |
|                                  | Motor coast signal active (Coasting).  | Check <i>parameter 5-12 Terminal 27 Digital Input</i> for correct setting for terminal 27 (use default setting).  | Apply 24 V on terminal 27 or program this terminal to [0] <i>No operation</i> .  |
|                                  | Wrong reference signal source.   | Check reference signal: Local, remote or bus reference? Preset reference active? Terminal connection correct? Scaling of terminals correct? Reference signal available? | Program correct settings. Check <i>parameter 3-13 Reference Site</i> . Set preset reference active in parameter group 3-1* <i>References</i> . Check for correct wiring. Check scaling of terminals. Check reference signal. |
| Motor running in wrong direction | Motor rotation limit.  | Check that <i>parameter 4-10 Motor Speed Direction</i> is programmed correctly.   | Program correct settings.  |
|                                  | Active reversing signal.   | Check if a reversing command is programmed for the terminal in parameter group 5-1* <i>Digital inputs</i> .   | Deactivate reversing signal.   |
|                                  | Wrong motor phase connection.  |   | See <i>chapter 4.6.1 Motor Cable</i> .   |

| Symptom                                  | Possible cause   | Test  | Solution  |
|--|--|---|---|
| Motor is not reaching maximum speed      | Frequency limits set wrong.  | Check output limits in: <ul style="list-style-type: none"> <li>Parameter 4-13 Motor Speed High Limit [RPM].</li> <li>Parameter 4-14 Motor Speed High Limit [Hz].</li> <li>Parameter 4-19 Max Output Frequency.</li> </ul> | Program correct limits.   |
|  | Reference input signal not scaled correctly.   | Check reference input signal scaling in 6-0* Analog I/O Mode and parameter group 3-1* References. Reference limits in parameter group 3-0* Reference Limit.   | Program correct settings.   |
| Motor speed unstable                     | Possible incorrect parameter settings.   | Check the settings of all motor parameters, including all motor compensation settings. For closed-loop operation, check PID settings.   | Check settings in parameter group 1-6* Load Depen. Setting. For closed-loop operation, check settings in parameter group 20-0* Feedback.  |
| Motor runs rough                         | Possible overmagnetisation.  | Check for incorrect motor settings in all motor parameters.   | Check motor settings in parameter groups 1-2* Motor Data, 1-3* Adv Motor Data, and 1-5* Load Indep. Setting.  |
| Motor does not brake                     | Possible incorrect settings in the brake parameters. Possible too short ramp down times. | Check brake parameters. Check ramp time settings.   | Check parameter group 2-0* DC Brake and 3-0* Reference Limits.  |
| Open power fuses or circuit breaker trip | Phase-to-phase shortcircuit.   | Motor or panel has a short phase-to-phase. Check motor and panel phase for short circuits.  | Eliminate any short circuits detected.  |
|  | Motor overload.  | Motor is overloaded for the application.  | Perform start-up test and verify that the motor current is within specifications. If motor current is exceeding nameplate full load current, motor may run only with reduced load. Review the specifications for the application. |
|  | Loose connections.   | Perform pre-startup check for loose connections.  | Tighten loose connections.  |
| Mains current imbalance greater than 3%  | Problem with mains power (See Alarm 4 Mains phase loss description).                     | Rotate input power leads into the frequency converter 1 position: A to B, B to C, C to A.   | If imbalanced leg follows the wire, it is a power problem. Check mains power supply.  |
|  | Problem with the frequency converter.  | Rotate input power leads into the frequency converter 1 position: A to B, B to C, C to A.   | If imbalance leg stays on same input terminal, it is a problem with the unit. Contact the supplier.   |
| Motor current imbalance greater than 3%  | Problem with motor or motor wiring.  | Rotate output motor leads 1 position: U to V, V to W, W to U.   | If imbalanced leg follows the wire, the problem is in the motor or motor wiring. Check motor and motor wiring.  |
|  | Problem with the frequency converters.   | Rotate output motor leads 1 position: U to V, V to W, W to U.   | If imbalance leg stays on same output terminal, it is a problem with the unit. Contact the supplier.  |

| Symptom   | Possible cause                                   | Test  | Solution  |
|---|--|---|---|
| Acoustic noise or vibration<br>(for example a fan blade is making noise or vibrations at certain frequencies) | Resonances, for example in the motor/fan system. | Bypass critical frequencies by using parameters in parameter group 4-6* <i>Speed Bypass</i> . | Check if noise and/or vibration have been reduced to an acceptable limit. |
|   |  | Turn off overmodulation in <i>parameter 14-03 Overmodulation</i> .                            |   |
|   |  | Change switching pattern and frequency in parameter group 14-0* <i>Inverter Switching</i> .   |   |
|   |  | Increase resonance dampening in <i>parameter 1-64 Resonance Dampening</i> .                   |   |

Table 7.5 Troubleshooting

## 8 Specifications

### 8.1 Power-Dependent Specifications

#### 8.1.1 Mains Supply 3x380–480 V AC







| Mains Supply 3x380–480 V AC   |  | N160   | N200              | N250              |
|---|--|--|-------------------|-------------------|
| Normal overload = 110% current for 60 s*  |  | NO   | NO                | NO                |
|   | Typical shaft output at 400 V [kW]   | 160  | 200               | 250               |
|   | Typical shaft output at 460 V [hp]   | 250  | 300               | 350               |
|   | Typical shaft output at 480 V [kW]   | 200  | 250               | 315               |
|   | Enclosure protection rating IP21/Nema Type 1   | D1n  | D2n               | D2n               |
|   | Enclosure protection rating IP54/NEMA Type 12  | D1n  | D2n               | D2n               |
|   | <b>Output current</b>  |  |                   |                   |
|   | Continuous (at 400 V) [A]  | 315  | 395               | 480               |
|   | Intermittent (60 s overload) (at 400 V) [A]  | 347  | 435               | 528               |
|   | Continuous (at 460/480 V) [A]  | 302  | 361               | 443               |
|   | Intermittent (60 s overload) (at 460/480 V) [A]  | 332  | 397               | 487               |
|   | Continuous kVA (at 400 V) [kVA]  | 218  | 274               | 333               |
|   | Continuous kVA (at 460 V) [kVA]  | 241  | 288               | 353               |
|   | Continuous kVA (at 480 V) [kVA]  | 262  | 313               | 384               |
|   |  |  |                   |                   |
| Maximum input current   |  |  |                   |                   |
|  | Continuous (at 400 V) [A]  | 304  | 381               | 463               |
|   | Continuous (at 460/480 V) [A]  | 291  | 348               | 427               |
|   | Maximum cable size, mains motor, brake, and load share [mm <sup>2</sup> (AWG <sup>2</sup> )] | Motor, brake, and load share: 2x95 (2x3/0)<br>Mains: 2x185 (2x350) | 2x185 (2x350 mcm) | 2x185 (2x350 mcm) |
|   | Maximum external mains fuses [A] <sup>1)</sup>   | 400  | 550               | 630               |
|   | Total LHD loss 400 V AC [W]  | 8725   | 9831              | 11371             |
|   | Total back channel loss 400 V AC [W]   | 7554   | 8580              | 10020             |
|   | Total filter loss 400 V AC [W]   | 4954   | 5714              | 6234              |
|   | Total LHD loss 460 V AC [W]  | 8906   | 9046              | 10626             |
|   | Total back channel loss 460 V AC [W]   | 7343   | 7374              | 8948              |
|   | Total filter loss 460 V AC [W]   | 4063   | 4187              | 4822              |
|   | Weight [kg/(lb)]   | 352 (776)  | 413 (910)         | 413 (910)         |
|   | Efficiency <sup>4)</sup>   | 0.96   |                   |                   |
|   | Acoustic noise   | 85dBa  |                   |                   |
|   | Output frequency   | 0–590 Hz   |                   |                   |
|   | Heat sink overtemperature trip   | 105 °C (221 °F)  |                   |                   |
|   | Power card ambient trip  | 85 °C (185 °F)   |                   |                   |
| * High overload = 150% current for 60 s, normal overload = 110% current for 60 s.   |  |  |                   |                   |

Table 8.1 D-frame Ratings

| Mains supply 3x380–480 V AC   |   |                   |                   |                   |                   |
|---|---|-------------------|-------------------|-------------------|-------------------|
|   |   | P315              | P355              | P400              | P450              |
| Normal overload = 110% current for 60 s*  |   | NO                | NO                | NO                | NO                |
|   | Typical shaft output at 400 V [kW]                            | 315               | 355               | 400               | 450               |
|   | Typical shaft output at 460 V [hp]                            | 450               | 500               | 600               | 600               |
|   | Typical shaft output at 480 V [kW]                            | 355               | 400               | 500               | 530               |
|   | Enclosure protection rating IP21/NEMA Type 1                  | E9                | E9                | E9                | E9                |
|   | Enclosure protection rating IP54/NEMA Type 12                 | E9                | E9                | E9                | E9                |
| Output current  |   |                   |                   |                   |                   |
|    | Continuous (at 400 V) [A]                                     | 600               | 658               | 745               | 800               |
|   | Intermittent (60 s overload) (at 400 V) [A]                   | 660               | 724               | 820               | 880               |
|   | Continuous (at 460/480 V) [A]                                 | 540               | 590               | 678               | 730               |
|   | Intermittent (60 s overload) (at 460/480 V) [A]               | 594               | 649               | 746               | 803               |
|   | Continuous kVA (at 400 V) [kVA]                               | 416               | 456               | 516               | 554               |
|   | Continuous kVA (at 460 V) [kVA]                               | 430               | 470               | 540               | 582               |
|   | Continuous kVA (at 480 V) [kVA]                               | 468               | 511               | 587               | 632               |
| Maximum input current   |   |                   |                   |                   |                   |
|  | Continuous (at 400 V) [A]                                     | 590               | 647               | 733               | 787               |
|   | Continuous (at 460/480 V) [A]                                 | 531               | 580               | 667               | 718               |
|   | Maximum cable size, mains, motor, and load share [mm² (AWG²)] | 4x240 (4x500 mcm) | 4x240 (4x500 mcm) | 4x240 (4x500 mcm) | 4x240 (4x500 mcm) |
|   | Maximum cable size, brake [mm² (AWG²)]                        | 2x185 (2x350 mcm) | 2x185 (2x350 mcm) | 2x185 (2x350 mcm) | 2x185 (2x350 mcm) |
|   | Maximum external mains fuses [A]¹)                            | 700               | 900               | 900               | 900               |
|   | Total LHD loss 400 V AC [W]                                   | 14051             | 15320             | 17180             | 18447             |
|   | Total back channel loss 400 V AC [W]                          | 11301             | 11648             | 13396             | 14570             |
|   | Total filter loss 400 V AC [W]                                | 7346              | 7788              | 8503              | 8974              |
|   | Total LHD loss 460 V AC [W]                                   | 12936             | 14083             | 15852             | 16962             |
|   | Total back channel loss 460 V AC [W]                          | 10277             | 10522             | 12184             | 13214             |
|   | Total filter loss 460 V AC [W]                                | 7066              | 7359              | 8033              | 8435              |
|   | Weight [kg/(lb)]  | 596 (1314)        | 623 (1373)        | 646 (1424)        | 646 (1424)        |
|   | Efficiency⁴)  | 0.96              |                   |                   |                   |
|   | Acoustic noise  | 72dBa             |                   |                   |                   |
|   | Output frequency  | 0–590 Hz          |                   |                   |                   |
|   | Heat sink overtemperature trip                                | 105 °C (221 ° F)  |                   |                   |                   |
|   | Power card ambient trip                                       | 85 °C (185 ° F)   |                   |                   |                   |

\* High overload = 160% current for 60 s, normal overload = 110% current for 60 s.

Table 8.2 E-frame Ratings

| Mains supply 3x380–480 V AC  |   |                      |       |       |       |
|--|---|----------------------|-------|-------|-------|
|  |   | P500                 | P560  | P630  | P710  |
| Normal overload =110% current for 60 s*  |   | NO                   | NO    | NO    | NO    |
|  | Typical shaft output at 400 V [kW]  | 500                  | 560   | 630   | 710   |
|  | Typical shaft output at 460 V [hp]  | 650                  | 750   | 900   | 1000  |
|  | Typical shaft output at 480 V [kW]  | 560                  | 630   | 710   | 800   |
|  | Enclosure protection rating IP21/<br>NEMA Type 1<br>IP54/NEMA Type 12     | F18                  | F18   | F18   | F18   |
|  | Output current  |                      |       |       |       |
|   | Continuous<br>(at 400 V) [A]  | 880                  | 990   | 1120  | 1260  |
|  | Intermittent (60 s overload)<br>(at 400 V) [A]                            | 968                  | 1089  | 1232  | 1386  |
|  | Continuous<br>(at 460/480 V) [A]  | 780                  | 890   | 1050  | 1160  |
|  | Intermittent (60 s overload)<br>(at 460/480 V) [A]                        | 858                  | 979   | 1155  | 1276  |
|  | Continuous kVA<br>(at 400 V) [kVA]  | 610                  | 686   | 776   | 873   |
|  | Continuous kVA<br>(at 460 V) [kVA]  | 621                  | 709   | 837   | 924   |
|  | Continuous kVA<br>(at 480 V) [kVA]  | 675                  | 771   | 909   | 1005  |
| Maximum input current  |   |                      |       |       |       |
|  | Continuous<br>(at 400 V) [A]  | 857                  | 964   | 1090  | 1227  |
|  | Continuous (at 460/480 V) [A]   | 759                  | 867   | 1022  | 1129  |
|  | Maximum cable size, motor [mm <sup>2</sup><br>(AWG <sup>2</sup> )]        | 8x150<br>(8x300 mcm) |       |       |       |
|  | Maximum cable size, mains F1/F2<br>[mm <sup>2</sup> (AWG <sup>2</sup> )]  | 8x240<br>(8x500 mcm) |       |       |       |
|  | Maximum cable size, mains F3/F4<br>[mm <sup>2</sup> (AWG <sup>2</sup> )]  | 8x456<br>(8x900 mcm) |       |       |       |
|  | Maximum cable size, load sharing<br>[mm <sup>2</sup> (AWG <sup>2</sup> )] | 4x120<br>(4x250 mcm) |       |       |       |
|  | Maximum cable size, brake [mm <sup>2</sup><br>(AWG <sup>2</sup> )]        | 4x185<br>(4x350 mcm) |       |       |       |
|  | Maximum. external mains fuses [A] <sup>1)</sup>                           | 1600                 |       | 2000  |       |
|  | Total LHD loss<br>400 V AC [W]  | 21909                | 24592 | 26640 | 30519 |
|  | Total back channel loss<br>400 V AC [W]                                   | 17767                | 19984 | 21728 | 24936 |
|  | Total filter loss<br>400 V AC [W]   | 11747                | 12771 | 14128 | 15845 |
|  | Total LHD loss<br>460 V AC [W]  | 19896                | 22353 | 25030 | 27989 |
|  | Total back channel loss<br>460 V AC [W]                                   | 16131                | 18175 | 20428 | 22897 |
|  | Total filter loss<br>460 V AC [W]   | 11020                | 11929 | 13435 | 14776 |
|  | Maximum panel options losses  | 400                  |       |       |       |
|  | Weight [kg/(lb)]  | 2009 (4429)          |       |       |       |
|  | Weight frequency converter section<br>[kg/(lb)]                           | 1004 (2213)          |       |       |       |
|  | Weight filter section [kg/(lb)]   | 1005 (2216)          |       |       |       |
|  | Efficiency <sup>4)</sup>  | 0.96                 |       |       |       |
|  | Acoustic noise  | 69dBa                |       |       |       |
|  | Output frequency  | 0–590 Hz             |       |       |       |
|  | Heat sink overtemperate trip  | 105 °C (221 ° F)     |       |       |       |
|  | Power card ambient trip   | 85 °C (185 ° F)      |       |       |       |

\* High overload = 160% current for 60 s, normal overload = 110% current for 60 s.

\* High overload = 160% current for 60 s, normal overload = 110% current for 60 s.

Table 8.3 F-frame Ratings



1) For type of fuse see *chapter 8.4.1 Fuses*.

2) American Wire Gauge.

3) Measured using 5 m shielded motor cables at rated load and rated frequency.

4) The typical power loss is at nominal load conditions and expected to be within  $\pm 15\%$  (tolerance relates to variety in voltage and cable conditions). Values are based on a typical motor efficiency (eff2/eff3 border line). Motors with lower efficiency also add to the power loss in the frequency converter and opposite. Applies for dimensioning of frequency converter cooling. If the switching frequency is higher than the default setting, the power losses may increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, refer to [www.danfoss.com/vltenergyefficiency](http://www.danfoss.com/vltenergyefficiency).

Further options and customer load may add up to 30 W to the losses (though typical only 4 W extra for a fully loaded control card, or options for slot A or slot B, each).


Although measurements are made with state-of-the-art equipment, some measurement inaccuracy must be allowed for ( $\pm 5\%$ ).

Efficiency measured at nominal current. For energy efficiency class, see *chapter 8.3 General Technical Data*. For part load losses, see [www.danfoss.com/vltenergyefficiency](http://www.danfoss.com/vltenergyefficiency).


## 8.1.2 Derating for Temperature

8


The frequency converter automatically derates the switching frequency, switching type, or output current under certain load or ambient conditions as described in the following. *Illustration 8.1*, *Illustration 8.2*, *Illustration 8.3*, and *Illustration 8.4* show the derating curve for SFAWM and 60 AVM switching modes.



**Illustration 8.1 Derating Enclosure Size D, N160 to N250 380–480 V (T5) Normal Overload 110%, 60 AVM**



**Illustration 8.2 Derating Enclosure Size D, N160 to N250 380–480 V (T5) Normal Overload 110%, SFAWM**



**Illustration 8.3 Derating Enclosure Sizes E and F, P315 to P710 380–480 V (T5) Normal Overload 110%, 60 AVM**




Illustration 8.4 Derating Enclosure Sizes E and F, P315 to P710  
380–480 V (T5) Normal Overload 110%, SFAVM

## 8.2 Mechanical Dimensions




Illustration 8.5 Enclosure Size D1n





Illustration 8.6 Enclosure Size D2n



8

Illustration 8.7 Enclosure Size E9




Illustration 8.8 Enclosure Size F18, Front, and Side View

### 8.3 General Technical Data

#### Mains supply (L1, L2, L3)

|                |               |
|----------------|---------------|
| Supply voltage | 380–480 V +5% |
|----------------|---------------|

#### Mains voltage low/mains drop-out:

During low mains voltage or mains drop-out, the frequency converter continues until the DC-link voltage drops below the minimum stop level, corresponding to 15% below the lowest rated supply voltage. Power-up and full torque cannot be expected at mains voltage lower than 10% below the lowest rated supply voltage.

|                  |              |
|------------------|--------------|
| Supply frequency | 50/60 Hz ±5% |
|------------------|--------------|

|  |                              |
|--|------------------------------|
| Maximum imbalance temporary between mains phases | 3.0% of rated supply voltage |
|--|------------------------------|

|                                 |                             |
|---------------------------------|-----------------------------|
| True power factor ( $\lambda$ ) | >0.98 nominal at rated load |
|---------------------------------|-----------------------------|

|   |         |
|---|---------|
| Displacement power factor ( $\cos\phi$ ) near unity | (>0.98) |
|---|---------|

|      |     |
|------|-----|
| THDi | <5% |
|------|-----|

|  |                        |
|--|------------------------|
| Switching on input supply L1, L2, L3 (power-ups) | maximum once/2 minutes |
|--|------------------------|

|                                    |   |
|------------------------------------|---|
| Environment according to EN60664-1 | overvoltage category III/pollution degree 2 |
|------------------------------------|---|

The unit is suitable for use on a circuit capable of delivering not more than 100000 RMS symmetrical Amperes, 480/690 V maximum.

#### Motor output (U, V, W)

|                |                          |
|----------------|--------------------------|
| Output voltage | 0–100% of supply voltage |
|----------------|--------------------------|

|                  |                        |
|------------------|------------------------|
| Output frequency | 0–590 Hz <sup>1)</sup> |
|------------------|------------------------|

|                     |           |
|---------------------|-----------|
| Switching on output | Unlimited |
|---------------------|-----------|

|            |             |
|------------|-------------|
| Ramp times | 0.01–3600 s |
|------------|-------------|

1) Voltage and power dependent

#### Torque characteristics

|                                   |                                     |
|-----------------------------------|-------------------------------------|
| Starting torque (constant torque) | maximum 150% for 60 s <sup>1)</sup> |
|-----------------------------------|-------------------------------------|

|                 |  |
|-----------------|--|
| Starting torque | maximum 180% up to 0.5 s <sup>1)</sup> |
|-----------------|--|

|                                   |                                     |
|-----------------------------------|-------------------------------------|
| Overload torque (constant torque) | maximum 150% for 60 s <sup>1)</sup> |
|-----------------------------------|-------------------------------------|

1) Percentage relates to nominal torque of the unit.

#### Cable lengths and cross-sections

|   |                |
|---|----------------|
| Maximum motor cable length, screened/armoured | 150 m (500 ft) |
|---|----------------|

|   |                 |
|---|-----------------|
| Maximum motor cable length, unscreened/unarmoured | 300 m (1000 ft) |
|---|-----------------|

|  |  |
|--|--|
| Maximum cross-section to motor, mains, load sharing, and brake <sup>1)</sup> |  |
|--|--|

|  |  |
|--|--|
| Maximum cross-section to control terminals, rigid wire | 1.5 mm <sup>2</sup> (16 AWG) (2x0.75 mm <sup>2</sup> ) |
|--|--|

|  |                            |
|--|----------------------------|
| Maximum cross-section to control terminals, flexible cable | 1 mm <sup>2</sup> (18 AWG) |
|--|----------------------------|

|  |                              |
|--|------------------------------|
| Maximum cross-section to control terminals, cable with enclosed core | 0.5 mm <sup>2</sup> (20 AWG) |
|--|------------------------------|

|  |                               |
|--|-------------------------------|
| Minimum cross-section to control terminals | 0.25 mm <sup>2</sup> (24 AWG) |
|--|-------------------------------|

1) See chapter 8.1.1 Mains Supply 3x380–480 V AC for more information

#### Digital inputs

|                             |   |
|-----------------------------|---|
| Programmable digital inputs | 4 (6) on frequency converter and 2 (4) on active filter |
|-----------------------------|---|

|                 |  |
|-----------------|--|
| Terminal number | 18, 19, 27 <sup>1)</sup> , 29 <sup>1)</sup> , 32, and 33 |
|-----------------|--|

|       |            |
|-------|------------|
| Logic | PNP or NPN |
|-------|------------|

|               |           |
|---------------|-----------|
| Voltage level | 0–24 V DC |
|---------------|-----------|

|                            |         |
|----------------------------|---------|
| Voltage level, logic 0 PNP | <5 V DC |
|----------------------------|---------|

|                            |          |
|----------------------------|----------|
| Voltage level, logic 1 PNP | >10 V DC |
|----------------------------|----------|

|                            |          |
|----------------------------|----------|
| Voltage level, logic 0 NPN | >19 V DC |
|----------------------------|----------|

|                            |          |
|----------------------------|----------|
| Voltage level, logic 1 NPN | <14 V DC |
|----------------------------|----------|

|                          |         |
|--------------------------|---------|
| Maximum voltage on input | 28 V DC |
|--------------------------|---------|

|                         |                            |
|-------------------------|----------------------------|
| Input resistance, $R_i$ | approximately 4 k $\Omega$ |
|-------------------------|----------------------------|

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

1) Terminals 27 and 29 can also be programmed as output.

# Analog inputs

|                              |   |
|------------------------------|---|
| Number of analog inputs      | 2 on frequency converter                              |
| Terminal number              | 53 and 54   |
| Modes                        | Voltage or current                                    |
| Mode select                  | Switch S201 and switch S202, switch A53 and A54       |
| Voltage mode                 | Switch S201/switch S202 = OFF (U), switch A53 and A54 |
| Voltage level                | 0–10 V (scaleable)                                    |
| Input resistance, $R_i$      | Approximately 10 k $\Omega$                           |
| Maximum voltage              | $\pm 20$ V  |
| Current mode                 | Switch S201/switch S202 = ON (I), switch A53 and A54  |
| Current level                | 0/4–20 mA (scaleable)                                 |
| Input resistance, $R_i$      | approximately 200 $\Omega$                            |
| Maximum current              | 30 mA   |
| Resolution for analog inputs | 10 bit (+ sign)                                       |
| Accuracy of analog inputs    | Maximum error 0.5% of full scale                      |
| Bandwidth                    | 100 Hz (D-frame), 200 Hz                              |

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high voltage terminals.




Illustration 8.9 PELV Isolation of Analog Inputs

# Pulse inputs

|  |                                   |
|--|-----------------------------------|
| Programmable pulse inputs                | 2 on frequency converter          |
| Terminal number pulse                    | 29 and 33                         |
| Maximum frequency at terminal, 29 and 33 | 110 kHz (push-pull driven)        |
| Maximum frequency at terminal, 29 and 33 | 5 kHz (open collector)            |
| Minimum frequency at terminal 29 and 33  | 4 Hz                              |
| Voltage level                            | see chapter 8.3.1 Digital inputs  |
| Maximum voltage on input                 | 28 V DC                           |
| Input resistance, $R_i$                  | approximately 4 k $\Omega$        |
| Pulse input accuracy (0.1–1 kHz)         | Maximum error: 0.1% of full scale |

# Analog output

|  |   |
|--|---|
| Number of programmable analog outputs            | 1 on both frequency converter and active filter |
| Terminal number                                  | 42  |
| Current range at analog output                   | 0/4–20 mA                                       |
| Maximum resistor load to common at analog output | 500 $\Omega$                                    |
| Accuracy on analog output                        | Maximum error: 0.8% of full scale               |
| Resolution on analog output                      | 8 bit   |

The analog output is galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

# Control card, RS485 serial communication

|                    |                                    |
|--------------------|------------------------------------|
| Terminal number    | 68 (PTX+, RX+) and 69 (N,TX-, RX-) |
| Terminal number 61 | Common for terminals 68 and 69     |

The RS485 serial communication circuit is functionally separated from other central circuits and galvanically isolated from the supply voltage (PELV).

**Digital output**

|  |   |
|--|---|
| Programmable digital/pulse outputs           | 2 on both frequency converter and active filter |
| Terminal number                              | 27 and 29 <sup>1)</sup>                         |
| Voltage level at digital/frequency output    | 0–24 V  |
| Maximum output current (sink or source)      | 40 mA   |
| Maximum load at frequency output             | 1 kΩ  |
| Maximum capacitive load at frequency output  | 10 nF   |
| Minimum output frequency at frequency output | 0 Hz  |
| Maximum output frequency at frequency output | 32 kHz  |
| Accuracy of frequency output                 | Maximum error: 0.1% of full scale               |
| Resolution of frequency outputs              | 12 bit  |

1) Terminals 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

**Control card, 24 V DC output**

|                 |                 |
|-----------------|-----------------|
| Terminal number | 13              |
| Output voltage  | 24 V (+1, -3 V) |
| Maximum load    | 200 mA          |

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

**8**
**Relay outputs**

|   |   |
|---|---|
| Programmable relay outputs  | 2 on frequency converter only               |
| <b>Relay 01 terminal number (D-frame)</b>   | 1–3 (break), 1–2 (make)                     |
| Maximum terminal load (AC-1) <sup>1)</sup> on 1–2 (NO) (Resistive load) <sup>2)3)</sup> | 400 V AC, 2 A                               |
| Maximum terminal load (AC-15) <sup>1)</sup> on 1–2 (NO) (Inductive load @ cosφ 0.4)     | 240 V AC, 0.2 A                             |
| Maximum terminal load (DC-1) <sup>1)</sup> on 1–2 (NO) (Resistive load)                 | 80 V DC, 2 A                                |
| Maximum terminal load (DC-13) <sup>1)</sup> on 1–2 (NO) (Inductive load)                | 24 V DC, 0.1 A                              |
| Maximum terminal load (AC-1) <sup>1)</sup> on 1–3 (NC) (Resistive load)                 | 240 V AC, 2 A                               |
| Maximum terminal load (AC-15) <sup>1)</sup> on 1–3 (NC) (Inductive load @ cosφ 0.4)     | 240 V AC, 0.2 A                             |
| Maximum terminal load (DC-1) <sup>1)</sup> on 1–3 (NC) (Resistive load)                 | 50 V DC, 2 A                                |
| Maximum terminal load (DC-13) <sup>1)</sup> on 1–3 (NC) (Inductive load)                | 24 V DC, 0.1 A                              |
| Minimum terminal load on 1–3 (NC), 1–2 (NO)   | 24 V DC 10 mA, 24 V AC 2 mA                 |
| Environment according to EN 60664-1   | overvoltage category III/pollution degree 2 |
| <b>Relay 01 terminal number (E-frame and F-frame)</b>                                   | 1–3 (break), 1–2 (make)                     |
| Maximum terminal load (AC-1) <sup>1)</sup> on 1–3 (NC), 1–2 (NO) (resistive load)       | 240 V AC, 2 A                               |
| Maximum terminal load (AC-15) <sup>1)</sup> (inductive load @ cosφ 0.4)                 | 240 V AC, 0.2 A                             |
| Maximum terminal load (DC-1) <sup>1)</sup> on 1–2 (NO), 1–3 (NC) (resistive load)       | 60 V DC, 1 A                                |
| Maximum terminal load (DC-13) <sup>1)</sup> (inductive load)                            | 24 V DC, 0.1 A                              |
| <b>Relay 02 terminal number</b>   | 4–6 (break), 4–5 (make)                     |
| Maximum terminal load (AC-1) <sup>1)</sup> on 4–5 (NO) (resistive load) <sup>2)3)</sup> | 400 V AC, 2 A                               |
| Maximum terminal load (AC-15) <sup>1)</sup> on 4–5 (NO) (inductive load @ cosφ 0.4)     | 240 V AC, 0.2 A                             |
| Maximum terminal load (DC-1) <sup>1)</sup> on 4–5 (NO) (resistive load)                 | 80 V DC, 2 A                                |
| Maximum terminal load (DC-13) <sup>1)</sup> on 4–5 (NO) (inductive load)                | 24 V DC, 0.1 A                              |
| Maximum terminal load (AC-1) <sup>1)</sup> on 4–6 (NC) (resistive load)                 | 240 V AC, 2 A                               |
| Maximum terminal load (AC-15) <sup>1)</sup> on 4–6 (NC) (inductive load @ cosφ 0.4)     | 240 V AC, 0.2 A                             |
| Maximum terminal load (DC-1) <sup>1)</sup> on 4–6 (NC) (resistive load)                 | 50 V DC, 2 A                                |
| Maximum terminal load (DC-13) <sup>1)</sup> on 4–6 (NC) (inductive load)                | 24 V DC, 0.1 A                              |
| Minimum terminal load on 1–3 (NC), 1–2 (NO), 4–6 (NC), 4–5 (NO)                         | 24 V DC 10 mA, 24 V AC 20 mA                |
| Environment according to EN 60664-1   | overvoltage category III/pollution degree 2 |

1) IEC 60947 parts 4 and 5.

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

2) Overvoltage Category II.

3) UL applications 300 V AC 2 A.

Control characteristics

|   |                                      |
|---|--------------------------------------|
| Resolution of output frequency at 0–1000 Hz                 | ±0.003 Hz                            |
| System response time (terminals 18, 19, 27, 29, 32, and 33) | ≤2 ms                                |
| Speed control range (open loop)                             | 1:100 of synchronous speed           |
| Speed accuracy (open loop)                                  | 30–4000 RPM: Maximum error of ±8 RPM |

*All control characteristics are based on a 4-pole asynchronous motor.*

Surroundings

|   |   |
|---|---|
| Enclosure protection rating, enclosure sizes D and E  | IP21, IP54  |
| Enclosure protection rating, enclosure size F   | IP21, IP54  |
| Vibration test  | 0.7 g   |
| Relative humidity   | 5–95% (IEC 721-3-3; Class 3K3 (non-condensing) during operation |
| Aggressive environment (IEC 60068-2-43) H <sub>2</sub> S test                                     | class kD  |
| Test method according to IEC 60068-2-43 H <sub>2</sub> S (10 days)                                |   |
| Ambient temperature (at 60 AVM switching mode)  |   |
| - with derating   | maximum 55 °C (131 °F)  |
| - with full output power, typical IE2 motors (see <i>chapter 8.1.2 Derating for Temperature</i> ) | maximum 50 °C (122 °F)  |
| - at full continuous FC output current  | maximum 45 °C (113 °F)  |
| Minimum ambient temperature during full-scale operation   | 0 °C (32 °F)  |
| Minimum ambient temperature at reduced performance  | -10 °C (14 °F)  |
| Temperature during storage/transport  | -25 to +65/70 °C (-13 to 149/158 °F)                            |
| Maximum altitude above sea level without derating   | 1000 m (3300 ft)  |
| Maximum altitude above sea level with derating  | 3000 m (10000 ft)   |

*For more information on derating, consult the design guide.*

|                         |  |
|-------------------------|--|
| EMC standards, emission | EN 61800-3, EN 61000-6-3/4, EN 55011, IEC 61800-3<br>EN 61800-3, EN 61000-6-1/2, |
| EMC standards, immunity | EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6             |

Control card performance

|               |      |
|---------------|------|
| Scan interval | 1 ms |
|---------------|------|

Control card, USB serial communication

|              |                        |
|--------------|------------------------|
| USB standard | 1.1 (full speed)       |
| USB plug     | USB type B device plug |

**NOTICE**

Connection to PC is carried out via a standard host/device USB cable.

The USB connection is galvanically isolated from the supply voltage (PELV) and other high voltage terminals.

The USB connection is not galvanically isolated from protective earth. Use only an isolated laptop/PC as connection to the USB connector on the frequency converter or an isolated USB cable/converter.

Protection and features:

- Electronic motor thermal protection against overload.
- Temperature monitoring of the heat sink ensures that the frequency converter trips if the temperature reaches a predefined level. An overload temperature cannot be reset until the temperature of the heat sink is below the allowed values.
- The frequency converter is protected against short circuits on motor terminals U, V, W.
- If a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- Monitoring of the DC-link voltage ensures that the frequency converter trips if the DC-link voltage is too low or too high.
- The frequency converter is protected against ground faults on motor terminals U, V, W.



## Specifications

## VLT® HVAC Drive FC 102 Low Harmonic Drive

### Power Ranges (LHD with AF)

|  |         |
|--|---------|
| Response time  | <0.5 ms |
| Settling time - reactive current control             | <40 ms  |
| Settling time - harmonic current control (filtering) | <20 ms  |
| Overshoot - reactive current control                 | <20%    |
| Overshoot - harmonic current control                 | <10%    |

### Grid conditions

|                |                        |
|----------------|------------------------|
| Supply voltage | 380–480 V, -10% to +5% |
|----------------|------------------------|

#### Mains voltage low/mains drop-out:

During low mains voltage or a mains drop-out, the filter continues until the DC-link voltage drops below the minimum stop level, which corresponds to 15% below the filter lowest rated supply voltage. Full compensation cannot be expected at mains voltage lower than 10% below the filter lowest rated supply voltage. If mains voltage exceeds the filter highest rated voltage, the filter continues to work but harmonic mitigation performance is reduced. The filter does not cut out until main voltages exceed 580 V.

|                  |                              |
|------------------|------------------------------|
| Supply frequency | 50/60 Hz ±5%                 |
|                  | 3.0% of rated supply voltage |

|   |   |
|---|---|
| Maximum imbalance temporary between mains phases where mitigation performance is kept high. | Filter mitigates at higher mains imbalance but harmonic mitigation performance is reduced<br>10% with kept mitigation performance |
|---|---|

|                             |  |
|-----------------------------|--|
| Maximum THDv pre-distortion | Reduced performance for higher pre-distortion levels |
|-----------------------------|--|

### Harmonic mitigation performance

|   |  |
|---|--|
|   | Best performance <4%                         |
| THDi                                    | Depending on filter vs. distortion ratio.    |
| Individual harmonic mitigation ability: | Current maximum RMS [% of rated RMS current] |
| 2 <sup>nd</sup>                         | 10%  |
| 4 <sup>th</sup>                         | 10%  |
| 5 <sup>th</sup>                         | 70%  |
| 7 <sup>th</sup>                         | 50%  |
| 8 <sup>th</sup>                         | 10%  |
| 10 <sup>th</sup>                        | 5%   |
| 11 <sup>th</sup>                        | 32%  |
| 13 <sup>th</sup>                        | 28%  |
| 14 <sup>th</sup>                        | 4%   |
| 16 <sup>th</sup>                        | 4%   |
| 17 <sup>th</sup>                        | 20%  |
| 19 <sup>th</sup>                        | 18%  |
| 20 <sup>th</sup>                        | 3%   |
| 22 <sup>nd</sup>                        | 3%   |
| 23 <sup>rd</sup>                        | 16%  |
| 25 <sup>th</sup>                        | 14%  |
| Total current of harmonics              | 90%  |

The filter is performance tested to the 40<sup>th</sup> order

### Reactive current compensation

|  |  |
|--|--|
| Cos phi                                      | Lagging and leading, depending on parameter settings |
| Cos phi                                      | Controllable 1.0 to 0.5 lagging                      |
| Reactive current, % of filter current rating | 100%   |

#### Generic specifications

|  |             |
|--|-------------|
| Filter efficiency                        | 97%         |
| Typical average switching frequency      | 3.0–4.5 kHz |
| Response time (reactive and harmonic)    | <0.5 ms     |
| Settling time - reactive current control | <20 ms      |
| Settling time - harmonic current control | <20 ms      |
| Overshoot - reactive current control     | <10%        |
| Overshoot - harmonic current control     | <10%        |

### 8.3.1 Derating for Altitude

The cooling capability of air is decreased at lower air pressure.

Below 1000 m (3300 ft) altitude, no derating is necessary, but above 1000 m (3300 ft), derate the ambient temperature ( $T_{AMB}$ ) or maximum output current ( $I_{out}$ ) in accordance with *Illustration 8.10*.

An alternative is to lower the ambient temperature at high altitudes and as a result of that ensure 100% output current at high altitudes. As an example of how to read the graph, the situation at 2000 m (6600 ft) is elaborated. At a temperature of 45 °C (113 °F) ( $T_{AMB, MAX} - 3.3 K$ ), 91% of the rated output current is available. At a temperature of 41.7 °C (107 °F), 100% of the rated output current is available.




Illustration 8.10 Altitude Derating




Illustration 8.11 Input/Output vs. Maximum Ambient Temperature

### 8.4 Fuses

Danfoss recommends using fuses and/or circuit breakers on the supply side as protection if there is component break-down inside the frequency converter (first fault).

#### NOTICE

Using fuses and/or circuit breakers ensures compliance with IEC 60364 for CE or NEC 2009 for UL.

#### Branch circuit protection

To protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines, and so on, must be protected against short circuit and overcurrent according to national/international regulations.

#### NOTICE

The recommendations do not cover branch circuit protection for UL.

#### Short-circuit protection

Danfoss recommends using the fuses/circuit breakers in *chapter 8.4.2 Fuse Tables* to protect service personnel and property if there is component break-down in the frequency converter.

## 8.4.1 Non-UL compliance

### Non-UL compliance

If UL/cUL is not to be complied with, Danfoss recommends using the fuses in *Table 8.4*, which ensure compliance with EN 50178:

|           |           |         |
|-----------|-----------|---------|
| N160–N250 | 380–500 V | Type gG |
| P315–P450 | 380–500 V | Type gR |

**Table 8.4 Recommended Fuses for non-UL Applications**

## 8.4.2 Fuse Tables

### UL Compliance

#### 380–480 V, enclosure sizes D, E, and F

The fuses below are suitable for use on a circuit capable of delivering 100000 Arms (symmetrical). With the proper fusing, the frequency converter short circuit current rating (SCCR) is 100000 Arms.

| Size/Type | Bussmann | Littelfuse  | Littelfuse PN | Bussmann PN | Siba PN       | Ferraz Shawmut Europ | Ferraz Shawmut NA | Ferraz Shawmut PN |
|-----------|----------|-------------|---------------|-------------|---------------|----------------------|-------------------|-------------------|
| 160 kW    | 170M4012 | LA50QS400-4 | L50S-400      | FWH-400A    | 20 610 31.400 | 6,9URD31D08A0400     | A070URD31KI0400   | A50QS400-4        |
| 200 kW    | 170M4015 | LA50QS500-4 | L50S-500      | FWH-500A    | 20 610 31.550 | 6,9URD31D08A0550     | A070URD31KI0550   | A50QS500-4        |
| 250 kW    | 170M5012 | LA50QS600-4 | L50S-600      | FWH-600A    | 20 610 31.630 | 6,9URD31D08A0630     | A070URD31KI0630   | A50QS600-4        |

**Table 8.5 Enclosure size D, Mains Fuses, 380–480 V**

| Size/Type | Bussmann PN <sup>1)</sup> | Rating       | Ferraz           | Siba          |
|-----------|---------------------------|--------------|------------------|---------------|
| 315 kW    | 170M4017                  | 700 A, 700 V | 6.9URD33D08A0700 | 20 630 32.700 |
| 355 kW    | 170M6013                  | 900 A, 700 V | 6.9URD33D08A0900 | 20 630 32.900 |
| 400 kW    | 170M6013                  | 900 A, 700 V | 6.9URD33D08A0900 | 20 630 32.900 |
| 450 kW    | 170M6013                  | 900 A, 700 V | 6.9URD33D08A0900 | 20 630 32.900 |

**Table 8.6 Enclosure size E, Mains Fuses, 380–480 V**

| Size/Type | Bussmann PN <sup>1)</sup> | Rating        | Siba           | Internal Bussmann option |
|-----------|---------------------------|---------------|----------------|--------------------------|
| 500 kW    | 170M7081                  | 1600 A, 700 V | 20 695 32.1600 | 170M7082                 |
| 560 kW    | 170M7081                  | 1600 A, 700 V | 20 695 32.1600 | 170M7082                 |
| 630 kW    | 170M7082                  | 2000 A, 700 V | 20 695 32.2000 | 170M7082                 |
| 710 kW    | 170M7082                  | 2000 A, 700 V | 20 695 32.2000 | 170M7082                 |

**Table 8.7 Enclosure size F, Mains Fuses, 380–480 V**

| Size/Type | Bussmann PN <sup>1)</sup> | Rating         | Siba           |
|-----------|---------------------------|----------------|----------------|
| 500 kW    | 170M8611                  | 1100 A, 1000 V | 20 781 32.1000 |
| 560 kW    | 170M8611                  | 1100 A, 1000 V | 20 781 32.1000 |
| 630 kW    | 170M6467                  | 1400 A, 700 V  | 20 681 32.1400 |
| 710 kW    | 170M6467                  | 1400 A, 700 V  | 20 681 32.1400 |

**Table 8.8 Enclosure Size F, Inverter Module DC-link Fuses, 380–480 V**

1) 170M fuses from Bussmann shown use the -/80 visual indicator, -TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted for external use.

## 8.4.3 Supplementary Fuses

### Supplementary fuses

| Enclosure size | Bussmann PN | Rating     |
|----------------|-------------|------------|
| D, E, and F    | KTK-4       | 4 A, 600 V |

**Table 8.9 SMPS Fuse**

| Size/Type                        | Bussmann PN | Littelfuse | Rating      |
|----------------------------------|-------------|------------|-------------|
| 355–710 kW, 380–480 V, 380–500 V |             | KLK-15     | 15 A, 600 V |

Table 8.10 Fan Fuses

| Size/Type             |           | Bussmann PN      | Rating      | Alternative fuses                                 |
|-----------------------|-----------|------------------|-------------|---|
| 500–710 kW, 380–480 V | 2.5–4.0 A | LPJ-6 SP or SPI  | 6 A, 600 V  | Any listed class J dual element, time delay, 6A   |
| 500–710 kW, 380–480 V | 4.0–6.3 A | LPJ-10 SP or SPI | 10 A, 600 V | Any listed class J dual element, time delay, 10 A |
| 500–710 kW, 380–480 V | 6.3–10 A  | LPJ-15 SP or SPI | 15 A, 600 V | Any listed class J dual element, time delay, 15 A |
| 500–710 kW, 380–480 V | 10–16 A   | LPJ-25 SP or SPI | 25 A, 600 V | Any listed class J dual element, time delay, 25 A |

Table 8.11 Manual Motor Controller Fuses

| Enclosure size | Bussmann PN <sup>1)</sup> | Rating      | Alternative fuses                                 |
|----------------|---------------------------|-------------|---|
| F              | LPJ-30 SP or SPI          | 30 A, 600 V | Any listed Class J dual element, time delay, 30 A |

Table 8.12 30 A Fuse Protected Terminal Fuse

| Enclosure size | Bussmann PN <sup>1)</sup> | Rating     | Alternative fuses                                |
|----------------|---------------------------|------------|--|
| F              | LPJ-6 SP or SPI           | 6 A, 600 V | Any listed class J dual element, time delay, 6 A |

Table 8.13 Control Transformer Fuse

| Enclosure size | Bussmann PN <sup>1)</sup> | Rating        |
|----------------|---------------------------|---------------|
| F              | GMC-800MA                 | 800 mA, 250 V |

Table 8.14 NAMUR Fuse

| Enclosure size | Bussmann PN <sup>1)</sup> | Rating     | Alternative fuses        |
|----------------|---------------------------|------------|--------------------------|
| F              | LP-CC-6                   | 6 A, 600 V | Any listed class CC, 6 A |

Table 8.15 Safety Relay Coil Fuse with PILS Relay

| Enclosure size | Littelfuse PN | Rating      |
|----------------|---------------|-------------|
| D, E, F        | KLK-15        | 15 A, 600 V |

Table 8.16 Mains Fuses (Power Card)

| Enclosure size | Bussmann PN | Rating     |
|----------------|-------------|------------|
| D, E, F        | FNQ-R-3     | 3 A, 600 V |

Table 8.17 Transformer Fuse (Mains Contactor)

| Enclosure size | Bussmann PN | Rating     |
|----------------|-------------|------------|
| D, E, F        | FNQ-R-1     | 1 A, 600 V |

Table 8.18 Soft Charge Fuses

1) 170M fuses from Bussmann shown use the -/80 visual indicator, -TN/80 Type T, -/110 or TN/110 Type T indicator fuses of the same size and amperage may be substituted for external use.

## 8.5 General Torque Tightening Values

For fastening hardware described in this manual, use the torque values in *Table 8.19*. These values are not intended for fastening IGBTs. See the instructions included with those replacement parts for correct values.

| Shaft size | Driver size torx/hex [mm] | Torque [Nm] | Torque [in-lbs] |
|------------|---------------------------|-------------|-----------------|
| M4         | T-20/7                    | 1.0         | 10              |
| M5         | T-25/8                    | 2.3         | 20              |
| M6         | T-30/10                   | 4.0         | 35              |
| M8         | T-40/13                   | 9.6         | 85              |
| M10        | T-50/17                   | 19.2        | 170             |
| M12        | 18/19                     | 19          | 170             |

Table 8.19 Torque Values

## 9 Appendix A - Parameters

### 9.1 Description of Parameters

#### 9.1.1 Main Menu

The main menu includes all available parameters in the frequency converter. All parameters are grouped by name indicating the function of the parameter group. All parameters are listed by name and number in this manual.

### 9.2 Frequency Converter Parameter Lists

| 0-0* | Operation/Display                    | 1-06 | 2-0* | Brakes                       | 4-5* | Adj. Warnings                        | 5-8* | I/O Options                          |
|------|--------------------------------------|------|------|------------------------------|------|--------------------------------------|------|--------------------------------------|
| 0-0* | Basic Settings                       | 1-06 | 2-0* | DC Brake                     | 4-50 | Warning Current Low                  | 5-80 | AHF Cap Reconnect Delay              |
| 0-01 | Language                             | 1-10 | 2-00 | DC Hold/Preheat Current      | 4-51 | Warning Current High                 | 5-9* | Bus Controlled                       |
| 0-02 | Motor Speed Unit                     | 1-11 | 2-01 | DC Brake Current             | 4-52 | Warning Speed Low                    | 5-90 | Digital & Relay Bus Control          |
| 0-03 | Regional Settings                    | 1-14 | 2-02 | DC Braking Time              | 4-53 | Warning Speed High                   | 5-93 | Pulse Out #27 Bus Control            |
| 0-04 | Operating State at Power-up          | 1-15 | 2-03 | DC Brake Cut In Speed [RPM]  | 4-54 | Warning Reference Low                | 5-94 | Pulse Out #27 Timeout Preset         |
| 0-05 | Local Mode Unit                      | 1-16 | 2-04 | DC Brake Cut In Speed [Hz]   | 4-55 | Warning Reference High               | 5-95 | Pulse Out #29 Bus Control            |
| 0-1* | Set-up Operations                    | 1-17 | 2-06 | Parking Current              | 4-56 | Warning Feedback Low                 | 5-96 | Pulse Out #29 Timeout Preset         |
| 0-10 | Active Set-up                        | 1-2* | 2-07 | Parking Time                 | 4-57 | Warning Feedback High                | 5-97 | Pulse Out #X30/6 Bus Control         |
| 0-11 | Programming Set-up                   | 1-20 | 2-1* | Brake Energy Funct.          | 4-58 | Missing Motor Phase Function         | 5-98 | Pulse Out #X30/6 Timeout Preset      |
| 0-12 | This Set-up Linked to                | 1-21 | 2-10 | Brake Function               | 4-6* | Speed Bypass                         | 6-0* | Analog In/Out                        |
| 0-13 | Readout: Linked Set-ups              | 1-22 | 2-11 | Brake Resistor (ohm)         | 4-60 | Bypass Speed From [RPM]              | 6-0* | Analog I/O Mode                      |
| 0-14 | Readout: Prog. Set-ups/Channel       | 1-23 | 2-12 | Brake Power Limit (kW)       | 4-61 | Bypass Speed From [Hz]               | 6-00 | Live Zero Timeout Time               |
| 0-2* | LCP Display                          | 1-24 | 2-13 | Brake Power Monitoring       | 4-62 | Bypass Speed To [RPM]                | 6-01 | Live Zero Timeout Function           |
| 0-20 | Display Line 1.1 Small               | 1-25 | 2-15 | Brake Check                  | 4-63 | Bypass Speed To [Hz]                 | 6-02 | Fire Mode Live Zero Timeout Function |
| 0-21 | Display Line 1.2 Small               | 1-26 | 2-16 | AC brake Max. Current        | 4-64 | Semi-Auto Bypass Set-up              | 6-1* | Analog Input 53                      |
| 0-22 | Display Line 1.3 Small               | 1-28 | 2-17 | Over-voltage Control         | 5-*  | Digital In/Out                       | 6-10 | Terminal 53 Low Voltage              |
| 0-23 | Display Line 2 Large                 | 1-29 | 3-*  | Reference/Ramps              | 5-0* | Digital I/O mode                     | 6-11 | Terminal 53 High Voltage             |
| 0-24 | Display Line 3 Large                 | 1-30 | 3-0* | Reference Limits             | 5-00 | Digital I/O mode                     | 6-12 | Terminal 53 Low Current              |
| 0-25 | My Personal Menu                     | 1-31 | 3-02 | Minimum Reference            | 5-01 | Terminal 27 Mode                     | 6-13 | Terminal 53 High Current             |
| 0-3* | LCP Custom Readout                   | 1-31 | 3-03 | Maximum Reference            | 5-02 | Terminal 29 Mode                     | 6-14 | Terminal 53 Low Ref./Feedb. Value    |
| 0-30 | Custom Readout Unit                  | 1-35 | 3-04 | Reference Function           | 5-1* | Digital Inputs                       | 6-15 | Terminal 53 High Ref./Feedb. Value   |
| 0-31 | Custom Readout Min Value             | 1-36 | 3-1* | References                   | 5-10 | Terminal 18 Digital Input            | 6-16 | Terminal 53 Filter Time Constant     |
| 0-32 | Custom Readout Max Value             | 1-37 | 3-10 | Preset Reference             | 5-11 | Terminal 19 Digital Input            | 6-17 | Terminal 53 Live Zero                |
| 0-33 | Display Text 1                       | 1-39 | 3-11 | Jog Speed [Hz]               | 5-12 | Terminal 27 Digital Input            | 6-2* | Analog Input 54                      |
| 0-38 | Display Text 2                       | 1-40 | 3-13 | Reference Site               | 5-13 | Terminal 29 Digital Input            | 6-20 | Terminal 54 Low Voltage              |
| 0-39 | Display Text 3                       | 1-46 | 3-14 | Preset Relative Reference    | 5-14 | Terminal 32 Digital Input            | 6-21 | Terminal 54 High Voltage             |
| 0-4* | LCP keypad                           | 1-5* | 3-15 | Reference 1 Source           | 5-15 | Terminal 33 Digital Input            | 6-22 | Terminal 54 Low Current              |
| 0-40 | [Hand On] Key on LCP                 | 1-50 | 3-16 | Reference 2 Source           | 5-16 | Terminal X30/2 Digital Input         | 6-23 | Terminal 54 High Current             |
| 0-41 | [Off] Key on LCP                     | 1-51 | 3-17 | Reference 3 Source           | 5-17 | Terminal X30/3 Digital Input         | 6-24 | Terminal 54 Low Ref./Feedb. Value    |
| 0-42 | [Auto On] Key on LCP                 | 1-52 | 3-18 | Reference 4 Source           | 5-18 | Terminal X30/4 Digital Input         | 6-25 | Terminal 54 High Ref./Feedb. Value   |
| 0-43 | [Reset] Key on LCP                   | 1-58 | 3-19 | Jog Speed [RPM]              | 5-19 | Terminal 37 Safe Stop                | 6-26 | Terminal 54 Filter Time Constant     |
| 0-44 | [Off/Reset] Key on LCP               | 1-59 | 3-4* | Ramp 1                       | 5-3* | Digital Outputs                      | 6-27 | Terminal 54 Live Zero                |
| 0-45 | [Drive Bypass] Key on LCP            | 1-60 | 3-41 | Ramp 1 Ramp Up Time          | 5-30 | Terminal 27 Digital Output           | 6-3* | Analog Input X30/11                  |
| 0-5* | Copy/Save                            | 1-6* | 3-42 | Ramp 1 Ramp Down Time        | 5-31 | Terminal 29 Digital Output           | 6-30 | Terminal X30/11 Low Voltage          |
| 0-50 | LCP Copy                             | 1-61 | 3-51 | Ramp 2 Ramp Up Time          | 5-32 | Term X30/6 Digi Out (MCB 101)        | 6-31 | Terminal X30/11 High Voltage         |
| 0-51 | Set-up Copy                          | 1-62 | 3-52 | Ramp 2 Ramp Down Time        | 5-33 | Term X30/7 Digi Out (MCB 101)        | 6-34 | Term. X30/11 Low Ref./Feedb. Value   |
| 0-6* | Password                             | 1-63 | 3-8* | Other Ramps                  | 5-4* | Relays                               | 6-35 | Term. X30/11 High Ref./Feedb. Value  |
| 0-60 | Main Menu Password                   | 1-64 | 3-80 | Jog Ramp Time                | 5-40 | Function Relay                       | 6-36 | Term. X30/11 Filter Time Constant    |
| 0-61 | Access to Main Menu w/o Password     | 1-65 | 3-81 | Quick Stop Ramp Time         | 5-41 | On Delay, Relay                      | 6-37 | Term. X30/11 Live Zero               |
| 0-65 | Personal Menu Password               | 1-66 | 3-82 | Starting Ramp Up Time        | 5-42 | Off Delay, Relay                     | 6-4* | Analog Input X30/12                  |
| 0-66 | Access to Personal Menu w/o Password | 1-7* | 3-9* | Digital Pot./Meter           | 5-5* | Pulse Input                          | 6-40 | Terminal X30/12 Low Voltage          |
| 0-67 | Bus Access Password                  | 1-70 | 3-90 | Step Size                    | 5-50 | Term. 29 Low Frequency               | 6-41 | Terminal X30/12 High Voltage         |
| 0-7* | Clock Settings                       | 1-71 | 3-91 | Ramp Time                    | 5-51 | Term. 29 High Frequency              | 6-44 | Term. X30/12 Low Ref./Feedb. Value   |
| 0-70 | Date and Time                        | 1-72 | 3-92 | Power Restore                | 5-52 | Term. 29 Low Ref./Feedb. Value       | 6-45 | Term. X30/12 High Ref./Feedb. Value  |
| 0-71 | Date Format                          | 1-73 | 3-93 | Maximum Limit                | 5-53 | Term. 29 High Ref./Feedb. Value      | 6-46 | Term. X30/12 Filter Time Constant    |
| 0-72 | Time Format                          | 1-77 | 3-94 | Minimum Limit                | 5-54 | Pulse Filter Time Constant #29       | 6-47 | Term. X30/12 Live Zero               |
| 0-74 | DST/Summertime                       | 1-78 | 3-95 | Ramp Delay                   | 5-55 | Term. 33 Low Frequency               | 6-5* | Analog Output 42                     |
| 0-76 | DST/Summertime Start                 | 1-79 | 4-*  | Limits/Warnings              | 5-56 | Term. 33 High Frequency              | 6-50 | Terminal 42 Output                   |
| 0-77 | DST/Summertime End                   | 1-80 | 4-1* | Motor Limits                 | 5-57 | Term. 33 Low Ref./Feedb. Value       | 6-51 | Terminal 42 Output Min Scale         |
| 0-79 | Clock Fault                          | 1-81 | 4-10 | Motor Speed Direction        | 5-58 | Term. 33 High Ref./Feedb. Value      | 6-52 | Terminal 42 Output Max Scale         |
| 0-81 | Working Days                         | 1-81 | 4-11 | Motor Speed Low Limit [RPM]  | 5-59 | Pulse Filter Time Constant #33       | 6-53 | Terminal 42 Output Bus Control       |
| 0-82 | Additional Working Days              | 1-82 | 4-12 | Motor Speed Low Limit [Hz]   | 5-6* | Pulse Output                         | 6-54 | Terminal 42 Output Timeout Preset    |
| 0-83 | Additional Non-Working Days          | 1-86 | 4-13 | Motor Speed High Limit [RPM] | 5-60 | Terminal 27 Pulse Output Variable    | 6-55 | Analog Output Filter                 |
| 0-89 | Date and Time Readout                | 1-87 | 4-14 | Motor Speed High Limit [Hz]  | 5-62 | Pulse Output Max Freq #27            | 6-6* | Analog Output X30/8                  |
| 1-*  | Load and Motor                       | 1-9* | 4-16 | Torque Limit Motor Mode      | 5-63 | Terminal 29 Pulse Output Variable    | 6-60 | Terminal X30/8 Output                |
| 1-0* | General Settings                     | 1-90 | 4-17 | Torque Limit Generator Mode  | 5-65 | Pulse Output Max Freq #29            | 6-61 | Terminal X30/8 Min. Scale            |
| 1-00 | Configuration Mode                   | 1-91 | 4-18 | Current Limit                | 5-66 | Terminal X30/6 Pulse Output Variable | 6-62 | Terminal X30/8 Max. Scale            |
| 1-03 | Torque Characteristics               | 1-93 | 4-19 | Max Output Frequency         | 5-68 | Pulse Output Max Freq #X30/6         | 6-63 | Terminal X30/8 Output Bus Control    |

|      |                                      |       |                           |       |                                 |       |                                     |       |                                   |
|------|--------------------------------------|-------|---------------------------|-------|---------------------------------|-------|-------------------------------------|-------|-----------------------------------|
| 6-64 | Terminal X30/8 Output Timeout Preset | 9-16  | PCD Read Configuration    | 12-20 | Control Instance                | 14-03 | Overmodulation                      | 15-3* | Alarm Log                         |
| 8-8* | Comm. and Options                    | 9-18  | Node Address              | 12-21 | Process Data Config Write       | 14-04 | PWM Random                          | 15-30 | Alarm Log: Error Code             |
| 8-0* | General Settings                     | 9-22  | Telegram Selection        | 12-22 | Process Data Config Read        | 14-1* | Mains On/Off                        | 15-31 | Alarm Log: Value                  |
| 8-01 | Control Site                         | 9-23  | Parameters for Signals    | 12-27 | Primary Master                  | 14-10 | Mains Failure                       | 15-32 | Alarm Log: Time                   |
| 8-02 | Control Source                       | 9-27  | Parameter Edit            | 12-28 | Store Data Values               | 14-11 | Mains Voltage at Mains Fault        | 15-33 | Alarm Log: Date and Time          |
| 8-03 | Control Timeout Time                 | 9-28  | Process Control           | 12-29 | Store Always                    | 14-12 | Function at Mains Imbalance         | 15-4* | Drive Identification              |
| 8-04 | Control Timeout Function             | 9-44  | Fault Message Counter     | 12-3* | Ethernet/IP                     | 14-2* | Reset Functions                     | 15-40 | FC Type                           |
| 8-05 | End-of-Timeout Function              | 9-45  | Fault Code                | 12-30 | Warning Parameter               | 14-20 | Reset Mode                          | 15-41 | Power Section                     |
| 8-06 | Reset Control Timeout                | 9-47  | Fault Number              | 12-31 | Net Reference                   | 14-21 | Automatic Restart Time              | 15-42 | Voltage                           |
| 8-07 | Diagnosis Trigger                    | 9-52  | Fault Situation Counter   | 12-32 | Net Control                     | 14-22 | Operation Mode                      | 15-43 | Software Version                  |
| 8-08 | Readout Filtering                    | 9-53  | Profibus Warning Word     | 12-33 | CIP Revision                    | 14-23 | Typecode Setting                    | 15-44 | Ordered Typecode String           |
| 8-09 | Communication Charset                | 9-63  | Actual Baud Rate          | 12-34 | CIP Product Code                | 14-25 | Trip Delay at Torque Limit          | 15-45 | Actual Typecode String            |
| 8-1* | Control Settings                     | 9-64  | Device Identification     | 12-35 | EDS Parameter                   | 14-26 | Trip Delay at Inverter Fault        | 15-46 | Frequency Converter Ordering No   |
| 8-10 | Control Profile                      | 9-65  | Profile Number            | 12-37 | COS Inhibit Timer               | 14-28 | Production Settings                 | 15-47 | Power Card Ordering No            |
| 8-13 | Configurable Status Word STW         | 9-67  | Control Word 1            | 12-38 | COS Filter                      | 14-29 | Service Code                        | 15-48 | LCP D No                          |
| 8-3* | FC Port Settings                     | 9-68  | Status Word 1             | 12-4* | Modbus TCP                      | 14-3* | Current Limit Ctrl.                 | 15-49 | SW ID Control Card                |
| 8-30 | Protocol                             | 9-71  | Profibus Save Data Values | 12-40 | Status Parameter                | 14-30 | Current Lim Ctrl, Proportional Gain | 15-50 | SW ID Power Card                  |
| 8-31 | Address                              | 9-72  | ProfibusDriveReset        | 12-41 | Slave Message Count             | 14-31 | Current Lim Ctrl, Integration Time  | 15-51 | Frequency Converter Serial Number |
| 8-32 | Baud Rate                            | 9-75  | DO Identification         | 12-42 | Slave Exception Message Count   | 14-32 | Current Lim Ctrl, Filter Time       | 15-53 | Power Card Serial Number          |
| 8-33 | Parity/Stop Bits                     | 9-80  | Defined Parameters (1)    | 12-8* | Other Ethernet Services         | 14-4* | Energy Optimising                   | 15-55 | Vendor URL                        |
| 8-34 | Estimated cycle time                 | 9-81  | Defined Parameters (2)    | 12-80 | FTP Server                      | 14-40 | VT Level                            | 15-56 | Vendor Name                       |
| 8-35 | Minimum Response Delay               | 9-82  | Defined Parameters (3)    | 12-81 | HTTP Server                     | 14-41 | AEQ Minimum Magnetisation           | 15-59 | CSV Filename                      |
| 8-36 | Maximum Response Delay               | 9-83  | Defined Parameters (4)    | 12-82 | SMTP Service                    | 14-42 | Minimum AEO Frequency               | 15-6* | Option Ident                      |
| 8-37 | Maximum Inter-Char Delay             | 9-84  | Defined Parameters (5)    | 12-89 | Transparent Socket Channel Port | 14-43 | Motor Cosphi                        | 15-60 | Option Mounted                    |
| 8-4* | FC MC protocol set                   | 9-90  | Changed Parameters (1)    | 12-9* | Advanced Ethernet Services      | 14-5* | Environment                         | 15-61 | Option SW Version                 |
| 8-40 | Telegram Selection                   | 9-91  | Changed Parameters (2)    | 12-90 | Cable Diagnostics               | 14-50 | RFI Filter                          | 15-62 | Option Ordering No                |
| 8-42 | PCD Write Configuration              | 9-92  | Changed Parameters (3)    | 12-91 | Auto Crossover                  | 14-51 | DC Link Compensation                | 15-63 | Option Serial No                  |
| 8-43 | PCD Read Configuration               | 9-93  | Changed Parameters (4)    | 12-92 | IGMP Snooping                   | 14-52 | Fan Control                         | 15-70 | Option in Slot A                  |
| 8-5* | Digital/Bus                          | 9-94  | Changed Parameters (5)    | 12-93 | Cable Error Length              | 14-53 | Fan Monitor                         | 15-71 | Slot A Option SW Version          |
| 8-50 | Coasting Select                      | 9-99  | Profibus Revision Counter | 12-94 | Broadcast Storm Protection      | 14-55 | Output Filter                       | 15-72 | Option in Slot B                  |
| 8-52 | DC Brake Select                      | 11-*  | LonWorks                  | 12-95 | Broadcast Storm Filter          | 14-59 | Actual Number of Inverter Units     | 15-73 | Slot B Option SW Version          |
| 8-53 | Start Select                         | 11-0* | LonWorks ID               | 12-96 | Port Config                     | 14-6* | Auto Derate                         | 15-8* | Operating Data II                 |
| 8-54 | Reversing Select                     | 11-00 | Neuron ID                 | 12-98 | Interface Counters              | 14-60 | Function at Overtemperature         | 15-80 | Fan Running Hours                 |
| 8-55 | Set-up Select                        | 11-1* | Lon Functions             | 12-99 | Media Counters                  | 14-61 | Function at Inverter Overload       | 15-81 | Preset Fan Running Hours          |
| 8-56 | Preset Reference Select              | 11-10 | Drive Profile             | 13-3* | Smart Logic                     | 14-62 | Inv. Overload Derate Current        | 15-9* | Parameter Info                    |
| 8-7* | BACnet                               | 11-15 | Lon Warning Word          | 13-0* | SLC Settings                    | 14-9* | Fault Settings                      | 15-92 | Defined Parameters                |
| 8-70 | BACnet Device Instance               | 11-17 | XIF Revision              | 13-00 | SL Controller Mode              | 14-90 | Fault Level                         | 15-93 | Modified Parameters               |
| 8-72 | MS/TP Max Masters                    | 11-18 | LonWorks Revision         | 13-01 | Start Event                     | 15-*  | Drive Information                   | 15-98 | Drive Identification              |
| 8-73 | MS/TP Max Info Frames                | 11-2* | Lon Param. Access         | 13-02 | Stop Event                      | 15-0* | Operating Data                      | 15-99 | Parameter Metadata                |
| 8-74 | "I-Am" Service                       | 11-21 | Store Data Values         | 13-03 | Reset SLC                       | 15-00 | Operating Hours                     | 16-*  | Data Readouts                     |
| 8-75 | Initialisation Password              | 12-2* | Ethernet                  | 13-1* | Comparators                     | 15-01 | Running Hours                       | 16-0* | General Status                    |
| 8-8* | FC Port Diagnostics                  | 12-0* | IP Settings               | 13-10 | Comparator Operand              | 15-02 | kWh Counter                         | 16-00 | Control Word                      |
| 8-80 | Bus Message Count                    | 12-00 | IP Address Assignment     | 13-11 | Comparator Operator             | 15-03 | Power Up's                          | 16-01 | Reference [Unit]                  |
| 8-81 | Bus Error Count                      | 12-01 | IP Address                | 13-12 | Comparator Value                | 15-04 | Over Temp's                         | 16-02 | Reference [%]                     |
| 8-82 | Slave Messages Rcvd                  | 12-02 | Subnet Mask               | 13-2* | Timers                          | 15-05 | Over Volts                          | 16-03 | Status Word                       |
| 8-83 | Slave Error Count                    | 12-03 | Default Gateway           | 13-20 | SL Controller Timer             | 15-06 | Reset kWh Counter                   | 16-05 | Main Actual Value [%]             |
| 8-84 | Slave Messages Sent                  | 12-04 | DHCP Server               | 13-4* | Logic Rules                     | 15-07 | Reset Running Hours Counter         | 16-09 | Custom Readout                    |
| 8-85 | Slave Timeout Errors                 | 12-05 | Lease Expires             | 13-40 | Logic Rule Boolean 1            | 15-08 | Number of Starts                    | 16-1* | Motor Status                      |
| 8-89 | Diagnostics Count                    | 12-06 | Name Servers              | 13-41 | Logic Rule Operator 1           | 15-1* | Data Log Settings                   | 16-10 | Power [kW]                        |
| 8-9* | Bus Jog/Feedback                     | 12-07 | Domain Name               | 13-42 | Logic Rule Boolean 2            | 15-10 | Logging Source                      | 16-11 | Power [hp]                        |
| 8-90 | Bus Jog 1 Speed                      | 12-08 | Host Name                 | 13-43 | Logic Rule Operator 2           | 15-11 | Logging Interval                    | 16-12 | Motor Voltage                     |
| 8-91 | Bus Jog 2 Speed                      | 12-09 | Physical Address          | 13-44 | Logic Rule Boolean 3            | 15-12 | Trigger Event                       | 16-13 | Frequency                         |
| 8-94 | Bus Feedback 1                       | 12-1* | Ethernet Link Parameters  | 13-5* | States                          | 15-13 | Logging Mode                        | 16-14 | Motor current                     |
| 8-95 | Bus Feedback 2                       | 12-10 | Link Status               | 13-51 | SL Controller Event             | 15-14 | Samples Before Trigger              | 16-15 | Frequency [%]                     |
| 8-96 | Bus Feedback 3                       | 12-11 | Link Duration             | 13-52 | SL Controller Action            | 15-2* | Historic Log                        | 16-16 | Torque [Nm]                       |
| 9-3* | Profibus                             | 12-12 | Auto Negotiation          | 14-*  | Special Functions               | 15-20 | Historic Log: Event                 | 16-17 | Speed [RPM]                       |
| 9-00 | Setpoint                             | 12-13 | Link Speed                | 14-0* | Inverter Switching              | 15-21 | Historic Log: Value                 | 16-18 | Motor Thermal                     |
| 9-07 | Actual Value                         | 12-14 | Link Duplex               | 14-00 | Switching Pattern               | 15-22 | Historic Log: Time                  | 16-20 | Motor Angle                       |
| 9-15 | PCD Write Configuration              | 12-2* | Process Data              | 14-01 | Switching Frequency             | 15-23 | Historic log: Date and Time         | 16-22 | Torque [%]                        |



|       |                            |       |                              |       |                               |       |                                   |       |                            |
|-------|----------------------------|-------|------------------------------|-------|-------------------------------|-------|-----------------------------------|-------|----------------------------|
| 16-26 | Power Filtered [kW]        | 18-01 | Maintenance Log: Action      | 20-8* | PID Basic Settings            | 21-58 | Ext. 3 Feedback [Unit]            | 22-86 | Speed at Design Point [Hz] |
| 16-27 | Power Filtered [hp]        | 18-02 | Maintenance Log: Time        | 20-81 | PID Normal/Inverse Control    | 21-59 | Ext. 3 Output [%]                 | 22-87 | Pressure at No-Flow Speed  |
| 16-30 | DC Link Voltage            | 18-1* | Fire Mode Log                | 20-82 | PID Start Speed [RPM]         | 21-6* | Ext. CL 3 PID                     | 22-88 | Pressure at Rated Speed    |
| 16-32 | Brake Energy /s            | 18-10 | Fire Mode Log: Event         | 20-83 | PID Start Speed [Hz]          | 21-60 | Ext. 3 Normal/Inverse Control     | 22-89 | Flow at Design Point       |
| 16-33 | Brake Energy /2 min        | 18-11 | Fire Mode Log: Time          | 20-84 | On Reference Bandwidth        | 21-61 | Ext. 3 Proportional Gain          | 22-90 | Flow at Rated Speed        |
| 16-34 | Heatsink Temp.             | 18-12 | Fire Mode Log: Date and Time | 20-9* | PID Controller                | 21-62 | Ext. 3 Integral Time              | 23-3* | Time-based Functions       |
| 16-35 | Inverter Thermal           | 18-3* | Inputs & Outputs             | 20-91 | PID Anti Windup               | 21-63 | Ext. 3 Differentiation Time       | 23-0* | Timed Actions              |
| 16-36 | Inv. Nom. Current          | 18-30 | Analog Input X42/1           | 20-93 | PID Proportional Gain         | 21-64 | Ext. 3 Diff. Gain Limit           | 23-00 | ON Time                    |
| 16-37 | Inv. Max. Current          | 18-31 | Analog Input X42/3           | 20-94 | PID Integral Time             | 22-*  | Appl. Functions                   | 23-01 | ON Action                  |
| 16-38 | SL Controller State        | 18-32 | Analog Input X42/5           | 20-95 | PID Differentiation Time      | 22-0* | Miscellaneous                     | 23-02 | OFF Time                   |
| 16-39 | Control Card Temp.         | 18-33 | Analog Out X42/7 [V]         | 20-96 | PID Diff. Gain Limit          | 22-00 | External Interlock Delay          | 23-03 | OFF Action                 |
| 16-40 | Logging Buffer Full        | 18-34 | Analog Out X42/9 [V]         | 21-*  | Ext. Closed Loop              | 22-01 | Power Filter Time                 | 23-04 | Occurrence                 |
| 16-41 | Logging Buffer Full        | 18-35 | Analog Out X42/11 [V]        | 21-0* | Ext. CL Autotuning            | 22-2* | No-Flow Detection                 | 23-0* | Timed Actions Settings     |
| 16-43 | Timed Actions Status       | 18-36 | Analog Input X48/2 [mA]      | 21-00 | Closed Loop Type              | 22-20 | Low Power Auto Set-up             | 23-08 | Timed Actions Mode         |
| 16-49 | Current Fault Source       | 18-37 | Temp. Input X48/4            | 21-01 | PID Performance               | 22-21 | Low Power Detection               | 23-09 | Timed Actions Reactivation |
| 16-50 | External Reference         | 18-38 | Temp. Input X48/10           | 21-02 | PID Output Change             | 22-22 | Low Speed Detection               | 23-1* | Maintenance                |
| 16-52 | Feedback [Unit]            | 18-39 | Ref. & Feeds.                | 21-03 | Minimum Feedback Level        | 22-23 | No-Flow Function                  | 23-10 | Maintenance Item           |
| 16-53 | Digi Pot Reference         | 18-5* | Sensorless Readout [unit]    | 21-04 | Maximum Feedback Level        | 22-24 | No-Flow Delay                     | 23-11 | Maintenance Action         |
| 16-54 | Feedback 1 [Unit]          | 20-*  | Drive Closed Loop            | 21-09 | PID Autotuning                | 22-26 | Dry Pump Function                 | 23-12 | Maintenance Time Base      |
| 16-55 | Feedback 2 [Unit]          | 20-0  | Feedback 1 Source            | 21-1* | Ext. CL 1 Ref/Fb.             | 22-27 | Dry Pump Delay                    | 23-13 | Maintenance Time Interval  |
| 16-56 | Feedback 3 [Unit]          | 20-00 | Feedback 1 Conversion        | 21-10 | Ext. 1 Ref/Feedback Unit      | 22-3* | No-Flow Power Tuning              | 23-14 | Maintenance Date and Time  |
| 16-58 | PID Output [%]             | 20-01 | Feedback 2 Source Unit       | 21-11 | Ext. 1 Minimum Reference      | 22-30 | No-Flow Power                     | 23-1* | Maintenance Reset          |
| 16-60 | Digital Input              | 20-02 | Feedback 2 Source            | 21-12 | Ext. 1 Maximum Reference      | 22-31 | Power Correction Factor           | 23-15 | Reset Maintenance Word     |
| 16-61 | Terminal 53 Switch Setting | 20-03 | Feedback 3 Source Unit       | 21-13 | Ext. 1 Reference Source       | 22-32 | Low Speed [RPM]                   | 23-16 | Maintenance Text           |
| 16-62 | Analog Input 53            | 20-04 | Feedback 2 Conversion        | 21-14 | Ext. 1 Feedback Source        | 22-33 | Low Speed [Hz]                    | 23-5* | Energy Log                 |
| 16-63 | Terminal 54 Switch Setting | 20-05 | Feedback 3 Conversion        | 21-15 | Ext. 1 Setpoint               | 22-34 | Low Speed Power [kW]              | 23-50 | Energy Log Resolution      |
| 16-64 | Analog Input 54            | 20-06 | Feedback 3 Source Unit       | 21-17 | Ext. 1 Reference [Unit]       | 22-35 | Low Speed Power [hp]              | 23-51 | Period Start               |
| 16-65 | Analog Output 42 [mA]      | 20-07 | Feedback 3 Source Unit       | 21-18 | Ext. 1 Feedback [Unit]        | 22-36 | High Speed [RPM]                  | 23-53 | Energy Log                 |
| 16-66 | Digital Output [bin]       | 20-08 | Reference/Feedback Unit      | 21-19 | Ext. 1 Output [%]             | 22-37 | High Speed [Hz]                   | 23-54 | Reset Energy Log           |
| 16-67 | Pulse Input #29 [Hz]       | 20-09 | Feedback 3 Conversion        | 21-2* | Ext. CL 1 PID                 | 22-38 | High Speed Power [kW]             | 23-6* | Trending                   |
| 16-68 | Pulse Input #33 [Hz]       | 20-10 | Feedback 3 Source Unit       | 21-20 | Ext. 1 Normal/Inverse Control | 22-39 | High Speed Power [hp]             | 23-60 | Trend Variable             |
| 16-69 | Pulse Output #27 [Hz]      | 20-11 | Reference/Feedback Unit      | 21-21 | Ext. 1 Proportional Gain      | 22-4* | Sleep Mode                        | 23-61 | Continuous Bin Data        |
| 16-70 | Pulse Output #29 [Hz]      | 20-12 | Minimum Reference/Feedb.     | 21-22 | Ext. 1 Integral Time          | 22-40 | Minimum Run Time                  | 23-62 | Timed Bin Data             |
| 16-71 | Relay Output [bin]         | 20-13 | Maximum Reference/Feedb.     | 21-23 | Ext. 1 Differentiation Time   | 22-41 | Minimum Sleep Time                | 23-63 | Timed Period Start         |
| 16-72 | Counter A                  | 20-14 | Feedback/Feedpoint           | 21-24 | Ext. 1 Dif. Gain Limit        | 22-42 | Wake-up Speed [RPM]               | 23-64 | Timed Period Stop          |
| 16-73 | Counter B                  | 20-20 | Feedback Function            | 21-3* | Ext. CL 2 Ref/Fb.             | 22-43 | Wake-up Speed [Hz]                | 23-65 | Minimum Bin Value          |
| 16-75 | Analog In X30/11           | 20-21 | Setpoint 1                   | 21-30 | Ext. 2 Ref/Feedback Unit      | 22-44 | Wake-up Ref/FB Difference         | 23-66 | Reset Continuous Bin Data  |
| 16-76 | Analog In X30/12           | 20-22 | Setpoint 2                   | 21-31 | Ext. 2 Minimum Reference      | 22-45 | Setpoint Boost                    | 23-67 | Reset Timed Bin Data       |
| 16-77 | Analog Out X30/8 [mA]      | 20-23 | Setpoint 3                   | 21-32 | Ext. 2 Maximum Reference      | 22-46 | Maximum Boost Time                | 23-8* | Payback Counter            |
| 16-8* | Fieldbus & FC Port         | 20-3* | Feeds. Adv. Conv.            | 21-33 | Ext. 2 Reference Source       | 22-5* | End of Curve                      | 23-80 | Power Reference Factor     |
| 16-80 | Fieldbus CTW 1             | 20-30 | Refrigerant                  | 21-34 | Ext. 2 Feedback Source        | 22-50 | End of Curve Function             | 23-81 | Energy Cost                |
| 16-82 | Fieldbus REF 1             | 20-31 | User-defined Refrigerant A1  | 21-35 | Ext. 2 Setpoint               | 22-51 | End of Curve Delay                | 23-82 | Investment                 |
| 16-84 | Comm. Option STW           | 20-32 | User-defined Refrigerant A2  | 21-37 | Ext. 2 Reference [Unit]       | 22-6* | Broken Belt Detection             | 23-83 | Energy Savings             |
| 16-85 | FC Port CTW 1              | 20-33 | User-defined Refrigerant A3  | 21-38 | Ext. 2 Feedback [Unit]        | 22-60 | Broken Belt Function              | 23-84 | Cost Savings               |
| 16-86 | FC Port REF 1              | 20-34 | Duct 1 Area [m2]             | 21-39 | Ext. 2 Output [%]             | 22-61 | Broken Belt Torque                | 24-*  | Appl. Functions 2          |
| 16-9* | Diagnosis Readouts         | 20-35 | Duct 1 Area [in2]            | 21-4* | Ext. CL 2 PID                 | 22-62 | Broken Belt Delay                 | 24-0* | Fire Mode                  |
| 16-90 | Alarm Word                 | 20-36 | Duct 2 Area [m2]             | 21-40 | Ext. 2 Normal/Inverse Control | 22-7* | Short Cycle Protection            | 24-00 | Fire Mode Function         |
| 16-91 | Alarm Word 2               | 20-37 | Duct 2 Area [in2]            | 21-41 | Ext. 2 Proportional Gain      | 22-75 | Short Cycle Protection            | 24-01 | Fire Mode Configuration    |
| 16-92 | Warning Word               | 20-38 | Air Density Factor [%]       | 21-42 | Ext. 2 Integral Time          | 22-76 | Interval between Starts           | 24-02 | Fire Mode Unit             |
| 16-93 | Warning Word 2             | 20-6* | Sensorless                   | 21-43 | Ext. 2 Differentiation Time   | 22-77 | Minimum Run Time                  | 24-03 | Fire Mode Min Reference    |
| 16-94 | Ext. Status Word           | 20-60 | Sensorless Unit              | 21-44 | Ext. 2 Dif. Gain Limit        | 22-78 | Minimum Run Time Override         | 24-04 | Fire Mode Max Reference    |
| 16-95 | Ext. Status Word 2         | 20-69 | Sensorless Information       | 21-45 | Ext. 2 Ref/Fb.                | 22-79 | Minimum Run Time Override Value   | 24-05 | Fire Mode Preset Reference |
| 16-96 | Maintenance Word           | 20-7* | PID Autotuning               | 21-50 | Ext. 3 Ref/Feedback Unit      | 22-8* | Flow Compensation                 | 24-06 | Fire Mode Reference Source |
| 18-0* | Maintenance Log            | 20-70 | Closed Loop Type             | 21-51 | Ext. 3 Minimum Reference      | 22-80 | Flow Compensation                 | 24-07 | Fire Mode Feedback Source  |
|       |                            | 20-71 | PID Performance              | 21-52 | Ext. 3 Maximum Reference      | 22-81 | Square-linear Curve Approximation | 24-09 | Fire Mode Alarm Handling   |
|       |                            | 20-72 | PID Output Change            | 21-53 | Ext. 3 Reference Source       | 22-82 | Work Point Calculation            | 24-1* | Drive Bypass               |
|       |                            | 20-73 | Minimum Feedback Level       | 21-54 | Ext. 3 Feedback Source        | 22-83 | Speed at No-Flow [RPM]            | 24-10 | Drive Bypass Function      |
|       |                            | 20-74 | Maximum Feedback Level       | 21-55 | Ext. 3 Setpoint               | 22-84 | Speed at Design Point [Hz]        | 24-11 | Drive Bypass Delay Time    |
| 18-00 | Maintenance Log: Item      | 20-79 | PID Autotuning               | 21-57 | Ext. 3 Reference [Unit]       | 22-85 | Speed at Design Point [RPM]       |       |                            |

|       |                             |       |                                    |       |                                    |
|-------|-----------------------------|-------|------------------------------------|-------|------------------------------------|
| 24-9* | Multi-Motor Funct.          | 25-91 | Manual Alternation                 | 35-00 | Term. X48/4 Temperature Unit       |
| 24-90 | Missing Motor Function      | 26-*  | Analog I/O Option                  | 35-01 | Term. X48/4 Input Type             |
| 24-91 | Missing Motor Coefficient 1 | 26-0* | Analog I/O Mode                    | 35-02 | Term. X48/7 Temperature Unit       |
| 24-92 | Missing Motor Coefficient 2 | 26-00 | Terminal X42/1 Mode                | 35-03 | Term. X48/7 Input Type             |
| 24-93 | Missing Motor Coefficient 3 | 26-01 | Terminal X42/3 Mode                | 35-04 | Term. X48/10 Temperature Unit      |
| 24-94 | Missing Motor Coefficient 4 | 26-02 | Terminal X42/5 Mode                | 35-05 | Term. X48/10 Input Type            |
| 24-95 | Locked Rotor Function       | 26-1* | Analog Input X42/1                 | 35-06 | Temperature Sensor Alarm Function  |
| 24-96 | Locked Rotor Coefficient 1  | 26-10 | Terminal X42/1 Low Voltage         | 35-1* | Temp. Input X48/4                  |
| 24-97 | Locked Rotor Coefficient 2  | 26-11 | Terminal X42/1 High Voltage        | 35-14 | Term. X48/4 Filter Time Constant   |
| 24-98 | Locked Rotor Coefficient 3  | 26-14 | Term. X42/1 Low Ref./Feedb. Value  | 35-15 | Term. X48/4 Temp. Monitor          |
| 24-99 | Locked Rotor Coefficient 4  | 26-15 | Term. X42/1 High Ref./Feedb. Value | 35-16 | Term. X48/4 Low Temp. Limit        |
| 25-*  | Cascade Controller          | 26-16 | Term. X42/1 Filter Time Constant   | 35-17 | Term. X48/4 High Temp. Limit       |
| 25-0* | System Settings             | 26-17 | Term. X42/1 Live Zero              | 35-2* | Temp. Input X48/7                  |
| 25-00 | Cascade Controller          | 26-2* | Analog Input X42/3                 | 35-24 | Term. X48/7 Filter Time Constant   |
| 25-02 | Motor Start                 | 26-20 | Terminal X42/3 Low Voltage         | 35-25 | Term. X48/7 Temp. Monitor          |
| 25-04 | Pump Cycling                | 26-21 | Terminal X42/3 High Voltage        | 35-26 | Term. X48/7 Low Temp. Limit        |
| 25-05 | Fixed Lead Pump             | 26-24 | Term. X42/3 Low Ref./Feedb. Value  | 35-27 | Term. X48/7 High Temp. Limit       |
| 25-06 | Number of Pumps             | 26-25 | Term. X42/3 High Ref./Feedb. Value | 35-3* | Temp. Input X48/10                 |
| 25-2* | Bandwidth Settings          | 26-26 | Term. X42/3 Filter Time Constant   | 35-34 | Term. X48/10 Filter Time Constant  |
| 25-20 | Staging Bandwidth           | 26-27 | Term. X42/3 Live Zero              | 35-35 | Term. X48/10 Temp. Monitor         |
| 25-21 | Override Bandwidth          | 26-3* | Analog Input X42/5                 | 35-36 | Term. X48/10 Low Temp. Limit       |
| 25-22 | Fixed Speed Bandwidth       | 26-30 | Terminal X42/5 Low Voltage         | 35-37 | Term. X48/10 High Temp. Limit      |
| 25-23 | SBW Staging Delay           | 26-31 | Terminal X42/5 High Voltage        | 35-4* | Analog Input X48/2                 |
| 25-24 | SBW Destaging Delay         | 26-34 | Term. X42/5 Low Ref./Feedb. Value  | 35-42 | Term. X48/2 Low Current            |
| 25-25 | OBW Time                    | 26-35 | Term. X42/5 High Ref./Feedb. Value | 35-43 | Term. X48/2 High Current           |
| 25-26 | Destage at No-Flow          | 26-36 | Term. X42/5 Filter Time Constant   | 35-44 | Term. X48/2 Low Ref./Feedb. Value  |
| 25-27 | Stage Function              | 26-37 | Term. X42/5 Live Zero              | 35-45 | Term. X48/2 High Ref./Feedb. Value |
| 25-28 | Stage Function Time         | 26-4* | Analog Out X42/7                   | 35-46 | Term. X48/2 Filter Time Constant   |
| 25-29 | Stage Function              | 26-40 | Terminal X42/7 Output              | 35-47 | Term. X48/2 Live Zero              |
| 25-30 | Destage Function Time       | 26-41 | Terminal X42/7 Min. Scale          |       |                                    |
| 25-4* | Staging Settings            | 26-42 | Terminal X42/7 Max. Scale          |       |                                    |
| 25-40 | Ramp Down Delay             | 26-43 | Terminal X42/7 Bus Control         |       |                                    |
| 25-41 | Ramp Up Delay               | 26-44 | Terminal X42/7 Timeout Preset      |       |                                    |
| 25-42 | Staging Threshold           | 26-5* | Analog Out X42/9                   |       |                                    |
| 25-43 | Destaging Threshold         | 26-50 | Terminal X42/9 Output              |       |                                    |
| 25-44 | Staging Speed [RPM]         | 26-51 | Terminal X42/9 Min. Scale          |       |                                    |
| 25-45 | Staging Speed [Hz]          | 26-52 | Terminal X42/9 Max. Scale          |       |                                    |
| 25-46 | Destaging Speed [RPM]       | 26-53 | Terminal X42/9 Bus Control         |       |                                    |
| 25-47 | Destaging Speed [Hz]        | 26-54 | Terminal X42/9 Timeout Preset      |       |                                    |
| 25-5* | Alternation Settings        | 26-6* | Analog Out X42/11                  |       |                                    |
| 25-50 | Lead Pump Alternation       | 26-60 | Terminal X42/11 Output             |       |                                    |
| 25-51 | Alternation Event           | 26-61 | Terminal X42/11 Min. Scale         |       |                                    |
| 25-52 | Alternation Time Interval   | 26-62 | Terminal X42/11 Max. Scale         |       |                                    |
| 25-53 | Alternation Timer Value     | 26-63 | Terminal X42/11 Bus Control        |       |                                    |
| 25-54 | Alternation Predefined Time | 26-64 | Terminal X42/11 Timeout Preset     |       |                                    |
| 25-55 | Alternate if Load < 50%     | 30-*  | Special Features                   |       |                                    |
| 25-56 | Staging Mode at Alternation | 30-2* | Adv. Start Adjust                  |       |                                    |
| 25-58 | Run Next Pump Delay         | 30-22 | Locked Rotor Detection             |       |                                    |
| 25-59 | Run on Mains Delay          | 30-23 | Locked Rotor Detection Time [s]    |       |                                    |
| 25-8* | Status                      | 31-*  | Bypass Option                      |       |                                    |
| 25-80 | Cascade Status              | 31-00 | Bypass Mode                        |       |                                    |
| 25-81 | Pump Status                 | 31-01 | Bypass Start Time Delay            |       |                                    |
| 25-82 | Lead Pump                   | 31-02 | Bypass Trip Time Delay             |       |                                    |
| 25-83 | Relay Status                | 31-03 | Test Mode Activation               |       |                                    |
| 25-84 | Pump ON Time                | 31-10 | Bypass Status Word                 |       |                                    |
| 25-85 | Relay ON Time               | 31-11 | Bypass Running Hours               |       |                                    |
| 25-86 | Reset Relay Counters        | 31-19 | Remote Bypass Activation           |       |                                    |
| 25-9* | Service                     | 35-*  | Sensor Input Option                |       |                                    |
| 25-90 | Pump Interlock              | 35-0* | Temp. Input Mode                   |       |                                    |

## 9.3 Active Filter Parameter Lists

### 9.3.1 Default Settings

#### Changes during operation:

*True* means that the parameter can be changed while the active filter is in operation, and *False* means that the unit must be stopped before a change can be made.

#### 4-Set-up:

*All set-up:* The parameter can be set individually in each of the 4 set-ups, (1 single parameter can have 4 different data values).

*1 set-up:* Data value is the same in all set-ups.

#### SR:

Size-related.

#### N/A:

No default value available.

#### Conversion index:

This number refers to a conversion figure used when writing or reading with an active filter.

| Conv. index  | 100 | 75      | 74   | 70 | 67   | 6       | 5      | 4     | 3    | 2   | 1  | 0 | -1  | -2   | -3    | -4     | -5      | -6       |
|--------------|-----|---------|------|----|------|---------|--------|-------|------|-----|----|---|-----|------|-------|--------|---------|----------|
| Conv. factor | 1   | 3600000 | 3600 | 60 | 1/60 | 1000000 | 100000 | 10000 | 1000 | 100 | 10 | 1 | 0.1 | 0.01 | 0.001 | 0.0001 | 0.00001 | 0.000001 |

Table 9.1 Conversion Index

| Data type | Description                          | Type   |
|-----------|--------------------------------------|--------|
| 2         | Integer 8                            | Int8   |
| 3         | Integer 16                           | Int16  |
| 4         | Integer 32                           | Int32  |
| 5         | Unsigned 8                           | UInt8  |
| 6         | Unsigned 16                          | UInt16 |
| 7         | Unsigned 32                          | UInt32 |
| 9         | Visible string                       | VisStr |
| 33        | Normalised value 2 bytes             | N2     |
| 35        | Bit sequence of 16 boolean variables | V2     |
| 54        | Time difference without date         | TimD   |

Table 9.2 Data Type and Description

### 9.3.2 0-\*\* Operation/Display

| Par. No. #                    | Parameter description                 | Default value   | 4-set-up    | Change during operation | Conversion index | Type   |
|-------------------------------|---------------------------------------|-----------------|-------------|-------------------------|------------------|--------|
| <b>0-0* Basic Settings</b>    |                                       |                 |             |                         |                  |        |
| 0-01                          | Language                              | [0] English     | 1 set-up    | TRUE                    | -                | UInt8  |
| 0-04                          | Operating state at power-up (hand)    | [1] Forced stop | All set-ups | TRUE                    | -                | UInt8  |
| <b>0-1* Set-up Operations</b> |                                       |                 |             |                         |                  |        |
| 0-10                          | Active set-up                         | [1] Set-up 1    | 1 set-up    | TRUE                    | -                | UInt8  |
| 0-11                          | Edit set-up                           | [1] Set-up 1    | All set-ups | TRUE                    | -                | UInt8  |
| 0-12                          | This set-up linked to                 | [0] Not linked  | All set-ups | FALSE                   | -                | UInt8  |
| 0-13                          | Readout: Linked set-ups               | 0 N/A           | All set-ups | FALSE                   | 0                | UInt16 |
| 0-14                          | Readout: Edit set-ups/channel         | 0 N/A           | All set-ups | TRUE                    | 0                | Int32  |
| <b>0-2* LCP Display</b>       |                                       |                 |             |                         |                  |        |
| 0-20                          | Display Line 1.1 small                | 30112           | All set-ups | TRUE                    | -                | UInt16 |
| 0-21                          | Display Line 1.2 small                | 30110           | All set-ups | TRUE                    | -                | UInt16 |
| 0-22                          | Display Line 1.3 small                | 30120           | All set-ups | TRUE                    | -                | UInt16 |
| 0-23                          | Display Line 2 large                  | 30100           | All set-ups | TRUE                    | -                | UInt16 |
| 0-24                          | Display Line 3 large                  | 30121           | All set-ups | TRUE                    | -                | UInt16 |
| 0-25                          | My personal menu                      | ExpressionLimit | 1 set-up    | TRUE                    | 0                | UInt16 |
| <b>0-4* LCP Keypad</b>        |                                       |                 |             |                         |                  |        |
| 0-40                          | [Hand on] key on LCP                  | [1] Enabled     | All set-ups | TRUE                    | -                | UInt8  |
| 0-41                          | [Off] key on LCP                      | [1] Enabled     | All set-ups | TRUE                    | -                | UInt8  |
| 0-42                          | [Auto on] key on LCP                  | [1] Enabled     | All set-ups | TRUE                    | -                | UInt8  |
| 0-43                          | [Reset] key on LCP                    | [1] Enabled     | All set-ups | TRUE                    | -                | UInt8  |
| <b>0-5* Copy/Save</b>         |                                       |                 |             |                         |                  |        |
| 0-50                          | LCP copy                              | [0] No copy     | All set-ups | FALSE                   | -                | UInt8  |
| 0-51                          | Set-up copy                           | [0] No copy     | All set-ups | FALSE                   | -                | UInt8  |
| <b>0-6* Password</b>          |                                       |                 |             |                         |                  |        |
| 0-60                          | Main menu password                    | 100 N/A         | 1 set-up    | TRUE                    | 0                | Int16  |
| 0-61                          | Access to main menu without password  | [0] Full access | 1 set-up    | TRUE                    | -                | UInt8  |
| 0-65                          | Quick menu password                   | 200 N/A         | 1 set-up    | TRUE                    | 0                | Int16  |
| 0-66                          | Access to quick menu without password | [0] Full access | 1 set-up    | TRUE                    | -                | UInt8  |

### 9.3.3 5-\*\* Digital In/Out

| Par. No. #                   | Parameter description        | Default value       | 4-set-up    | Change during operation | Conversion index | Type   |
|------------------------------|------------------------------|---------------------|-------------|-------------------------|------------------|--------|
| <b>5-0* Digital I/O mode</b> |                              |                     |             |                         |                  |        |
| 5-00                         | Digital I/O mode             | [0] PNP             | All set-ups | FALSE                   | -                | UInt8  |
| 5-01                         | Terminal 27 mode             | [0] Input           | All set-ups | TRUE                    | -                | UInt8  |
| 5-02                         | Terminal 29 mode             | [0] Input           | All set-ups | TRUE                    | -                | UInt8  |
| <b>5-1* Digital Inputs</b>   |                              |                     |             |                         |                  |        |
| 5-10                         | Terminal 18 digital input    | [8] Start           | All set-ups | TRUE                    | -                | UInt8  |
| 5-11                         | Terminal 19 digital input    | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| 5-12                         | Terminal 27 digital input    | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| 5-13                         | Terminal 29 digital input    | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| 5-16                         | Terminal X30/2 digital input | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| 5-17                         | Terminal X30/3 digital input | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| 5-18                         | Terminal X30/4 digital input | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| 5-19                         | Terminal 37 Safe stop        | [1] Safe Stop Alarm | 1 set-up    | TRUE                    | -                | UInt8  |
| <b>5-3* Digital Outputs</b>  |                              |                     |             |                         |                  |        |
| 5-30                         | Terminal 27 Digital output   | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| 5-31                         | Terminal 29 Digital output   | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| <b>5-4* Relays</b>           |                              |                     |             |                         |                  |        |
| 5-40                         | Function relay               | [0] No operation    | All set-ups | TRUE                    | -                | UInt8  |
| 5-41                         | On delay, relay              | 0.30 s              | All set-ups | TRUE                    | -2               | UInt16 |
| 5-42                         | Off delay, relay             | 0.30 s              | All set-ups | TRUE                    | -2               | UInt16 |

### 9.3.4 8-\*\* Comm. and Options

| Par. No. #                   | Parameter description         | Default value             | 4-set-up    | Change during operation | Conversion index | Type   |
|------------------------------|-------------------------------|---------------------------|-------------|-------------------------|------------------|--------|
| <b>8-0* General Settings</b> |                               |                           |             |                         |                  |        |
| 8-01                         | Control site                  | [0] Digital and ctrl.word | All set-ups | TRUE                    | -                | UInt8  |
| 8-02                         | Control word source           | null                      | All set-ups | TRUE                    | -                | UInt8  |
| 8-03                         | Control word timeout time     | 1.0 s                     | 1 set-up    | TRUE                    | -1               | UInt32 |
| 8-04                         | Control word timeout function | [0] Off                   | 1 set-up    | TRUE                    | -                | UInt8  |
| 8-05                         | End-of-timeout Function       | [1] Resume set-up         | 1 set-up    | TRUE                    | -                | UInt8  |
| 8-06                         | Reset control word timeout    | [0] Do not reset          | All set-ups | TRUE                    | -                | UInt8  |
| <b>8-3* FC Port Settings</b> |                               |                           |             |                         |                  |        |
| 8-30                         | Protocol                      | [1] FC MC                 | 1 set-up    | TRUE                    | -                | UInt8  |
| 8-31                         | Address                       | 2 N/A                     | 1 set-up    | TRUE                    | 0                | UInt8  |
| 8-32                         | FC port baud rate             | [2] 9600 Baud             | 1 set-up    | TRUE                    | -                | UInt8  |
| 8-35                         | Minimum response delay        | 10 ms                     | All set-ups | TRUE                    | -3               | UInt16 |
| 8-36                         | Max response delay            | 5000 ms                   | 1 set-up    | TRUE                    | -3               | UInt16 |
| 8-37                         | Max liter-char delay          | 25 ms                     | 1 set-up    | TRUE                    | -3               | UInt16 |
| <b>8-5* Digital/Bus</b>      |                               |                           |             |                         |                  |        |
| 8-53                         | Start select                  | [3] Logic OR              | All set-ups | TRUE                    | -                | UInt8  |
| 8-55                         | Set-up select                 | [3] Logic OR              | All set-ups | TRUE                    | -                | UInt8  |

### 9.3.5 14-\*\* Special Functions

| Par. No. #               | Parameter description  | Default value        | 4-set-up    | Change during operation | Conversion index | Type   |
|--------------------------|------------------------|----------------------|-------------|-------------------------|------------------|--------|
| <b>14-2* Trip Reset</b>  |                        |                      |             |                         |                  |        |
| 14-20                    | Reset mode             | [0] Manual reset     | All set-ups | TRUE                    | -                | UInt8  |
| 14-21                    | Automatic restart time | 10 s                 | All set-ups | TRUE                    | 0                | UInt16 |
| 14-22                    | Operation mode         | [0] Normal operation | All set-ups | TRUE                    | -                | UInt8  |
| 14-23                    | Typecode setting       | null                 | 2 set-ups   | FALSE                   | -                | UInt8  |
| 14-28                    | Production settings    | [0] No action        | All set-ups | TRUE                    | -                | UInt8  |
| 14-29                    | Service code           | 0 N/A                | All set-ups | TRUE                    | 0                | Int32  |
| <b>14-5* Environment</b> |                        |                      |             |                         |                  |        |
| 14-50                    | RFI filter             | [1] On               | 1 set-up    | FALSE                   | -                | UInt8  |
| 14-53                    | Fan monitor            | [1] Warning          | All set-ups | TRUE                    | -                | UInt8  |
| 14-54                    | Bus partner            | 1 N/A                | 2 set-ups   | TRUE                    | 0                | UInt16 |

### 9.3.6 15-\*\* FC Information

| Par. No. #                       | Parameter description       | Default value    | 4-set-up    | Change during operation | Conversion index | Type       |
|----------------------------------|-----------------------------|------------------|-------------|-------------------------|------------------|------------|
| <b>15-0* Operating Data</b>      |                             |                  |             |                         |                  |            |
| 15-00                            | Operating hours             | 0 h              | All set-ups | FALSE                   | 74               | UInt32     |
| 15-01                            | Running hours               | 0 h              | All set-ups | FALSE                   | 74               | UInt32     |
| 15-03                            | Power up's                  | 0 N/A            | All set-ups | FALSE                   | 0                | UInt32     |
| 15-04                            | Over temp's                 | 0 N/A            | All set-ups | FALSE                   | 0                | UInt16     |
| 15-05                            | Over volt's                 | 0 N/A            | All set-ups | FALSE                   | 0                | UInt16     |
| 15-07                            | Reset running hours counter | [0] Do not reset | All set-ups | TRUE                    | -                | UInt8      |
| <b>15-1* Data Log Settings</b>   |                             |                  |             |                         |                  |            |
| 15-10                            | Logging source              | 0                | 2 set-ups   | TRUE                    | -                | UInt16     |
| 15-11                            | Logging interval            | ExpressionLimit  | 2 set-ups   | TRUE                    | -3               | TimD       |
| 15-12                            | Trigger event               | [0] False        | 1 set-up    | TRUE                    | -                | UInt8      |
| 15-13                            | Logging mode                | [0] Log always   | 2 set-ups   | TRUE                    | -                | UInt8      |
| 15-14                            | Samples before trigger      | 50 N/A           | 2 set-ups   | TRUE                    | 0                | UInt8      |
| <b>15-2* Historic Log</b>        |                             |                  |             |                         |                  |            |
| 15-20                            | Historic log: Event         | 0 N/A            | All set-ups | FALSE                   | 0                | UInt8      |
| 15-21                            | Historic log: Value         | 0 N/A            | All set-ups | FALSE                   | 0                | UInt32     |
| 15-22                            | Historic log: Time          | 0 ms             | All set-ups | FALSE                   | -3               | UInt32     |
| <b>15-3* Fault Log</b>           |                             |                  |             |                         |                  |            |
| 15-30                            | Fault log: Error code       | 0 N/A            | All set-ups | FALSE                   | 0                | UInt16     |
| 15-31                            | Fault log: Value            | 0 N/A            | All set-ups | FALSE                   | 0                | Int16      |
| 15-32                            | Fault log: Time             | 0 s              | All set-ups | FALSE                   | 0                | UInt32     |
| <b>15-4* Unit Identification</b> |                             |                  |             |                         |                  |            |
| 15-40                            | FC type                     | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[6]  |
| 15-41                            | Power section               | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[20] |
| 15-42                            | Voltage                     | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[20] |
| 15-43                            | Software version            | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[5]  |
| 15-44                            | Ordered typecode string     | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[40] |
| 15-45                            | Actual typecode string      | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[40] |
| 15-46                            | Unit ordering number        | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[8]  |
| 15-47                            | Power card ordering number  | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[8]  |
| 15-48                            | LCP ID number               | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[20] |
| 15-49                            | SW ID control card          | 0 N/A            | All set-ups | FALSE                   | 0                | VisStr[20] |

| Par. No. #                  | Parameter description     | Default value | 4-set-up    | Change during operation | Conversion index | Type       |
|-----------------------------|---------------------------|---------------|-------------|-------------------------|------------------|------------|
| 15-50                       | SW ID power card          | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[20] |
| 15-51                       | Unit serial number        | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[10] |
| 15-53                       | Power card serial number  | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[19] |
| <b>15-6* Option Ident</b>   |                           |               |             |                         |                  |            |
| 15-60                       | Option mounted            | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[30] |
| 15-61                       | Option SW version         | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[20] |
| 15-62                       | Option ordering number    | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[8]  |
| 15-63                       | Option serial number      | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[18] |
| 15-70                       | Option in slot A          | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[30] |
| 15-71                       | Slot A option SW version  | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[20] |
| 15-72                       | Option in slot B          | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[30] |
| 15-73                       | Slot B option SW version  | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[20] |
| 15-74                       | Option in slot C0         | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[30] |
| 15-75                       | Slot C0 option SW version | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[20] |
| 15-76                       | Option in slot C1         | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[30] |
| 15-77                       | Slot C1 option SW version | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[20] |
| <b>15-9* Parameter Info</b> |                           |               |             |                         |                  |            |
| 15-92                       | Defined parameters        | 0 N/A         | All set-ups | FALSE                   | 0                | UInt16     |
| 15-93                       | Modified parameters       | 0 N/A         | All set-ups | FALSE                   | 0                | UInt16     |
| 15-98                       | Unit identification       | 0 N/A         | All set-ups | FALSE                   | 0                | VisStr[40] |
| 15-99                       | Parameter metadata        | 0 N/A         | All set-ups | FALSE                   | 0                | UInt16     |

### 9.3.7 16-\*\* Data Readouts

| Par. No. #                          | Parameter description | Default value   | 4-set-up    | Change during operation | Conversion index | Type   |
|-------------------------------------|-----------------------|-----------------|-------------|-------------------------|------------------|--------|
| <b>16-0* General Status</b>         |                       |                 |             |                         |                  |        |
| 16-00                               | Control word          | 0 N/A           | All set-ups | FALSE                   | 0                | V2     |
| 16-03                               | Status word           | 0 N/A           | All set-ups | FALSE                   | 0                | V2     |
| <b>16-3* AF Status</b>              |                       |                 |             |                         |                  |        |
| 16-30                               | DC link voltage       | 0 V             | All set-ups | FALSE                   | 0                | Uint16 |
| 16-34                               | Heatsink temp.        | 0 °C            | All set-ups | FALSE                   | 100              | Uint8  |
| 16-35                               | Inverter thermal      | 0 %             | All set-ups | FALSE                   | 0                | Uint8  |
| 16-36                               | Inv. nom. current     | ExpressionLimit | All set-ups | FALSE                   | -2               | Uint32 |
| 16-37                               | Inv. max. current     | ExpressionLimit | All set-ups | FALSE                   | -2               | Uint32 |
| 16-39                               | Control card temp.    | 0 °C            | All set-ups | FALSE                   | 100              | Uint8  |
| 16-40                               | Logging buffer full   | [0] No          | All set-ups | TRUE                    | -                | Uint8  |
| 16-49                               | Current fault source  | 0 N/A           | All set-ups | TRUE                    | 0                | Uint8  |
| <b>16-6* Inputs &amp; Outputs</b>   |                       |                 |             |                         |                  |        |
| 16-60                               | Digital input         | 0 N/A           | All set-ups | FALSE                   | 0                | Uint16 |
| 16-66                               | Digital output [bin]  | 0 N/A           | All set-ups | FALSE                   | 0                | Int16  |
| 16-71                               | Relay output [bin]    | 0 N/A           | All set-ups | FALSE                   | 0                | Int16  |
| <b>16-8* Fieldbus &amp; FC Port</b> |                       |                 |             |                         |                  |        |
| 16-80                               | Fieldbus CTW 1        | 0 N/A           | All set-ups | FALSE                   | 0                | V2     |
| 16-84                               | Comm. option STW      | 0 N/A           | All set-ups | FALSE                   | 0                | V2     |
| 16-85                               | FC port CTW 1         | 0 N/A           | All set-ups | FALSE                   | 0                | V2     |
| <b>16-9* Diagnosis Readouts</b>     |                       |                 |             |                         |                  |        |
| 16-90                               | Alarm word            | 0 N/A           | All set-ups | FALSE                   | 0                | Uint32 |
| 16-91                               | Alarm word 2          | 0 N/A           | All set-ups | FALSE                   | 0                | Uint32 |
| 16-92                               | Warning word          | 0 N/A           | All set-ups | FALSE                   | 0                | Uint32 |
| 16-93                               | Warning word 2        | 0 N/A           | All set-ups | FALSE                   | 0                | Uint32 |
| 16-94                               | Ext. status word      | 0 N/A           | All set-ups | FALSE                   | 0                | Uint32 |



### 9.3.8 300-\*\* AF Settings

#### NOTICE

Except for *parameter 300-10 Active Filter Nominal Voltage*, it is not recommended to change the settings in this parameter group.

| Par. No. #                     | Parameter description         | Default value      | 4-set-up    | Change during operation | Conversion index | Type   |
|--------------------------------|-------------------------------|--------------------|-------------|-------------------------|------------------|--------|
| <b>300-0* General Settings</b> |                               |                    |             |                         |                  |        |
| 300-00                         | Harmonic cancellation mode    | [0] Overall        | All set-ups | TRUE                    | -                | Uint8  |
| 300-01                         | Compensation priority         | [0] Harmonics      | All set-ups | TRUE                    | -                | Uint8  |
| 300-08                         | Lagging reactive current      | [0] Disabled       | All set-ups |                         |                  |        |
| <b>300-1* Network Settings</b> |                               |                    |             |                         |                  |        |
| 300-10                         | Active filter nominal voltage | ExpressionLimit    | 2 set-ups   | FALSE                   | 0                | Uint32 |
| <b>300-2* CT Settings</b>      |                               |                    |             |                         |                  |        |
| 300-20                         | CT primary rating             | ExpressionLimit    | 2 set-ups   | FALSE                   | 0                | Uint32 |
| 300-22                         | CT nominal voltage            | 342 V              | 2 set-ups   | FALSE                   | 0                | Uint32 |
| 300-24                         | CT sequence                   | [0] L1, L2, L3     | 2 set-ups   | FALSE                   | -                | Uint8  |
| 300-25                         | CT polarity                   | [0] Normal         | 2 set-ups   | FALSE                   | -                | Uint8  |
| 300-26                         | CT placement                  | [1] Load Current   | 2 set-ups   | FALSE                   | -                | Uint8  |
| 300-29                         | Start auto CT detection       | [0] Off            | All set-ups | FALSE                   | -                | Uint8  |
| <b>300-3* Compensation</b>     |                               |                    |             |                         |                  |        |
| 300-30                         | Compensation points           | 0.0 A              | All set-ups | TRUE                    | -1               | Uint32 |
| 300-35                         | Cosphi reference              | 0.500 N/A          | All set-ups | TRUE                    | -3               | Uint16 |
| <b>300-4* Paralleling</b>      |                               |                    |             |                         |                  |        |
| 300-40                         | Master follower selection     | [2] Not Paralleled | 2 set-ups   | FALSE                   | -                | Uint8  |
| 300-41                         | Follower ID                   | 1 N/A              | 2 set-ups   | FALSE                   | 0                | Uint32 |
| 300-42                         | Number of follower AFs        | 1 N/A              | 2 set-ups   | FALSE                   | 0                | Uint32 |
| <b>300-5* Sleep Mode</b>       |                               |                    |             |                         |                  |        |
| 300-50                         | Enable sleep mode             | null               | 2 set-ups   | TRUE                    | -                | Uint8  |
| 300-51                         | Sleep mode trig source        | [0] Mains current  | All set-ups | TRUE                    | -                | Uint8  |
| 300-52                         | Sleep mode wake up trigger    | ExpressionLimit    | All set-ups | TRUE                    | 0                | Uint32 |
| 300-53                         | Sleep mode sleep trigger      | 80 %               | All set-ups | TRUE                    | 0                | Uint32 |

### 9.3.9 301-\*\* AF Readouts

| Par. No. #                     | Parameter description        | Default value | 4-set-up    | Change during operation | Conversion index | Type   |
|--------------------------------|------------------------------|---------------|-------------|-------------------------|------------------|--------|
| <b>301-0* Output Currents</b>  |                              |               |             |                         |                  |        |
| 301-00                         | Output current [A]           | 0.00 A        | All set-ups | TRUE                    | -2               | Int32  |
| 301-01                         | Output current [%]           | 0.0 %         | All set-ups | TRUE                    | -1               | Int32  |
| <b>301-1* Unit Performance</b> |                              |               |             |                         |                  |        |
| 301-10                         | THD of current [%]           | 0.0 %         | All set-ups | TRUE                    | -1               | Uint16 |
| 301-11                         | Estimated THD of voltage [%] | 0.0 %         | All set-ups |                         |                  | Uint16 |
| 301-12                         | Power factor                 | 0.00 N/A      | All set-ups | TRUE                    | -2               | Uint16 |
| 301-13                         | Cosphi                       | 0.00 N/A      | All set-ups | TRUE                    | -2               | Int16  |
| 301-14                         | Leftover currents            | 0.0 A         | All set-ups | TRUE                    | -1               | Uint32 |
| <b>301-2* Mains Status</b>     |                              |               |             |                         |                  |        |
| 301-20                         | Mains current [A]            | 0 A           | All set-ups | TRUE                    | 0                | Int32  |
| 301-21                         | Mains frequency              | 0 Hz          | All set-ups | TRUE                    | 0                | Uint8  |
| 301-22                         | Fund. mains current [A]      | 0 A           | All set-ups | TRUE                    | 0                | Int32  |

## 10 Appendix B

### 10.1 Abbreviations and Conventions

|               |  |
|---------------|--|
| AC            | Alternating current  |
| AEO           | Automatic energy optimization                                |
| AMA           | Automatic motor adaptation                                   |
| AWG           | American wire gauge  |
| °C            | Degrees celsius  |
| DC            | Direct current   |
| EMC           | Electromagnetic compatibility                                |
| ETR           | Electronic thermal relay                                     |
| $f_{M,N}$     | Nominal motor frequency                                      |
| FC            | Frequency converter  |
| $I_{LIM}$     | Current limit  |
| $I_{INV}$     | Rated inverter output current                                |
| $I_{M,N}$     | Nominal motor current  |
| $I_{VLT,MAX}$ | The maximum output current                                   |
| $I_{VLT,N}$   | The rated output current supplied by the frequency converter |
| IP            | Ingress protection   |
| LCP           | Local control panel  |
| N.A.          | Not applicable   |
| $P_{M,N}$     | Nominal motor power  |
| PCB           | Printed circuit board  |
| PE            | Protective earth   |
| PELV          | Protective extra low voltage                                 |
| Regen         | Regenerative terminals                                       |
| RPM           | Revolutions per minute                                       |
| $T_{LIM}$     | Torque limit   |
| $U_{M,N}$     | Nominal motor voltage  |

Table 10.1 Abbreviations

#### Conventions

Numbered lists indicate procedures.

Bullet lists indicate other information and description of illustrations.

Italicized text indicates:

- Cross-reference.
- Link.
- Footnote.
- Parameter name, parameter group name, parameter option.

# Index

## A

|                                    |            |
|------------------------------------|------------|
| A53 switch.....                    | 50         |
| A54 switch.....                    | 50         |
| Abbreviation.....                  | 111        |
| AC mains.....                      | 20         |
| Active filter.....                 | 5          |
| Additional resources.....          | 5          |
| AF Readouts.....                   | 110        |
| AF Settings.....                   | 110        |
| Airflow.....                       | 23         |
| Alarm log.....                     | 56         |
| AMA.....                           |            |
| AMA.....                           | 50, 68, 71 |
| AMA, successful.....               | 51         |
| AMA, unsuccessful.....             | 51         |
| Analog signal.....                 | 67         |
| Anchoring.....                     | 26         |
| Approval.....                      | 15         |
| Auto on.....                       | 56, 61     |
| Auto remote coasting.....          | 55         |
| Automatic energy optimization..... | 60         |
| Automatic motor adaptation.....    | 50, 61     |
| Auto-reset.....                    | 55         |

## B

|                                |    |
|--------------------------------|----|
| Back cooling.....              | 23 |
| Bottom view.....               | 26 |
| Brake.....                     |    |
| cable.....                     | 39 |
| chopper.....                   | 39 |
| control.....                   | 68 |
| resistor.....                  | 67 |
| Electromechanical brake.....   | 48 |
| Mechanical brake control.....  | 48 |
| Braking.....                   | 69 |
| Branch circuit protection..... | 95 |
| Bus termination switch.....    | 50 |

## C

|                            |        |
|----------------------------|--------|
| Cable.....                 |        |
| length, cross-section..... | 90     |
| Cabling.....               | 36     |
| Motor cable.....           | 36     |
| Screened cable.....        | 38, 54 |
| CE compliance mark.....    | 15     |
| Circuit breaker.....       | 54     |
| Closed loop.....           | 49     |
| Comm. and Options.....     | 106    |

|                                       |            |
|---------------------------------------|------------|
| Communication option.....             | 70         |
| Compliance mark, CE.....              | 15         |
| Conduit.....                          | 54         |
| Control.....                          |            |
| card.....                             | 67         |
| card performance.....                 | 93         |
| card, 24 V DC output.....             | 92         |
| card, RS485 serial communication..... | 91         |
| card, USB serial communication.....   | 93         |
| characteristic.....                   | 93         |
| system.....                           | 5          |
| terminal.....                         | 44, 56, 58 |
| terminals, access.....                | 44         |
| wiring.....                           | 37, 54     |

|                        |     |
|------------------------|-----|
| Convention.....        | 111 |
| Cooling.....           | 23  |
| Cooling clearance..... | 54  |

## Current

|                          |        |
|--------------------------|--------|
| Current.....             | 15     |
| distortion.....          | 16     |
| rating.....              | 21, 67 |
| DC current.....          | 36     |
| Full load current.....   | 21     |
| Fundamental current..... | 15     |
| Harmonic current.....    | 15     |
| Input.....               | 15     |
| Output current.....      | 21, 67 |

## D

|                         |         |
|-------------------------|---------|
| Data Readouts.....      | 109     |
| DC link.....            | 67, 78  |
| Default settings.....   | 57, 104 |
| Definition.....         | 5       |
| Delta.....              | 50      |
| Derating, altitude..... | 95      |
| Digital In/Out.....     | 106     |
| Digital input.....      | 90      |
| Dimension.....          | 15      |
| Discharge time.....     | 20      |
| Disconnect switch.....  | 53, 55  |
| Distortion.....         | 6       |

## E

|                                 |    |
|---------------------------------|----|
| ELCB relay.....                 | 38 |
| Electrical installation.....    | 44 |
| Electrical noise.....           | 37 |
| EMC.....                        | 54 |
| EMC-compliant installation..... | 36 |
| Enclosure.....                  | 15 |
| Exploded view.....              | 7  |
| External alarm reset.....       | 64 |

|   |                    |                                    |                |
|---|--------------------|------------------------------------|----------------|
| External fan supply.....                    | 40                 | Input                              |                |
| <b>F</b>                                    |                    | Analog.....                        | 67             |
| Factory installed brake chopper option..... | 39                 | Analog input.....                  | 91             |
| Fan.....                                    | 40                 | Digital input.....                 | 68             |
| Fault log.....                              | 56                 | power.....                         | 37, 54         |
| Fault message, active filter.....           | 78                 | signal.....                        | 49             |
| FC Information.....                         | 107                | terminal.....                      | 49, 53         |
| Feedback.....                               | 49, 54, 71         | voltage.....                       | 55             |
| F-frame option.....                         | 51                 | Mains input.....                   | 33             |
| Fieldbus connection.....                    | 42                 | Installation.....                  | 54, 55         |
| Filter capacitor.....                       | 38                 | Insulation resistance monitor..... | 52             |
| Final set-up and test.....                  | 50                 | Intermediate circuit.....          | 67             |
| Fourier series analysis.....                | 15                 | IT main.....                       | 38             |
| Fuse.....                                   | 36, 54, 70, 80, 95 | Items supplied.....                | 22             |
| Fuse tables.....                            | 96                 | <b>L</b>                           |                |
| Fusing.....                                 | 36, 54             | Leakage current (>3.5 mA).....     | 37             |
| <b>G</b>                                    |                    | Lifting.....                       | 24             |
| Grid condition.....                         | 94                 | Local control.....                 | 56             |
| Ground connection.....                      | 37, 54             | Local control panel (LCP).....     | 55             |
| Ground wire.....                            | 37, 54             | <b>M</b>                           |                |
| Grounding.....                              | 37, 38, 53, 54     | Main menu.....                     | 56             |
| Grounding hazard.....                       | 37                 | Mains                              |                |
| <b>H</b>                                    |                    | connection.....                    | 40             |
| Hand on.....                                | 56                 | input.....                         | 33             |
| Harmonics                                   |                    | supply (L1, L2, L3).....           | 90             |
| Analysis.....                               | 15                 | terminal.....                      | 49             |
| Harmonic mitigation performance.....        | 94                 | voltage.....                       | 55             |
| Harmonics.....                              | 6, 15, 16, 17      | Supply.....                        | 15             |
| distortion.....                             | 15                 | Manual initialization.....         | 57             |
| Overload prevention.....                    | 15                 | Manual motor starter.....          | 52             |
| Voltage harmonics.....                      | 16                 | MCT 10.....                        | 55             |
| Heat sink.....                              | 71                 | Mechanical dimension.....          | 87             |
| Heater.....                                 | 51                 | Menu key.....                      | 55, 56         |
| High voltage.....                           | 53                 | Menu structure.....                | 56             |
| Hoisting application.....                   | 48                 | Motor                              |                |
| <b>I</b>                                    |                    | cable.....                         | 36, 38         |
| IEC emergency stop, Pilz safety relay.....  | 52                 | current.....                       | 55, 61, 71     |
| Initialization.....                         | 57                 | data.....                          | 59, 61, 67, 72 |
|   |                    | insulation.....                    | 39             |
|   |                    | name plate.....                    | 50             |
|   |                    | output.....                        | 90             |
|   |                    | power.....                         | 55, 71         |
|   |                    | protection.....                    | 93             |
|   |                    | rotation.....                      | 61             |
|   |                    | rotation check.....                | 39             |
|   |                    | speed.....                         | 58             |
|   |                    | thermal protection.....            | 49, 65         |
|   |                    | thermistor.....                    | 65             |
|   |                    | wiring.....                        | 54             |
|   |                    | Thermistor.....                    | 65             |
|   |                    | Mounting.....                      | 54             |

## N

|                        |            |
|------------------------|------------|
| Nameplate.....         | 22         |
| NAMUR.....             | 51         |
| Navigation key.....    | 55, 56, 58 |
| NDE bearing.....       | 40         |
| Noise isolation.....   | 54         |
| Non-UL compliance..... | 96         |

## O

|                             |       |
|-----------------------------|-------|
| Open loop.....              | 49    |
| Operation key.....          | 55    |
| Operation/Display.....      | 105   |
| Optional equipment.....     | 5, 55 |
| Output                      |       |
| Analog output.....          | 91    |
| Digital output.....         | 92    |
| performance (U, V, W).....  | 90    |
| Relay output.....           | 92    |
| Overcurrent protection..... | 36    |
| Overload protection.....    | 21    |

## P

|                                  |                    |
|----------------------------------|--------------------|
| Parallel connection, motor.....  | 49                 |
| Parameter menu structure.....    | 100                |
| PELV.....                        | 65                 |
| Phase loss.....                  | 67                 |
| Planning, installation site..... | 21                 |
| Point of common coupling.....    | 16                 |
| Power                            |                    |
| Input power.....                 | 20, 53, 54, 66, 80 |
| Input voltage.....               | 66                 |
| Power.....                       | 37                 |
| connection.....                  | 36                 |
| factor.....                      | 54                 |
| ranges.....                      | 94                 |
| rating.....                      | 15                 |
| Power, input.....                | 66                 |
| Programming.....                 | 55, 56             |
| Protection, feature.....         | 93                 |
| Pulse input.....                 | 91                 |
| Pulse start/stop.....            | 64                 |

## Q

|                          |        |
|--------------------------|--------|
| Qualified personnel..... | 20     |
| Quick menu.....          | 55, 56 |

## R

|                                    |    |
|------------------------------------|----|
| RCD.....                           | 38 |
| Reactive current compensation..... | 94 |

## Reference

|                              |                            |
|------------------------------|----------------------------|
| Analog speed reference.....  | 62                         |
| Reference.....               | 55, 62                     |
| Speed reference.....         | 62                         |
| Reset.....                   | 55, 56, 57, 66, 67, 68, 72 |
| Residual current device..... | 51                         |
| RFI capacitor.....           | 38                         |
| RFI switch.....              | 38                         |
| RS485.....                   | 48, 65                     |
| Run command.....             | 61                         |

## S

|                              |            |
|------------------------------|------------|
| Safe Torque Off.....         | 48         |
| Screened/armoured cable..... | 41         |
| Screening, cable.....        | 36         |
| Serial communication.....    | 56, 66, 93 |
| Set-up.....                  | 56, 61     |
| Shipping damage.....         | 21         |
| Short circuit                |            |
| Short circuit.....           | 68         |
| Short-circuit ratio.....     | 16         |
| SmartStart.....              | 58         |
| Special Functions.....       | 107        |
| Speed reference.....         | 49, 61     |
| Start/stop command.....      | 63         |
| Start-up.....                | 57, 80     |
| Status display.....          | 66         |
| Status message.....          | 66         |
| Status mode.....             | 66         |
| STO.....                     | 48         |
| Supply voltage.....          | 53, 70     |
| Surrounding.....             | 93         |
| Switch.....                  | 49         |
| Switching frequency.....     | 37         |

## T

|                               |    |
|-------------------------------|----|
| Temperature limit.....        | 54 |
| Terminal                      |    |
| Control terminal.....         | 56 |
| Input.....                    | 67 |
| Input terminal.....           | 49 |
| Mains terminal.....           | 49 |
| Output terminal.....          | 53 |
| 53.....                       | 49 |
| 54.....                       | 49 |
| function.....                 | 40 |
| location.....                 | 30 |
| Thermal motor protection..... | 68 |
| Thermistor.....               | 68 |

|                                |        |
|--------------------------------|--------|
| Torque                         |        |
| Torque.....                    | 35, 68 |
| characteristic.....            | 90     |
| Torque, terminals.....         | 35     |
| Total harmonic distortion..... | 15     |
| Transformers.....              | 15     |
| Trip                           |        |
| Trip.....                      | 65     |
| Troubleshooting.....           | 80     |
| <br>U                          |        |
| Undervoltage.....              | 17     |
| <br>V                          |        |
| Voltage                        |        |
| imbalance.....                 | 67     |
| level.....                     | 90     |
| Voltage, input.....            | 66     |
| VVC+.....                      | 60     |
| <br>W                          |        |
| Warning.....                   | 66     |
| Wire size.....                 | 36     |
| Wiring.....                    | 15     |
| Working principle.....         | 6      |



.....  
Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.  
.....

Danfoss A/S  
Ulsnaes 1  
DK-6300 Graasten  
[vlt-drives.danfoss.com](http://vlt-drives.danfoss.com)

