


Installation Guide


Steel Valve with Air-Vent for Convectors

1 Installation in Convector


Built-in valve, type RA-N, code no. 013G8370




Lubricate valve insert by dipping in water.




Insert the built-in valve into the steel valve housing



Fasten built-in valve with a torque of 30 Nm +/- 10%. 21M spanner.




Fasten air-vent with a torque of 10 Nm +/- 10%. 13M spanner.




5. Fit protection cap. Tighten cap.

2 Replacement of Gland Seal



Replace the gland seal, code no. 013L0669. Can be done without draining the heating system.

¹⁾ 17M spanner for fixing the setting dial, ²⁾ 10M spanner.



Test operation of valve spindle, by pushing the pin.