

ENGINEERING  
TOMORROW



Application Guide

# MyDrive Insight

OPEN UP A NEW DIMENSION OF INTELLIGENCE

PROGRAMMABLE  
PREDICTIVE MAINTENANCE  
DATA SECURITY  
CONNECTIVITY  
APPLICATION PERFORMANCE  
POWER DENSITY



Contents

1	Introduction to Application Guide	4
1.1	Version History	4
2	PC Control	5
2.1	MyDrive® Insight	5

# 1 Introduction to Application Guide

## 1.1 Version History

This guide is regularly reviewed and updated. All suggestions for improvement are welcome.

The original language of this guide is English.

Version	Remarks
01	First version. Information in this version of the guide corresponds to application software version 2.11.2.

## 2 PC Control

### 2.1 MyDrive® Insight

MyDrive® Insight is a platform-independent software tool that supports the commissioning, engineering, and monitoring of iC7 series. Some of the key features include:

- Fast and easy configuration and commissioning.
- Monitor the drives as part of daily operations.
- Collect data and information for troubleshooting, maintenance, and service.
- Discovery and access to multiple drives in a network.
- Intuitive user interface.
- Notifications and visualizations of real time information and events about the drive.
- PC control to perform operations such as starting or stopping the drive, set references, set direction, reset, and coast of the drive.
- Perform updates on single or multiple drives.
- Backup and restore of parameter settings.
- Data logging and analyzing for troubleshooting.

#### NOTICE

This chapter applies to MyDrive® Insight version 2.8.0 or above. Please make sure to uninstall lower versions of MyDrive® Insight from your device to utilize the latest MyDrive® Insight functions.

The section MyDrive® Insight in the application guide covers basic information such as getting started with MyDrive® Insight, accessing and viewing or changing the parameters, and PC control to operate the drive using MyDrive® Insight. For further information on the different MyDrive screens, integrated help within MyDrive® Insight will be available in future releases.

#### 2.1.1 Getting Started with MyDrive Insight

As a prerequisite, ensure that MyDrive® Insight is installed on the device (PC or laptop). MyDrive® Insight can be downloaded and installed from MyDrive® Suite, available here: <https://suite.mydrive.danfoss.com/>

##### Procedure

1. To establish a point-to-point connection between the drive and the device, use the communication interface X0 and the RJ45 Ethernet port on the device by using a standard Ethernet cable.

If the device does not have an RJ45 Ethernet port or it is already in use, then a conventional adapter from USB-C to RJ45 can be used. To connect several drives at the same time, use an Ethernet switch between the PC and the control unit.




Illustration 1: Connection to the PC

A      Ethernet switch

- 2. When the drive is powered up and in *Ready* state, open MyDrive® Insight on the device and the drive is recognized.
- 3. To establish or confirm the connection, click the arrow button.



Illustration 2: Confirm Connection

➡ Once the connection is established, the drive is marked with a connection symbol (green color) in MyDrive® Insight as shown.




Illustration 3: Establish Connection

4. Select the required interaction for the drive. In this example, the *Device Info* screen is shown.




Illustration 4: Device Info

## NOTICE

The application guide covers basic information such as accessing parameters and using the PC control in MyDrive® Insight.

## 2.1.2 Accessing Parameters and Understanding Parameter Screens in MyDrive Insight

### Viewing and Changing Parameters

1. To access the parameters of the connected drive, click *Setup and Service*.
2. Click *Parameters* → *Live* as shown.




Illustration 5: Setup and Service

### Parameter Screen Overview

The following is an overview of the *Parameters (Live)* screen in MyDrive® Insight.

The screenshot displays the 'Parameters' screen in the MyDrive Insight PC Control application. The interface is divided into three main sections:

- Left Sidebar:** Contains navigation options such as 'All devices', 'Device Info', 'Live', 'Graphs and reports', 'Setup and service', 'Parameters', 'Live' (selected), 'Interface configuration', 'Functional safety', 'Events', and 'Customization'.
- Central Panel:** Displays a list of parameters organized by group (1). A search field (2) is at the top. The parameter list table (3) includes columns for INDEX, NAME, VALUE, DEFAULT, MIN, and MAX. The 'PC Control' button (4) is located at the top right of the central panel.
- Right Sidebar:** Shows a 'Favorites' panel (5) with a star icon at the top of the page. It lists selected parameters and their status (e.g., 'Select all', 'TN', 'Trip', 'Warning', 'Enable').

Illustration 6: Parameters (Live)

Table 1: Legend Table

Legend	Name	Description
1	Parameter group	Navigate through the different parameter groups in the drive.
2	Search field	Use the search function to find a specific parameter.
3	Value field	View and change a parameter value or selection. All the parameters for the drive are shown on the Live screen.
4	PC Control button	Switch to PC control to start or stop the drive using MyDrive Insight.
5	Favorites	Select a parameter as a favorite by clicking the star in its row. Open the favorites panel on the right side of the screen by clicking the star at the top of the page.

Navigate through different parameter groups

In the following picture, *parameter group 4 Motor* is shown as an example.






Illustration 7: Parameter Group

1. Click the parameter group (1) from the *Live* pane.
2. Click the parameter subgroup (2).
3. Repeat step 2, until the right level of parameter subgroup (3) is reached to find the specific parameters (4).

## NOTICE

When in a specific parameter subgroup, only parameters relevant to the parameter subgroup can be accessed.

### Searching for a specific parameter

In the *Search* field, type the search term. The search returns all parameters that have the search term in the name.

In the following example, all parameters with *DC-Link* in the name are listed in the search results.




Illustration 8: Search button

1	Search term
2	Search results

### 2.1.3 Viewing and Changing Parameter Settings

When in a specific parameter group, all parameters related to the parameter group are shown. Depending on the access type of the parameter, there is a possibility to view the parameter setting or change the current selection or value of the parameter.

In the following picture, *parameter group 4 Motor* is shown as an example.

Live devices

All devices

ic7-136b7309032955g172

169.254.79.207:2020

Device info

Live

Graphs and reports

Setup and service

Parameters

Live

Interface configuration

Functional safety

Events

Customization

Parameters

ic7-136b7309032955g172

REM

Start Blocked

1

2

6

7

8

9

10

11

12

Overview

1 Grid

2 Power Conversion & DC Link

3 Filters & Brake Chopper

4 Motor

5 Application

6 Maintenance & Service

7 Functional Safety

8 Customization

9 I/O

10 Connectivity

INDEX	NAME	VALUE	DEFAULT	MIN	MAX	UNIT	NUMBER
4.1.1	Motor Current	0.00		0.00	9.00	A	9000
4.1.2	Motor Current %	0.0		0.0	200.0	%	9001
4.1.3	U-phase RMS current	0.01		0.00	9.00	A	9020
4.1.4	V-phase RMS current	0.01		0.00	9.00	A	9021
4.1.5	W-phase RMS current	0.01		0.00	9.00	A	9022
4.1.6	Motor Voltage	0.0		0.0	1000.0	V	9005
4.1.7	Motor Voltage %	0.00		0.00	200.00	%	9006
4.1.11	Motor Torque	0.00		-10000000.00	10000000.00	Nm	9009
4.1.12	Motor Torque %	0.0		-300.0	300.0	%	1708
4.1.13	Motor Shaft Power	0.00		-6470.00	6470.00	kW	9008
4.1.14	Motor Power %	0.0		-300.0	300.0	%	1707
4.1.15	Motor Electrical Power	0.00		-6470.00	6470.00	kW	9043
4.1.16	ETR Motor Thermal Load	0.0		0.0	100.0	%	2951
4.1.17	Motor Current Output	None	None	0	29999		2302
4.1.18	Motor Voltage Output	None	None	0	29999		2303
4.1.19	Absolute Motor Torque Output	None	None	0	29999		2306
4.1.20	Motor Torque 200% Output	None	None	0	29999		2310
4.1.21	Absolute Motor Speed Output	None	None	0	29999		2301
4.1.22	Motor Speed 200% Output	None	None	0	29999		2309
4.1.23	Actual Motor Power Output	None	None	0	29999		2305
4.1.24	AMA Progress	0.0		0.0	100.0	%	429
4.2.1.1	Motor Type	Asyn. Induction Motor	Asyn. Induction ...	0	65535		407
4.2.1.2	Number of Pole Pairs	2	2	0	65535		406
4.2.1.3	AMA Mode	Off	Off	0	4		420
4.2.1.5	Motor Cable Length	100.0	100.0	0.0	10000.0	m	425
4.2.2.1	Nominal Power	1.10	1.10	0.02	6.47	kW	405
4.2.2.2	Nominal Current	2.8000	2.8000	0.0300	9.0000	A	400
4.2.2.3	Nominal Speed	1420.0	1420.0	0.0	10000.0	rpm	402
4.2.2.4	Nominal Frequency	50.0	50.0	0.0	2000.0	Hz	403
4.2.2.5	Nominal Voltage	400.0	400.0	5.0	1000.0	V	401
4.2.3.1	Stator Resistance Rs	4.7838	4.7838	0.0000	1000000.0000	Ω	408
4.2.3.2	Rotor Resistance Rr	3.6703	3.6703	0.0000	1000000.0000	Ω	409
4.2.3.3	Iron Loss Resistance Rfe	2993.9	2993.9	0.0	11000000.0000	Ω	413
4.2.3.4	Stator Leakage Reactance Xls	8.2479	8.2479	0.0000	3141.5928	Ω	440

Illustration 9: Parameter Overview

Table 2: Legend Table

Number	Field Name	Description
1	<i>Index</i>	Based on the parameter group structure, the index defines the location of the parameter. The index is not used as a unique identifier of a parameter.
2	<i>Name</i>	Name of the parameter.
3	Status parameter	Provides the current status or value of a parameter. The parameter value is shown in a light gray color and cannot be changed.
4	Selection parameters	To see all selections available for the parameter, click the value in the <i>Value</i> field.
5	Range parameters	The parameter value can be modified based on the ranges defined (maximum and minimum values).
6	<i>Value</i>	The current value of the parameter.
7	<i>Default</i>	The factory setting (default value) of the parameter.
8	<i>Min and Max</i>	When applicable, the minimum and maximum values of the parameter are shown in the <i>Min</i> and <i>Max</i> fields.
9	<i>Unit</i>	When applicable, the unit of the parameter is shown in the <i>Unit</i> field.
10	<i>Number</i>	The unique identifier for each parameter. The identifier is independent and decoupled from the parameter index values.
11	<i>Help</i>	Click the ? button to see a description about the parameter.
12	<i>Favorites (star)</i>	Clicking the Favorites icon will add the parameter to Favorites.

## 2.1.4 PC Control to Operate the Drive Using MyDrive® Insight

To operate the drive using PC control, click the *Control Panel* button in MyDrive® Insight. The following illustration shows the different screens to operate the drive via MyDrive® Insight.




Illustration 10: Operate Drive using MyDrive® Insight

To access PC Control in MyDrive® Insight and operate the drive, perform the following:

1. Click the *REQUEST CONTROL* button (1).
2. Click *Continue* (2) to confirm secure operational conditions while controlling the drive using MyDrive® Insight.
3. Use the *START*, *STOP*, *STOP COAST* buttons (3) to perform a drive operation. Use the sliders (4) to increase or decrease the reference speed.
4. To reset a drive in case of a fault, click *RESET FAULTS* (5).
5. For ease of access, click the Pin button (6) to make the control panel constantly visible on the screen.

## 2.1.5 Datalogger

The datalogger in MyDrive Insight enables the monitoring of signals and related information for the selected signals. To access the Datalogger feature, select the drive (1), then go to *Graphs and Reports* (2) → *Datalogger* (3).




Illustration 11: Navigating to Datalogger

The following image shows the *Datalogger* main controls.




Illustration 12: Datalogger Screen

Table 3: Main Controls

Legend	Description
1	Opens the window to select available Datalogger files for viewing.
2	Shows the list of Datalogger settings.
3	Shows the Datalogger status.
4	Enables or disables Datalogger. When disabled, all Datalogger configuration settings are inactive. When enabled, Datalogger is active and operates based on the configuration settings.
5	Activates the force trigger. The 0 – 1 transition (rising edge) triggers Datalogger manually. This function is typically used with automatic triggers.
6	Arms Datalogger. The 0 – 1 transition (rising edge) readies Datalogger for triggering.
7	Applies any changed settings.

2.1.5.1 Configuring Datalogger

To configure the datalogger, follow these 2 main steps:

- Configure the signals to be recorded using the datalogger.
- Configure the datalogger settings.

Procedure:

1. Open Datalogger.

The settings view opens.






Illustration 13: Datalogger Settings


The description of the user interface elements in the screen is as follows:

Field name	Field description
Sample time (ms)	Enter a sample time in ms. The actual sample time is dependent on the switching frequency. Fast sample rate settings result in data changing slowly in the resulting log.
Window time (s)	Defines the size of the capture window. Enter the window time in seconds. High sample rates and large capture times that result in large capture files may be rejected when the configuration is applied.
Storage	Select the location to which datalogger files are stored. Available selections are: <ul style="list-style-type: none"> <li><b>RAM:</b> Settings are stored on the RAM of the drive.</li> <li><b>Flash:</b> Settings are stored on the flash of the drive.</li> <li><b>SD card:</b> Data is stored on the (optional) microSD card.</li> </ul> The supported microSD cards are: SD, SDHC, or SDXC, which must be formatted for the FAT32 file system. SDHC is the recommended type as they are delivered preformatted to FAT32.
Trigger position (s)	Adjust the slider to position the trigger. Setting the trigger position to 0 indicates that the datalogger recording starts at the time of the trigger. Setting a negative value indicates that the datalogger recording starts after the trigger has occurred. Setting a positive value indicates that the datalogger recording starts before the trigger has occurred.
Trigger type	The trigger types are the following: <ul style="list-style-type: none"> <li><b>No trigger</b> (manual trigger only)</li> <li><b>Equal</b> triggers when the value of the trigger source variable is equal to trigger level 1.</li> <li><b>Not equal</b> triggers when the value of the trigger source variable is not equal to trigger level 1.</li> <li><b>Greater than</b> triggers when the value of the trigger source variable is greater than trigger level 1.</li> <li><b>Greater than or equal to</b> triggers when the value of the trigger source variable is greater than or equal to trigger level 1.</li> <li><b>Less than</b> triggers when the value of the trigger source variable is less than trigger level 1.</li> </ul>

Field name	Field description
	<ul style="list-style-type: none"> <li>- <b>Less than or equal to</b> triggers when the value of the trigger source variable is less than or equal to trigger level 1.</li> <li>- <b>Rising edge</b> triggers when the value of the trigger source variable rises above trigger level 1. If the trigger source is already above trigger level 1, the trigger must first drop below the trigger level.</li> <li>- <b>Falling edge</b> triggers when the value of the trigger source variable falls below trigger level 1. If the trigger source is already below trigger level 1, the trigger must first rise above the trigger level.</li> </ul>
Trigger level 1	Defines the trigger level associated with the defined trigger type. This level is used for all single-level trigger types. The entry in the field defines the lower trigger level for window trigger types, such as bounds and out of bounds.
File name	Name of the file for datalogger recording.
Over-write	<p>Click the toggle button to turn the overwrite function on or off.</p> <ul style="list-style-type: none"> <li>- <b>On:</b> Overwrite is enabled. A file number is not appended to the datalog file. The datalogger overwrites a previous datalog file.</li> <li>- <b>Off:</b> Overwrite is disabled. A file number is appended to the log file. For each datalog, the datalog file is incremented and the previous datalog file is not overwritten.</li> </ul>
Next file number	The number entered in this field is appended to the initial datalog file. Entry in the field is useful when datalogs are previously available in the drive. The number is auto-incremented with each datalog recording when the entry in <i>Next file number</i> is enabled.
Trigger mode	<p>Select 1 of the following trigger modes.</p> <ul style="list-style-type: none"> <li>- <b>Single trigger mode:</b> After a datalog recording, the datalogger must be rearmed before another trigger is allowed.</li> <li>- <b>Auto trigger mode:</b> After a datalog recording, the datalogger automatically rearms and starts to accept triggers.</li> </ul>
Trigger source	Click the <i>Add signal</i> button under the <i>Trigger source</i> heading. A <i>Trigger source</i> field appears. Click on the <i>Trigger source</i> field to select the signal source which is used for triggering the datalogger recording. The trigger source list opens in a new window:

Field name	Field description
	 <p><b>Settings</b></p> <p>Sample time (ms): 1500</p> <p>Window time (s): 5</p> <p>Storage: Temporal device storage (RAM)</p> <p>Trigger type: Equal</p> <p>File name: user</p> <p>Next file number: 1</p> <p><b>Trigger source</b></p> <p>Trigger source: Control Unit Temperature</p> <p><b>Signals</b></p> <p>Signal 1: Control Unit Temperature</p> <p>Signal 3: Control Unit Temperature (2952)</p> <p>Signal 4: Control Unit Temperature (2952)</p> <p><b>Trigger source</b></p> <p>Motor Ctrl. Ready status word (1710)</p> <p>Speed Reference (1718)</p> <p>Actual Torque Limit Motoring (1812)</p> <p>Actual Torque Limit Regenerative (1813)</p> <p>Output Current Limit % (2700)</p> <p>Main Fan Speed (2931)</p> <p>Brake Power (2933)</p> <p>Brake Power Average (2934)</p> <p>Heat Sink Temperature (2950)</p> <p>ETR Motor Thermal Load (2951)</p> <p>Control Unit Temperature (2952)</p> <p>e30bk189.10</p>
Signals	<p>Click the <i>Add signal</i> button under the <i>Signals</i> heading. A <i>Signal</i> field appears. Click on the <i>Signal</i> field to select the signals that are logged. The signal list opens in a new window:</p>  <p><b>Settings</b></p> <p>Sample time (ms): 1500</p> <p>Window time (s): 5</p> <p>Storage: Temporal device storage (RAM)</p> <p>Trigger type: Equal</p> <p>File name: user</p> <p>Next file number: 1</p> <p><b>Trigger source</b></p> <p>Trigger source: Control Unit Temperature</p> <p><b>Signals</b></p> <p>Signal 1: Control Unit Temperature</p> <p>Signal 3: Heat Sink Temperature</p> <p>Signal 5: Select signal</p> <p>Signal 7: Select signal</p> <p>Signal 4: Select signal</p> <p>Signal 6: Select signal</p> <p>Signal 8: Select signal</p> <p><b>Signals</b></p> <p>On Reference Flag (6074)</p> <p>Process Controller Output (6075)</p> <p>Feedback 1 Value (6080)</p> <p>Feedback 2 Value (6085)</p> <p>Adv. Feed Forward Value (6086)</p> <p>Feedback Value (6090)</p> <p>Setpoint Value (6092)</p> <p>Control Panel Process Control Reference (6094)</p> <p>Speed Reference After Ramp (6150)</p> <p>Final Speed Reference (6151)</p> <p>e30bk190.10</p> <p>Add more signals as necessary by clicking the <i>Add signal</i> button again.</p>

2. Click *Apply settings*.



After the signal selection and the datalogger settings, the datalogger is ready to record the logs. To view a recorded datalog file, click the icon shown in the following figure.




Illustration 14: Datalogger View Icon

### 2.1.6 Backup and Restore

#### Backup

The Backup feature in MyDrive® Insight allows to store the parameter settings of the drive into a new or existing project file, RAM, or flash memory of the drive, or to an optional microSD card.

To utilize the microSD card as a storage device, the microSD card must be inserted in the slot on the interface module located behind the control panel, as shown in the image below.




Illustration 15: MicroSD Card Slot

1	The microSD card
---	------------------

The following are the types of microSD card supported by the interface module, which must be formatted for the file system FAT32.

- Secure Digital (SD) card
- Secure Digital High Capacity (SDHC)
- Secure Digital Extended Capacity (SDXC)

### NOTICE

It is recommended to use SDHC cards as they are delivered as preformatted to FAT32.




### 2.1.6.1 Backing up the Drive

#### Procedure

1. To back up the drive, select a drive, go to *Setup & Services* → *Parameters*.

➡ The *Parameters Live* screen is shown.

2. Click the icon as shown in the figure.



➡ This opens a screen to select the backup destination. The destinations to back up are:

- **Project:** The user can back up an existing project or a new project.
- **Device file system:** The user can back up to 1 of the available memory devices of the drive.

3. Click *Next*.
4.
  - If *Project* was selected, give the backup file a name and description.
  - If *Device file system* was selected, select where to save the backup. The selections are flash, RAM, or an (optional) microSD card. It is possible to specify a name for the backup file as well.
5. Click *Backup* to begin backup.

➡ Once backup is completed, a notification screen about it appears. If a *Project* backup was created, the backup is shown in the device menu under *Parameters*.




Illustration 17: Backup File in the Menu

## 2.1.6.2 Restoring the Data to the Drive

### Procedure

1. To restore data to the drive, select a drive, go to *Setup & Service* → *Parameters*.
2. Click the icon as shown in the image below.




Illustration 18: Restore Data Icon


3. Select the source of the data which has to be restored to the drive.



4. Click *Next* to select the backup source device and view the available backup files.
5. If *Project* is the restore source, select the correct backup to restore. Click *Next*.



6. Select the files for restoring data into the drive, as shown in the figure below, and click *Next*.






Illustration 21: Restore Data

7. The system asks you to confirm the restore action. Click *Restore*.



Illustration 22: Confirm Restore

➡ On successful restore of data, a message is displayed.

Index

B

Backup & Restore..... 16

Backup Data..... 17

D

Datalogger..... 11

P

PC Control with MyDrive Insight..... 11

R

Restore Data..... 18

V

Version history..... 4

ENGINEERING  
TOMORROW



**Danfoss A/S**  
Nordborgvej 81  
DK-6430 Nordborg  
[www.danfoss.com](http://www.danfoss.com)

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

