

Programming Guide

Strategy for heat recovery on CO₂ transcritical rack (Pack Control)

1. In Pack Controller

- A. Heat reclaim request can be based on a number of user selected options including:
- heat exchanger outlet temp
 - heat exchanger inlet/outlet TD
 - fluid temperature
- B. Once there is a call for heat reclaim based on the above, 3-way modulating valve is energized as long as safety conditions are met:
- Flow switch, if used, confirms proper flow
 - temp sensors on heat exchanger inlet/outlet, fluid temp, and CO₂ discharge line after 3-way valve all measure below boiling (212 °F).
- C. 'HP offset' with heat reclaim valve energized, control of condensation pressure can be altered based on a 0 – 10 V signal into the pack controller.
- during heat reclaim and a signal of 0 V, pressure target is increased to setting for 'gas cooler-heat recovery minimum pressure'
 - during heat reclaim and a signal of 10 V, pressure target is increased to setting for 'gas cooler heat recovery offset pressure'
 - during heat reclaim and a signal between 0 – 10 V, pressure target is increased linearly to a value that corresponds to range between min pressure and offset pressure.
 - in the event multiple 0 – 10 V sources are being used (up to 5), maximum voltage signal will be used for control signal.
- D. 'Max heat reclaim' the following control occurs within the pack controller
- during heat reclaim and a signal of 0 – 2.5 V, pressure target is increased to setting for 'gas cooler heat recovery minimum pressure'
 - during heat reclaim and a signal of 7 V, pressure target is increased to setting for 'gas cooler heat recovery offset pressure'
 - during heat reclaim and a signal between 2.5 – 7 V, pressure target is increased linearly to a value that corresponds to range between min pressure and offset pressure.
 - during heat reclaim and a signal between 6.5 – 8 V, gas cooler fan capacity is decreased proportionally (voltage increase results in larger capacity decrease). At 8 V or greater, gas cooler fans are disabled.
 - if piping exists, valve to fully bypass gas cooler for maximum recovery can be utilized. Bypass would occur at a voltage signal of 9.5 V. Bypass valve would be disabled once voltage signal drops below 8 V.

2. In EMS controller

- A. 0 – 10 V signal(s) generated based on desired amount of heat reclaim, signal(s) sent to pack controller.

Danfoss A/S

Climate Solutions • danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.