

Operator's Manual

# ET5070 Crimping Machine



## Imprint

**Manufacturer:**

UNIFLEX-Hydraulik GmbH  
Robert-Bosch-Strasse 50-52  
D-61184 Karben  
Germany

Phone: +49 (0) 60 39 / 91 71 - 0  
Fax: +49 (0) 60 39 / 91 71 - 181

**This Operating Manual of the machine is a translation; the original is in German.**

**Date of revision: 2024-07-22**

**Version: 1.2**

© Copyright by UNIFLEX-Hydraulik GmbH

Technical modifications reserved.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without explicit authorization are prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

## EC / UK - Declaration of Conformity

In accordance with EC Machinery Directive 2006/42/EC and UK-Supply of Machinery (Safety) Regulations 2008.

The following machine

ET5070

was developed, designed and manufactured in compliance with EC Directive 2006/42/EC and UK-Supply of Machinery (Safety) Regulations 2008, in the sole responsibility of

UNIFLEX-Hydraulik GmbH  
Robert-Bosch-Strasse 50 - 52  
D-61184 Karben

The following standards, codes and specifications have been applied:

- EC Directive 2006/42/EC
- EMC Directive 2014/30/EC
- EN ISO 12100: 2010
- EN 60204-1: 2018
- UK-Supply of Machinery (Safety) Regulations 2008
- UK-Electromagnetic Compatibility Regulations 2016

This declaration are invalid when the machine is modified or if unauthorized and unapproved third-party components are used without our prior approval.

Entity authorised for documentation: Uniflex-Hydraulik GmbH, Technical Documentation Dept.

Karben, 04.10.2022



Managing Director Harald von Waitz

# Contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>About this document</b> .....            | <b>7</b>  |
| 1.1      | Target groups .....                         | 7         |
| 1.2      | Storage .....                               | 9         |
| 1.3      | Name plate .....                            | 9         |
| 1.4      | Abbreviations .....                         | 9         |
| <b>2</b> | <b>Safety instructions</b> .....            | <b>10</b> |
| 2.1      | Presentation of warnings .....              | 10        |
| 2.2      | Intended use .....                          | 10        |
| 2.3      | Product-specific risks .....                | 12        |
| 2.3.1    | Risks imposed by mechanical equipment ..... | 12        |
| 2.3.2    | Risks imposed by electricity .....          | 12        |
| 2.3.3    | Risks imposed by hydraulic equipment .....  | 12        |
| 2.3.4    | Risks imposed by noise .....                | 13        |
| 2.3.5    | Risks imposed by substances .....           | 13        |
| 2.3.6    | Risk by hot surfaces .....                  | 13        |
| 2.3.7    | Risks in case of fire .....                 | 13        |
| 2.4      | Safety .....                                | 15        |
| 2.4.1    | Working area .....                          | 15        |
| 2.4.2    | Emergency-stop button .....                 | 16        |
| 2.4.3    | Protection equipment .....                  | 16        |
| 2.4.4    | Warning signs on the machine .....          | 17        |
| <b>3</b> | <b>Machine description</b> .....            | <b>19</b> |
| 3.1      | Design and function .....                   | 19        |
| 3.2      | Accessories .....                           | 20        |
| 3.3      | Options .....                               | 21        |
| 3.4      | Forming process .....                       | 21        |
| 3.5      | Operation and display elements C.2 .....    | 22        |
| 3.6      | Electric sockets .....                      | 24        |
| 3.7      | Depth stop (accessory) .....                | 25        |
| 3.8      | Foot pedal (accessory) .....                | 26        |
| 3.9      | Operation modes .....                       | 26        |
| 3.10     | Technical data .....                        | 28        |
| <b>4</b> | <b>Transport and commissioning</b> .....    | <b>31</b> |

## Contents

---

|          |   |           |
|----------|---|-----------|
| 4.1      | Transport .....   | 31        |
| 4.2      | Intermediate storage of machine/unit.....   | 32        |
| 4.3      | Commissioning .....   | 32        |
| 4.3.1    | Filling hydraulic oil .....   | 33        |
| 4.3.2    | Electrical connection.....  | 35        |
| 4.3.3    | Bleeding the hydraulic system .....   | 37        |
| <b>5</b> | <b>Operation .....</b>  | <b>38</b> |
| 5.1      | What you have to observe .....  | 38        |
| 5.2      | Activation .....  | 38        |
| 5.3      | Forming the workpiece.....  | 39        |
| 5.3.1    | Prerequisites.....  | 39        |
| 5.3.2    | Operation mode buttons control panel.....   | 39        |
| 5.3.3    | Remote automatic mode, via dual foot switch .....                                   | 41        |
| 5.3.4    | Remote automatic mode, via depth stop .....   | 42        |
| 5.4      | Changing the crimping dies .....  | 43        |
| 5.4.1    | Changing the crimping dies/intermediate dies with a die key .....                   | 43        |
| 5.4.2    | Changing the crimping dies with the quick die change system (only profile 239)..... | 45        |
| 5.5      | Adjusting the depth stop .....  | 47        |
| 5.6      | Setting the forming dimension .....   | 49        |
| 5.7      | Stop .....  | 50        |
| 5.8      | Emergency stop.....   | 50        |
| 5.9      | Cleaning.....   | 52        |
| <b>6</b> | <b>Maintenance.....</b>   | <b>53</b> |
| 6.1      | What you have to observe .....  | 53        |
| 6.2      | Maintenance schedule.....   | 53        |
| 6.3      | Hydraulic oil and hydraulic oil filter replacement .....                            | 56        |
| 6.4      | Checking and replacing slide bearing plates.....                                    | 58        |
| 6.5      | Installation of spring-mounted pressure piece in intermediate dies .....            | 61        |
| 6.6      | Replacement of relay/opto-coupler .....   | 62        |
| <b>7</b> | <b>Troubleshooting .....</b>  | <b>63</b> |
| <b>8</b> | <b>Decommissioning, disposal .....</b>  | <b>64</b> |
| 8.1      | Dismantling .....   | 65        |
| 8.2      | Recycling .....   | 65        |
| 8.3      | Consumables and waste.....  | 65        |
| <b>9</b> | <b>Annex .....</b>  | <b>66</b> |

## Contents

---

|       |  |    |
|-------|--|----|
| 9.1   | Accessories (upgradable).....  | 66 |
| 9.2   | Options (only available ex works).....                                     | 66 |
| 9.3   | Spare parts list.....  | 67 |
| 9.3.1 | Mechanics.....   | 67 |
| 9.3.2 | Hydraulic system.....  | 71 |
| 9.3.3 | Electric equipment.....  | 73 |
| 9.4   | Base dies.....   | 75 |
| 9.5   | Intermediate dies 237.239.2L2.....   | 76 |
| 9.6   | Spare parts kit.....   | 77 |
| 9.7   | Retaining bolt for standard crimping dies (depending on crimping die)..... | 78 |
| 9.8   | Hydraulic diagram.....   | 80 |
| 9.9   | Electric diagram.....  | 82 |
| 9.10  | Maintenance log.....   | 88 |
| 9.11  | Declaration of qualified staff.....  | 89 |

# 1 About this document

## 1.1 Target groups

---

# 1 About this document

In this Operation Manual, the “forming machine ET5070” is consistently referred to as machine.

This Operation Manual includes important notes on how you operate your machine/unit safely, properly and economically.

Use not in compliance with the intended purpose may result in hazard to the operator's health and life and/or in the risk of damage to/the machine/unit. Consequently, please only use the machine/unit

- in good order and condition,
- in accordance with its intended purpose,
- in a safety-conscious manner, with awareness of risks and hazards,
- in compliance with all notes included in this Operation Manual.

The machine/unit may only be operated by staff who

- has read the Operation Manual,
- has understood it,
- has been instructed in the operation of the machine/unit, and
- has signed in the Annex.



Figures may include accessories/options. Customer-specific equipment may vary.

The product images shown are for reference only and may differ from the product delivered.

## 1.1 Target groups

The target groups of this Operation Manual are:

### Owner

An owner is a natural person or entity using the device himself/herself/itself, or on whose behalf the device is used. An owner may appoint a representative to exercise the owner's rights and obligations.

The owner has to make sure that

# 1 About this document

## 1.1 Target groups

---

- national provisions, occupational safety regulations and applicable environmental protection regulations are fully complied with;
- persons working on the machine/unit are adequately qualified;
- persons working on the machine/unit are suitable for operating the machine/unit;
- the Operation Manual has been read and understood. One hardcopy of the Operation Manual must always be kept at a designated place where the machine/unit is used.
- persons working on the machine/unit are aware of potential risks;
- the operating staff is familiar with the location as well as with operating the fire alarm and fighting means. Free access to this equipment must be ensured.
- personal protection equipment is worn (safety footwear, protection gloves and safety glasses).

### **Machine/unit fitters**

Machine/unit fitters must be at least 18 years old and have completed training for the task, i.e. they must have attended a specialist vocational training.

#### A fitter

- must observe the instructions in the Operation Manual;
- must inform the owner on failures and damage.

### **Operator**

An operator is a person charged with and instructed in the proper operation of the machine/unit by the owner or the otherwise contractually obliged person.

#### The operator

- must observe the instructions in the Operation Manual;
- must inform the owner on failures and damage.
- must not perform and maintenance or repair work on the machine/unit.



# 1 About this document

## 1.2 Storage

---

### 1.2 Storage

The Operation Manual is part of the machine/unit and must be kept near the machine/unit at all times. Upon disposal of the machine/unit, the Operation Manual must also be handed over.

### 1.3 Name plate

The name plate is fixed near the power cable.

### 1.4 Abbreviations

|     |                                  |
|-----|----------------------------------|
| CFM | Crimp Force Monitoring           |
| FD  | Manual Flow Divider              |
| PB  | Crimping dies                    |
| PBK | Calibration crimping dies        |
| PFC | Pressure Force Control           |
| PFM | Pressure Force Monitoring        |
| QDC | Quick crimping die change system |
| ZWB | Intermediate dies                |

## 2 Safety instructions

### 2.1 Presentation of warnings

Warning notes in the Operation Manual warn against risks involved with the handling of the machine/unit. Risk levels are identified as follows:

**HAZARD!**

The signal word HAZARD identifies an imminent hazard resulting in serious injuries or death. This warning is supplemented by a triangular hazard symbol.

**WARNING!**

The signal word WARNING identifies a potentially hazardous situation, which might result in serious injuries or death. This warning is supplemented by a triangular hazard symbol.

**CAUTION!**

The signal word CAUTION identifies a potentially hazardous situation, which might result in light injuries. This warning is supplemented by a triangular hazard symbol.

**ATTENTION!**

The signal word ATTENTION identifies a potentially hazardous situation, in which the product or property in the environment may be damaged. This warning is supplemented by a hazard symbol or an exclamation mark.

### 2.2 Intended use

This machine is a forming machine for industrial use, only suitable for the manufacture of hose connections with a permissible diameter depending on the fitting and the hose thickness, see “Technical Data” in Section 3.

Intended purposes include:

- single workplace for one person only,
- single stroke with manual feed and withdrawal,
- for maximum hydraulic operating pressure, see “Technical Data” in Section 3.
- operating temperature between 10 °C and 35 °C,
- operation in a closed room,
- use of eight identical original UNIFLEX dies with the same label or seven dies and one associated marking crimping die.

## 2 Safety instructions

### 2.2 Intended use

---

- The machine must not be operated by persons not capable of operating the machine without any risk. These may include:
  - persons with physical or mental disabilities;
  - children and persons under age;
  - persons with a restricted capability for the operation of machines (e.g. under the influence of drugs, alcohol or narcotics)

Use of the control in compliance with the intended purpose also includes compliance with the instructions in this Operation Manual.

#### **Use for other than the intended purpose**

Any other use is considered as being not in compliance with the intended purpose, in particular:

- design modification of the machine;
- use in explosive environments;
- forming of non-metal workpieces without specific safeguards approved by UNIFLEX;
- misuse of consumables and waste materials.

In particular non-metal workpieces may be overstressed by the forming process so that this may result in a sudden failure. Chips or seriously accelerated workpiece parts impose a high risk potential for operators, individuals and objects, even outside the working area.

#### **WARNING!**



#### **Risk for life and health!**

Use not in compliance with the intended purpose imposes risks for life and health. Consequences resulting from use for other than the intended purpose shall be under the sole responsibility of the owner.

- Always use the machine in compliance with its intended purpose.

## 2.3 Product-specific risks

The machine/unit is designed in accordance with the latest state of technology. Nevertheless, the machine/unit may impose risks:

### 2.3.1 Risks imposed by mechanical equipment

#### Risk of squeezing

When the die system closes, there is a risk of getting squeezed between the die and the workpiece.

- Keep the feed opening for the workpiece as small as possible.
- Keep sufficient distance to the die system.

#### Tilting hazard

The risk of tilting mainly exists while the machine is being transported.

- Observe the machine's centre of gravity during transport.

### 2.3.2 Risks imposed by electricity

There is a risk of electrocution near the live parts!

- Work on electric systems may only be performed by qualified electricians or instructed and trained persons under the supervision of a qualified electrician.
- Deactivate the machine/unit and secure it against unintentional restart before maintenance.

### 2.3.3 Risks imposed by hydraulic equipment

Risks are imposed by all hydraulic lines and connections. Hydraulic systems are subject to special safety provisions. Work on hydraulic equipment may only be performed by persons with expert knowledge of and experience with hydraulic equipment.

- After the machine/unit is deactivated, the given and potentially hazardous residual energy has to be considered.
- Relieve the residual pressure in the system before performing repair or maintenance work on hydraulic systems.

## 2 Safety instructions

### 2.3 Product-specific risks

---

- Regularly check lines and bolted connections for leaks and visible damage. Immediately remedy any damage detected.

Repair work on the hydraulic system of the machine/unit or on its components may only be performed by UNIFLEX specialist staff.

#### 2.3.4 Risks imposed by noise

The noise level meter acc. to IEC 804, Class 2, was calibrated before measuring.

The operation of the machine/unit causes noise emissions of < 70 dB(A) at the workplace. Noise protection is not required.

Higher noise emissions may occur when other machine/unit is simultaneously used at the workplace. The machine/unit owner must provide for appropriate protection, e.g.

- instruct staff to wear ear protection,
- provide information/instructions on risks,
- identify hazardous areas,
- provide health monitoring.

#### 2.3.5 Risks imposed by substances

Oils, greases and emulsions may penetrate the skin. When handling hazardous substances, oils and greases, the manufacturers' safety instructions have to be observed. Apply skin protection appropriate for the hazardous substances used.

#### 2.3.6 Risk by hot surfaces

There is a risk of burning when the electric motor and/or the workpiece are touched after forming.

- Keep sufficient distance to the electric motor.
- Wear protection gloves.

#### 2.3.7 Risks in case of fire

The operating staff has to be familiar with the location as well as with operating the fire alarm and fighting means. Free access to this equipment must be ensured.

## 2 Safety instructions


### 2.3 Product-specific risks

---

Never use water to extinguish a fire. For appropriate fire extinguishing action, please read the safety data sheet of the hydraulic oil supplier.

## 2.4 Safety

### 2.4.1 Working area



The working area is designed as the area 3 ft all around the machine (shaded).

- Keep the working area free from trip hazards.
- Use ducts for lines and cables.
- Provide good illumination.
- Keep access to hydraulic supply free.


## 2 Safety instructions

### 2.4 Safety

---

#### 2.4.2 Emergency-stop button

The machine is fitted with an emergency-stop button on the control panel.



Immediately activate the emergency-stop button (1) in cases of emergency.

Remedy the cause of the emergency stop first before unlocking the emergency-stop button.

Do not pull the emergency-stop button for unlocking it, but release it by rotating it.

#### 2.4.3 Protection equipment

Due to the variety of customer-specific workpieces, UNIFLEX is not capable of supplying additional standard protection equipment together with the machine for the prevention of potential residual risks imposed by the machine.

The necessity of additional, workpiece-specific protection equipment may for instance arise for angled workpiece geometries needing a large opening for being inserted into the forming machine. The pressure joining of insulators, structural steel and steel ropes, too, may require special safeguards.

The owner has to consider the need for adapted protection equipment before commissioning. If such need exists, the relevant protection equipment has to be mounted before commissioning of the machine.

UNIFLEX will provide you with customized solutions for protection equipment upon request. Please do not hesitate to address your personal contact for consultation.




## 2 Safety instructions

### 2.4 Safety

Mounted safety equipment must not be removed, bypassed or avoided.

#### 2.4.4 Warning signs on the machine



**Hand injury**  
on the die system



**Risk of squeezing**  
on the die system



**Hot surface**  
on the electric motor

## 2 Safety instructions

### 2.4 Safety

---




**Oiling / greasing prohibited**  
on the die system

Illegible or missing warning signs must immediately be replaced by the owner.

## 3 Machine description

### 3.1 Design and function

#### Base machine



- (1) Crimping tool
- (2) Oil sight glass
- (3) Power unit (comprising electric motor, pump, control block)
- (4) Control cabinet
- (5) Control panel with buttons and control system CONTROL C.2 / IPC
- (6) Position encoder system

The crimping tool (1) is closed hydraulically, whereby the work piece is formed. The pressure needed for this purpose is built up by the electrically driven pump (5) in the cylinders.

The position encoder system (6) records the current position of the die system and transfers the value to the control system.


## 3 Machine description

### 3.2 Accessories

---

Data records may be saved in the item memory and recalled at any time in the control system. Depending on the operation mode, the actual forming process is controlled via the buttons on the control panel (5).

#### Crimping tool



The die system comprises base dies, intermediate dies (depending on the application) and crimping dies.

There are two different types of base dies; the master dies (1) are located on the positions 3 o'clock, 6 o'clock, 9 o'clock and 12 o'clock. The secondary dies (2) are located in between. All base dies are mounted on slide plates. The crimping dies (3) and the intermediate dies (4), if any, are plugged onto the basic crimping dies. The intermediate dies (4) are needed if small work pieces are to be formed on a large machine.

After the forming process, the base dies are pressed apart by the pressure springs (6) when the machine opens. The guiding plates (5) guide the base dies axially in the machine.

### 3.2 Accessories

The machine may be fitted with accessories. A list of the available accessories is included in the Annex, Section "Accessories".

## 3 Machine description

### 3.3 Options

---

### 3.3 Options

The machine can be fitted with Options. A list of the available options is included in the Annex, Section "Options".

### 3.4 Forming process

There are two types of forming process with different target parameters:

- Forming to a defined diameter
- Forming to a defined pressure

#### **Forming to a defined diameter**

This is the standard process for forming to produce hydraulic hoses. The crimping tool closes until it reaches a pre-set diameter, regardless of the required forming force. The required forming force may be up to the machine's maximum capacity.

Optionally, it is possible to monitor the required forming pressure (= forming force) at the time when the pre-set diameter is reached, in order to detect workpiece deviations (PFM option: Pressure Force Monitoring).

#### **Forming to a defined pressure**


This process is used for special applications, e.g. insulators with a fibreglass rod, which are pressure-sensitive. Due to the workpiece tolerances, forming to a specific diameter could result in the destruction of the workpiece. The crimping tool closes until the pre-set pressure value is reached; there is no pressure control.


Optionally, it is possible to monitor the obtained forming diameter at the time when the pre-set pressure is reached, in order to detect workpiece deviations (PFM option: Pressure Force Monitoring).

Optional pressure control to the requested pre-set pressure, including the possibility to vary the pressure built-up speed and soft approach of the pre-set pressure (PFC function: Pressure Force Control).


### 3 Machine description

#### 3.5 Operation and display elements C.2

| <b>WARNING!</b>   |   |
|---|---|
|  | <p><b>Risk of injuries!</b></p> <p>In particular non-metal workpieces may be overstressed by the forming process so that this may result in a sudden failure. Chips or seriously accelerated workpiece parts impose a high risk potential for operators, individuals and objects, even outside the working area!</p> <ul style="list-style-type: none"><li>• Relevant workpieces should only be formed using specific safeguards.</li></ul> |

| <b>ATTENTION!</b>   |   |
|---|---|
|  | <p><b>Risk of damage to machinery!</b></p> <p>The machine lifetime is reduced with a high permanent load, while wear increases disproportionately.</p> <ul style="list-style-type: none"><li>• When using the machine in series production, it must not permanently be loaded with over 2/3 of the maximum operating pressure.</li><li>• The especially high load during pressure joining of isolators, structural steel as well as steel ropes (PFC applications) necessitates machine overhauls after 150,000 forming processes, each. Please contact our Service department in due time: +49 (0)6039 9171-0.</li></ul> |

### 3.5 Operation and display elements C.2



(1) Emergency-stop button

## 3 Machine description

### 3.5 Operation and display elements C.2

---


- (2) Illuminated Motor on button [I]
- (3) Motor off button [O]
- (4) Illuminated foot switch [↩]
- (5) Illuminated Open tool button [←|→]
- (6) Illuminated Close tool button [→|←]
- (7) Locking lever / angle setting
- (8) control panel of CONTROL C.2



The illuminated buttons [I] and [O] may be arranged the other way round, depending on the control version.



The operation of the control system CONTROL C.2 is described in a separate Operation Manual. This description is supplied with the machine.




- (1) LAN socket for connection with a network. Network connection options are set out in the description of the relevant optional packages.
- (2) 2 x USB sockets (for the use of memory media, callipers or barcode scanners certified by UNIFLEX, only)

### 3 Machine description

#### 3.6 Electric sockets

---

### 3.6 Electric sockets



- (1) Main power switch
- (2) Socket for single foot switch
- (3) Power cable screw connection
- (4) Socket for depth stop / dual foot switch
- (5) Control panel connection




### 3 Machine description

#### 3.7 Depth stop (accessory)

---

### 3.7 Depth stop (accessory)



- (1) Connection cable with plunger switch
- (2) Star handle screw
- (3) Sleeve
- (4) Compression spring
- (5) Stop disc
- (6) Clamping yoke
- (7) Locking shaft
- (8) Gusset plate

### 3 Machine description

#### 3.8 Foot pedal (accessory)

### 3.8 Foot pedal (accessory)



- (1) Close machine pedal [→|←]
- (2) Open machine pedal [←|→]

#### WARNING!



#### Risk by fatiguing posture!



A static posture may result in work-related musculoskeletal disorders and reduce productivity.

- Make sure that operators have sufficient periods of relief and recreation.

### 3.9 Operation modes

The control unit provides for the following operation modes for operating the forming tool:

- Manual operation

C.2  / IPC  is activated in the control. The forming process is controlled manually via the buttons on the control panel or external buttons (depth stop or dual foot switch):

- Activate the [→|←] button for closing and forming. The [←|→] button is used for opening.
- Dual foot switch  
The right foot switch is used for closing and forming. The left foot switch is used for opening.
- Depth stop  
The tool is closed automatically when the workpiece activates the depth stop by pressure. Press the [←|→] button to open the tool.



## 3 Machine description


### 3.9 Operation modes

---

As soon as the pre-set forming diameter or forming pressure is reached in the control, the tool stops and opens automatically.

- Semi-automatic operation

C.2  / IPC  is activated in the control. The forming process is started manually via the buttons on the control panel or external buttons, e.g. the dual foot switch:

- Activate the  button for closing and forming.
- Dual foot switch  
The right foot switch is used for closing.
- Depth stop  
The tool is closed automatically when the workpiece activates the depth stop by pressure.




As soon as the forming diameter or forming pressure as defined in the control is reached, the tool stops and opens automatically after the preset holding time.

Production is possible in any operation mode.



The operation mode selected before deactivating the machine will be active upon a restart. The operation modes are set on the control panel.



When the Foot switch button  is activated, the Close tool button  is inoperative, even if the button is illuminated. The Open tool button  is always active independently.



The operation of the control system is described in a separate Operation Manual. This description is supplied with the machine.

## 3 Machine description

### 3.10 Technical data

---

#### 3.10 Technical data

##### Machine

|                      |                      |
|----------------------|----------------------|
| Dimensions L x W x H | 1200 x 600 x 1700 mm |
| Weight               | approx. 750 kg       |
| Control              | CONTROL C.2          |
| Operation mode       | S6-70 %              |
| Noise level          | < 70 dB(A)*          |
| Protection class     | IP 40                |

##### Function

|                           |   |
|---------------------------|---|
| Forming force             | 3150 kN / 315 t   |
| Max. forming range        | Ø dies + 20 mm<br>(max. outer diameter of the fittings<br>before forming) |
| Maximum Ø dies            | 145 mm  |
| Opening size without dies | 215 mm  |
| Opening distance          | +70 mm  |
| Closing speed             | 23 mm/s   |
| Forming speed             | 1.4 mm/s  |
| Opening speed             | 33 mm/s   |

## 3 Machine description

### 3.10 Technical data

---

#### Workpiece capacity

|          |  |
|----------|--|
| SAE R13  | max. 2", depending on fitting                      |
| SAE R 15 | 2½", depending on fitting                          |
| Industry | max. 4" (6"), without flange, depending on fitting |
| Die type | 237 L / 239  |

#### Electric connection

|  |   |
|--|---|
| Connection power   | 4 kW  |
| Supply voltage adjustable                                  | 230 V 50/60 Hz, 3 phases+PE<br>380 V 50/60 Hz, 3 phases+PE<br>400 V 50/60 Hz, 3 phases+PE<br>420 V 50 Hz, 3 phases+PE<br>440 V 60 Hz, 3 phases+PE<br>460 V 60 Hz, 3 phases+PE<br>480 V 60 Hz, 3 phases+PE |
| Voltage selection by plug position                         | Δ 230 V 50/60 Hz, 3 Phases<br>Y 380 - 480 V 50/60 Hz, 3 Phases  |
| Motor protection setting (red marking at adjustment scale) | 230 V, 15 A<br>380 - 480 V; 8.5 A   |
| Back-up fuse   | 230 V: 20 A delayed,<br>400 V: 16 A delayed,<br>preferably thermal fuses, if circuit breakers are used these should be of the class C type  |

#### Hydraulic system

|                 |                                 |
|-----------------|---------------------------------|
| Oil volume      | approx. 100 l                   |
| Oil type        | HLP 46, DIN 51524, 10μ filtered |
| System pressure | max. 330 bar                    |

#### Building prerequisites

## 3 Machine description

### 3.10 Technical data

---

|                         |                                 |
|-------------------------|---------------------------------|
| Permanent floor loading | Approx. 0.07 kg/mm <sup>2</sup> |
| Floor carrying capacity | Min. 2500 kg/m <sup>2</sup>     |
| Floor quality           | B25                             |
| Evenness                | Max. unevenness 5 mm/m          |
| Inclination             | max. 5 mm/m                     |

#### **Ambient conditions**

|                     |               |
|---------------------|---------------|
| Ambient temperature | 10 °C – 35 °C |
| Air humidity        | 45 % – 65 %   |

The \*data are theoretical/computed values, or values measured on a prototype. Actual values may vary slightly, depending on the machine.

## 4 Transport and commissioning


### 4.1 Transport

---

## 4 Transport and commissioning

### 4.1 Transport

The goods should be transported in the original packaging. During transport, the goods must be secured safely within the packaging. All applicable laws and regulations relating to securing loads shall be observed during transport.



The machine/unit may only be unloaded and transported by means of a forklift, a lift truck or a crane. When a crane is used for transport, lifting gear with a sufficient length and lifting capacity has to be used. For machine/unit weight, please refer to "Technical data" in Section 3.

## 4 Transport and commissioning

### 4.2 Intermediate storage of machine/unit

---

#### WARNING!



#### Danger from falling loads!

Risk of injury from falling loads.

- Do not stand under suspended loads.

#### WARNING!



#### Danger from tilting machine/unit!

The machine/unit may tilt if it is transported improperly. There is a risk of being injured.

- Consider the machine/unit's centre of gravity (1).
- Only lift the machine/unit at the designated points.

1. Lift the machine/unit with a forklift, lift truck or crane at the designated points (2) and transfer it to the location of installation.

## 4.2 Intermediate storage of machine/unit

If the machine/unit cannot be mounted immediately upon delivery, it must be protected against:

- Contamination,
- Weather influences,
- Mechanical damage.

The machine/unit components may only be stored in closed rooms and under the following conditions:

- temperature between 10°C and 35°C,
- maximum air humidity 80% (non-condensating).

## 4.3 Commissioning

The machine is commissioned by the customer's fitter.

1. Place the machine on an even ground at the place of installation.



## 4 Transport and commissioning

### 4.3 Commissioning

#### WARNING!



#### Risk by tilting machine!

If not bolted to the floor, the machine may tilt. There is a risk of being injured.

- Fix the machine on the floor.

2. Use suitable bolts to fix the machine legs on the floor.



Place the machine in a way so that it is easily accessible for maintenance work from all sides.

3. Check the machine for damage.
4. Check the electric cables for damage.
5. Train the operating staff and record training sessions in "Declaration of trained staff", Section 9.

#### WARNING!



#### Risk of injuries!

Machine components might loosen during transport. Such components might be flung out during to the forming process. There is a risk of being injured.


- Open and close the machine several times without any work-piece.
- Check the machine for atypical noise.

#### 4.3.1 Filling hydraulic oil

If the UNIFLEX forming machine was purchased without hydraulic oil filling, the appropriate new, clean and pre-filtered hydraulic oil has to be filled before commissioning (for oil type, please refer to "Technical data" in Section 3).

## 4 Transport and commissioning

### 4.3 Commissioning



#### CAUTION!



##### Risk of injuries!

Contact with hydraulic oil and other consumables imposes a risk of injuries for the skin, eyes, respiratory and intestinal tracts! Hydraulic liquid spills impose danger of slipping and falling!

- Observe supplier's protection and safety instructions (see data sheet).
- Wear personal protection equipment.
- Do not eat, drink or smoke in the working area and when handling consumables.
- Ensure good ventilation.
- Avoid floor contamination.

#### ATTENTION!



##### Risk of fire!

Hydraulic liquid spray or spills imposes a risk of fire.

- Avoid ignition sources (welding, cutting and soldering work) near the hydraulic oil filling.

1. Open the cover (1).
2. Fill in hydraulic oil; for quantity and type, please refer to "Technical data" in Section 3.  
The oil level can be read on the fill level indicator (2). The oil level should be at the centre of the fill level indicator.
3. Close the cover (1).

## 4 Transport and commissioning

### 4.3 Commissioning

---

4. Do not operate the machine for a minimum of four hours so that the dirt particles in the system may settle.

#### 4.3.2 Electrical connection

##### ATTENTION!



##### Risk of damage to machinery

The voltage range described in this Section is only permissible for multi-voltage machines (MVA). Reconnecting the machine with a fixed input voltage will result in the destruction of the machine.

- Do not reconnect machines with fixed input voltage.

##### WARNING!




##### Risk by electrical voltage!

There is a risk of electrocution near the live parts!

- Work on electric systems may only be performed by qualified electricians or instructed and trained persons under the supervision of a qualified electrician.
- Do not operate the machine without a sufficiently rated ground wire.
- Deactivate the machine and secure it against unintentional restart before maintenance.

## 4 Transport and commissioning

### 4.3 Commissioning



1. Connect the voltage selection plug to the correct slot in the control cabinet -  $\Delta$  230 V on connection (3), Y 400 V on connection (1).
2. Set the motor protection switch (2) as specified in the Technical data.



The permissible voltage frequency ranges and the relevant motor protection setting are also indicated on the sticker in the control cabinet door.

3. Have the power cable of the machine connected to the local mains by a qualified electrician according to the regulations of the Electricity Board.
4. Check the electric motor rotational direction according to the arrow. Exchange outer cable (phases) of the connection, if required.

## 4 Transport and commissioning

### 4.3 Commissioning

---

#### ATTENTION!



#### **Risk of damage to machinery!**

Extended operation of the motor with an incorrect rotational direction or operating the machine without oil will destroy the hydraulic pump.

- Make sure that the hydraulic oil filling in the machine is sufficient before starting the machine.
- Ensure that the rotational direction of the motor is correct. Observe the red arrow on the motor cover.

#### 4.3.3 Bleeding the hydraulic system

1. Switch on the machine.
2. Operate the machine in the idle mode for two minutes in order to fill the pump with oil.
3. Open and close the tool several times.
4. Check oil level, add hydraulic oil if required.

## 5 Operation

### 5.1 What you have to observe

---

## 5 Operation

### 5.1 What you have to observe

The operator has received the Operation Manual from the owner, has read and understood it and will observe it.


#### Before starting and/or re-starting

- Ensure sufficient illumination of the working area of the machine/unit.

#### During operation

- Observe the safety instructions on the machine/unit.
- Make sure that no other persons stay in the working area.
- Use appropriate aids to handle heavy workpiece.
- Each movement of the hand must be observed.
- The control cabinet must be closed securely.
- Eating, drinking and smoking at the workplace is prohibited.
- Wear close-fitting clothes.
- Do not wear watches or jewellery.

### 5.2 Activation



1. Check that there is no emergency-stop situation.
2. Activate the power switch (1). The control starts the operating system; the starting screen showing the UNIFLEX logo will appear after a few seconds.

## 5 Operation

### 5.3 Forming the workpiece

---


## 5.3 Forming the workpiece

### 5.3.1 Prerequisites

Prerequisites for a correct forming process:

- The die system and the workpiece match each other.
- The proper jaw system is correctly mounted in the tool.
- The forming dimension and the dies have been entered in the control system, please also refer to "Setting the forming dimension" in Section 5.
- Preferably form the workpiece in the centre of the crimping die length. Eccentric forming leads to a conical forming result and an increased one-sided wear of the die system and the bearing plates.

### 5.3.2 Operation mode buttons control panel



## 5 Operation

### 5.3 Forming the workpiece

#### WARNING!



#### Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the die and the workpiece.

- Keep the feed opening for the workpiece as small as possible.
- Keep a minimum distance of 120 mm (A) to the die system.

1. Manually position the pre-mounted workpiece in the tool.
2. Hold the workpiece with one hand during the forming process.
3. Press and hold the button [↵] to close the tool; the forming process starts and ends when the pre-set diameter/pressure is reached.
4. **Manual operation mode:** Press the [↵] button upon completion of the forming process to open the tool.
5. **Semiautomatic operation mode:** Wait until the hold time defined in the control has expired; the tool will then open automatically.
6. Remove the workpiece from the tool.
7. Check the forming dimension after the first forming process. Correct the forming dimension in case of deviations between the actual dimension and the specified dimension (see “Setting the forming dimension” in Section 5).




Open the crimping tool only so much that the hose may be placed and/or removed easily. Excessive opening means risk of squeezing and time loss.



## 5 Operation

### 5.3 Forming the workpiece

#### 5.3.3 Remote automatic mode, via dual foot switch




#### WARNING!



#### Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the die and the workpiece.

- Keep the feed opening for the workpiece as small as possible.
- Keep a minimum distance of 120 mm (A) to the die system.

1. Press [


## 5 Operation

### 5.3 Forming the workpiece



The operation mode Remote automatic via the dual foot switch is only functional if the plug of the dual foot switch is connected to the control cabinet.

#### 5.3.4 Remote automatic mode, via depth stop



#### WARNING!



#### Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the die and the workpiece.

- Keep the feed opening for the workpiece as small as possible.
- Keep a minimum distance of 120 mm (A) to the die system.

1. Switch on the [👉] button to activate the depth stop.
2. Insert the pre-assembled workpiece into the machine manually and press it against the depth stop.
3. Hold the workpiece with one hand during forming; the workpiece must continuously activate the depth stop during forming.
4. **Manual operation mode:** Press the [↔] button to open the machine when the forming process is completed.

## 5 Operation

### 5.4 Changing the crimping dies

---


5. **Semi-automatic operation mode:** Wait until the hold time defined in the control has expired; the tool will then open automatically.
6. Remove the workpiece from the tool.
7. Check the forming dimension after the first forming process. Correct the forming dimension in case of deviations between the actual dimension and the specified dimension (see "Setting the forming dimension" in Section 5).



The Automatic External mode with the depth stop is only functional if the connection of the depth stop is established in the control cabinet.

## 5.4 Changing the crimping dies

### 5.4.1 Changing the crimping dies/intermediate dies with a die key



#### Positioning the dies

1. Open the crimping tool fully.
2. Deactivate the machine at the power switch.

## 5 Operation

### 5.4 Changing the crimping dies

#### WARNING!



#### Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the dies.

- Only replace the dies when the motor is deactivated.

3. Use the die key to press and hold the locking pin (2) in the basic die (3) backward.
4. Use the holding pin to place the crimping dies in the locating hole (1).
5. Remove the die key and release the pressure on the locking pin (2) - the crimping die is now fixed.



Always mount a complete set of identical crimping dies with the same label and diameter. One set comprises eight crimping dies or seven crimping dies and one associated marking die.

#### Removing the crimping dies

1. Open the crimping tool fully.
2. Deactivate the machine at the power switch.

#### WARNING!



#### Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the dies.

- Only replace the dies when the machine is deactivated.

3. Hold the crimping die to be removed with one hand.
4. Use the die key to press and hold the locking pin (2) in the basic die (3) backward with the other hand.
5. Remove the crimping die concerned.
6. Remove the die key and release the pressure on the holding pin (2).

## 5 Operation

### 5.4 Changing the crimping dies




Intermediate dies are positioned and removed in the same manner when needed.



After forming heavy fittings, the locking pin (2) may be a little sluggish. In this case, use a rubber mallet to loosen the locking pin (2) by carefully knocking on the die key.

#### 5.4.2 Changing the crimping dies with the quick die change system (only profile 239)



1. Select the change position for crimping dies in the control by activating the button [QDC].
2. Press the [↩] button to open the crimping tool so that the dies type PB239 can just be inserted.
3. Push the eight pins of the quick die change system (1) into the front holes of the crimping dies (2).
4. Rotate anti-clockwise and remove the crimping dies (2) from the deposit.
5. Check the retaining bolts (3) of the crimping dies for damage.
6. Hold the quick die change system with crimping dies in the centre of the crimping tool.

## 5 Operation

### 5.4 Changing the crimping dies

#### WARNING!



##### Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the dies.

- Take care that no parts of your body are inside the forming area when the crimping dies close.

#### ATTENTION!



##### Risk of damage to machinery!

The retaining bolts and the crimping dies will be destroyed if the retaining bolts do not fit in the mounting hole of the base dies or intermediate dies.

- Pay attention to the correct position of the quick die change system with crimping dies.


7. Press the [→|←] button to close the tool.  
All retaining bolts (3) must slide into the relevant mounting hole (4) of the basic or intermediate dies, and the spring-mounted pressure pieces must engage into the retaining bolts.
8. Remove the quick die change system (1) and check that the crimping dies fit tightly.
9. Proceed in reverse order to remove the crimping dies.



Always use a complete set of equal crimping dies with the same identification and diameter. One set comprises eight crimping dies or seven crimping dies and one matching marking die.

## 5 Operation

### 5.5 Adjusting the depth stop



#### ATTENTION!



##### **Risk of damage to machinery!**

If the crimping dies protrude beyond the basic and intermediate dies, the crimping dies, the intermediate dies and the machine will be damaged (see (X) in the figure). In the figure, the crimping die (2) is placed incorrectly.


- Place the crimping die (2) in the base and/or intermediate die (3) so that it does not protrude.  
In the figure, the crimping die (1) is placed correctly.

### 5.5 Adjusting the depth stop

The depth stop must be adjusted specifically for the work piece. When inserting the hose, the crimping process is triggered by contact with the stop disc. When the pre-defined forming diameter or forming pressure is reached, the tool will stop automatically. Remove depth stop for special applications, e.g. pipe bends.

## 5 Operation

### 5.5 Adjusting the depth stop



1. Dismantle the linchpin (6).
2. Loosen the star handle screw (7).
3. Move the clamping yoke (5) into the desired position.
4. Mount the linchpin (6).

#### **WARNING!**



#### **Risk of squeezing!**

There is risk of getting squeezed between the depth stop and the machine chassis when positioning the depth stop.

- Mount the linchpin.
- Tighten the star handle screw.

5. Tighten the star handle screw (7).
6. Loosen the star handle screw (3).
7. Adjust the sleeve (2) with stop disc (4) in the axial direction.
8. Tighten the star handle screw (3).
9. Connect the cable (1) into the socket for the depth stop.





## 5 Operation

### 5.6 Setting the forming dimension

---


#### Adjusting the control unit:

1. Activate the illuminated  foot pedal. The machine is closed automatically when the workpiece is pressed against the depth stop.
2. Form the workpiece.
3. Press the  button to open the tool.
4. Check the workpiece.
5. If the workpiece meets the requirements: produce other identical workpieces.
6. If the dimension is not reached: Adjust difference on the control unit, form again and check the workpiece.



Activate automatic opening in the control for series production.

### 5.6 Setting the forming dimension



The forming dimension (X) must be set specifically for the workpiece.

1. Read the forming dimension in the forming dimension table of the system supplier, e.g.  $\text{Ø } 17.4 \text{ mm}$ .
2. Select crimping dies with a smaller or the same diameter, e.g.  $\text{Ø } 17 \text{ mm}$ ,
3. Place the crimping dies in the tool.
4. Set the control and/or micrometer to the requested dimension:

**Control system:** Forming dimension diameter

**Micrometer:** Workpiece forming dimension less crimping die diameter


## 5 Operation

### 5.7 Stop

---

5. Form the workpiece.
6. Check the workpiece.
7. If the dimension is reached: manufacture other identical workpieces.
8. If the dimension is not reached: Adjust difference on control and/or in the micrometer, repeat the forming process and check the workpiece.

### 5.7 Stop



1. Complete the forming process.
2. Deposit the work piece outside the machine.
3. Deactivate the main switch (1).
4. Check the machine for contamination, leaks and external damage.
5. Check the crimping tool and retaining bolts for contamination, damage and secure fitting.
6. Check the oil level.
7. Remove contamination, dust and chips using a vacuum.



Inform the fitter in case of damage or other irregularities.

### 5.8 Emergency stop

#### In case of an emergency

Immediately press the emergency-stop button (1) in cases of emergency. The crimping tool movement will be stopped. The drive unit is shut down.

### Restart after and emergency

#### WARNING!



#### Risk of injuries!

The emergency-stop button was probably activated due to the occurrence of a hazardous situation. A restart of the machine may cause injuries if the hazardous situation has not yet been remedied!

- Remedy the hazardous situation before a restart.

1. Remedy the cause of the emergency stop.
2. Unlock the emergency-stop button.
3. Reset the error messages on the control.

## 5.9 Cleaning

### ATTENTION!



#### **Risk of damage to machinery!**

If the machine is cleaned with a steam jet or compressed air, dirt and water may ingress in the machine and cause serious damage.

- Do not use a steam jet to clean the machine.
- Do not use compressed air to clean the machine.

1. Vacuum the machine from metal abrasion (crimping scale) in the opened crimping tool, or use a soft cloth to clean it. For this purpose, remove the crimping dies and the intermediate dies.

## 6 Maintenance

### 6.1 What you have to observe

---

## 6 Maintenance

Regular maintenance will ensure the continuous operation reliability of the device.

### 6.1 What you have to observe

This Section describes action to be taken by you as the fitter regularly to ensure the troublefree use of the machine/unit.

- Maintenance work may only be performed by qualified maintenance staff (machine/unit fitters).
- Repair work on the machine/unit or components may only be performed by appropriately qualified expert staff or UNIFLEX experts!
- The machine/unit must always be deactivated during maintenance work (see "Deactivation" in Section 5). Use the lock to prevent the main switch from being switched on and also attach a sign. Example text:

Machine/unit out of service for  
maintenance work!  
Do not switch on!

- Welding, flame-cutting and grinding work on and in the machine/unit and its environment must be approved in advance. There is a risk of fire. The machine/unit must be cleaned from dust and inflammable substances. Adequate ventilation must be ensured.

### 6.2 Maintenance schedule

If not specified otherwise, inspections listed in the maintenance schedule are visual inspection. Replace defective parts.

If you work in 2 shifts, the check frequency has to be doubled. If you work in 3 shifts, you proceed as with 2-shift operation.

Record maintenance work performed in the maintenance log.

## 6 Maintenance

### 6.2 Maintenance schedule

| Maintenance item  | Weekly | Monthly | Every 6 months | Number of years |
|---|--------|---------|----------------|-----------------|
| <b>Hydraulic system</b>   |        |         |                |                 |
| Hydraulic energy lines – hoses: Check for porosity and leaks.   |        | X       |                |                 |
| Hydraulic energy lines - bolted connections of hoses and pipes: Check for leaks.  |        | X       |                |                 |
| Hydraulic oil: Check oil level, add oil if required (see “Replacing hydraulic oil” in Section 6).   |        | X       |                |                 |
| Hydraulic oil filter: Change according to control display.  |        |         |                |                 |
| Hydraulic oil: Replace  |        |         |                | 1               |
| Hydraulic hoses: Have replaced (DIN 20066) no later than six years after manufacture (see label). Make sure that replacement hoses are of equivalent quality (high-pressure hoses).   |        |         |                | 6               |
| <b>Crimping tool</b>  |        |         |                |                 |
| Crimping tool: Check for damage and wear.   |        | X       |                |                 |
| Retaining bolt: Check for damage.   |        | X       |                |                 |
| Slide bearing plates: Check for wear (see “Checking and replacing slide bearing plates” in Section 6).  |        |         | X              |                 |
| Pressure springs between base dies: Check for damage.   |        |         | X              |                 |
| Guiding plates: Check for wear (visible grooves, unevenness).   |        |         | X              |                 |
| Hexagon socket screws in the base dies: retighten initially after 1000 crimping cycles , subsequently after 50,000 crimping cycles, each (HM 3xx M8, torque MA = 25 Nm; HM400 / HM 450 / HM 480 M8, torque MA = 40 Nm, HM 660 / HM 665.3 M12, torque MA =145 Nm). |        |         |                |                 |
| Check all bolted connections for secure fitting and retighten if necessary.   |        |         |                | 1               |

## 6 Maintenance

### 6.2 Maintenance schedule

| Maintenance item  | Weekly | Monthly | Every 6 months | Number of years |
|---|--------|---------|----------------|-----------------|
| Complete crimping tool: overhaul after 150,000 crimping cycles.<br>Only in case of extreme loads when insulators, structural steel as well as steel ropes (PFC applications) are pressure-joined. |        |         |                | 1.5             |
| <b>Safety equipment</b>   |        |         |                |                 |
| Emergency-stop button: Check function   | X      |         |                |                 |
| Check permanently installed partitioning protection equipment and covers for completeness and correct installation  |        | X       |                |                 |
| Check case foot switch for completeness. The case protects the pedals against unintentional activation.   |        | X       |                |                 |
| Warning signs on the machine: Check legibility (see "Warning signs on the machine" in Section 2)  |        |         | X              |                 |



Hydraulic oil changes and wear part replacements must be recorded in the maintenance log!

## 6 Maintenance

### 6.3 Hydraulic oil and hydraulic oil filter replacement

### 6.3 Hydraulic oil and hydraulic oil filter replacement

#### CAUTION!



#### Risk of injuries!

Contact with hydraulic oil and other consumables imposes a risk of injuries for the skin, eyes, respiratory and intestinal tracts! Hydraulic liquid spills impose danger of slipping and falling!

- Observe supplier's protection and safety instructions (see data sheet).
- Wear personal protection equipment.
- Do not eat, drink or smoke in the working area and when handling consumables.
- Ensure good ventilation.
- Avoid floor contamination.

#### ATTENTION!




#### Risk of fire!

Hydraulic liquid spray or spills imposes a risk of fire.

- Avoid ignition sources (welding, cutting and soldering work) near the hydraulic oil filling.

#### Hydraulic oil



1. Deactivate the machine on the power switch and secure it against unintentional restart.



## 6 Maintenance

### 6.3 Hydraulic oil and hydraulic oil filter replacement

---

2. Let the hydraulic oil cool down until the tank enclosure is warm to the touch.
3. Open the cover (1) and unscrew the screen.
4. Pump out hydraulic oil by using an external pump.
5. Fill in new hydraulic oil (see “Technical Data” in chapter 3).
6. Close the cover (1).
7. Do not operate the machine for a minimum of four hours so that the dirt particles in the system may settle.
8. Start the machine.
9. Operate the machine in the idle mode for two minutes.
10. Run the tool several times to bleed the hydraulic oil system.
11. Check oil level. The oil level should be at the centre of the fill level indicator (2); refill hydraulic oil, if required.

#### Hydraulic oil filter


The hydraulic oil filter is located in the machine enclosure and is accessible when the plate on the back is dismantled. The replacement filter number is indicated on the sticker near the pressure filter.

1. Open the crimping tool fully.



If it is not possible to open the crimping tool completely, contact service department.


2. Deactivate the machine on the power switch and secure it against unintentional restart.
3. Unscrew the plate on the machine back.



4. Operate the valve (1) manually in both directions, once each, using the wrench (2) to discharge residual pressure, if any.

## 6 Maintenance

### 6.4 Checking and replacing slide bearing plates



5. Place an oil sump (3) beneath the machine.
6. Loosen the screws on the filter (2) and remove it.
7. Remove the filter housing (1).
8. Replace the filter element.
9. Reassemble everything in the reverse order.
10. Check oil level, refill hydraulic oil, if required.
11. Operate the machine in the idle mode for two minutes.



Dispose of the oil and filter in compliance with the applicable local environmental protection regulations.

### 6.4 Checking and replacing slide bearing plates

#### Checking slide bearing plates



Check slide bearing plates for wear, replace defective parts. The slide bearing plate (1) is new, the slide bearing plate (2) is worn.

## 6 Maintenance

### 6.4 Checking and replacing slide bearing plates

#### ATTENTION!




#### Risk of damage to machinery!

Worn slide bearing plates may cause damage to the machine and lead to inaccuracies of the forming dimension.

- Replace worn slide bearing plates in good time.

#### Replacing slide bearing plates




1. Open the crimping tool fully.
2. Deactivate the machine on the main switch and secure it against unintentional restart.
3. Unscrew the hexagon socket screws (1) (four each in the front and back) and remove the plates (2).

## 6 Maintenance

### 6.4 Checking and replacing slide bearing plates

---

4. Loosen the hexagon socket screws (4) (eight at the front and the back, each) with adjusting washers and remove the guiding plates (3).
5. Use die wrench to press secondary dies (9) towards the centre of the tool.
6. Replace the four secondary bearing plates (8) by new ones. In doing so, use the new secondary bearing plates to push out the old secondary bearing sheets, each.
7. Slightly loosen the hexagon socket screw (7) in the 6 o'clock master dies and the 12 o'clock master dies (10).
8. Unscrew the flat headed screws with slot (6) (four each in the front and back).



9. Slightly lift off the master dies (10) by using a screw driver and replace the four main bearing plates (5) by new ones. In doing so, use the new main bearing plates to push out the old main bearing sheets, each. Pull out screw driver again.
10. Replace hexagon socket screw (7) and tighten it to the torque for M8 MA = 25 Nm.
11. Reassemble guiding plates and protective plates in the reverse order.
12. For this purpose, fix one shim ring per screw on the secondary dies with grease before the guiding plates (3) are screwed on.
13. Perform a forming test run and check the formed sleeve.



Shims, if present, have to be inserted at the same position as before.


## 6 Maintenance

### 6.5 Installation of spring-mounted pressure piece in intermediate dies



After replacement of the slide bearing plates, the machine has to be recalibrated (see CONTROL C.2 / IPC Operation Manual).

### 6.5 Installation of spring-mounted pressure piece in intermediate dies



The intermediate die 237.239.2L2 (1) has two pin holes. For using the second pin hole, an additional spring-mounted pressure piece (4) has to be mounted in the intermediate dies:

1. Remove the intermediate die from the machine.
2. Insert a pressure piece (4) in the hole (3) and screw it in by twelve revolutions.
3. Press the crimping dies (2) into the locating hole with the newly mounted pressure piece.



Only screw in the pressure piece until the crimping dies cannot be moved manually any longer. If the pressure pieces are tightened excessively, the pins will be subject to excessive wear.

## 6 Maintenance

### 6.6 Replacement of relay/opto-coupler

---

#### 6.6 Replacement of relay/opto-coupler







1. Deactivate the machine on the power switch and secure it against unintentional restart.
2. Open the control cabinet.
3. Open the flap 90° and press down on the hinge with the opened flap (1).  
The relay/opto-coupler (2) will spring up.
4. Remove the relay/opto-coupler and replace it by a new one.
5. Close flap.

## 7 Troubleshooting

| Error                            | Cause   | Remedy  |
|----------------------------------|---|---|
| Machine does not close/open      | Main switch is OFF  | Activate the main switch  |
|                                  | Voltage incorrect   | Check voltage supply  |
|                                  | Power plug defective  | Check power plug and replace if necessary   |
|                                  | Rotational direction of electric motor incorrect              | Check rotation direction, correct electrical connection   |
|                                  | Insufficient amount of hydraulic oil                          | Refill oil  |
|                                  | Power unit defective  | Check power unit  |
|                                  | Operation buttons defective                                   | Check operation buttons and replace, if required  |
| Machine forms unevenly/conically | Dial on flow divider has completely been turned to the right. | Turn dial on flow divider completely to the left.   |
|                                  | Bearing plates worn   | Check bearing plates for wear and replace if necessary  |
|                                  | Base dies damaged   | Check base dies for damage and replace if necessary   |
|                                  | Crimping dies damaged   | Check crimping dies for damage and replace if necessary   |
| Crimping dimension not achieved  | Crimping area is not centred                                  | Preferably form the work piece in the centre of the crimping die length   |
|                                  | Bearing plates worn   | Check bearing plates for wear and replace if necessary  |
|                                  | Oil pressure too low  | Check oil pressure at the MP measuring point, pump or pipe may be leaking or defective, repair or replace   |
|                                  | Incorrect crimping dies used                                  | Check crimping die diameter and crimping die section and replace, if required (for crimping die section, please refer to "Technical data" in Section 3) |

Error messages displayed on the control panel are described in the separate operating instructions of the control system.

## 8 Decommissioning, disposal

| WARNING!  |  |
|---|--|
|    | <p><b>Risk by electrical voltage!</b></p> <p>There is a risk of electrocution near the live parts!</p> <ul style="list-style-type: none"><li>• Shut down the machine/unit.</li><li>• Disconnect the machine/unit from the power supply.</li></ul>  |
| CAUTION!  |  |
|  | <p><b>Risk of injuries!</b></p> <p>Contact with hydraulic oil and other consumables imposes a risk of injuries for the skin, eyes, respiratory and intestinal tracts! Hydraulic liquid spills impose danger of slipping and falling!</p> <ul style="list-style-type: none"><li>• Observe supplier's protection and safety instructions (see data sheet).</li><li>• Wear personal protection equipment.</li><li>• Do not eat, drink or smoke in the working area and when handling consumables.</li><li>• Ensure good ventilation.</li><li>• Avoid floor contamination.</li></ul> |
| ATTENTION!  |  |
|  | <p><b>Risk of fire!</b></p> <p>Hydraulic liquid spray or spills imposes a risk of fire.</p> <ul style="list-style-type: none"><li>• Avoid ignition sources (welding, cutting and soldering work) near the hydraulic oil filling.</li></ul>   |
| CAUTION!  |  |
|  | <p><b>Risk of injuries!</b></p> <p>Parts of the machine/unit may be under pressure and/or tension. Loosening components may impose a risk of injuries!</p> <ul style="list-style-type: none"><li>• De-pressurize the machine/unit before performing any work and check for potential sources of hazard.</li></ul>  |



## 8 Decommissioning, disposal

### 8.1 Dismantling

---

#### 8.1 Dismantling

This section describes activities to be performed by you as the operator to ensure the safe dismantling of the machine/unit.

- The machine/unit may only be dismantled by entrusted and qualified staff.
- Open the machine/unit completely.
- Depressurise the machine/unit before dismantling it (deactivate the hydraulic pump and secure it against restart; operate valve manually, if any; open bolted hydraulic connections slowly and carefully).
- Check the machine/unit for mechanical tension and consider it during dismantling.
- Empty the machine/unit of all consumables, see “Maintenance”, Section 6.

#### 8.2 Recycling

The machine/unit contains metal, hydraulic hoses, electric cables and electronic components, depending on the type.

As regards disposal, the applicable national environmental protection and waste disposal regulations have to be complied with.

#### 8.3 Consumables and waste

Observe applicable national environmental protection and waste disposal regulations.

Return consumables, e.g. oils, greases, test media, to supplier - they are hazardous waste. Also observe the information given on the safety data sheet.

## 9 Annex

### 9.1 Accessories (upgradable)

## 9 Annex



Individual machine/unit components may deviate in their features. Please indicate the serial number of the machine for spare part orders.

### 9.1 Accessories (upgradable)

| Accessories                        | Article code   |
|------------------------------------|--|
| Quick die change system            | QDC 239.5  |
| Die deposit                        | QDS 239 B<br>QDS 239 C<br>QDS 239 R                    |
| TU-QDS system                      | QDS-S.2 double row<br>TU-QDS F Shelf<br>TU-QDS F 239 I |
| Depth stop                         | TA HM 3xx C A  |
| Mirror                             | SHS 375-380  |
| Camera set                         | OCS 10.3 retro   |
| Lamp with magnetic base            | LUS  |
| Die key                            | 239.017.4  |
| Oil cooler<br>(HM3xx PFC Standard) | OC HM3xx/HM245 MVA                                     |
| Crimping die system                | 237L/239+PTS System                                    |
| Intermediate die set               | 237.239.2L2  |

Please contact our Sales department for ordering accessories.


For more control accessories, please refer to the Control C.2 / IPC Operation Manual.

### 9.2 Options (only available ex works)

| Options                  | Item number                    |
|--------------------------|--------------------------------|
| Manual current regulator | 241.930 (not for PFC machines) |

## 9.3 Spare parts list

### 9.3.1 Mechanics



| Item | Quantity | Article code | Description        |
|------|----------|--------------|--------------------|
| 4    | 1        | 232.104.3    | U-profile          |
| 6    | 1 set    | SK 1130.3    | Lateral guidance   |
| 20   | 4        | 232.113.4    | Main counter-plate |
| 21   | 4        | 232.114.3    | Side counter-plate |
| 22   | 8        | 237.103.4    | Counter-plate      |

## 9 Annex


### 9.3 Spare parts list

---

| Item | Quantity | Article code | Description  |
|------|----------|--------------|--|
| 23   | 2 sets   | 232.128.3    | protection plate   |
| 24   | 8        | 798.110142   | Flathead screw DIN 921 M8x12                                 |
| 25   | 32       | 798.220016   | Shim ring DIN 988 6.0x12.0x0.1                               |
| 30   | 2        | 238.300.3    | Hydraulic cylinder   |
| 31   | 1        | 238.311.3    | Hydraulic cylinder   |
| 505  | 2        | 798.120012   | Hexagon socket head screw DIN EN ISO 4762 M24x2x50           |
| 508  | 6        | 798.120123   | Hexagon screw DIN EN ISO 4017 M16x30                         |
| 509  | 4        | 798.320008   | Hexagon nut DIN EN ISO 4032 M72x3                            |
| 510  | 2        | 232.105.4    | Washer   |
| 513  | 8        | 798.110154   | Hexagon socket head screw with shaft DIN EN ISO 4014 M10x150 |
| 514  | 8        | 777.501      | Schnorr lock washer S10                                      |

## 9 Annex

### 9.3 Spare parts list



| Position | Quantity | Article number          | Description                        |
|----------|----------|-------------------------|------------------------------------|
| 202      | 1        | 232.132.2 / 232.133.2   | Protection pad                     |
| 203      | 2        | 232.168.3               | Protection plate, lateral Guidance |
| 206      | 1        | 241.018.3 + colour code | Protection hood position sensor    |
| 208      | 1        | 241.021.3 + colour code | protection plate                   |
| 209      | 1        | 235.015.3               | Holder operator panel              |
| 312      | 1        | 266.353                 | Oil sight glass                    |
| 313      | 1        | UC-AB-1163-40           | Oil filler plug                    |
| 314      | 1        | 777.022                 | Clamp lever                        |

## 9 Annex

### 9.3 Spare parts list


---

| Position | Quantity | Article number | Description                               |
|----------|----------|----------------|---|
| 315      | 2        | 578.4          | Oil prohibition sign                      |
| 316      | 2        | 715.4          | Warning sign crushing risk                |
| 317      | 6        | 716.4          | Warning sign Warning of hand injuries     |
| 1000     | 1        | 238.1100       | Pressing tool complete<br>HM 325 / HM 375 |
| 1001     | 1 Set    | 237.1003       | Base jaws set PB 237                      |

## 9 Annex

### 9.3 Spare parts list

#### 9.3.2 Hydraulic system




| Item | Quantity | Part code   | Designation  |
|------|----------|-------------|--|
| 300  | 1        | 232.059_XYZ | Hydraulic manifold complete XYZ = supplier ID letter |
| 301  | 1        | 232.057     | Suction valve, complete                              |
| 309  | 1        | 220.916     | Pressure sensor                                      |

## 9 Annex

### 9.3 Spare parts list

| Item       | Quantity | Part code       | Designation                                      |
|------------|----------|-----------------|--|
| 310        | 1        | 239.350         | Hydraulic pump                                   |
|            |          | 239.351         | HM 325   |
|            |          | 232.013         | HM 325 H   |
|            |          | 232.010         | HM 375 / HM 380 / HM 3xxPFC<br>HM375 H / HM380 H |
| 311        | 1        | 777.303         | Bell housing                                     |
|            |          | PR250-122-433-1 | HM 325<br>HM 375 / HM 380 / HM 3xxPFC            |
| No picture | 1        | M28             | Coupling HM 325                                  |
|            | 1        | 238.251         | Coupling HM 375 / HM 380 / HM 3xx PFC            |
| 350        | 2        | 232.031         | Hose assembly                                    |
| 351        | 1        | 238.603         | Hose assembly                                    |
| 352        | 2        | 238.604         | Hose assembly                                    |
| 353        | 1        | 238.607         | Hose assembly                                    |
| 354        | 1        | 238.608         | Hose assembly                                    |
| 355        | 1        | 238.615         | Hose assembly                                    |
| 356        | 2        | 238.619         | Hose assembly                                    |
| 357        | 1        | 241.352         | Hose assembly                                    |
| 358        | 1        | 238.604         | Hose assembly HM 325                             |
|            | 1        | 241.351         | Hose assembly HM 375 / HM 380                    |




The number of the replacement filter (1) can be found on the sticker (2) next to the pressure filter.



## 9 Annex

### 9.3 Spare parts list

#### 9.3.3 Electric equipment




| Item       | Quantity | Article code            | Designation                  |
|------------|----------|-------------------------|------------------------------|
| 400        | 1        | 807.710                 | CONTROL C.2 800 mm           |
|            | 1        | 807.711                 | CONTROL C.2 1800 mm          |
|            | 1        | 807.860                 | CONTROL IPC 800 mm           |
| 401        | 1        | 807.415                 | Position encoder             |
| 402        | 1        | 8.06.100                | Main power switch            |
| 403        | 1        | 888.621                 | Voltage selection unit       |
| 404        | 1        | 880.014                 | Motor protection combination |
| 405        | 1        | 807.318                 | Switching power supply       |
| 406        | 1        | 888.406                 | Passive interface            |
|            |          | 888.411                 | Relay                        |
|            |          | 888.410                 | Opto-coupler                 |
| 407        | 1        | 807.375                 | CPU                          |
| 408        | 1        | 807.601                 | Electrical sheet, complete   |
| No picture | 1        | 807.610                 | Outside cable kit            |
| 410        | 1        | 800.244.2 + colour code | Control cabinet              |

## 9 Annex


### 9.3 Spare parts list

| Item | Quantity | Article code       | Designation                                      |
|------|----------|--------------------|--|
| 411  | 1        | 232.011<br>238.011 | Electrical motor 4 kW<br>Electrical motor 5.5 kW |
| 412  | 1        | 888.701            | Selec amplifier (for PFC machines only)          |



| Position | Number | Article number | Designation              |
|----------|--------|----------------|--------------------------|
| 420      | 1      | TA HM 3xx C A  | Depth stop, complete     |
| 421      | 1      | 807.430        | Plunger switch, complete |
| 422      | 1      | 232.036        | Star knob screw M8       |

## 9.4 Base dies




| Item | Quantity | Part code  | Designation                         |
|------|----------|------------|-------------------------------------|
| 1    | 4        | 237.101.2  | Master dies                         |
|      | 4        | 237.102.2  | Secondary dies                      |
| 2    | 8        | 232.153.4  | Locking bolt                        |
| 3    | 8        | D-195A-21  | Pressure spring                     |
| 4    | 8        | 798.420027 | Threaded pin DIN EN ISO 4028 M5x10  |
| 5    | 8        | 798.420026 | Threaded pin DIN EN ISO 4026 M12x20 |

## 9 Annex

### 9.5 Intermediate dies 237.239.2L2

---

#### 9.5 Intermediate dies 237.239.2L2



| Item | Quantity | Article code | Designation                   |
|------|----------|--------------|-------------------------------|
| 1    | 8        | 239,151      | Spring-mounted pressure piece |
| 2    | 8        | 232.504.4    | Holding pin                   |

## 9 Annex

### 9.6 Spare parts kit

---









#### 9.6 Spare parts kit

| Number per machine | Part code    | Designation                                      |
|--------------------|--------------|--|
| 1                  | 238.1100     | Replacement tool HM 325 / HM 375                 |
| 1                  | 238.1102     | Replacement tool HM 380 / HM 3xx PFC             |
| 24                 | D-106340     | Pressure spring                                  |
| 8                  | 232.504.4    | Retaining bolt (profile: 232 / 237 / 237L / 554) |
| 8                  | 239.041.4 sw | Retaining bolt, plastic (profile: 239 / 239L)    |
| 8                  | 239.041      | Retaining bolt, steel (profile: 239 / 239L)      |
| 1                  | 239.151      | Pressure spring screw(profile: 239)              |
| 1                  | 232.1        | Slide bearing set                                |
| 1                  | 238.4        | Guiding plate set                                |
| 1                  | VK 302       | Standard packaging (single machines)             |
| 1                  | 800.605      | Interface calliper cable                         |
| 1                  | 800.609      | Calliper   |
| 1                  | 800.610      | Single foot switch                               |

## 9 Annex

### 9.7 Retaining bolt for standard crimping dies (depending on crimping die)

### 9.7 Retaining bolt for standard crimping dies (depending on crimping die)

| Retaining bolt  | Crimping die profile |     |     |     |               |     |     |     |     |     |
|---|----------------------|-----|-----|-----|---------------|-----|-----|-----|-----|-----|
|   | 262                  | 263 | 239 | 266 | 232           | 237 | 554 | 245 | 246 | 247 |
| <br>262.104.4        | x                    |     |     |     |               |     |     |     |     |     |
| <br>262.129.3        |                      | x   |     |     |               |     |     |     |     |     |
| <br>239.041.4       |                      |     | x   |     |               |     |     |     |     |     |
| <br>239.041.4 (sw) |                      |     | x   |     |               |     |     |     |     |     |
| <br>232.504.4      |                      |     |     | x   | x             | x   |     |     |     |     |
| <br>232.505.4      |                      |     |     |     | Ø96 /<br>Ø103 |     |     |     |     |     |
| <br>220.502.4      |                      |     |     |     |               |     | x   |     |     |     |
| <br>245.114.4      |                      |     |     |     |               |     |     | x   | x   | x   |

## 9 Annex

### 9.7 Retaining bolt for standard crimping dies (depending on crimping die)

---






# 9 Annex

## 9.8 Hydraulic diagram

| 1  |                     | 2                           |                         | 3                            |  |
|--|---------------------|-----------------------------|-------------------------|------------------------------|--|
| Für diese Unterlage behalten wir alle Rechte vor. Sie darf ohne unsere vorherige schriftliche Genehmigung weder vervielfältigt noch benutzt noch Dritten zugänglich gemacht werden. Uniflex Hydraulik GmbH | Pos.                | Benennung                   | Designation             | Teile-Nr. / Article-No.      |  |
|  | 1                   | Hydrauliktank               | hydrauliktank           | 241.001.0                    |  |
|  | 1.1                 | Öleinfüllstutzen            |                         | UC-AB-1163-40                |  |
|  | 1.2                 | Ölschauglas                 | oil level gauge         | 266.353                      |  |
|  | 2                   | Presszylinder               | press cylinder          | 238.300.3 (HM 380 238.315.3) |  |
|  | 3                   | Rückhubzylinder             | return cylinder         | 238.311.3                    |  |
|  | 4                   | Steuerblock                 | control block           | 232.059                      |  |
|  | 6                   | Hydraulikpumpe 9 L          | hydraulik pump 9 L      | 239.350 (HM 325)             |  |
|  |                     | Hydraulikpumpe 9 L          | hydraulik pump 9 L      | 232.013 (HM 375 / HM 380)    |  |
|  |                     | Hydraulikpumpe 12 L         | hydraulik pump 12 L     | 232.010                      |  |
|  | 7                   | Drucksensor                 | pressure sensor         | 220.916                      |  |
|  | 9                   | Druckfilter                 | pressure filter         | -                            |  |
|  | 10                  | E-Motor 4 kW                | electro-motor 4 kW      | 232.011                      |  |
|  |                     | E-Motor 5,5 kW              | elektro-motor 5,5 kW    | 238.011                      |  |
|  | 11                  | 4/3 Wegeventil (NG 6)       | 4/3 directional valve   | 227.001                      |  |
|  | 12                  | Stromregler                 | regulator               | 238.057                      |  |
|  | 14.1                | Druckbegrenzungsventil P1   | pressure relief valve   | -                            |  |
|  | 14.2                | Druckbegrenzungsventil P2   | pressure relief valve   | -                            |  |
|  | 14.3                | 2/2 Wege Sitzventil         | pressure sequence valve | -                            |  |
| 14.4   | 2/2 Wege Sitzventil | pressure sequence valve     | -                       |                              |  |
| 19   | Nachsaugventil      | anti-cavitation check valve | 232.057                 |                              |  |

|  |  |   |  |                                |  |   |  |
|--|--|---|--|--------------------------------|--|---|--|
| CAD  |  |  |  | Werkstoff / Halbz.             |  | Teil von Maschinentyp<br>HM 3xx FD<br>Stromregler |  |
|  |  | Projektionsmethode 1 DIN 6  |  | Maßstab                        |  | Gewicht   |  |
| Allgemeintoleranzen<br>ISO 2768-mK<br>DIN EN ISO 13920 |  | Oberfläche<br>DIN ISO 1302<br>DIN 4768  |  | Gehört zu Zeichnung            |  | EDV-Pfad<br>..\\                                  |  |
| Datum  |  | Name  |  | Benennung                      |  |   |  |
| 18.02.15   |  | RV  |  | <b>Stückliste zu 241.803.3</b> |  |   |  |
| Gepr.  |  |   |  | Zeichnung Nr.                  |  |   |  |
|  |  |   |  | <b>241.803.4</b>               |  |   |  |
| And. Index   |  | Änderung  |  | Feld                           |  | Datum   |  |
|  |  |   |  |                                |  | Blatt<br>2<br>2 Bl.                               |  |
| Name   |  | Urspr.:   |  | Ers. für:                      |  | Ers. durch:                                       |  |
|  |  |   |  |                                |  |   |  |








# 9 Annex

## 9.9 Electric diagram











## 9 Annex

### 9.11 Declaration of qualified staff

---

#### 9.11 Declaration of qualified staff

I herewith declare that I have attended an internal training for the operation of the UNIFLEX machine and have been informed on all safety-related details. In addition I declare that I have read and understood this Operation Manual completely.

|      |      |      |           |
|------|------|------|-----------|
|      |      |      |           |
| City | Date | Name | Signature |

|      |      |      |           |
|------|------|------|-----------|
|      |      |      |           |
| City | Date | Name | Signature |

|      |      |      |           |
|------|------|------|-----------|
|      |      |      |           |
| City | Date | Name | Signature |

|      |      |      |           |
|------|------|------|-----------|
|      |      |      |           |
| City | Date | Name | Signature |

|      |      |      |           |
|------|------|------|-----------|
|      |      |      |           |
| City | Date | Name | Signature |

|      |      |      |           |
|------|------|------|-----------|
|      |      |      |           |
| City | Date | Name | Signature |

## 9 Annex

### 9.11 Declaration of qualified staff

---

## 9 Annex

### 9.11 Declaration of qualified staff

---

## About Danfoss Power Solutions FC

We sincerely appreciate your choice in selecting this product as part of the range of tooling products distributed by Danfoss.

Danfoss hoses, fittings, and tooling provide the ultimate fluid conveyance solutions for a variety of equipment and applications around the world. We proudly engineer to support a sustainable future for tomorrow.

To learn more please visit: <http://www.danfoss.com/en/about-danfoss/our-businesses/power-solutions>

### **Danfoss Power Solutions**

14615 Lone Oak Road  
Eden Prairie, MN 55344, USA  
Phone: 952-937-9800

### **Danfoss Power Solutions II GmbH**

Fluid Conveyance  
Dr. -Reckeweg-Str. 1  
DE-76532 Baden-Baden  
Tel.: +49 7221 6820  
Machine and tooling selection hotline: [FcMachineSupportEMEA@danfoss.com](mailto:FcMachineSupportEMEA@danfoss.com)  
Service and repair Hotline: [FcMachineRepairsEMEA@danfoss.com](mailto:FcMachineRepairsEMEA@danfoss.com)

### **Danfoss Power Solutions (US) Company**

2800 East 13th Street  
Ames, IA 50010, USA  
Phone: +1 515-239-6000

### **Danfoss Power Solutions GmbH & Co.OHG**

Krokamp 35  
D-2439 Neumünster, Germany  
Phone: +49 4321 871 0

### **Danfoss Power Solutions ApS**

Nordborgvej 81  
DK-6430 Nordborg, Denmark  
Phone: +45 7488 2222

### **Danfoss Power Solutions Trade (Shanghai) Co. Ltd.**

Building #22, No 1000 Jin Hai Rd  
Jin Qiao, Pudong New District  
Shanghai, China 201206  
Phone: +86 21 3418 5200w

Thank you for participating in the Danfoss tooling program. We are pleased to offer you high-quality tooling machines manufactured by our trusted partner, Uniflex. These machines are designed to meet the rigorous standards of our industry, ensuring reliability, precision, and efficiency in your operations. We are committed to providing you with the best tools to support your success.

---

Danfoss can accept no responsibility for possible errors in catalogs, brochures, and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are the property of the respective companies.

Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.