

ENGINEERING
TOMORROW



Operating Guide

iC7-Hybrid PROFINET

PROFINET RT OS7PR



drives.danfoss.com |



Contents

1 Introduction and Safety

| | |
|------------------------------------|---|
| 1.1 Purpose of the Operating Guide | 5 |
| 1.2 Additional Resources | 5 |
| 1.3 Safety Symbols | 5 |
| 1.4 Qualified Personnel | 6 |
| 1.5 Safety Precautions | 6 |
| 1.6 Abbreviations | 7 |
| 1.7 Trademarks | 8 |
| 1.8 Version History | 8 |

2 Product Overview

| | |
|--|----|
| 2.1 PROFINET Features and Technical Data | 9 |
| 2.2 Communication Profiles and Objects | 9 |
| 2.2.2 iC Generic | 10 |
| 2.2.3 iC Hybrid | 12 |
| 2.2.4 iC Speed | 15 |
| 2.2.5 PROFIdrive Application Class 1 | 17 |
| 2.3 Submodules | 20 |
| 2.4 Functional Extension Options | 21 |
| 2.5 Network Topologies | 21 |

3 Fieldbus Cable Connections

| | |
|--|----|
| 3.1 Prerequisites for Installation | 25 |
| 3.2 Installation in Frequency Converters | 25 |
| 3.3 Installation in System Modules | 26 |
| 3.4 EMC-compliant Installation | 27 |

4 Configuration

| | |
|--|----|
| 4.1 Configuring Fieldbus Protection Settings | 29 |
| 4.1.1 Fieldbus Protection Settings for DC/DC Converter | 29 |
| 4.1.2 Fieldbus Protection Settings for Grid Converter | 30 |
| 4.1.3 Fieldbus Protection Settings for Generator | 32 |
| 4.2 Configuring the Ethernet Interface | 33 |

| | | |
|----------|--|----|
| 4.3 | Configuring Name of Station | 33 |
| 4.4 | GSDML File (Device Description File) | 34 |
| 4.5 | Reference and Main Actual Value Handling | 34 |
| 4.5.1 | DC/DC Converter and Grid Converter | 34 |
| 4.5.2 | Generator | 34 |
| 5 | Parameter Access | |
| 5.1 | Overview | 35 |
| 5.2 | PROFIdrive Parameter Numbers | 35 |
| 6 | Troubleshooting | |
| 6.1 | Diagnostics | 36 |
| 6.2 | PROFINET Report | 36 |
| 6.3 | Configuring Port Mirroring Settings | 37 |
| 6.4 | Identifying a Unit | 37 |
| 6.5 | Fieldbus Indicator LEDs | 37 |

1 Introduction and Safety

1.1 Purpose of the Operating Guide

This operating guide provides information about configuring the system, controlling the drive or power converter, accessing parameters, programming, troubleshooting, and some typical application examples.

The operating guide is intended for use by qualified personnel, who are familiar with the iC7 drives and power converters, PROFINET technology, and the PC or PLC that is used as a master in the system.

Read the instructions before configuring PROFINET, and follow the procedures in this guide.

1.2 Additional Resources

Additional resources are available to help understand the features, and safely install and operate the iC7 series products:

- Safety guides, which provide important safety information related to installing iC7 series drives and power converters.
- Installation guides, which cover the mechanical and electrical installation of drives, power converters, or functional extension options.
- Design guides, which provide technical information to understand the capabilities of the iC7 series drives or power converters for integration into motor control and monitoring systems.
- Operating guides, which include instructions for control options, and other components for the drive.
- Application guides, which provide instructions on setting up the drive or power converter for a specific end use. Application guides for application software packages also provide an overview of the parameters and value ranges for operating the drives or power converters, configuration examples with recommended parameter settings, and troubleshooting steps.
- *Facts Worth Knowing about AC Drives*, available for download on www.danfoss.com.
- Other supplemental publications, drawings, and guides are available at www.danfoss.com.

Latest versions of Danfoss product guides are available for download at <https://www.danfoss.com/en/service-and-support/documentation/>.

1.3 Safety Symbols

The following symbols are used in Danfoss documentation.

DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates information considered important, but not hazard-related (for example, messages relating to property damage).

The guide also includes ISO warning symbols related to hot surfaces and burn hazard, high voltage and electric shock, and referring to the instructions.

| | |
|--|--|
| | ISO warning symbol for hot surfaces and burn hazard |
| | ISO warning symbol for high voltage and electric shock |
| | ISO action symbol for referring to the instructions |

1.4 Qualified Personnel

Correct and reliable transport, storage, installation, operation, and maintenance are required for the trouble-free and safe operation of the product. Only qualified personnel are allowed to install and operate this equipment.

Qualified personnel are defined as trained staff, who are authorized to install, commission, and maintain equipment, systems, and circuits in accordance with pertinent laws and regulations. Also, the qualified personnel must be familiar with the instructions and safety measures described in this guide.

1.5 Safety Precautions

WARNING



HIGH VOLTAGE

Drives and power converters contain high voltage when connected to AC mains input, DC supply, or load sharing. Failure to perform installation, startup, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel are allowed to perform installation, startup, and maintenance.

WARNING

UNINTENDED START

When the drive or power converter is connected to the AC mains or connected on the DC terminals, the motor may start at any time, causing risk of death, serious injury, and equipment or property damage.

- Stop the drive or power converter before configuring parameters.
- Make sure that the drive or power converter cannot be started by an external switch, a fieldbus command, an input reference signal from the control panel, or after a cleared fault condition.
- Disconnect the drive or power converter from the mains whenever safety considerations make it necessary to avoid an unintended motor start.
- Check that the drive or power converter and any driven equipment are in operational readiness.

⚠ WARNING



DISCHARGE TIME

The drive or power converter contains DC-link capacitors, which can remain charged even when the drive or power converter is not powered. High voltage can be present even when the warning indicator lights are off. Failure to wait the specified time after power has been removed before performing service or repair work can result in death or serious injury.

- Stop the motor.
- Disconnect all power sources, including permanent magnet type motors.
- Wait for capacitors to discharge fully. The discharge time is specified on the drive or power converter product label.
- Measure the voltage level to verify full discharge.

⚠ WARNING

LEAKAGE CURRENT HAZARD

Leakage currents exceed 3.5 mA. Failure to ground the drive or power converter properly can result in death or serious injury.

- Ensure that the minimum size of the ground conductor complies with the local safety regulations for high touch current equipment.

⚠ WARNING

EQUIPMENT HAZARD

Contact with rotating shafts and electrical equipment can result in death or serious injury.

- Ensure that only trained and qualified personnel perform installation, start-up, and maintenance.
- Ensure that electrical work conforms to national and local electrical codes.
- Follow the procedures in this guide.

⚠ CAUTION

INTERNAL FAILURE HAZARD

An internal failure in the drive or power converter can result in serious injury when the drive or power converter is not properly closed.

- Ensure that all safety covers are in place and securely fastened before applying power.

1.6 Abbreviations

Table 1: Abbreviations

| Abbreviation | Definition |
|--------------|--------------------------------------|
| CTW | Control word |
| DAP | Device access point |
| DCP | Discovery and configuration protocol |
| DHCP | Dynamic host configuration protocol |
| DO | Drive object |
| DU | Drive unit |
| EMC | Electromagnetic compatibility |

Table 1: Abbreviations (continued)

| Abbreviation | Definition |
|--------------|-------------------------------|
| I/O | Input/Output |
| IP | Internet protocol |
| IRT | Isochronous real time |
| LED | Light-emitting diode |
| LLDP | Link layer discovery protocol |
| LSB | Least significant bit |
| MAP | Module access point |
| MAV | Main actual value |
| MRC | Media redundancy client |
| MRM | Media redundancy manager |
| MRP | Media redundancy protocol |
| MRV | Main reference value |
| MSB | Most significant bit |
| PAP | Parameter access point |
| PC | Personal computer |
| PCD | Process channel data |
| PDEV | P-Device |
| PLC | Programmable logic controller |
| PNU | Parameter number |
| PPO | Process parameter object |
| REF | Reference |
| RFG | Ramp frequency generator |
| RT | Real time |
| STW | Status word |

1.7 Trademarks

PROFIBUS® and PROFINET® are registered trademarks of PROFIBUS and PROFINET International (PI).

PROFIdrive® is a registered trademark licensed by PROFIBUS and PROFINET International (PI).

1.8 Version History

This guide is regularly reviewed and updated. All suggestions for improvement are welcome.

The original language of this guide is English.

Table 2: Version History

| Version | Remarks |
|------------------------------|--|
| AQ481922002453, version 0201 | Added instructions for configuring PROFINET RT with iC7 Series Generator application software. |
| AQ481922002453, version 0101 | First release. |

2 Product Overview

2.1 PROFINET Features and Technical Data

Fieldbus options for iC7 are integrated in the control board. Fieldbuses are enabled on communication interfaces X1 and X2 only. Modbus TCP is offered as standard, and other protocols such as PROFINET RT can be selected in the configurator when ordering a drive or power converter, or alternatively, they can be activated later by a proof-of-purchase token.

Table 3: PROFINET Model Codes

| Model code | Description |
|------------|-------------------|
| +BAPR | PROFINET RT OS7PR |

PROFINET is the Ethernet-based automation standard of PROFIBUS and PROFINET International (PI) for the implementation of an integrated and consistent automation solution based on Industrial Ethernet. PROFINET supports the integration of distributed field devices and time-critical applications in switched Ethernet networks. It also supports the integration of component-based distributed automation systems for vertical and horizontal integration of networks.

Table 4: PROFINET Features

| Feature | Technical data |
|--------------------|---|
| Cyclic response | 1 ms update cycle |
| | PROFINET RT Conformance Class B (CC-B) |
| | Data consistency with submodule |
| Diagnostics | PROFINET Extended Diagnostics |
| | PROFINET Diagnostics (ALARM CR) |
| Connection | MRP (Media Redundancy Protocol) |
| | LLDP/SNMP |
| | Netload Class III, Advanced robustness against net load |
| | IPv4 |
| | Addressing mode: DCP, STATIC, DHCP/BOOTP |
| System integration | Supported GSDML versions: <ul style="list-style-type: none"> • GSDML version 2.42: current version • GSDML version 2.35: compatible with legacy systems • GSDML version 2.31: compatible with legacy systems |
| PROFInergy | Version 1.3 |

2.2 Communication Profiles and Objects

2.2.1 Overview

The iC7 series complies with PROFINET and PROFIdrive standards, mandatory PNU objects, PROFINET Extended Diagnostics, and a range of vendor-specific profiles for product-specific applications.

Each application in the iC7 series has a dedicated profile or profiles for fieldbus communication.

When using the Generator application software, a communication profile must be selected. Communication profiles are selected in parameter **Fieldbus Profile (1301)**. The parameter is applied only when the active control place is set to fieldbus control and when parameter **Converter Mode (162)** is set to **Motor Control**. The supported profiles for motor control operation are iC Generic, iC Speed, and PROFIdrive Application Class 1.

If parameter *Converter Mode (162)* is set to *Grid Control* when using any of the iC7-Hybrid application software, only the iC Hybrid profile is available.

Table 5: Communication Profiles and Supported Applications

| Profile | Grid Converter | DC/DC Converter | Generator |
|--------------------------------|----------------|-----------------|-----------|
| iC Generic | – | – | X |
| iC Hybrid | X | X | X |
| iC Speed | – | – | X |
| PROFIdrive Application Class 0 | X | X | – |
| PROFIdrive Application Class 1 | – | – | X |
| PROFenergy version 1.3 | X | X | X |
| PROFIdrive standard PNUs | X | X | X |

2.2.2 iC Generic

2.2.2.1 Overview

The iC Generic profile is used for motor control operation with the iC7 Series Generator application software.

2.2.2.2 Control Word

Table 6: iC Generic Profile Control Word Bits

| Bit | Name | Description |
|-----|-------------------|--|
| 0 | Ramp Stop | 0: The ramp stop request is inactive. The drive can be started. 1: The drive is ready to operate. |
| 1 | Coast Stop | 0: A running drive coasts to a stop (modulation stops). 1: The coast request is inactive. The drive can be started. |
| 2 | Quick Stop | 0: The drive stops with the Quick Stop function. 1: The Quick Stop request is inactive. The drive can be started. |
| 3 | Start | 0: The drive stops operating with the method determined by the parameter <i>Missing Start Response (4717)</i> . 1: The drive starts to operate on the rising edge of this signal. |
| 4 | – | Reserved |
| 5 | – | Reserved |
| 6 | – | Reserved |
| 7 | Event Reset | 0: Event Reset Inactive 1: Event Reset Active A rising edge of this signal resets events (warnings, faults, and so on), which do not have active triggering conditions. After a fault the drive goes to a Switching On Inhibited state, which must be acknowledged with bit 0. |
| 8 | Reference Reverse | 0: The speed reference remains normal. 1: The speed reference is reversed. The reference can also be reversed with a negative setpoint. Double negatives result in a forward reference. |

Table 6: iC Generic Profile Control Word Bits (continued)

| Bit | Name | Description |
|-----|--------------------------|---|
| 9 | – | Reserved |
| 10 | Data Valid | <p>0: Ignores the current process data. Uses the previously processed data when the Data Valid bit was previously true.</p> <p>1: Reads the current process data.</p> <p>For most of the control word commands to be acknowledged by the drive, fieldbus must be the commanding control place. See options in parameter group Control Places in parameter group 2 Parameters.</p> |
| 11 | Watchdog | <p>0: Watchdog low</p> <p>1: Watchdog high</p> <p>Continuous toggling 0–1 can be used as a sign of life between the drive and the fieldbus master. The value of this bit is also passed through the fieldbus status word as is.</p> |
| 12 | Fieldbus Digital Input 1 | <p>0: Fieldbus Digital Input 1 inactive</p> <p>1: Fieldbus Digital Input 1 active</p> <p>Select the value CTWB12 for any input parameter to use this signal for the activation of a selected function.</p> |
| 13 | Fieldbus Digital Input 2 | <p>0: Fieldbus Digital Input 2 inactive</p> <p>1: Fieldbus Digital Input 2 active</p> <p>Select the value CTWB13 for any input parameter to use this signal for the activation of a selected function.</p> |
| 14 | Fieldbus Digital Input 3 | <p>0: Fieldbus Digital Input 3 inactive</p> <p>1: Fieldbus Digital Input 3 active</p> <p>Select the value CTWB14 for any input parameter to use this signal for the activation of a selected function.</p> |
| 15 | Fieldbus Digital Input 4 | <p>0: Fieldbus Digital Input 4 inactive</p> <p>1: Fieldbus Digital Input 4 active</p> <p>Select the value CTWB15 for any input parameter to use this signal for the activation of a selected function</p> |

2.2.2.3 Status Word

Table 7: iC Generic Profile Status Word Bits

| Bit | Name | Description |
|-----|--------------------|---|
| 0 | Ready To Switch On | <p>0: The drive is not ready to receive a start command because of at least 1 of the following conditions is true: Fault Active, Ramp Stop Active, Coast Stop Active, or Quick Stop Active.</p> <p>1: The drive is ready to accept a start command.</p> |
| 1 | Power Unit Ready | <p>0: The drive cannot be set running because the ready conditions of the power unit are not met. Check parameter Motor Control Start Ready Status Word (6207) for any conditions that are not met.</p> <p>1: All power unit ready conditions are met.</p> |

Table 7: iC Generic Profile Status Word Bits (continued)

| Bit | Name | Description |
|-----|-------------------------|---|
| 2 | Drive Running | 0: The drive is not running. 1: The drive is running. |
| 3 | Fault Active | 0: No active drive faults. 1: One or more drive faults are active. Switching on is inhibited. |
| 4 | – | Reserved |
| 5 | Quick Stop Active | 0: The quick stop command is inactive. A new start command is required. 1: The quick stop command is active. This command can also be given from another control source than fieldbus. |
| 6 | – | Reserved |
| 7 | Warning Active | 0: All drive warnings are inactive. 1: One or more drive warnings are active. |
| 8 | – | Reserved |
| 9 | Fieldbus Control Active | 0: Fieldbus is not the active control place. 1: Fieldbus is the active control place. |
| 10 | – | Reserved |
| 11 | Run Enabled | 0: The digital input signal <i>Run Enable Input (103)</i> is inactive, and modulation is disabled. 1: The digital input signal <i>Run Enable Input (103)</i> is active, and modulation is enabled. |
| 12 | – | Reserved |
| 13 | – | Reserved |
| 14 | – | Reserved |
| 15 | Watchdog Feedback | 0: The watchdog signal that the drive has received is low. 1: The watchdog signal that the drive has received is high. |

2.2.3 iC Hybrid

2.2.3.1 Overview

The iC Hybrid profile is used in the iC7 series with Grid Converter and DC/DC Converter applications, and with the Generator application in grid control mode.

2.2.3.2 Control Word

Table 8: Control Word Bits in iC Hybrid Profile

| Bit | Name | Description |
|-----|--------------------------|---|
| 0 | Switch On Enabled | <p>0: Pre-charging⁽¹⁾, closing the main circuit breaker⁽¹⁾, and running are prevented or interrupted. If the main circuit breaker is closed, it opens⁽¹⁾.</p> <p>1: Pre-charging⁽¹⁾, closing the main circuit breaker⁽¹⁾, and running are not prevented or interrupted.</p> |
| 1 | MCB Close Enabled | <p>0: Closing the main circuit breaker is prevented⁽¹⁾ or the main circuit breaker is opened⁽¹⁾, and running is prevented or interrupted.</p> <p>1: Closing the main circuit breaker is not prevented⁽¹⁾.</p> |
| 2 | Quick Stop | <p>0: Activate Quick Stop.</p> <p>1: Do not activate Quick Stop.</p> |
| 3 | Start | <p>0: Stop the unit if it is running, or stop the startup sequence if it is not completed.</p> <p>1: Initiate the startup sequence (DC-link pre-charging⁽²⁾, closing the main circuit breaker⁽²⁾, and start running), or keep the unit running.</p> |
| 4 | Pre-charge | <p>0: Stop the DC-link pre-charging, if ongoing.</p> <p>1: Start or continue the DC-link pre-charging.</p> |
| 5 | – | Reserved |
| 6 | – | Reserved |
| 7 | Event Reset | <p>0: No action.</p> <p>1: Reset active warnings/faults.</p> |
| 8 | – | Reserved |
| 9 | – | Reserved |
| 10 | Data Valid | <p>0: Ignore the current incoming process data values, instead use the last processed value when the Data Valid bit was true.</p> <p>1: Use the current incoming process data values. For most of the control word commands to be acknowledged by the drive or power converter, the active control place must be set to fieldbus control in parameter group Control Places in parameter group 2 Parameters.</p> |
| 11 | Watchdog | <p>Incoming watchdog bit.</p> <p>With continuous toggling between 0 and 1, this bit can be used as a sign-of-life between the drive or power converter and fieldbus controller. The value of this bit is passed through the fieldbus status word as is.</p> |
| 12 | Fieldbus Digital Input 1 | <p>0: Fieldbus Digital Input 1 inactive.</p> <p>1: Fieldbus Digital Input 1 active.</p> <p>Select the value CTWB12 for any input parameter to use this signal to activate a function.</p> |

Table 8: Control Word Bits in iC Hybrid Profile (continued)

| Bit | Name | Description |
|-----|--------------------------|---|
| 13 | Fieldbus Digital Input 2 | 0: Fieldbus Digital Input 2 inactive. 1: Fieldbus Digital Input 2 active. Select the value CTWB13 for any input parameter to use this signal to activate a function. |
| 14 | Fieldbus Digital Input 3 | 0: Fieldbus Digital Input 3 inactive. 1: Fieldbus Digital Input 3 active. Select the value CTWB14 for any input parameter to use this signal to activate a function. |
| 15 | Fieldbus Digital Input 4 | 0: Fieldbus Digital Input 4 inactive. 1: Fieldbus Digital Input 4 active. Select the value CTWB15 for any input parameter to use this signal to activate a function. |

1) If controlled by the grid converter unit.

2) If applicable.

2.2.3.3 Status Word

Table 9: Status Word Bits in iC Hybrid Profile

| Bit | Name | Description |
|-----|--------------------|--|
| 0 | Ready to Switch On | 0: Not ready to switch on. 1: Ready to switch on. |
| 1 | Ready to Run | 0: The converter is not ready to start modulation. Check Grid Control Ready Status (5096) or DC/DC Control Ready Status (6520) and Application Ready Status Word (6525) . 1: The converter is ready to start modulating. |
| 2 | Running | 0: The converter is not modulating. 1: The converter is modulating. |
| 3 | Fault | 0: No faults are active. 1: One or more faults are active. |
| 4 | – | Reserved |
| 5 | Quick Stop | 0: Quick stop active. 1: Quick stop not active. |
| 6 | – | Reserved |
| 7 | Warning | 0: No warnings active. 1: One or more warnings are active. |
| 8 | – | Reserved |
| 9 | Control by PLC | 0: The active control place is not fieldbus. 1: The active control place is fieldbus. |
| 10 | – | Reserved |

Table 9: Status Word Bits in iC Hybrid Profile (continued)

| Bit | Name | Description |
|-----|-------------------|--|
| 11 | Run Enabled | 0: Run enable from the dedicated input signal is missing. 1: Run enable from the dedicated input signal is present. |
| 12 | – | Reserved |
| 13 | – | Reserved |
| 14 | – | Reserved |
| 15 | Watchdog Feedback | 0: The watchdog signal is low. 1: The watchdog signal is high. |

2.2.4 iC Speed

2.2.4.1 Overview

The iC Speed profile is used with iC7 series Generator application software. The iC Speed profile differs from the PROFIdrive profile, because it does not have a state machine. It is only controlled by the actual state 1/0 of the control bits, not the sequence in which they are manipulated.

2.2.4.2 Control Word

Table 10: iC Speed Profile Control Word Bits

| Bit number | Name | Description |
|------------|-----------------------------------|--|
| 0 | Speed Preset Reference Selector 1 | Use these bits to select between speed presets: 00: Preset reference 1 01: Preset reference 2 10: Preset reference 3 11: Preset reference 4 |
| 1 | Speed Preset Reference selector 1 | Use these bits to select between speed presets: 00: Preset reference 1 01: Preset reference 2 10: Preset reference 3 11: Preset reference 4 |
| 2 | – | Reserved |
| 3 | Coast Stop | 0: The drive coasts to a stop. 1: The coast request is inactive. The drive can be started. |
| 4 | Quick Stop | 0: The drive stops with the Quick Stop function. 1: The Quick Stop request is inactive. The drive can be started. |
| 5 | Freeze Speed Reference | 0: The speed reference (input of the ramp generator) is frozen to its latest value. 1: The speed reference can be changed freely. |
| 6 | Start | 0: The drive stops operating with the method determined by parameter <i>Missing Start Response (4717)</i> . 1: The drive starts to operate on the rising edge of this signal. |

Table 10: iC Speed Profile Control Word Bits (continued)

| Bit number | Name | Description |
|------------|--------------------------|---|
| 7 | Event Reset | The rising edge of this signal resets events (warnings, faults, and so on), which do not have active triggering conditions. 0: Event reset inactive. 1: Event reset active. |
| 8 | – | Reserved |
| 9 | Speed Ramp | 0: Ramp 1 is active. Configure ramp in parameter group 2.4.1.2 Ramp 1 . 1: Ramp 2 is active. Configure ramp in parameter group 2.4.1.3 Ramp 2 . |
| 10 | Data Valid | 0: Ignores the current process data. Uses the previously processed data when the Data Valid bit was previously true. 1: Reads the current process data (controlled by PLC). For most of the control word commands to be acknowledged by the drive, fieldbus must be the commanding control place. See options in parameter group Control Places in parameter group 2 Parameters . |
| 11 | – | Reserved. |
| 12 | Fieldbus Digital Input 1 | 0: Fieldbus Digital Input 1 inactive 1: Fieldbus Digital Input 1 active Select the value CTWB12 for any input parameter to use this signal for the activation of a selected function. |
| 13 | Fieldbus Digital Input 2 | 0: Fieldbus Digital Input 2 inactive 1: Fieldbus Digital Input 2 active Select the value CTWB13 for any input parameter to use this signal for the activation of a selected function. |
| 14 | Fieldbus Digital Input 3 | 0: Fieldbus Digital Input 3 inactive 1: Fieldbus Digital Input 3 active Select the value CTWB14 for any input parameter to use this signal for the activation of a selected function. |
| 15 | Fieldbus Digital Input 3 | 0: Fieldbus Digital Input 4 inactive 1: Fieldbus Digital Input 4 active Select the value CTWB15 for any input parameter to use this signal for the activation of a selected function. |

2.2.4.3 Status Word

Table 11: iC Speed Profile Status Word Bits

| Bit number | Name | Description |
|------------|---------------|---|
| 0 | Control Ready | 0: The device controls are not ready and do not react to process data. 1: The device controls are ready and react to process data. |
| 1 | Drive Ready | 0: The drive is not ready for operation. 1: The drive is ready for operation. |

Table 11: iC Speed Profile Status Word Bits (continued)

| Bit number | Name | Description |
|------------|------------------|--|
| 2 | Coast | 0: There is an active coast stop command and the drive is in a coast stop state. 1: There are no active coast signals. The drive can be started. |
| 3 | Fault | 0: There are no active faults. 1: There is at least 1 active fault. The drive cannot be started before the fault condition is cleared and the fault is reset. |
| 4 | – | Reserved |
| 5 | – | Reserved |
| 6 | – | Reserved |
| 7 | Warning | 0: There are no active warnings. 1: There is at least 1 active warning. The cause of the warning should be investigated and mitigated. |
| 8 | Speed Reference | 0: Speed not at reference. The motor speed differs from the given speed reference, for example, due to ramping. 1: Speed at reference. The motor speed matches the given speed reference. |
| 9 | Fieldbus Control | 0: Fieldbus control inactive. None of the basic command functions of the drive are affected by fieldbus commands. 1: Fieldbus control active. Fieldbus is the active control place, or configured as part of the advanced control place. |
| 10 | Limiter | 0: Limiter inactive. All limiters (regulators) are inactive. 1: Limiter active. One or more limiters (regulator) are actively limiting the drive current, torque, and so on. See parameter <i>Motor Regulator Status Word (1715)</i> for further details. |
| 11 | Operation | 0: The drive is not modulating (operating). 1: The drive is modulating (operating). |
| 12 | – | Reserved |
| 13 | – | Reserved |
| 14 | – | Reserved |
| 15 | – | Reserved |

2.2.5 PROFIdrive Application Class 1

2.2.5.1 Overview

Standard telegram 1 is implemented according to PROFIdrive Application Class 1 profile as defined in the PROFIdrive standard and state machine diagram. It can be used with iC7 series Generator application software.

2.2.5.2 Control Word

Table 12: Control Word Bits in PROFIdrive Standard Telegram 1

| Bit number | Name | Description |
|------------|--------------------------|---|
| 0 | On-Off | <p>0: The drive cannot operate. A running drive is stopped with a ramp to zero speed. A resettable Switching On Inhibited state is reset.</p> <p>1: The drive is ready to operate.</p> |
| 1 | Coast Stop | <p>0: The drive coasts to a stop.</p> <p>1: The coast request is inactive. The drive can be started.</p> |
| 2 | Quick Stop | <p>0: The drive stops with the quick stop function.</p> <p>1: The quick stop request is inactive. The drive is ready to operate.</p> |
| 3 | Operation | <p>0: The drive stops operating and coasts to a stop.</p> <p>1: The drive starts to operate on the rising edge of this signal.</p> |
| 4 | Ramp Generator | <p>0: Reset ramp generator. The output of the RFG is set to 0. The drive decelerates along the current limit or along the voltage limit of the DC link.</p> <p>1: Enable ramp generator (RFG).</p> |
| 5 | Speed Reference | <p>0: Freeze speed reference. The speed reference (input of the ramp generator) is frozen to its latest value.</p> <p>1: Unfreeze speed reference. The speed reference can be changed freely.</p> |
| 6 | Reference | <p>0: Disable reference. The speed reference (ramp generator input) is forced to zero.</p> <p>1: Enable reference. The speed reference can be changed freely.</p> |
| 7 | Event Reset | <p>0: Event reset inactive.</p> <p>1: Event reset active.</p> <p>The rising edge of this signal resets events, which do not have active triggering conditions. After a fault, the drive goes to a Switching On Inhibited state, which must be acknowledged with bit 0.</p> |
| 8 | – | Reserved |
| 9 | – | Reserved |
| 10 | Fieldbus Control | <p>0: Ignores the current process data. Uses the previously processed data when the Data Valid bit was previously true.</p> <p>1: Reads the current process data (controlled by PLC).</p> <p>For most of the control word commands to be acknowledged by the drive, fieldbus must be the commanding control place. See options in parameter group Control Places in parameter group 2 Parameters.</p> |
| 11 | – | Reserved |
| 12 | Fieldbus Digital Input 1 | <p>0: Fieldbus Digital Input 1 inactive.</p> <p>1: Fieldbus Digital Input 1 active.</p> <p>Select the value CTWB12 for any input parameter to use this signal for the activation of a selected function.</p> |

Table 12: Control Word Bits in PROFIdrive Standard Telegram 1 (continued)

| Bit number | Name | Description |
|------------|--------------------------|--|
| 13 | Fieldbus Digital Input 2 | 0: Fieldbus Digital Input 2 inactive. 1: Fieldbus Digital Input 2 active. Select the value CTWB13 for any input parameter to use this signal for the activation of a selected function. |
| 14 | Fieldbus Digital Input 3 | 0: Fieldbus Digital Input 3 inactive. 1: Fieldbus Digital Input 3 active. Select the value CTWB14 for any input parameter to use this signal for the activation of a selected function. |
| 15 | Fieldbus Digital Input 4 | 0: Fieldbus Digital Input 4 inactive. 1: Fieldbus Digital Input 4 active. Select the value CTWB15 for any input parameter to use this signal for the activation of a selected function. |

2.2.5.3 Status Word

Table 13: Status Word Bits in PROFIdrive Standard Telegram 1

| Bit number | Name | Description |
|------------|------------------------|--|
| 0 | Ready to Switch On | 0: Not ready to switch on 1: Ready to switch on. Motor control is ready, no active faults and switching on (control word bit 0) is allowed. |
| 1 | Ready to Operate | 0: Not ready to be started. The drive cannot be set running with a start command. 1: Ready to be started. Control is switched on and a start command can be given. |
| 2 | Operation | 0: The drive is not running. 1: The drive is running. |
| 3 | Faults | 0: All drive faults are inactive. 1: One or more drive faults is active. Switching on is inhibited. |
| 4 | Coast Stop | 0: The Coast Stop command is active. 1: The Coast Stop command is inactive. |
| 5 | Quick Stop | 0: The Quick Stop command is active. Switching on is inhibited. The command can be given from fieldbus or IO. 1: The Quick Stop command is inactive. A new start command is required. |
| 6 | Switching On Inhibited | 0: Switching on allowed. Nothing is inhibiting the drive from being switched on (control word bit 0 can be activated). 1: Switching on inhibited due to faults or quick stop. After faults have been acknowledged or the quick stop command is removed, the Off command must be given to reset the state. |

Table 13: Status Word Bits in PROFIdrive Standard Telegram 1 (continued)

| Bit number | Name | Description |
|------------|---|--|
| 7 | Warning | 0: All drive warnings are inactive. 1: One or more warnings are active. |
| 8 | Speed Error Within/Out of Tolerance Range | 0: Speed error out of tolerance range. The actual speed differs from the speed reference more than 1% of motor nominal speed. 1: Speed error within the tolerance range. The actual speed differs from the speed reference less than 1% of motor nominal speed |
| 9 | Fieldbus Control Active/Inactive | 0: Fieldbus control inactive. None of the basic command functions of the drive are affected by fieldbus commands. 1: Fieldbus control active. Fieldbus is the active control place or configured as part of the advanced control place. |
| 10 | Speed Reached/Speed not Reached | 0: Speed not reached. The actual speed is below the comparison value set with parameter <i>Limit Supervision 1 Threshold (5253)</i> . 1: Speed reached. The actual speed is above the comparison value set with parameter <i>Limit Supervision 1 Threshold (5253)</i> . |
| 11 | – | Reserved. |
| 12 | – | Reserved. |
| 13 | – | Reserved. |
| 14 | – | Reserved. |
| 15 | – | Reserved. |

2.3 Submodules

In iC7 series, the exchange of process data values is done through submodules:

- Profile signals
- Process data input and output signals. The available signal content can be browsed in the iC7-Hybrid device description files (see [4.4 GSDML File \(Device Description File\)](#)) for further information).

Table 14: Submodule Sizes

| Application | Cyclic input data | Cyclic output data |
|--------------------------------|-------------------|----------------------------|
| iC Hybrid Profile | [STW] [MAV] | [CTW] [REF] |
| iC Generic Profile | [STW] [MAV] | [CTW] [REF] ⁽¹⁾ |
| iC Speed Profile | [STW] [MAV] | [CTW] [REF] ⁽¹⁾ |
| PROFIdrive Standard Telegram 1 | [STW] [MAV] | [CTW] [REF] ⁽¹⁾ |

1) *Fieldbus Profile (1301)*

Table 15: Signal Module Sizes

| Application | Cyclic input data | Cyclic output data |
|--|-----------------------|-----------------------|
| DC/DC Converter, Grid Converter, Generator | 4 signals (16 bytes) | 4 signals (16 bytes) |
| | 8 signals (32 bytes) | 8 signals (32 bytes) |
| | 12 signals (48 bytes) | 12 signals (48 bytes) |
| | 16 signals (64 bytes) | 16 signals (64 bytes) |
| | 20 signals (80 bytes) | 20 signals (80 bytes) |

Each of the selections in a signal module can comprise the following data types:

- Boolean
- Unsigned 8/16/32
- Signed 8/16/32
- Float32

The buffer size adapts to the data type of the selected signals. If a Boolean type is mapped, only bit 0 is used in the selected signal address, and the remaining 7 bits are not used.

The actual interpretation of the value that is read or written depends on the data type and representation. For example, motor current is a real-type 32-bit value that is represented as float, and publishing the motor current as an actual value does not need any scaling and factoring.

2.4 Functional Extension Options

Each functional extension option is defined by its own PROFINET device model with a module and submodule(s).

Slot 1 contains the application and the subsequent slots contain the installed options. Each option supports a module access point (MAP), and other submodules contain the process data.




Figure 1: Example of a PROFINET Device Model with Functional Extension Options Installed in an iC7-Hybrid Power Converter

2.5 Network Topologies

2.5.1 Overview

Communication interface X1/X2 is used for fieldbus connection.

The communication interface in the iC7 drives and power converters has 2 Ethernet ports (X1 and X2) and an embedded switch with 2 Ethernet RJ45 connectors. It has 1 MAC and IP address, and is considered a single device in the network. The communication interface supports 3 network topologies:

- Line topology

- Star topology
- Ring topology

2.5.2 Line Topology

In many applications, line topology enables simpler cabling and the use of fewer Ethernet switches. Observe network performance and the number of devices in a line topology. Too many devices in a line may exceed network update time limits.

NOTICE

When line topology is used, take precautions to avoid timeout in the PLC when more than 8 drives or power converters are installed in series. Each drive or power converter in the network adds a small delay to the communication due to the built-in Ethernet switch. When the update time is too short, the delay can lead to a timeout in the PLC.

- Set the update time as shown in the table. The numbers given are typical values and can vary from installation to installation.

| Number of units connected in series | Minimum update time [ms] |
|-------------------------------------|--------------------------|
| <8 | 2 |
| 8–16 | 4 |
| 16–32 | 8 |
| 33–50 | 16 |
| >50 | Not recommended |



NOTE: Using tools such as MyDrive® Insight may influence system performance in a line topology.




Figure 2: Example of Line Topology


NOTICE

Installing drives or power converters of different current ratings in line topology may result in unwanted power-off behavior.

- Mount the drives or power converters with the longest discharge time first in the line topology. In normal operation, the drives or power converters with bigger current ratings have a longer discharge time.

2.5.3 Star Topology

In a star network, all devices are connected to the same switch or switches. Star topology reduces the damage caused by a single cable failure. In a star topology, a single cable failure affects a single device instead of all devices in the network. In many applications, this topology enables simpler cabling depending on the location and distance of the device.



e30bk813.10

Figure 3: Example of Star Topology

2.5.4 Ring Topology

Ring topology enables the same simpler cabling and reduced cabling costs as line topology, but also reduces the damage caused by a single cable failure in a similar manner as star topology.

NOTICE

When ring topology is used, take precautions to avoid timeout in the PLC when more than 8 drives or power converters are installed in series. Each drive or power converter in the network adds a small delay to the communication due to the built-in Ethernet switch. When the update time is too short, the delay can lead to a timeout in the PLC.

- Set the update time as shown in the table. The numbers given are typical values and can vary from installation to installation.

| Number of units connected in series | Minimum update time [ms] |
|-------------------------------------|--------------------------|
| <8 | 2 |
| 8–16 | 4 |
| 16–32 | 8 |
| 33–50 | 16 |
| >50 | Not recommended |

The ring topology protocol depends on the protocol in use.

For PROFINET, the Media Redundancy Protocol (MRP) is used. The MRP is designed to react deterministically on a cable failure. One of the nodes in the network has the role of Media Redundancy Manager (MRM), which observes and controls the ring topology to react to network faults. Usually this device is a PLC or network switch.




Figure 4: Example of Ring Topology

3 Fieldbus Cable Connections

3.1 Prerequisites for Installation

Communication interfaces are integrated in the control board in iC7 drives and power converters.

The position of the connections differs based on the control board concept and frame, for example. For more information on the location of the connections, cabling, and shielding, refer to the product-specific design guide.

3.2 Installation in Frequency Converters

3.2.1 Communication Interface X1/X2 in Frames FA02–FA12

The communication interface is on the top of the frequency converter as shown in [Figure 5](#). Industrial-grade RJ45 connectors are recommended for optimal connection. A combined shield/fixing plate, the Fieldbus EMC plate, is available as an accessory to strengthen the mechanical fixation of the cables. For information on ordering the EMC plate, refer to the product-specific design guide.




Figure 5: Location of the Communication Interface, X1/X2 in FA02-FA12 Frames (with the Optional EMC Plate)

3.2.2 Communication Interface X1/X2 in Frames FB09–FB12/FK06–FK12

The communication interface ports are located inside the frequency converter. The position of the ports and the recommended wiring path are shown in [Figure 6](#) and [Figure 7](#).




Figure 6: Communication Port X0, X1, and X2 Locations in FK06–FK08 Frames




Figure 7: Communication Port X0, X1, and X2 Locations in FB09–FB12/FK09–FK12 Frames

3.3 Installation in System Modules

3.3.1 Communication Interface X1/X2 in System Modules

For systems that use system modules, the communication interface ports are located at the bottom facing side of the modular control unit as shown in [Figure 8](#).




Figure 8: Communication Port X0, X1, and X2 Locations in the Modular Control Unit

| | | | |
|---|--------------------|---|--------------------|
| 1 | Ethernet port (X0) | 2 | Ethernet port (X1) |
| 3 | Ethernet port (X2) | | |

3.4 EMC-compliant Installation

3.4.1 Overview

To obtain an EMC-compliant installation, follow the instructions provided in the product-specific design guide and the installation guide included in the shipment.

3.4.2 Grounding

- Ensure that all stations connected to the fieldbus network are connected to the same ground potential. When distances between the stations in a fieldbus network are long, connect the individual station to the same ground potential. Install equalizing cables between the system components.
- Establish a grounding connection with low HF impedance, for example, by mounting the unit on a conductive backplate.
- Keep the ground wire connections as short as possible.

3.4.3 Cable Routing

For more information on cabling, refer to the product-specific design guide and installation guide included in the shipment.

NOTICE

EMC INTERFERENCE

Failure to isolate fieldbus communication, motor, and brake resistor cables can result in unintended behavior or reduced performance.

- Use shielded cables for motor and control wiring, and separate cables for fieldbus communication, motor wiring, and brake resistor.
- A minimum of 200 mm (7.9 in) clearance between power, motor, and control cables is required. For power sizes above 315 kW (450 hp), increase the minimum distance to 500 mm (20 in).

NOTICE

CABLE ROUTING

- When the fieldbus cable intersects a motor cable or a brake resistor cable, ensure that the cables intersect at an angle of 90°.




Figure 9: Cable Routing

| | | | |
|---|--|---|------------------|
| 1 | Fieldbus cable | 2 | 90° intersection |
| 3 | ≥200 mm (7.9 in) (≥ 500 mm (20 in) for power sizes >315 kW (450 hp)) | | |

4 Configuration

4.1 Configuring Fieldbus Protection Settings

4.1.1 Fieldbus Protection Settings for DC/DC Converter

The general fieldbus settings are in parameter group *Parameters > Protections and Responses > Fieldbus Protections*.

Table 16: Fieldbus Protection Setting Parameters for DC/DC Converter

| Parameter | Parameter number | Value | Description |
|--|------------------|---|---|
| Fieldbus Fault Response | 1304 | <ul style="list-style-type: none"> No response Info Warning Warning, Current Lim. Ramp - Persistent Fault (default) See Table 17 for descriptions of the events. | Select the behavior when a fieldbus fault, for example, loss of I/O connection occurs. |
| No Fieldbus Connection Response | 1305 | <ul style="list-style-type: none"> No response (default) Info Warning Warning, Current Lim. Ramp - Persistent Fault See Table 17 for descriptions of the events. | Select the behavior if an active fieldbus connection has not been established. |
| Process Data Timeout Response | 1306 | <ul style="list-style-type: none"> No response Info (default) Warning Warning, Current Lim. Ramp - Persistent Fault See Table 17 for descriptions of the events. | Select the response if there is no fieldbus connection. |
| Process Data Timeout Time | 1340 | 0.05–18000 s (Default value: 1.00 s) | Set the timeout time. If process data is not received within the time set, a process data timeout is triggered. |
| Fieldbus Watchdog Response | 5244 | <ul style="list-style-type: none"> No response Info Warning (default) Warning, Current Lim. Ramp - Persistent Fault See Table 17 for descriptions of the events. | Select the response in case the fieldbus watchdog bit (bit 11) has not changed its value within the specific watchdog delay time. |

Table 16: Fieldbus Protection Setting Parameters for DC/DC Converter (continued)

| Parameter | Parameter number | Value | Description |
|--------------------------------------|------------------|-----------------------------------|--|
| <i>Fieldbus Watchdog Delay</i> | 5245 | 0.00–3000 s (Default: 5.00 s) | Set a delay time for after which the fieldbus watchdog event is triggered if the watchdog bit has not changed its value. |
| <i>Fieldbus Watchdog Start Delay</i> | 5246 | 0.00–3000 s (Default: 30.00 s) | Set a delay time for after which the fieldbus watchdog event is triggered if the watchdog bit has not changed its value. This time applies only immediately after powering the control unit. |

Table 17: Event Descriptions

| Value | Description |
|---|--|
| No response | The event is ignored. |
| Info | The event is logged in the event log. |
| Warning | The converter issues a warning. |
| Warning, Current Lim. Ramp - Persistent | The drive or power converter issues a warning, and the positive/negative active current limits are ramped down to preset values. The current limit overrides stay active until the warning is acknowledged by a reset. |
| Fault | A fault is issued, and the modulation is stopped. |

4.1.2 Fieldbus Protection Settings for Grid Converter

The general fieldbus settings are in parameter group *Parameters* > *Protections and Responses* > *Fieldbus Protections*.

Table 18: Fieldbus Protection Setting Parameters for Grid Converter

| Parameter | Parameter number | Value | Description |
|--|------------------|--|--|
| <i>Fieldbus Fault Response</i> | 1304 | <ul style="list-style-type: none"> • No response • Info • Warning • Warning, Current Lim. Ramp - Persistent • Fault (default) • Fault, open MCB See Table 19 for descriptions of the events. | Select the behavior when a fieldbus fault, for example, loss of I/O connection occurs. |
| <i>No Fieldbus Connection Response</i> | 1305 | <ul style="list-style-type: none"> • No response (default) • Info • Warning • Warning, Current Lim. Ramp - Persistent • Fault • Fault, open MCB See Table 19 for descriptions of the events. | Select the behavior if an active fieldbus connection has not been established. |

Table 18: Fieldbus Protection Setting Parameters for Grid Converter (continued)

| Parameter | Parameter number | Value | Description |
|--------------------------------------|------------------|---|--|
| Process Data Timeout Response | 1306 | <ul style="list-style-type: none"> No response Info (default) Warning Warning, Current Lim. Ramp - Persistent Fault Fault, open MCB See Table 19 for descriptions of the events. | Select the response if there is no fieldbus connection. |
| Process Data Timeout Time | 1340 | 0.05–18000 s (Default value: 1.00 s) | Set the timeout time. If process data is not received within the time set, a process data timeout is triggered. |
| Fieldbus Watchdog Response | 5244 | <ul style="list-style-type: none"> No response No response Warning (default) Warning, Current Lim. Ramp - Persistent Fault Fault, open MCB See Table 19 for descriptions of the events. | Select the response in case the fieldbus watchdog bit (bit 11) has not changed its value within the specific watchdog delay time. |
| Fieldbus Watchdog Delay | 5245 | 0.00–3000 s (Default: 5.00 s) | Set a delay time for after which the fieldbus watchdog event is triggered if the watchdog bit has not changed its value. |
| Fieldbus Watchdog Start Delay | 5246 | 0.00–3000 s (Default: 30.00 s) | Set a delay time for after which the fieldbus watchdog event is triggered if the watchdog bit has not changed its value. This time applies only immediately after powering the control unit. |

Table 19: Event Descriptions

| Value | Description |
|---|--|
| No response | The event is ignored. |
| Info | The event is logged in the event log. |
| Warning | The drive or power converter issues a warning. |
| Warning, Current Lim. Ramp - Persistent | The drive or power converter issues a warning, and the positive/negative active current limits are ramped down to preset values. The current limit overrides stay active until the warning is acknowledged by a reset. |
| Fault | The drive or power converter issues a fault, and the modulation is stopped. |
| Fault, open MCB | The drive or power converter issues a fault, the modulation is stopped and the MCB is opened, if controlled by the converter. |

4.1.3 Fieldbus Protection Settings for Generator

The general fieldbus settings are in parameter group *Parameters > Protections and Responses > Fieldbus Protections*.

Table 20: Fieldbus Protection Setting Parameters for Generator

| Parameter | Parameter number | Value | Description |
|--------------------------------------|------------------|---|--|
| Fieldbus Fault Response | 1303 | <ul style="list-style-type: none"> No response Info (default) Warning Fault, ramp to coast Fault, coast See Table 21 for descriptions of the events. | Select the behavior when a fieldbus fault, for example, loss of I/O connection occurs. |
| Process Data Timeout Response | 5291 | <ul style="list-style-type: none"> No response Info (default) Warning Fault, ramp to coast Fault, coast See Table 21 for descriptions of the events. | Select the response if there is no fieldbus connection. |
| Process Data Timeout Delay | 1340 | 0.05–18000 s (Default value: 1.00 s) | Set the timeout time. If process data is not received within the time set, a process data timeout is triggered. |
| Fieldbus Watchdog Response | 5244 | <ul style="list-style-type: none"> No response (default) Info Warning Fault, ramp to coast Fault, coast See Table 21 for descriptions of the events. | Select the response in case the fieldbus watchdog bit (bit 11) has not changed its value within the specific watchdog delay time. |
| Fieldbus Watchdog Delay | 5245 | 0.00–3000 s (Default: 5.00 s) | Set a delay time for after which the fieldbus watchdog event is triggered if the watchdog bit has not changed its value. |
| Fieldbus Watchdog Start Delay | 5246 | 0.00–3000 s (Default: 30.00 s) | Set a delay time for after which the fieldbus watchdog event is triggered if the watchdog bit has not changed its value. This time applies only immediately after powering the control unit. |

Table 21: Event Descriptions

| Value | Description |
|----------------------|---|
| No response | The event is ignored. |
| Info | The event is logged in the event log. |
| Warning | The drive or power converter issues a warning. |
| Fault, ramp to coast | The drive or power converter issues a fault, and ramps the motor speed to 0 before stopping modulation. |
| Fault, coast | The drive or power converter issues a fault and modulation is stopped immediately. |

4.2 Configuring the Ethernet Interface

The X1 and X2 interfaces are internally connected with an Ethernet switch and share the same physical MAC layer, and the same IP settings apply to both interfaces. IPv4 settings are configured in MyDrive® Insight or in the control panel.

1. Configure IPv4 settings.
 - In MyDrive® Insight, go to *Setup and Service* > *Interface configuration* > *Interface X1/X2* > *IPv4 settings*.
 - In the control panel, navigate to parameter group **Communication Interfaces**.

Table 22: IPv4 Settings

| Function | Value | Description |
|--------------------------------|-------------------|--|
| Interface X1/X2 MAC address | 00:1B:08:xx:xx:xx | The MAC address of interface X1/X2. The value is read-only. |
| IPv4 addressing method | Disable | Only link-local IP address in the 169.254.xxx.xxx range is active. |
| | Static IP | A static IP address is entered manually. |
| | Automatic | IP address is assigned via a DHCP or BOOTP server. |
| | DCP (default) | DCP is used with PROFINET where a PLC assigns the IP address, subnet mask, and other relevant parameters. |
| Requested IPv4 address | xxx.xxx.xxx.xxx | If Automatic is selected as the IPv4 addressing method and no DHCP/BOOTP server is present, the X1/X2 interface automatically configures an IP address and subnet mask in the 169.254.xxx.xxx range. |
| Requested IPv4 subnet mask | xxx.xxx.xxx.xxx | The requested IPv4 subnet mask for the interface. |
| Requested IPv4 gateway address | xxx.xxx.xxx.xxx | Requested IPv4 gateway address for the interface. |
| Enable ACD | Enable | Request to enable or disable Address Conflict Detection for the interface. The change does not take effect before a power cycle is performed. If no conflicts are detected, ACD activity shows 0. If an address conflict occurs, the ACD activity shows 1, and the IPv4 interface reverts to an automatically assigned IP address in the 169.254.xxx.xxx range. The recommended setting for PROFINET is Disable . |
| | Disable (default) | |
| DNS server 1, 2 | xxx.xxx.xxx.xxx | The user-requested Domain Name Server 1 for the interface (for manual IP addressing mode only). |

4.3 Configuring Name of Station

1. Navigate to parameter **Name of Station (7080)**.

| Parameter name | Parameter number | Value | Additional information |
|------------------------|------------------|--|--|
| Name of Station | 7080 | Accepted characters: <ul style="list-style-type: none"> • Lower case letters (a–z) • Numbers (0–9) • Special characters: dash (-), full stop (.) The value can be up to 127 characters or digits in total. The maximum length for each component separated by a full stop or dash is 63 characters or digits. Spaces are not allowed. | Each PROFINET device has a unique Name of Station. |

4.4 GSDML File (Device Description File)

To configure a PROFINET controller, the configuration tool needs a GSDML file for each type of device in the network. The GSDML file is a PROFINET xml file containing the necessary communication setup data for a device. Each product in the iC7 series has a unique GSDML file.

Download the GSDML files for the iC7 series from <https://www.danfoss.com/en/service-and-support/downloads/dds/fieldbus-configuration-files/>. Check that the GSDML file version is compatible with the firmware version.

4.5 Reference and Main Actual Value Handling

4.5.1 DC/DC Converter and Grid Converter

For the Grid Converter and DC/DC Converter applications, the Main Reference [REF] and Main Actual Value [MAV] are tied to the DC-link voltage of the converter. Both of these signals are interfaced as 32-bit floating point values. They are expressed in % of parameter *DC-link Nominal Voltage (2834)*.

4.5.2 Generator

In the Generator application software, the Main Reference [REF] and Main Actual Value [MAV] are tied to the motor electrical speed in Hz. Both of these signals are interfaced as 16-bit integer values. Parameters *Fieldbus Speed Scale Max (6310)*, *Fieldbus Speed Scale Min (6311)*, *Fieldbus Speed Signal Max (6312)*, and *Fieldbus Speed Signal Min (6313)* are used to scale the raw input signal for the motor speed reference [REF] to Hz, and to scale the motor electrical speed [MAV] in Hz to the raw output signal.

With the PROFIdrive profile, the scaling is automatically set for the input signal values +32767/-32768 to correspond to speed values of +199.99%/-200.00% of motor nominal speed.

Table 23: Reference and Main Actual Handling Parameters

| Parameter name | Parameter number | Default value | |
|----------------------------------|------------------|-------------------------|------------|
| | | iC Generic and iC Speed | PROFIdrive |
| <i>Fieldbus Speed Signal Max</i> | 6312 | 10000 | 32767 |
| <i>Fieldbus Speed Signal Min</i> | 6313 | -10000 | -32768 |
| <i>Fieldbus Speed Scale Max</i> | 6310 | 100.00 Hz | 2*Fnom |
| <i>Fieldbus Speed Scale Min</i> | 6311 | -100.00 Hz | -2*Fnom |

5 Parameter Access

5.1 Overview

iC7 series supports access to parameters via Base Mode Parameter Access. The data mechanism transmits requests and replies acyclically. The requests and replies are transmitted by the Acyclic Data Exchange mechanism.

For detailed instructions on how to access parameters, refer to the documentation provided by the PLC manufacturer.

5.2 PROFIdrive Parameter Numbers

PROFIdrive specifies a list of standard PNUs and maps them to the areas defined in [Table 24](#). For more details on PROFIdrive PNUs, refer to the latest version of the PROFIdrive standard.

The iC7 series supports all mandatory PNU objects and some optional and the device-specific parameter access range. The PROFIdrive parameters are not accessible via MyDrive® Insight or the control panel.

Table 24: Supported PNUs

| PNU | Description |
|---------|---|
| 922 | Telegram selection |
| 923 | List of all parameters for signals |
| 944 | Fault message counter |
| 947 | Fault number |
| 950 | Scaling of the fault buffer |
| 964 | Drive unit identification |
| 965 | Profile identification number |
| 972 | Drive reset |
| 974 | Base mode parameter access service identification |
| 975 | Drive object identification |
| 976 | Load device parameter set |
| 977 | Transfer in non-volatile memory (global) |
| 980–989 | Number list of defined parameters |
| 60000 | Velocity reference value |
| 61000 | NameOfStation (read only) |
| 61001 | IpOfStation (read only) |
| 61002 | MacOfStation (read only) |
| 61003 | DefaultGatewayOfStation (read only) |
| 61004 | SubnetMaskOfStation (read only) |

6 Troubleshooting

6.1 Diagnostics

The iC7 series supports diagnostic event messaging for control systems by using faults and warnings. The faults and warnings are enabled by default. Whenever one occurs, it is indicated on the display of a control system. If diagnosis interrupt is used by the control system, it is possible to read out the fault or warning event within the PLC program and to react accordingly.

Table 25: Diagnostics Parameters

| Parameter name | Parameter number | Value | Description |
|----------------------------|------------------|---|--|
| Diagnostics Fault | 7081 | <ul style="list-style-type: none"> Enabled (default) Disabled | Enables diagnostic fault. When disabled, the device does not send any PROFINET diagnosis message with severity Fault when a fault is present on the device. |
| Diagnostics Warning | 7083 | <ul style="list-style-type: none"> Enabled (default) Disabled | Enables diagnostic warning. When disabled, the device does not send any PROFINET diagnosis message with severity Maintenance required when a warning is present on the device. |

6.2 PROFINET Report

The PROFINET report is available in MyDrive®Insight. The report shows the current status of:

- Connections
- Configuration
- Mapped signals and their values

PROFINET Status

Name: iC7

IP: 192.168.3.2

Connections

| AR | State | Type | Count | Controller | Controller IP |
|----|---------------|--------|-------|---------------|---------------|
| 1 | Connected | Single | 8 | pn-io-simu-20 | 192.168.3.99 |
| 2 | Not connected | - | 0 | | 0.0.0.0 |
| 3 | Not connected | - | 0 | | 0.0.0.0 |
| 4 | Not connected | - | 0 | | 0.0.0.0 |

Module Configuration

| Slot | Module | Subslot | Submodule | IOPS | IOCS |
|------|-------------------------------|---------|--|------|------|
| 1 | Industry Application | 1 | Module Access Point | GOOD | GOOD |
| 1 | Industry Application | 2 | IC speed profile | GOOD | GOOD |
| 2 | Basic I/O | 1 | Module Access Point | GOOD | GOOD |
| 2 | Basic I/O | 2 | Basic I/O Relay Terminal 2 | - | - |
| 2 | Basic I/O | 3 | Basic I/O Relay Terminal 5 | - | - |
| 2 | Basic I/O | 4 | Basic I/O Digital Input Status Word | GOOD | GOOD |
| 2 | Basic I/O | 11 | Basic I/O Analog Input Terminal 33 Voltage | GOOD | GOOD |
| 3 | General Purpose I/O OC7C0 | 1 | Module Access Point | GOOD | GOOD |
| 3 | General Purpose I/O OC7C0 | 5 | General Purpose I/O Digital Output T7 | GOOD | GOOD |
| 3 | General Purpose I/O OC7C0 | 6 | General Purpose I/O Digital Output T8 | GOOD | GOOD |
| 4 | Relay OC7R0 | 1 | Module Access Point | GOOD | GOOD |
| 4 | Relay OC7R0 | 2 | Relay Terminal 2 | GOOD | GOOD |
| 4 | Relay OC7R0 | 3 | Relay Terminal 5 | GOOD | GOOD |
| 4 | Relay OC7R0 | 4 | Relay Terminal 8 | GOOD | GOOD |
| 5 | Temperature Measurement OC7T0 | 1 | Module Access Point | - | - |
| 5 | Temperature Measurement OC7T0 | 2 | Temperature Input T4 | - | - |
| 0 | Device Access Point | 1 | Device Access Point | GOOD | GOOD |
| 0 | Device Access Point | 32768 | Interface X1/X2 | GOOD | GOOD |
| 0 | Device Access Point | 32769 | Port X1 | GOOD | GOOD |
| 0 | Device Access Point | 32770 | Port X2 | GOOD | GOOD |

AR 1

Industry Application/iC speed profile Outputs

| Signal | Name | Unit | Value | Value as hex |
|--------|----------------------------|------|--------|--------------|
| 1335 | Fieldbus Control Word | - | 0x047C | 0x047C |
| 1339 | Fieldbus Speed Reference 1 | - | 8192 | 0x2000 |

Industry Application/iC speed profile Inputs

| Signal | Name | Unit | Value | Value as hex |
|--------|----------------------------------|------|--------|--------------|
| 1307 | Fieldbus Status Word | - | 0x0E07 | 0x0E07 |
| 1308 | Fieldbus Speed Main Actual Value | - | 7826 | 0x1E92 |

Basic I/O/Basic I/O Digital Input Status Word Inputs

| Signal | Name | Unit | Value | Value as hex |
|--------|----------------------|------|--------|--------------|
| 1614 | Digital Input Status | - | 0x0002 | 0x0002 |

Basic I/O/Basic I/O Analog Input Terminal 33 Voltage Inputs

| Signal | Name | Unit | Value | Value as hex |
|--------|---------------|------|-------|--------------|
| 16110 | Basic I/O T33 | - | 0 | 0x0000 |

General Purpose I/O OC7C0/General Purpose I/O Digital Output T7 Outputs

| Signal | Name | Unit | Value | Value as hex |
|--------|------------------------|------|-------|--------------|
| 16124 | General Purpose I/O T7 | - | false | 0x00 |

General Purpose I/O OC7C0/General Purpose I/O Digital Output T8 Outputs

| Signal | Name | Unit | Value | Value as hex |
|--------|------------------------|------|-------|--------------|
| 16125 | General Purpose I/O T8 | - | false | 0x00 |

Relay OC7R0/Relay Terminal 2 Outputs

| Signal | Name | Unit | Value | Value as hex |
|--------|----------|------|-------|--------------|
| 16100 | Relay T2 | - | false | 0x00 |

Relay OC7R0/Relay Terminal 5 Outputs

| Signal | Name | Unit | Value | Value as hex |
|--------|----------|------|-------|--------------|
| 16101 | Relay T5 | - | false | 0x00 |

Relay OC7R0/Relay Terminal 8 Outputs

| Signal | Name | Unit | Value | Value as hex |
|--------|----------|------|-------|--------------|
| 16102 | Relay T8 | - | false | 0x00 |

e30bk437.10

Figure 10: Example of a PROFINET Report

6.3 Configuring Port Mirroring Settings

Enable or disable the port mirroring function for network troubleshooting with a network analyzer tool.

1. In MyDrive® Insight, go to *Setup and Service > Interface Configuration > Port Mirroring Settings*.


Table 26: Port Mirroring Settings

| Function | Selections | Description |
|--------------------------------|--|--|
| Source port | <ul style="list-style-type: none"> • X1 • X2 | Frames are mirrored from this port. |
| Destination port | <ul style="list-style-type: none"> • X1 • X2 | Frames are mirrored to this port. |
| Block RX from destination port | Enable/Disable | Device does not receive any frames from Destination Port when enabled. |
| Enable port mirroring | Enable/Disable | Enables the Port Mirroring feature. |

6.4 Identifying a Unit

The winking function makes the fieldbus indicator LEDs ST, X1, and X2 flash yellow to make it easy to identify a unit. The function is enabled in MyDrive® Insight.

1. In MyDrive® Insight, click the device name in live mode.
2. Select *Device Status*.
3. To activate or deactivate the feature, click the toggle switch.



See [6.5 Fieldbus Indicator LEDs](#) for more information on interpreting the LED signals and where the LEDs are located.

6.5 Fieldbus Indicator LEDs

The fieldbus indicator LEDs are in the top right corner of the control panel and the bottom part of the front-facing side of the modular control unit.





Figure 11: Fieldbus Indicator LEDs on Control Panel



1 Fieldbus indicator LEDs (ST, X1, and X2)

Figure 12: Fieldbus Indicator LEDs on Modular Control Board

- The LED labeled ST shows the module status.
- The LED labeled X1 shows the network status on Ethernet port X1.
- The LED labeled X2 shows the network status on Ethernet port X2.

Table 27: Fieldbus Indicator LED Functions

| LED label | Status | LED pattern | Description |
|-----------|---|-----------------|---|
| ST | DCP blink | Flashing yellow | PROFINET discovery protocol active, 3 s flashing. |
| | Not configured | Off | PROFINET not configured. |
| | IO connection faulted | Steady red | A PROFINET IO connection has faulted. |
| | Configuration mismatch | Flashing red | PROFINET configuration mismatch. |
| | Configured/No IO connection | Flashing green | Device is configured from PLC master but no IO connection has been established. |
| | All IO connections OK | Solid green | PROFINET IO connection to device established. |
| X1/X2 | DCP blink | Flashing yellow | PROFINET discovery protocol active, 3 s flashing. |
| | Link down | Off | – |
| | Invalid configuration/Duplicated IP address | Solid red | IP configuration error |
| | Link up | Solid green | Ethernet link is active. |

Danfoss Drives Oy
Runsorintie 7
FIN-65380 Vaasa
drives.danfoss.com

.....
Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalog descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogs, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product. All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.
.....

172K4283B

