



VLT® AutomationDrive FC 301/FC 302

Software versions 10.00 and 49.1x



Contents

1 Introduction

1.1 Purpose of the Programming Guide	15
1.2 Supported Software Versions	15
1.3 Document Version	15
1.4 Type Approvals and Certifications	15
1.5 Integrated Motion Controller	16

2 Safety

2.1 Safety Symbols	17
2.2 Safety Precautions	17
2.3 Protection Mode	19

3 Electrical Wiring

3.1 Wiring Diagram	20
3.2 Input Polarity of Control Terminals	21
3.3 Grounding of Shielded/Armored Cables	22

4 Other Wiring Examples

4.1 Start/Stop	23
4.2 Pulse Start/Stop	23
4.3 Speed Up/Down	24
4.4 Potentiometer Reference	25

5 How to Program

5.1 The Graphical Local Control Panel	26
5.1.1 Overview of the LCP	26
5.1.2 LCD Display	27
5.1.3 LCP Keys	28
5.1.4 Quick Transfer of Parameter Settings between Multiple Drives	29
5.1.5 Transferring Data	29
5.1.5.1 Transferring Data from the Drive to the LCP	29
5.1.5.2 Transferring Data from the LCP to the Drive	30
5.1.6 Display Mode	30
5.1.7 Display Mode - Selection of Readouts	30

5.1.8	Status Views	32
5.1.8.1	Status View I	32
5.1.8.2	Status View II	33
5.1.8.3	Status View III	33
5.1.9	Parameter Setup	33
5.1.10	Quick Menu Key Functions	34
5.1.11	Initial Commissioning	35
5.1.12	Main Menu Mode	37
5.1.13	Parameter Selection	37
5.1.14	Changing Data	37
5.1.15	Changing a Text Value	37
5.1.16	Changing a Data Value	38
5.1.17	Infinitely Variable Change of Numeric Data Value	38
5.1.18	Value, Step by Step	39
5.1.19	Readout and Programming of Indexed Parameters	39
5.1.20	Changing Values of Indexed Parameters	39
5.2	The Numerical Control Panel	40
5.2.1	Overview of the Numerical LCP	40
5.2.2	LCP Keys, Numerical LCP	40
5.3	Restoring Factory Default Settings	42
5.3.1	Restoring Factory Default Settings Using the Recommended Initialization	42
5.3.2	Restoring Factory Default Settings Using Manual Initialization	43
5.3.3	Resetting all Parameters	43

6 Parameter Descriptions

6.1	Selecting Parameters	45
6.2	Parameter Group 0-** Operation and Display	45
6.2.1	Introduction to Parameter Group 0-** Operation and Display	45
6.2.2	0-0* Basic Settings	45
6.2.3	0-1* Set-up Operations	47
6.2.4	0-2* LCP Display	51
6.2.5	0-3* LCP Custom Readout	60
6.2.6	0-4* LCP Keypad	65
6.2.7	0-5* Copy/Save	67
6.2.8	0-6* Password	68
6.2.9	0-7* Clock Settings	70

6.2.10 0-9* Varia	74
6.3 Parameter Group 1-** Load and Motor	76
6.3.1 1-0* General Settings	76
6.3.2 Motor Setups	83
6.3.2.1 Induction Motor Setup	83
6.3.2.2 PM Motor Setup	84
6.3.2.3 Programming of Permanent Magnet Motors	84
6.3.2.4 SynRM Motor Setup with VVC+	86
6.3.2.5 Programming of SynRM Motors	86
6.3.3 1-1* Special Settings	87
6.3.4 1-2* Motor Data	89
6.3.5 1-3* Adv. Motor Data	96
6.3.6 1-5* Load Indep. Setting	103
6.3.7 1-6* Load Depend. Setting	108
6.3.8 1-7* Start Adjustments	111
6.3.9 1-8* Stop Adjustments	115
6.3.10 1-9* Motor Temperature	119
6.3.10.1 Connections Related to Motor Temperature Control	124
6.4 Parameter Group 2-** Brakes	128
6.4.1 2-0* DC Brakes	128
6.4.2 2-1* Brake Energy Funct.	130
6.4.3 2-2* Mechanical Brake	134
6.4.4 Hoist Mechanical Brake	137
6.4.5 2-3* Adv. Mech. Brake	138
6.5 Parameter Group 3-** Reference/Ramps	139
6.5.1 3-0* Reference Limits	139
6.5.2 3-1* References	144
6.5.3 3-2* References II	152
6.5.4 3-3* Gen Ramp & Sync	155
6.5.5 3-4* Ramp 1	159
6.5.6 3-5* Ramp 2	163
6.5.7 3-6* Ramp 3	166
6.5.8 3-7* Ramp 4	169
6.5.9 3-8* Other Ramps	172
6.5.10 3-9* Digital Pot.Meter	174
6.6 Parameter Group 4-** Limits/Warnings	176

6.6.1 4-1* Motor Limits	176
6.6.2 4-2* Limit Factors	178
6.6.3 4-3* Motor Feedback Monitoring	181
6.6.4 4-4* Speed Monitor	184
6.6.5 4-5* Adjustable Warnings	186
6.6.6 4-6* Speed Bypass	190
6.6.7 4-7* Position Monitor	191
6.6.8 4-8* Power Limit	194
6.6.9 4-9* Directional Limits	196
6.7 Parameter Group 5-** Digital In/Out	197
6.7.1 5-0* Digital I/O Mode	197
6.7.2 5-1* Digital Inputs	198
6.7.3 5-3* Digital Outputs	231
6.7.4 5-4* Relays	248
6.7.5 5-5* Pulse Input	257
6.7.6 5-6* Pulse Outputs	259
6.7.7 5-7* 24 V Encoder Input	264
6.7.8 5-8* I/O Options	268
6.7.9 5-9* Bus-controlled	269
6.8 Parameter Group 6-** Analog In/Out	271
6.8.1 6-0* Analog I/O Mode	271
6.8.2 6-1* Analog Input 1	272
6.8.3 6-2* Analog Input 2	274
6.8.4 6-3* Analog Input 3 General Purpose I/O MCB 101	276
6.8.5 6-4* Analog Input X30/12	277
6.8.6 6-5* Analog Output 1	278
6.8.7 6-6* Analog Output 2 MCB 101	282
6.8.8 6-7* Analog Output 3 MCB 113	285
6.8.9 6-8* Analog Output 4 MCB 113	288
6.9 Parameter Group 7-** Controllers	291
6.9.1 Speed PID Droop	291
6.9.2 Speed Trim	293
6.9.3 7-0* Speed PID Ctrl.	294
6.9.4 7-1* Torque PI Control	298
6.9.5 7-2* Process Ctrl. Feedb.	300

6.9.6	7-3* Process PID Ctrl.	301
6.9.7	7-4* Advanced Process PID Ctrl.	303
6.9.8	7-5* Ext. Process PID Ctrl.	305
6.9.9	7-7* Speed PID Ctrl. II	307
6.9.10	7-9* Position PI Ctrl.	308
6.10	Parameter Group 8-** Communications and Options	311
6.10.1	8-0* General Settings	311
6.10.2	8-1* Ctrl. Word Settings	315
6.10.3	8-2* Counters	328
6.10.4	8-3* FC Port Settings	328
6.10.5	8-4* FC MC Protocol Select	330
6.10.6	8-5* Digital/Bus	342
6.10.7	8-8* FC Port Diagnostics	346
6.10.8	8-9* Bus Jog	346
6.11	Parameter Group 9-** PROFIBUS	347
6.12	Parameter Group 10-** CAN Fieldbus	371
6.12.1	10-0* Common Settings	371
6.12.2	10-1* DeviceNet	372
6.12.3	10-2* COS Filters	382
6.12.4	10-3* Parameter Access	383
6.12.5	10-5* CANopen	384
6.13	Parameter Group 12-** Ethernet	392
6.13.1	12-0* IP Settings	392
6.13.2	12-1* Ethernet Link Parameters	394
6.13.3	12-2* Process Data	395
6.13.4	12-3* EtherNet/IP	404
6.13.5	12-4* Modbus TCP	406
6.13.6	12-4* Fieldbus Extension	407
6.13.7	12-5* EtherCAT	407
6.13.8	12-6* Ethernet POWERLINK	409
6.13.9	12-8* Other Ethernet Services	410
6.13.10	12-9* Advanced Ethernet Services	412
6.14	Parameter Group 13-** Smart Logic Control	415
6.14.1	Introduction to Smart Logic Control	415
6.14.2	13-0* SLC Settings	417

6.14.3	13-1* Comparators	424
6.14.4	13-1* RS Flip Flops	432
6.14.5	13-2* Timers	441
6.14.6	13-4* Logic Rules	441
6.14.7	13-5* States	455
6.14.8	13-9* User-defined Alerts and Readouts	486
6.15	Parameter Group 14-** Special Functions	491
6.15.1	14-0* Inverter Switching	491
6.15.2	14-1* Mains On/Off	494
6.15.3	14-2* Trip Reset	501
6.15.4	14-3* Current Limit Control	504
6.15.5	14-4* Energy Optimizing	507
6.15.6	14-5* Environment	509
6.15.7	14-6* Auto Derate	514
6.15.8	14-7* Compatibility	516
6.15.9	14-8* Options	517
6.15.10	14-9* Fault Settings	518
6.16	Parameter Group 15-** Drive Information	520
6.16.1	15-0* Operating Data	520
6.16.2	15-1* Data Log Settings	522
6.16.3	Service Log	529
6.16.4	Clearing the Service Log	530
6.16.5	Service Log Indication	531
6.16.6	Alarms that Trigger a Service Log Record	531
6.16.7	15-2* Historic Log	532
6.16.8	15-3* Alarm Log	534
6.16.9	15-4* Drive Identification	535
6.16.10	15-6* Option Ident.	537
6.16.11	15-8* Operating Data II	539
6.16.12	15-9* Parameter Info	541
6.17	Parameter Group 16-** Data Readouts	542
6.17.1	16-0* General Status	542
6.17.2	16-1* Motor Status	544
6.17.3	16-3* Drive Status	547
6.17.4	16-5* Ref. & Feedb.	550

6.17.5	16-6* Inputs and Outputs	551
6.17.6	16-8* Fieldbus & FC Port	556
6.17.7	16-9* Diagnosis Readouts	558
6.18	Parameter Group 17-** Feedback	561
6.18.1	17-0* Encoder Interface	561
6.18.2	17-1* Inc. Enc. Interface	562
6.18.3	17-2* Abs. Enc. Interface	563
6.18.4	17-4* Fieldbus Reference 2	565
6.18.5	17-5* Resolver Interface	566
6.18.6	17-6* Monitoring and Application	568
6.18.7	17-7* Position Scaling	569
6.18.8	17-8* Position Homing	574
6.18.9	17-9* Position Configuration	580
6.19	Parameter Group 18-** Data Readouts 2	584
6.19.1	18-0* Maintenance Log	584
6.19.2	18-1* Emergency Mode Log	586
6.19.3	18-1* Parameter Log	586
6.19.4	18-2* Motor Readouts	587
6.19.5	18-3* Analog Readouts	589
6.19.6	18-4* PGIO Data Readouts	590
6.19.7	18-4* Last Warning	592
6.19.8	18-5* Active Alarms/Warnings	592
6.19.9	18-6* Inputs & Outputs 2	592
6.19.10	18-6* Motor Status 2	593
6.19.11	18-6* Diagnosis Readout 2	593
6.19.12	18-7* Rectifier Status	594
6.19.13	18-8* General Status	597
6.19.14	18-9* PID Readouts	597
6.20	Parameter Group 19-** Application Parameters	599
6.21	Parameter Group 22-** Appl. Functions	599
6.21.1	22-0* Miscellaneous	599
6.22	Parameter Group 23-** Time-based Functions	599
6.22.1	23-0* Timed Actions	599
6.22.2	23-0* Timed Actions Settings	607
6.22.3	23-1* Maintenance	608

6.22.4 23-1* Maintenance Reset	611
6.23 Parameter Group 24-** Application Functions 2	612
6.23.1 24-0* Emergency Mode	612
6.23.2 24-4* Emergency Mode 2	620
6.23.3 24-5* Digi CAM Switch A	622
6.23.4 24-6* Digi. CAM Switch B	624
6.23.5 24-7* Anti-sway Ramp	626
6.24 Parameter Group 30-** Special Features	627
6.24.1 30-0* Wobble Function	627
6.24.2 30-2* Adv. Start Adjust	631
6.24.3 30-2* Light Load Detection	632
6.24.4 30-5* Unit Configuration	633
6.24.5 30-7* Power Low Monitor Protection	633
6.24.6 30-8* Compatibility (I)	634
6.25 Parameter Group 31-** Bypass Option	636
6.26 Parameter Group 32-** MCO Basic Settings	637
6.27 32-0* Encoder 2	637
6.28 32-3* Encoder 1	641
6.29 32-5* Feedback Source	644
6.30 32-6* PID Controller	645
6.31 32-8* Velocity & Accel.	648
6.32 Parameter Group 33-** MCO Adv. Settings	650
6.32.1 33-0* Home Motion	650
6.32.2 33-1* Synchronization	651
6.32.3 33-4* Limit Handling	655
6.32.4 33-5* I/O Configuration	657
6.32.5 33-8* Global Parameters	667
6.32.6 33-9* MCO Port Settings	669
6.33 Parameter Group 34-** MCO Data Readouts	671
6.33.1 34-0* PCD Write Par.	671
6.33.2 34-2* PCD Read Par.	672
6.33.3 34-4* Inputs & Outputs	674
6.33.4 34-5* Process Data	674
6.33.5 34-7* Diagnosis Readouts	676
6.34 Parameter Group 35-** Sensor Input Option	677

6.34.1	35-0* Temp. Input Mode	677
6.34.2	35-1* Temp. Input X48/4	679
6.34.3	35-2* Temp. Input X48/7	680
6.34.4	35-3* Temp. Input X48/10	681
6.34.5	35-4* Analog Input X48/2	681
6.35	Parameter Group 36-** Programmable I/O Option	683
6.35.1	36-0* I/O Mode	683
6.35.2	36-1* Analog Input X49/1	685
6.35.3	36-2* Analog Input X49/3	686
6.35.4	36-3* Analog Input X49/5	688
6.35.5	36-4* Output X49/7	689
6.35.6	36-5* Output X49/9	695
6.35.7	36-6* Output X49/11	701
6.36	Parameter Group 40-** Special Settings	708
6.36.1	40-1* Aux. Functions Control	708
6.36.2	40-2* PM Motor Specific	709
6.36.3	40-3* Fieldbus Profile	710
6.36.4	40-4* Extend. Fault Log	712
6.36.5	40-5* Advanced Control Settings	714
6.37	Parameter Group 42-** Safety Functions	716
6.37.1	Introduction to Safety Functions	716
6.37.2	42-0* Speed Performance	716
6.37.3	42-1* Speed Monitoring	717
6.37.4	42-2* Safe Input	719
6.37.5	42-3* General	720
6.37.6	42-4* SS1	721
6.37.7	42-5* SLS	723
6.37.8	42-6* Safe Fieldbus	724
6.37.9	42-7* SMS	725
6.37.10	42-8* Status	725
6.37.11	42-9* Special	727
6.38	Parameter Group 43-** Unit Readouts	727
6.38.1	Purpose of the Parameter Group	727
6.38.2	43-0* Component Status	727
6.38.3	43-1* Power Card Status	728

6.38.4	43-2* Fan Pow.Card Status	730
6.38.5	43-3* Warning Log	731
6.39	Parameter Group 44-** Motor Protection	734
6.39.1	44-2* Check Motor	734
6.40	Parameter Group 45-** Condition Based Monitoring	734
6.40.1	45-0* Cockpit: Monitor	734
6.40.2	45-1* Cockpit: Actl Status	739
6.40.3	45-2* Baseline Settings	742
6.40.4	45-3* Threshold Config.	745
6.40.5	45-4* Threshold Generation	751
6.40.6	45-5* Sensor Config.	752
6.40.7	45-6* Stator Res. Setting	753
6.40.8	45-8* Cavitation Config.	755
6.40.9	45-9* Actual Readouts	756
6.41	Parameter Group 46-** CBM Adv. Thresholds	757
6.41.1	46-0* History	757
6.41.2	46-0* General	758
6.41.3	46-1* Timing	758
6.41.4	46-2* Stator	760
6.41.5	46-3* Load	761
6.41.6	46-4* Sensor 1	763
6.41.7	46-5* Sensor 2	764
6.41.8	46-6* Sensor 3	765
6.41.9	46-7* Sensor 4	766
6.41.10	46-8* Cavitation	767
6.42	Parameter Group 47-** CBM Baseline Data	767
6.42.1	47-0* History	767
6.42.2	47-0* Speeds	768
6.42.3	47-0* Stator	768
6.42.4	47-1* Stator Res. Active	770
6.42.5	47-2* Stator Res. Load	771
6.42.6	47-3* Load	773
6.42.7	47-4* Sensor 1	775
6.42.8	47-5* Sensor 2	776
6.42.9	47-6* Sensor 3	778

6.42.10 47-7* Sensor 4	780
6.42.11 47-8* Cavitation	781
6.42.12 47-9* Min Max Speed	783
6.43 Parameter Group 48-** CBM Applications	784
6.43.1 48-0* Cavitation Control	784
6.44 Parameter Group 49-** CBM-SWF	787
6.44.1 49-0* Cockpit: Monitoring	787
6.44.2 49-1* Baseline Settings	791
6.44.3 49-2* Threshold Config.	795
6.44.4 49-3* Adv Monitoring Readouts 1	796
6.45 Parameter Group 50-** License	797
6.46 Parameter Group 600-** PROFIsafe	798
6.47 Parameter Group 601-** PROFIdrive 2	798

7 Features of the Integrated Motion Controller

7.1 Introduction to IMC	799
7.2 Positioning, Homing, and Synchronization	799
7.2.1 Positioning	799
7.2.2 Homing	800
7.2.3 Synchronization	800
7.2.4 Fieldbus References	801
7.3 Control	802
7.3.1 Control Loops	802
7.3.2 Control and Status Signals	802

8 Troubleshooting

8.1 Status Messages	806
8.1.1 Warnings and Alarms	806
8.1.2 Warning/Alarm Code List	806
8.1.3 Indicator Light	823
8.1.4 Alarm Word, Warning Word, and Extended Status Word	823
8.2 Descriptions of Warnings and Alarms	828

1 Introduction

1.1 Purpose of the Programming Guide

This programming guide provides information required for setting up parameters in a drive. The guide contains the following main areas:

- How to use the local control panel (LCP)
- Detailed descriptions of all parameters
- Troubleshooting

1.2 Supported Software Versions

Supported software versions: 10.00 and 49.10

This programming guide can be used for all FC 301 and FC 302 drives, and for VLT® Decentral Drive FCD 302.

The software version number can be read from parameter **15-43 Software Version**.

1.3 Document Version

This guide is regularly reviewed and updated. All suggestions for improvement are welcome.

The original language of this guide is in English.

Version	Remarks	Software Version
AU275636650261, version 33	Update to new software version including cybersecurity	FC 301/FC 302: 10.00 IMC: 49.10

1.4 Type Approvals and Certifications

The following table shows examples of possible type approvals and certifications for Danfoss drives.

NOTICE		
Drives of enclosure size T7 (525–690 V) are not UL listed.		

Table 1: Type Approvals and Certifications

Table 1: Type Approvals and Certifications - (continued)

NOTICE

The specific approvals and certification for the drive are on the nameplate of the drive. For more information, contact the local Danfoss office or partner.

For more information on UL 508C thermal memory retention requirements, refer to the section Motor Thermal Protection in the product-specific design guide.

For more information on compliance with the European Agreement concerning International Carriage of Dangerous Goods by Inland Waterways (AND), refer to the section AND-compliant Installation in the product-specific design guide.

1.5 Integrated Motion Controller

The integrated motion controller (IMC) enables position control. For more information, refer to the chapter *Features of the Integrated Motion Controller*.

2 Safety

2.1 Safety Symbols

The following symbols are used in Danfoss documentation and products.

 DANGER
Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

 WARNING
Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

 CAUTION
Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE
Indicates information considered important, but not hazard-related (for example, messages relating to property damage).

	ISO warning symbol for general warnings
	ISO warning symbol for hot surfaces and burn hazard
	ISO warning symbol for high voltage and electric shock
	Symbol for indicating the required discharge time of the capacitors in the product.
	ISO action symbol for referring to the instructions

2.2 Safety Precautions

 WARNING
LACK OF SAFETY AWARENESS This guide provides important information on preventing injury and damage to the equipment or the system. Ignoring this information can lead to death, serious injury, or severe damage to the equipment. • Make sure to fully understand the dangers and safety measures present in the application. • Before performing any electrical work on the drive, lock out and tag out all power sources to the drive.

 WARNING



HAZARDOUS VOLTAGE

Drives contain hazardous voltage when connected to the AC mains or connected on the DC terminals. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.

 WARNING

UNINTENDED START

When the drive is connected to AC mains, DC supply, or load sharing, the motor may start at any time. The motor may start by activation of an external switch, a fieldbus command, an input reference signal from the LCP or LOP, via remote operation using MCT 10 Set-up software, or after a cleared fault condition. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage.

- Disconnect the drive from the mains.
- Press *[Off/Reset]* on the LCP before programming parameters.
- Ensure that the drive is fully wired and assembled when it is connected to AC mains, DC supply, or load sharing.

 WARNING



DISCHARGE TIME

The drive contains DC-link capacitors, which can remain charged even when the drive is not powered. High voltage can be present even when the warning indicator lights are off.

Failure to wait the specified time after power has been removed before performing service or repair work could result in death or serious injury.

- Stop the motor.
- Disconnect AC mains, permanent magnet type motors, and remote DC-link supplies, including battery backups, UPS, and DC-link connections to other drives.
- Wait for the capacitors to discharge fully before performing any service or repair work. The discharge time is specified on the drive product label.
- Use a measuring device to make sure that there is no voltage before opening the drive or performing any work on the cables.

NOTICE

USING THE SAFE TORQUE OFF

When using the Safe Torque Off, always follow the instructions in the VLT® Frequency Converters - Safe Torque Off Operating Guide.

NOTICE

CONTROL SIGNALS

Control signals from, or internally within, the drive may in rare cases be activated in error, be delayed, or fail to occur entirely. When used in situations where safety is critical, for example, when controlling the electromagnetic brake function of a hoist application, do not rely on these control signals exclusively.

NOTICE

HAZARDOUS SITUATIONS

Hazardous situations must be identified by the machine builder/integrator who is responsible for considering the necessary preventive means. More monitoring and protective devices may be included, always according to valid national safety regulations, for example, law on mechanical tools and regulations for the prevention of accidents.

2.3 Protection Mode

Once a hardware limit on motor current or DC-link voltage is exceeded, the drive enters protection mode. Protection mode means a change of the PWM modulation strategy and a low switching frequency to minimize losses. This continues for 10 s after the last fault and increases the reliability and robustness of the drive while re-establishing full control of the motor.

The following situations cause the drive to enter protection mode:

- Undervoltage, the voltage has dropped below the low limit.
- Overvoltage, the voltage has exceeded the upper limit. Protection mode can be avoided by activating overvoltage control in parameter **2-17 Overvoltage Control**. However, activating overvoltage control extends the ramp times.
- Overcurrent, the current has exceeded the limit defined in parameter **4-18 Current Limit**.
- Ground fault, a ground fault has appeared.

To remove protection mode, set parameter **14-26 Trip Delay at Inverter Fault** to 0.

3 Electrical Wiring

3.1 Wiring Diagram




Figure 1: Wiring Diagram

A=Analog, D=Digital

1) Do not connect cable shield.

Terminal 37 is used for Safe Torque Off (STO). For STO installation instructions, refer to the VLT® Frequency Converters - Safe Torque Off Operating Guide.

Long control cables and analog signals may in rare cases, depending on installation, result in 50/60 Hz ground loops due to noise from mains supply cables. If 50/60 Hz ground loops occur, consider breaking the shield or insert a 100 nF capacitor between shield and enclosure.

To avoid ground currents from both groups to affect other groups, connect the digital and analog inputs and outputs separately to the common inputs (terminals 20, 55, and 39) of the drive. For example, switching on the digital input may disturb the analog input signal.

3.2 Input Polarity of Control Terminals

NOTICE

Control cables must be shielded.




Figure 2: PNP (Source)




Figure 3: NPN (Sink)

3.3 Grounding of Shielded/Armored Cables

See the section *Grounding* in the design guide for the correct termination of control cables.




Figure 4: Grounding of Shielded/Armored Cables

4 Other Wiring Examples

4.1 Start/Stop

Terminal 18 = Parameter 5-10 **Terminal 18 Digital Input, [8] Start**.

Terminal 27 = Parameter 5-12 **Terminal 27 Digital Input, [0] No Operation** (default [2] **Coast inverse**).

Terminal 37 = Safe Torque Off (where available).





Figure 5: Start/Stop

4.2 Pulse Start/Stop

Terminal 18 = Parameter 5-10 **Terminal 18 Digital Input, [9] Latched start**.

Terminal 27 = Parameter 5-12 **Terminal 27 Digital Input, [6] Stop inverse**.

Terminal 37 = Safe Torque Off (where available).




Figure 6: Pulse Start/Stop

4.3 Speed Up/Down

Terminals 29/32 = Speed up/down

Terminal 18 = Parameter 5-10 Terminal 18 Digital Input, [9] Start (default).

Terminal 27 = Parameter 5-12 Terminal 27 Digital Input, [19] Freeze reference.

Terminal 29 = Parameter 5-13 Terminal 29 Digital Input, [21] Speed up

Terminal 32 = Parameter 5-14 Terminal 32 Digital Input, [22] Speed down




Figure 7: Speed Up/Down

4.4 Potentiometer Reference

Voltage reference via a potentiometer

Reference source 1= [1] *Analog input 53* (default).

Terminal 53, Low Voltage = 0 V.

Terminal 53, High Voltage = 10 V.

Terminal 53, Low Ref./Feedback = 0 RPM.

Terminal 53, High Ref./Feedback = 1500 RPM.

Switch S201 = OFF (U).




Figure 8: Potentiometer Reference

5 How to Program

5.1 The Graphical Local Control Panel

5.1.1 Overview of the LCP

Easily program the drive via the local control panel (LCP).




Figure 9: The LCP

1	Graphical display with status lines.	2	Menu keys and indicator lights - changing parameters and switching between display functions.
3	Navigation keys and indicator lights.	4	Operation keys and indicator lights.
a	Status line: Status message showing icons and graphics.	b	Line 1–2: Operator data lines showing data defined or selected. Add up to 1 extra line by pressing [Status].
c	Status line: Status messages showing text.		

The LCP display can show up to 5 items of operating data while showing *Status*.



NOTE: If start-up is delayed, the LCP shows the INITIALIZING message until it is ready. Adding or removing options can delay the start-up.

5.1.2 LCD Display

The display has backlight and a total of 6 alpha-numeric lines. The display lines show the direction of rotation (arrow), the selected setup, and the programming setup. The display is divided into 3 sections.

Top section

The top section shows up to 2 measurements in normal operating status.



NOTE: The EM-x number in the middle of the top line indicates the active setup in parameter groups **24-0x Emergency Mode** and **24-4x Emergency Mode 2**. The active emergency mode setup can also be read in parameter **0-17 Active Emergency Setup**.

Middle section

The top line shows up to 5 measurements with related unit, regardless of status (except in the case of alarm/warning).

Bottom section

The bottom section always shows the state of the drive in *Status* mode.




Figure 10: Overview of the Display

The active setup (selected as the active setup in parameter **0-10 Active Set-up**) is shown. When programming another setup than the active setup, the number of the programmed setup appears to the right.

Display contrast adjustment

Press [Status] and [▲] for darker display.

Press [Status] and [▼] for brighter display.

Most parameter setups can be changed immediately via the LCP, unless a password has been created via parameter **0-60 Main Menu Password** or via parameter **0-65 Quick Menu Password**.

Indicator lights

If certain threshold values are exceeded, the alarm and/or warning indicator lights up, A status and alarm text appear on the LCP. The ON indicator light is activated when the drive receives mains voltage, via a DC bus terminal, or 24 V external supply. At the same time, the back indicator light is on.

- Green LED/On: Control section is working.
- Yellow LED/Warn.: Indicates a warning.
- Flashing Red LED/Alarm: Indicates an alarm.




Figure 11: Indicator Lights

5.1.3 LCP Keys

Control keys

The control keys are divided into functions. The keys below the display and indicator lights are used for parameter setup, including option of display indication during normal operation.

Table 2: LCP Keys and Description

LCP keys	Description
[Status]	Indicates the status of the drive and/or the motor. Select between 3 different readouts by pressing [Status]: 5 line readouts, 4 line readouts, or smart logic control. Press [Status] for selecting the mode of display or for changing back to display mode from either the quick menu mode, the main menu mode, or the alarm mode. Also use [Status] to toggle single or double readout mode.
[Quick Menu]	Allows quick access to different quick menus such as: • My personal menu • Quick set-up • SmartStart • Changes made • Loggings Press [Quick Menu] to program the parameters belonging to the Quick Menu. It is possible to switch directly between quick menu mode and main menu mode.
[Main Menu]	Use the main menu for programming all parameters. It is possible to switch directly between main menu mode and quick menu mode. Parameter shortcut can be carried out by pressing down [Main Menu] for 3 s. The parameter shortcut allows direct access to any parameter.
[Alarm Log]	Shows an alarm list of the 5 latest alarms (numbered A1–A5). To obtain more details about an alarm, press the navigation keys to maneuver to the alarm number and press [OK]. Information about the condition of the drive before it enters the alarm mode is shown.
[Back]	Returns to the previous step or layer in the navigation structure.
[Cancel]	Last change or command is canceled as long as the display has not been changed.
[Info]	Supplies information about a command, parameter, or function in any display window. [Info] provides detailed information whenever help is needed. Exit info mode by pressing either [Info], [Back], or [Cancel].
Navigation keys	The 4 navigation keys are used to navigate between the different options available in Quick Menu, Main Menu, and Alarm Log. Press the keys to move the cursor.
[OK]	Press to select a parameter marked by the cursor and to enable the change of a parameter.

Local control keys

Local control keys are at the bottom of the control panel.

Table 3: Local Control Keys and Description

LCP keys	Description
[Hand On]	Enables control of the drive via the LCP. [Hand On] also starts the motor, and it is now possible to enter the motor speed data with the navigation keys. The key can be selected as [1] Enable or [0] Disable via parameter 0-40 [Hand On] Key on LCP. External stop signals activated with control signals or a fieldbus override a start command via the LCP. The following control signals are still active when [Hand On] is activated: • [Hand On] - [Off] - [Auto On] • Reset • Coast stop inverse • Setup select bit 0 - Setup select bit 1 • Stop command from serial communication • Quick stop • DC brake
[Off]	Stops the connected motor. The key can be selected as [1] Enable or [0] Disable via parameter 0-41 [Off] Key on LCP. If the external stop function is not selected and the [Off] key is inactive, the motor can be stopped by disconnecting the voltage.
[Auto On]	Enables the drive to be controlled via the control terminals and/or installed communication ports. When a start signal is applied on the control terminals and/or the bus, the drive starts. The key can be selected as [1] Enable or [0] Disable via parameter 0-42 [Auto On] Key on LCP.  NOTE: An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand On] – [Auto On].
[Reset]	Use [Reset] for resetting the drive after an alarm (trip). It can be selected as [1] Enable or [0] Disable via parameter 0-43 [Reset] Key on LCP. The parameter shortcut can be carried out by pressing down the [Main Menu] key for 3 s. The parameter shortcut provides direct access to any parameter.

5.1.4 Quick Transfer of Parameter Settings between Multiple Drives

When setup of a drive is completed, store the data in the LCP. Then connect the LCP to another drive and copy the parameter settings to the new drive.

5.1.5 Transferring Data

5.1.5.1 Transferring Data from the Drive to the LCP

1. Go to parameter **0-50 LCP Copy**.
2. Press [OK]
3. Select **[1] All to LCP**.
4. Press [OK].

5.1.5.2 Transferring Data from the LCP to the Drive

1. Go to parameter **0-50 LCP Copy**.
2. Press [OK].
3. Select [2] **All from LCP**.
4. Press [OK].

5.1.6 Display Mode

In normal operation, up to 5 different operating variables can be indicated continuously in the middle section: 1.1, 1.2, and 1.3, as well as 2 and 3.

5.1.7 Display Mode - Selection of Readouts

It is possible to toggle between 3 status readout screens by pressing [Status].

Operating variables with different formatting are shown in each status view (status view I, status view II, and status view III).

Refer to [Table 4](#) to see the measurements that can be linked to each of the operating variables. When options are mounted, more measurements are available.

Define the links:

- Parameter **0-20 Display Line 1.1 Small**.
- Parameter **0-21 Display Line 1.2 Small**.
- Parameter **0-22 Display Line 1.3 Small**.
- Parameter **0-23 Display Line 2 Large**.
- Parameter **0-24 Display Line 3 Large**.

Each readout parameter selected in parameter **0-20 Display Line 1.1 Small** to parameter **0-24 Display Line 3 Large** has its own scale and digits after a possible decimal point. The larger the numeric value of parameter is, the fewer digits are shown after the decimal point.

Example: Current readout 5.25 A, 15.2 A, 105 A.

Table 4: Units

Operating variable	Unit
Parameter 16-00 Control Word	hex
Parameter 16-01 Reference [Unit]	[Unit]
Parameter 16-02 Reference [%]	%
Parameter 16-03 Status Word	hex
Parameter 16-05 Main Actual Value [%]	%
Parameter 16-06 Actual Position	
Parameter 16-09 Custom Readout	
Parameter 16-10 Power [kW]	[kW]
Parameter 16-11 Power [hp]	[hp]
Parameter 16-12 Motor Voltage	[V]
Parameter 16-13 Frequency	[Hz]
Parameter 16-14 Motor current	[A]
Parameter 16-15 Frequency [%]	%
Parameter 16-16 Torque [Nm]	Nm

Table 4: Units - (continued)

Operating variable	Unit
Parameter 16-17 Speed [RPM]	[RPM]
Parameter 16-18 Motor Thermal	%
Parameter 16-20 Motor Angle	
Parameter 16-21 Torque [%] High Res.	%
Parameter 16-22 Torque [%]	%
Parameter 16-23 Motor Shaft Power [kW]	kW
Parameter 16-24 Calibrated Stator Resistance	Ω
Parameter 16-25 Torque [Nm] High	Nm
Parameter 16-30 DC Link Voltage	V
Parameter 16-32 Brake Energy /s	kW
Parameter 16-33 Brake Energy Average	kW
Parameter 16-34 Heatsink Temp.	°C
Parameter 16-35 Inverter Thermal	%
Parameter 16-36 Inv. Nom. Current	A
Parameter 16-37 Inv. Max. Current	A
Parameter 16-38 SL Controller State (This is an array parameter with the selections 16-38.0–16-38.3).	
Parameter 16-39 Control Card Temp.	°C
Parameter 16-40 Logging Buffer Full	
Parameter 16-42 Service Log Counter	
Parameter 16-43 Timed Actions Status	
Parameter 16-45 Motor Phase U Current	A
Parameter 16-46 Motor Phase V Current	A
Parameter 16-47 Motor Phase W Current	A
Parameter 16-48 Speed Ref. After Ramp [RPM]	RPM
Parameter 16-49 Current Fault Source	
Parameter 16-50 External Reference	
Parameter 16-51 Pulse Reference	
Parameter 16-52 Feedback[Unit]	[Unit]
Parameter 16-53 Digi Pot Reference	
Parameter 16-57 Feedback [RPM]	RPM
Parameter 16-60 Digital Input	bin
Parameter 16-61 Terminal 53 Switch Setting	V
Parameter 16-62 Analog Input 53	
Parameter 16-63 Terminal 54 Switch Setting	V
Parameter 16-64 Analog Input 54	
Parameter 16-65 Analog Output 42 [mA]	[mA]

Table 4: Units - (continued)

Operating variable	Unit
Parameter 16-66 <i>Digital Output [bin]</i>	[bin]
Parameter 16-67 <i>Pulse Input #29 [Hz]</i>	[Hz]
Parameter 16-68 <i>Freq. Input #33 [Hz]</i>	[Hz]
Parameter 16-69 <i>Pulse Output #27 [Hz]</i>	[Hz]
Parameter 16-70 <i>Pulse Output #29 [Hz]</i>	[Hz]
Parameter 16-71 <i>Relay Output [bin]</i>	
Parameter 16-72 <i>Counter A</i>	
Parameter 16-73 <i>Counter B</i>	
Parameter 16-74 <i>Prec. Stop Counter</i>	
Parameter 16-80 <i>Fieldbus CTW 1</i>	hex
Parameter 16-82 <i>Fieldbus REF 1</i>	hex
Parameter 16-84 <i>Comm. Option STW</i>	hex
Parameter 16-85 <i>FC Port CTW 1</i>	hex
Parameter 16-86 <i>FC Port REF 1</i>	hex
Parameter 16-87 <i>Bus Readout Alarm/Warning</i> (This is an array parameter with the selections 16-87.0–16.87.2).	
Parameter 16-88 <i>Fieldbus Torque FF.</i>	
Parameter 16-89 <i>Configurable Alarm/Warning Word</i>	
Parameter 16-90 <i>Alarm Word</i>	hex
Parameter 16-92 <i>Warning Word</i>	hex
Parameter 16-93 <i>Warning Word 2</i>	hex
Parameter 16-94 <i>Ext. Status Word</i>	hex
Parameter 16-95 <i>Ext. Status Word 2</i>	hex
Parameter 16-96 <i>Maintenance Word</i>	hex
Parameter 16-97 <i>Alarm Word 3</i>	hex
Parameter 16-98 <i>Warning Word 3</i>	hex

5.1.8 Status Views

5.1.8.1 Status View I

The readout state is standard after start-up or initialization. Press [Info] to obtain information about the units linked to the shown operating variables (1.1, 1.2, 1.3, 2, and 3). See the operating variables in the following illustration.




Figure 12: Status View I

5.1.8.2 Status View II

See the operating variables (1.1, 1.2, 1.3, and 2) shown in the following illustration. In the example, speed, motor current, motor power, and frequency are selected in the 1st and 2nd lines.




Figure 13: Status View II

5.1.8.3 Status View III

This state shows the event and action of the smart logic control.




Figure 14: Status View III

5.1.9 Parameter Setup

The drive can be used for practically all assignments. The drive offers 2 programming modes:

- Main menu mode
- Quick menu mode

Main menu mode provides access to all parameters.

Quick menu mode enables operation of the drive by setting only a few basic parameters.

Parameters can be changed in either main menu mode or quick menu mode.

5.1.10 Quick Menu Key Functions

Press [Quick Menu] to enter a list of different areas contained in the Quick Menu.




Figure 15: Quick Menus

Select *Q1 My Personal Menu* to show the selected personal parameters. These parameters are selected in parameter **0-25 My Personal Menu**. Up to 50 different parameters can be added in this menu.

Select *Q2 Quick Setup* to go through a selection of parameters to get the motor running almost optimally. The default settings for the other parameters consider the required control functions and the configuration of signal inputs/outputs (control terminals).

Parameters are selected via the navigation keys. The parameters in [Table 5](#) are accessible.

Table 5: Selection of Parameter

Parameter	Setting
Parameter 0-01 Language	Select the language. Default is [0] English .
Parameter 1-20 Motor Power [kW]	[kW]
Parameter 1-22 Motor Voltage	[V]
Parameter 1-23 Motor Frequency	[Hz]
Parameter 1-24 Motor Current	[A]
Parameter 1-25 Motor Nominal Speed	[RPM]
Parameter 5-12 Terminal 27 Digital Input	[0] No function
Parameter 1-29 Automatic Motor Adaptation (AMA)	[1] Enable complete AMA
Parameter 3-02 Minimum Reference	[RPM]
Parameter 3-03 Maximum Reference	[RPM]
Parameter 3-41 Ramp 1 Ramp Up Time	[s]
Parameter 3-42 Ramp 1 Ramp Down Time	[s]
Parameter 3-13 Reference Site	Select whether to control the drive via digital inputs, LCP, or remote control.

1) If terminal 27 is set to **[0] No operation**, no connection to +24 V on terminal 27 is necessary.

Select *Changes made* to get the information about:

- The last 10 changes. Use the [▲] [▼] navigation keys to scroll between the last 10 changed parameters.
- The changes made since default setting.

Select *Loggings* to get information about the shown line readouts. The information is shown as graphs. Only parameters selected in parameter **0-20 Display Line 1.1 Small** and parameter **0-24 Display Line 3 Large** can be viewed. It is possible to store up to 120 samples in the memory for later reference.

5.1.11 Initial Commissioning

The easiest way of carrying out the initial commissioning is by pressing [Quick Menu] and following the quick setup procedure using LCP 102. Read the procedure from left to right. The example applies to an open-loop application.

Table 6: Quick Setup Procedure

Press				
		Q2 Quick Menu		
Parameter 0-01 Language		Set language		
Parameter 1-20 Motor Power [kW]		Set motor nameplate power.		
Parameter 1-22 Motor Voltage		Set nameplate voltage.		
Parameter 1-23 Motor Frequency		Set nameplate frequency.		
Parameter 1-24 Motor Current		Set nameplate current.		
Parameter 1-25 Motor Nominal Speed		Set nameplate speed in RPM.		
Parameter 5-12 Terminal 27 Digital Input		If terminal default is [2] Coast inverse , it is possible to change this setting to [0] No function . No connection to terminal 27 is then needed for running AMA.		

Table 6: Quick Setup Procedure - (continued)

Press				
Parameter 1-29 <i>Automatic Motor Adaptation (AMA)</i>		Set the desired AMA function. Enabling complete AMA is recommended.		
Parameter 3-02 <i>Minimum Reference</i>		Set the minimum speed of the motor shaft.		
Parameter 3-03 <i>Maximum Reference</i>		Set the maximum speed of the motor shaft.		
Parameter 3-41 Ramp 1 <i>Ramp Up Time</i>		Set the ramp-up time with reference to synchronous motor speed, n_s .		
Parameter 3-42 Ramp 1 <i>Ramp Down Time</i>		Set the ramp-down time with reference to synchronous motor speed, n_s .		
Parameter 3-13 <i>Reference Site</i>		Set the site from where the reference must work.		

Another easy way of commissioning the drive is by using the smart application setup (SAS), which can also be found by pressing [Quick Menu]. To set up the applications listed, follow the instructions on the successive screens.

The [Info] key can be used throughout the SAS to see help information for various selections, settings, and messages. The following 3 applications are included:

- Mechanical brake.
- Conveyor.
- Pump/fan.

The following fieldbuses can be selected:

- PROFIBUS.
- PROFINET.
- DeviceNet.
- EtherNet/IP.



NOTE: The drive ignores any start conditions when SAS is active.



NOTE: The smart setup runs automatically on the 1st power-up of the drive or after a reset to factory settings. If no action is taken, the SAS screen automatically disappears after 10 minutes.

5.1.12 Main Menu Mode

Press [Main Menu] to enter the main menu mode. The readout in the following illustration appears on the display. The middle and bottom sections in the display show a list of parameter groups, which can be selected by toggling the [▲] and [▼] keys.




Figure 16: Main Menu Mode

Each parameter has a name and number which remain the same regardless of the programming mode. In the main menu mode, the parameters are divided into groups. The 1st digit of the parameter number (from the left) indicates the parameter group number.

All parameters can be changed in the Main Menu. However, depending on the choice of configuration (parameter **1-00 Configuration Mode**), some parameters can be hidden. For example, open loop hides all the PID parameters, and other enabled options make more parameter groups visible.

5.1.13 Parameter Selection

In the main menu mode, the parameters are divided into groups. Select a parameter group with the navigation keys.

After selecting a parameter group, select a parameter with the navigation keys.

The middle section on the display shows the parameter number and name, and the selected parameter value.




Figure 17: Parameter Selection

5.1.14 Changing Data

The procedure for changing data in the quick menu mode and the main menu mode is the same. Press [OK] to change the selected parameter.

The procedure for changing data depends on whether the selected parameter represents a numeric data value or a text value.

5.1.15 Changing a Text Value

If the selected parameter is a text value, change the text value with the [▲] [▼] keys.

Place the cursor on the value to save and press [OK].




Figure 18: Changing a Text Value

5.1.16 Changing a Data Value

If the selected parameter shows a numeric data value, change the selected data value with the [◀] [▶] and the [▲] [▼] navigation keys. Press the [◀] [▶] keys to move the cursor horizontally.




Figure 19: Changing a Data Value

Press the [▲] [▼] keys to change the data value. [▲] increases the data value, and [▼] decreases the data value. Place the cursor on the value to save and press [OK].




Figure 20: Saving a Data Value

5.1.17 Infinitely Variable Change of Numeric Data Value

If the selected parameter shows a numeric data value, select a digit with [◀] [▶].




Figure 21: Selecting a Digit

Change the selected digit infinitely variably with [▲] [▼]. The cursor indicates the selected digit. Place the cursor on the digit to save and press [OK].




Figure 22: Saving

5.1.18 Value, Step by Step

Certain parameters can be changed step by step. This applies to:

- Parameter **1-20 Motor Power [kW]**.
- Parameter **1-22 Motor Voltage**.
- Parameter **1-23 Motor Frequency**.

The parameters are changed both as a group of numeric data values and as numeric data values that are infinitely varying.

5.1.19 Readout and Programming of Indexed Parameters

Parameters are indexed when placed in a rolling stack. Parameter **15-30 Fault Log: Error Code** to parameter **15-32 Alarm Log: Time** contain a fault log, which can be read out. Select a parameter, press [OK], and press the [▲] [▼] keys to scroll through the value log.

5.1.20 Changing Values of Indexed Parameters

Change parameter **3-10 Preset Reference** as an example.

Procedure

1. Select the parameter, press [OK], and press [▲] [▼] to scroll through the indexed values.
2. To change the parameter value, select the indexed value and press [OK].
3. Change the value by pressing [▲] [▼].
4. Press [OK] to accept the new setting.
5. Press [Cancel] to abort. Press [Back] to leave the parameter.

5.2 The Numerical Control Panel

5.2.1 Overview of the Numerical LCP




Figure 23: NLCP

1	Numeric display.	2	Menu keys and indicator lights - changing parameters and switching between display functions.
3	Navigation keys and indicator lights.	4	Operation keys and indicator lights.

Display line

Status messages showing icons and numeric value.

Indicator lights

- Green LED/On: indicates if control section is on.
- Yellow LED/Wrn: indicates a warning.
- Flashing red LED/Alarm: indicates an alarm.

5.2.2 LCP Keys, Numerical LCP

The control keys are divided into functions. The keys below the display and indicator lights are used for parameter setup, including option of display indication during normal operation.

Table 7: LCP Keys and Description

LCP keys	Description
[Status]	Indicates the status of the drive and/or the motor. If an alarm occurs, the NLCP automatically switches to status mode. Several alarms can be shown.  NOTE: Parameter copy is not possible with LCP 101 numerical local control panel. Figure 24: Status Mode Figure 25: Alarm
[Quick Menu]/[Main Menu]	Used for programming the parameters in the Quick Menu and Main Menu, respectively. When the value flashes, press [▲] or [▼] to change parameter values. Parameters with functional options show values such as [1], [2], and so on. For a description of the different options, see the individual parameter descriptions in the section <i>Parameter Descriptions</i>. Figure 26: Main Menu/Quick Setup
[Back]	Returns to the previous step or layer in the navigation structure.
Navigation keys	The 2 navigation keys are used to navigate between the different options available in Quick Menu and Main Menu. Press the keys to move the cursor.
[OK]	Press to select a parameter marked by the cursor and to enable the change of a parameter.

Local control keys: Local control keys are at the bottom of the control panel.

Table 8: Local Control Keys and Description

LCP keys	Description
[Hand On]	Enables control of the drive via the LCP. [Hand On] also starts the motor, and it is now possible to enter the motor speed data with the navigation keys. The key can be selected as [1] Enable or [0] Disable via parameter 0-40 [Hand on] Key on LCP. External stop signals activated with control signals or a fieldbus override a start command via the LCP. The following control signals are still active when [Hand On] is activated: • [Hand On] - [Off] - [Auto On] • Reset • Coast stop inverse • Reversing • Setup select lsb - Setup select msb • Stop command from serial communication • Quick stop • DC brake
[Off]	Stops the connected motor. The key can be selected as [1] Enable or [0] Disable via parameter 0-41 [Off] Key on LCP. If the external stop function is not selected and the [Off] key is inactive, the motor can be stopped by disconnecting the voltage.
[Auto On]	Enables the drive to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the drive starts. The key can be selected as [1] Enable or [0] Disable via parameter 0-42 [Auto on] Key on LCP. NOTE: An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand On] – [Auto On].
[Reset]	Is used for resetting the drive after an alarm (trip). It can be selected as [1] Enable or [0] Disable via parameter 0-43 [Reset] key on LCP.

5.3 Restoring Factory Default Settings

5.3.1 Restoring Factory Default Settings Using the Recommended Initialization

NOTICE

LOSS OF DATA

Restoring default settings results in a loss of programming, motor data, localization, and monitoring records.

- To create a backup, upload data to the LCP before initialization.

1. Press [Main Menu] twice to access parameters.
2. Go to parameter **14-22 Operation Mode** and press [OK].

Parameter **14-22 Operation Mode** does not reset the following settings:

- Running hours.
- Serial communication options.
- Personal menu settings.
- Fault log, alarm log, and other monitoring functions.

3. Scroll to *Initialization* and press [OK].
4. Remove power to the unit and wait for the display to turn off.
5. Apply power to the unit. Default parameter settings are restored during start-up. Start-up takes slightly longer than normal.
6. After alarm 80, *Drive initialized* appears, press [Reset].

5.3.2 Restoring Factory Default Settings Using Manual Initialization

NOTICE

LOSS OF DATA

Restoring default settings results in a loss of programming, motor data, localization, and monitoring records.

- To create a backup, upload data to the LCP before initialization.



NOTE: A manual initialization also resets serial communication, RFI filter settings, and fault log settings.

Procedure

1. Remove power to the unit and wait for the display to turn off.
2. Press and hold [Status], [Main Menu], and [OK] simultaneously while applying power to the unit (approximately 5 s or until an audible click sounds and the fan starts).


Manually initializing does not reset the following parameter settings:

- Parameter **15-00 Operating Hours**
- Parameter **15-03 Power Up's**
- Parameter **15-04 Over Temp's**
- Parameter **15-05 Over Volt's**

Start-up takes slightly longer than normal.

5.3.3 Resetting all Parameters

1. Remove power to the unit and wait for the display to turn off.
2. Press [Hand on]+[OK]+[Reset] simultaneously while applying power to the unit (approximately 5 s or until an audible click sounds and the fan starts).



➡ All parameters are reset to factory setting, and the security file is deleted.

6 Parameter Descriptions

6.1 Selecting Parameters

The parameters are grouped into various parameter groups for easy selection of the correct parameter for optimal operation of the drive. Parameter descriptions and selections are shown in the LCP. Access the parameters by pressing [Quick Menu] or [Main Menu] on the LCP. The Quick Menu is used mainly for commissioning the unit at start-up by providing parameters necessary to start operation. The Main Menu provides access to all parameters for detailed application programming.

All digital input/output and analog input/output terminals are multi-functional. All terminals have factory setting functions suitable for a wide range of relevant applications. If other special functions are required, they must be programmed in parameter groups **5-** Digital In/Out** or **6-** Analog In/Out**.

An asterisk (*) following an option number in a parameter indicates a default setting.

6.2 Parameter Group 0-** Operation and Display

6.2.1 Introduction to Parameter Group 0-** Operation and Display

Parameters related to the basic functions of the drive, function of the LCP keys, and configuration of the LCP display.

6.2.2 0-0* Basic Settings

0-01 Language

Default value:	[0] English	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Defines the language to be used in the display. All languages are available in the drive. English cannot be erased or manipulated.

Option	Name	Description
[0]*	English	
[1]	Deutsch	
[2]	Français	
[3]	Dansk	
[4]	Español	
[5]	Italiano	
[6]	Svenska	
[7]	Nederlands	
[10]	Chinese	
[20]	Suomi	
[22]	English US	
[27]	Greek	
[28]	Bras. Port	
[36]	Slovenian	
[39]	Korean	

Option	Name	Description
[40]	Japanese	
[41]	Turkish	
[42]	Trad.Chinese	
[43]	Bulgarian	
[44]	Srpski	
[45]	Romanian	
[46]	Magyar	
[47]	Czech	
[48]	Polski	
[49]	Russian	
[50]	Thai	
[51]	Bahasa Indonesia	
[52]	Hrvatski	

0-02 Motor Speed Unit

Default value:	–	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: Changing the motor speed unit resets certain parameters to their initial value. Select the motor speed unit before modifying other parameters.

The information shown in the display depends on the settings in parameter **0-02 Motor Speed Unit** and parameter **0-03 Regional Settings**. The default settings of parameter **0-02 Motor Speed Unit** and parameter **0-03 Regional Settings** depend on the region to which the drive is supplied.

Option	Name	Description
[0]	RPM	Select to show motor speed variables and parameters using motor speed (RPM).
[1]	Hz	Select to show motor speed variables and parameters using output frequency (Hz).

0-03 Regional Settings

Default value:	–	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Option	Name	Description
[0]	International	Activate parameter 1-20 Motor Power [kW] for setting the motor power in kW and set the default value of parameter 1-23 Motor Frequency to 50 Hz.
[1]	North America	Activate parameter 1-20 Motor Power [kW] for setting the motor power in kW and set the default value of parameter 1-23 Motor Frequency to 60 Hz.

0-04 Operating State at Power-up (Hand)

Default value:	[1] Forced stop, ref=old	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the operating state when reconnecting the drive to mains voltage after it has been powered down in hand-on mode.

Option	Name	Description
[0]	Resume	Restart the drive, maintaining the start/stop settings (applied by <i>[Hand On]/[Off]</i>) selected before the power-down of the drive.
[1]*	Forced stop, ref=old	Restart the drive with a saved local reference after mains voltage reappears and after pressing <i>[Hand On]</i> .
[2]	Forced stop, ref=0	Reset the local reference to 0 when restarting the drive.

6.2.3 0-1* Set-up Operations

Define and control the individual parameter setups. The drive has 4 parameter setups that can be programmed independently of each other. This makes the drive very flexible and able to solve advanced control functionality problems, often saving the cost of external control equipment. Parameter setups can be used to program the drive to operate according to 1 control scheme in 1 setup (for example, motor 1 for horizontal movement) and another control scheme in another setup (for example, motor 2 for vertical movement). Alternatively, parameter setups can be used in OEM machine building to identically program all factory-fitted drives for different machine types within a range to have the same parameters. During production/commissioning, simply select a specific setup depending on which machine the drive is installed on.

The active setup is the setup in which the drive is currently operating. The active setup can be selected in parameter **0-10 Active Set-up** and is shown in the LCP. By using multi-setup, it is possible to switch between setups with the drive running, or the drive can be stopped via digital input or serial communication commands. If it is necessary to change setups while the drive is running, ensure that parameter **0-12 This Set-up Linked to** is programmed as required. By using parameter **0-11 Edit Set-up**, it is possible to edit parameters within any of the setups while continuing the operation of the drive in its active setup. If similar parameter settings are required in different setups, it is possible to copy parameter settings between the setups to enable quicker commissioning by using parameter **0-51 LCP Copy**.

Use parameter **0-51 Set-up Copy** to copy a setup to 1 or all other setups. Stop the drive before switching between setups where parameters marked FALSE in the *Change during operation* field have different values. To avoid conflicting settings of the same parameter within 2 different setups, link the setups together using parameter **0-12 This Set-up Linked to**. Parameters which are not changeable during operation are marked FALSE in the *Change during operation* field.

0-10 Active Set-up

Default value:	[1] Set-up 1	Parameter type:	Option

Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the setup to control the drive functions.

Option	Name	Description
[0]	Factory setup	Cannot be changed. It contains the data set and can be used as a data source when returning the other setups to a known state.
[1]*	Set-up 1	[1] Set-up 1 to [4] Set-up 4 are the 4 separate parameter setups within which all parameters can be programmed.
[2]	Set-up 2	
[3]	Set-up 3	
[4]	Set-up 4	
[9]	Multi Set-up	Remote setup selections using digital inputs and the serial communication port. This setup used the settings from parameter 0-12 This Set-up Linked to . Stop the drive before making changes to open-loop and closed-loop functions.




Figure 27: Edit Setup

0-11 Edit Set-up

Default value:	[1] Set-up 1	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the setup to be edited (programmed) during operation, either the active setup or 1 of the inactive setups.

Option	Name	Description
[0]	Factory setup	Cannot be edited, but it is useful as a data source to return the other setups to a known state.
[1]*	Set-up 1	[1] Set-up 1 to [4] Set-up 4 can be edited freely during operation, independently of the active setup.
[2]	Set-up 2	
[3]	Set-up 3	
[4]	Set-up 4	
[9]	Active Set-up	Can also be edited during operation. Edit the selected setup from a range of sources: LCP, FC RS-485, FC USB, or up to 5 fieldbus sites.

0-12 This Set-up Linked to

Default value:	[0] Not linked	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

To enable conflict-free changes from 1 setup to another during operation, link setups containing parameters which are not changeable during operation. The link ensures synchronizing of the not changeable during operation-parameter values when moving from 1 setup to another during operation. Not changeable during operation-parameters can be identified by the label FALSE in the *Change during operation* field. Parameter **0-12 This Set-up Linked to** is used by **[9] Multi set-up** in parameter **0-10 Active Set-up**. Multi setup is used to move from 1 setup to another during operation.

Option	Name	Description
[0]*	Not linked	
[1]	Set-up 1	
[2]	Set-up 2	
[3]	Set-up 3	
[4]	Set-up 4	

Example

Use multi set-up to shift from setup 1 to setup 2 while the motor is running. Program in setup 1 first, then ensure that setup 1 and setup 2 are synchronized (or linked). Synchronization can be performed in 2 ways:

- Select the following options:
 - **[2] Set-up 2** in parameter **0-11 Edit Set-up**
 - Set parameter **0-12 This Set-up Linked to** to **[1] Set-up 1**.




Figure 28: Setup 1

- While still in setup 1, copy setup 1 to setup 2. Then set parameter **0-12 This Set-up Linked to** to **[2] Set-up 2**.




Figure 29: Setup 2

0-13 Readout: Linked Set-ups

Default value:	0	Parameter type:	Readout, Array [5]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View a list of all the setups linked by parameter **0-12 This Set-up Linked to**. The parameter has 1 index for each parameter setup. The value for each index shows which setups are linked to that parameter setup.

Table 9: Setup Link Example

Index	LCP value
0	{0}
1	{1,2}
2	{1,2}
3	{3}
4	{4}

0-14 Readout: Edit Set-ups/Channel

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

View the setting of parameter **0-11 Edit Set-up** for each of the 4 different communication channels. When the number is shown as a hex number, as it is in the LCP, each number represents 1 channel. Numbers 1–4 represent a setup number; F means factory setting; and A means active setup. The channels are, from right to left: LCP, FC bus, USB, HPFB1-5.

Example

The number AAAAAA21h means the following:

- The drive received the setting of setup 2 via a fieldbus channel. The selection is reflected in parameter **0-11 Edit Set-up**.
- A user selected setup 1 via the LCP.
- All other channels are using the active setup.

0-15 Readout: Actual Setup

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

Makes it possible to read out the active setup, also when **[9] Multi Set-up** is selected in parameter **0-10 Active Set-up**.

6.2.4 0-2* LCP Display

Define the variables shown in the LCP. For information on how to write display texts, refer to:

- Parameter **0-37 Display Text 1**.
- Parameter **0-38 Display Text 2**.
- Parameter **0-39 Display Text 3**.

0-20 Display Line 1.1 Small

Default value:	[1617] Speed RPM	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Select a variable for display in line 1, left position.

Option	Name	Description
[0]	None	No display value selected.
[9]	Performance monitor	
[15]	Readout: actual setup	
[37]	Display text 1	Enables an individual text string to be written for showing in the LCP or to be read via serial communication.
[38]	Display text 2	Enables an individual text string to be written for showing in the LCP or to be read via serial communication.
[39]	Display text 3	Enables an individual text string to be written for showing in the LCP or to be read via serial communication.
[89]	Date and time readout	Shows the current date and time.
[748]	PCD feed forward	
[953]	PROFIBUS warning word	Shows the PROFIBUS communication warnings.

Option	Name	Description
[1005]	Readout transmit error counter	Shows the number of CAN control transmission errors since the last power-up.
[1006]	Readout receive error counter	Shows the number of CAN control receipt errors since the last power-up.
[1007]	Readout bus off counter	Shows the number of bus off-events since the last power-up.
[1013]	Warning parameter	Shows a DeviceNet-specific warning word. One separate bit is assigned to every warning.
[1230]	Warning parameter	Shows the EtherNet/IP-specific status word.
[1397]	Alert alarm word	Shows the alert alarm word in hex code.
[1398]	Alert warning word	Shows the alert warning word in hex code.
[1399]	Alert status word	Shows the alert status word in hex code.
[1472]	Legacy alarm word	Shows the compatibility alarm word as a hexadecimal value
[1473]	Legacy warning word	Shows the compatibility warning word as a hexadecimal value.
[1474]	Leg. ext. status word	Shows the compatibility extended status word as a hexadecimal value.
[1500]	Operating hours	Shows how many hours the drive has run. The value is saved when the drive is turned off.
[1501]	Running hours	Shows the number of running hours of the motor.
[1502]	kWh counter	Shows the mains power consumption in kWh.
[1580]	Fan running hours	Shows how many hours the external fan has run. The value is saved when the drive is turned off.
[1583]	Motor U_d	
[1584]	Motor U_q	
[1585]	Motor I_d	
[1586]	Motor I_q	
[1587]	kWh counter hires	Shows the motor power consumption in kWh as a mean value over 1 hour. Reset the counter in parameter 15-06 Reset kWh Counter . Decimal places are reset at power-up.
[1600]	Control word	Shows the control word sent from the drive via the serial communication port in hex code.
[1601]	Reference [Unit]	Total reference (sum of digital/analog/preset/bus/freeze reference/catch up and slow down) in selected unit.
[1602]	Reference %	Total reference (sum of digital/analog/preset/bus/freeze reference/catch up and slow down) in percent.
[1603]	Status word	Present status word.
[1605]	Main actual value [%]	Shows the 2-byte word sent with the status word to the bus master reporting the main actual value in %.
[1606]	Actual position	Actual position in position units selected in parameter 17-70 Position Unit .

Option	Name	Description
[1607]	Target position	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Active target position in position units selected in parameter 17-70 Position Unit.
[1608]	Position error	Actual position PI error in position units selected in parameter 17-70 Position Unit .
[1609]	Custom readout	Shows the user-defined readouts as defined in: - Parameter 0-30 Custom Readout Unit - Parameter 0-31 Custom Readout Min Value - Parameter 0-32 Custom Readout Max Value
[1610]	Power [kW]	Actual power consumed by the motor in kW.
[1611]	Power [hp]	Actual power consumed by the motor in hp.
[1612]	Motor voltage	Voltage supplied to the motor.
[1613]	Frequency	Motor frequency, that is, the output frequency from the drive in Hz.
[1614]	Motor current	Phase current of the motor measured as effective value.
[1615]	Frequency [%]	Motor frequency, that is, the output frequency from the drive in percent.
[1616]	Torque [Nm]	Actual motor torque in Nm.
[1617]*	Speed [RPM]	Speed in RPM (revolutions per minute), that is, the motor shaft speed in closed loop.
[1618]	Motor thermal	Thermal load on the motor calculated by the ETR function.
[1619]	Thermistor sensor temperature	Returning the actual temperature on a KTY/Pt1000 thermistor sensor built in the motor.
[1620]	Motor angle	Shows the current encoder/resolver angle offset relative to the index position. The value range of 0–65535 corresponds to 0–2 x pi (radians).
[1621]	Torque [%] high res.	The value shown is the torque in percent of nominal torque with sign and 0.1% resolution applied to the motor shaft.
[1622]	Torque [%]	Present motor load as a percentage of the rated motor torque.
[1623]	Motor shaft power [kW]	Shows the power applied to the motor shaft. This is an estimate based on the motor shaft torque and motor speed. The motor speed is estimated unless operating in a speed-closed-loop mode.
[1624]	Calibrated stator resistance	Shows the calibrated stator resistance.
[1625]	Torque [Nm] high	Shows the torque value with sign applied to the motor shaft. Some motors supply more than 160% torque. Consequently, the minimum value and the maximum value depend on the maximum motor current as well as the motor used. This specific readout has been adapted to the able to show higher values than the standard readout in parameter 16-16 Torque [Nm] .
[1628]	Angle error	The angle error between the estimated angle and feedback angle.

Option	Name	Description
[1630]	DC link voltage	DC-link voltage in the drive.
[1631]	System temp.	Shows the combined (highest) internal system temperature measurement.
[1632]	Brake energy /s	Present brake power transferred to an external brake resistor. Stated as an instant value.
[1633]	Brake energy average	Brake power transferred to an external brake resistor. The mean power is calculated continuously for the most recent 120 s.
[1634]	Heatsink temp.	Present heat sink temperature of the drive. The cutout limit is $95 \pm 5 \text{ }^{\circ}\text{C}$ ($203 \pm 9 \text{ }^{\circ}\text{F}$); cutting back in occurs at $70 \pm 5 \text{ }^{\circ}\text{C}$ ($158 \pm 9 \text{ }^{\circ}\text{F}$).
[1635]	Inverter thermal	Percentage load of the inverters.
[1636]	Inv. nom. current	Nominal current of the inverter.
[1637]	Inv. max. current	Maximum current of the inverter.
[1638]	SL controller state	State of the event executed by the control.
[1639]	Control card temp.	Temperature of the control card.
[1642]	Service log counter	Shows the number of logs stored in the Service Log file.
[1643]	Timed actions status	See parameter group 23-0* Timed Actions .
[1644]	Speed error [RPM]	Shows the speed error RPM.
[1645]	Motor phase U current	Shows the motor phase U current.
[1646]	Motor phase V current	Shows the motor phase V current.
[1647]	Motor phase W current	Shows the motor phase W current.
[1648]	Speed. ref. after ramp [RPM]	This parameter shows the reference given to the drive after the speed ramp in RPM.
[1650]	External reference	Sum of the external reference as a percentage, that is, the sum of analog/pulse/bus.
[1651]	Pulse reference	Frequency in Hz connected to the digital inputs (18, 19 or 32, 33).
[1652]	Feedback[Unit]	Reference value from programmed digital inputs.
[1653]	Digi pot reference	Shows the contribution of the digital potentiometer to the actual reference feedback.
[1657]	Feedback [RPM]	Read the actual motor RPM from the feedback source in both closed loop and open loop. Select the feedback source in parameter 7-00 Speed PID Feedback Source .
[1660]	Digital input	Signal states from the 6 digital terminals (18, 19, 27, 29, 32, and 33). There are 16 bits in total, but only 6 of them are used. Input 18 corresponds to the far left of the used bits. Signal log=0; Signal high=1.
[1661]	Terminal 53 switch setting	Setting of input terminal 53. Current=0; Voltage=1.
[1662]	Analog input 53	Actual value at input 53 either as a reference or protection value.
[1663]	Terminal 54 switch setting	Setting of input terminal 54. Current=0; Voltage=1.
[1664]	Analog input 54	Actual value at input 54 either as reference or protection value.

Option	Name	Description
[1665]	Analog output 42 [mA]	Actual value at output 42 in mA. Use parameter 6-50 Terminal 42 Output to select the value to be shown.
[1666]	Digital output [bin]	Binary value of all digital outputs.
[1667]	Freq. input #29 [Hz]	Actual value of the frequency applied at terminal 29 as an impulse input.
[1668]	Freq. input #33 [Hz]	Actual value of the frequency applied at terminal 33 as an impulse input.
[1669]	Pulse output #27 [Hz]	Actual value of impulses applied to terminal 27 in digital output mode.
[1670]	Pulse output #29 [Hz]	Actual value of impulses applied to terminal 29 in digital output mode.
[1671]	Relay output [bin]	Shows the settings of all relays.
[1672]	Counter A	Application-dependent (for example, SLC control).
[1673]	Counter B	Application-dependent (for example, SLC control).
[1674]	Prec. stop counter	Shows the actual value of the counter.
[1675]	Analog in X30/11	Actual value at input X30/11 either as reference or protection value.
[1676]	Analog in X30/12	Actual value at input X30/12 either as reference or protection value.
[1677]	Analog out X30/8 [mA]	Actual value at output X30/8 in mA. Use parameter 6-60 Terminal X30/8 Output to select the value to be shown.
[1678]	Analog out X45/1 [mA]	Returns the output value on the terminal.
[1679]	Analog out X45/3 [mA]	Returns the output value on the terminal.
[1680]	Fieldbus CTW 1	Control word (CTW) received from the bus master.
[1681]	Fieldbus sync. REF	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[1682]	Fieldbus REF 1	Mains reference value sent with control word from the bus master.
[1683]	Fielbus pos. REF	
[1684]	Comm. option STW	Extended fieldbus communication option status word.
[1685]	FC port CTW 1	Control word (CTW) received from the bus master.
[1686]	FC port REF 1	Status word (STW) sent to the bus master.
[1687]	Bus readout alarm/warning	Shows the human-readable alarm and warning numbers in hex code as shown in the alarm log.
[1688]	Fieldbus torque FF	Shows the fieldbus torque feed forward.
[1689]	Configurable alarm/warning word	Shows the configurable alarm and warning word.
[1690]	Alarm word	One or more alarms in a hex code.
[1691]	Alarm word 2	One or more alarms in a hex code.
[1692]	Warning word	One or more warnings in a hex code.

Option	Name	Description
[1693]	Warning word 2	One or more warnings in a hex code.
[1694]	Ext. status word	One or more status conditions in a hex code.
[1695]	Ext. status word 2	One or more status conditions in a hex code.
[1696]	Maintenance word	The bits reflect the status for the programmed preventive maintenance events in parameter group 23-1* Maintenance .
[1697]	Alarm word 3	Shows alarm word 3 as a hexadecimal value.
[1698]	Warning word 3	Shows warning word 3 as a hexadecimal value.
[1699]	Ext. status word	
[1766]	SSI status	
[1767]	Raw inc. quad counter	
[1768]	Raw abs. pos. low	
[1769]	Raw abs. pos. high	
[1804]	Mech Brake Count	Shows the mechanical brake count as a decimal value.
[1820]	Commanded position	
[1821]	Master position	
[1823]	Virtual master pos.	
 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.		
[1827]	Safe opt. est. speed	
[1828]	Safe opt. meas. speed	
[1829]	Safe opt. speed error	
[1836]	Analog input X48/2 [mA]	
[1837]	Temp. input X48/4	
[1838]	Temp. input X48/7	
[1839]	Temp. input X48/10	
[1840]	Analog input X49/1	
[1841]	Analog input X49/3	
[1842]	Analog input X49/5	
[1843]	Analog out X49/7	
[1844]	Analog out X49/9	
[1845]	Analog out X49/11	
[1846]	X49 digital output [bin]	
[1847]	Last warning	Shows the last warning.
[1848]	Last warning count	Shows how many times the last warning has been active.
[1860]	Digital input 2	
[1861]	Temp. input X48 max	
[1864]	Power based speed limit	

Option	Name	Description
[1866]	Actual switching frequency	
[1867]	Alarm word 4	
[1868]	Warning word 4	
[1870]	Mains voltage	Shows the mains voltage measurement.
[1871]	Mains frequency	Shows the mains frequency measurement.
[1872]	Mains imbalance	Shows the maximum measured imbalance for the 3 mains line-to-line measurements.
[1873]	Worst inrush	Identifies which active inrush is producing the data shown in parameter 18-70 Mains Voltage , parameter 18-71 Mains Frequency , parameter 18-72 Mains Imbalance , and parameter 18-75 Rectifier DC Volt . 1 = inrush 1, 2 = inrush 2, and so on.
[1874]	Inrush mode	The reported mode of each inrush board. Values: 0 = unknown, 1 = inrush, 2 = running. Indexes: 0 = inrush 1, 1 = inrush 2, and so on.
[1875]	Rectifier DC volt.	Shows the DC voltage measurement from the rectifier module.
[1876]	Mains voltage2	Shows the mains voltage measurement. Indexes: 0 = inrush1 average, 1 = inrush2 average, 4 = inrush1 L1, 5 = inrush2 L1, 8 = inrush1 L2, and so on.
[1877]	Mains frequency2	Shows the mains frequency measurement. Indexes: 0 = inrush1 average, 1 = inrush2 average, 4 = inrush1 L1, 5 = inrush2 L1, 8 = inrush1 L2, and so on.
[1878]	Mains imbalance2	Shows the maximum measured imbalance for the 3 mains line-to-line measurements. Indexes: 0 = inrush1 average, 1 = inrush2 average, 4 = inrush1 L1, 5 = inrush2 L1, 8 = inrush1 L2, and so on.
[1879]	Rectifier DC volt.2	Shows the DC voltage measurement from the rectifier module. Indexes: 0 = inrush1 average, 1 = inrush2 average, 4 = inrush1 L1, 5 = inrush2 L1, 8 = inrush1 L2, and so on.
[1890]	Process PID error	Shows the error value in the process PID controller.
[1891]	Process PID output	Shows the raw output value from the process PID controller.
[1892]	Process PID clamped output	Shows the output value from the process PID controller after reaching a clamp limit.
[1893]	Process PID gain scaled output	Shows the output value from the process PID controller after reaching a clamp limit and scaling the resulting value with considerations to the gain.
[1899]	Speed PID torque FF. [Nm]	Readout of the total commanded torque feed forward.
[2316]	Maintenance text	Showing customized messages for maintenance item and action.
[3019]	Wobble delta freq. scaled	
[3110]	Bypass status word	Shows the status of the bypass as a hexadecimal value.
[3111]	Bypass running hours	Shows the number of hours in which the motor has run in bypass mode. The counter can be reset in parameter 15-07 Reset Running Hours Counter . The value is saved when the drive is turned off.

Option	Name	Description
[3401]	PCD 1 write to MCO	
[3402]	PCD 2 write to MCO	
[3403]	PCD 3 write to MCO	
[3404]	PCD 4 write to MCO	
[3405]	PCD 5 write to MCO	
[3406]	PCD 6 write to MCO	
[3407]	PCD 7 write to MCO	
[3408]	PCD 8 write to MCO	
[3409]	PCD 9 write to MCO	
[3410]	PCD 10 write to MCO	
[3421]	PCD 1 read from MCO	
[3422]	PCD 2 read from MCO	
[3423]	PCD 3 read from MCO	
[3424]	PCD 4 read from MCO	
[3425]	PCD 5 read from MCO	
[3426]	PCD 6 read from MCO	
[3427]	PCD 7 read from MCO	
[3428]	PCD 8 read from MCO	
[3429]	PCD 9 read from MCO	
[3430]	PCD 10 read from MCO	
[3440]	Digital inputs	Read out the status of the digital inputs.
[3441]	Digital outputs	Read out the status of the digital outputs.
[3450]	Actual position	Shows the actual position.
[3451]	Commanded position	Set the follower position in UU. Corresponds to the CPOS command.
[3452]	Actual master position	Current master position in qc. Corresponds to MAPOS command.
[3453]	Slave index position	Last slave index position in UU. Corresponds to IPOS command.
[3454]	Master index position	Last master index position in qc. Corresponds to MIPOS command.
[3455]	Curve position	Retrieve the follower position that corresponds to the current master position of the curve. Corresponds to CURVEPOS command.
[3456]	Track error	Queries the actual position error of the axis in UU (in consideration of the signs). Corresponds to TRACKER command.
[3457]	Synchronizing error	Queries the actual synchronization error of the follower. This is the distance between the actual master position (converted with drive factor and offset) and the actual position of the follower. The result is shown in UU.
[3458]	Actual velocity	The actual velocity in UU/s. Corresponds to AVEL command.

Option	Name	Description
[3459]	Actual master velocity	The actual velocity master in qc/s. Corresponds to MAVEL command.
[3460]	Synchronizing status	Flag to query synchronization status. Corresponds to SYNCSTAT command.
[3461]	Axis status	
[3462]	Program status	
[3464]	MCO 302 status	
[3465]	MCO 302 control	
[3466]	SPI error counter	
[3470]	MCO alarm word 1	
[3471]	MCO alarm word 2	
[4027]	Back EMF voltage	
[4029]	B-EMF protection log readout	To log events when B-EMF protection is disabled. This is a readout parameter to retrieve the data at a later point.
[4235]	S-CRC value	 NOTE: This option is only available in FC 302 with IMC software version 49.1X or newer.
[4280]	Safe option status	
[4281]	Safe option status 2	
[4282]	Safe control word	 NOTE: This option is only available in FC 302 with IMC software version 49.1X or newer.
[4283]	Safe status word	 NOTE: This option is only available in FC 302 with IMC software version 49.1X or newer.
[4285]	Active safe func.	
[4286]	Safe option info	
[4427]	Estimated D-axis inductance (Ld)	When [5] 1st start check motor or [6] Every st. check motor is selected in parameter 1-47 Torque Calibration , the last estimated Ld is shown.
[4429]	Estimated back EMF at 1000 RPM	When [5] 1st start check motor or [6] Every st. check motor is selected in parameter 1-47 Torque Calibration , the last estimated Back EMF at 1000 RPM is shown.
[4521]	Status	
[4522]	Progress	
[4523]	Baseline failure	
[4589]	Cavitation [%]	
[4590]	Stator [%]	
[4591]	Load [%]	

Option	Name	Description
[4592]	Sensor 1 [%]	
[4593]	Sensor 1 [unit]	
[4594]	Sensor 2 [%]	
[4595]	Sensor 2 [unit]	
[4596]	Sensor 3 [%]	
[4597]	Sensor 3 [unit]	
[4598]	Sensor 4 [%]	
[4599]	Sensor 4 [unit]	
[4901]	Autonomous status	
[4902]	Autonomous capacitance value	
[4911]	Baseline status	
[4916]	Baseline progress	

0-21 Display Line 1.2 Small

The options are the same as those listed for parameter **0-20 Display Line 1.1 Small**. Select a variable to show in line 1, center position.

0-22 Display Line 1.3 Small

The options are the same as those listed for parameter **0-20 Display Line 1.1 Small**. Select a variable to show in line 1, right position.

0-23 Display Line 2 Large

The options are the same as those listed for parameter **0-20 Display Line 1.1 Small**. Select a variable to show in line 2.

0-24 Display Line 3 Large

The options are the same as those listed for parameter **0-20 Display Line 1.1 Small**. Select a variable to show in line 3.

0-25 My Personal Menu

Default value:	Size related	Parameter type:	Array [50]
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Define up to 50 parameters to appear in the *Q1 Personal Menu*, accessible via the [Quick Menu] key on the LCP. The parameters are shown in the *Q1 Personal Menu* in the order they are programmed into this array parameter. Delete parameters by setting the value to 0000. For example, this can be used to provide quick, simple access to just 1 or up to 50 parameters, which require changing on a regular basis (for example, for plant maintenance reasons) or by an OEM to enable simple commissioning of their equipment.

6.2.5 0-3* LCP Custom Readout

It is possible to customize the display elements for various purposes:

- Custom readout. Value proportional to speed (linear, squared, or cubed depending on the unit selected in parameter **0-30 Custom Readout Unit**).
- Display text. Text string stored in a parameter.

Custom readout

The calculated value to be shown is based on the settings in:

- Parameter **0-30 Custom Readout Unit**.
- Parameter **0-31 Custom Readout Min Value** (linear only).
- Parameter **0-32 Custom Readout Max Value**.
- Parameter **4-13 Motor Speed High Limit [RPM]**.
- Parameter **4-14 Motor Speed High Limit [Hz]**.
- Actual speed.




Figure 30: Custom Readout

The relation depends on the type of unit selected in parameter **0-30 Custom Readout Unit**.

Table 10: Speed Relations for Different Unit Types

Unit type	Speed relation
Dimensionless	Linear
Speed	
Flow, volume	
Flow, mass	
Velocity	
Length	
Temperature	
Pressure	Quadratic
Power	Cubic

0-30 Unit for User-defined Readout

Default value:	[0] None	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

It is possible to program a value to be shown in the display of the LCP. The value has a linear, squared, or cubed relation to speed. This relation depends on the unit type selected. The actual calculated value can be read in parameter **16-09 Custom Readout**, and/or shown in the display by selecting **[16-09] Custom Readout** in parameter **0-20 Display Line 1.1 Small** to parameter **0-24 Display Line 3 Large**.

Option	Name	Description
[0]*	None	
[1]	%	
[5]	PPM	
[10]	1/min	
[11]	rpm	
[12]	Pulse/s	
[20]	l/s	
[21]	l/min	
[22]	l/h	
[23]	m ³ /s	
[24]	m ³ /min	
[25]	m ³ /h	
[30]	kg/s	
[31]	kg/min	
[32]	kg/h	
[33]	t/min	
[34]	t/h	
[40]	m/s	
[41]	m/min	
[45]	m	
[60]	°C	
[70]	mbar	
[71]	bar	
[72]	Pa	
[73]	kPa	
[74]	m WG	
[80]	kW	
[120]	GPM	
[121]	gal/s	
[122]	gal/min	
[123]	gal/h	
[124]	CFM	
[125]	ft ³ /s	

Option	Name	Description
[126]	ft ³ /min	
[127]	ft ³ /h	
[130]	lb/s	
[131]	lb/min	
[132]	lb/h	
[140]	ft/s	
[141]	ft/min	
[145]	ft	
[160]	°F	
[170]	psi	
[171]	lb/in ²	
[172]	in WG	
[173]	ft WG	
[176]	kpsi	
[177]	MPa	
[178]	kBar	
[180]	hp	

0-31 Min Value of User-defined Readout

Default value:	0 CustomReadoutUnit	Parameter type:	Range, -999999.99 CustomReadoutUnit - par. 0-32
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	True

This parameter sets the minimum value of the custom-defined readout (occurs at 0 speed). It is only possible to set different from 0 when selecting a linear unit in parameter **0-30 Unit for User-defined Readout**. For quadratic and cubic units, the minimum value is 0.

0-32 Custom Readout Max Value

Default value:	100 CustomReadoutUnit	Parameter type:	Range, par. 0-31 -999999.99 CustomReadoutUnit
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	True

This parameter sets the maximum value to be shown when the speed of the motor has reached the set value for parameter **4-13 Motor Speed High Limit [RPM]** or parameter **4-14 Motor Speed High Limit [Hz]** (depends on setting in parameter **0-02 Motor Speed Unit**).

0-33 Source of User-defined Readout

Default value:	[240] Default source	Parameter type:	Option
Setup:	All setups	Conversion index:	–

Data type:	UInt8	Change during operation:	True

Enter the source of the user-defined readout.

Option	Name	Description
[105]	Torque related to rated	
[143]	PID Clamped Output 4–20mA	
[240]*	Default Source	

0-34 System Use Notification Text

Default value:	Size related	Parameter type:	Range, 0 - 250
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[240]	Change during operation:	True

Enter a text notifying users about the need for authorization to operate the device and informing about the liability of actions taken.

Parameter 0-37 Display Text 1

Default value:	Size related	Parameter type:	Range, 0 - 25
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[25]	Change during operation:	True

Enter a text which can be viewed in the graphical display by selecting *[37] Display Text 1* in

- Parameter *0-20 Display Line 1 Small*
- Parameter *0-21 Display Line 1.2 Small*
- Parameter *0-22 Display Line 1.3 Small*
- Parameter *0-23 Display Line 2 Large*
- Parameter *0-24 Display Line 3 Large*

0-38 Display Text 2

Default value:	Size related	Parameter type:	Range, 0–25
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[25]	Change during operation:	True

Enter a text which can be viewed in the graphical display by selecting *[38] Display Text 2* in

- Parameter *0-20 Display Line 1 Small*
- Parameter *0-21 Display Line 1.2 Small*
- Parameter *0-22 Display Line 1.3 Small*
- Parameter *0-23 Display Line 2 Large*
- Parameter *0-24 Display Line 3 Large*

0-39 Display Text 3

Default value:	0	Parameter type:	Range, 0–25

Setup:	1 setup	Conversion index:	0
Data type:	VisStr[25]	Change during operation:	True

Enter a text which can be viewed in the graphical display by selecting **[39] Display Text 3** in

- Parameter **0-20 Display Line 1 Small**
- Parameter **0-21 Display Line 1.2 Small**
- Parameter **0-22 Display Line 1.3 Small**
- Parameter **0-23 Display Line 2 Large**
- Parameter **0-24 Display Line 3 Large**

6.2.6 0-4* LCP Keypad

Enable, disable, and password protect individual keys on the LCP.

0-40 [Hand On] Key on LCP

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Disabled	No effect when [Hand On] is pressed. Select [0] Disabled to avoid accidental start of the drive in hand-on mode.
[1]	Enabled	The LCP switches to hand-on mode directly when [Hand On] is pressed.
[2]	Password	After pressing [Hand On] a password is required. If parameter 0-40 [Hand on] Key on LCP is included in <i>My Personal Menu</i> , define the password in parameter 0-65 Personal Menu Password . Otherwise define the password in parameter 0-60 Main Menu Password .
[3]	Hand Off/On	When [Hand On] is pressed once, the LCP switches to Off mode. When pressed again, the LCP switches to hand-on mode.
[4]	Hand Off/On w. Passw.	Same as option [3] Hand Off/On but a password is required (see option [2] Password).
[9]	Enabled, ref=0	When switching to [Hand On], the reference is set to 0.

0-41 [Off] Key on LCP

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Disabled	Avoids accidental stop of the drive.
[1]	Enabled	
[2]	Password	Avoids unauthorized stop. If parameter 0-41 [Off] Key on LCP is included in the Quick Menu, then define the password in parameter 0-65 Personal Menu Password .

0-42 [Auto On] Key on LCP

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Disabled	Avoids accidental stop of the drive in auto-on mode.
[1]	Enabled	
[2]	Password	Avoids unauthorized start in auto-on mode. If parameter 0-42 [Auto on] Key on LCP is included in the Quick Menu, then define the password in parameter 0-65 Personal Menu Password .

0-43 [Reset] Key on LCP

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Disabled	No effect when [Reset] is pressed. Avoids accidental alarm reset.
[1]	Enabled	
[2]	Password	Avoids unauthorized start in auto-on mode. If parameter 0-43 [Reset] Key on LCP is included in the Quick Menu, define the password in parameter 0-65 Personal Menu Password .
[7]	Enabled without OFF	Resets the drive without setting it in Off mode.
[8]	Password without OFF	Resets the drive without setting it in Off mode. A password is required when pressing [Reset] (see option [2] Password).

0-44 [Off/Reset] Key on LCP

Default value:	[1] Enabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available when a VLT® Bypass Option MCB 104 is installed in the drive.

Enable or disable the [Off/Reset] key.

Option	Name	Description
[0]	Disabled	No effect when [Reset] is pressed. Avoids accidental alarm reset.
[1]*	Enabled	
[2]	Password	Avoids unauthorized start in auto-on mode. If parameter 0-43 [Reset] Key on LCP is included in the Quick Menu, define the password in parameter 0-65 Personal Menu Password .

0-45 [Drive Bypass] Key on LCP

Default value:	[1] Enabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available when a VLT® Bypass Option MCB 114 is installed in the drive.

Press [Off] and select **[0] Disabled** to avoid unintended stop of the drive. Press [Off] and select **[2] Password** to avoid unauthorized bypass of the drive. If parameter **0-45 [Drive Bypass] Key on LCP** is included in the Quick Menu, define the password in parameter **0-65 Personal Menu Password**.

Option	Name	Description
[0]	Disabled	Disables the key.
[1]*	Enabled	
[2]	Password	

6.2.7 0-5* Copy/Save

Copy parameters from and to the LCP. Use these parameters for saving and copying setups from 1 drive to another.

0-50 LCP Copy

Default value:	[0] No copy	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Option	Name	Description
[0]*	No copy	
[1]	All to LCP	Copies all parameters in all setups from the drive memory to the LCP memory.
[2]	All from LCP	Copies all parameters in all setups from the LCP memory to the drive memory.

Option	Name	Description
[3]	Size indep. from LCP	Copy only the parameters that are independent of the motor size. This selection can be used to program several drives with the same function without disturbing motor data.
[4]	File from MCO to LCP	Copy the MCO file to the LCP memory.
[5]	File from LCP to MCO	Copy the MCPO file from the LCP memory to MCO.
[6]	Data from DYN to LCP	
[7]	Data from LCP to DYN	
[9]	Safety Par. from LCP	Copy the safety parameters from the LCP to the drive memory.
[10]	Delete LCP copy data	Use to delete the copy after the transfer is complete.
[11]	Security to LCP	Copy only the <i>Security Configuration File</i> to the LCP.
[12]	Security from LCP	NOTE: This option requires an authorized account with permission to update. Update the <i>Security Configuration File</i> from the LCP.
[13]	Security&Params to LCP	Create a backup of the <i>Security Configuration File</i> and all the application parameters to the LCP.
[14]	Security&Params from LCP	Copies the <i>Security Configuration File</i> and all the application parameters from the LCP.

0-51 Set-up Copy

Default value:	[0] No copy	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	No copy	No function.
[1]	Copy to set-up 1	Copies all parameters in the present programming setup (defined in parameter 0-11 Edit Set-up) to set-up 1.
[2]	Copy to set-up 2	Copies all parameters in the present programming setup (defined in parameter 0-11 Edit Set-up) to set-up 2.
[3]	Copy to set-up 3	Copies all parameters in the present programming setup (defined in parameter 0-11 Edit Set-up) to set-up 3.
[4]	Copy to set-up 4	Copies all parameters in the present programming setup (defined in parameter 0-11 Edit Set-up) to set-up 4.
[9]	Copy to all	Copies the parameters in the present setup to each of the setups 1 to 4.

6.2.8 0-6* Password



NOTE: When a security file is enabled, the password settings in parameter group **0-6* Password** are disabled.

0-60 Main Menu Password

Default value:	Size related	Parameter type:	Range, -9999 - 9999
Setup:	1 setup	Conversion index:	0
Data type:	Int16	Change during operation:	True

Define the password for access to the Main Menu via the [Main Menu] key. If parameter **0-61 Access to Main Menu w/o Password** is set to [0] **Full access**, this parameter is ignored. When a valid password is entered, this unlocks the drive for 30 minutes.

0-61 Access to Main Menu w/o Password

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

If [0] **Full access** is selected, parameter **0-60 Main Menu Password**, parameter **0-65 Personal Menu Password**, and parameter **0-66 Access to Personal Menu w/o Password** are ignored.

Option	Name	Description
[0]	Full access	Disables password defined in parameter 0-60 Main Menu Password .
[1]	LCP: Read only	Prevent unauthorized editing of Main Menu parameters.
[2]	LCP: No access	Prevent unauthorized viewing and editing of Main Menu parameters.
[3]	Bus: Read only	Read-only functions for parameters on fieldbus and/or FC standard bus.
[4]	Bus: No access	No access to parameters is allowed via fieldbus and/or FC standard bus.
[5]	All: Read only	Read-only function for parameters on LCP, fieldbus, or FC standard bus.
[6]	All: No access	No access from LCP, fieldbus, or FC standard bus is allowed.
[7]	Secure configuration	Security file is applied.

0-65 Personal Menu Password

Default value:	200	Parameter type:	Range, -9999 - 9999
Setup:	1 setup	Conversion index:	0
Data type:	Int16	Change during operation:	True

Define the password for access to the Quick Menu via the [Quick Menu] key. If parameter **0-66 Access to Personal Menu w/o Password** is set to [0] **Full access**, this parameter is ignored.

0-66 Access to Personal Menu w/o Password

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

If parameter **0-61 Access to Main Menu w/o Password** is set to **[0] Full access**, this parameter is ignored.

Option	Name	Description
[0]	Full access	Disables password defined in parameter 0-65 Personal Menu Password .
[1]	LCP: Read only	Prevent unauthorized editing of Quick Menu parameters.
[3]	Bus: Read only	Read-only functions for Quick Menu parameters on fieldbus and/or FC standard bus.
[5]	All: Read only	Read-only function for Quick Menu parameters on LCP, fieldbus, or FC standard bus.
[7]	Secure configuration	Security file is applied.

0-67 Bus Password Access

Default value:	0	Parameter type:	Range, 0 - 9999
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Use this parameter to unlock the drive via fieldbus or VLT® Motion Control Tool MCT 10.

When a valid password is entered, the drives is unlocked for 30 minutes.

0-68 Safety Parameters Password

Default value:	300	Parameter type:	Range, 0 - 9999
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter the password for the safety parameters access. If parameter **0-69 Password Protection of Safety Parameters** is set to **[0] Disabled**, this parameter is ignored.

0-69 Password Protection of Safety Parameters

Default value:	[0] Disabled	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	

6.2.9 0-7* Clock Settings

0-70 Date and Time

Default value:	Size related	Parameter type:	Range, 0 - 0
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

Sets the date and time of the internal clock. The format to be used is set in parameter **0-71 Date Format** and parameter **0-72 Time Format**. When using the VLT® Real-time Clock MCB 117 option, the time is synchronized at 15:00 every day.

0-71 Date Format

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the date format to be used in the LCP.

Option	Name	Description
[0]	YYYY-MM-DD	
[1]	DD-MM-YYYY	
[2]	MM/DD/YYYY	

0-72 Time Format

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Set the time format to be used in the LCP.

Option	Name	Description
[0]	24 h	
[1]	12 h	

0-73 Time Zone Offset

Default value:	0 min	Parameter type:	Range, -780...780 min
Setup:	2 setups	Conversion index:	70
Data type:	Int16	Change during operation:	False

Enter the time zone offset relative to UTC. This parameter is required for the automatic daylight saving time adjustment.

0-74 DST/Summertime

Default value:	[0] Off	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select how to handle daylight saving time/summer time. For manual setting of DST/summer time, enter the start date and end date in parameter **0-76 DST/Summertime Start** and parameter **0-77 DST/Summertime End**.

Option	Name	Description
[0]*	Off	
[2]	Manual	

0-75 Last Power Off Time

Default value:	Size related	Parameter type:	Readout, Array [5]
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

This parameter stores the last 5 drive power-off timestamps. Index [0] is the latest power-off time, and index [4] is the oldest.

0-76 DST/Summertime Start

Default value:	Size related	Parameter type:	Range, 0 - 0
Setup:	1 setup	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

Sets the date and time when DST/summer time starts. The date is programmed in the format selected in parameter **0-71 Date Format**.

0-77 DST/Summertime End

Default value:	Size related	Parameter type:	Range, 0 - 0
Setup:	1 setup	Data type:	TimeOfDay
Change during operation:	True		

Sets the date and time when DST/summer time ends. The date is programmed in the format selected in parameter **0-71 Date Format**.

0-79 Clock Fault

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Enables or disables the clock warning when the clock has not been set, or has been reset due to a power-down and no backup is installed.

Option	Name	Description
[0]	Disabled	
[1]	Enabled	

0-81 Working Days

Default value:	–	Parameter type:	Option, Array [7]
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Array with 7 elements [0]–[6] shown below the parameter number in the display. Press [OK] and step between elements with [▲] and [▼]. Set for each weekday if it is a working day or a non-working day. The first element of the array is Monday. The working days are used for timed actions.

Option	Name	Description
[0]	No	
[1]	Yes	

0-82 Additional Working Days

Default value:	Size related	Parameter type:	Array [5]
Setup:	1 setup	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

Array with 5 elements [0]–[4] shown below the parameter number in the display. Press [OK] and step between elements with [▲] and [▼]. Defines dates for additional working days that would normally be non-working days according to parameter **0-81 Working Days**.

0-83 Additional Non-working Days

Default value:	Size related	Parameter type:	Array [15]
Setup:	1 setup	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

Array with 15 elements [0]–[14] shown below the parameter number in the display. Press [OK] and step between elements with [▲] and [▼]. Defines dates for additional working days that would normally be non-working days according to parameter **0-81 Working Days**.

0-84 Time for Fieldbus

Default value:	0	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Shows the time for fieldbus.

0-85 Summer Time Start for Fieldbus

Default value:	0	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Parameter type:	Uint32	Change during operation:	True

Shows the summer time start for fieldbus.

0-86 Summer Time End for Fieldbus

Default value:	0	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Shows the summer time end for fieldbus.

0-88 Clock Restore at Powerup

Default value:	[0] Disabled	Parameter type:	Option

Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	Disabled	Restoring the time at power-up is disabled.
[1]	Enabled	Restoring the time at power-up is enabled. Date and time will be stored at power down. When the drive is powered up, the previous time is used. As the previous time is incorrect, <i>warning 98, Clock Fault</i> is issued and stays active until date and time are set again.

0-89 Date and Time Readout

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[25]	Change during operation:	True

Shows the current date and time. The date and time is updated continuously. The clock does not begin counting until a setting different from default has been made in parameter **0-70 Date and Time**.

6.2.10 0-9* Varia

0-91 Integrity Check at Power-up

Default value:	[0] No check	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

This parameter controls the behavior of the boot time integrity check of installed software. The boot loader checks the integrity of the application firmware before loading and executing, both AOC and DTM. If the integrity check fails for AOC, the boot process is stopped. On the next power-up, the drive will try to execute Testmonitor instead. Testmonitor mode can be used to flash another software. However, if the integrity check also fails for Testmonitor, the control card cannot be recovered on the field and must be replaced.

The integrity of the *Security Configuration File* (SCF) is always checked on every power-up and on every update of the file. If this parameter is set to **[2] Always**, the integrity of the SCF is checked before being loaded.

Option	Name	Description
[0]*	No check	There is no boot time integrity check of the firmware. However, a check of the SCF takes place.
[1]	After firmware update	The integrity of the firmware is only checked once on the next power-up after a software update.
[2]	Always	The integrity of software and the SCF is checked at every power-up. Depending on the size of the software and SCF, the integrity check may delay the start-up time by 2–3 s.

0-92 Checksum (SHA256)

Default value:	0	Parameter type:	Readout, Array [7]

Setup:	All setups	Conversion index:	0
Data type:	VisStr[64]	Change during operation:	False

This is a readout parameter for integrity hash values (256-bit value produced by SHA-2 algorithm represented as 64 hexadecimal symbols). Each index shows a calculated hash of an installed application firmware or stored file that is a fundamental corner stone maintaining the integrity and security of the device.

Index values correspond to the following:

- [0] Checksum of the installed Application Oriented Controller (AOC) software.
- [1] Checksum of the *Security Configuration File*, 0 if the security file is not uploaded to the drive, or it is not in use/invalid.
- [2] 0, reserved.
- [3] Checksum of the installed Testmonitor software.
- [4] Always 0, reserved.
- [5] B-option FW.
- [6] C-option FW.

0-93 Session Timeout (in Seconds)

Default value:	300 s	Parameter type:	Range, 30 - 3000000
Setup:	1 setup	Conversion index:	0
Data type:	UInt32	Change during operation:	True

Set for how many seconds a session of a logged-in user is kept active after a period of inactivity. Inactivity is measured differently for different access ports. For the LCP, a user is defined as inactive if no keys are pressed. Serial or network communication is inactive if no requests are sent to the drive.

0-94 Max Login Attempts

Default value:	5	Parameter type:	Range, 1 - 255
Setup:	1 setup	Conversion index:	0
Data type:	UInt8	Change during operation:	True

Set the number of failed login attempts that are allowed on a given interface before a rate-limited cool-down is activated on that interface. When an interface is in cool-down for the 1st time, no user sessions can be started on that access port for 30 s. Following authentication failures on the channel will increase the cool-down time geometrically until reaching a sealing limit of approximately 8 minutes. During the cool-down time, all user log-on actions will fail. This is a measure to protect the drive from brute force attacks using the hardware of the unit. To avoid a denial of service attack, a cool-down can be ended prematurely on a given interface if an authorized person logs in on another channel and changes the value of this parameter.

Changing the value of this parameter resets all the cool-down timers for all the interfaces.

The factory setting is 5 failed attempts before cool-down is activated. If the cool-down behavior is not acceptable, set the parameter to a maximum value of 255.

0-95 Warning LED Blinking

Default value:	[0] Constant on	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	Constant on	
[1]	Blinking	Use [1] Blinking to identify a drive when many drives are mounted together.

6.3 Parameter Group 1-** Load and Motor

6.3.1 1-0* General Settings

Define whether the drive operates in speed mode or torque mode, and whether the internal PID control should be active or not.



NOTE:

The following parameters are only available in FC 302:

- Parameter **1-02 Flux Motor Feedback Source**
- Parameter **1-07 Motor Angle Offset Adjust**

1-00 Configuration Mode

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the application control principle to be used when a remote reference (that is via analog input or fieldbus) is active. A remote reference can only be active when parameter **3-13 Reference Site** is set to **[0] Linked to Hand/Auto** or **[1] Remote**.

Option	Name	Description
[0]	Speed open loop	Enables speed control (without feedback signal from motor) with automatic slip compensation for almost constant speed at varying loads. Compensations are active, but can be disabled in parameter group 1-** Load and Motor . Set the speed control parameters in parameter group 7-0* Speed PID Ctrl.
[1]	Speed closed loop	Enables speed closed-loop control with feedback. Obtain full holding torque at 0 RPM. For increased speed accuracy, provide a feedback signal and set the speed PID control. Set the speed control parameters in parameter group 7-0* Speed PID Ctrl.
[2]	Torque	NOTE: This option is only available in FC 302. Enables torque closed-loop control with feedback. Only possible when parameter 1-01 Motor Control Principle is set to [3] Flux w/ motor feedb.
[3]	Process	Enables the use of process control in the drive. Set the process control parameters in parameter groups 7-2* Process Ctrl. Feedb. and 7-3* Process PID Ctrl.
[4]	Torque open loop	Enables the use of torque open-loop mode (parameter 1-01 Motor Control Principle). Set the torque PID parameters in parameter group 7-1* Torque PI Control.

Option	Name	Description
[5]	Wobble	Enables the wobble functionality in parameter 30-00 Wobble Mode to parameter 30-19 Wobble Delta Freq. Scaled .
[6]	Surface winder	Enables the surface winder control-specific parameters in parameter groups 7-2* Process Ctrl. Feedb. and 7-3* Process PID Ctrl.
[7]	Extended PID speed OL	Specific parameters in parameter groups 7-2* Process Ctrl. Feedb. to 7-5* Ext. Process PID Ctrl.
[8]	Extended PID speed CL	Specific parameters in parameter groups 7-2* Process Ctrl. Feedb. to 7-5* Ext. Process PID Ctrl.
[9]	Positioning	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Activates positioning mode.
[10]	Synchronization	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Activates synchronization mode.
[11]	Cyclic sync. position	NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer. Activates cyclic synchronous position mode.
[12]	Cyclic sync. velocity	NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer. Activates cyclic synchronous velocity mode.
[15]	Mode of operation DS402	NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer. DS 402 operation modes are selected by parameter 1-09 Mode of Operation . With this selection, parameter 8-10 Control Word Profile is automatically set to [7] CANopen DSP 402 and the control word bits are used according to the DS 402 profile based on the selection in parameter 1-09 Mode of Operation .

1-01 Motor Control Principle

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False

Select which motor control principle to employ. The best shaft performance is achieved by using either flux vector control modes **[2] Flux sensorless** or **[3] Flux w/motor feedb.**

Option	Name	Description
[0]	U/f	Special motor mode, for parallel-connected motors in special motor applications. When U/f is selected, the characteristic of the control principle can be edited in parameter 1-55 U/f Characteristic - U and parameter 1-56 U/f Characteristic - F .
[1]	VVC+	Voltage vector control principle is suitable for most applications. The main benefit of VVC+ operation is that it uses a robust motor model.
[2]	Flux sensorless	 NOTE: This option is only available in FC 302. Flux vector control without encoder feedback, for simple installation and robustness against sudden load changes.
[3]	Flux w/motor feedb	 NOTE: This option is only available in FC 302. High accuracy speed and torque control, suitable for the most demanding applications.

1-02 Flux Motor Feedback Source

Default value:	[1] 24V encoder 32/33	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

 NOTE: This parameter cannot be adjusted while the motor is running.

 NOTE: Options **[12] MCB 102 Absolute** and **[13] 24V encoder 27/29** are only available in FC 302 with IMC software version 48.3X or newer.

Select the source of the feedback for flux closed-loop motor control. Set parameter **1-01 Motor Control Principle** to **[3] Flux with motor feedback option**. The feedback device is typically mounted directly on the motor shaft. The feedback device can also be mounted in the application, provided that the gear ratio between motor and encoder is fixed and accurate. Configure the gear ratio between motor and encoder in parameter **7-94 Position PI Feedback Scale Numerator** and parameter **7-95 Position PI Feedback Scale Denominator** without any rounding error.

Option	Name	Description
[1]*	24V encoder 32/33	Single signal generated from 24 V High Threshold Logic (HTL) encoder connected to terminals 32 and 33. Configure the 24 V encoder interface in parameter group 5.7* 24 V Encoder Input . Program terminals 32/33 to [0] No operation .
[2]	MCB 102	This option is only available for VLT® Encoder Option MCB 102. Configure the encoder interface in parameter groups 17-0* Encoder Interface , 17-1* Inc. Enc. Interface , and 17-2* Abs. Enc. Interface .
[3]	MCB 103	This option is only available for VLT® Resolver Option MCB 103. Configure the resolver interface in parameter group 17-5* Resolver Interface .

Option	Name	Description
[4]	MCO Encoder 1 X56	The MCO encoder 1 X56 is only available with motion control options MCO 305, MCO 350 and MCO 351. Configure the encoder interface in parameter group 32-3* Encoder 1 .
[5]	MCO Encoder 2 X55	The MCO encoder 1 X56 is only available with motion control options MCO 305, MCO 350 and MCO 351. Configure the encoder interface in parameter group 32-0* Encoder 2 .
[6]	Analog input 53	
[7]	Analog input 54	
[8]	Frequency input 29	
[9]	Frequency input 33	
[11]	MCB 15X	
[12]	MCB 102 Absolute	The option is only available for VLT® Encoder Option MCB 102 with version 4.00 and higher and when parameter 17-00 Encoders Connected is set to [1] Two Encoders .
[13]	24V encoder 27/29	Single-signal HTL encoder connected to digital inputs 27 and 29. 24 V encoder is configured in parameter group 5.7* 24V Encoder Input . Program terminals 27/29 to [0] No operation .
[20]	None	

1-03 Torque Characteristics

Default value:	[0] Constant torque	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter cannot be adjusted while the motor is running.

Select the torque characteristic required. VT and AEO are both energy-saving operations.

Option	Name	Description
[0]*	Constant torque	Motor shaft output provides constant torque under variable speed control.
[1]	Variable torque	Motor shaft output provides variable torque under variable speed control. Set the variable torque level in parameter 14-40 VT Level .

Option	Name	Description
[2]	Auto energy optim.	Automatically optimizes energy consumption by minimizing magnetization and frequency via parameter 14-41 AEO Minimum Magnetisation and parameter 14-42 Minimum AEO Frequency .
[5]	Constant power	The function provides a constant power in the field weakening area. The torque shape of motor mode is used as a limit in the generator mode. This is done to limit the power in generator mode that otherwise becomes considerably larger than in motor mode, due to the high DC-link voltage available in generator mode. $P_{\text{shaft}}[W] = \omega_{\text{mech}}[\text{rad/s}] \times T[\text{Nm}]$




Figure 31: Relationship with Constant Power

1-04 Overload Mode

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Use this parameter to configure the drive for either high or normal overload. When selecting the drive size, always review the technical data in the operating guide or the design guide to know the available output current.

Option	Name	Description
[0]	High torque	Allows up to 160% overtorque.
[1]	Normal torque	For oversized motor. Allows up to 110% overtorque.

1-05 Local Mode Configuration

Default value:	[2] As mode par. 1-00	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select which application configuration mode (parameter **1-00 Configuration Mode**), that is application control principle, to use when a local (LCP) reference is active. A local reference can be active only when parameter **3-13 Reference Site** is set to **[0] Linked to Hand/Auto** or **[2] Local**. By default the local reference is active in hand-on mode only.

Option	Name	Description
[0]	Speed open loop	This selection controls the motor speed from 0 to maximum speed.
[1]	Speed closed loop	
[2]*	As mode par. 1-00	This selection controls the motor speed from minimum to maximum reference.
[4]	Positioning	

1-06 Clockwise Direction

Default value:	[0] Normal	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

This parameter defines the term clockwise corresponding to the LCP direction arrow. Used for easy change of direction of shaft rotation without swapping motor wires.

Option	Name	Description
[0]*	Normal	The motor shaft turns in clockwise direction when the drive is connected U⇒U, V⇒V, and W⇒W to the motor.
[1]	Inverse	The motor shaft turns in counterclockwise direction when the drive is connected U⇒U, V⇒V, and W⇒W to the motor.
[2]	Inverse all	Inverts motor direction, feedback direction, and angle offset on PM motor.

1-07 Motor Angle Offset Adjust

Default value:	[0] Manual	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only valid in the combination of a PM motor with feedback.

Option	Name	Description
[0]*	Manual	The functionality of this option depends on the type of the feedback device. This option sets the drive to use the motor angle offset entered in parameter 1-41 Motor Angle Offset , if an absolute feedback device is used. If an incremental feedback device is selected, the drive automatically adjusts the motor angle offset on the 1st start after power-up, or when the motor data is changed.
[1]	Auto	The drive adjusts the motor angle offset automatically on the 1st start after power-up, or when the motor data is changed no matter what feedback device is selected. This means that the options [1] Manual and [2] Auto are identical for the incremental encoder.
[2]	Auto every start	The drive adjusts the motor angle offset automatically on every start, or when the motor data is changed.
[3]	Off	Selecting this option turns the automatic offset adjustment off.
[4]	Once with store	This option updates parameter 1-41 Motor Angle Offset automatically when the angle value is 0. This option is valid only for absolute feedback devices. The function uses rotor detection and then applies DC hold to make the offset adjustment more accurate.
[5]	Auto Every Start & Run	Rotor angle offset is adjusted at every start and when reducing speed below parameter 1-53 Model Shift Frequency . Motor control is sensorless above parameter 1-53 Model Shift Frequency using the estimated rotor position as feedback. Below parameter 1-53 Model Shift Frequency the encoder is used as feedback.
[6]	Auto first start & run	See the descriptions of [1] Auto and [5] Auto every start & run .
[7]	Manual & run	See the descriptions of [0] Manual and [5] Auto every start & run .

1-09 Mode of Operation

Default value:	[0] No mode change	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available with software version 48.8X and newer.

Select mode of operation according to CANopen DS402. This parameter is only active when parameter **1-00 Configuration Mode** is set to **[15] Mode of operation**.

Option	Name	Description
[0]*	No mode change	No mode of operation selected. Active mode of operation is velocity mode.
[1]	Profile position mode	Basic positioning mode where the drive profile generator calculates the speed profile based on set target position, speed and ramps.
[2]	Velocity mode (vl)	Basic speed mode using the set speed and ramps.

Option	Name	Description
[6]	Homing mode	Activates the homing function selected in parameter 17-80 Homing Function .
[8]	Cyclic sync position mode	The drive controls the position based on cyclic position reference from an external controller. Speed/ramp profile must be calculated/handled by the external controller.
[9]	Cyclic sync velocity mode	The drive controls the speed based on cyclic speed reference from an external controller. Acceleration/deceleration must be handled by the external controller.
[249]	Gear mode	The drive is synchronizing to the provided master positions using the set gear ratio.
[250]	Cam mode	The drive is synchronizing to the provided master positions according to the set Cam table.

6.3.2 Motor Setups

6.3.2.1 Induction Motor Setup

Enter the following motor data. Find the information on the motor nameplate.

- Parameter **1-20 Motor Power [kW]** or parameter **1-21 Motor Power [HP]**.
- Parameter **1-22 Motor Voltage**.
- Parameter **1-23 Motor Frequency**.
- Parameter **1-24 Motor Current**.
- Parameter **1-25 Motor Nominal Speed**.

When running in flux mode, or in VVC+ mode, extra motor data is required to set up the following parameters. Find the data in the motor datasheet (this data is typically not available on the motor nameplate). Run a complete automatic motor adaptation (AMA) using parameter **1-29 Automatic Motor Adaptation (AMA) [1] Enable Complete AMA** or enter the parameters manually. Parameter **1-36 Iron Loss Resistance (Rfe)** is always entered manually.

- Parameter **1-30 Stator Resistance (Rs)**.
- Parameter **1-31 Rotor Resistance (Rr)**.
- Parameter **1-33 Stator Leakage Reactance (X1)**.
- Parameter **1-34 Rotor Leakage Reactance (X2)**.
- Parameter **1-35 Main Reactance (Xh)**.
- Parameter **1-36 Iron Loss Resistance (Rfe)**.

Application-specific adjustment when running VVC+

VVC+ is the most robust control mode. In most situations, it provides optimum performance without further adjustments. Run a complete AMA for best performance.

Application-specific adjustment when running flux

Flux control mode is the preferred control principle for optimum shaft performance in dynamic applications. Perform an AMA since this control mode requires precise motor data. Depending on the application, further adjustments may be required.

Table 11: Recommendations for Flux Applications

Application	Settings
Low-inertia applications	Keep calculated values.
High-inertia applications	Parameter 1-66 Min. Current at Low Speed . Increase current to a value between default and maximum depending on the application. Set ramp times matching in the application. Too fast ramp up causes an overcurrent or overtorque. Too fast ramp down causes an overvoltage trip.
High load at low speed	Parameter 1-66 Min. Current at Low Speed . Increase current to a value between default and maximum depending on the application.
No-load application	Adjust parameter 1-18 Min. Current at No Load to achieve a smoother motor operation by reducing torque ripple and vibration.
Flux sensorless control principle only	Adjust parameter 1-53 Model Shift Frequency . Example 1: If the motor oscillates at 5 Hz, and dynamic performance is required at 15 Hz, set parameter 1-53 Model Shift Frequency to 10 Hz. Example 2: If the application involves dynamic load changes at low speed, reduce parameter 1-53 Model Shift Frequency . Observe the motor behavior to make sure that the model shift frequency is not reduced too much. Symptoms of inappropriate model shift frequency are oscillations or drive tripping.

6.3.2.2 PM Motor Setup

NOTICE

PM motor setup is only available in FC 302.

This section describes how to set up a PM motor. The following example covers a non-salient PM motor.

6.3.2.3 Programming of Permanent Magnet Motors

6.3.2.3.1 Initial Programming Steps

1. To activate permanent magnet motor operation, select **[1] PM, non-salient SPM** in parameter **1-10 Motor Construction**.

6.3.2.3.2 Programming Motor Data

After selecting a permanent magnet motor, the permanent magnet motor-related parameters in parameter groups **1-2* Motor Data**, **1-3* Adv. Motor Data**, and **1-4* Adv. Motor Data II** are active. The necessary data is on the motor nameplate and on the motor datasheet.

1. Set parameter **1-24 Motor Current**.
2. Set parameter **1-25 Motor Nominal Speed**.
3. Set parameter **1-26 Motor Cont. Rated Torque**.
4. Set parameter **1-39 Motor Poles**.
5. Run a complete AMA by setting parameter **1-29 Automatic Motor Adaptation (AMA)** to **[1] Enable complete AMA**.

6. If a complete AMA is NOT performed, configure the following parameters manually:
 - a. Parameter **1-30 Stator Resistance (Rs)**: Enter the line-to-common stator winding resistance (Rs). If only line-to-line data is available, divide the line-to-line value by 2 to get the line-to-common value.
 - b. Parameter **1-37 d-axis Inductance (Ld)**: Enter the line-to-common direct axis inductance of the permanent magnet motor. If only line-to-line data is available, divide the line-to-line value by 2 to get the line-to-common value.
 - c. Parameter **1-40 Back EMF at 1000 RPM**: Enter the line-to-line back EMF of the permanent magnet motor at 1000 RPM (RMS value). Back EMF is the voltage generated by a permanent magnet motor when no drive is connected and the shaft is turned externally. It is normally specified for nominal motor speed or for 1000 RPM measured between 2 lines. If the value is not available for a motor speed of 1000 RPM, calculate the correct value as follows: If back EMF is, for example, 320 V at 1800 RPM, it can be calculated at 1000 RPM as follows: Back EMF = (Voltage/RPM)x1000 = (320/1800)x1000 = 178.
7. For IPM motors, configure the inductance values in the following parameters:
 - a. Parameter **1-38 q-axis Inductance (Lq)**.
 - b. Parameter **1-44 d-axis Inductance Sat. (LdSat)**.
 - c. Parameter **1-45 q-axis Inductance Sat (LqSat)**.
 - d. Parameter **1-49 q-axis Inductance Sat. Point**.



NOTE: IPM motors may be missing some inductance values on the product label or in the datasheets. Perform an AMA to get the valid values.

6.3.2.3.3 Testing Motor Operation

1. Start the motor at low speed (100–200 RPM). If the motor does not turn, check the installation, general programming, and motor data.
2. Check if the start function in parameter **1-70 Start Mode** fits the application requirements.

6.3.2.3.4 Activating Permanent Magnet Rotor Detection

This function is the recommended selection for applications where the motor starts from standstill, for example pumps or conveyors. On some motors, a sound is heard when the drive performs the rotor detection. This does not harm the motor.

1. Select **[0] Rotor detection** in parameter **1-70 Start Mode**.



Rotor detection is now activated.

6.3.2.3.5 Activating Permanent Magnet Parking

This function is the recommended selection for applications where the motor is rotating at slow speed, for example, windmilling in fan applications. Parameter **2-06 Parking Current** and parameter **2-07 Parking Time** can be adjusted. Increase the factory setting of these parameters for applications with high inertia.

1. Select **[1] Parking** in parameter **1-70 Start Mode**.



Parking is now activated.

6.3.2.3.6 Application-specific Adjustment when Running VVC+

VVC+ is the most robust control mode. In most situations, it provides optimum performance without further adjustments. Run a complete AMA for best performance.

Start the motor at nominal speed. If the application does not run well, check the VVC+ permanent magnet motor settings. See recommendations for various applications in [Table 12](#).

Table 12: Recommendations for Various Applications

Application	Settings
Low-inertia applications $I_{Load}/I_{Motor} < 5$	Increase parameter 1-17 Voltage Filter Time Const. by factor 5–10. Reduce parameter 1-14 Damping Gain . Reduce parameter 1-66 Min. Current at Low Speed (<100%).
Low-inertia applications $50 > I_{Load}/I_{Motor} > 5$	Keep the default values.
High-inertia applications $I_{Load}/I_{Motor} > 50$	Increase parameter 1-14 Damping Gain , parameter 1-15 Low Speed Filter Time Const. , and parameter 1-16 High Speed Filter Time Const.
High load at low speed <30% (rated speed)	Increase parameter 1-17 Voltage Filter Time Const. Increase parameter 1-66 Min. Current at Low Speed to adjust the starting torque. 100% current provides nominal torque as starting torque. This parameter is independent of parameter 30-20 High Starting Torque Time [s] and parameter 30-21 High Starting Torque Current [%] . Working at a current level higher than 100% for a prolonged time can cause the motor to overheat.

If the motor starts oscillating at a certain speed, increase parameter **1-14 Damping Gain**. Increase the value in small steps. Depending on the motor, this parameter can be set to 10–100% higher than the default value.

Application-specific adjustment when running flux

The flux control principle is the preferred control principle for optimum shaft performance in dynamic applications. Perform and AMA because this control mode requires precise motor data. Depending on the application, further adjustments may be required.

6.3.2.4 SynRM Motor Setup with VVC+

The SmartStart wizard covers the basic configuration of SynRM motors.

6.3.2.5 Programming of SynRM Motors

6.3.2.5.1 Initial Programming

1. Select **[5] Sync. Reluctance** in parameter **1-10 Motor Construction**.

SynRM motor operation is activated.

6.3.2.5.2 Programming SynRM Motor Data

After performing the initial programming steps, the SynRM motor-related parameters in parameter groups **1-2* Motor Data**, **1-3* Adv. Motor Data**, and **1-4* Adv. Motor Data II** are active. Find the required motor data on the motor data on the motor nameplate and in the motor datasheet.

1. Program in the following order:
 - a. Parameter **1-23 Motor Frequency**.
 - b. Parameter **1-24 Motor Current**.
 - c. Parameter **1-25 Motor Nominal Speed**.
 - d. Parameter **1-26 Motor Cont. Rated Torque**.
2. Run a complete AMA.
 - Select **[1] Enable complete AMA** in parameter **1-29 Automatic Motor Adaptation (AMA)**, or

- Enter the following manually:
 - Parameter **1-30 Stator Resistance (Rs)**.
 - Parameter **1-37 d-axis Inductance (Ld)**.
 - Parameter **1-44 d-axis Inductance Sat. (LdSat)**.
 - Parameter **1-45 q-axis Inductance Sat. (LqSat)**.
 - Parameter **1-48 Inductance Sat. Point**.

6.3.2.5.3 Application-specific Adjustment when Running VVC+ with SynRM Motors

VVC+ is the most robust control mode. In most situations, it provides optimum performance without further adjustments. Run a complete AMA for best performance.

Start the motor at nominal speed. If the application does not run well, check the VVC+ SynRM settings. See recommendations for various applications in [Table 13](#).

Table 13: Recommendations for Various Applications

Application	Settings
Low-inertia applications $I_{Load}/I_{Motor} < 5$	Increase parameter 1-17 Voltage Filter Time Const. by factor 5–10. Reduce parameter 1-14 Damping Gain . Reduce parameter 1-66 Min. Current at Low Speed (<100%).
Low-inertia applications $50 > I_{Load}/I_{Motor} > 5$	Keep the default values.
High-inertia applications $I_{Load}/I_{Motor} > 50$	Increase parameter 1-14 Damping Gain , parameter 1-15 Low Speed Filter Time Const. , and parameter 1-16 High Speed Filter Time Const.
High load at low speed <30% (rated speed)	Increase parameter 1-17 Voltage Filter Time Const. Increase parameter 1-66 Min. Current at Low Speed to adjust the starting torque. 100% current provides nominal torque as starting torque. This parameter is independent of parameter 30-20 High Starting Torque Time [s] and parameter 30-21 High Starting Torque Current [%] . Working at a current level higher than 100% for a prolonged time can cause the motor to overheat.

If the motor starts oscillating at a certain speed, increase parameter **1-14 Damping Gain**. Increase the value in small steps. Depending on the motor, this parameter can be set to 10–100% higher than the default value.

6.3.3 1-1* Special Settings



NOTE:

The following parameter is only available in FC 302:

- Parameter **1-11 Motor Model**



NOTE: The parameters within this parameter group cannot be adjusted while the motor is running.

1-10 Motor Construction

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–

Data type: Uint8

Change during operation: False

Select the motor design type.

NOTE: FC 301 only allows the selection of induction motors.

Option	Name	Description
[0]	Asynchron	Use for ASM/IM motors.
[1]	PM, non salient SPM	NOTE: This option is only available in FC 302. Use for SPM motors, surface-mounted magnet. PM motors are divided into 2 groups, with either surface-mounted (SPM)/non-salient magnets or interior-mounted (IPM)/ salient magnets.
[2]	PM, salient IPM	NOTE: This option is only available in FC 302. Use for IPM motors, interior-mounted magnet. PM motors are divided into 2 groups, with either surface-mounted (SPM)/non-salient magnets or interior-mounted (IPM)/ salient magnets.
[5]	SynRM	Use for SynRM, synchronous reluctance motors.
[6]	PMaSynRM	Use for PMaSynRM, Permanent Magnet assisted synchronous reluctance motors.

1-11 Motor Model

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Automatically sets the factory values for the selected motor. If the default value **[1] Std. Asynchron** is used, determine settings manually according to the selection in parameter **1-10 Motor Construction**.

NOTE: There are no models available for SynRM motors.

Option	Name	Description
[1]	Std. asynchron	Default motor model when [0] Asynchron is selected in parameter 1-10 Motor Construction .
[2]	Std. PM, non salient	Selectable when [1] PM, non-salient SPM is selected in parameter 1-10 Motor Construction .
[3]	Std. PM salient	
[10]	Danfoss OGD LA10	Selectable when [1] PM, non-salient SPM is selected in parameter 1-10 Motor Construction . Only available for T5 in 1.5–3.0 kW. Settings are loaded automatically for this specific motor.
[11]	Danfoss OGD V210	Selectable when [1] PM, non-salient SPM is selected in parameter 1-10 Motor Construction . Only available for T5 in 0.75–3.0 kW. Settings are loaded automatically for this specific motor.

1-14 Damping Gain

Default value:	Size related	Parameter type:	Range, 0 - 250%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

The damping gain stabilizes the PM machine to run smoothly and with stability. The value of damping gain controls the dynamic performance of the PM machine. High damping gain gives high dynamic performance and low damping gain gives low dynamic performance. The dynamic performance is related to the machine data and load type. If the damping gain is too high or low, the control becomes unstable.

1-15 Low Speed Filter Time Const.

Default value:	Size related	Parameter type:	Range, 0.01 - 20 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The time constant is used below 10% rated speed. Obtain quick control through a short dampening time constant. However, if this value is too short, the control becomes unstable.

1-16 High Speed Filter Time Const.

Default value:	Size related	Parameter type:	Range, 0.01 - 20 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The time constant is used above 10% rated speed. Obtain quick control through a short dampening time constant. However, if this value is too short, the control becomes unstable.

1-17 Voltage Filter Time Const.

Default value:	Size related	Parameter type:	Range, 0.001 - 2 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Reduces the influence of high frequency ripple and system resonance in the calculation of supply voltage. Without this filter, the ripples in the currents can distort the calculated voltage and affect the stability of the system.

1-18 Min. Current at No Load

Default value:	0%	Parameter type:	Range, 0 - 50%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Adjust this parameter to achieve a smoother motor operation.

6.3.4 1-2* Motor Data

This parameter group specifies input data required from the nameplate on the connected motor.



NOTE: Changing the value of these parameters affects the settings of other parameters.



NOTE:

The following parameters have no effect when parameter **1-10 Motor Construction** is set to **[1] PM, non-salient**, **[2] PM, salient IPM**, **[5] Sync. reluctance**:

- Parameter **1-20 Motor Power [kW]**
- Parameter **1-21 Motor Power [HP]**
- Parameter **1-22 Motor Voltage**
- Parameter **1-23 Motor Frequency**

1-20 Motor Power [kW]

Default value:	Size related	Parameter type:	Range, 0.09 - 3000.00 kW
Setup:	All setups	Conversion index:	1
Data type:	Uint32	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Enter the nominal motor power in kW according to the motor nameplate data. The default value corresponds to the nominal rated output of the drive. This parameter is visible in the LCP if parameter **0-03 Regional Settings** is set to **[0] International**.

1-21 Motor Power [HP]

Default value:	Size related	Parameter type:	Range, 0.09 - 3000.00 hp
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	False

Enter the nominal motor power in hp according to the motor nameplate data. The default value corresponds to the nominal rated output of the drive. This parameter is visible in the LCP if parameter **0-03 Regional Settings** is set to **[1] North America**.

1-22 Motor Voltage

Default value:	Size related	Parameter type:	Range, 10 - 1000 V
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False



NOTE: Setting this parameter sets the following parameters to their default settings:

- Parameter **1-15 Low Speed Filter Time Const.**
- Parameter **1-16 High Speed Filter Time Const.**
- Parameter **1-17 Voltage Filter Time Const.**
- Parameter **1-24 motor Current**
- Parameter **1-30 Stator Resistance (Rs)**
- Parameter **1-31 Rotor Resistance (Rr)**
- Parameter **1-33 Stator Leakage Reactance (X1)**
- Parameter **1-34 Rotor Leakage Reactance (X2)**
- Parameter **1-35 Main Reactance (Xh)**
- Parameter **1-36 Iron Loss Resistance (Rfe)**
- Parameter **4-18 Current Limit**
- Parameter **14-31 Current Lim Ctrl, Integration Time**
- Parameter **14-43 Motor Cosphi**
- Parameter **16-36 Inv. Nom. Current**
- Parameter **16-37 Inv. Max. Current**
- Parameter **45-33 Alarm High**
- Parameter **45-62 Load Threshold**

Enter the nominal motor voltage according to the motor nameplate data. The default value corresponds to the nominal rated output of the unit.

1-23 Motor Frequency

Default value:	–	Parameter type:	Range, 5 - 1000 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False



NOTE: From software version 6.72 onwards, the output frequency of the drive is limited to 590 Hz.



NOTE: Setting this parameter sets the following parameters to their default settings:

- Parameter **1-15 Low Speed Filter Time Const.**
- Parameter **1-16 High Speed Filter Time Const.**
- Parameter **1-17 Voltage Filter Time Const.**
- Parameter **1-24 motor Current**
- Parameter **1-30 Stator Resistance (Rs)**
- Parameter **1-31 Rotor Resistance (Rr)**
- Parameter **1-33 Stator Leakage Reactance (X1)**
- Parameter **1-34 Rotor Leakage Reactance (X2)**
- Parameter **1-35 Main Reactance (Xh)**
- Parameter **1-36 Iron Loss Resistance (Rfe)**
- Parameter **4-18 Current Limit**
- Parameter **14-31 Current Lim Ctrl, Integration Time**
- Parameter **14-43 Motor Cosphi**
- Parameter **16-36 Inv. Nom. Current**
- Parameter **16-37 Inv. Max. Current**
- Parameter **45-33 Alarm High**
- Parameter **45-62 Load Threshold**

Select the motor frequency value from the motor nameplate data. If a value other than 50 Hz or 60 Hz is selected, adapt the load-independent settings in parameter **1-50 Motor Magnetisation at Zero Speed** to parameter **1-53 Model Shift Frequency**. For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V/50 Hz. To run at 87 Hz, adapt parameter **4-13 Motor Speed High Limit [RPM]** and parameter **3-03 Maximum Reference**.

1-24 Motor Current

Default value:	Size related	Parameter type:	Range, 0.10 - 10000.00 A
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: Setting this parameter sets the following parameters to their default settings:

- Parameter **1-15 Low Speed Filter Time Const.**
- Parameter **1-16 High Speed Filter Time Const.**
- Parameter **1-17 Voltage Filter Time Const.**
- Parameter **1-30 Stator Resistance (Rs)**
- Parameter **1-31 Rotor Resistance (Rr)**
- Parameter **1-33 Stator Leakage Reactance (X1)**
- Parameter **1-34 Rotor Leakage Reactance (X2)**
- Parameter **1-35 Main Reactance (Xh)**
- Parameter **1-36 Iron Loss Resistance (Rfe)**
- Parameter **4-18 Current Limit**
- Parameter **14-31 Current Lim Ctrl, Integration Time**
- Parameter **14-43 Motor Cosphi**
- Parameter **45-33 Alarm High**
- Parameter **45-62 Load Threshold**

Enter the nominal motor current value from the motor nameplate data. The data is used for calculating torque, motor overload protection, and so on.

1-25 Motor Nominal Speed

Default value:	Size related	Parameter type:	Range, 10 - 60000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: Changing this parameter will affect settings of other parameters.

Enter the nominal motor speed value from the motor nameplate data. The data is used for calculating motor compensations.

$$nm, n = ns - nslip$$

1-26 Motor Cont. Rated Torque

Default value:	Size related	Parameter type:	Range, 0.1 - 10000.0 Nm
Setup:	All setups	Conversion index:	-1
Data type:	Uint32	Change during operation:	False



NOTE: Changing this parameter sets certain other parameters to their default settings.

Enter the value from the motor nameplate data. The default value corresponds to the nominal rated output. This parameter is available when parameter **1-10 Motor Construction** is set to **[1] PM, non-salient SPM**, **[2] PM, salient IPM**, **[5] SynRM**, and **[6] PMSynRM**.

1-29 Automatic Motor Adaptation (AMA)

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

The AMA function optimizes dynamic motor performance by automatically optimizing the advanced motor parameters (parameter **1-30 Stator Resistance (Rs)** to parameter **1-35 Main Reactance (Xh)**) on a cold motor at standstill. Activate the AMA function by pressing **[Hand On]** after selecting **[1] Enable Complete AMA** or **[2] Enable Reduced AMA**. If an LC filter is used between the drive and the motor, always select **[2] Enable Reduced AMA**. See also the section *Automatic Motor Adaptation* in the design guide. After a normal sequence, the display reads: **Press [OK] to finish AMA**. After pressing **[OK]**, the drive is ready for operation.



NOTE: Ensure that a value is set in parameter **14-43 Motor Cosphi** before running AMA II.

Option	Name	Description
[0]*	Off	
[1]	Enable complete AMA	Performs • AMA of the stator resistance R_s • The rotor resistance R_r • The stator leakage reactance X_1 • The rotor leakage reactance X_2 • The main reactance X_h Do not select this option if an LC filter is used between the drive and the motor. For best performance, it is recommended to obtain the advanced motor data from the motor manufacturer to enter into parameter 1-31 Rotor Resistance (Rr) through parameter 1-36 Iron Loss Resistance (Rfe). Complete AMA cannot be performed on permanent magnet motors.
[2]	Enable Reduced AMA	Performs a reduced AMA of the stator resistance R_s in the system only. This option is available for standard asynchronous motors and non-salient PM motors.
[3]	Enable reduced AMA II	Performs AMA of the stator resistance R_s, the rotor resistance R_r, the stator leakage reactance X_1, the rotor leakage reactance X_{21}, and the main reactance X_h.
[4]	Enable reduced AMA II	Performs a reduced AMA of the stator resistance R_s in the system only. Select this option if an LC filter is used between the drive and the motor. The AMA II is a variant of AMA, based on the principles of the torque calibration. It is recommended for special motors (for example S3) and high-power motors.

Option	Name	Description
[5]	Enable rotating AMA II	Performs rotation with 60% of nominal speed in Flux Sensorless with soft PID independent of selection in parameter 1-01 Motor Control Principle . Measures Back EMF on PM motors and re-measures main reactance (X_h) on induction motors. Ensure that the motor poles specified in parameter 1-39 Motor Poles are correct for accurate back EMF measurement.
[6]	Enable 360° turn OL	Sensorless: Performs a 360° test run in sensorless mode to verify the number of motor poles specified in parameter 1-39 Motor Poles. Closed loop: Performs a 360° test run in sensorless mode to test the encoder before running in closed loop. The speed is set in parameter 3-19 Jog Speed [RPM]. During the test run, the direction of rotation is verified and the number of pulses per revolution is verified to match the configuration in parameter group 17-** Motor Feedb. Option or parameter group 5-** Digital In/Out based on the selected encoder. After completing the 360° test run, either of the following messages are shown: - Encoder/Resolver OK - Encoder/Resolver Fail - Encoder/Resolver Inverted - Encoder/Resolver resolution/poles low - Encoder/Resolver resolution/poles high The parameter 1-41 Motor Angle Offset is automatically set when using PM motor and absolute encoder or resolver.
[7]	Enable inertia run	Use this option to ramp up in the mode as specified in parameter 1-01 Motor Control Principle . Measured inertia is set in parameter 1-69 System Inertia and parameter 7-08 Speed PID Feed Forward Factor is set to 90%.


NOTE:

For the best adaptation of the drive, run AMA on a cold motor.

Option **[5] Enable rotating AMA II** runs the motor while measuring motor data.

Perform a reduced AMA if a sine-wave filter is connected.



NOTE: It is important to set parameter group **1-2* Motor Data** correctly, since these parameters form part of the AMA algorithm. Perform an AMA to achieve optimum dynamic motor performance. It may take up to 10 minutes, depending on the power rating of the motor.



NOTE: Avoid generating external torque during AMA.



NOTE: If 1 of the settings in parameter group **1-2* Motor Data** is changed, parameter **1-30 Stator Resistance (Rs)** to parameter **1-39 Motor Poles** return to default setting.



NOTE: AMA works problem-free on 1 motor size down, it typically works on 2 motor sizes down, it rarely works on 3 motor sizes down, at it never works on 4 motor sizes down. Remember that the accuracy of the measured motor data is poorer when operating on motors than the nominal drive size.

6.3.5 1-3* Adv. Motor Data



NOTE:

The following parameters are only available in FC 302:

- Parameter **1-37 d-axis Inductance (Ld)**
- Parameter **1-38 q-axis Inductance (Lq)**
- Parameter **1-40 Back EMF at 1000 RPM**
- Parameter **1-44 d-axis Inductance Sat. (LdSat)**
- Parameter **1-45 q-axis Inductance Sat. (LqSat)**
- Parameter **1-45 q-axis Inductance Sat. (LqSat)**

This parameter group contains parameters related to:

- Motor nameplate load compensations.
- Application load type.
- Electronic brake function for quick stop/hold of the motor.

Ensure that the motor data in parameter **1-30 Stator Resistance (Rs)** to parameter **1-39 Motor Poles** matches the motor. The default settings are based on standard motor values. If the motor parameters are not set correctly, a malfunction of the drive system may occur. If the motor data is unknown, running an AMA (automatic motor adaptation) is recommended. See parameter **1-29 Automatic Motor Adaptation (AMA)**.

Parameter groups **1-3* Adv. Motor Data** and **1-4* Adv. Motor Data II** cannot be adjusted while the motor is running.



NOTE: A simple check of the $X_1 + X_h$ sum value is to divide the line-to-line motor voltage by the $\sqrt{3}$ and divide this value by the motor no-load current. $[VL-L/\sqrt{3}]/INL = X_1 + X_h$. To magnetize the motor properly, these values are important. For high-pole motors, it is highly recommended to perform this check.




Figure 32: Motor Equivalent Diagram of an Induction Motor

1-30 Stator Resistance (Rs)

Default value:	Size related	Parameter type:	Range, 0.0140 - 140.0000 Ohm

Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	False

Set the line-to-common stator resistance value. Enter the value from a motor datasheet or perform an AMA on a cold motor.



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: The parameter value is updated after each torque calibration if option [3] *1st start with store* or option [4] *Every start with store* is selected in parameter 1-47 *Torque Calibration*.

1-31 Rotor Resistance (Rr)

Default value:	Size related	Parameter type:	Range, 0.0100 - 100.0000 Ohm
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	False



NOTE: Parameter 1-31 *Rotor Resistance (Rr)* has no effect when parameter 1-10 *Motor Construction* is set to [1] *PM, non-salient SPM*, [2] *PM, salient IPM*, [5] *SynRM*, and [6] *PMSynRM*.

Set the rotor resistance value R_r to improve shaft performance using 1 of these methods:

- Run an AMA on a cold motor. The drive measures the value from the motor. All compensations are reset to 100%.
- Enter the R_r value manually. Obtain the value from the motor supplier.
- Use the R_r default setting. The drive establishes the setting based on the motor nameplate data.

1-33 Stator Leakage Reactance (X1)

Default value:	Size related	Parameter type:	Range, 0.0400 - 400.0000 Ohm
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	False



NOTE: This parameter is only relevant for induction motors.

Set the stator leakage reactance of the motor using 1 of these methods:

- Run an AMA on a cold motor. The drive measures the value from the motor.
- Enter the X_1 value manually. Obtain the value from the motor supplier.
- Use the X_1 default setting. The drive establishes the setting based on the motor nameplate data.



NOTE: The parameter value is updated after each torque calibration if option [3] *1st start with store* or option [4] *Every start with store* is selected in parameter 1-47 *Torque Calibration*.

1-34 Rotor Leakage Reactance (X2)

Default value:	Size related	Parameter type:	Range, 0.0400 - 400.0000 Ohm

Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	False



NOTE: This parameter is only relevant for induction motors.

Set the rotor leakage reactance of the motor using 1 of these methods:

- Run an AMA on a cold motor. The drive measures the value from the motor.
- Enter the X_2 value manually. Obtain the value from the motor supplier.
- Use the X_2 default setting. The drive establishes the setting based on the motor nameplate data.



NOTE: The parameter value is updated after each torque calibration if option [3] *1st start with store* or option [4] *Every start with store* is selected in parameter **1-47 Torque Calibration**.

1-35 Main Reactance (Xh)

Default value:	Size related	Parameter type:	Range, 1.0000 - 10000.0000 [Ohm]
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: Parameter **1-35 Main Reactance (Xh)** has no effect when parameter **1-10 Motor Construction** is set to [1] *PM, non-salient SPM*.

Set the main reactance of the motor using 1 of these methods:

- Run an AMA on a cold motor. The drive measures the value from the motor.
- Enter the X_h value manually. Obtain the value from the motor supplier.
- Use the X_h default setting. The drive establishes the setting based on the motor nameplate data.



NOTE: The parameter value is updated after each torque calibration if option [3] *1st start with store* or option [4] *Every start with store* is selected in parameter **1-47 Torque Calibration**.

1-36 Iron Loss Resistance (Rfe)

Default value:	Size related	Parameter type:	Range, 0 - 10000.000 Ohm
Setup:	All setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Enter the equivalent iron loss resistance (R_{Fe}) value to compensate for iron loss in the motor. The R_{Fe} value cannot be found by performing an AMA. The R_{Fe} value is especially important in torque control applications. If R_{Fe} is unknown, leave parameter **1-36 Iron Loss Resistance (R_{Fe})** on default setting.

1-37 d-axis Inductance (L_d)

Default value:	0.1 mH	Parameter type:	Range, 0 - 1000.0 mH
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False



NOTE: This parameter is only active when parameter **1-10 Motor Construction** is set to **[1] PM, non-salient SPM**.

Enter line-to-common direct axis inductance of the permanent magnet motor. Obtain the value from the permanent magnet motor datasheet.

For induction motors, stator resistance and d-axis inductance values are normally described in technical specifications as between line and common (star point). For PM motors, they are typically described in technical specifications as between line to line. PM motors are typically built for star connection.

Table 14: Parameters Related to PM Motors

Parameter	Function
Parameter 1-30 Stator Resistance (R_s) (line to common)	This parameter gives stator winding resistance (R_s) similar to induction motor stator resistance. The stator resistance is defined for line-to-common measurement. For line-to-line data, where stator resistance is measured between any 2 lines, divide by 2.
Parameter 1-37 d-axis Inductance (L_d) (line to common)	This parameter gives direct axis inductance of the permanent magnet motor. The d-axis inductance is defined for phase-to-common measurement. For line-to-line data, where stator resistance is measured between any 2 lines, divide by 2.
Parameter 1-40 Back EMF at 1000 RPM RMS (line-to-line value)	This parameter gives back EMF across the stator terminal of the permanent magnet motor at 1000 RPM mechanical speed specifically. It is defined between line-to-line and expressed in RMS value.



NOTE: Motor manufacturers provide values for stator resistance (parameter **1-30 Stator Resistance (R_s)**) and d-axis inductance (parameter **1-37 d-axis Inductance (L_d)**) in technical specifications as between line and common (star point) or line between line. There is no general standard. The different setups of stator winding resistance and induction are shown in *illustration Stator Winding Setups*. Danfoss AC drives always require the line-to-common value. The back EMF of a permanent magnet motor is defined as induced EMF developed across any of 2 phases of stator winding of a free-running motor. Danfoss AC drives always require the line-to-line RMS value measured at 1000 RPM, mechanical speed of rotation, see *illustration Machine Parameter Definitions of Back EMF of PM Motors*.




Figure 33: Stator Winding Setups




Figure 34: Machine Parameter Definitions of Back EMF of PM Motors

1-38 q-axis Inductance (Lq)

Default value:	Size related	Parameter type:	Range, 0.001 - 1000 mH
Setup:	All setups	Conversion index:	-6
Data type:	Int32	Change during operation:	False

Set the value of the q-axis inductance. See the motor datasheet.

1-39 Motor Poles

Default value:	Size related	Parameter type:	Range, 2 - 255
Setup:	All setups	Conversion index:	0
Data type:	UInt8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Enter the number of motor poles. The number of motor poles is always an even number as it refers to the total number of poles, not pairs of poles.

Table 15: Pole Number for Normal Speed Ranges

Poles	$\sim n_n@50\text{ Hz}$	$\sim n_n@60\text{ Hz}$
2	2700–2880	3520–3460
4	1350–1450	1625–1730
6	700–960	840–1153

Table 15 shows the pole number for normal speed ranges of various motor types. Define motors designed for other frequencies separately. The motor pole value is always an even number because it refers to the total pole number, not pairs of poles. The drive created the initial setting of parameter **1-39 Motor Poles** based on parameter **1-23 Motor Frequency** and parameter **1-25 Motor Nominal Speed**.

1-40 Back EMF at 1000 RPM

Default value:	Size related	Parameter type:	Range, 1 - 9000 V
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Conversion index:	False



NOTE: This parameter is only active when parameter **1-10 Motor Construction** is set to options that enable permanent magnet motors.

Set the nominal back EMF for the motor when running at 1000 RPM. Back EMF is the voltage generated by a permanent magnet motor when no drive is connected and the shaft is turned externally. Back EMF is normally specified for nominal motor speed or for 1000 RPM measured between 2 lines. If the value is not available for a motor speed of 1000 RPM, calculate the correct value as follows:

$$\text{BackEMF} = (\text{Voltage} \div \text{RPM}) \times 1000$$

In an example where the voltage is 320 V and RPM is 1800, the back EMF at 1000 RPM is:

$$(320 \div 1800) \times 1000 = 178$$

1-41 Motor Angle Offset

Default value:	0	Parameter type:	Range, -32768 - 32767
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True



NOTE: This parameter is only active when parameter **1-10 Motor Construction** is set to **[1] PM, non-salient SPM** (permanent magnet motor).

Enter the correct offset angle between the PM motor and the index position (single-turn) of the attached encoder or resolver. The value range of 0-32768 corresponds to 0–2 x pi (radians). To obtain the offset angle value: After drive start-up, apply DC hold and enter the value of parameter **16-20 Motor Angle** into this parameter.

1-44 d-axis Inductance Sat. (LdSat)

Default value:	Size related	Parameter type:	Range, 0.001 - 1000 mH
Setup:	All setups	Conversion index:	-6
Data type:	Int32	Change during operation:	False

This parameter corresponds to the inductance saturation of L_d . Ideally, this parameter has the same value as parameter **1-37 d-axis Inductance (L_d)**. If the motor supplier provides an induction curve, enter the induction value at 200% of the nominal value.

1-45 q-axis Inductance Sat. (L_q Sat)

Default value:	Size related	Parameter type:	Range, 0.001 - 1000 mH
Setup:	All setups	Conversion index:	-6
Data type:	Int32	Change during operation:	False

This parameter corresponds to the inductance saturation of L_q . Ideally, this parameter has the same value as parameter **1-38 q-axis Inductance (L_q)**. If the motor supplier provides an induction curve, enter the induction value at 200% of the nominal value.

1-46 Position Detection Gain

Default value:	Size related	Parameter type:	Range, 20 - 200%
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Adjusts the amplitude of the test pulse during position detection at start. Adjust this parameter to improve the position measurement.

1-47 Torque Calibration

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Use this parameter to optimize the torque estimate in the full speed range. The estimated torque is based on the shaft power, $P_{\text{shaft}} = P_m - R_s \times I^2$. Make sure that the R_s value is correct. The R_s value in this formula is equal to the power loss in the motor, the cable, and the drive. When this parameter is active, the drive calculates the R_s value during power-up, ensuring the optimal torque estimate and optimal performance. Use this feature in cases when it is not possible to adjust parameter **1-30 Stator Resistance (R_s)** on each drive to compensate for the cable length, drive losses, and the temperature deviation on the motor.

Option	Name	Description
[0]	Off	
[1]	1st start after pwr-up	Calibrates at the 1st start-up after power-up and keeps this value until reset by a power cycle.
[2]	Every start	Calibrates at every start-up, compensating for a possible change in motor temperature since last start-up. The value is reset after a power cycle.
[3]	1st start with store	The drive calibrates the torque at the 1st start-up after power-up. This option is used to update motor parameters: - Parameter 1-30 Stator Resistance (R_s). - Parameter 1-33 Stator Leakage Reactance (X_1). - Parameter 1-34 Rotor Leakage Reactance (X_2). - Parameter 1-37 d-axis Inductance (L_d).

Option	Name	Description
[4]	Every start with store	The drive calibrates the torque at every start-up, compensating for a possible change in motor temperature since last start-up. This option is used to update motor parameters: - Parameter 1-30 Stator Resistance (Rs). - Parameter 1-33 Stator Leakage Reactance (X1). - Parameter 1-34 Rotor Leakage Reactance (X2). - Parameter 1-37 d-axis Inductance (Ld).
[5]	1st start check motor	NOTE: This option is only available for FC 302.
[6]	Every st. check motor	NOTE: This option is only available for FC 302.

1-48 d-axis Inductance Sat. Point

Default value:	Size related	Parameter type:	Range, 1 - 500%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

NOTE: Run an AMA to set the value of this parameter. Edit the value manually only when the application requires a value other than determined by AMA.

Select the d-axis inductance saturation point. The drive uses this value to optimize the performance of SynRM motors. Select the value that matches the point where the inductance equals the mean value of parameter **1-37 d-axis Inductance (Ld)** and parameter **1-44 d-axis Inductance Sat. (LdSat)**, as percentage of nominal current.

1-49 q-axis Inductance Sat. Point

Default value:	Size related	Parameter type:	Range, 1 - 500%
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	False

NOTE: Run an AMA to set the value of this parameter. Edit the value manually only when the application requires a value other than determined by AMA.

Enter the q-axis inductance saturation point. The drive uses this value to optimize the performance of IPM motors. Select the value that matches the point where the inductance equals the average value of parameter **1-38 q-axis Inductance (Lq)** and parameter **1-45 q-axis Inductance Sat. (LqSat)**, as a percentage of nominal current.

6.3.6 1-5* Load Indep. Setting

NOTE:

The following parameter is only available in FC 302:

- Parameter **1-53 Model Shift Frequency**

This parameter group contains parameters related to:

- Motor nameplate load compensations.
- Application load type.
- Electronic brake function for quick stop/hold of the motor.

1-50 Motor Magnetization at Zero Speed

Default value:	100%	Parameter type:	Range, 0 - 300%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True



NOTE: Parameter **1-50 Motor Magnetization at Zero Speed** has no effect when parameter **1-10 Motor Construction** = [1] **PM, nonsalient SPM**.

Use this parameter along with parameter **1-51 Min Speed Normal Magnetizing [RPM]** to obtain a different thermal load on the motor when running at low speed. Enter a value which is a percentage of the rated magnetizing current. If the setting is too low, the torque on the motor shaft may be reduced.




Figure 35: Motor Magnetization

1-51 Min Speed Normal Magnetizing [RPM]

Default value:	Size related	Parameter type:	Range, 10 - 600 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True



NOTE: Parameter **1-51 Min Speed Normal Magnetizing [RPM]** has no effect when parameter **1-10 Motor Construction** = [1] **PM, nonsalient SPM**.

Set the required speed for normal magnetizing current. If the speed is set lower than the motor slip speed, parameter **1-50 Motor Magnetization at Zero Speed** and parameter **1-51 Min Speed Normal Magnetizing [RPM]** are of no significance. Use this parameter along with parameter **1-50 Motor Magnetization at Zero Speed**.

1-52 Min Speed Normal Magnetizing [Hz]

Default value:	Size related	Parameter type:	Range, 0 - 250.0 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True



NOTE: Parameter **1-52 Min Speed Normal Magnetizing [Hz]** has no effect when parameter **1-10 Motor Construction** = [1] *PM, non-salient SPM*.

Set the required frequency for normal magnetizing current. If the frequency is set lower than the motor slip frequency, parameter **1-50 Motor Magnetization at Zero Speed** is inactive. Use this parameter along with parameter **1-50 Motor Magnetization at Zero Speed**.

1-53 Model Shift Frequency

Default value:	Size related	Parameter type:	Range, 4 - 18.0 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Flux model shift: Enter the frequency value for shifting between 2 models for determining motor speed. Select the value based on settings in parameter **1-00 Configuration Mode** and parameter **1-01 Motor Control Principle**. There are the following options:

- Shift between flux model 1 and flux model 2.
- Shift between variable current mode and flux model 2.
- No shift between models at low speed if parameter **40-50 Flux Sensorless Model Shift** is set to option [0] *Off*.

Flux model 1 - flux model 2: This model is used when parameter **1-00 Configuration Mode** is set to [1] *Speed closed loop* or [2] *Torque*, and parameter **1-01 Motor Control Principle** is set to [3] *Flux w/motor feedback*. With this parameter, it is possible to make an adjustment of the shifting point where the drive changes between flux model 1 and flux model 2, which is useful in some sensitive speed and torque control applications.




Figure 36: Example of Parameter **1-00 Configuration Mode** = [1] *Speed closed loop* or [2] *Torque* and parameter **1-01 Motor Control Principle** = [3] *Flux w/motor feedback*

Variable current - flux model - sensorless: This model is used when parameter **1-00 Configuration Mode** is set to [0] *Speed open loop* and parameter **1-01 Motor Control Principle** is set to [2] *Flux sensorless*. In speed open loop in flux mode, the speed is determined from the current measurement. Below $f_{norm} \times 0.1$, the drive runs on a variable current model. Above $f_{norm} \times 0.125$ the drive runs on a flux model.




Figure 37: Parameter 1-00 Configuration Mode = [0] Speed open loop, parameter 1-01 Motor Control Principle = [2] Flux sensorless

1-54 Voltage Reduction in Fieldweakening

Default value:	0 V	Parameter type:	Range, -50 - 100 V
Setup:	All setups	Conversion index:	0
Data type:	Int8	Change during operation:	True

The value of this parameter reduces the maximum voltage available for the flux of the motor in field weakening, providing more voltage for torque. Increasing the value increases the risk of stalling at high speed. When reducing the voltage below 0, the output voltage is increased and at some point the current controller is forced into "Voltage Limit".

1-55 U/f Characteristic - U

Default value:	Size related	Parameter type:	Array [6]
Setup:	All setups	Conversion index:	-1
Data type:	UInt16	Change during operation:	True

Enter the voltage at each frequency point to manually form a U/f characteristic matching the motor. The frequency points are defined in parameter **1-56 U/f Characteristic - F**. This parameter is an array parameter [0-5] and is only accessible when parameter **1-01 Motor Control Principle** is set to [0] U/f.

1-56 U/f Characteristic - F

Default value:	Size related	Parameter type:	Array [6]
Setup:	All setups	Conversion index:	-1
Data type:	UInt16	Change during operation:	True

Enter the frequency points to form a U/f characteristic manually matching the motor. The voltage at each point is defined in parameter **1-55 U/f Characteristic - U**. This parameter is an array parameter [0-5] and is only accessible when parameter **1-01 Motor Control Principle** is set to [0] U/f.




Figure 38: U/f Characteristic

1-57 Torque Estimation Time Constant

Default value:	150 ms	Parameter type:	Range, 50 - 1000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only valid in FC 302 with IMC software version 48.0X and newer.

Enter the time constant for the torque estimation below model change point in flux sensorless control principle.

1-58 Flying Start Test Pulses Current

Default value:	Size related	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False



NOTE: This parameter is only available in VVC+.



NOTE: This parameter is active when parameter **1-73 Flying Start** is enabled.

Sets the current level for the flying start test pulses that are used to detect the motor direction. 100% means $I_{m,n}$. Adjust the value to be high enough to avoid noise influence, but low enough to avoid affecting the accuracy (current must be able to drop to 0 before the next pulse). Reduce the value to reduce the generated torque. Default is 30% for asynchronous motors. For permanent magnet motors, the default may vary, but a general setting of 20% is recommended. For adjusting permanent magnet motors, the value tunes for back EMF and d-axis inductance of the motor.

1-59 Flying Start Test Pulses Frequency

Default value:	Size related	Parameter type:	Range, 0 - 500%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Induction motor: Set the frequency of the flying start test pulses that are used to detect the motor direction. For induction motors, the value 100% means that the slip is doubled. Increase this value to reduce the generated torque. For synchronous motors, this value is the percentage $n_{m,n}$ of the free-running motor. Above this value, flying start is always performed. Below this value, the start mode is selected in parameter **1-70 Start Mode**.

6.3.7 1-6* Load Depend. Setting



NOTE:

The following parameters are only available in FC 302:

- Parameter **1-66 Min. Current at Low Speed**
- Parameter **1-67 Load Type**
- Parameter **1-68 Motor Inertia**
- Parameter **1-69 System Inertia**

1-60 Low Speed Load Compensation

Default value:	100%	Parameter type:	Range, 0 - 300%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the % value to compensate voltage in relation to load when the motor is running at low speed and obtain the optimum U/f characteristic. The motor size determines the frequency range within which this parameter is active.

Motor size	Changeover
0.25–7.5 kW	<10 Hz
11–45 kW	<5 Hz
55–maximum power size kW	<3–4 Hz




Figure 39: Changeover

1-61 High Speed Load Compensation

Default value:	100%	Parameter type:	Range, 0 - 300%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True



NOTE: Parameter **1-61 High Speed Load Compensation** only has effect when parameter **1-10 Motor Construction** = [0] *Asynchron*.

Enter the % value to compensate voltage in relation to load when the motor is running at high speed and obtain the optimum U/f characteristic. The motor size determines the frequency range within which this parameter is active.

Motor size	Changeover
0.25–7.5 kW	>10 Hz
11–45 kW	>5 Hz
55–maximum powerHz size kW	>3–4

1-62 Slip Compensation

Default value:	Size related	Parameter type:	Range, -500 - 500%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the % value for slip compensation to compensate for tolerances in the value of $n_{M,N}$. Slip compensation is calculated automatically, that is on the basis of the nominal motor speed $n_{M,N}$. This function is not active when parameter **1-00 Configuration Mode** is set to [1] *Speed closed loop* or [2] *Torque* torque control with speed feedback or when parameter **1-01 Motor Control Principle** is set to [0] *U/f*.

1-63 Slip Compensation Time Constant

Default value:	Size related	Parameter type:	Range, 0.05 - 5 s
Setup:	All setups	Conversion index:	-2
Data type:	UInt16	Change during operation:	True



NOTE: Parameter **1-63 Slip Compensation Time Constant** only has effect when parameter **1-10 Motor Construction** = [0] *Asynchron*.

Enter the slip compensation reaction speed. A high value results in slow reaction, and a low value results in quick reaction. If low-frequency resonance problems arise, use a longer time setting.

1-64 Resonance Damping

Default value:	Size related	Parameter type:	Range, 0 - 1000%
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True



NOTE: Parameter **1-64 Resonance Damping** has no effect when parameter **1-10 Motor Construction** = [1] *PM, nonsalient SPM*.

Enter the resonance damping value. Set parameter **1-64 Resonance Damping** and parameter **1-65 Resonance Damping Time Constant** to help eliminate high-frequency resonance problems. To reduce resonance oscillation, increase the value of parameter **1-64 Resonance Damping**.

1-65 Resonance Damping Time Constant

Default value:	5 ms	Parameter type:	Range, 1 - 50 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint8	Change during operation:	True



NOTE: Parameter **1-65 Resonance Damping Time Constant** only has effect when parameter **1-10 Motor Construction** = [0] *Asynchron*.

Set parameter **1-64 Resonance Damping** and parameter **1-65 Resonance Damping Time Constant** to help eliminate high-frequency resonance problems. Enter the time constant that provides the best dampening.

1-66 Min. Current at Low Speed

Default value:	Size related	Parameter type:	Range, 1 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True



NOTE: If parameter **40-50 Flux Sensorless Model Shift** is set to [0] *Off*, this parameter is ignored.

Enter the minimum motor current at low speed, see parameter **1-53 Model Shift Frequency**. Increasing this current improves motor torque at low speed. Parameter **1-66 Min. Current at Low Speed** is enabled when parameter **1-00 Configuration Mode** is set to [0] *Speed open loop* only. The drive runs with constant current through motor for speeds below 10 Hz. For speeds above 10 Hz, the motor flux model in the drive controls the motor. Parameter **4-16 Torque Limit Motor Mode** and/or parameter **4-17 Torque Limit Generator Mode** automatically adjust parameter **1-66 Min. Current at Low Speed**. The parameter with the highest value adjusts parameter **1-66 Min. Current at Low Speed**. The current setting in parameter **1-66 Min. Current at Low Speed** is composed of the torque generating current and the magnetizing current. **Example:** Set parameter **4-16 Torque Limit Motor Mode** to 100% and set parameter **4-17 Torque Limit Generator Mode** to 60%. Parameter **1-66 Min. Current at Low Speed** automatically adjusts to about 127%, depending on the motor size.

1-67 Load Type

Default setting:	[0] Passive load	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Passive load	For conveyors, fans, and pump applications.
[1]	Active load	For hoisting applications. This option allows the drive to ramp up at 0 RPM. When [1] Active Load is selected, set parameter 1-66 Min. Current at Low Speed to a level which corresponds to maximum torque.

1-68 Motor Inertia

Default value:	0 kgm	Parameter type:	Range, 0.0000 - 10000.0000 kgm ²
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	False

Enter the motor inertia to obtain an improved torque readout and therefore a better estimate of the mechanical torque on the shaft. Available in flux control principle only.

1-69 System Inertia

Default value:	Size related	Parameter type:	Range, 0000 - 10000.0000 kgm ²
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

The system inertia and parameter **7-08 Speed PID Feed Forward Factor** are used to calculate acceleration feed forward for the speed PID controller. Automatic measurement of system inertia and setting of this parameter are activated by setting the parameter to 0. System inertia is calculated after the 1st running cycle with sufficient data and the parameter is automatically set after stop. The function is only active when parameter **1-01 Motor Control Principle** is set to **[2] Flux Sensorless** or **[3] Flux w/motor feedb**. Accelerate to at least model shift frequency (parameter **1-53 Model Shift Frequency**) + 10 Hz and decelerate to produce a result. Measurement is possible in both speed, position, or synchronization mode.

6.3.8 1-7* Start Adjustments

1-70 Start Mode

Default value:	[0] Rotor detection	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the start-up mode. This is done to initialize the VVC+ control core for previously free-running motor. Both selections estimate the speed and angle. Active for PM and SynRM motors in VVC+ only.

Option	Name	Description
[0]*	Rotor detection	Estimates the electrical angle of the rotor and uses this as a starting point. Standard selection for automation applications.
[1]	Parking	The parking function applies DC current across the stator winding and rotates the rotor to electrical 0 position (typically selected for HVAC applications). Parking current and time are configured in parameter 2-06 Parking Current and parameter 2-07 Parking Time .
[2]	Rotor det. w/parking	Combining rotor detection with the parking function.
[4]	Rotor Detection II	Estimates the electrical angle of the rotor by sending out test pulses. If the motor is restarted in less than 1.0 s, this function does a second measurement. If movement is detected, the start will be delayed for maximum 10 s.

1-71 Start Delay

Default value:	0 s	Parameter type:	Range, 0 - 25.5 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

This parameter refers to the start function selected in parameter **1-72 Start Function**. Enter the time delay required before commencing acceleration.

1-72 Start Function

Default value:	[2] Coast/delay time	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the start function during start delay. This parameter is linked to parameter **1-71 Start Delay**.

Option	Name	Description
[0]	DC hold/delay time	Energize the motor with a DC hold current (parameter 2-00 DC Hold Current) during the start delay time.
[1]	DC brake/delay time	Energize the motor with a DC brake current (parameter 2-01 DC Brake Current) during the start delay time.
[2]*	Coast/delay time	Motor coasted during the start delay time (inverter off).
[3]	Start speed cw	Only possible with VVC+. Connect the function described in parameter 1-74 Start Speed [RPM] and parameter 1-76 Start Current in the start delay time. Regardless of the value applied by the reference signal, the output speed applies the setting of the start speed in parameter 1-74 Start Speed [RPM] or parameter 1-75 Start Speed [Hz] , and the output current corresponds to the setting of the start current in parameter 1-76 Start Current . This function is typically used in hoisting applications without counterweight and especially in applications with a cone-motor where the start is clockwise, followed by rotation in the reference direction.

Option	Name	Description
[4]	Horizontal operation	Only possible with VVC+. For obtaining the function described in parameter 1-74 Start Speed [RPM] and parameter 1-76 Start Current during the start delay time . The motor rotates in the reference direction. If the reference signal equals 0, parameter 1-74 Start Speed [RPM] is ignored and the output speed equals 0. The output current corresponds to the setting of the start current in parameter 1-76 Start Current .
[5]	VVC+/flux clockwise	For the function described in parameter 1-74 Start Speed [RPM] only. The start current is calculated automatically. This function uses the start speed in the start delay time only. Regardless of the value set by the reference signal, the output speed equals the setting of the start speed in parameter 1-74 Start Speed [RPM] . [3] Start speed/current clockwise and [5] VVC+/Flux clockwise are typically used in hoisting applications. [4] Start speed/current in reference direction is particularly used in applications with counterweight and horizontal movement.
[6]	Hoist mech. brake rel	For utilizing mechanical brake control functions (parameter 2-24 Stop Delay to parameter 2-28 Gain Boost Factor). This parameter is only active in flux control principle, in a mode with motor feedback or sensorless mode.
[7]	VVC+/flux counter-cw	Same function as in [5] VVC+/flux clockwise but running in the opposite direction.

Flying start function

When flying start is enabled, parameter **1-71 Start Delay** and parameter **1-72 Start Function** have no function. When options **[1] Enable** and **[2] Enabled always** are enabled, parameter **1-58 Flying Start Test Pulses Current** and **1-59 Flying Start Test Pulses Frequency** are used to specify conditions for flying start. For flying start version 2, option **[11]** to **[14]** are specific to asynchronous motor (induction motor) in VVC+ up to 132 Hz output frequency. These options provide a faster, more reliable, and robust flying start. When parameter **1-73 Flying Start** is enabled, parameter **1-71 Start Delay** has no function.

1-73 Flying Start

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This function is not recommended for hoisting applications. For power levels above 55 kW, flux mode must be used to achieve the best performance.



NOTE: To obtain the best flying start performance, the advanced motor data, parameter **1-30 Stator Resistance (Rs)** to parameter **1-35 Main Reactance (Xh)**, must be correct.

This function makes it possible to catch a freely spinning motor, for example, coasted because of mains dropout. When parameter **1-73 Flying Start** is enabled, parameter **1-71 Start Delay** has no function. Search direction for flying start is linked to the setting in parameter **4-10 Motor Speed Direction**. **[0] Clockwise**: Flying start searches in clockwise direction. If not successful, a DC brake is carried out. **[2] Both**

Directions: The flying start first searches in the direction determined by the last reference (direction). If the speed is not found, flying start searches in the other direction. If not successful, a DC brake activates in the time set in parameter **2-02 DC Braking Time**. Start then takes place from 0 Hz.

Option	Name	Description
[0]	Disabled	No function.
[1]	Enabled	Enable after coast.
[2]	Enabled always	Enable at every start.
[3]	Enabled ref. dir.	Enable after coast, search in reference direction only.
[4]	Enab. always ref. dir.	Enable at every start, search in reference direction only.
[11]	v2 Enabled	Enable flying start version 2, after coast.
[12]	v2 Enabled Always	Enable flying start version 2, at every start.
[13]	v2 Enabled Ref. Dir.	Enable flying start version 2, after coast, search in reference direction only.
[14]	v2 Enab. Alw. Ref. Dir.	Enable flying start version 2, OK at every start, search in reference direction only.

1-74 Start Speed [RPM]

Default value:	Size related	Parameter type:	Range, 0 - 600 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Set a motor start speed. After the start signal, the output speed leaps to set value. Set the start function in parameter **1-72 Start Function** to **[3] Start speed cw**, **[4] Horizontal operation**, or **[5] VVC+ /Flux clockwise**, and set a start delay time in parameter **1-71 Start Delay**.

1-75 Start Speed [HZ]

Default value:	Size related	Parameter type:	Range, 0 - 500.0 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

This parameter can be used for hoist applications (cone rotor). Set a motor start speed. After the start signal, the output speed leaps to the set value. Set the start function in parameter **1-72 Start Function** to **[3] Start speed cw**, **[4] Horizontal operation**, or **[5] VVC+/Flux clockwise**, and set a start delay time in parameter **1-71 Start Delay**.

1-76 Start Current

Default value:	0 A	Parameter type:	Range, 0 - par. 1-24 A
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Some motors, for example cone rotor motors, need extra current/starting speed to disengage the rotor. To obtain this boost, set the required current in parameter **1-76 Start Current**. Set parameter **1-74 Start Speed [RPM]**. Set parameter **1-72 Start Function** to **[3] Start speed cw** or **[4] Horizontal operation**, and set a start delay time in parameter **1-71 Start Delay**. This parameter can be used for hoist applications (cone rotor).

6.3.9 1-8* Stop Adjustments



NOTE:

The following parameter is only valid for FC 302:

- Parameter **1-83 Precise stop function**

1-80 Function at Stop

Default value:	[0] Coast	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the drive function after a stop command or after the speed is ramped down to the settings in parameter **1-81 Min Speed for Function at Stop [RPM]**.

Table 16: Options Depending on Control

		ASM	SPM	IPM	SynRM
VVC+	Speed OL	All options	[0],[1],[5]	[0],[1],[5]	[0],[1],[5]
Flux OL	Speed OL	[0],[1],[2],[3],[5],[6]	[0],[1],[5]	[0],[1],[5]	–
Flux CL	Speed CL	All options	[0],[1],[5],[8]	[0],[1],[5],[8]	–

Option	Name	Description
[0]*	Coast	Leaves the motor in free mode. The motor is disconnected from the drive.
[1]	DC hold	Energizes the motor with a DC hold current (see parameter 2-00 DC Hold Current).
[2]	Motor check	Checks if a motor has been connected. The interval for checking the motor can be defined in parameter 4-49 Motor Check Time Interval .

Option	Name	Description
[3]	Premagnetizing	Builds up a magnetic field while the motor is stopped. This magnetic field allows the motor to produce torque quickly at subsequent start commands (induction motors only). This premagnetizing function does not help the 1st start command. Two different solutions are available to premagnetize the device for the 1st start command: - Start the drive with a 0 RPM reference and wait 2–4 rotor time constants before increasing the speed reference. - Use the start delay with DC hold: Set parameter 1-71 Start Delay to the required premagnetizing time (2–4 rotor time constants). See the time constants description further in this section. Set parameter 1-72 Start Function to either [0] DC hold or [1] DC Brake. Set the DC hold or DC brake current magnitude (parameter 2-00 DC Hold Current or parameter 2-01 DC Brake Current) to be equal to $I_{\text{pre-mag}} = U_{\text{nom}} / (1.73 \times X_h)$. Sample rotor time constants = $(X_h + X_2) / (6.3 \times \text{Freq}_{\text{nom}} \times R_r)$ 1 kW = 0.2 s 10 kW = 0.5 s 100 kW = 1.7 s 1000 kW = 2.5 s
[4]	DC voltage U0	When the motor is stopped, parameter 1-55 U/f Characteristic - U [0] defines the voltage at 0 Hz.
[5]	Coast at low reference	When the reference is below parameter 1-81 Min Speed for Function at Stop [RPM] , the drive coasts the motor.
[6]	Motor check, alarm	The drive issues an alarm if 1 or more motor phases are missing.
[8]	Torque ramp to zero	 NOTE: This option is only available in FC 302. When the motor reaches the speed defined in parameter 1-81 Min Speed for Function at Stop [RPM], the drive ramps the torque down to 0 torque (for example, for extruder applications where a high torque is present at low speed). The torque ramp time can be set in parameter 1-89 Stop Func Torque Ramp Time.
[10]	Motor Preheat	

1-81 Min Speed for Function at Stop [RPM]

Default value:	Size related	Parameter type:	Range, 0 - 600 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Set the speed at which to activate parameter **1-80 Function at Stop**.

1-82 Min Speed for Function at Stop [Hz]

Default value:	Size related	Parameter type:	Range, 0 - 500.0 Hz
Setup:	All setups	Conversion index:	-1

Data type:	Uint16	Change during operation:	True

Set the output frequency at which to activate parameter **1-80 Function at Stop**.

1-83 Precise Stop Function

Default value:	[0] Precise ramp stop	Parameter type:	Option
Setup:	All seutps	Conversion index:	–
Data type:	Uint8	Change during operation:	False

NOTE: This parameter is valid for FC 302 only.

NOTE: This parameter cannot be adjusted while the motor is running.

Precise-stop functions are advantageous in applications where high precision is required. If using a standard stop command, the accuracy is determined by the internal task time. That is not the case when using the precise-stop function. It eliminates the task-time dependence and increases the accuracy substantially. The drive tolerance is normally given by its task time. However, by using its special precise-stop function, the tolerance is independent of the task time because the stop signal immediately interrupts the execution of the drive program. The precise-stop function gives a highly reproducible delay from the stop signal is given until the ramping down starts. Run a test to find this delay as it is a sum of sensor, PLC, and mechanical parts.

To ensure optimum accuracy, there should be at least 10 cycles during ramp down, see:

- Parameter **3-42 Ramp 1 Ramp Down Time**
- Parameter **3-52 Ramp 2 Ramp Down Time**
- Parameter **3-62 Ramp 3 Ramp Down Time**
- Parameter **3-72 Ramp 4 Ramp Down Time**

The precise-stop function is set up here and enabled from a digital input on terminal 29 or terminal 33.

Option	Name	Description
[0]*	Precise ramp stop	Only optimal when the operational speed, for example, the operational speed of a conveyor belt, is constant. This is an open-loop control. Achieves high repetitive precision at the stop point.
[1]	Cnt stop with reset	Counts the number of pulses, typically from an encoder, and generates a stop signal after a preprogrammed number of pulses, defined in parameter 1-84 Precise Stop Counter Value , has been received at terminal 29 or terminal 33. This is direct feedback with one-way closed-loop control. The counter function is activated (starts timing) at the edge of the start signal (when it changes from stop to start). After each precise stop, the number of pulses counted during ramp-down to 0 RPM are reset.
[2]	Cnt stop w/o reset	Same as [2] Cnt stop with reset but the number of pulses counted during ramp down to 0 RPM are deducted from the counter value entered in parameter 1-84 Precise Stop Counter Value . This reset function can be used to compensate for the extra distance done during ramping down and to reduce the impacts of gradual wear of mechanical parts.

Option	Name	Description
[3]	Speed comp stop	Stops at precisely the same point, regardless of the present speed. The stop signal is delayed internally when the present speed is lower than the maximum speed (set in parameter 4-19 Max Output Frequency). The delay is calculated on the basis of the reference speed of the drive and not on the basis of the actual speed. Make sure that the drive has ramped up before activating the speed-compensated stop.
[4]	Com cnt stop w/rst	Same as [3] Speed comp stop but after each precise stop, the number of pulses counted during ramp down to 0 RPM is reset.
[5]	Comp cnt stop w/o r	Same as [3] Speed comp stop but the number of pulses counted during ramp down to 0 RPM is deducted from the counter value entered in parameter 1-84 Precise Stop Counter Value . This reset function can be used to compensate for the extra distance done during ramping down and to reduce the impacts of gradual wear of mechanical parts.

1-84 Precise Stop Counter Value

Default value:	100000	Parameter type:	Range, 0 - 999999999
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Enter the counter value to be used in the integrated precise stop function, parameter **1-83 Precise Stop Function**. The maximum permissible frequency at terminal 29 or 33 is 110 kHz.



NOTE: Not used for selections **[0] Precise ramp stop** and **[3] Speed comp stop** in parameter **1-83 Precise Stop Function**.

1-85 Precise Stop Speed Compensation Delay

Default value:	10 ms	Parameter type:	Range, 0 - 100 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint8	Change during operation:	True

Enter the delay time for sensors, PLCs, and so on for use in parameter **1-83 Precise Stop Function**. In speed-compensated stop mode, the delay time at different frequencies has a major influence on the stop function.



NOTE: Not used for selections **[0] Precise ramp stop**, **[1] Cnt stop with reset**, and **[2] Cnt stop w/o reset** in parameter **1-83 Precise Stop Function**.

1-89 Stop Func Torque Ramp Time

Default value:	0.01 s	Parameter type:	Range, 0.01 - 3600.00 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Configure the time in seconds during which the torque is ramped to 0, after the motor speed is ramped down to the minimum speed as specified in parameter **1-81 Min Speed for Function at Stop [RPM]**.

6.3.10 1-9* Motor Temperature



NOTE:

The following parameters are only available in FC 302:

- Parameter **1-94 ATEX ETR Cur.Lim.Speed Reduction**
- Parameter **1-95 Thermistor Sensor Type**
- Parameter **1-96 Thermistor Sensor Resource**
- Parameter **1-98 ATEX ETR Interpol. Points Freq.**
- Parameter **1-99 ATEX ETR Interpol. Points Current**

1-90 Motor Thermal Protection

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: If **[20] ATEX ETR** is selected, set parameter **4-18 Current Limit** to 150%.

Motor thermal protection can be implemented using a range of techniques:

- Via a PTC sensor in the motor windings connected to 1 of the analog or digital inputs (parameter **1-93 Thermistor Resource**). See the *chapter PTC Thermistor Connection*.
- Via a KTY sensor in the motor winding connected to an analog input (parameter **1-96 Thermistor Sensor Resource**). See the *chapter KTY Sensor Connection*.
- Via calculation (ETR = Electronic Thermal Relay) of the thermal load, based on the actual load and time. The calculated thermal load is compared with the rated motor current $I_{M,N}$ and the rated motor frequency $f_{M,N}$. See the *chapter ETR*.
- Via a mechanical thermal switch (Klixon type). See the *chapter Klixon*.

For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.

Option	Name	Description
[0]	No protection	Continuously overloaded motor when no warning or trip of the drive is required.
[1]	Thermistor warning	Activates a warning when the connected thermistor or KTY sensor in the motor reacts in the event of motor overtemperature.
[2]	Thermistor trip	Stops (trips) the drive when connected thermistor or KTY sensor in the motor reacts in the event of motor overtemperature. The thermistor cutout value must be more than 3 Ω. Integrate a thermistor (PTC sensor) in the motor for winding protection.
[3]	ETR warning 1	Calculates the load when setup 1 is active and activates a warning on the display when the motor is overloaded. Program a warning signal via 1 of the digital outputs.

Option	Name	Description
[4]	ETR trip 1	Calculates the load when set-up 1 is active and stops (trips) the drive when the motor is overloaded. Program a warning signal via 1 of the digital outputs. The signal appears in the event of a warning and if the drive trips (thermal warning).
[5]	ETR warning 2	Same as [3] <i>ETR warning 1</i> , but for setup 2.
[6]	ETR trip 2	Same as [4] <i>ETR trip 1</i> , but for setup 2.
[7]	ETR warning 3	Same as [3] <i>ETR warning 1</i> , but for setup 3.
[8]	ETR trip 3	Same as [4] <i>ETR trip 1</i> , but for setup 3.
[9]	ETR warning 4	Same as [3] <i>ETR warning 1</i> , but for setup 4.
[10]	ETR trip 4	Same as [4] <i>ETR trip 1</i> , but for setup 4.
[20]	ATEX ETR	Activates the thermal monitoring function for Ex-e motors for ATEX. Enables parameter <i>1-94 ATEX ETR cur.lim. speed reduction</i> , parameter <i>1-98 ATEX ETR interpol. points freq.</i> , and parameter <i>1-99 ATEX ETR interpol points current</i> .
[21]	Advanced ETR	

1-91 Motor External Fan

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	No	No external fan is required, that is the motor is derated at low speed.
[1]	Yes	Applies an external motor fan (external ventilation), so no derating of the motor is required at low speed. The upper curve in the illustration below ($f_{out} = 1 \times f_{M,N}$) is followed if the motor current is lower than nominal motor current (see parameter 1-24 Motor Current). If the motor current exceeds nominal current, the operation time still decreases as if no fan was installed.




Figure 40: ETR Profile

1-93 Thermistor Resource

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: Set digital input to **[0] PNP - Active at 24 V** in parameter **5-00 Digital I/O Mode**.



NOTE: When using VLT® PTC Thermistor Card MCB 112 always select **[0] None**.

Select the input to which the thermistor (PTC sensor) should be connected. An analog input option **[1] Analog Input 53** or **[2] Analog Input 54** cannot be selected if the analog input is already in use as a reference source (selected in parameter **3-15 Reference Resource 1**, parameter **3-16 Reference Resource 2**, or parameter **3-17 Reference Resource 3**).

Option	Name	Description
[0]	None	
[1]	Analog input 53	
[2]	Analog input 54	
[3]	Digital input 18	
[4]	Digital input 19	
[5]	Digital input 32	
[6]	Digital input 33	

1-94 ATEX ETR Cur. Lim. Speed Reduction

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	2 setups	Conversion index:	-1

Data type:	Uint16	Change during operation:	True

Only visible if parameter **1-90 Motor Thermal Protection** is set to **[20] ATEX ETR**.

1-95 Thermistor Sensor Type

Default value:	[0] KTY Sensor 1	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the used type of thermistor sensor.

Option	Name	Description
[0]*	KTY sensor 1	1 kΩ at 100 °C (212 °F).
[1]	KTY sensor 2	1 kΩ at 25 °C (77 °F).
[2]	KTY sensor 3	2 kΩ at 25 °C (77 °F).
[3]	Pt1000	1 kΩ at 0 °C (32 °F).
[4]	Ni1000 (6178 ppm/K)	1 kΩ at 0 °C (32 °F).
[5]	Ni1000-LG (TC5)	Examples: - Siemens LG-Ni1000 - Tasseron RTD Ni1000-TC5 1000 Ohm

1-96 Thermistor Sensor Resource

Default value:	[0] None	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select analog input terminal 54 to be used for connection of KTY/Pt1000/Ni1000 thermistor sensor. Terminal 54 cannot be selected as thermistor source if otherwise used as reference (see parameter **3-15 Reference Resource 1** to parameter **3-17 Reference Resource 3**).



NOTE: Connection of thermistor sensor between terminals 54 and 55 (GND).

Option	Name	Description
[0]*	None	
[2]	Analog input 54	

1-97 Thermistor Threshold Level

Default value:	80 °C	Parameter type:	Range, -40...220 °C
Setup:	1 setup	Conversion index:	100
Data type:	Int16	Change during operation:	True

Select the thermistor sensor threshold level for motor thermal protection.

1-98 ATEX ETR Interpol. Points Freq.

Default value:	Size related	Parameter type:	Array [4]
Setup:	1 setup	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Only visible if parameter **1-90 Motor Thermal Protection** is set to **[20] ATEX ETR**.

Enter the 4 frequency points [Hz] from the motor nameplate into this array.



NOTE: All frequency/current limit points from the motor nameplate or motor datasheet must be programmed.




Figure 41: Example of ATEX ETR Thermal Limitation Curve

1-99 ATEX ETR Interpol. Points Current

Default value:	Size related	Parameter type:	Array [4]
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Definition of the thermal limitation curve. For example, see parameter **1-98 ATEX ETR Interpol. Points Freq.**

Interpolation points

x-axis: f_m [Hz]

y-axis: $I_m/I_{m,n} \times 100$ [%]

Table 17: Interpolation Points

Parameter 1-98 ATEX ETR Interpol. Points Freq.	Parameter 1-99 ATEX ETR Interpol. Points Current
[0]=5 Hz	[0]=40%
[1]=15 Hz	[1]=80%
[2]=25 Hz	[2]=100%
[3]=50 Hz	[3]=100%

Use the 4 current points [A] from the motor nameplate. Calculate the values as a percentage of nominal motor current, $I_m/I_{m,n} \times 100$ [%], and enter the values into the array. All operating points underneath the curve are allowed continuously. Above the line, however, these points are only allowed for a limited time calculated as a function of the overload. When machine current is greater than 1.5 times the rated current, shutdown is immediate.



NOTE: All frequency/current limit points from the motor nameplate of motor datasheet must be programmed.

6.3.10.1 Connections Related to Motor Temperature Control

6.3.10.1.1 PTC Thermistor Connection




Figure 42: PTC Profile

Using a digital input and 10 V as supply: Example: The drive trips when the motor temperature is too high.

Parameter setup:

- Set parameter **1-90 Motor Thermal Protection** to **[2] Thermistor Trip**.
- Set parameter **1-93 Thermistor Source** to **[6] Digital Input**.




Figure 43: PTC Thermistor Connection - Digital Input

Using an analog input and 10 V as supply: Example: The drive trips when the motor temperature is too high.

Parameter setup:

- Set parameter **1-90 Motor Thermal Protection** to **[2] Thermistor Trip**.
- Set parameter **1-93 Thermistor Source** to **[2] Analog Input 54**.




Figure 44: PTC Thermistor Connection - Analog Input

Table 18: Threshold Cutout Values

Input digital/analog	Supply voltage	Threshold cutout values
Digital	10 V	<800 Ω⇒2.7 kΩ
Analog	10 V	<3.0 kΩ⇒3.0 kΩ



NOTE: Check that the selected supply voltage follows the specification of the used thermistor element.

6.3.10.1.2 KTY Sensor Connection



NOTE: KTY sensor connection is only available in FC 302.

KTY sensors are used especially in permanent magnet servo motors (PM motors) for dynamic adjusting of motor parameters such as stator resistance (parameter **1-30 Stator Resistance (Rs)**) for PM motors and also rotor resistance (parameter **1-31 Rotor Resistance (Rr)**) for induction motors, depending on winding temperature. The calculation is:

$$R_s = R_{s20} \cdot \alpha \cdot (1 + \alpha_{cu} \cdot \Delta T) \text{ where } \alpha_{cu} = 0.00393.$$

KTY sensors can be used for motor overload protection (parameter **1-97 KTY Threshold Level**). FC 302 can handle 3 types of KTY sensors defined in parameter **1-95 KTY Sensor Type**. The actual sensor temperature can be read out from parameter **16-19 KTY Sensor Temperature**.




Figure 45: KTY Type Selection

KTY Sensor 1: 1 kΩ at 100 °C (212 °F), for example, Philips KTY 84-1.

KTY Sensor 2: 1 kΩ at 25 °C (77 °F), for example, Philips KTY 83-1.

KTY Sensor 3: 2 kΩ at 25 °C (77 °F), for example, Philips KTY-10.



NOTE: If the temperature of the motor is used through a thermistor or KTY sensor, the PELV is not complied with if there are short circuits between motor windings and the sensor. To comply with PELV, put extra isolation on the sensor.

6.3.10.1.3 ETR

The calculations estimate the need for a lower load at lower speed due to less cooling from the fan incorporated in the motor.




Figure 46: ETR Profile

6.3.10.1.4 ATEX ETR

The VLT® PTC Thermistor Card MCB 112 offers ATEX-approved monitoring of motor temperature. Alternatively, an external ATEX-approved PTC protection device can be used.



NOTE: Only use ATEX Ex-e-approved motors for this function. See motor nameplate, approval certificate, datasheet, or contact motor supplier.

When controlling an Ex-e motor with increased safety, it is important to ensure certain limitations. The parameters that must be programmed are presented in [Table 19](#).

Table 19: Parameters

Function	Setting
Parameter 1-90 Motor Thermal Protection	[20] ATEX ETR
Parameter 1-94 ATEX ETR cur.lim. speed reduction	20%
Parameter 1-98 ATEX ETR interpol. points freq.	Motor nameplate.
Parameter 1-99 ATEX ETR interpol points current	
Parameter 1-23 Motor Frequency	Enter the same value as for parameter 4-19 Max Output Frequency .
Parameter 4-19 Max Output Frequency	Motor nameplate, possibly reduced for long motor cables, sine-wave filter, or reduced supply voltage.
Parameter 4-18 Current Limit	Forced to 150% by 1-90 [20]
Parameter 5-15 Terminal 33 Digital Input	[80] PTC Card 1
Parameter 5-19 Terminal 37 Safe Stop	[4] PTC 1 Alarm
Parameter 14-01 Switching Frequency	Check that the default value fulfills the requirement from the motor nameplate. If not, use a sine-wave filter.
Parameter 14-26 Trip Delay at Inverter Fault	0



NOTE: Compare the minimum switching frequency requirement stated by the motor manufacturer to the minimum switching frequency of the drive, the default value in parameter **14-01 Switching Frequency**. If the drive does not meet this requirement, use a sine-wave filter.

6.3.10.1.5 Klixon

The Klixon type thermal circuit breaker uses a KLIXON® metal dish. At a predetermined overload, the heat caused by the current through the disc causes a trip.

Using a digital input and 24 V as supply:

Example: The drive trips when the motor temperature is too high.

Parameter setup:

- Set parameter **1-90 Motor Thermal Protection** to **[2] Thermistor Trip**.
- Set parameter **1-93 Thermistor Source** to **[6] Digital Input**.




Figure 47: Thermistor Connection

6.4 Parameter Group 2-** Brakes

6.4.1 2-0* DC Brakes

Parameter group for configuring the DC brake and DC hold functions.

2-00 DC Hold Current

Default value:	Size related	Parameter type:	Range, 0 - 160%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True



NOTE: The maximum value depends on the rated motor current. Avoid 100% current for too long. It may damage the motor. In VVC+ control core, low values (<20%) of DC hold may result in wrong currents with larger motor sizes (>90 kW) and should be avoided. In cases when low DC hold currents with larger motors are required, select Flux control core to ensure the right currents.

Enter a value for the holding current as a percentage of the rated motor current $I_{M,N}$ set in parameter **1-24 Motor Current**. 100% DC hold current corresponds to $I_{M,N}$. This parameter holds the motor function (holding torque) or preheats the motor. This parameter is active if DC hold is selected in parameter **1-72 Start Function [0]** or parameter **1-80 Function at Stop [1]**.

2-01 DC Brake Current

Default value:	50%	Parameter type:	Range, 0 - 1000%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True



NOTE: The maximum value depends on the rated motor current. Avoid 100% current for too long. It may damage the motor.

Enter a value for current as a percentage of the rated motor current $I_{M,N}$, see parameter **1-24 Motor Current**. 100% DC brake current corresponds to $I_{M,N}$. DC brake current is applied on a stop command, when the speed is lower than the limit set in parameter **2-03 DC Brake Cut In Speed [RPM]**; when the DC brake inverse function is active, or via the serial communication port. The braking current is active during the time period set in parameter **2-02 DC Braking Time**.

2-02 DC Braking Time

Default value:	10 s	Parameter type:	Range, 0 - 60 s

Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Set the duration of the DC brake current set in parameter **2-01 DC Brake Current**, once activated.

2-03 DC Brake Cut In Speed [RPM]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-13 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Set the DC brake cut-in speed for activation of the DC brake current set in parameter **2-01 DC Brake Current**, upon a stop command.

2-04 DC Brake Cut In Speed [Hz]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-14 RPM
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True



NOTE: Parameter **2-04 DC Brake Cut In Speed [Hz]** is not effective when parameter **1-10 Motor Construction** = **[1] PM, nonsalient SPM**.

Set the DC brake cut-in speed for activation of the DC brake current set in parameter **2-01 DC Brake Current**, upon a stop command.

2-05 Maximum Reference

Default value:	Par. 3-03 ReferenceFeedbackUnit	Parameter type:	Range, par. 3-02 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

This is an access parameter to parameter **3-03 Maximum Reference** for legacy products. The maximum reference is the highest value obtainable by summing all references. The maximum reference unit matches the option selected in parameter **1-00 Configuration Mode** and the unit in parameter **3-01 Reference/Feedback Unit**.

2-06 Parking Current

Default value:	50%	Parameter type:	Range, 0 - 1000%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set current as percentage of rated motor current, parameter **1-24 Motor Current**. Is used when enabled in parameter **1-70 Start Mode**.

2-07 Parking Time

Default value:	3 s	Parameter type:	Range, 0.1 - 60 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Set the duration of the parking current set in parameter **2-06 Parking Current**, once activated.

6.4.2 2-1* Brake Energy Funct.

Parameter group for selecting dynamic brake parameters. Only valid for drives with brake chopper.

2-10 Brake Function

Default value:	–	Parameter type	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Off	No brake resistor installed.
[1]	Resistor brake	A brake resistor is incorporated in the system for dissipation of surplus brake energy as heat. Connecting a brake resistor allows a higher DC-link voltage during braking (generating operation). The resistor brake function is only active in drives with an integral dynamic brake.
[2]	AC brake	Improves braking without using a brake resistor. This parameter controls an overmagnetization of the motor when running with a generative load. This function can improve the OVC function. Increasing the electrical losses in the motor allows the OVC function to increase the braking torque without exceeding the overvoltage limit.
 NOTE: The AC brake is not as efficient as dynamic braking with resistor. AC brake is for VVC+ mode in both open and closed loop.		
[3]	Forced AC brake	This option applies AC brake current at ramp down as defined in parameter 2-16 AC Brake Max. Current .

2-11 Brake Resistor (ohm)

Default value:	Size related	Parameter type:	Range, 0 - 65535 Ohm
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the brake resistor value in Ω . This value is used for monitoring the power to the brake resistor in parameter **2-13 Brake Power Monitoring**. This parameter is only active in drives with an integral dynamic brake. Use this parameter for values without decimals. For a selection with 2 decimals, use parameter **30-81 Brake Resistor (ohm)**.

2-12 Brake Power Limit (kW)

Default value:	Size related	Parameter type:	Range, 0.001 - 2000.000 kW
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Parameter **2-12 Brake Power Limit (kW)** is the expected average power dissipated in the brake resistor over a period of 120 s. It is used as the monitoring limit for parameter **16-33 Brake Energy Average** and thereby specifies when a warning/alarm is to be given. To calculate parameter **2-12 Brake Power Limit (kW)**, the following formula can be used. $P_{br,avg}$ is the average power dissipated in the brake resistor. R_{br} is the resistance of the brake resistor. t_{br} is the active braking time within the 120 s period, T_{br} . U_{br} is the DC voltage where the brake resistor is active. This depends on the unit as follows:

$$P_{br,avg}[W] = \frac{U_{br}^2[V] \times t_{br}[s]}{R_{br}[\Omega] \times T_{br}[s]}$$

- T2 units: 390 V
- T4 units: 778 V
- T5 units: 810 V
- T6 units: 943 V/1099 V for D–F enclosures
- T7 units: 1099 V



NOTE: If R_{br} is not known, or if T_{br} is different from 120 s, the practical approach is to run the brake application, read parameter **16-33 Brake Energy Average** and then enter this + 20% in parameter **2-12 Brake Power Limit (kW)**.

2-13 Brake Power Monitoring

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter is only active in drives with a brake. This parameter enables monitoring of the power to the brake resistor. The power is calculated based on the resistance (parameter **2-11 Brake Resistor (ohm)**), the DC-link voltage, and the resistor duty time. If power monitoring is set to **[0] Off** or **[1] Warning**, the brake function remains active, even if the monitoring limit is exceeded. This may lead to thermal overload of the resistor. It is also possible to generate a warning via a relay/digital output. The measuring accuracy of the power monitoring depends on the accuracy of the resistance of the resistor (better than ±20%).

Option	Name	Description
[0]*	Off	No brake power monitoring required.
[1]	Warning 120s	Activates a warning on the display when the power transmitted during the duty time exceeds 100% of the monitoring limit (parameter 2-12 Brake Power Limit (kW)). The warning disappears when the transmitted power drops below 80% of the monitoring limit.
[2]	Trip 120s	Trips the drive and shows an alarm when the calculated power exceeds 100% of the monitoring limit.
[3]	Warning & Trip 120s	Activates both of the above, including warning and alarm.
[4]	Warning 30s	Activates a warning on the display when the power transmitted during the duty time exceeds 100% of the monitoring limit (parameter 2-12 Brake Power Limit (kW)). The warning disappears when the transmitted power drops below 80% of the monitoring limit.
[5]	Trip 30s	Trips the drive and shows an alarm when the calculated power exceeds 100% of the monitoring limit.
[6]	Warning & trip 30s	Activates both of the above, including warning and alarm.

Option	Name	Description
[7]	Warning 60s	Activates a warning on the display when the power transmitted during the duty time exceeds 100% of the monitoring limit (parameter 2-12 Brake Power Limit (kW)). The warning disappears when the transmitted power drops below 80% of the monitoring limit.
[8]	Trip 60s	Trips the drive and shows an alarm when the calculated power exceeds 100% of the monitoring limit.
[9]	Warning & trip 60s	Activates both of the above, including warning and alarm.
[10]	Warning 300s	Activates a warning on the display when the power transmitted during the duty time exceeds 100% of the monitoring limit (parameter 2-12 Brake Power Limit (kW)). The warning disappears when the transmitted power drops below 80% of the monitoring limit.
[11]	Trip 300s	Trips the drive and shows an alarm when the calculated power exceeds 100% of the monitoring limit.
[12]	Warning & trip 300s	Activates both of the above, including warning and alarm.
[13]	Warning 600s	Activates a warning on the display when the power transmitted during the duty time exceeds 100% of the monitoring limit (parameter 2-12 Brake Power Limit (kW)). The warning disappears when the transmitted power drops below 80% of the monitoring limit.
[14]	Trip 600s	Trips the drive and shows an alarm when the calculated power exceeds 100% of the monitoring limit.
[15]	Warning & trip 600s	Activates both of the above, including warning and alarm.

2-14 Brake Voltage Reduce

Default value:	0 V	Parameter type:	Range, 0 - 200 V
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter can reduce the DC voltage where the brake resistor is active. It is only valid for T4 units. Setting this parameter may change the brake resistor (parameter **2-11 Brake Resistor (ohm)**).

2-15 Brake Check

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Parameter **2-15 Brake Check** is only active in drives with an integral dynamic brake. Select type of test and monitoring function to check the connection to the brake resistor, or whether a brake resistor is present, and then show a warning or an alarm in the event of a fault.



NOTE: The brake resistor disconnection function is tested during power-up. However, the brake IGBT test is performed when there is no braking. A warning or trip disconnects the brake function.

The testing sequence is as follows:

- 1: The DC-link ripple amplitude is measured for 300 ms without braking.
- 2: The DC-link ripple amplitude is measured for 300 ms with the brake turned on.
 - If the DC-link ripple amplitude while braking is lower than the DC-link ripple amplitude before braking +1%: *Brake check has failed by returning a warning or alarm.*
 - If the DC-link ripple amplitude while braking is higher than the DC-link ripple amplitude before braking +1%: *Brake check is OK.*



NOTE: Remove a warning arising with **[0] Off** or **[1] Warning** by cycling the mains supply. The fault must be corrected first. For **[0] Off** or **[1] Warning**, the drive keeps running even if a fault is located.

Option	Name	Description
[0]*	Off	Monitors brake resistor and brake IGBT for a short circuit during operation. If a short circuit occurs, <i>Warning 25 Brake resistor shortcircuited</i> appears.
[1]	Warning	Monitors brake resistor and brake IGBT for a short circuit and runs a test for brake resistor disconnection during power-up.
[2]	Trip	Monitors for a short circuit or disconnection of the brake resistor, or a short circuit of the brake IGBT. If a fault occurs, the drive cuts out while showing an alarm (trip lock).
[3]	Stop and trip	Monitors for a short circuit or disconnection of the brake resistor, or a short circuit of the brake IGBT. If a fault occurs, the drive ramps down to coast and then trips. A trip lock alarm is shown (for example, warnings 25, 27, or 28).
[4]	AC brake	NOTE: This option is only available in FC 302. Monitors for a short circuit or disconnection of the brake resistor, or a short circuit of the brake IGBT. If a fault occurs, the drive performs a controlled ramp-down.
[5]	Trip lock	

2-16 AC Brake Max. Current

Default value:	100%	Parameter type:	Range, 0 - 1000.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint32	Change during operation:	True

Enter the maximum allowed current when using AC braking to avoid overheating of motor windings.



NOTE: Parameter **2-16 AC brake Max. Current** has no effect when parameter **1-10 Motor Construction** = **[1] PM, non salient SPM**.

2-17 Over-voltage Control

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–

Data type: Uint8 **Change during operation:** True

Overvoltage control (OVC) reduces the risk of the drive tripping due to an overvoltage on the DC-link caused by generative power from the load.

NOTE: Do not enable OVC in hoisting applications.

Option	Name	Description
[0]*	Disabled	No OVC required.
[1]	Enabled (not at stop)	Activates OVC except when using a stop signal to stop the drive.
[2]	Enabled	Activates OVC.

2-18 Brake Check Condition

Default value: [0] At power up **Parameter type:** Option
Setup: All setups **Conversion index:** –
Data type: Uint8 **Change during operation:** True

Option	Name	Description
[0]*	At power up	Brake check at power-up.
[1]	After coast situations	Brake check is performed after coast situations.

2-19 Over-voltage Gain

Default value: 100% **Parameter type:** Range, 10 - 200%
Setup: All setups **Conversion index:** 0
Data type: Uint16 **Change during operation:** True

Use this parameter for adjusting the overvoltage gain for parameter **2-17 Over-voltage Control** in the low-speed area.

6.4.3 2-2* Mechanical Brake

Parameters for controlling operation of an electro-magnetic (mechanical) brake, typically required in hoisting applications.

To control a mechanical braking, a relay output (relay 01 or relay 02) or a programmed digital output (terminal 27 or 29) is required. Normally, this output must be closed during periods when the drive is unable to hold the motor, for example due to an excessive load.

Select **[32] Mechanical Brake Control** for applications with an electro-magnetic brake in parameter **5-40 Function Relay**, parameter **5-30 Terminal 27 Digital Output**, or parameter **5-31 Terminal 29 Digital Output**. When selecting **[32] Mechanical brake control**, the mechanical braking is closed from start-up until the output current is above the level selected in parameter **2-20 Release Brake Current**. During stop, the mechanical braking activates when the speed drops below the level specified in parameter **2-21 Activate Brake Speed [RPM]**. If the drive enters an alarm condition, an overcurrent, or overvoltage situation, the mechanical braking immediately cuts in. This is also the case during Safe Torque Off.

NOTE: Protection mode and trip delay features (parameter **14-25 Trip Delay at Torque Limit** and parameter **14-26 Trip Delay at Inverter Fault**) may delay the activation of the mechanical braking in an alarm condition. These features must be disabled in hoisting applications.




Figure 48: Mechanical Braking

2-20 Release Brake Current

Default value:	Par. 16-37 A	Parameter type:	Range, 0 - par. 16-37 A
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Set the motor current for release of the mechanical braking when a start condition is present. The default value is the maximum current the inverter can provide for the particular power size. The upper limit is specified in parameter **16-37 Inv. Max. Current**.



NOTE: When mechanical brake control output is selected, but no mechanical braking is connected, the function does not work by default setting due to too low motor current.

2-21 Activate Brake Speed [RPM]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-13 RPM
Conversion index:	67	Data type:	Uint16
Change during operation:	True		

Set the motor speed for activation of the mechanical braking when a stop condition is present.

2-22 Activate Brake Speed [Hz]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-14
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Set the motor frequency for activation of the mechanical braking when a stop condition is present.

2-23 Activate Brake Delay

Default value:	0 s	Parameter type:	Range, 0 - 5 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

Enter the brake delay time of the coast after ramp-down time. The shaft is held at 0 speed with full holding torque. Ensure that the mechanical braking has locked the load before the motor enters coast mode. To adjust transition of the load to the mechanical braking, set parameter **2-23 Activate Brake Delay** and parameter **2-24 Stop Delay**. Setting of brake delay parameters does not affect the torque. The drive does not register that mechanical braking is holding the load. After setting parameter **2-23 Activate Brake Delay**, the torque drops to 0 after a few minutes. The sudden torque change leads to movement and noise.

2-24 Stop Delay

Default value:	0 s	Parameter type:	Range, 0 - 5 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

Set the time interval from the moment when the motor is stopped until the brake closes. To adjust transition of the load to the mechanical braking, set parameter **2-23 Activate Brake Delay** and parameter **2-24 Stop Delay**. This parameter is a part of the stop function.

2-25 Brake Release Time

Default value:	0.20 s	Parameter type:	Range, 0 - 20 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This value defines the time it takes for the mechanical brake to open. This parameter must act as a timeout when brake feedback is activated.

2-26 Torque Ref

Default value:	0%	Parameter type:	Range, -300 - 300%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

The value defines the torque applied against the closed mechanical brake before release. The torque/load on a crane is positive and is 10–160%. To obtain the best starting point, set parameter **2-26 Torque Ref** to approximately 70%. The torque/load on a lift can be both positive and negative and between -160% and +160%. To obtain the best starting point, set parameter **2-26 Torque Ref** to 0%. The higher the torque error is (parameter **2-26 Torque Ref** vs. actual torque), the more movement during load takeover.

2-27 Torque Ramp Up Time

Default value:	0.2 s	Parameter type:	Range, 0 - 5 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

The value defines the duration of the torque ramp in clockwise direction. Value 0 enables very fast magnetization in flux control principle.

2-28 Gain Boost Factor

Default value:	1	Parameter type:	Range, 0 - 4
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Only active in flux closed loop. The function ensures a smooth transition from torque control mode to speed control mode when the motor takes over the load from the brake. Increase to minimize the movement. Activate the advanced mechanical braking (parameter group 2-3* *Adv. Mech Brake*) by setting parameter **2-28 Gain Boost Factor** to 0.

2-29 Torque Ramp Down Time

Default value:	0 s	Parameter type:	Range, 0 - 5 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

Torque ramp-down time.

6.4.4 Hoist Mechanical Brake

The hoist mechanical brake control supports the following functions:

- 2 channels for mechanical braking feedback to offer further protection against unintended behavior resulting from broken cable.
- Monitoring of mechanical braking feedback throughout the complete cycle. This helps protect the mechanical brake, especially if more drives are connected to the same shaft.
- No ramp-up until feedback confirms that mechanical brake is open.
- Improved load control at stop. If the value of parameter **2-23 Activate Brake Delay** is too low, *Warning 22, Hoist mech. brake* is activated and the torque is not allowed to ramp down.
- The transition when motor takes over the load from the brake can be configured. Parameter **2-28 Gain Boost Factor** can be increased to minimize the movement. To achieve smooth transition, change the setting from the speed control to the position control during the changeover.
- Set parameter **2-28 Gain Boost Factor** to 0 to enable position control during parameter **2-02 DC Braking Time**. This enables parameter **2-30 Position P Start Proportional Gain** to parameter **2-33 Speed PID Start Lowpass Filter Time**, which are PID parameters for the position control.




Figure 49: Brake Release Sequence for Hoist Mechanical Brake Control

Parameter **2-26 Torque Ref** to parameter **2-33 Speed PID Start Lowpass Filter Time** are only available for the hoist mechanical brake control (flux with motor feedback).

6.4.5 2-3* Adv. Mech. Brake

Parameter **2-30 Position P Start Proportional Gain** to parameter **2-33 Speed PID Start Lowpass Filter Time** can be set up for very smooth transition change from speed control to position control during parameter **2-25 Brake Release Time** - the time when the load is transferred from the mechanical brake to the drive. Parameter **2-30 Position P Start Proportional Gain** to parameter **2-33 Speed PID Start Lowpass Filter Time** are activated when parameter **2-28 Gain Boost Factor** is set to 0.

2-30 Position P Start Proportional Gain

Default value:	0.0000	Parameter type:	Range, 0.0000 - 1.0000
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True

Enter the position controller during start proportional gain. Quick control is obtained at high amplification. However, if the amplification is too high, the process may become unstable.

2-31 Speed PID Start Proportional Gain

Default value:	0.0150	Parameter type:	Range, 0.0000 - 1.0000
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True

Enter the speed controller proportional gain during start. Quick control is obtained at high amplification. However, if amplification is too high, the process may become unstable.

2-32 Speed PID Start Integral Time

Default value:	200.0 ms	Parameter type:	Range, 1.0 - 20000.0 ms
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True

Enter the speed controller integral time. Obtain quick control through a short integral time, though if the integral time is too short, the process becomes unstable. An excessively long integral time disables the integral action.

2-33 Speed PID Start Lowpass Filter Time

Default value:	10.0 ms	Parameter type:	Range, 0.1 - 100.0 ms
Setup:	All setups	Conversion index:	-4
Data type:	Uint16	Change during operation:	True

Set a time constant for the speed control low-pass filter. The low-pass filter improves steady-state performance and dampens oscillations on the feedback signal. However, severe filtering can be detrimental to dynamic performance.

2-34 Zero Speed Position P Proportional Gain

Default value:	0.0000	Parameter type:	Range, 0.0000 - 1.000
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.1X and newer.

Enter the proportional gain for position control at standstill in speed mode.

6.5 Parameter Group 3-** Reference/Ramps

6.5.1 3-0* Reference Limits

3-00 Reference Range

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the range of the reference signal and the feedback signal. Signal values can be positive only, or positive and negative. The minimum limit may have a negative value, unless [1] *Speed closed loop control* or [3] *Process* is selected in parameter *1-00 Configuration Mode*.

Option	Name	Description
[0]	Min - Max	Select the range of the reference signal and the feedback signal. Signal values can be positive only, or positive and negative. The minimum limit may have a negative value, unless [1] Speed closed loop control or [3] Process is selected in parameter 1-00 Configuration Mode .
[1]	-Max - +Max	For both positive and negative values (both directions, relative to parameter 4-10 Motor Speed Direction).

3-01 Reference/Feedback Unit

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the unit to be used in process PID control references and feedbacks. Parameter **1-00 Configuration Mode** must be either **[3] Process** or **[8] Extended PID Control**.

Option	Name	Description
[0]	None	
[1]	%	
[2]	RPM	
[3]	Hz	
[4]	Nm	
[5]	PPM	
[10]	l/min	
[12]	Pulse/s	
[20]	l/s	
[21]	l/min	
[22]	l/h	
[23]	m ³ /s	
[24]	m ³ /min	
[25]	m ³ /h	
[30]	kg/s	
[31]	kg/min	
[32]	kg/h	
[33]	t/min	
[34]	t/h	
[40]	m/s	
[41]	m/min	
[45]	m	

Option	Name	Description
[60]	°C	
[70]	mbar	
[71]	bar	
[72]	Pa	
[73]	kPa	
[74]	m WG	
[80]	kW	
[120]	GPM	
[121]	gal/s	
[122]	gal/min	
[123]	gal/h	
[124]	CFM	
[125]	ft ³ /s	
[126]	ft ³ /min	
[127]	ft ³ /h	
[130]	lb/s	
[131]	lb/min	
[132]	lb/h	
[140]	ft/s	
[141]	ft/min	
[145]	ft	
[150]	lb ft	
[160]	°F	
[170]	psi	
[171]	lb/in ³	
[172]	in WG	
[173]	ft WG	
[180]	HP	

3-02 Minimum Reference

Default value:	Size related	Parameter type:	Range, -999999.999 ReferenceFeedbackUnit - par. 3-03 Maximum Reference
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the minimum reference. The minimum reference is the lowest value obtainable by summing all references. Minimum reference is active only when parameter **3-00 Reference Range** is set to **[0] Min.- Max.** The minimum reference unit matches:

- The configuration of parameter **1-00 Configuration Mode**: For **[1] Speed closed loop, RPM**; for **[2] Torque, Nm**.
- The unit selected in parameter **3-01 Reference/ Feedback Unit**.

If option **[10] Synchronization** is selected in parameter **1-00 Configuration Mode**, this parameter defines the maximum speed deviation when performing the position offset defined in parameter **3-26 Master Offset**. Also see parameter **3-28 Master Offset Speed Ref.**

3-03 Maximum Reference

Default value:	Size related	Parameter type:	Range, 0.000 - 999999.999 Reference FeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the maximum reference. The maximum reference is the highest value obtainable by summing all references. The maximum reference unit matches:

- The configuration selected in parameter **1-00 Configuration Mode**: For **[1] Speed closed loop, RPM**; for **[2] Torque, Nm**.
- The unit selected in parameter **3-00 Reference Range**.

If **[9] Positioning** is selected in parameter **1-00 Configuration Mode**, this parameter defines the default speed for positioning.

3-04 Reference Function

Default value:	[0] Sum	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	Sum	Sums both external and preset reference sources.
[1]	External/Preset	Use either the preset or the external reference source. Shift between external and preset via a command or a digital input.

3-05 On Reference Window

Default value:	Size related	Parameter type:	Range, 0 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the tolerance window for on-reference or on-target status. Depending on the option selected in parameter **1-00 Configuration Mode**, this parameter defines the following:

- Speed mode: Speed window for on-reference status.
- Torque mode: Torque window for on-reference status.
- Position mode: Speed window for on-target status. See also parameter **3-08 On Target Window**.



NOTE: Parameter **3-08 On Target Window** is only available in FC 302 with IMC software version 48.0X and newer.

3-06 Minimum Position

Default value:	-100000 AbsolutePositionUnit	Parameter type:	Range, -2147483648 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X and newer.

Enter the minimum position. This parameter defines the position range in linear axis mode (parameter **17-76 Position Axis Mode**) and in the position limit function (parameter **4-73 Position Limit Function**).

3-07 Maximum Position

Default value:	100000 AbsolutePositionUnit	Parameter type:	Range, -2147483648 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Enter the maximum position. This parameter defines the position range in linear axis mode (parameter **17-76 Position Axis Mode**).
Position range limits:

- Linear: Parameter **3-06 Minimum Position** to parameter **3-07 Maximum Position**.
- Rotary: 0-parameter **3-07 Maximum Position**.

The position limit function uses this parameter (parameter **4-73 Position Limit Function**).

3-08 On Target Window

Default value:	5 AbsolutePositionUnit	Parameter type:	Range, 0 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

The drive considers the positioning completed and sends the on target signal when the actual position is within parameter **3-08 On Target Window** for the duration of parameter **3-09 On Target Time** and the actual speed is less than parameter **3-05 On Reference Window**.

3-09 On Target Time

Default value:	1 ms	Parameter type:	Range, 0 - 60000 ms
Setup:	All setups	Conversion index:	-3

Data type: Uint16 **Change during operation:** True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Enter the time for evaluating the on-target window, see also parameter **3-08 On Target Window**.

6.5.2 3-1* References

Select the preset references. Select Preset ref. bit 0/1/2 [16], [17], or [18] for the corresponding digital inputs in parameter group **5-1* Digital Inputs**.

3-10 Preset Reference

Default value:	0%	Parameter type:	Array [8]
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Enter up to 8 different preset references (0–7) in this parameter, using array programming. The preset reference is stated as a percentage of the value Ref_{MAX} (parameter **3-03 Maximum Reference**). If a Ref_{MIN} different from 0 (parameter **3-02 Minimum Reference**) is programmed, the preset reference is calculated as a percentage of the full reference range, that is on the basis of the difference between Ref_{MAX} and Ref_{MIN} . Afterwards, the value is added to Ref_{MIN} . When using preset references, select preset reference bit 0/1/2 [16], [17] or [18] for the corresponding digital inputs in parameter group **5-1* Digital Inputs**.




Figure 50: Preset Reference




Figure 51: Preset Reference Scheme

Table 20: Preset Reference Bits

Preset ref. bit	2	1	0
Preset ref. 0	0	0	0
Preset ref. 1	0	0	1
Preset ref. 2	0	1	0
Preset ref. 3	0	1	1
Preset ref. 4	1	0	0
Preset ref. 5	1	0	1
Preset ref. 6	1	1	0
Preset ref. 7	1	1	1

3-11 Jog Speed [Hz]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-14 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

The jog speed is a fixed output speed at which the drive is running when the jog function is activated. See also parameter **3-80 Jog/Homing Ramp Time**.

3-12 Catch Up/Slow Down Value

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Enter a percentage (relative) value to be either added to or deducted from the actual reference for catch up or slow down. If catch up is selected via 1 of the digital inputs (parameter **5-10 Terminal 18 Digital Input** to parameter **5-15 Terminal 33 Digital Input**), the percentage (relative) value is added to the total reference. If slow down is selected via 1 of the digital inputs (parameter **5-10 Terminal 18 Digital Input** to parameter **5-15 Terminal 33 Digital Input**), the percentage (relative) value is deducted from the total reference. Obtain extended functionality with the DigiPot function. See parameter group **3-9* Digital Potentiometer**.

3-13 Reference Site

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select which reference site to activate.

Option	Name	Description
[0]	Linked to hand/auto	Use local reference when in hand-on mode, or remote reference when in auto-on mode.
[1]	Remote	Use remote reference in both hand-on mode and auto-on mode.
[2]	Local	Use local reference in both hand-on and auto-on mode.
 NOTE: When set to [2] Local, the drive starts with this setting again after a power-down.		
[3]	Linked to H/A MCO	Select this option to enable the FFACC factor in parameter 32-66 Acceleration Feed-Forward . Enabling FFACC reduces jitter and makes the transmission from the motion controller to the control card of the drive faster. This leads to faster response times for dynamic applications and position control. For more information about FFACC, see VLT® Motion Control MCO 305 Operating Instructions.

3-14 Preset Relative Reference

Default value:	0%	Parameter type:	Range, -200 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	True

The actual reference, X, is increased or decreased with percentage Y, which gives the resulting actual reference, Z. The actual reference (X) is the sum of the inputs selected in:

- Parameter **3-15 Reference Resource 1**.
- Parameter **3-16 Reference Resource 2**.
- Parameter **3-17 Reference Resource 3**.
- Parameter **8-02 Control Word Source**.




Figure 52: Preset Relative Reference




Figure 53: Actual Reference

3-15 Reference Resource 1

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the reference input to be used for the 1st reference signal. Parameter **3-15 Resource Reference 1**, parameter **3-16 Resource Reference 2**, and parameter **3-17 Resource Reference 3** define up to 3 different reference signals. The sum of these reference signals defines the actual reference. Select the speed reference source in parameter **3-15 Reference Resource 1** when parameter **1-00 Configuration Mode** is set to **[9] Positioning** in positioning mode.



NOTE: The options [3],[4], and [5] are only available in FC 302 with IMC software version 48.0X and newer.



NOTE: The options [6], [12], [13], and [14] are only available in FC 302 with IMC software version 48.3X and newer.



NOTE: The options [15] and [16] are only available in FC 302 with IMC software version 48.4X and newer.

Option	Name	Description
[0]	No function	
[1]	Analog Input 53	
[2]	Analog Input 54	
[3]	24V Encoder 32/33	
[4]	MCB 102	
[5]	MCB 103	
[6]	Virtual Master	
[7]	Frequency Input 29	
		NOTE: This option is only available in FC 302.
[8]	Frequency Input 33	
[11]	Local Bus Reference	Reference from terminals 68 and 69.

Option	Name	Description
[12]	Preset Reference	Select this option to set the speed reference in parameter 3-10 Preset Reference together with the preset target in parameter 3-20 Preset Target to calculate speed profile for positioning.
[13]	24V Encoder 27/29	
[14]	MCB 102 Absolute	
[15]	MCO Encoder 1 X56	
[16]	MCO Encoder 2 X55	
[20]	Digital Potmeter	
[21]	Analog Input X30/11	VLT® General Purpose I/O MCB 101
[22]	Analog Input X30/12	VLT® General Purpose I/O MCB 101
[29]	Analog Input X48/2	
[37]	Analog Input X49/1	
[38]	Analog Input X49/3	
[39]	Analog Input X49/5	

3-16 Reference Resource 2

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the reference input to be used for the 2nd reference signal. Parameter **3-15 Resource Reference 1**, parameter **3-16 Resource Reference 2**, and parameter **3-17 Resource Reference 3** define up to 3 different reference signals. The sum of these reference signals defines the actual reference. When parameter **1-00 Configuration Mode** is set to **[9] Positioning**. Configure parameter **3-16 Reference Resource 2** to select the source for target position.



NOTE: The options [3],[4], and [5] are only available in FC 302 with IMC software version 48.0X and newer.



NOTE: The options [6], [12], [13], and [14] are only available in FC 302 with IMC software version 48.3X and newer.



NOTE: The options [15] and [16] are only available in FC 302 with IMC software version 48.4X and newer.

Option	Name	Description
[0]	No function	
[1]	Analog Input 53	
[2]	Analog Input 54	
[3]	24V Encoder 32/33	Single signal generated from 24 V High Threshold Logic (HTL) encoder connected to terminals 32 and 33. Configure the 24 V encoder interface in parameter group 5-7* 24 V Encoder Option . Program terminals 32/33 to [0] No operation .

Option	Name	Description
[4]	MCB 102	This is only available for VLT® Encoder Option MCB 102. Configure the encoder interface in parameter groups 17-0* Encoder Interface , 17-1* Inc. Enc. Interface , and 17-2* Abs. Enc. Interface .
[5]	MCB 103	This is only available for VLT® Resolver Option MCB 103. Configure the resolver interface in parameter group 17-5* Resolver Interface .
[6]	Virtual Master	Master signal for the drive which hosts the virtual master without an external connection. This option is only active when option [10] Synchronization is selected in parameter 1-00 Configuration Mode .
[7]	Frequency Input 29	NOTE: This option is only available in FC 302.
[8]	Frequency Input 33	
[11]	Local Bus Reference	Reference from terminals 68 and 69.
[12]	Preset Reference	
[13]	24V Encoder 27/29	Single signal generated from 24 V High Threshold Logic (HTL) encoder connected to terminals 27 and 29. Configure the 24 V encoder interface in parameter group 5.7* 24 V Encoder Input . Program terminals 27/29 to [0] No operation .
[14]	MCB 102 Absolute	The option is only available for VLT® Encoder Option MCB 102 with version 4.00 and newer and when parameter 17-00 Encoders Connected is set to option [1] Two Encoders .
[15]	MCO Encoder 1 X56	
[16]	MCO Encoder 2 X55	
[20]	Digital Potmeter	
[21]	Analog Input X30/11	VLT® General Purpose I/O MCB 101
[22]	Analog Input X30/12	VLT® General Purpose I/O MCB 101
[29]	Analog Input X48/2	
[37]	Analog Input X49/1	
[38]	Analog Input X49/3	
[39]	Analog Input X49/5	

3-17 Reference Resource 3

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the reference input to be used for the 3rd reference signal. Parameter **3-15 Resource Reference 1**, parameter **3-16 Resource Reference 2**, and parameter **3-17 Resource Reference 3** define up to 3 different reference signals. The sum of these reference signals defines the actual reference.



NOTE: The options [3], [4], and [5] are only available in FC 302 with IMC software version 48.0X and newer.



NOTE: The options [6], [12], [13], and [14] are only available in FC 302 with IMC software version 48.3X and newer.



NOTE: The options [15] and [16] are only available in FC 302 with IMC software version 48.4X and newer.

Option	Name	Description
[0]	No function	
[1]	Analog Input 53	
[2]	Analog Input 54	
[3]	24V Encoder 32/33	
[4]	MCB 102	
[5]	MCB 103	
[6]	Virtual Master	
[7]	Frequency Input 29	 NOTE: This option is only available in FC 302.
[8]	Frequency Input 33	
[11]	Local Bus Reference	Reference from terminals 68 and 69.
[12]	Preset Reference	
[13]	24V Encoder 27/29	
[14]	MCB 102 Absolute	
[15]	MCO Encoder 1 X56	
[16]	MCO Encoder 2 X55	
[20]	Digital Potmeter	
[21]	Analog Input X30/11	
[22]	Analog Input X30/12	
[29]	Analog Input X48/2	
[37]	Analog Input X49/1	
[38]	Analog Input X49/3	
[39]	Analog Input X49/5	

3-18 Relative Scaling Reference Resource

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: The options [3], [4], and [5] are only available in FC 302 with IMC software version 48.0X and newer.



NOTE: The options [6], [12], [13], and [14] are only available in FC 302 with IMC software version 48.3X and newer.



NOTE: The options [15] and [16] are only available in FC 302 with IMC software version 48.4X and newer.

Select a variable value to be added to the fixed value (defined in parameter **3-14 Preset Relative Reference**). The sum of the fixed and variable values (labeled Y in the following drawing) is multiplied by the actual reference (labeled X in the following drawing). This product is then added to the actual reference ($X + X \cdot Y / 100$) to give the resulting actual reference.




Figure 54: Resulting Actual Reference

Option	Name	Description
[0]*	No function	
[1]	Analog Input 53	
[2]	Analog Input 54	
[3]	24V Encoder 32/33	
[4]	MCB 102	
[5]	MCB 103	
[6]	Virtual Master	
[7]	Frequency Input 29	
[8]	Frequency Input 33	
[11]	Local Bus Reference	Reference from terminals 68 and 69.
[12]	Preset Reference	
[13]	24V Encoder 27/29	
[14]	MCB 102 Absolute	
[15]	MCO Encoder 1 X56	
[16]	MCO Encoder 2 X55	
[20]	Digital Potmeter	
[21]	Analog Input X30/11	
[22]	Analog Input X30/12	



NOTE: This option is only available in FC 302.

Option	Name	Description
[29]	Analog Input X48/2	
[37]	Analog Input X49/1	
[38]	Analog Input X49/3	
[39]	Analog Input X49/5	

3-19 Jog Speed [RPM]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-13 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter a value for the jog speed n_{JOG} , which is a fixed output speed. The drive runs at this speed when the jog function is activated. The maximum limit is defined in parameter **4-13 Motor Speed High Limit [RPM]**. See also parameter **3-80 Jog/Homing Ramp Time**.

6.5.3 3-2* References II

3-20 Preset Target

Default value:	0 AbsolutePositionUnit	Parameter type:	Array [8]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Set up to 8 target positions. Select from the 8 preset positions using digital inputs or the fieldbus control word.

3-21 Touch Target

Default value:	0 AbsolutePositionUnit	Parameter type:	Range, -2147483648 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

The value 2147483647 = Latch Only. With Latch Only actual position of touch sensor is latched and updated in parameter **18-25 Latched Actual Pos** but no positioning is executed. Enter the target position in touch probe positioning mode. This parameter defines the distance from the detection event of the touch probe sensor to the final target position in position units.

3-22 Master Scale Numerator

Default value:	1	Parameter type:	Range, -2147483648 - 2147483647
Setup:	All setups	Conversion index:	0

Data type: Int32	Change during operation: True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Parameter **3-22 Master Scale Numerator** and parameter **3-23 Master Scale Denominator** define the gear ratio between the master and the follower in synchronization mode.

$$\text{Master revolutions} = \frac{\text{Par.3-22}}{\text{Par.3-23}} \times \text{Follower revolutions}$$

3-23 Master Scale Denominator

Default value: 1	Parameter type: Range, -2147483648 - 2147483647
Setup: All setups	Conversion index: 0
Data type: Int32	Change during operation: True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Refer to parameter **3-22 Master Scale Numerator**.

3-24 Master Lowpass Filter Time

Default value: 20 ms	Parameter type: Range, 1 - 2000 ms
Setup: All setups	Conversion index: -1
Data type: Uint16	Change during operation: True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Enter the time constant for master speed calculation in synchronizing mode.

3-25 Fieldbus Sync. Resolution

Default value: 1048576	Parameter type: Range, 0 - 2147483647
Setup: All setups	Conversion index: 0
Data type: Uint32	Change during operation: True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Set the resolution of the fieldbus reference in synchronization mode. 0 sets the full unsigned 32-bit value, $2^{32} = 429496729$.

3-26 Master Offset

Default value: 0 AbsolutePositionUnit	Parameter type: Range, -2147483648 - 2147483647 AbsolutePositionUnit
Setup: All setups	Conversion index: 0

Data type:	Int32	Change during operation:	True

NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Enter the position offset between the master and the follower in synchronization mode. This value is added to the follower position at each activation of a digital input with option **[113] Enable Reference** or bit 5 of the fieldbus control word. Parameter **3-02 Minimum Reference** defines the maximum deviation from the actual master speed during the execution of the offset.

3-27 Virtual Master Max Ref

Default value:	50.0 RPS	Parameter type:	Range, 0.0 - 590.0 RPS
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

NOTE: This parameter is only available in FC 302 with IMC software version 48.1X or newer.

Enter the maximum reference for the virtual master. The actual reference is set relative to this value using the source selected in parameter **3-15 Reference Resource 1** or fieldbus reference 1. The rotation direction is controlled by the forward/reverse signal on a digital input or fieldbus. Use parameter group **3-6* Ramp 3** to configure acceleration and deceleration.

3-28 Master Offset Speed Ref

Default value:	1500 RPM	Parameter type:	Range, 0 - 65000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

NOTE: This parameter is only available in FC 302 with IMC software version 48.2X or newer.

Enter the speed reference for changing the master offset in synchronization mode. To ensure compatibility with software versions 48.01 and 48.10, this parameter is only active when parameter **3-02 Minimum Reference** is set to 0.

3-29 Interpolation Time Period

Default value:	Size related	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

NOTE: This parameter is only available in FC 302 with IMC software version 48.5X.

Set the time interval of the cyclic reference for CSV, CSP, or synchronizing. **CSV:** When providing only speed reference. Acceleration/ deceleration is interpolated based on this time interval. **CSP/Synchronizing:** When only providing position reference speed and acceleration/ deceleration is interpolated based on this time interval.

Index	Range	Description
[0], default 1	1–1000	The time period in seconds but actual time is scaled by index 1.
[1], default -3	-3–0	The exponent for the time period in index 0. Actual time = index 0 to the power of index 1. Example: Index 0 = 1 and index 1 = -3 ⇒ time set in ms.

6.5.4 3-3* Gen Ramp & Sync



NOTE:

The following parameters are only available in FC 302:

- Parameter **3-30 Min. Speed Ramp Time**

3-30 Min. Speed Ramp Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Use this parameter for torque mode. Enter the acceleration time from 0 RPM to the low motor speed limit set in parameter **4-11 Motor Speed Low Limit**. Ensure that the output current required for achieving the ramp-up time does not exceed the limit set in parameter **4-18 Current Limit**.

3-32 Ramp Speed Ref

Default value:	0 RPM	Parameter type:	Range, 0 - 1000000 RPM
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter a value to specify the ramp speed reference. When 0 is specified, the ramp speed is selected based on the settings in parameter **1-23 Motor Frequency** for induction motors and parameter **1-25 Motor Nominal Speed** for synchronous motors. When a value greater than 0 is specified, the ramp speed reference is used to accelerate or decelerate irrespectively of motor type or data.

3-33 Sync Mode & Start Behavior

Default value:	[0] Relative Sync	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X or newer.

Select the type of synchronization and start mechanism for synchronization mode. Marker synchronization is enabled when options **[10] Marker Shortest**, **[11] Marker Catch Up**, or **[12] Marker Slow Down** is selected.

Option	Name	Description
[0]*	Relative Sync.	The follower position is locked to the master position at start, then Enable Reference is active.
[1]	Relative Re-Sync.	The position of the follower drive stays locked to the master drive's position when Enable Reference is active, though the drive is stopped or coasted. For example, when the drive is restarted after an alarm, the follower drive realigns with the master drive.
[2]	Absolute Sync.	The position of the follower drive is always locked to the position of the master drive.
[10]	Marker Shortest	Controls the behavior of the 1st marker synchronization. Marker synchronization start-up behavior depends on parameter 3-34 Marker Distance : - When parameter 3-34 Marker Distance = 0 (OFF), the 1st follower marker is aligned with the 1st master marker. - When parameter 3-34 Marker Distance > 0, the 1st follower marker is aligned with the closest master marker to accelerate or decelerate to the correct position by a maximum of half the marker distance.
[11]	Marker Catch Up	Select this option to accelerate the follower to reach the position of the previous master marker during marker synchronization.
[12]	Marker Slow Down	Select this option to decelerate the follower to align with the subsequent master marker during marker synchronization.
[13]	Mar. Dis. Meas. Fo.	Select this option to measure the follower marker distance while synchronizing without marker correction, when the master is running. The measured follower marker distance is set in parameter 3-34 Marker Distance .
[14]	Mar. Dis. Meas. Ma.	Select this option to measure master marker distance while synchronizing without marker correction, when the master is running. The measured master marker distance is set in parameter 3-34 Marker Distance .
[15]	Mar. meas. shortest	Continuous measurement of distance between master and follower marker where the behavior depends on parameter 3-34 Marker Distance . - Parameter 3-34 Marker Distance = 0 (OFF): Distance is measure between the 1st follower marker and the 1st master marker no matter which one comes first, this is considered as the 1st pair of markers. Distance will then be measured between every following pairs of master and follower markers. - Parameter 3-34 Marker Distance > 0: At every follower marker distance is measured to the closest master marker. The result of the measurement is updated in parameter 18-24 Marker Po. Offset in position units as defined in parameter group 17-0* Encoder Interface.

Option	Name	Description
[16]	Mar. meas. catch up	Continuous measurement of distance between master and follower marker. At every follower marker the distance is measured to the latest master marker. The result of the measurement is updated in parameter 18-24 Marker Po. Offset in position units as defined in parameter group 17-0* Encoder Interface .
[17]	Mar. meas. slow down	Continuous measurement of distance between master and follower marker. At every master marker the distance is measured to the latest follower maker. The result of the measurement is updated in parameter 18-24 Marker Po. Offset in position units as defined in parameter group 17-0* Encoder Interface .
[20]	CAM	Synchronizing according to the profile defined by parameter 3-36 CAM Master Table and parameter 3-37 CAM Follower Table .
[21]	CAM offset	Synchronizing according to the profile defined by parameter 3-36 CAM Master Table and parameter 3-37 CAM Follower Table with master offset defined in parameter 3-26 Master Offset .

3-34 Marker Distance

Default value:	0 AbsolutePositionUnit	Parameter type:	Range, 0 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer.

Enter the approximate distance between 2 markers. To measure the marker distance for follower or master marker, select the corresponding marker measuring function in parameter **3-33 Sync. Mode & Start Behavior**. Marker distance is in position units as defined in parameter group **17-1* Inc. Enc. Interface**. The value is converted to the position units of the follower using the master scale set in parameter **3-22 Master Scale Numerator** and parameter **3-23 Master Scale Denominator**. Configure the marker distance to utilize the marker window function.

3-35 Marker Window

Default value:	0 AbsolutePositionUnit	Parameter type:	Range, 0 - par. 3-34 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X or newer.

Make sure to configure parameter **3-34 Marker Distance**. The marker window function is only active when the marker distance is set. Enter the window size around the expected marker position where the marker is accepted. The marker window is used for both master and follower marker and the position units are as defined in parameter group **17-7* Position Scaling**. Master position value is converted to follower position units using the master scale set in parameter **3-22 Master Scale Numerator** and parameter **3-23 Master Scale Denominator**.

3-36 CAM Master Table

Default value:	0	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.7X or newer.

Master position which together with the corresponding element of parameter **3-37 CAM Follower Table** forms a CAM position point.

3-37 CAM Follower Table

Default value:	0	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.7X or newer.

Follower position which together with the corresponding element of parameter **3-36 CAM Master Table** forms a CAM position point.

3-38 CAM Curve Table

Default value:	–	Parameter type:	Option, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	UInt8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.7X or newer.

Option	Name	Description
[0]	None	
[1]	Linear	Connects the CAM table point with a straight line, corresponds to a fixed gear ratio between master and follower.
[2]	Poly x'order	Connects the CAM table points with an x-order polynomial where x is determined by the number of consecutive points of this type.
[3]	Poly 2'order	Connects the CAM table points with a 2nd order polynomial.
[4]	Poly 3'order	Connects the CAM table points with a 3rd order polynomial.

Option	Name	Description
[5]	Poly 4'order	Connects the CAM table points with a 4th order polynomial. At least 2 consecutive CAM table points of this type are required to use this selection.
[6]	Poly 5'order	Connects the CAM table points with a 5th order polynomial. At least 3 consecutive CAM table points of this type are required to use this selection.
[8]	Sine	Connects the CAM table points with a full sine wave.
[9]	Cosine	Connects the CAM table points with a full cosine wave.
[10]	End	Always select this option for the last point of the curve.

3-39 CAM Follower Gain

Default value:	100.0	Parameter type:	Range, 0.0 - 500.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.7X or newer.

The follower table is multiplied by this gain which can be adjusted while running.

6.5.5 3-4* Ramp 1

For each of the 4 ramps (parameter groups **3-4* Ramp 1**, **3-5* Ramp 2**, **3-6* Ramp 3**, and **3-7* Ramp 4**) configure the ramp parameters:

- Ramp type
- Ramping times (duration of acceleration and deceleration)
- Level of jerk compensation for S-ramps

Start by setting the linear ramping times corresponding to [Figure 55](#) and [Figure 56](#).




Figure 55: Linear Ramping Times

If S-ramps are selected, set the level of non-linear jerk compensation required. Set jerk compensation by defining the proportion of ramp-up and ramp-down times where acceleration and deceleration are variable (that is, increasing or decreasing). The S-ramp acceleration and deceleration settings are defined as a percentage of the actual ramp time.




Figure 56: Non-linear Ramping Times

3-40 Ramp 1 Type

Default value:	[1] Linear	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: If [1] *S-ramp Const Jerk* is selected and the reference during ramping is changed, the ramp time may be prolonged to realize a jerk-free movement. A prolonged ramp time may result in a longer start or stop time. Extra adjustment of the S-ramp ratios or switching initiators may be necessary.

Select the ramp type, depending on requirements for acceleration/deceleration. A linear ramp gives constant acceleration during ramping. An S-ramp gives non-linear acceleration, compensating for jerk in the application.

Option	Name	Description
[0]*	Linear	
[1]	S-ramp Const Jerk	Acceleration with the lowest possible jerk.
[2]	S-ramp Const Time	S-ramp based on the values set in parameter 3-41 Ramp 1 Ramp Up Time and parameter 3-42 Ramp 1 Ramp Down Time .
[4]	Linear anti-sway	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer. Anti-sway ramp for smooth starting and stopping without swinging for cranes with hanging load. With the anti-sway ramp, the ramp time is the time it takes to accelerate/decelerate from actual speed to the set speed reference. In addition to the ramp time settings, other required settings for the anti-sway ramp are found in parameter group 24-7* Anti-Sway Ramp.

Option	Name	Description
[5]	Linear anti-oscillate	NOTE: This option is only available in FC 302 with IMC software version 48-98 or newer. Anti-oscillating ramping function for tall, upright structures driven at the base, for example, a stacker crane, which will oscillate during start and stop with short ramp times. The anti-oscillation ramp function cancels oscillation when positioning by using a special ramp function adapted to the mechanical oscillation frequency of the structure. The ramp time is based on parameter 24-72 Period of Swing as the time it takes for accelerate/decelerate from the actual speed to the set speed reference. The ramp time can be extended to multiple swing periods by defining parameter 24-73 Max Speed Change per Swin. When using anti-oscillation ramp types, there is a <i>notch filter</i> with a center frequency of 7/period of swing after the ramp generator. With parameter 24-74 Notch Filter Bandwidth set to 100%, the width of the filter corresponds to the center frequency.
[6]	S-ramp anti-oscillate	NOTE: This option is only available in FC 302 with IMC software version 48-98 or newer. Anti-oscillating ramping function for tall, upright structures driven at the base, for example, a stacker crane, which will oscillate during start and stop with short ramp times. The anti-oscillation ramp function cancels oscillation when positioning by using a special ramp function adapted to the mechanical oscillation frequency of the structure. The ramp time is based on parameter 24-72 Period of Swing as the time it takes for accelerate/decelerate from the actual speed to the set speed reference. The ramp time can be extended to multiple swing periods by defining parameter 24-73 Max Speed Change per Swin. When using anti-oscillation ramp types, there is a <i>notch filter</i> with a center frequency of 7/period of swing after the ramp generator. With parameter 24-74 Notch Filter Bandwidth set to 100%, the width of the filter corresponds to the center frequency.

3-41 Ramp 1 Ramp Up Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp-up time, that is the acceleration time from 0 RPM to the synchronous motor speed n_s . Select a ramp-up time which prevents the output current from exceeding the current limit in parameter **4-18 Current Limit during ramping**. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-down time in parameter **3-42 Ramp 1 Ramp Down Time**.

$$\text{Par.3-41} = \frac{t_{\text{acc}}[\text{s}] \times n_s[\text{RPM}]}{\text{ref}[\text{RPM}]}$$

3-42 Ramp 1 Ramp Down Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s

Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp-down time, that is the deceleration time from the synchronous motor speed n_s to 0 RPM. Select a ramp-down time such that no overvoltage occurs in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in parameter **4-18 Current Limit**. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in parameter **3-41 Ramp 1 Ramp Up Time**.
$$\text{Par.3-42} = \frac{t_{\text{dec}}[\text{s}] \times n_s[\text{RPM}]}{\text{ref}[\text{RPM}]}$$

3-45 Ramp 1 S-ramp Ratio at Accel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-41 Ramp 1 Ramp Up Time**) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks occurring in the application.

3-46 Ramp 1 S-ramp Ratio at Accel. End

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-41 Ramp 1 Ramp Up Time**) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-47 Ramp 1 S-ramp Ratio at Decel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-42 Ramp 1 Ramp Down Time**) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-48 Ramp 1 S-ramp Ratio at Decel. End

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-42 Ramp 1 Ramp Down Time**) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

6.5.6 3-5* Ramp 2

3-50 Ramp 2 Type

Default value:	[0] Linear	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: If [1] **S-ramp Const Jerk** is selected and the reference during ramping is changed, the ramp time may be prolonged to realize a jerk-free movement. A prolonged ramp time may result in a longer start or stop time. Additional adjustment of the S-ramp ratios or switching initiators may be necessary.

Select the ramp type, depending on requirements for acceleration/deceleration. A linear ramp gives constant acceleration during ramping. An S-ramp gives non-linear acceleration, compensating for jerk in the application.

Option	Name	Description
[0]*	Linear	
[1]	S-ramp Const Jerk	Acceleration with lowest possible jerk.
[2]	S-ramp Const Time	S-ramp based on the values set in parameter 3-51 Ramp 2 Ramp Up Time and parameter 3-52 Ramp 2 Ramp Down Time .
[4]	Linear anti-sway	 NOTE: This option is only available in FFC 302 with IMC software version 48.96 or newer. Anti-sway ramp for smooth starting and stopping without swinging for cranes with hanging load. With the anti-sway ramp, the ramp time is the time it takes to accelerate/decelerate from actual speed to the set speed reference. In addition to the ramp time settings, other required settings for the anti-sway ramp are found in parameter group 24-7* Anti-Sway Ramp.

Option	Name	Description
[5]	Linear anti-oscillate	 NOTE: This option is only available in FC 302 with IMC software version 48-98 or newer. Anti-oscillating ramping function for tall, upright structures driven at the base, for example, a stacker crane, which will oscillate during start and stop with short ramp times. The anti-oscillation ramp function cancels oscillation when positioning by using a special ramp function adapted to the mechanical oscillation frequency of the structure. The ramp time is based on parameter 24-72 Period of Swing as the time it takes for accelerate/decelerate from the actual speed to the set speed reference. The ramp time can be extended to multiple swing periods by defining parameter 24-73 Max Speed Change per Swin. When using anti-oscillation ramp types, there is a <i>notch filter</i> with a center frequency of 7/period of swing after the ramp generator. With parameter 24-74 Notch Filter Bandwidth set to 100%, the width of the filter corresponds to the center frequency.
[6]	S-ramp anti-oscillate	 NOTE: This option is only available in FC 302 with IMC software version 48-98 or newer. Anti-oscillating ramping function for tall, upright structures driven at the base, for example, a stacker crane, which will oscillate during start and stop with short ramp times. The anti-oscillation ramp function cancels oscillation when positioning by using a special ramp function adapted to the mechanical oscillation frequency of the structure. The ramp time is based on parameter 24-72 Period of Swing as the time it takes for accelerate/decelerate from the actual speed to the set speed reference. The ramp time can be extended to multiple swing periods by defining parameter 24-73 Max Speed Change per Swin. When using anti-oscillation ramp types, there is a <i>notch filter</i> with a center frequency of 7/period of swing after the ramp generator. With parameter 24-74 Notch Filter Bandwidth set to 100%, the width of the filter corresponds to the center frequency.

3-51 Ramp 2 Ramp Up Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp-up time, that is the acceleration time from 0 RPM to the nominal motor speed n_s . Select a ramp-up time such that the output current does not exceed the current limit in parameter **4-18 Current Limit** during ramping. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-down time in parameter **3-52 Ramp 2 Ramp Down Time**.

$$\text{Par.3-51} = \frac{t_{acc}[s] \times n_s[\text{RPM}]}{\text{ref}[\text{RPM}]}$$

3-52 Ramp 2 Ramp Down Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s

Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp-down time, that is the deceleration time from the nominal motor speed n_s to 0 RPM. Select a ramp-down time such that no overvoltage occurs in the drive due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in parameter **4-18 Current Limit**. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in parameter **3-51 Ramp 2 Ramp Up Time**.

$$\text{Par.3-52} = \frac{t_{\text{dec}}[\text{s}] \times n_s[\text{RPM}]}{\text{ref}[\text{RPM}]}$$

3-55 Ramp 2 S-ramp Ratio at Accel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-51 Ramp 2 Ramp Up Time**) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks occurring in the application.

3-56 Ramp 2 S-ramp Ratio at Accel. End

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-51 Ramp 2 Ramp Up Time**) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-57 Ramp 2 S-ramp Ratio at Decel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-52 Ramp 1 Ramp Down Time**) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-58 Ramp 2 S-ramp Ratio at Decel. End

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-52 Ramp 2 Ramp Down Time**) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

6.5.7 3-6* Ramp 3

3-60 Ramp 3 Type

Default value:	[0] Linear	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: If [1] *S-ramp Const Jerk* is selected and the reference during ramping is changed, the ramp time may be prolonged to realize a jerk-free movement. A prolonged ramp time may result in a longer start or stop time. Additional adjustment of the S-ramp ratios or switching initiators may be necessary.

Select the ramp type, depending on requirements for acceleration/deceleration. A linear ramp gives constant acceleration during ramping. An S-ramp gives non-linear acceleration, compensating for jerk in the application.

Option	Name	Description
[0]*	Linear	
[1]	S-ramp Const Jerk	Acceleration with lowest possible jerk.
[2]	S-ramp Const Time	S-ramp based on the values set in parameter 3-61 Ramp 3 Ramp Up Time and parameter 3-62 Ramp 3 Ramp Down Time .
[4]	Linear anti-sway	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer. Anti-sway ramp for smooth starting and stopping without swinging for cranes with hanging load. With the anti-sway ramp, the ramp time is the time it takes to accelerate/decelerate from actual speed to the set speed reference. In addition to the ramp time settings, other required settings for the anti-sway ramp are found in parameter group 24-7* Anti-Sway Ramp .

Option	Name	Description
[5]	Linear anti-oscillate	 NOTE: This option is only available in FC 302 with IMC software version 48-98 or newer. Anti-oscillating ramping function for tall, upright structures driven at the base, for example, a stacker crane, which will oscillate during start and stop with short ramp times. The anti-oscillation ramp function cancels oscillation when positioning by using a special ramp function adapted to the mechanical oscillation frequency of the structure. The ramp time is based on parameter 24-72 Period of Swing as the time it takes for accelerate/decelerate from the actual speed to the set speed reference. The ramp time can be extended to multiple swing periods by defining parameter 24-73 Max Speed Change per Swin. When using anti-oscillation ramp types, there is a <i>notch filter</i> with a center frequency of 7/period of swing after the ramp generator. With parameter 24-74 Notch Filter Bandwidth set to 100%, the width of the filter corresponds to the center frequency.
[6]	S-ramp anti-oscillate	 NOTE: This option is only available in FC 302 with IMC software version 48-98 or newer. Anti-oscillating ramping function for tall, upright structures driven at the base, for example, a stacker crane, which will oscillate during start and stop with short ramp times. The anti-oscillation ramp function cancels oscillation when positioning by using a special ramp function adapted to the mechanical oscillation frequency of the structure. The ramp time is based on parameter 24-72 Period of Swing as the time it takes for accelerate/decelerate from the actual speed to the set speed reference. The ramp time can be extended to multiple swing periods by defining parameter 24-73 Max Speed Change per Swin. When using anti-oscillation ramp types, there is a <i>notch filter</i> with a center frequency of 7/period of swing after the ramp generator. With parameter 24-74 Notch Filter Bandwidth set to 100%, the width of the filter corresponds to the center frequency.

3-61 Ramp 3 Ramp Up Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp-up time, that is the acceleration time from 0 RPM to the nominal motor speed n_s . Select a ramp-up time such that the output current does not exceed the current limit in parameter **4-18 Current Limit** during ramping. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-down time in parameter **3-62 Ramp 3 Ramp Down Time**.

$$\text{Par.3-61} = \frac{t_{acc}[s] \times n_s[\text{RPM}]}{\text{ref}[\text{RPM}]}$$

3-62 Ramp 3 Ramp Down Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s

Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp-down time, that is the deceleration time from the nominal motor speed n_s to 0 RPM. Select a ramp-down time such that no overvoltage occurs in the drive due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in parameter **4-18 Current Limit**. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in parameter **3-61 Ramp 3 Ramp Up Time**.

$$\text{Par.3-62} = \frac{t_{\text{dec}}[\text{s}] \times n_s[\text{RPM}]}{\text{ref}[\text{RPM}]}$$

3-65 Ramp 3 S-ramp Ratio at Accel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-61 Ramp 3 Ramp Up Time**) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks occurring in the application.

3-66 Ramp 3 S-ramp Ratio at Accel. End

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-61 Ramp 3 Ramp Up Time**) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-67 Ramp 3 S-ramp Ratio at Decel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-52 Ramp 1 Ramp Down Time**) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-68 Ramp 3 S-ramp Ratio at Decel. End

Default value:	50%	Parameter type:	Range, 1 -99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-62 Ramp 3 Ramp Down Time**) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

6.5.8 3-7* Ramp 4

3-70 Ramp 4 Type

Default value:	[0] Linear	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: If [1] **S-ramp Const Jerk** is selected and the reference during ramping is changed, the ramp time may be prolonged to realize a jerk-free movement. A prolonged ramp time may result in a longer start or stop time. Additional adjustment of the S-ramp ratios or switching initiators may be necessary.

Select the ramp type, depending on requirements for acceleration/deceleration. A linear ramp gives constant acceleration during ramping. An S-ramp gives non-linear acceleration, compensating for jerk in the application.

Option	Name	Description
[0]*	Linear	
[1]	S-ramp Const Jerk	Acceleration with lowest possible jerk.
[2]	S-ramp Const Time	S-ramp based on the values set in parameter 3-71 Ramp 3 Ramp Up Time and parameter 3-72 Ramp 3 Ramp Down Time .
[4]	Linear anti-sway	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer. Anti-sway ramp for smooth starting and stopping without swinging for cranes with hanging load. With the anti-sway ramp, the ramp time is the time it takes to accelerate/decelerate from actual speed to the set speed reference. In addition to the ramp time settings, other required settings for the anti-sway ramp are found in parameter group 24-7* Anti-Sway Ramp.

Option	Name	Description
[5]	Linear anti-oscillate	 NOTE: This option is only available in FC 302 with IMC software version 48-98 or newer. Anti-oscillating ramping function for tall, upright structures driven at the base, for example, a stacker crane, which will oscillate during start and stop with short ramp times. The anti-oscillation ramp function cancels oscillation when positioning by using a special ramp function adapted to the mechanical oscillation frequency of the structure. The ramp time is based on parameter 24-72 Period of Swing as the time it takes for accelerate/decelerate from the actual speed to the set speed reference. The ramp time can be extended to multiple swing periods by defining parameter 24-73 Max Speed Change per Swin. When using anti-oscillation ramp types, there is a <i>notch filter</i> with a center frequency of 7/period of swing after the ramp generator. With parameter 24-74 Notch Filter Bandwidth set to 100%, the width of the filter corresponds to the center frequency.
[6]	S-ramp anti-oscillating	 NOTE: This option is only available in FC 302 with IMC software version 48-98 or newer. Anti-oscillating ramping function for tall, upright structures driven at the base, for example, a stacker crane, which will oscillate during start and stop with short ramp times. The anti-oscillation ramp function cancels oscillation when positioning by using a special ramp function adapted to the mechanical oscillation frequency of the structure. The ramp time is based on parameter 24-72 Period of Swing as the time it takes for accelerate/decelerate from the actual speed to the set speed reference. The ramp time can be extended to multiple swing periods by defining parameter 24-73 Max Speed Change per Swin. When using anti-oscillation ramp types, there is a <i>notch filter</i> with a center frequency of 7/period of swing after the ramp generator. With parameter 24-74 Notch Filter Bandwidth set to 100%, the width of the filter corresponds to the center frequency.

3-71 Ramp 4 Ramp Up Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp-up time, that is the acceleration time from 0 RPM to the nominal motor speed n_s . Select a ramp-up time such that the output current does not exceed the current limit in parameter **4-18 Current Limit** during ramping. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-down time in parameter **3-72 Ramp 4 Ramp Down Time**.

$$\text{Par.3-71} = \frac{t_{\text{acc}}[\text{s}] \times n_s[\text{RPM}]}{\text{ref}[\text{RPM}]}$$

3-72 Ramp 4 Ramp Down Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s

Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp-down time, that is the deceleration time from the nominal motor speed n_s to 0 RPM. Select a ramp-down time such that no overvoltage occurs in the drive due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in parameter **4-18 Current Limit**. The value 0.00 corresponds to 0.01 s in speed mode. See ramp-up time in parameter **3-71 Ramp 4 Ramp Up Time**.

$$\text{Par.3-72} = \frac{t_{\text{dec}}[\text{s}] \times n_s[\text{RPM}]}{\text{ref}[\text{RPM}]}$$

3-75 Ramp 4 S-ramp Ratio at Accel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-71 Ramp 4 Ramp Up Time**) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks occurring in the application.

3-76 Ramp 4 S-ramp Ratio at Accel. End

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-71 Ramp 4 Ramp Up Time**) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-77 Ramp 4 S-ramp Ratio at Decel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-72 Ramp 4 Ramp Down Time**) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-78 Ramp 4 S-ramp Ratio at Decel. End

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-72 Ramp 4 Ramp Down Time**) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

6.5.9 3-8* Other Ramps

3-80 Jog/Homing Ramp Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the jog ramp time, that is the acceleration/deceleration time between 0 RPM and the rated motor frequency n_s . Ensure that the resulting output current required for the given jog ramp time does not exceed the current limit in parameter **4-18 Current Limit**. The jog ramp time starts after activation of a jog signal via the LCP, a selected digital input, or the serial communication port. When jog state is disabled, then the normal ramping times are valid.




Figure 57: Jog Ramp Time

$$\text{Par.3-80} = \frac{t_{\text{jog}}[\text{s}] \times n_s[\text{RPM}]}{\Delta \text{jog speed}(\text{par.3-19})[\text{RPM}]}$$

3-81 Quick Stop Ramp Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	2 setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the quick-stop ramp-down time, that is the deceleration time from the synchronous motor speed to 0 RPM. Ensure that no resulting overvoltage occurs in the inverter due to regenerative operation of the motor required to achieve the given ramp-down time. Ensure also that the generated current required to achieve the given ramp-down time does not exceed the current limit (set in parameter **4-18 Current Limit**). Quick stop is activated with a signal on a selected digital input, or via the serial communication port.




Figure 58: Quick Stop Ramp Time

3-82 Quick Stop Ramp Type

Default value:	[1] Linear	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the ramp type, depending on requirements for acceleration/deceleration. A linear ramp gives constant acceleration during ramping. An S-ramp gives non-linear acceleration, compensating for jerk in the application.

Option	Name	Description
[0]*	Linear	
[1]	S-ramp Const Jerk	Acceleration with the lowest possible jerk.
[2]	S-ramp Const Time	S-ramp based on the values set in parameter 3-83 Quick Stop S-ramp Ratio at Decel. Start and parameter 3-84 Quick Stop S-ramp Ratio at Decel. End .

3-83 Quick Stop S-ramp Ratio at Decel. Start

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-up time (parameter **3-41 Ramp 1 Ramp Up Time**) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-84 Quick Stop S-ramp at Decel. End

Default value:	50%	Parameter type:	Range, 1 - 99%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the proportion of the total ramp-down time (parameter **3-42 Ramp 1 Ramp Down Time**) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-89 Ramp Lowpass Filter Time

Default value:	1 ms	Parameter type:	Range, 1 - 200 ms
Setup:	All setups	Conversion index:	-4
Data type:	Uint16	Change during operation:	True

Use this parameter to set how smoothly the speed changes.

6.5.10 3-9* Digital Pot.Meter

The digital potentiometer enables increase or decrease of the actual reference by adjusting the setup of the digital inputs using the functions increase, decrease, or clear. To activate the function, set at least 1 digital input to increase or decrease.




Figure 59: Increase Actual Reference




Figure 60: Increase/Decrease Actual Reference

3-90 Step Size

Default value:	0.10%	Parameter type:	Range, 0.01 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the increment size required for increase/decrease as a percentage of the synchronous motor speed, n_s . If increase/decrease is activated, the resulting reference is increased or decreased by the value set in this parameter.

3-91 Ramp Time

Default value:	1 s	Parameter type:	Range, 0 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the ramp time, that is the time for adjustment of the reference 0–100% of the specified digital potentiometer function (increase, decrease, or clear). If increase/decrease is activated for longer than the ramp delay period specified in parameter **3-95 Ramp Delay**, the actual reference is ramped up/down according to this ramp time. The ramp time is defined as the time used to adjust the reference by the step size specified in parameter **3-90 Step Size**.

3-92 Power Restore

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	Off	Resets the digital potentiometer reference to 0% after power-up.
[1]	On	Restores the most recent digital potentiometer reference at power-up.

3-93 Maximum Limit

Default value:	100%	Parameter type:	Range, -200 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Set the maximum allowed value for the resulting reference. This is recommended if the digital potentiometer is used for fine-tuning of the resulting reference.

3-94 Minimum Limit

Default value:	-100%	Parameter type:	Range, -200 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Set the minimum allowed value for the resulting reference. This is recommended if the digital potentiometer is used for fine-tuning of the resulting reference.

3-95 Ramp Delay

Default value:	Size related	Parameter type:	Range, 0 - 0
Setup:	All setups	Conversion index:	-3
Data type:	TimD	Change during operation:	True

Enter the delay required from activation of the digital potentiometer function until the drive starts to ramp the reference. With a delay of 0 ms, the reference starts to ramp when increase/decrease is activated. See also parameter **3-91 Ramp Time**.

6.6 Parameter Group 4-** Limits/Warnings

6.6.1 4-1* Motor Limits

Define torque, current, and speed limits for the motor, and the reaction of the drive when the limits are exceeded. A limit may generate a message in the display. A warning always generates a message in the display or in the fieldbus. A monitoring function may initiate a warning or a trip after which the drive stops and generates an alarm message.

4-10 Motor Speed Direction

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Select the motor speed directions required. Use this parameter to prevent unwanted reversing. When parameter **1-00 Configuration Mode** is set to **[3] Process**, parameter **4-10 Motor Speed Direction** is set to **[0] Clockwise** as default. The setting in parameter **4-10 Motor Speed Direction** does not limit options for setting parameter **4-13 Motor Speed High Limit [RPM]**.

Option	Name	Description
[0]	Clockwise	The reference is set to CW rotation. Reversing input (default terminal 19) must be open.
[1]	Counterclockwise	The reference is set to CCW rotation. Reversing input (default terminal 19) must be closed. If reversing is required with reverse input open, the motor direction can be changed by parameter 1-06 Clockwise Direction .
[2]	Both directions	Allows the motor to rotate in both directions.

4-11 Motor Speed Low Limit [RPM]

Default value:	Size related	Parameter type:	Range, 0 - setting in par. 4-13 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the minimum limit for motor speed. The motor speed low limit can be set to correspond to the manufacturer's recommended minimum motor speed. The motor speed low limit must not exceed the setting in parameter **4-13 Motor Speed High Limit [RPM]**.

4-12 Motor Speed Low Limit [Hz]

Default value:	Size related	Parameter type:	Range, 0 - setting in par. 4-14 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Enter the minimum limit for motor speed. The motor speed low limit can be set to correspond to the minimum output frequency of the motor shaft. The motor speed low limit must not exceed the setting in parameter **4-14 Motor Speed High Limit [Hz]**.

4-13 Motor Speed High Limit [RPM]

Default value:	Size related	Parameter type:	Range, 0 - 60000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the maximum limit for motor speed. The motor speed high limit can be set to correspond to the manufacturer's maximum nominal motor speed. The motor speed high limit must exceed the setting in parameter **4-11 Motor Speed Low Limit [RPM]**.

4-14 Motor Speed High Limit [Hz]

Default value:	Size related	Parameter type:	Range, 0 - 1000.0 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Enter the maximum limit for motor speed in Hz. Parameter **4-14 Motor Speed High Limit [Hz]** can be set to correspond to the manufacturer's recommended maximum motor speed. The motor speed high limit must exceed the value in parameter **4-12 Motor Speed Low Limit [Hz]**. The output frequency must not exceed 10% of the switching frequency (parameter **14-01 Switching Frequency**).

4-16 Torque Limit Motor Mode

Default value:	Size related	Parameter type:	Range, 0 - 1000.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True



NOTE: If changing parameter **4-16 Torque Limit Motor Mode** when parameter **1-00 Configuration Mode** is set to **[0] Speed open loop**, parameter **1-66 Min. Current at Low Speed** is automatically readjusted.



NOTE: When parameter **1-00 Configuration Mode** is set to **[0] Speed open loop**, parameter **1-66 Min. Current at Low Speed** is automatically readjusted.



NOTE: The torque limit reacts to the actual, non-filtered torque, including torque spikes. This is not the torque that is seen from the LCP or the fieldbus as the torque is filtered.

This function limits the torque on the shaft to protect the mechanical installation.

4-17 Torque Limit Generator Mode

Default value:	Size related	Parameter type:	Range, 0 - 1000.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

This function limits the torque on the shaft to protect the mechanical installation.

4-18 Current Limit

Default value:	Size related	Parameter type:	Range, 1.0 - 1000.0%

Setup:	All setups	Conversion index:	-1
Data type:	Uint32	Change during operation:	True



NOTE: If [20] *ATEX ETR* is selected in parameter *1-90 Motor Thermal Protection*, set parameter *4-18 Current Limit* current limit to 150%.

This is a true current limit function that continues in the oversynchronous range. However, due to field weakening the motor torque at current limit will drop accordingly when the voltage increase stops above the synchronized speed of the motor.

4-19 Max Output Frequency

Default value:	Size related	Parameter type:	Range, 1 - 590 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: Maximum output frequency cannot exceed 10% of the inverter switching frequency (parameter *14-01 Switching Frequency*).

Provides a final limit on the output frequency for improved safety in applications where overspeeding is to be avoided. This limit is final in all configurations (independent of the setting in parameter *1-00 Configuration Mode*).

6.6.2 4-2* Limit Factors



NOTE:

The following parameters are only available in FC 302:

- Parameter *4-25 Power Limit Motor Factor Source*
- Parameter *4-26 Power Limit Gener. Factor Source*

4-20 Torque Limit Factor Source

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select an analog input for scaling the settings in parameter *4-16 Torque Limit Motor Mode* and parameter *4-17 Torque Limit Generator Mode* 0–100% (or inverse). The signal levels corresponding to 0% and 100% are defined in the analog input scaling, for example parameter group *6-1* Analog Input 1*. This parameter is only active when parameter *1-00 Configuration Mode* is in [0] *Speed Open Loop* or [1] *Speed Closed Loop*.

Option	Name	Description
[0]*	No function	
[2]	Analog in 53	

Option	Name	Description
[4]	Analog in 53 inv	
[6]	Analog in 54	
[8]	Analog in 54 inv	
[10]	Analog in X30-11	
[12]	Analog in X30-11 inv	
[14]	Analog in X30-12	
[16]	Analog in X30-12 inv	

4-21 Speed Limit Factor Source

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Parameter type:	Uint8	Change during operation:	True

Select an analog input for scaling the settings in parameter **4-19 Max Output Frequency** 0–100% (or the other way around). The signal levels corresponding to 0% and 100% are defined in the analog input scaling, for example parameter group **6-1* Analog Input 1**. This parameter is only active when parameter **1-00 Configuration Mode** is in **[4] Torque Open Loop**.

Option	Name	Description
[0]*	No function	
[2]	Analog in 53	
[4]	Analog in 53 inv	
[6]	Analog in 54	
[8]	Analog in 54 inv	
[10]	Analog in X30-11	
[12]	Analog in X30-11 inv	
[14]	Analog in X30-12	
[16]	Analog in X30-12 inv	

4-23 Brake Check Limit Factor Source

Default value:	[0] DC-link voltage	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the input source for the function in parameter **2-15 Brake Check**. If several drives are carrying out a brake check simultaneously, the resistance in the grid leads to a voltage drop on the mains or DC link and a false brake check can occur. Use an external current sensor on every brake resistor. If an application requires a 100% valid brake check, connect the sensor to an analog input.

Option	Name	Description
[0]*	DC-link voltage	The drive performs the brake check by monitoring the DC-link voltage. The drive injects current in the brake resistor, which lowers the DC-link voltage.
[1]	Analog input 53	Select to use an external current sensor for brake monitoring.
[2]	Analog input 54	Select to use an external current sensor for brake monitoring

4-24 Brake Check Limit Factor

Default value:	98%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

Enter the limit factor that parameter **2-15 Brake Check** uses when performing the brake check. The drive uses the limit factor depending on the selection in parameter **4-23 Brake Check Limit Factor Source**: **[0] DC-link voltage** - the drive applies the factor to the EEPROM data in the DC link. **[1] Analog Input 53** or **[2] Analog Input 54** - the brake check fails if the input current on the analog input is lower than the maximum input current multiplied by the limit factor. For example, in the following configuration the brake check fails if the input current is lower than 16 mA:

- A current transducer with a range of 4–20 mA is connected to analog input 53.
- Parameter **4-24 Brake Check Limit Factor** is set to 80%.

4-25 Power Limit Motor Factor Source

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the input that scales the value in parameter **4-82 Power Limit Motor Mode** from 0% to 100%.

Option	Name	Description
[0]*	No function	
[2]	Analog in 53	
[4]	Analog in 53 inv	
[6]	Analog in 54	
[8]	Analog in 54 inv	
[10]	Analog in X30-11	
[12]	Analog in X30-11 inv	
[14]	Analog in X30-12	
[16]	Analog in X30-12 inv	

4-26 Power Limit Gener. Factor Source

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the input that scales the value in parameter **4-83 Power Limit Generator Mode** from 0% to 100%.

Option	Name	Description
[0]*	No function	
[2]	Analog in 53	
[4]	Analog in 53 inv	
[6]	Analog in 54	
[8]	Analog in 54 inv	
[10]	Analog in X30-11	
[12]	Analog in X30-11 inv	
[14]	Analog in X30-12	
[16]	Analog in X30-12 inv	

4-29 Speed Low Limit Factor Source

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the input that scales the limit set in parameter **4-11 Motor Speed Low Limit [RPM]** or parameter **4-12 Motor Speed Low Limit [Hz]** from 0% to 100%.

Option	Name	Description
[0]*	No function	
[2]	Analog in 53	
[4]	Analog in 53 inv	
[6]	Analog in 54	
[8]	Analog in 54 inv	
[10]	Analog in X30-11	
[12]	Analog in X30-11 inv	
[14]	Analog in X30-12	
[16]	Analog in X30-12 inv	

6.6.3 4-3* Motor Feedback Monitoring

This parameter group includes monitoring and handling of motor feedback devices, such as encoders and resolvers.

4-30 Motor Feedback Loss Function

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

This function is used to monitor consistency in the feedback signal, that is if the feedback signal is available. Select which action the drive should take if a feedback fault is detected. The selected action is to take place when the feedback signal differs from the output speed by the value set in parameter **4-31 Motor Feedback Speed Error** for longer than the value set in parameter **4-32 Motor Feedback Loss Timeout**.

Option	Name	Description
[0]	Disabled	
[1]	Warning	
[2]	Trip	
[3]	Jog	
[4]	Freeze output	
[5]	Max speed	
[6]	Switch to open loop	
[7]	Select setup 1	
[8]	Select setup 2	
[9]	Select setup 3	
[10]	Select setup 4	
[11]	Stop & trip	

4-31 Motor Feedback Speed Error

Default value:	300 RPM	Parameter type:	Range, 1 - 600 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Select the minimum allowed error in speed (output speed vs. feedback).




Figure 61: Motor Feedback Speed Error

4-32 Motor Feedback Loss Timeout

Default value:	Size related	Parameter type:	Range, 0 - 60 s

Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the timeout value allowing the speed error set in parameter **4-31 Motor Feedback Speed Error** to be exceeded before enabling the function selected in parameter **4-30 Motor Feedback Loss Function**.

4-34 Tracking Error Function

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This function is used to monitor that the application follows the expected speed profile. In closed loop, the speed reference to the PID is compared to the encoder feedback (filtered). In open loop, the speed reference to the PID is compensated for slip and compared to the frequency that is sent to the motor (parameter **16-13 Frequency**). The reaction is activated if the measured difference is more than the value specified in parameter **4-35 Tracking Error** for the time specified in parameter **4-36 Tracking Error Timeout**. A tracking error in closed loop does not imply that there is a problem with the feedback signal. A tracking error can be the result of torque limit at too heavy loads.

Option	Name	Description
[0]	Disable	
[1]	Warning	
[2]	Trip	
[3]	Trip after stop	

4-35 Tracking Error

Default value:	10 RPM	Parameter type:	Range, 1 - 600 RPM
Setups:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the maximum allowed speed error between the motor speed and the output of the ramp when not ramping. In open loop, the motor speed is estimated and in closed loop, it is the feedback from encoder/resolver.

4-36 Tracking Error Timeout

Default value:	1 s	Parameter type:	Range, 0 - 60 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the timeout period during which an error greater than the value set in parameter **4-35 Tracking Error** is allowed.

4-37 Tracking Error Ramping

Default value:	100 RPM	Parameter type:	Range, 1 - 600 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the maximum allowed speed error between the motor speed and the output of the ramp when ramping. In open loop, the motor speed is estimated and in closed loop, the encoder measures the speed.

4-38 Tracking Error Ramping Timeout

Default value:	1 s	Parameter type:	Range, 0 - 60 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the timeout period during which an error greater than the value set in parameter **4-37 Tracking Error Ramping** while ramping is allowed.

4-39 Tracking Error After Ramping Timeout

Default value:	5 s	Parameter type:	Range, 0 - 60 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the timeout period after ramping where parameter **4-37 Tracking Error Ramping** and parameter **4-38 Tracking Error Ramping Timeout** are still active.

6.6.4 4-4* Speed Monitor

4-43 Motor Speed Monitor Function

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available in the flux control principle.

Select how the drive reacts when the motor speed monitor-function detects overspeed or wrong rotation direction. When the motor speed monitor is active, the drive detects an error if the following conditions are true for a time period specified in parameter **4-45 Motor Speed Monitor Timeout**:

- The actual speed differs from the reference speed in parameter **16-48 Speed Ref. After Ramp [RPM]**.
- The difference between the speeds exceeds the value in parameter **4-44 Motor Speed Monitor Max**.

In speed closed loop, the actual speed is the feedback from the encoder measured during the time defined in parameter **7-06 Speed PID Lowpass Filter Time**. In open loop, the actual speed is the estimated motor speed.




Figure 62: Speed Reference and Maximum Allowed Speed Difference

Solid line		Parameter 16-48 Speed Ref. After Ramp [RPM]	Dotted line	Parameter 4-44 Motor Speed Monitor Max
Option	Name	Description		
[0]	Disabled			
[1]	Warning	The drive reports <i>warning 101, Speed monitor</i> when the speed is outside the limit.		
[2]	Trip	The drive trips and reports <i>alarm 101, Speed monitor</i> .		
[3]	Jog			
[4]	Freeze output			
[5]	Max speed			
[6]	Switch to open loop			
[7]	Select setup 1			
[8]	Select setup 2			
[9]	Select setup 3			
[10]	Select setup 4			
[11]	Stop & trip			
[12]	Trip/warning	The drive reports <i>alarm 101, Speed monitor</i> in running mode and <i>warning 101, Speed monitor</i> in stop or coast mode. This option is only available in closed-loop operation.		
[13]	Trip/catch	Select when there is a need to catch a load, for example when mechanical braking fails. This option is available in closed loop only. The drive trips and reports <i>alarm 101, Speed monitor</i> in running mode. In stop mode, the drive catches the flying load and reports <i>warning 101, Speed monitor</i> . In catch mode, the drive applies holding torque to control the 0 speed on a potentially malfunctioning brake (closed loop). To exit this mode, send a new start signal to the drive. A coast or Safe Torque Off also terminates the function.		

4-44 Motor Speed Monitor Max

Default value:	300 RPM	Parameter type:	Range, 10 - 500 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True



NOTE: Only available in flux control principle.

Enter the maximum allowable speed deviation between the actual mechanical shaft speed and the value in parameter **16-48 Speed Ref. After Ramp [RPM]**.

4-45 Motor Speed Monitor Timeout

Default value:	0.1 s	Parameter type:	Range, 0 - 60 s

Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True



NOTE: Only available in flux control principle.

Enter the timeout period during which a deviation defined in parameter **4-44 Motor Speed Monitor Max** is allowable. The timer for this parameter is reset if the deviation stops exceeding the value in parameter **4-44 Motor Speed Monitor Max**.

4-46 Motor Protection Current Limit

Default value:	0 A	Parameter type:	Range, 0 - 10000.00 A
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	False

Set the peak motor current at which the drive disables the PWM to protect the motor.

4-47 Motor Protection Reaction Time

Default value:	10 us	Parameter type:	Range, 0.1 - 100 us
Setup:	All setups	Conversion index:	-7
Data type:	Uint16	Change during operation:	False

The maximum time the peak motor current can exceed the motor protection current limit before the drive disables the PWM to protect the motor.

4-49 Motor Check Time Interval

Default value:	[0] As fast as possible	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the time interval at which the connections between the motor and the drive are checked, when the motor is stopped. The motor check is performed at a specified interval, unless the motor is started in between.

Option	Name	Description
[0]*	As fast as possible	The motor time constant (x10) is used as the time interval to check the motor.
[5]	Every 1 hour	
[10]	Every 2 hours	
[15]	Every 12 hours	
[20]	Every 24 hours	

6.6.5 4-5* Adjustable Warnings

Use these parameters for adjustable warning limits for current, speed, reference, and feedback. Warnings are shown on the LCP and can be programmed to be outputs or to be read out via fieldbus in the extended status word.




Figure 63: Adjustable Warnings

4-50 Warning Current Low

Default value:	0 A	Parameter type:	Range, 0 - setting in par. 4-51
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the I_{LOW} value. When the motor current drops below this limit, the display reads *Current Low*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only). Refer to [Figure 63](#).

4-51 Warning Current High

Default value:	Size related	Parameter type:	Range, setting in par. 4-50 - setting in par. 16-37
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the I_{HIGH} value. When the motor current exceeds this limit, the display reads *Current High*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only). Refer to [Figure 63](#).

4-52 Warning Speed Low

Default value:	0 RPM	Parameter type:	Range, 0 - setting in par. 4-53 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the n_{LOW} value. When the motor speed exceeds this limit, the display reads *Speed low*. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only). Refer to [Figure 63](#).

4-53 Warning Speed High

Default value:	Size related	Parameter type:	Range, setting in par. 4-53 - 60000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the n_{HIGH} value. When the motor speed exceeds this value, the display reads *Speed high*. The signal outputs can be programmed to produce a status signal on terminals 27 or 29 (FC 302 only) and on relay outputs 01 or 02 (FC 302 only). Refer to [Figure 63](#).

4-54 Warning Reference Low

Default value:	-999999.999	Parameter type:	Range, -999999.999 - setting in par. 4-55
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the lower reference limit. When the actual reference drops below this limit, the display indicates Ref_{LOW} . The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

4-55 Warning Reference High

Default value:	999999.999	Parameter type:	Range, setting in par. 4-54 - 999999.999
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the upper reference limit. When the actual reference exceeds this limit, the display reads Ref_{high} . The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

4-56 Warning Feedback Low

Default value:	Size related	Parameter type:	Range, -999999.999 - setting in par. 4-57
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the lower feedback limit. When the feedback drops below this limit, the display reads $Feedb_{LOW}$. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

4-57 Warning Feedback High

Default value:	Size related	Parameter type:	Range, par. 4-56 - 999999.99
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the upper feedback limit. When the feedback exceeds this limit, the display reads $Feedb_{High}$. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 (FC 302 only) and on relay output 01 or 02 (FC 302 only).

4-58 Missing Motor Phase Function

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The function detects missing motor phase while the motor is running. Shows alarms 30, 31, 32 if a motor phase is missing. Enable this function to protect the application and motor from malfunctioning if a motor phase is missing.

Option	Name	Description
[0]	Disabled	The drive does not issue a missing motor phase alarm.
[1]	Trip 100 ms	The drive performs a scan for 100 ms to detect missing motor phase. When a missing motor phase is detected, the drive trips. This selection is recommended when the motor is running at a speed of 10 Hz and above.
[2]	Trip 1000 ms	The drive performs a scan for 1000 ms to detect missing motor phase. When a missing motor phase is detected, the drive trips. This selection is recommended when the motor is running at a low speed of 1 Hz and above.
[3]	Trip 100 ms 3ph detec.	 NOTE: Only available in in flux closed loop. To activate for U/f and VVC+, set parameter 4-59 Motor Check at Start to [0] On. This option is relevant for applications where the motor load and motor currents are very low, such as lowering a lift. Selecting this option allows to prevent false motor phase detection due to low currents. The drive performs a scan for 100 ms to detect missing motor phases.
[5]	Motor check	 NOTE: This option is only available in FC 302.  NOTE: The motor automatically resumes operation when the motor is reconnected. This option allows disconnection of the motor with a service switch without issuing an alarm. The drive coasts and automatically resumes operation when the motor is reconnected.

The following table details the detection of missing motor phase function for different motor control principles:

Table 21: Missing Motor Phase for Different Motor Control Principles

Option	Missing motor phase function	U/f	VVC+	Flux open loop	Flux closed loop
[0]	Disabled	No function.			
[1]	Trip 100 ms	Detects missing 1 phase.	Detects missing 1 phase.	Detects 1–3 phases.	Detects 1–3 phases.
[2]	Trip 1000 ms	Detects missing 1 phase.	Detects missing 1 phase.	Detects missing 1 phase.	N/A

Table 21: Missing Motor Phase for Different Motor Control Principles - (continued)

Option	Missing motor phase function	U/f	VVC+	Flux open loop	Flux closed loop
[3]	Trip 100 ms 3 phase limit	N/A ⁽¹⁾			
[5]	Motor check (service switch)	Coasts if the motor is disconnected or auto started when the motor is reconnected.			

1) When parameter 4-59 Motor Check at Start is set to [1] On, 3-phase detection is enabled for U/f and VVC+ motor control.

4-59 Motor Check at Start

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: Adjusting this parameter while the motor is running will not have effect until the next motor start.

This function detects missing motor phase before each start. Shows *alarm 30*, *alarm 31*, *alarm 32* if motor phases are missing. In these cases, the drive trips and an alarm is issued. The function has been developed to avoid disengaging a mechanical brake if motor phases are missing, for example, in lift applications.

Option	Name	Description
[0]*	Off	CAUTION RISK OF MOTOR DAMAGE Using this option may lead to motor damage. Select [1] On to make the drive check that all 3 motor phases are present.
[1]	On	The drive does not issue a missing motor phase alarm. Before each start, the drive checks if all 3 motor phases are present. The check is performed without any shaft movement. The function also enables 3-phase detection in U/f and VVC+ mode. See description in parameter 4-58 Missing Motor Phase Function.

The following table details the motor check at start for different motor control principles:

Table 22: Motor Check at Start for Different Motor Control Principles

Option	Motor check at start	U/f	VVC+	Flux open loop	Flux closed loop
[0]	Off	No function.	N/A		
[1]	On				

6.6.6 4-6* Speed Bypass

Some systems require that certain output frequencies of speeds are avoided due to resonance problems in the system. A maximum of 4 frequency or speed ranges can be avoided.

4-60 Bypass Speed From [RPM]

Default value:	Size related	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Some systems call for avoiding certain output speeds due to resonance problems in the system. Enter the lower limits of the speeds to be avoided.

4-61 Bypass Speed From [Hz]

Default value:	Size related	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Some systems require that certain output frequencies or speeds are avoided due to resonance problems in the system. Enter the lower limits of the speeds to be avoided.

4-62 Bypass Speed To [RPM]

Default value:	Size related	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Some systems call for avoiding certain output speeds due to resonance problems in the system. Enter the upper limits of the speeds to be avoided.

4-63 Bypass Speed To [Hz]

Default value:	Size related	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Some systems require that certain output frequencies or speeds are avoided due to resonance problems in the system. Enter the upper limits of the speeds to be avoided.

6.6.7 4-7* Position Monitor

4-70 Position Error Function

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Select the function which is activated when the position error exceeds the maximum allowed value. Position error is the difference between the actual position and the commanded position. The position error is the input for the position PI controller.

Option	Name	Description
[0]*	Disabled	The drive does not monitor the position error.
[1]	Warning	The drive issues a warning when the maximum allowed position error is exceeded. The drive continues operation.
[2]	Trip	The drive trips when the maximum allowed position error is exceeded.
[4]	Stop & Trip	
[6]	Qstop & trip	

4-71 Maximum Position Error

Default value:	1000 AbsolutionPositionUnit	Parameter type:	Range, 0 - 2147483647 AbsolutionPositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Enter the maximum allowed position tracking error in position units defined in parameter group **17-7* Position Scaling**. If this value is exceeded during the time set in parameter **4-72 Position Error Timeout**, the position error function in parameter **4-70 Position Error Function** is activated.

4-72 Position Error Timeout

Default value:	0.100 s	Parameter type:	Range, 0.000 - 60.000 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

If the error defined in parameter **4-71 Maximum Position Error** is present longer than the time in this parameter, the drive activates the function selected in parameter **4-70 Position Error Function**.

4-73 Position Limit Function

Default value:	[3] Abs. pos. mode stop	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Select the function which is activated when the position is outside the limits defined in parameter **3-06 Minimum Position** and parameter **3-07 Maximum Position**.

Option	Name	Description
[0]	Disabled	The drive does not monitor the position limits.
[1]	Warning	The drive issues a warning when the position is outside the limits.
[2]	Warning & Trip	The drive issues a warning when the set target is outside the position limits. The drive starts the positioning and then trips when the position limit is reached.
[3]*	Abs. Pos. Mode Stop	The drive monitors position limits only in absolute positioning mode. The drive issues a warning and stops at the position limit when the target position is outside the position limits.
[4]	Abs. Pos. Md. Stop & Trip	The drive monitors position limits only in absolute positioning mode. The drive stops at the position limit and trips when the target position is outside the position limits.
[5]	Position Stop	When the set target is outside the position limits, the drive uses the position limit as target. This option works in all modes of operation including speed and torque control. The drive issues a warning when at limit position.
[6]	Position Stop & Trip	When the set target is outside the position limits, the drive uses the position limit as target. This option works in all modes of operation including speed and torque control. The drive trips when at limit position.
[7]	Speed Stop	When the set target is outside the position limits, the drive performs a ramp down and stops at the limit position. This option works in all modes of operation. The drive issues a warning stop.
[8]	Speed Stop & Trip	When the set target is outside the position limits, the drive performs a ramp down and stops at the limit position. This option works in all modes of operation. The drive trips at stop.

4-74 Start Fwd/Rev Function

Default value:	[0] Stop	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.2X or newer.

Select the action that the drive executes when there is an active signal on a digital input with options **[12] Enable Start Forward** or **[13] Enable Start Reverse** selected. The drive executes the function selected in this parameter when running into an end limit switch and then the motion is only allowed in the opposite direction. When an option with trip is selected, the drive can resume motion only after reset.

Option	Name	Description
[0]*	Stop	The drive stops the motor.
[1]	Stop & Warning	The drive stops the motor and shows <i>warning 215, Start Fwd/Rev.</i>
[2]	Stop & Trip	The drive stops the motor and trips with <i>alarm 215, Start Fwd/Rev.</i>
[3]	Qstop	The drive performs the quick stop.

Option	Name	Description
[4]	Qstop & Warning	The drive performs the quick stop and shows <i>warning 215, Start Fwd/Rev.</i>
[5]	Qstop & Trip	The drive performs the quick stop and trips with <i>alarm 215, Start Fwd/Rev.</i>
[6]	Coast	The drive coasts the motor.
[7]	Coast & Warning	The drive coasts the motor and trips with <i>warning 215, Start Fwd/Rev.</i>
[8]	Coast & Trip	The drive coasts the motor and trips with <i>alarm 215, Start Fwd/Rev.</i>
[9]	Zero Speed Ref	The drive ramps down and keeps the motor magnetized at 0 speed. In the positioning and the synchronization modes, the position controller stays active and retains the actual position.
[10]	Zero Sp. Ref. & War.	Same as option [9] Zero Speed Ref and shows <i>warning 215, Start Fwd/Rev.</i>

4-75 Touch Timeout

Default value:	6000.0 s	Parameter type:	Range, 0.1 - 6000.0 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.2X or newer.

Enter the timeout for the touch probe positioning. If the drive does not detect the touch probe sensor before the timeout when the touch probe positioning is active, the drive trips with *alarm 216, Touch Timeout*. The value 6000 equals Off.

6.6.8 4-8* Power Limit



NOTE: This parameter group is only available in FC 302.

4-80 Power Limit Func. Motor Mode

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select whether the power limit function is enabled. Define the power limit motor mode in parameter **4-82 Power Limit Motor Mode**.

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	
[2]	When activated	Activation via a digital input or a fieldbus.

Option	Name	Description
[3]	Calculate speed limit	Calculates the maximum possible speed. The value can be read in 18-64 Power Based Speed Limit or via PCD data.
[4]	Calculate and limit speed	Calculates and limits the maximum possible speed. The value can be read in parameter 4-13 Motor Speed High Limit [RPM] or via PCD data.

4-81 Power Limit Func. Generator Mode

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select whether the power limit function is enabled in generating mode. Define the power limit motor mode in parameter **4-83 Power Limit Generator Mode**.

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	
[2]	When activated	Activation via a digital input or a fieldbus.
[3]	Calculate speed limit	Calculates the maximum possible speed which can be read in parameter 18-64 Power Based Speed Limit or via PCD data.
[4]	Calculate and limit speed	Calculates and limits the maximum possible speed. The value can be read in parameter 4-13 Motor Speed High Limit [RPM] or via PCD data.

4-82 Power Limit Motor Mode

Default value:	100.0%	Parameter type:	Range, 0.0 - 200.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Enter the maximum output power when the power limit function is active. Related parameters: parameter **1-20 Motor Power [kW]**, parameter **1-21 Motor Power [HP]**.

4-83 Power Limit Generator Mode

Default value:	100.0%	Parameter type:	Range, 0.0 - 200.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Changing during operation:	True

Enter the maximum generating power when the power limit function is active. Related parameters: parameter **1-20 Motor Power [kW]**, parameter **1-21 Motor Power [HP]**.

6.6.9 4-9* Directional Limits

The directional limits functionality allows specifying different torque and speed limits for different combinations of torque application direction and rotation direction. In [Figure 64](#), quadrants 1–4 show different combinations of rotation direction and torque application, and the parameters that act in different quadrants.




Figure 64: Example of Directional Limits

A speed limit value cannot exceed the value of parameter **4-13 Motor Speed High Limit [RPM]** or parameter **4-14 Motor Speed High Limit [Hz]**. A torque limit value cannot exceed the value of parameter **4-16 Torque Limit Motor Mode** or parameter **4-17 Torque Limit Generator Mode**.

4-90 Directional Limit Mode

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select whether the directional limits are enabled. With directional limits enabled, it is possible to specify different speed and torque limits for clockwise and counterclockwise rotation directions.

Option	Name	Description
[0]*	Disabled	Directional limits are disabled.
[1]	Enabled	Directional limits are active for the speed values.
[2]	Torque	Directional limits are active for the torque values.
[3]	Speed and torque	Directional limits are active for both torque and speed values.

4-91 Positive Speed Limit [RPM]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-13 RPM
Setup:	All setups	Conversion index:	67
Data type:	UInt16	Change during operation:	True

Enter the limit for the motor speed when the rotation direction is clockwise.

4-92 Positive Speed Limit [Hz]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-14 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Enter the limit for the motor speed when the rotation direction is clockwise.

4-93 Negative Speed Limit [RPM]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-13 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the limit for the motor speed when the rotation direction is counterclockwise.

4-94 Negative Speed Limit [Hz]

Default value:	Size related	Parameter type:	Range, 0 - par. 4-14 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Enter the limit for the motor speed when the rotation direction is counterclockwise.

4-95 Positive Torque Limit

Default value:	Size related	Parameter type:	Range, 0 - 160.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Enter the limit for the motor torque when the rotation direction is clockwise.

4-96 Negative Torque Limit

Default value:	Size related	Parameter type:	Range, 0 - 160.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Enter the limit for the motor torque when the rotation direction is counterclockwise.

6.7 Parameter Group 5-** Digital In/Out

6.7.1 5-0* Digital I/O Mode



NOTE:

The following parameter is only available in FC 302:

- Parameter **5-02 Terminal 29 Mode**

This parameter group contains parameters for configuring the input and output using NPN and PNP.

5-00 Digital I/O Mode

Default value:	[0] PNP	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: Perform a power cycle to activate the parameter once it has been changed.

Digital inputs and programmed digital outputs are preprogrammable for operation either in PNP or NPN systems.

Option	Name	Description
[0]*	PNP	Action on positive directional pulses (‡). PNP systems are pulled down to GND.
[1]	NPN	Action on negative directional pulses (‡). NPN systems are pulled up to +24 V, internally in the drive.

5-01 Terminal 27 Mode

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Input	Defines terminal 27 as a digital input.
[1]	Output	Defines terminal 27 as a digital output.

5-02 Terminal 29 Mode

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Input	Defines terminal 29 as a digital input.
[1]	Output	Defines terminal 29 as a digital output.

6.7.2 5-1* Digital Inputs



NOTE: The following parameter is only available in FC 302:

- Parameter **5-13 Terminal 29 Digital Input**

The digital inputs are used for selecting various functions in the drive. Refer to [Table 24](#) for functions which can be assigned to digital inputs.

Functions in function group 1 have higher priority than functions in function group 2.

Table 23: Function Groups

Group	Functions
1	Reset, coast stop, reset and coast stop, quick stop, DC brake, stop, and the [Off] key.
2	Start, latched start, reversing, start reversing, jog, and freeze output.

Table 24: Digital Input Functions and Terminals

Digital input function	Select	Terminal
No operation	[0]	All, terminal 32, 33
Reset	[1]	All
Coast inverse	[2]	All, terminal 27
Coast and reset inverse	[3]	All
Quick stop inverse	[4]	All
DC brake inverse	[5]	All
Stop inverse	[6]	All
Start	[8]	All, terminal 18
Latched start	[9]	All
Reversing	[10]	All, terminal 19
Start reversing	[11]	All
Enable start forward	[12]	All
Enable start reverse	[13]	All
Jog	[14]	All, terminal 29
Preset reference on	[15]	All
Preset ref bit 0	[16]	All
Preset ref bit 1	[17]	All
Preset ref bit 2	[18]	All
Freeze reference	[19]	All
Freeze output	[20]	All
Speed up	[21]	All
Speed down	[22]	All
Set-up select bit 0	[23]	All
Set-up select bit 1	[24]	All
Precise stop inverse	[26]	Terminal 18, 19
Precise start, stop	[27]	Terminal 18, 19
Catch up	[28]	All
Slow down	[29]	All
Counter input	[30]	Terminal 29, 33

Table 24: Digital Input Functions and Terminals - (continued)

Digital input function	Select	Terminal
Pulse input edge triggered	[31]	Terminal 29, 33
Pulse input time based	[32]	Terminal 29, 33
Ramp bit 0	[34]	All
Ramp bit 1	[35]	All
Emergency mode	[37]	All
Latched precise start	[40]	Terminal 18, 19
Latched precise stop inverse	[41]	Terminal 18, 19
Restart drive	[44]	All
External interlock	[51]	–
DigiPot increase	[55]	All
DigitPot decrease	[56]	All
DigiPot clear	[57]	All
DigiPot hoist	[58]	All
Counter A (up)	[60]	Terminal 29, 33
Counter A (down)	[61]	Terminal 29, 33
Reset counter A	[62]	All
Counter B (up)	[63]	Terminal 29, 33
Counter B (down)	[64]	Terminal 29, 33
Reset counter B	[65]	All
Timed actions disabled	[68]	All
Mech. brake feedb.	[70]	All
Mech. brake feedb. inv.	[71]	All
PID error inv.	[72]	All
PID reset I-part	[73]	All
PID enable	[74]	All
MCO specific	[75]	All
Reset maint. word	[78]	
PTC card 1	[80]	All
PROFIdrive OFF2	[91]	All
PROFIdrive OFF3	[92]	All
Light-load detection	[94]	All
Evacuation	[95]	All
Mains loss	[96]	Terminal 32, 33
Mains loss inverse	[97]	Terminal 32, 33
Start edge triggered	[98]	All
Safety option reset	[100]	

Table 24: Digital Input Functions and Terminals - (continued)

Digital input function	Select	Terminal
Activate CAM cycles	[102]	
Act. CAM cycles inv.	[103]	
Active CAM table	[104]	
Set vir. mas. pos. to actual	[105]	
Set master home	[106]	
Target inverse	[107]	
Enable master offset	[108]	All
Start virtual master	[109]	All
Start homing	[110]	All
Activate touch	[111]	All
Relative position	[112]	All
Enable reference	[113]	All
Sync. to pos. mode	[114]	All
Home sensor	[115]	All
Home sensor inverse	[116]	All
Touch sensor	[117]	All
Touch sensor inverse	[118]	All
Speed mode	[119]	All
Position vir. master	[122]	
Master marker	[123]	
Master marker inv.	[124]	
Follower marker	[125]	
Follower marker inv.	[126]	
Dir. home sensor	[127]	All
Dir. home sen. inv.	[128]	All
Constant OFF actions	[129]	
Constant ON actions	[130]	
Emcy mode ref bit 0	[190]	All
Emcy mode ref bit 1	[191]	All
Emcy mode ref bit 2	[192]	All
Test emcy mode	[195]	All
Reset emcy mode	[196]	All
Power limit mot.	[231]	All
Power limit gen.	[232]	All
Power limit both	[233]	All
Light load + evacuation	[234]	All

VLT® AutomationDrive FC 301/FC 302 standard terminals are 18, 19, 27, 29, 32, and 33. VLT® General Purpose I/O MCB 101 terminals are X30/2, X30/3, and X30/4. In FC 302, terminal 29 also functions as an output.

Functions dedicated to only 1 digital input are stated in the associated parameter.

All digital inputs can be programmed to these functions:

Table 25: Digital Inputs, Function Descriptions - 1

Option		Function
[0]	No operation	No reaction to signals transmitted to the terminal.
[1]	Reset	Resets the drive after a trip/alarm. Not all alarms can be reset.
[2]	Coast inverse	(Default digital input 27): Coast stop, inverted input (NC). The drive leaves the motor in free mode. Logic 0⇒coast stop.
[3]	Coast and reset inverse	Reset and coast stop inverted input (NC). Leaves the motor in free mode and resets the drive. Logic 0⇒coast stop and reset.
[4]	Quick stop inverse	Inverted input (NC). Generates a stop in accordance with quick stop ramp time set in parameter 3-81 Quick Stop Ramp Time . When the motor stops, the shaft is in free mode. Logic 0⇒quick stop.
[5]	DC brake inverse	Inverted input for DC brake (NC). Stops motor by energizing it with a DC current for a certain time period. See parameter 2-01 DC Brake Current to parameter 2-03 DC Brake Cut In Speed [RPM] . The function is only active when the value in parameter 2-02 DC Braking Time is different from 0. Logic 0⇒DC brake.
[6]	Stop inverse	Stop inverted function. Generates a stop function when the selected terminal goes from logical level 1 to logical level 0. The stop is performed according to the selected ramp time: • Parameter 3-42 Ramp 1 Ramp Down Time, • Parameter 3-52 Ramp 2 Ramp Down Time, • Parameter 3-62 Ramp 3 Ramp down Time, and • Parameter 3-72 Ramp 4 Ramp Down Time.  NOTE: When the drive is at the torque limit and has received a stop command, it may not stop by itself. To ensure that the drive stops, configure a digital output to [27] Torque limit and stop. Connect this digital output to a digital input that is configured as coast.
[8]	Start	(Default digital input 18): Select start for a start/stop command. Logic 1 = start, logic 0⇒stop.
[9]	Latched start	If a pulse is applied for minimum 2 ms, the motor starts. The motor stops when stop inverse is activated, or a reset command (via DI, bus, or LCP) is given.
[10]	Reversing	(Default digital input 19): Change the direction of motor shaft rotation. Select logic 1 to reverse. The reversing signal only changes the direction of rotation. It does not activate the start function. Select both directions in parameter 4-10 Motor Speed Direction . The function is not active in process closed loop.
[11]	Start reversing	Used for start/stop and for reversing on the same wire. Signals on start are not allowed at the same time.

Table 25: Digital Inputs, Function Descriptions - 1 - (continued)

Option		Function
[12]	Enable start forward	Disengages the counterclockwise movement and allows clockwise direction.
[13]	Enable start reverse	Disengages the clockwise movement and allows counterclockwise direction.
[14]	Jog	(Default digital input 29): Activate jog speed. See parameter 3-11 Jog Speed [Hz] .
[15]	Preset reference on	Shifts between external reference and preset reference. It is assumed that [1] External/preset has been selected in parameter 3-04 Reference Function . Logic 0 = external reference active; logic 1 = 1 of the 8 preset references is active.
[16]	Preset ref bit 0	Preset reference bit 0, 1, and 2 enable a choice between 1 of the 8 preset references according to Table 26 .
[17]	Preset ref bit 1	Same as [16] Preset ref bit 0 .
[18]	Preset ref bit 2	Same as [16] Preset ref bit 0 .

Table 26: Preset Reference Bit

Preset ref. bit	2	1	0
Preset ref. 0	0	0	0
Preset ref. 1	0	0	1
Preset ref. 2	0	1	0
Preset ref. 3	0	1	1
Preset ref. 4	1	0	0
Preset ref. 5	1	0	1
Preset ref. 6	1	1	0
Preset ref. 7	1	1	1

Table 27: Digital Inputs, Function Descriptions - 2

Option		Function
[19]	Freeze ref	Freezes the actual reference, which is now the point of enable/condition to be used for [21] Speed up and [22] Speed down . If speed up/speed down is used, the speed change always follows ramp 2 (parameter 3-51 Ramp 2 Ramp Up Time and parameter 3-52 Ramp 2 Ramp Down Time) in the range 0–parameter 3-03 Maximum Reference .
[20]	Freeze output	Freezes the actual motor frequency (Hz), which is now the point of enable/condition to be used for [21] Speed up and [22] Speed down . If speed up/speed down is used, the speed change always follows ramp 2 (parameter 3-51 Ramp 2 Ramp Up Time and parameter 3-52 Ramp 2 Ramp Down Time) in the range 0–parameter 1-23 Motor Frequency . NOTE: When freeze output is active, the drive cannot be stopped via a low [8] Start signal. Stop the drive via a terminal programmed for [2] Coasting inverse or [3] Coast and reset inverse.
[21]	Speed up	Select [21] Speed up and [22] Speed down for digital control of the up/down speed (motor potentiometer). Activate this function by selecting either [19] Freeze ref or [20] Freeze output . When speed up/speed down is activated for less than 400 ms, the resulting reference is increased/decreased by 0.1%. If speed up/speed down is activated for more than 400 ms, the resulting reference follows the setting in ramping up/down parameters 3- x1/3-x2.

Table 28: Shut Down/Catch Up

	Shut down	Catch up
Unchanged speed	0	0
Reduced by %-value	1	0
Increased by %-value	0	1
Reduced by %-value	1	1

Table 29: Digital Inputs, Function Descriptions - 3

Option		Function
[22]	Speed down	Same as [21] Speed up .
[23]	Set-up select bit 0	Select [23] Set-up select bit 0 or select [24] Set-up select bit 1 to select 1 of the 4 set-ups. Set parameter 0-10 Active Set-up to [9] Multi Set-up .
[24]	Set-up select bit 1	(Default digital input 32): Same as [23] Set-up select bit 0 .
[26]	Precise stop inv.	Sends an inverted stop signal when the precise stop function is activated in parameter 1-83 Precise Stop Function . Precise stop inverse function is available for terminals 18 or 19.

Table 29: Digital Inputs, Function Descriptions - 3 - (continued)

Option	Function
[27]	Precise start, stop
[28]	Catch up
[29]	Slow down
[30]	Counter input
[31]	Pulse edge triggered
[32]	Pulse time-based


Use when [0] *Precise ramp stop* is selected in parameter 1-83 *Precise Stop Function*. Precise start, stop is available for terminals 18 and 19. Precise start ensures that the rotor turning angle from standing still to reference is the same for each start (for same ramp time, same setpoint). This function is the equivalent to the precise stop where the rotor turning angle from reference to standstill is the same for each stop. When using parameter 1-83 *Precise Stop Function* option [1] *Cnt stop with reset* or [2] *Cnt stop w/o reset*: The drive needs a precise stop signal before reaching the value of parameter 1-84 *Precise Stop Counter Value*. If this signal is not supplied, the drive does not stop when the value in parameter 1-84 *Precise Stop Counter Value* is reached. Trigger precise start, stop by a digital input. The function is available for terminals 18 and 19.

Increases reference value by percentage (relative) set in parameter 3-12 *Catch up/slow Down Value*.

Reduces reference value by percentage (relative) set in parameter 3-12 *Catch up/slow Down Value*.

Precise stop function in parameter 1-83 *Precise Stop Function* acts as counter stop or speed-compensated counter stop with or without reset. Set the counter value in parameter 1-84 *Precise Stop Counter Value*.

Counts the number of pulse flanks per sample time. This gives a higher resolution at high frequencies, but is not as precise at lower frequencies. Use this pulse principle for encoders with low resolution (for example 30 PPR).



Measures the duration between pulse flanks. This gives a higher resolution at lower frequencies, but is not as precise at higher frequencies. This principle has a cutoff frequency, which makes it unsuited for encoders with low resolutions (for example 30 PPR) at low speeds.




Table 29: Digital Inputs, Function Descriptions - 3 - (continued)

Option		Function
[34]	Ramp bit 0	Enables a selection between 1 of the 4 ramps available, according to Table 30 .
[35]	Ramp bit 1	Same as [34] Ramp bit 0 .

Table 30: Preset Ramp Bit

Preset ramp bit	1	0
Ramp 1	0	0
Ramp 2	0	1
Ramp 3	1	0
Ramp 4	1	1

Table 31: Digital Inputs, Function Descriptions - 4

Option		Function
[37]	Emergency mode	A signal applied puts the drive into emergency mode and the pre-set ref bits 0–2 define the operation mode of emergency mode where all other commands are disregarded. See parameter group 24-0* Emergency Mode and parameter group 24-2* Emergency Mode 2 .
[40]	Latched precise start	A latched precise start only requires a pulse of 3 ms on terminals 18 or 19. When using for parameter 1-83 Precise Stop Function[1] Cnt stop with reset or [2] Cnt stop w/o reset : When the reference is reached, the drive internally enables the precise stop signal. This means that the drive does the precise stop when the counter value of parameter 1-84 Precise Stop Counter Value is reached.
[41]	Latched precise stop inverse	Sends a latched stop signal when the precise stop function is activated in parameter 1-83 Precise Stop Function . The latched precise stop inverse function is available for terminals 18 or 19.
[44]	Restart drive	
[51]	External interlock	This function makes it possible to give an external fault to the drive. This fault is treated in the same way as an internally generated alarm.
[55]	DigiPot increase	Increase signal to the digital potentiometer function described in parameter group 3-9* Digital Pot. Meter .
[56]	DigiPot Decrease	Decrease signal to the digital potentiometer function described in parameter group 3-9* Digital Pot. Meter .
[57]	DigiPot Clear	Clears the digital potentiometer reference described in parameter group 3-9* Digital Pot. Meter .
[58]	DigiPot hoist	
[60]	Counter A (up)	(Terminal 29 or 33 only). Input for increment counting in the SLC counter.
[61]	Counter A (down)	(Terminal 29 or 33 only). Input for decrement counting in the SLC counter.

Table 31: Digital Inputs, Function Descriptions - 4 - (continued)

Option		Function
[62]	Reset Counter A	Input for reset of counter A.
[63]	Counter B (up)	(Terminal 29 or 33 only). Input for increment counting in the SLC counter.
[64]	Counter B (down)	(Terminal 29 or 33 only). Input for decrement counting in the SLC counter.
[65]	Reset Counter B	Input for reset of counter B.
[68]	Timed actions disabled	
[70]	Mech. Brake Feedback	Brake feedback for hoisting applications: Set parameter 1-01 Motor Control Principle to [3] Flux w/ motor feedback ; set parameter 1-72 Start Function to [6] Hoist mech brake Ref.
[71]	Mech. Brake Feedback inv.	Inverted brake feedback for hoisting applications.
[72]	PID error inverse	When enabled, this option inverts the resulting error from the process PID controller. Available only if parameter 1-00 Configuration Mode is set to [6] Surface Winder , [7] Extended PID Speed OL , or [8] Extended PID Speed CL .
[73]	PID reset I-part	When enabled, this option resets the I-part of the process PID controller. Equivalent to parameter 7-40 Process PID I-part Reset . Available only if parameter 1-00 Configuration Mode is set to [6] Surface Winder , [7] Extended PID Speed OL , or [8] Extended PID Speed CL .
[74]	PID enable	Enables the extended process PID controller. Equivalent to parameter 7-50 Process PID Extended PID . Available only if parameter 1-00 Configuration Mode is set to [7] Extended PID Speed OL or [8] Extended PID Speed CL .
[75]	MCO specific	
[78]	Reset main. word	Resets all data in parameter 16-96 Maintenance Word to 0.
[80]	PTC Card 1	All digital inputs can be set to [80] PTC Card 1 . However, only 1 digital input must be set to this option.
[91]	PROFIdrive OFF2	The functionality is the same as the corresponding control word bit of the PROFIBUS/PROFINET option.
[92]	PROFIdrive OFF3	The functionality is the same as the corresponding control word bit of the PROFIBUS/PROFINET option.
[94]	Light Load Detection	Light-load detection is a feature for lift application to ensure that the lift runs in the evacuation direction which requires the least energy (UPS capacity), during an emergency. See parameter 30-25 Light Load Delay [s], parameter 30-26 Delay Before Measurements, parameter 30-27 Light Load Speed [%], parameter 30-28 Evacuation Speed [%], and parameter 30-29 Ramp Time for light-load detection configurations.  NOTE: Flying start overrules light load detection.

Table 31: Digital Inputs, Function Descriptions - 4 - (continued)

Option		Function
[95]	Evacuation	Evacuation Mode is a feature for lift application to enable drives to operate at reduced DC voltage for evacuation of people if there is power failure. When the feature is activated, undervoltage limits and enable voltage limits are reduced so that the drive can be operated with 230 V single-phase UPS-supply.
[96]	Mains loss	Select to improve kinetic back-up. When the mains voltage goes back to a level that is close to (but still lower than) the detection level, the output speed increases and kinetic back-up remains active. To avoid this situation, send a status signal to the drive. When the signal on the digital input is low (0), the drive forcibly turns off the kinetic back-up.  NOTE: Only available for pulse inputs at terminals 32/33.
[97]	Mains loss inverse	When the signal on the digital input is high (1), the drive forcibly turns off the kinetic backup. For more details, see the description of [96] <i>Mains loss</i>.  NOTE: Only available for pulse inputs at terminals 32/33.
[98]	Start edge triggered	Edge-triggered start command. Keeps the start command alive. It can be used for a start push key.
[100]	Safety option reset	Resets the safety option. Available only when the safety option is mounted.
[102]	Activate CAM Cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer. Normally-open contact for activating the number of CAM cycles set in parameter 17-97 Number of CAM Cycles.
[103]	Act. CAM cycles inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer. Normally-closed contact for activating the number of CAM cycles set in parameter 17-97 Number of CAM Cycles.
[104]	Activate CAM table	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer. Signal for activation of new CAM table while running with bumpless transfer.
[105]	Set vir. mas. pos. to actual	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer. Signal for setting virtual master position = actual follower position. This is needed for setting the correct starting position for position-controlled virtual master ensuring that the virtual master position is aligned with the physical position of the follower.

Table 31: Digital Inputs, Function Descriptions - 4 - (continued)

Option		Function
[106]	Set master home	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer. Sets the actual master position to the value of parameter 17-88 Master Home Position.
[107]	Target inverse	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer. Changes the sign of the set target position. For example, if the set target is 1000, the activation of this option changes the value to -1000.
[108]	Enable master offset	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Activates the master offset selected in parameter 3-26 Master Offset when parameter 17-93 Master Offset Selection has a selection from [1] Absolute to [5] Relative Touch Sensor.
[109]	Enable. vir.master	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Enables signal for the virtual master function. Only applicable when option [10] Synchronization is selected in parameter 1-00 Configuration Mode.
[110]	Start homing	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Starts the homing function selected in parameter 17-80 Homing Function. Must remain high until homing is done, otherwise homing is aborted.
[111]	Activate touch	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Activates monitoring of the touch sensor input.
[112]	Relative position	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. This option selects between absolute and relative positioning. The option is valid for the next positioning command.

Table 31: Digital Inputs, Function Descriptions - 4 - (continued)

Option		Function
[113]	Enable reference	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Positioning mode: The drive activates the selected positioning type and target, and starts the motion towards the new target. The motion starts either immediately or when active positioning is completed, depending on the settings of parameter 17-90 Absolute Position Mode and parameter 17-91 Relative Position Mode. Synchronization mode: High signal locks the actual follower position to the actual master position. The follower starts and catches up with the master. Low signal stops the synchronization and the follower makes a controlled stop.
[114]	Sync. to pos. mode	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Select positioning in synchronization mode.
[115]	Home sensor	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Normally-open contact for defining the home position. The function is defined in parameter 17-80 Homing Function.
[116]	Home sensor inv.	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Normally-closed contact for defining the home position. The function is defined in parameter 17-80 Homing Function.
[117]	Touch sensor	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Normally-open contact. Serves as a reference for touch probe positioning.
[118]	Touch sensor inv	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Normally-closed contact. Serves as a reference for touch probe positioning.
[119]	Speed mode	NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Select the speed mode when [9] Positioning or [10] Synchronization is selected in parameter 1-00 Configuration Mode. Speed reference is set by reference resource 1 or fieldbus REF1 relative to parameter 3-03 Maximum Reference.

Table 31: Digital Inputs, Function Descriptions - 4 - (continued)

Option		Function
[122]	Position vir. master	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer. Activates position-controlled virtual master when [10] Synchronization is selected in parameter 1-00 Configuration Mode. When the option is selected, the following occurs: - Target position is set by Fieldbus Pos. Ref. or preset target is as defined in parameter 3-20 Preset Target. - Speed is set relative to parameter 3-27 Virtual Master Max Ref by the source selected in parameter 3-15 Reference Resource 1 or fieldbus REF1. - Acceleration and deceleration are set as defined in parameter group 3-6* Ramp 3.
[123]	Master marker	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer. Normally-open contact. Serves as input for master marker signal during marker synchronization based on the option selected in parameter 3-33 Sync. Mode & Start behavior.
[124]	Master marker inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer. Normally-closed contact. Activates master marker signal for marker synchronization based on the option selected in parameter 3-33 Sync. Mode & Start Behavior.
[125]	Follower marker	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer. Normally-open contact. Serves as input for follower marker signal during marker synchronization based on the option selected in parameter 3-33 Sync. Mode & Start Behavior.
[126]	Follow marker inv	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer. Normally-closed contact. Serves as input for follower marker signal during marker synchronization based on the option selected in parameter 3-33 Sync. Mode & Start Behavior.
[127]	Dir. home sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer. Normally open contact for defining the home position at the same edge of the sensor signal independent of running direction. Only for the 2 homing types [2] Home Sync and [9] Direction with Sensor.

Table 31: Digital Inputs, Function Descriptions - 4 - (continued)

Option		Function
[128]	Dir. home sen. inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer. Normally closed contact for defining the home position at the same edge of the sensor signal independent of running direction. Only for the 2 homing types [2] Home Sync and [9] Direction with Sensor.
[129]	Constant OFF actions	
[130]	Constant ON actions	
[190]	Emcy mode ref bit 0	Enables a choice between 1 of the 8 preset reference according to Table 26 .
[191]	Emcy mode ref bit 1	Enables a choice between 1 of the 8 preset reference according to Table 26 .
[192]	Emcy mode ref bit 2	Enables a choice between 1 of the 8 preset reference according to Table 26 .
[195]	Test emcy mode	Activation of emergency mode via parameter 24-09 Emergency Mode Alarm Handling , option [2] Trip all alarms/test with stop on all alarms and in normal operation mode. The test timer is set in parameter 24-42 Timeout for Emergency Mode Test , and countdown starts when the test signal is active.
[196]	Reset emcy mode	When operating in emergency mode with impulse signals (parameter 24-43 Emergency Mode Signal Operation , option [2] Impulse, set-reset) the reset signal stops the emergency mode operation.
[231]	Power limit mot.	 NOTE: This option is only available in FC 302. Serves as input to activate the power limit function in the motor mode. See parameter group 4-8* Power Limit.
[232]	Power limit gen.	 NOTE: This option is only available in FC 302. Serves as input to activate the power limit function in the generating mode. See parameter group 4-8* Power Limit.
[233]	Power limit both	 NOTE: This option is only available in FC 302. Serves as input to activate the power limit function in both the motor and the generating mode. See parameter group 4-8* Power Limit.
[234]	Light load + evacuation	 NOTE: This option is only available in FC 302. Use this option to activate both light-load detection and evacuation.

5-10 Terminal 18 Digital Input

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the function from the available digital input range and the additional options **[60] Counter A (up)**, **[61] Counter A (down)**, **[63] Counter B (up)**, and **[64] Counter B (down)**. Counters are used in smart logic control functions. All functions are described in [Table 25](#), [Table 27](#), [Table 29](#), and [Table 31](#).

Option	Name	Description
[0]	No operation	
[1]	Reset	
[2]	Coast inverse	
[3]	Coast and reset inv	
[4]	Quick stop inverse	
[5]	DC-brake inverse	
[6]	Stop inverse	
[8]	Start	
[9]	Latched	
[10]	Reversing	
[11]	Start reversing	
[12]	Enable start forward	
[13]	Enable start reverse	
[14]	Jog	
[15]	Preset reference on	
[16]	Preset ref bit 0	
[17]	Preset ref bit 1	
[18]	Preset ref bit 2	
[19]	Freeze reference	
[20]	Freeze output	
[21]	Speed up	
[22]	Speed down	
[23]	Set-up select bit 0	
[24]	Set-up select bit 1	
[26]	Precise stop inverse	
[27]	Precise start, stop	
[28]	Catch up	
[29]	Slow down	
[34]	Ramp bit 0	

Option	Name	Description
[35]	Ramp bit 1	
[37]	Emergency mode	
[40]	Latched precise start	
[41]	Latch prec stop inv	
[44]	Restart drive	
[51]	External interlock	
[55]	DigiPot increase	
[56]	DigiPot decrease	
[57]	DigiPot clear	
[58]	DigiPot hoist	
[62]	Reset counter A	
[65]	Reset counter B	
[68]	Timed actions disabled	
[70]	Mech. brake feedb.	
[71]	Mech. brake feedb. inv.	
[72]	PID error inverse	
[73]	PID reset 1 part	
[74]	PID enable	
[75]	MCO specific	
[78]	Reset maint. word	
[80]	PTC card 1	
[91]	PROFIdrive OFF2	
[92]	PROFIdrive OFF3	
[94]	Light load detection	
[95]	Evacuation mode	
[96]	Mains loss	
[97]	Mains loss inverse	
[98]	Start edge triggered	
[100]	Safe option reset	
[102]	Activate CAM cycles	
[103]	Act. CAM cycles inv.	
[104]	Active CAM table	
[105]	Set vir. mas. pos. to actual	
[106]	Set master home	
[107]	Target inverse	
[108]	Enable mast. offset	
[109]	Enable vir. master	

Option	Name	Description
[110]	Start homing	
[111]	Activate touch	
[112]	Relative position	
[113]	Enable reference	
[114]	Sync. to pos. mode	
[115]	Home sensor	
[116]	Home sensor inv.	
[117]	Touch sensor	
[118]	Touch sensor inv.	
[119]	Speed mode	
[122]	Position vir. master	
[123]	Master marker	
[124]	Master marker inv.	
[125]	Follower marker	
[126]	Follow. marker inv.	
[127]	Dir. home sensor	
[128]	Dir. home sen. inv.	
[129]	Constant OFF actions	
[130]	Constant ON actions	
[190]	Emcy mode ref bit 0	
[191]	Emcy mode ref bit 1	
[192]	Emcy mode ref bit 2	
[195]	Test emcy mode	
[196]	Reset emcy mode	
[231]	Power limit mot.	NOTE: This option is only available in FC 302.
[232]	Power limit gen.	NOTE: This option is only available in FC 302.
[233]	Power limit both	NOTE: This option is only available in FC 302.
[234]	Light load + evacuation	NOTE: This option is only available in FC 302.

5-11 Terminal 19 Digital Input

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-10 Terminal 18 Digital Input*.

5-12 Terminal 27 Digital Input

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	No operation	
[1]	Reset	
[2]	Coast inverse	
[3]	Coast and reset inv	
[4]	Quick stop inverse	
[5]	DC-brake inverse	
[6]	Stop inverse	
[8]	Start	
[9]	Latched start	
[10]	Reversing	
[11]	Start reversing	
[12]	Enable start forward	
[13]	Enable start reverse	
[14]	Jog	
[15]	Preset reference on	
[16]	Preset ref bit 0	
[17]	Preset ref bit 1	
[18]	Preset ref bit 2	
[19]	Freeze reference	
[20]	Freeze output	
[21]	Speed up	
[22]	Speed down	
[23]	Set-up select bit 0	
[24]	Set-up select bit 1	
[28]	Catch up	
[29]	Slow down	
[34]	Ramp bit 0	
[35]	Ramp bit 1	
[37]	Emergency mode	
[44]	Restart drive	
[51]	External interlock	

Option	Name	Description
[55]	DigiPot increase	
[56]	DigiPot decrease	
[57]	DigiPot clear	
[58]	DigiPot hoist	
[62]	Reset counter A	
[65]	Reset counter B	
[68]	Timed actions disabled	
[70]	Mech. brake feedb.	
[71]	Mech. brake feedb. inv.	
[72]	PID error inverse	
[73]	PID reset I part	
[74]	PID enable	
[75]	MCO specific	
[78]	Reset maint. word	
[80]	PTC card 1	
[91]	PROFIdrive OFF2	
[92]	PROFIdrive OFF3	
[94]	Light load detection	NOTE: This option is only available in FC 302.
[95]	Evacuation mode	NOTE: This option is only available in FC 302.
[96]	Mains loss	
[97]	Mains loss inverse	
[98]	Start edge triggered	
[100]	Safe option reset	
[102]	Activate CAM cycles	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[103]	Act. CAM cycles inv.	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[104]	Activate CAM table	NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[105]	Set vir. mas. pos. to actual	NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.

Option	Name	Description
[106]	Set master home	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[107]	Target inverse	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[108]	Enable master offset	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[109]	Start virtual master	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[110]	Start homing	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[111]	Activate touch	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[112]	Relative position	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[113]	Enable reference	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[114]	Sync. to pos. mode	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[115]	Home sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[116]	Home sensor inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[117]	Touch sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[118]	Touch sensor inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.

Option	Name	Description
[119]	Speed mode	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[122]	Position vir. master	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[123]	Master marker	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[124]	Master marker inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[125]	Follower marker	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[126]	Follower mar. inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[127]	Dir. home sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[128]	Dir. home sen. inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[129]	Constant OFF actions	
[130]	Constant ON actions	
[190]	Emcy mode ref bit 0	
[191]	Emcy mode ref bit 1	
[192]	Emcy mode ref bit 2	
[195]	Test emcy mode	
[196]	Reset emcy mode	
[231]	Power limit mot	 NOTE: This option is only available in FC 302.
[232]	Power limit gen.	 NOTE: This option is only available in FC 302.

Option	Name	Description
[233]	Power limit both	 NOTE: This option is only available in FC 302.
[234]	Light load + evacuation	 NOTE: This option is only available in FC 302.

5-13 Terminal 29 Digital Input

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	No operation	
[1]	Reset	
[2]	Coast inverse	
[3]	Coast and reset inv	
[4]	Quick stop inverse	
[5]	DC-brake inverse	
[6]	Stop inverse	
[8]	Start	
[9]	Latched start	
[10]	Reversing	
[11]	Start reversing	
[12]	Enable start forward	
[13]	Enable start reverse	
[14]	Jog	
[15]	Preset reference on	
[16]	Preset ref bit 0	
[17]	Preset ref bit 1	
[18]	Preset ref bit 2	
[19]	Freeze reference	
[20]	Freeze output	
[21]	Speed up	
[22]	Speed down	
[23]	Set-up select bit 0	
[24]	Set-up select bit 1	
[28]	Catch up	
[29]	Slow down	

Option	Name	Description
[30]	Counter input	
[31]	Pulse edge triggered	
[32]	Pulse time based	
[34]	Ramp bit 0	
[35]	Ramp bit 1	
[37]	Emergency mode	
[44]	Restart drive	
[51]	External interlock	
[55]	DigiPot increase	
[56]	DigiPot decrease	
[57]	DigiPot clear	
[58]	DigiPot hoist	
[60]	Counter A (up)	
[61]	Counter A (down)	
[62]	Reset counter A	
[63]	Counter B (up)	
[64]	Counter A (down)	
[65]	Reset counter B	
[68]	Timed actions disabled	
[70]	Mech. brake feedb.	
[71]	Mech. brake feedb. inv.	
[72]	PID error inverse	
[73]	PID reset I part	
[74]	PID enable	
[75]	MCO specific	
[78]	Reset maint. word	
[80]	PTC card 1	
[91]	PROFIdrive OFF2	
[92]	PROFIdrive OFF3	
[94]	Light load detection	 NOTE: This option is only available in FC 302.
[95]	Evacuation mode	 NOTE: This option is only available in FC 302.
[96]	Mains loss	
[97]	Mains loss inverse	
[98]	Start edge triggered	
[100]	Safe option reset	

Option	Name	Description
[102]	Activate CAM cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[103]	Act. CAM cycles inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[104]	Activate CAM table	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[105]	Set vir. mas. pos. to actual	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[106]	Set master home	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[107]	Target inverse	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[108]	Enable master offset	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[109]	Start virtual master	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[110]	Start homing	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[111]	Activate touch	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[112]	Relative position	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[113]	Enable reference	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[114]	Sync. to pos. mode	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.

Option	Name	Description
[115]	Home sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[116]	Home sensor inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[117]	Touch sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[118]	Touch sensor inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[119]	Speed mode	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[122]	Position vir. master	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[123]	Master marker	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[124]	Master marker inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[125]	Follower marker	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[126]	Follower mar. inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[127]	Dir. home sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[128]	Dir. home sen. inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[129]	Constant OFF actions	
[130]	Constant ON actions	
[190]	Emcy mode ref bit 0	
[191]	Emcy mode ref bit 1	

Option	Name	Description
[192]	Emcy mode ref bit 2	
[195]	Test emcy mode	
[196]	Reset emcy mode	
[231]	Power limit mot	 NOTE: This option is only available in FC 302.
[232]	Power limit gen.	 NOTE: This option is only available in FC 302.
[233]	Power limit both	 NOTE: This option is only available in FC 302.
[234]	Light load + evacuation	 NOTE: This option is only available in FC 302.

5-14 Terminal 32 Digital Input

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-12 Terminal 27 Digital Input*.

5-15 Terminal 33 Digital Input

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-10 Terminal 18 Digital Input*.

5-16 Terminal X30/2 Digital Input

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-12 Terminal 12 Digital Input*.

5-17 Terminal X30/3 Digital Input

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-12 Terminal 27 Digital Input*.

5-18 Terminal X30/4 Digital Input

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter **5-10 Terminal 18 Digital Input**.

Parameter 5-19 Terminal 37 Safe Stop

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: Options **[4] PTC 1 Alarm** to **[9] PTC 1 & Relay W/A** are only available when the VLT® PTC Thermistor Card MCB 112 is connected.



NOTE: Selecting Auto Reset/Warning enables automatic restart of the drive.

Use this parameter to configure the Safe Torque Off functionality. A warning message makes the drive coast the motor and enables the automatic restart. An alarm message makes the drive coast the motor and requires a manual restart (via a fieldbus, Digital I/O, or by pressing [RESET] on the LCP). When the VLT® PTC Thermistor Card MCB 112 is mounted, configure the PTC options to get the full benefit from the alarm handling.

Option	Name	Description
[1]	Safe stop alarm	Coasts the drive when Safe Torque Off is activated. Manual reset from LCP, digital input, or fieldbus.
[3]	Safe stop warning	Coasts the drive when Safe Torque Off is activated (terminal 37 off). When the Safe Torque Off circuit is re-established, the drive continues without manual reset.
[4]	PTC 1 alarm	Coasts the drive when Safe Torque Off is activated. Manual reset from LCP, digital input, or fieldbus.
[5]	PTC 1 warning	Coasts the drive when Safe Torque Off is activated (terminal 37 off). When the Safe Torque Off circuit is re-established, the drive continues without manual reset, unless a digital input set to [80] PTC Card 1 is still enabled.
[6]	PTC 1 & Relay A	This option is used when the VLT® PTC Thermistor Card MCB 112 gates with a stop key through a safety relay to terminal 37. Coasts the drive when Safe Torque Off is activated. Manual reset from LCP, digital input, or fieldbus.
[7]	PTC 1 & Relay W	This option is used when the VLT® PTC Thermistor Card MCB 112 gates with a stop key through a safety relay to terminal 37. Coasts the drive when Safe Torque Off is activated (terminal 37 off). When the Safe Torque Off circuit is re-established, the drive continues without manual reset, unless a digital input set to [80] PTC Card 1 is still enabled.

Option	Name	Description
[8]	PTC 1 & Relay A/W	This option enables using a combination of alarm and warning.
[9]	PTC 1 & Relay W/A	This option enables using a combination of warning and alarm.

Table 32: Overview of Functions, Alarms, and Warnings

Function	Number	PTC	Relay
No function	[0]	–	–
Safe Torque Off alarm	[1]*	–	Safe Torque Off [A68 ⁽¹⁾]
Safe Torque Off warning	[3]	–	Safe Torque Off [W68 ⁽¹⁾]
PTC 1 alarm	[4]	PTC 1 Safe Torque Off [A71]	–
PTC 1 warning	[5]	PTC 1 Safe Torque Off [W71]	–
PTC 1 and relay A	[6]	PTC 1 Safe Torque off [A71]	Safe Torque Off [A68]
PTC 1 and relay W	[7]	PTC 1 Safe Torque Off [W71]	Safe Torque Off [W68]
PTC 1 and relay A/W	[8]	PTC 1 Safe Torque Off [A71]	Safe Torque Off [W68]
PTC 1 and relay W/A	[9]	PTC 1 Safe Torque Off [W71]	Safe Torque Off [A68]

1) W means warning and A means alarm.

A dangerous failure related to STO issues *alarm 72, Dangerous Failure*.

5-20 Terminal X46/1 Digital Input

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

All functions are described in [Table 25](#), [Table 27](#), [Table 29](#), and [Table 31](#).

Option	Name	Description
[0]*	No operation	
[1]	Reset	
[2]	Coast inverse	
[3]	Coast and reset inv	
[4]	Quick stop inverse	
[5]	DC-brake inverse	
[6]	Stop inverse	
[8]	Start	
[9]	Latched	
[10]	Reversing	
[11]	Start reversing	
[12]	Enable start forward	
[13]	Enable start reverse	
[14]	Jog	

Option	Name	Description
[15]	Preset reference on	
[16]	Preset ref bit 0	
[17]	Preset ref bit 1	
[18]	Preset ref bit 2	
[19]	Freeze reference	
[20]	Freeze output	
[21]	Speed up	
[22]	Speed down	
[23]	Set-up select bit 0	
[24]	Set-up select bit 1	
[28]	Catch up	
[29]	Slow down	
[34]	Ramp bit 0	
[35]	Ramp bit 1	
[37]	Emergency mode	
[44]	Restart drive	
[51]	External interlock	
[55]	DigiPot increase	
[56]	DigiPot decrease	
[57]	DigiPot clear	
[58]	DigiPot hoist	
[62]	Reset counter A	
[65]	Reset counter B	
[68]	Timed actions disabled	
[70]	Mech. brake feedb.	
[71]	Mech. brake feedb. inv.	
[72]	PID error inverse	
[73]	PID reset 1 part	
[74]	PID enable	
[75]	MCO specific	
[78]	Reset maint. word	
[80]	PTC card 1	
[91]	PROFIdrive OFF2	
[92]	PROFIdrive OFF3	
[94]	Light load detection	



NOTE: This option is only available in FC 302.

Option	Name	Description
[95]	Evacuation mode	 NOTE: This option is only available in FC 302.
[96]	Mains loss	
[97]	Mains loss inverse	
[98]	Start edge triggered	
[100]	Safe option reset	
[102]	Activate CAM cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[103]	Act. CAM cycles inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[104]	Activate CAM table	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[105]	Set. vir. mas. pos. to actual	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[106]	Set master home	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[107]	Target inverse	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[108]	Enable master offset	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[109]	Start virtual master	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[110]	Start homing	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[111]	Activate touch	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[112]	Relative position	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.

Option	Name	Description
[113]	Enabled reference	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[114]	Sync. to pos. mode	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[115]	Home sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[116]	Home sensor inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[117]	Touch sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[118]	Touch sensor inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[119]	Speed mode	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[122]	Position vir. master	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[123]	Master marker	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[124]	Master marker inv	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[125]	Follower marker	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[126]	Follow. marker inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[127]	Dir. home sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.

Option	Name	Description
[128]	Dir. home sen. inv.	NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[129]	Constant OFF actions	
[130]	Constant ON actions	
[190]	Emcy mode ref bit 0	
[191]	Emcy mode ref bit 1	
[192]	Emcy mode ref bit 2	
[195]	Test emcy mode	
[196]	Reset emcy mode	
[231]	Power limit mot.	NOTE: This option is only available in FC 302.
[232]	Power limit gen.	NOTE: This option is only available in FC 302.
[233]	Power limit both	NOTE: This option is only available in FC 302.
[234]	Light load + evacuation	NOTE: This option is only available in FC 302.

5-21 Terminal X46/3 Digital Input

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-20 Terminal X46/1 Digital Input*.

5-22 Terminal X46/5 Digital Input

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-20 Terminal X46/1 Digital Input*.

5-23 Terminal X46/7 Digital Input

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-20 Terminal X46/1 Digital Input*.

5-24 Terminal X46/9

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-20 Terminal X46/1 Digital Input*.

5-25 Terminal X46/11 Digital Input

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-20 Terminal X46/1 Digital Input*.

5-26 Terminal X46/13 Digital Input

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-20 Terminal X46/1 Digital Input*.

5-29 Sensor Input Bounce Filter

Default value:	1 ms	Parameter type:	Range, 1 - 5000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48-98 or newer.

Bounce filter for Home, Touch, and Marker sensor signals to avoid capturing false signals during bouncing. The sensor signal must be low for the filter time duration before a new instance is captured.

6.7.3 5-3* Digital Outputs



NOTE:

The following parameter is only available in FC 302:

- Parameter *5-31 Terminal 29 Digital Output*

The 2 solid-state digital outputs are common for terminals 27 and 29. Set the I/O function for terminal 27 in parameter *5-01 Terminal 27 Mode*, and set the I/O function for terminal 29 in parameter *5-02 Terminal 29 Mode*.



NOTE: These parameters cannot be adjusted while the motor is running.

Table 33: Digital Outputs, Function Descriptions - 1

Option		Function
[0]	No operation	Default for all digital outputs and relay outputs.
[1]	Control ready	The control card is ready.
[2]	Drive ready	The drive is ready for operation and applies a supply signal on the control card.
[3]	Drive rdy/rem ctrl	The drive is ready for operation and is in auto-on mode.
[4]	Enable/no warning	Ready for operation. No start or stop command has been given (start/disable). No warnings are active.
[5]	Running	The motor runs, and shaft torque is present.
[6]	Running/no warning	The output speed is higher than the speed set in parameter 1-81 Min Speed for Function at Stop [RPM] . The motor runs and there are no warnings.
[7]	Run in range/no warn	The motor runs within the programmed current and speed ranges set in parameter 4-50 Warning Current Low to parameter 4-53 Warning Speed High . There are no warnings.
[8]	Run on ref/no warn	The motor runs at reference speed. There are no warnings.
[9]	Alarm	An alarm activates the output. There are no warnings.
[10]	Alarm or warning	An alarm or warning activates the output.
[11]	At torque limit	The torque limit set in parameter 4-16 Torque Limit Motor Mode or parameter 4-17 Torque Limit Generator Mode has been exceeded.
[12]	Out of current range	The motor current is outside the range set in parameter 4-18 Current Limit .
[13]	Below current, low	The motor current is lower than set in parameter 4-50 Warning Current Low .
[14]	Above current, high	The motor current is higher than set in parameter 4-51 Warning Current High .
[15]	Out of speed range	The output frequency is outside the frequency range set in parameter 4-52 Warning Speed Low and parameter 4-53 Warning Speed High .
[16]	Below speed, low	Output speed is lower than the setting in parameter 4-52 Warning Speed Low .
[17]	Above speed, high	The output speed is higher than the setting in parameter 4-53 Warning Speed High .
[18]	Out of feedb. range	Feedback is below the limit set in parameter 4-56 Warning Feedback Low and parameter 4-57 Warning Feedback High .
[19]	Below feedback, low	Feedback is below the limit set in parameter 4-56 Warning Feedback Low .
[20]	Above feedback, high	Feedback is above the limit set in parameter 4-57 Warning Feedback High .
[21]	Thermal warning	The thermal warning turns on when the temperature exceeds the limit in the motor, the drive, the brake resistor, or the thermistor.
[22]	Ready, no thermal W	The drive is ready for operation, and there is no overtemperature warning.

Table 33: Digital Outputs, Function Descriptions - 1 - (continued)

Option		Function
[23]	Remote, ready, no TW	The drive is ready for operation and is in auto-on mode. There is no overtemperature warning.
[24]	Ready, voltage OK	The drive is ready for operation and the mains voltage is within the specified voltage range.
[25]	Reverse	The motor runs (or is ready to run) clockwise when logic = 0 and runs counterclockwise when logic = 1. The output changes when the reversing signal is applied.
[26]	Bus OK	Active communication (no timeout) via the serial communication port.
[27]	Torque limit & stop	Used for coast stop and in torque limit conditions. If the drive has received a stop signal and is at the torque limit, the signal is logic 0.
[28]	Brake, no brake war	Brake is active, and there are no warnings.
[29]	Brake ready, no fault	Brake is ready for operation and there are no faults.
[30]	Brake fault (IGBT)	Output is logic 1 when the brake IGBT is short-circuited. Use this function to protect the drive if there is a fault on the brake modules. To cut out the main voltage from the drive, use the output/relay.
[31]	Relay 123	Relay is activated when [0] Control Word is selected in parameter group 8-** Communications and Options .
[32]	Mech brake ctrl	Enables control of an external mechanical brake. For more information on mechanical brake control, refer to the drive-specific design guide.
[33]	Safe stop active	Indicates that the Safe Torque Off on terminal 37 is activated.
[35]	External interlock	The external interlock has been activated via 1 of the digital inputs.
[38]	Motor feedback error	
[39]	Tracking Error	
[40]	Out of ref range	Active when the actual speed is outside settings in parameter 4-52 Warning Speed Low and in parameter 4-55 Warning Reference High .
[41]	Below reference, low	Active when the actual speed is below speed reference setting.
[42]	Above ref, high	Active when the actual speed is above speed reference setting.
[43]	Extended PID limit	
[45]	Bus ctrl.	Controls output via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . If a bus timeout occurs, the output state is retained.
[46]	Bus ctrl, 1 if timeout	Controls output via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . If a bus timeout occurs, the output state is set high (on).

Table 33: Digital Outputs, Function Descriptions - 1 - (continued)

Option		Function
[47]	Bus ctrl, 0 if timeout	Controls output via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . If a bus timeout occurs, the output state is set low (off).
[50]	On reference	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Active when a VLT® Advanced Cascade Controller MCO 102 or VLT® Motion Control MCO 305 is connected. The output is controlled from the option.
[51]	MCO controlled	Active when a VLT® Advanced Cascade Controller MCO 102 or VLT® Motion Control MCO 305 is connected. The output is controlled from the option.
[54]	24V encoder sim	Digital outputs 27 and 29 simulate a single-signal HTL encoder. Select source for the signal generation in parameter 5-78 Term 27/29 Encoder Sim .
[55]	Pulse output	
[59]	Remote,enable,no TW	
[60]	Comparator 0	See parameter group 13-1* Comparators . If comparator 0 is evaluated as true, the output goes high. Otherwise, it is low.
[61]	Comparator 1	See parameter group 13-1* Comparators . If comparator 1 is evaluated as true, the output goes high. Otherwise, it is low.
[62]	Comparator 2	See parameter group 13-1* Comparators . If comparator 2 is evaluated as true, the output goes high. Otherwise, it is low.
[63]	Comparator 3	See parameter group 13-1* Comparators . If comparator 3 is evaluated as true, the output goes high. Otherwise, it is low.
[64]	Comparator 4	See parameter group 13-1* Comparators . If comparator 4 is evaluated as true, the output goes high. Otherwise, it is low.
[65]	Comparator 5	See parameter group 13-1* Comparators . If comparator 5 is evaluated as true, the output goes high. Otherwise, it is low.
[66]	Comparator 6	See parameter group 13-1* Comparators . If comparator 6 is evaluated as true, the output goes high. Otherwise, it is low.
[67]	Comparator 7	See parameter group 13-1* Comparators . If comparator 7 is evaluated as true, the output goes high. Otherwise, it is low.
[68]	Comparator 8	See parameter group 13-1* Comparators . If comparator 8 is evaluated as true, the output goes high. Otherwise, it is low.
[69]	Comparator 9	See parameter group 13-1* Comparators . If comparator 9 is evaluated as true, the output goes high. Otherwise, it is low.
[70]	Logic rule 0	See parameter group 13-4* Logic Rules . If logic rule 0 is evaluated as true, the output goes high. Otherwise, it is low.
[71]	Logic rule 1	See parameter group 13-4* Logic Rules . If logic rule 1 is evaluated as true, the output goes high. Otherwise, it is low.
[72]	Logic rule 2	See parameter group 13-4* Logic Rules . If logic rule 2 is evaluated as true, the output goes high. Otherwise, it is low.

Table 33: Digital Outputs, Function Descriptions - 1 - (continued)

Option		Function
[73]	Logic rule 3	See parameter group 13-4* Logic Rules . If logic rule 3 is evaluated as true, the output goes high. Otherwise, it is low.
[74]	Logic rule 4	See parameter group 13-4* Logic Rules . If logic rule 4 is evaluated as true, the output goes high. Otherwise, it is low.
[75]	Logic rule 5	See parameter group 13-4* Logic Rules . If logic rule 5 is evaluated as true, the output goes high. Otherwise, it is low.
[76]	Logic rule 6	See parameter group 13-4* Logic Rules . If logic rule 6 is evaluated as true, the output goes high. Otherwise, it is low.
[77]	Logic rule 7	See parameter group 13-4* Logic Rules . If logic rule 7 is evaluated as true, the output goes high. Otherwise, it is low.
[78]	Logic rule 8	See parameter group 13-4* Logic Rules . If logic rule 8 is evaluated as true, the output goes high. Otherwise, it is low.
[79]	Logic rule 9	See parameter group 13-4* Logic Rules . If logic rule 9 is evaluated as true, the output goes high. Otherwise, it is low.
[80]	SL digital output A	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [38] Set dig. out. A high is executed. The output goes low whenever the smart logic action [32] Set dig. out. A low is executed.
[81]	SL digital output B	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [39] Set dig. out. B high is executed. The output goes low whenever the smart logic action [33] Set dig. out. B low is executed.
[82]	SL digital output C	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [40] Set dig. out. C high is executed. The output goes low whenever the smart logic action [34] Set dig. out. C low is executed.
[83]	SL digital output D	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [41] Set dig. out. D high is executed. The output goes low whenever the smart logic action [35] Set dig. out. D low is executed.
[84]	SL digital output E	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [42] Set dig. out. E high is executed. The output goes low whenever the smart logic action [36] Set dig. out. E low is executed.
[85]	SL digital output F	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [43] Set dig. out. F high is executed. The output goes low whenever the smart logic action [37] Set dig. out. F low is executed.
[90]	kWh counter pulse	Sends a pulse (200 ms pulse width) to the output terminal whenever kWh counter changes (parameter 15-02 kWh Counter).
[96]	Reverse after ramp	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.

Table 33: Digital Outputs, Function Descriptions - 1 - (continued)

Option		Function
[98]	Virtual master dir.	NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. A virtual master signal that controls the rotation direction of followers.
[100]	Digi. CAM switch A	NOTE: This option is only available in FC 302 with IMC software version 48.95 or newer.
[101]	Digi. CAM sw. A inv	NOTE: This option is only available in FC 302 with IMC software version 48.95 or newer.
[102]	Digi. CAM switch B	NOTE: This option is only available in FC 302 with IMC software version 48.95 or newer.
[103]	Digi. CAM sw. B inv	NOTE: This option is only available in FC 302 with IMC software version 48.95 or newer.
[120]	Local ref active	Output is high when parameter 3-13 Reference Site = [2] Local .

Table 34: Local Reference Active

Reference site set in parameter 3-13 Reference Site	Local reference active [120]	Remote reference active [121]
Reference site: Local parameter 3-13 Reference Site	1	0
Reference site: Remote parameter 3-13 Reference Site	0	1
Reference site: Linked to Hand/ Auto	–	–
Hand	1	0
Hand⇒off	1	0
Auto⇒off	0	0
Auto	0	1

Table 35: 5-30 Digital Outputs - 2

Option		Function
[121]	Remote ref active	Output is high when parameter 3-13 Reference Site = [1] Remote or [0] Linked to hand/auto while the LCP is in auto-on mode. See Table 34 .
[122]	No alarm	Output is high when no alarm is present.
[123]	Start command active	Output is high when there is an active start command (that is via digital input bus connection, hand-on, or auto-on), and no stop or start command is active.

Table 35: 5-30 Digital Outputs - 2 - (continued)

Option		Function
[124]	Running reverse	Output is high when the drive runs counterclockwise (the logical product of the status bits running AND reverse).
[125]	Drive in hand mode	Output is high when the drive is in hand-on mode (as indicated by the LED light above [Hand On]).
[126]	Drive in auto mode	Output is high when the drive is in auto-on mode (as indicated by the LED light above [Auto On]).
[150]	CBM warning	
[151]	ATEX ETR cur. alarm	Selectable if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If Alarm 164 ATEX ETR cur.lim.alarm is active, the output is 1.
[152]	ATEX ETR freq. alarm	Selectable if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If Alarm 166, ATEX ETR freq.lim.alarm is active, the output is 1.
[153]	ATEX ETR cur. warning	Selectable if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If Alarm 163 ATEX ETR cur.lim.warning is active, the output is 1.
[154]	ATEX ETR freq. warning	Selectable if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If Warning 165, ATEX ETR freq.lim.warning is active, the output is 1.
[173]	10Wh counter pulse	
[178]	RS Flipflop 8	
[179]	RS Flipflop 9	
[180]	Clock fault	The clock fault has been reset to default (2000-01-01) because of a power failure.
[181]	Prev. maintenance	One or more preventive maintenance events programmed in parameter 23-10 Maintenance Item has passed the time for the specified action in parameter 23-11 Maintenance Action .
[188]	AHF capacitor connect	The capacitors are turned on at 20% (hysteresis of 50% gives an interval of 10–30%). The capacitors are disconnected below 10%. The off delay is 10 s and restarts if the nominal power goes above 10% during the delay. Parameter 5-80 AHF Cap Reconnect Delay is used to guarantee a minimum off time for the capacitors.
[189]	External fan control	The internal logics for the internal fan control is transferred to this output to make it possible to control an external fan (relevant for hp duct cooling).
[190]	Safe function active	
[191]	Safe opt. reset req.	
[192]	RS Flipflop 0	See parameter group 13-1* Comparators .
[193]	RS Flipflop 1	See parameter group 13-1* Comparators .
[194]	RS Flipflop 2	See parameter group 13-1* Comparators .
[195]	RS Flipflop 3	See parameter group 13-1* Comparators .
[196]	RS Flipflop 4	See parameter group 13-1* Comparators .

Table 35: 5-30 Digital Outputs - 2 - (continued)

Option		Function
[197]	RS Flipflop 5	See parameter group 13-1* Comparators .
[198]	RS Flipflop 6	See parameter group 13-1* Comparators .
[199]	RS Flipflop 7	See parameter group 13-1* Comparators .
[210]	Pos. set. acknowledge	
[221]	IGBT cooling	Use this option for handling the overcurrent trips. When the drive detects an overcurrent condition, it shows <i>alarm 13, Overcurrent</i> and triggers a reset. If the overcurrent condition occurs for the 3rd time in a row, the drive shows <i>alarm 13, Overcurrent</i> and initiates a 3-minute delay before the next reset.
[222]	Homing OK	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Homing is completed with the selected homing function in parameter 17-80 Homing Function.
[223]	On target	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Positioning is completed and the on-target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position limit	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position error	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. The target position is reached in touch probe position mode.
[227]	Touch activated	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Touch probe positioning is active. The drive monitors the touch probe sensor input.

Table 35: 5-30 Digital Outputs - 2 - (continued)

Option	Function
[228]	Touch sensor found  NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. The touch sensor has been detected.
[229]	Vir. master on ref.  NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. The virtual master is running on the set reference.
[231]	In power lim. mot.
[232]	In power lim. gen.
[233]	In power limit
[234]	PE power off
[246]	Emcy mode was act. The drive has been operating in emergency mode.
[247]	Emergency mode The drive is operating in emergency mode. See parameter group 24-0* Emergency Mode .
[249]	Emcy m. OPR unexpected Emergency mode input or safe stop is not operating as expected, for example, live zero monitoring on an analog input is activated.
[250]	Emcy mode limits During emergency mode operation, 1 of the critical alarms has been activated and suppressed by emergency mode. This may lead to reduced drive performance and expected operation life-time before service is required.
[254]	Testing emcy mode Emergency mode is activated in a special test mode where the drive stops on all alarms.

5-30 Terminal 27 Digital Output

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the function from the available digital output range and the additional options **[60] Counter A (up)**, **[61] Counter A (down)**, **[63] Counter B (up)**, and **[64] Counter B (down)**. Counters are used in smart logic control functions. All functions are described in [Table 33](#) and [Table 35](#).

Option	Name	Description
[0]	No operation	
[1]	Control ready	
[2]	Drive ready	
[3]	Coast and reset inv	
[4]	Enable/no warning	
[5]	Running	
[6]	Running/no warning	

Option	Name	Description
[7]	Run in range/no warn	
[8]	Run on ref/no warn	
[9]	Alarm	
[10]	Alarm or warning	
[11]	At torque limit	
[12]	Out of current range	
[13]	Below current, low	
[14]	Above current, high	
[15]	Out of speed range	
[16]	Below speed, low	
[17]	Above speed, high	
[18]	Out of feedb. range	
[19]	Below feedback, low	
[20]	Above feedback, high	
[21]	Thermal warning	
[22]	Ready,no thermal W	
[23]	Remote,ready, no TW	
[24]	Ready, Voltage OK	
[25]	Reverse	
[26]	Bus OK	
[27]	Torque limit & stop	
[28]	Brake, no brake war	
[29]	Brake ready, no fault	
[30]	Brake fault (IGBT)	
[31]	Relay 123	
[32]	Mech brake ctrl	
[33]	Safe stop active	
[35]	External interlock	
[38]	Motor feedback error	
[39]	Tracking error	
[40]	Out of ref range	
[41]	Below reference, low	
[42]	Above ref, high	
[43]	Extended PID Limit	
[45]	Bus ctrl.	
[46]	Bus ctrl, 1 if timeout	
[47]	Bus ctrl, 0 if timeout	

Option	Name	Description
[50]	On reference	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[51]	MCO controlled	
[54]	24V Encoder Sim	
[55]	Pulse output	
[59]	Actual position 4–20mA	
[60]	Comparator 0	
[61]	Comparator 1	
[62]	Comparator 2	
[63]	Comparator 3	
[64]	Comparator 4	
[65]	Comparator 5	
[66]	Comparator 6	
[67]	Comparator 7	
[68]	Comparator 8	
[69]	Comparator 9	
[70]	Logic rule 0	
[71]	Logic rule 1	
[72]	Logic rule 2	
[73]	Logic rule 3	
[74]	Logic rule 4	
[75]	Logic rule 5	
[76]	Logic rule 6	
[77]	Logic rule 7	
[78]	Logic rule 8	
[79]	Logic rule 9	
[80]	SL digital output A	
[81]	SL digital output B	
[82]	SL digital output C	
[83]	SL digital output D	
[84]	SL digital output E	
[85]	SL digital output F	
[90]	kWh counter pulse	
[96]	Reverse after ramp	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.

Option	Name	Description
[98]	Virtual master dir	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[100]	Digi. CAM switch A	 NOTE: This option is only available in FC 302 with IMC software version 48.95 and newer. Digital CAM switch A. See parameter group 24-5* Digi. CAM Switch A for more details.
[101]	Digi. CAM sw. A inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.95 and newer. Digital CAM switch A inverted. See parameter group 24-5* Digi. CAM Switch A for more details.
[102]	Digi CAM. switch B	 NOTE: This option is only available in FC 302 with IMC software version 48.95 and newer. Digital CAM switch B. See parameter group 24-6* Digi. CAM Switch B for more details.
[103]	Digi. CAM sw B inv.	 NOTE: This option is only available in FC 302 with IMC software version 48.95 or newer. Digital CAM switch B inverted. See parameter group 24-6* Digi. CAM Switch B for more details.
[120]	Local ref active	
[121]	Remote ref active	
[122]	No alarm	
[123]	Start command activ	
[124]	Running reverse	
[125]	Drive in hand mode	
[126]	Drive in auto mode	
[150]	CBM warning	 NOTE: This option is only available in FC 302.
[151]	ATEX ETR cur. alarm	
[152]	ATEX ETR freq. alarm	
[153]	ATEX ETR cur. warning	
[154]	ATEX ETR freq. warning	
[173]	10Wh counter pulse	
[178]	RS Flipflops 8	
[179]	RS flipflops 9	
[180]	Clock fault	
[181]	Prev. Maintenance	

Option	Name	Description
[188]	AHF Capacitor Connect	
[189]	External Fan Control	
[190]	Safe Function active	
[191]	Safe Opt. Reset req.	
[192]	RS Flipflop 0	
[193]	RS Flipflop 1	
[194]	RS Flipflop 2	
[195]	RS Flipflop 3	
[196]	RS Flipflop 4	
[197]	RS Flipflop 5	
[198]	RS Flipflop 6	
[199]	RS Flipflop 7	
[210]	Pos. set. acknowledge	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[221]	IGBT-cooling	
[222]	Homing OK	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[223]	On target	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[224]	Position limit	 NOTE: This option is only available in software version 48.0X or newer.
[225]	Position error	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[226]	Touch on target	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[227]	Touch activated	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[228]	Touch sensor found	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.

Option	Name	Description
[229]	Vir. master on ref.	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[231]	In Power Lim. Mot.	
[232]	In Power Lim. Gen.	
[233]	In Power Limit	
[234]	PE power off	
[246]	Emcy mode was act.	
[247]	Emergency mode	
[249]	Emcy m. OPR unexpected	
[250]	Emcy mode limits	
[254]	Testing emcy mode	

5-31 Terminal 29 Digital Output

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The options for this parameter are the same as those listed for parameter *5-30 Terminal 27 Digital Output*.

5-32 Term X30/6 Digi Out (MCB 101)

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter is active when option module VLT® General Purpose I/O MCB 101 is mounted in the drive. The options for this parameter are the same as those listed for parameter *5-30 Terminal 27 Digital Output*.

5-33 Term X30/7 Digi Out (MCB 101)

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	No operation	
[1]	Control ready	
[2]	Drive ready	
[3]	Coast and reset inv	
[4]	Enable/no warning	

Option	Name	Description
[5]	Running	
[6]	Running/no warning	
[7]	Run in range/no warn	
[8]	Run on ref/no warn	
[9]	Alarm	
[10]	Alarm or warning	
[11]	At torque limit	
[12]	Out of current range	
[13]	Below current, low	
[14]	Above current, high	
[15]	Out of speed range	
[16]	Below speed, low	
[17]	Above speed, high	
[18]	Out of feedb. range	
[19]	Below feedback, low	
[20]	Above feedback, high	
[21]	Thermal warning	
[22]	Ready,no thermal W	
[23]	Remote,ready, no TW	
[24]	Ready, Voltage OK	
[25]	Reverse	
[26]	Bus OK	
[27]	Torque limit & stop	
[28]	Brake, no brake war	
[29]	Brake ready, no fault	
[30]	Brake fault (IGBT)	
[31]	Relay 123	
[32]	Mech brake ctrl	
[33]	Safe stop active	
[35]	External interlock	
[38]	Motor feedback error	
[39]	Tracking error	
[40]	Out of ref range	
[41]	Below reference, low	
[42]	Above ref, high	
[43]	Extended PID Limit	
[45]	Bus ctrl.	

Option	Name	Description
[46]	Bus ctrl, 1 if timeout	
[47]	Bus ctrl, 0 if timeout	
[50]	On reference	 NOTE: This option is only available in FC 302 with IMC software 48.0X or newer.
[51]	MCO controlled	
[59]	Actual position 4–20mA	
[60]	Comparator 0	
[61]	Comparator 1	
[62]	Comparator 2	
[63]	Comparator 3	
[64]	Comparator 4	
[65]	Comparator 5	
[66]	Comparator 6	
[67]	Comparator 7	
[68]	Comparator 8	
[69]	Comparator 9	
[70]	Logic rule 0	
[71]	Logic rule 1	
[72]	Logic rule 2	
[73]	Logic rule 3	
[74]	Logic rule 4	
[75]	Logic rule 5	
[76]	Logic rule 6	
[77]	Logic rule 7	
[78]	Logic rule 8	
[79]	Logic rule 9	
[80]	SL digital output A	
[81]	SL digital output B	
[82]	SL digital output C	
[83]	SL digital output D	
[84]	SL digital output E	
[85]	SL digital output F	
[90]	kWh counter pulse	
[96]	Reverse after ramp	 NOTE: This option is only available in FC 302 with IMC software 48.1X or newer.

Option	Name	Description
[98]	Virtual master dir	 NOTE: This option is only available in FC 302 with IMC software 48.1X or newer.
[120]	Local ref active	
[121]	Remote ref active	
[122]	No alarm	
[123]	Start command activ	
[124]	Running reverse	
[125]	Drive in hand mode	
[126]	Drive in auto mode	
[150]	CBM warning	 NOTE: This option is only available in FC 302.
[151]	ATEX ETR cur. alarm	
[152]	ATEX ETR freq. alarm	
[153]	ATEX ETR cur. warning	
[154]	ATEX ETR freq. warning	
[173]	10Wh counter pulse	
[180]	Clock fault	
[181]	Prev. Maintenance	
[188]	AHF Capacitor Connect	
[189]	External Fan Control	
[190]	Safe Function active	
[191]	Safe Opt. Reset req.	
[192]	RS Flipflop 0	
[193]	RS Flipflop 1	
[194]	RS Flipflop 2	
[195]	RS Flipflop 3	
[196]	RS Flipflop 4	
[197]	RS Flipflop 5	
[198]	RS Flipflop 6	
[199]	RS Flipflop 7	
[221]	IGBT-cooling	
[222]	Homing OK	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.

Option	Name	Description
[223]	On target	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[224]	Position limit	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[225]	Position error	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[226]	Touch on target	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[227]	Touch activated	NOTE: This option is only available in FC 302 with software version 48.0X or newer.
[231]	In Power Lim. Mot.	
[232]	In Power Lim. Gen.	
[233]	In Power Limit	
[234]	PE power off	
[246]	Emcy mode was act.	
[247]	Emergency mode	
[249]	Emcy m. OPR unexpected	
[250]	Emcy mode limits	
[254]	Testing emcy mode	

6.7.4 5-4* Relays

This parameter groups contains parameters for configuring the timing and the output functions for the relays.

5-40 Function Relay

Default value:	–	Parameter type:	Option, Array [9]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select options to define the function of the relays. Relay 1 [0], relay 2 [1]. With VLT® Extended Relay Card MCB 113 installed: Relay 3 [2], Relay 4 [3], Relay 5 [4], Relay 6 [5]. With VLT® Relay Card MCB 105 installed: Relay 7 [6], relay 8 [7], Relay 9 [8].

Option	Name	Description
[0]	No operation	All digital and relay outputs are by default set to No Operation.
[1]	Control ready	The control card is ready.
[2]	Drive ready	The drive is ready to operate. Mains and control supplies are OK.

Option	Name	Description
[3]	Drive rdy/rem ctrl	The drive is ready for operation and is in auto-on mode.
[4]	Enable/no warning	Ready for operation. No start or stop commands have been applied (start/disable). No warnings are active.
[5]	Running	The motor is running, and shaft torque is present.
[6]	Running/no warning	Output speed is higher than the speed set in parameter 1-81 Min Speed for Function at Stop [RPM] . The motor runs and there are no warnings.
[7]	Run in range/no warn	The motor runs within the programmed current and the speed ranges set in parameter 4-50 Warning Current Low and parameter 4-53 Warning Speed High . No warnings.
[8]	Run on ref/no warn	The motor runs at reference speed. No warnings.
[9]	Alarm	An alarm activates the output. No warnings.
[10]	Alarm or warning	An alarm or a warning activates the output.
[11]	At torque limit	The torque limit set in parameter 4-16 Torque Limit Motor Mode or parameter 4-17 Torque Limit Generator Mode has been exceeded.
[12]	Out of current range	The motor current is outside the range set in parameter 4-18 Current Limit .
[13]	Below current, low	The motor current is lower than set in parameter 4-50 Warning Current Low .
[14]	Above current, high	The motor current is higher than set in parameter 4-51 Warning Current High .
[15]	Out of speed range	Output speed/frequency is outside the frequency range set in parameter 4-52 Warning Speed Low and parameter 4-53 Warning Speed High .
[16]	Below speed, low	Output speed is lower than the setting in parameter 4-52 Warning Speed Low .
[17]	Above speed, high	Output speed is higher than the setting in parameter 4-53 Warning Speed High .
[18]	Out of feedb. range	Feedback is outside the range set in parameter 4-56 Warning Feedback Low and parameter 4-57 Warning Feedback High .
[19]	Below feedback, low	Feedback is below the limit set in parameter 4-56 Warning Feedback Low .
[20]	Above feedback, high	Feedback is above the limit set in parameter 4-57 Warning Feedback High .
[21]	Thermal warning	Thermal warning turns on when the temperature exceeds the limit either in motor, drive, brake resistor, or connected thermistor.
[22]	Ready,no thermal W	The drive is ready for operation and there is no overtemperature warning.
[23]	Remote,ready, no TW	The drive is ready for operation and is in auto-on mode. There is no overtemperature warning.
[24]	Ready, Voltage OK	The drive is ready for operation and the mains voltage is within the specified voltage range.

Option	Name	Description
[25]	Reverse	The motor runs (or is ready to run) clockwise when logic = 0 and counterclockwise when logic = 1. The output changes as soon as the reversing signal is applied.
[26]	Bus OK	Active communication (no timeout) via the serial communication port.
[27]	Torque limit & stop	Use for performing a coasted stop in a torque limit condition. If the drive has received a stop signal and is in torque limit, the signal is logic 0.
[28]	Brake, no brake war	Brake is active and there are no warnings.
[29]	Brake ready, no fault	Brake is ready for operation and there are no faults.
[30]	Brake fault (IGBT)	Output is logic 1 when the brake IGBT is short-circuited. Use this function to protect the drive if there is a fault on the brake module. Use the digital output/relay to cut out the main voltage from the drive.
[31]	Relay 123	Digital output/relay is activated when [0] Control Word is selected in parameter group 8-** Comm. and Options .
[32]	Mech brake ctrl	Selection of mechanical brake control. When selected parameters in parameter group 2-2* Mechanical Brake are active. The output must be reinforced to carry the current for the coil in the brake. Usually solved by connecting an external relay to the selected digital output.
[33]	Safe stop active	Indicates that the Safe Torque Off on terminal 37 has been activated.  NOTE: This option is only available in FC 302.
[35]	External interlock	Activate relay 1 by control word from fieldbus. No other functional impact in the drive. Typical application: Controlling auxiliary device from fieldbus. The function is valid when [0] FC profile in parameter 8-10 Control Word Profile is selected.
[36]	Control word bit 11	
[37]	Control word bit 12	
		 NOTE: This option is only available in FC 302.
		Activate relay 2 by control word from fieldbus. No other functional impact in the drive. Typical application: Controlling auxiliary device from fieldbus. The function is valid when [0] FC profile in parameter 8-10 Control Word Profile is selected.
[38]	Motor feedback error	Failure in the speed feedback loop from motor running in closed loop. The output can eventually be used to prepare switching the drive in open loop in an emergency case.
[39]	Tracking error	When the difference between calculated speed and actual speed in parameter 4-35 Tracking Error is larger than selected, the digital output/relay is active.
[40]	Out of ref range	Active when the actual speed is outside the settings in parameter 4-52 Warning Speed Low to parameter 4-55 Warning Reference High .

Option	Name	Description
[41]	Below reference, low	Active when the actual speed is below speed reference setting.
[42]	Above ref, high	Active when actual speed is above speed reference setting.
[43]	Extended PID Limit	
[45]	Bus ctrl.	Controls digital output/relay via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . The output state is retained in the event of bus timeout.
[46]	Bus ctrl, 1 if timeout	Controls output via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . If a bus timeout occurs, the output state is set high (on).
[47]	Bus ctrl, 0 if timeout	Controls output via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . If a bus timeout occurs, the output state is set low (off).
[50]	On reference	 NOTE: This option is only available in FC 302 with IMC software version 48.0X.
[51]	MCO controlled	
[59]	Remote, enable, no TW	
[60]	Comparator 0	See parameter group 13-1* Comparators . If comparator 0 in SLC is true, the output goes high. Otherwise, it is low.
[61]	Comparator 1	See parameter group 13-1* Comparators . If comparator 1 in SLC is true, the output goes high. Otherwise, it is low.
[62]	Comparator 2	See parameter group 13-1* Comparators . If comparator 2 in SLC is true, the output goes high. Otherwise, it is low.
[63]	Comparator 3	See parameter group 13-1* Comparators . If comparator 3 in SLC is true, the output goes high. Otherwise, it is low.
[64]	Comparator 4	See parameter group 13-1* Comparators . If comparator 4 in SLC is true, the output goes high. Otherwise, it is low.
[65]	Comparator 5	See parameter group 13-1* Comparators . If comparator 5 in SLC is true, the output goes high. Otherwise, it is low.
[66]	Comparator 6	See parameter group 13-1* Comparators . If comparator 6 in SLC is true, the output goes high. Otherwise, it is low.
[67]	Comparator 7	See parameter group 13-1* Comparators . If comparator 7 in SLC is true, the output goes high. Otherwise, it is low.
[68]	Comparator 8	See parameter group 13-1* Comparators . If comparator 8 in SLC is true, the output goes high. Otherwise, it is low.
[69]	Comparator 9	See parameter group 13-1* Comparators . If comparator 9 in SLC is true, the output goes high. Otherwise, it is low.
[70]	Logic rule 0	See parameter group 13-4* Logic Rules . If logic rule 0 in SLC is true, the output goes high. Otherwise, it is low.
[71]	Logic rule 1	See parameter group 13-4* Logic Rules . If logic rule 1 in SLC is true, the output goes high. Otherwise, it is low.

Option	Name	Description
[72]	Logic rule 2	See parameter group 13-4* Logic Rules . If logic rule 2 in SLC is true, the output goes high. Otherwise, it is low.
[73]	Logic rule 3	See parameter group 13-4* Logic Rules . If logic rule 3 in SLC is true, the output goes high. Otherwise, it is low.
[74]	Logic rule 4	See parameter group 13-4* Logic Rules . If logic rule 4 in SLC is true, the output goes high. Otherwise, it is low.
[75]	Logic rule 5	See parameter group 13-4* Logic Rules . If logic rule 5 in SLC is true, the output goes high. Otherwise, it is low.
[76]	Logic rule 6	See parameter group 13-4* Logic Rules . If logic rule 6 in SLC is true, the output goes high. Otherwise, it is low.
[77]	Logic rule 7	See parameter group 13-4* Logic Rules . If logic rule 7 in SLC is true, the output goes high. Otherwise, it is low.
[78]	Logic rule 8	See parameter group 13-4* Logic Rules . If logic rule 8 in SLC is true, the output goes high. Otherwise, it is low.
[79]	Logic rule 9	See parameter group 13-4* Logic Rules . If logic rule 9 in SLC is true, the output goes high. Otherwise, it is low.
[80]	SL digital output A	See parameter 13-52 SL Controller Action . Output A is low on smart logic action [32] <i>Set digital out A low</i> . Output A is high on smart logic action [38] <i>Set digital out A high</i> .
[81]	SL digital output B	See parameter 13-52 SL Controller Action . Output B is low on smart logic action [33] <i>Set digital out B low</i> . Output B is high on smart logic action [39] <i>Set digital out B high</i> .
[82]	SL digital output C	See parameter 13-52 SL Controller Action . Output C is low on smart logic action [34] <i>Set digital out C low</i> . Output C is high on smart logic action [40] <i>Set digital out C high</i> .
[83]	SL digital output D	See parameter 13-52 SL Controller Action . Output D is low on smart logic action [35] <i>Set digital out D low</i> . Output D is high on smart logic action [41] <i>Set digital out D high</i> .
[84]	SL digital output E	See parameter 13-52 SL Controller Action . Output E is low on smart logic action [36] <i>Set digital out E low</i> . Output E is high on smart logic action [42] <i>Set digital out E high</i> .
[85]	SL digital output F	See parameter 13-52 SL Controller Action . Output F is low on smart logic action [37] <i>Set digital out F low</i> . Output F is high on smart logic action [43] <i>Set digital out F high</i> .
[96]	Reverse after ramp	 NOTE: This option is only available with software version 48.1X or newer. See the description in parameter group 5-3* Digital Outputs.

Option	Name	Description
[98]	Virtual master dir.	 NOTE: This option is only available with software version 48.1X or newer. See the description in parameter group 5-3* Digital Outputs .
[120]	Local ref active	Output is high when parameter 3-13 Reference Site = [2] Local or when parameter 3-13 Reference Site = [0] Linked to hand auto at the same time as the LCP is in hand-on mode.

Table 36: Local Reference Active

Reference site set in parameter 3-13 Reference Site	Local reference active [120]	Remote reference active [121]
Reference site: Local parameter 3-13 Reference Site [2] Local	1	0
Reference site: Remote parameter 3-13 Reference Site [1] Remote	0	1
Reference site: Linked to Hand/ Auto		
Hand	1	0
Hand⇒off	1	0
Auto⇒off	0	0
Auto	0	1

Option	Name	Description
[121]	Remote ref active	Output is high when parameter 3-13 Reference Site = [1] Remote or [0] Linked to hand/auto while the LCP .
[122]	No alarm	Output is high when no alarm is present.
[123]	Start command active	Output is high when the start command is high (that is via digital input, bus connection, <i>[Hand On]</i> , or <i>[Auto On]</i>), and a stop has been the last command.
[124]	Running reverse	Output is high when the drive is running counterclockwise (the logical product of the status bits running AND reverse).
[125]	Drive in hand mode	Output is high when the drive is in hand-on mode (as indicated by the LED light above <i>[Hand On]</i>).
[126]	Drive in auto mode	Output is high when the drive is in auto-on mode (as indicated by LED light on above <i>[Auto On]</i>).
[150]	CBM warning	 NOTE: This option is only available in FC 302.
[151]	ATEX ETR cur. alarm	Selectable if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 164, ATEX ETR cur.lim.alarm</i> is active, the output is 1.
[152]	ATEX ETR freq. alarm	Selectable if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166, ATEX ETR freq.lim.alarm</i> is active, the output is 1.

Option	Name	Description
[153]	ATEX ETR cur. warning	Selectable if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163, ATEX ETR cur.lim.warning</i> is active, the output is 1.
[154]	ATEX ETR freq. warning	Selectable if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165, ATEX ETR freq.lim.warning</i> is active, the output is 1.
[173]	10Wh counter pulse	
[178]	RS Flipflop 8	See parameter group 13-1* Comparators .
[179]	RS Flipflop 9	See parameter group 13-1* Comparators .
[180]	Clock fault	The clock function has been reset to default (2000-01-01) because of a power failure.
[181]	Prev. Maintenance	One or more of the preventive maintenance events programmed in parameter 23-10 Maintenance Item has passed the time for the specified action in parameter 23-22 Maintenance Action .
[188]	AHF Capacitor Connect	
[189]	External Fan Control	The internal logics for the internal fan control is transferred to this output to make it possible to control an external fan (relevant for hp duct cooling).
[190]	Safe Function active	
[191]	Safe Opt. Reset req.	
[192]	RS Flipflop 0	See parameter group 13-1* Comparators .
[193]	RS Flipflop 1	See parameter group 13-1* Comparators .
[194]	RS Flipflop 2	See parameter group 13-1* Comparators .
[195]	RS Flipflop 3	See parameter group 13-1* Comparators .
[196]	RS Flipflop 4	See parameter group 13-1* Comparators .
[197]	RS Flipflop 5	See parameter group 13-1* Comparators .
[198]	RS Flipflop 6	See parameter group 13-1* Comparators .
[199]	RS Flipflop 7	See parameter group 13-1* Comparators .
[210]	Pos. set. acknowledge	 NOTE: This option is available only with software version 48.8X or newer.
[221]	IGBT-cooling	Use this option for handling the overcurrent trips. When the drive detects an overcurrent condition, it shows <i>alarm 13, Overcurrent</i> and triggers a reset. If the overcurrent condition occurs 3 times in a row, the drive shows <i>alarm 13, Overcurrent</i> and initiates a 3 minute delay before the next reset.
[222]	Homing OK	 NOTE: This option is available only with software version 48.0X or newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).

Option	Name	Description
[223]	On target	 NOTE: This option is available only with software version 48.0X or newer. Positioning is completed and the on target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position limit	 NOTE: This option is available only with software version 48.0X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position error	 NOTE: This option is available only with software version 48.0X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	 NOTE: This option is available only with software version 48.0X or newer. Target position is reached in touch probe position mode.
[227]	Touch activated	 NOTE: This option is available only with software version 48.0X or newer. Touch probe positioning active. The drive monitors the touch probe sensor input.
[228]	Touch sensor found	 NOTE: This option is available only with software version 48.5X or newer. The touch sensor has been detected.
[229]	Vir. master on ref.	 NOTE: This option is available only with software version 48.7X or newer. The virtual master is running on the set reference.
[231]	In power lim. mot.	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[232]	In power lim. gen.	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[233]	In power limit	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.

Option	Name	Description
[234]	PE power off	
[246]	Emcy mode was act.	The drive has been operating in emergency mode.
[247]	Emergency mode	The drive is operating in emergency mode. See parameter group 24-0* Emergency Mode .
[249]	Emcy m. OPR unexpected	Emergency mode is not operating as expected, for example, live zero monitoring on an analog input is activated.
[250]	Emcy mode limits	During emergency mode operation, 1 of the critical alarms has been activated and suppressed by emergency mode. This may lead to reduced drive performance and expected lifetime before service is required.
[254]	Testing emcy mode	Emergency mode was activated in a special test mode where the drive stops on all alarms.

5-41 On Delay, Relay

Default value:	0.01 s	Parameter type:	Array [9]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the delay of the relay cut-in time. Select 1 of 2 internal mechanical relays in an array function. See parameter **5-40 Function Relay** for details.




Figure 67: On Delay, Relay

5-42 Off Delay, Relay

Default value:	0.01 s	Parameter type:	Array [9]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the delay of the relay cutout time. Select 1 of 2 internal mechanical relays in an array function. See parameter **5-40 Function Relay** for details. If the selected event condition changes before a delay timer expires, the relay output is unaffected.




Figure 68: Off Delay, Relay

6.7.5 5-5* Pulse Input



- NOTE:
- The following parameters are only available in FC 302:
- Parameter **5-50 Term. 29 Low Frequency**
 - Parameter **5-51 Term. 29 High Frequency**
 - Parameter **5-52 Term. 29 Low Ref./Feedb. Value**
 - Parameter **5-53 Term. 29 High Ref./Feedb. Value**
 - Parameter **5-54 Pulse Filter Time Constant #29**

The pulse input parameters are used to define an appropriate window for the impulse reference area by configuring the scaling and filter settings for the pulse inputs. Input terminals 29 or 33 act as frequency reference inputs. Set terminal 29 (parameter **5-13 Terminal 29 Digital Input**) or terminal 33 (parameter **5-15 Terminal 33 Digital Input**) to **[32] Pulse input**. If terminal 29 is used, set parameter **5-10 Terminal 27 Mode** to **[0] Input**.




Figure 69: Pulse Input

5-50 Term. 29 Low Frequency

Default value:	100 Hz	Parameter type:	Range, 0 - 110000 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Enter the low frequency limit corresponding to the low motor shaft speed (that is low reference value) in parameter **5-52 Term. 29 Low Ref./Feedb. Value**. Refer to [Figure 69](#).

5-51 Term. 29 High Frequency

Default value:	Size related	Parameter type:	Range, 0 - 110000 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Enter the high frequency limit corresponding to the high motor shaft speed (that is high reference value) in parameter **5-53 Term. 29 High Ref./Feedb. Value**.

5-52 Term. 29 Low Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the low reference value limit for the motor shaft speed [RPM]. This is also the lowest feedback value, see also parameter **5-57 Term. 33 Low Ref./Feedb. Value**. Set terminal 29 to digital input (parameter **5-02 Terminal 29 Mode = [0] Input** (default) and parameter **5-13 Terminal 29 Digital Input** = applicable value).

5-53 Term. 29 High Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the high reference value [RPM] for the motor shaft speed and the high feedback value, see also parameter **5-58 Term. 33 High Ref./Feedb. Value**. Select terminal 29 as a digital input (parameter **5-02 Terminal 29 Mode = [0] Input** (default) and parameter **5-13 Terminal 29 Digital Input** = applicable value).

5-54 Pulse Filter Time Constant #29

Default value:	100 ms	Parameter type:	Range, 1 - 1000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	False

Enter the pulse filter time constant. The pulse filter dampens oscillations of the feedback signal. If there is a lot of noise in the system, this is an advantage. A high time constant value results in better dampening but also increases the time delay through the filter.

5-55 Term. 33 Low Frequency

Default value:	100 Hz	Parameter type:	Range, 0 - 110000 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Enter the low frequency corresponding to the low motor shaft speed (that is low reference value) in parameter **5-57 Term. 33 Low Ref./Feedb. Value**.

5-56 Term. 33 High Frequency

Default value:	Size related	Parameter type:	Range, 0 - 110000 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Enter the high frequency corresponding to the high motor shaft speed (that is high reference value) in parameter **5-58 Term. 33 High Ref./Feedb. Value**.

5-57 Term. 33 Low Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the low reference value [RPM] for the motor shaft speed. This is also the low feedback value, see also parameter **5-52 Term. 29 Low Ref./Feedb. Value**.

5-58 Term. 33 High Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the high reference value [RPM] for the motor shaft speed. See also parameter **5-53 Term. 29 High Ref./Feedb. Value**.

5-59 Pulse Filter Time Constant #33

Default value:	100 ms	Parameter type:	Range, 1 - 1000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Enter the pulse filter time constant. The low-pass filter reduces the influence and dampens oscillations on the feedback signal from the control. This is an advantage if there is a lot of noise in the system.

6.7.6 5-6* Pulse Outputs



NOTE: These parameters cannot be adjusted while the motor is running.



NOTE: The following parameters are only available in FC 302.

This parameter group contains parameters for configuring pulse outputs with their functions and scaling. Terminals 27 and 29 area allocated to pulse output via parameter **5-01 Terminal 27 Mode** and parameter **5-02 Terminal 29 Mode**, respectively.




Figure 70: Configuration of Pulse Outputs

Table 37: Options for Readout Output Variables

Option	Name	Description
		Parameters for configuring the scaling and output functions of pulse outputs. The pulse outputs are designated to terminals 27 or 29. Select terminal 27 output in parameter 5-01 Terminal 27 Mode and terminal 29 output in parameter 5-02 Terminal 29 Mode .
[0]	No operation	
[45]	Bus control	Control digital output via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . The output state is retained if a bus timeout occurs.
[48]	Bus control timeout	
[51]	MCO-controlled	
[97]	Reference after ramp	NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Actual speed reference after the ramp. Use this output as master signal for speed synchronization of follower drives. The reference is set in parameter 16-48 Speed Ref. After Ramp [RPM].
[99]	Virtual master speed	NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Virtual master signal for controlling the speed or position the followers.
[100]	Output frequency	
[101]	Reference	
[102]	Feedback	
[103]	Motor current	

Table 37: Options for Readout Output Variables - (continued)

Option	Name	Description
[104]	Torque relative to limit	
[105]	Torque relative to rated	
[106]	Power	
[107]	Speed	
[108]	Torque	
[109]	Max. out freq	
[119]	Torque % lim	

5-60 Terminal 27 Pulse Output Variable

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	No operation	Select the display output for terminal 27.
[45]	Bus ctrl.	
[48]	Bus ctrl., timeout	
[51]	MCO controlled	
[97]	Reference after ramp	NOTE: This option is only available with software version 48.1X or newer. Actual speed reference after the ramp. Use this output as master signal for speed synchronization of follower drives. The reference is set in parameter 16-48 Speed Ref. After Ramp [RPM].
[99]	Virtual master speed	NOTE: This option is only available with software version 48.1X or newer. Virtual master signal for controlling the speed or position of the followers.
[100]	Output frequency	
[101]	Reference	
[102]	Feedback	
[103]	Motor current	
[104]	Torque rel to limit	
[105]	Torque related to rated	
[106]	Power	
[107]	Speed	
[108]	Torque	

Option	Name	Description
[109]	Max out freq	
[119]	Torque % lim	

5-62 Pulse Output Max Freq #27

Default value:	Size related	Parameter type:	Range, 0 - 32000 Hz (0 - 110000 Hz in IMC software)
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Set the maximum frequency for terminal 27 corresponding to the output variable selected in parameter **5-60 Terminal 27 Pulse Output Variable**.

5-63 Terminal 29 Pulse Output Variable

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	No operation	Select the display output for terminal 29.
[45]	Bus ctrl.	Control digital output via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . The output state is retained if a bus timeout occurs.
[48]	Bus ctrl., timeout	
[51]	MCO controlled	
[97]	Reference after ramp	 NOTE: This option is only available with software version 48.1X or newer. Actual speed reference after the ramp. Use this output as master signal for speed synchronization of follower drives. The reference is set in parameter 16-48 Speed Ref. After Ramp [RPM].
[99]	Virtual master speed	 NOTE: This option is only available with software version 48.1X or newer. Virtual master signal for controlling the speed or position of the followers.
[100]	Output frequency	
[101]	Reference	
[102]	Feedback	
[103]	Motor current	
[104]	Torque rel to limit	
[105]	Torque related to rated	

Option	Name	Description
[106]	Power	
[107]	Speed	
[108]	Torque	
[109]	Max out freq	
[119]	Torque % lim	

5-65 Pulse Output Max Freq #29

Default value:	Size related	Parameter type:	Range, 0 - 32000 Hz (0 - 110000 Hz in IMC software)
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Set the maximum frequency for terminal 29 corresponding to the output variable selected in parameter **5-63 Terminal 29 Pulse Output Variable**.

5-66 Terminal X30/6 Pulse Output Variable

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the variable for readout on terminal X30/6. This parameter is active when VLT® General Purpose I/O MCB 101 is installed in the drive. The options and functions are the same as in parameter group **5-6* Pulse Outputs**.

Option	Name	Description
[0]	No operation	Select the display output for terminal X30/6.
[45]	Bus ctrl.	Control digital output via bus. The state of the output is set in parameter 5-90 Digital & Relay Bus Control . The output state is retained if a bus timeout occurs.
[48]	Bus ctrl., timeout	
[51]	MCO controlled	
[97]	Reference after ramp	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Actual speed reference after the ramp. Use this output as master signal for speed synchronization of follower drives. The reference is set in parameter 16-48 Speed Ref. After Ramp [RPM].
[99]	Virtual master speed	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Virtual master signal for controlling the speed or position of the followers.
[100]	Output frequency	
[101]	Reference	

Option	Name	Description
[102]	Feedback	
[103]	Motor current	
[104]	Torque rel to limit	
[105]	Torque related to rated	
[106]	Power	
[107]	Speed	
[108]	Torque	
[109]	Max out freq	
[119]	Torque % lim	

5-68 Pulse Output Max Freq #30/6

Default value:	Size related	Parameter type:	Range, 0 - 32000 Hz (0 - 110000 Hz in IMC software)
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True



NOTE: This parameter cannot be changed while the motor is running.


Set the maximum frequency on terminal X30/6 referring to the output variable selected in parameter **5-66 Terminal X30/6 Pulse Output Variable**. This parameter is active when VLT® General Purpose I/O MCB 101 is installed in the drive.

6.7.7 5-7* 24 V Encoder Input

Connect the 24 V encoder to terminal 12 (24 V DC supply), terminal 32 (channel A), terminal 33 (channel B), and terminal 20 (GND). The digital inputs 32/33 are active for encoder inputs when **[1] 24 V encoder** is selected in parameter **1-02 Flux Motor Feedback Source** and parameter **7-00 Speed PID Feedback Source**. The encoder used is a dual-channel (A and B) 24 V type. Maximum input frequency: 110 kHz.


Encoder connection to the drive

24 V incremental encoder. Maximum cable length is 5 m (16.4 ft).



e30ba090.12

Figure 71: Encoder Connection



e30ba646.10

Figure 72: Encoder Rotation Direction

5-70 Term 32/33 Pulses Per Revolution

Default value:	1024	Parameter type:	Range, 1 - 4096 (with IMC, 1 - 16384)
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Set the resolution of the encoder connected to terminal 32/33 in pulses per revolution.

5-71 Term 32/33 Encoder Direction

Default value:	[0] Clockwise	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Change the detected encoder rotation direction without changing the wiring to the encoder.

Option	Name	Description
[0]*	Clockwise	Sets channel A 90° (electrical degrees) behind channel B upon clockwise rotation of the encoder shaft.
[1]	Counter clockwise	Sets channel A 90° (electrical degrees) ahead of channel B upon clockwise rotation of the encoder shaft.

5-72 Term 32/33 Encoder Type

Default value:	[0] Quadrature A/B format	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X or newer.

Select the signal type of the encoder connected to terminals 32, 33.

Option	Name	Description
[0]*	Quadrature A/B format	Encoder with 2 tracks: A and B, displaced 90° for detecting the rotational direction.
[1]	Single channel 33	Encoder with 1 track connected to terminal 33.
[2]	Single channel w/dir.	Encoder with 1 track connected to terminal 33. The direction is set with a signal on terminal 32: 0 V = forward/clockwise, 24 V = reverse/counterclockwise.

5-75 Term 27/29 Pulses Per Revolution

Default value:	1024	Parameter type:	Range, 1 - 16384

Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer.

Set the resolution of the encoder connected to terminal 27/29 in pulses per revolution.

5-76 Term 27/29 Encoder Direction

Default value:	[0] Clockwise	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer.

Change the detected encoder rotation direction without changing the wiring to the encoder.

Option	Name	Description
[0]*	Clockwise	Sets channel A 90° (electrical degrees) behind channel B upon clockwise rotation of the encoder shaft.
[1]	Counter clockwise	Sets channel A 90° (electrical degrees) ahead of channel B upon clockwise rotation of the encoder shaft.

5-77 Term 27/29 Encoder Type

Default value:	[0] Quadrature A/B format	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer.

Select the signal type of the encoder connected to terminals 27, 29.

Option	Name	Description
[0]*	Quadrature A/B format	Encoder with 2 tracks: A and B, displaced 90° for detecting the rotational direction.
[1]	Single channel 33	Encoder with 1 track connected to terminal 29.
[2]	Single channel w/dir.	Encoder with 1 track connected to terminal 29. The direction is set with a signal on terminal 32: 0 V = forward/clockwise, 24 V = reverse/counterclockwise.

5-78 Term 27/29 Encoder Sim

Default value:	[1] Actual position	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer.

Select the source for generation of the encoder simulation output. To enable 24 V encoder simulation on terminal 27/29, set parameter **5-30 Terminal 27 Digital Output** and parameter **5-31 Terminal 29 Digital Output** to **[54] 24V Encoder Sim**.

Option	Name	Description
[1]*	Actual position	The encoder simulation is a mirror of the actual position. The output is scaled by parameter 5-75 Term 27/29 Pulses Per Revolution related to 1 motor revolution. One motor revolution is represented by the number of pulses set in parameter 5-75 Term 27/29 Pulses Per Revolution . This means that 1 motor revolution is represented by the number of pulses set in parameter 5-75 Term 27/29 Pulses Per Revolution .
[2]	Commanded position	The encoder simulation is a mirror of the commanded position (position setpoint for the position PI controller). The output is scaled by parameter 5-75 Term 27/29 Pulses Per Revolution related to 1 motor revolution. This means that 1 motor revolution is represented by the number of pulses set in parameter 5-75 Term 27/29 Pulses Per Revolution .
[3]	Vir. master position	The encoder simulation is generated by the virtual master function. The output is scaled by parameter 5-75 Term 27/29 Pulses Per Revolution . Virtual master speed reference can be set by fieldbus REF 1 or the source selected in parameter 3-16 Reference Resource 2 relative to parameter 3-27 Virtual Master Max Ref . Example: With parameter 3-27 Virtual Master Max Ref = 50 Hz and a reference of 50% the output corresponds to a master speed of 50 Hz x 60/min x 50% = 1500 RPM. The pulse frequency will be parameter 5-75 Term 27/29 Pulses Per Revolution , for example, 1024 x 1500 RPM / 60 = 25.6 kHz. Speed of the individual followers is determined by their scaling in parameter 3-22 Master Scale Numerator , parameter 3-23 Master Scale Denominator , parameter 17-72 Position Unit Numerator , and parameter 17-73 Position Unit Denominator .
[4]	24V encoder 32/33	The encoder simulation is a mirror of the encoder signal on terminal 32/33. The drive can be used as repeater.

6.7.8 5-8* I/O Options



NOTE: This parameter group is only available in FC 302.

5-80 AHF Cap Reconnect Delay

Default value:	25 s	Parameter type:	Range, 1 - 120 s
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Guarantees a minimum off-time for the capacitors. The timer starts once the AHF capacitor disconnects and has to expire before the output is allowed to be on again. It only turns on again if the drive power is 20–30%.

6.7.9 5-9* Bus-controlled



NOTE: The following parameters are only available in FC 302.

This parameter group contains parameters for selecting digital and relay outputs via a fieldbus setting.

5-90 Digital & Relay Bus Control

Default value:	0	Parameter type:	Range, 0 - 0xFFFFFFFF
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter holds the state of the digital outputs and relays that is controlled by bus. A logical 1 indicates that the output is high or active. A logical 0 indicates that the output is low or inactive.

Table 38: Bus-controlled Digital Outputs and Relays

Bit	Output/Relay
0	Digital output terminal 27
1	Digital output terminal 29
2	Digital output terminal X30/6
3	Digital output terminal X30/7
4	Relay 1 output terminal
5	Relay 2 output terminal
6	Option B relay 1 output terminal
7	Option B relay 2 output terminal
8	Option B relay 3 output terminal
9-15	Reserved for future terminals
16	Option C relay 1 output terminal
17	Option C relay 2 output terminal
18	Option C relay 3 output terminal
19	Option C relay 4 output terminal
20	Option C relay 5 output terminal
21	Option C relay 6 output terminal
22	Option C relay 7 output terminal

Table 38: Bus-controlled Digital Outputs and Relays - (continued)

Bit	Output/Relay
23	Option C relay 8 output terminal
21–31	Reserved for future terminals

5-93 Pulse Out #27 Bus Control

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

Set the output frequency transferred to output terminal 27 when the terminal is configured as **[45] Bus Controlled** in parameter **5-60 Terminal 27 Pulse Output Variable**.

5-94 Pulse Out #27 Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the output frequency transferred to output terminal 27 when the terminal is configured as **[48] Bus Ctrl Timeout** in parameter **5-60 Terminal 27 Pulse Output Variable** and a timeout is detected.

5-95 Pulse Out #29 Bus Control

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

Set the output frequency transferred to output terminal 29 when the terminal is configured as **[45] Bus Controlled** in parameter **5-63 Terminal 29 Pulse Output Variable**.

5-96 Pulse Out #29 Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the output frequency transferred to output terminal 29 when the terminal is configured as **[48] Bus Ctrl Timeout** in parameter **5-63 Terminal 29 Pulse Output Variable** and a timeout is detected.

5-97 Pulse Out #30/6 Bus Control

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

Set the output frequency transferred to output terminal X30/6 when the terminal is configured as **[45] Bus ctrl.** in parameter **5-66 Terminal X30/6 Pulse Output Variable**.

5-98 Pulse Out #30/6 Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	-2
Data type:	Uint16	Changing during operation:	True

Set the output frequency transferred to output terminal X30/6 when the terminal is configured as **[48] Bus Ctrl Timeout** in parameter **5-66 Terminal X30/6 Pulse Output Variable** and a timeout is detected.

6.8 Parameter Group 6-** Analog In/Out

6.8.1 6-0* Analog I/O Mode

The analog inputs can be allocated to be either voltage (FC 301: 0–10 V, FC 302: 0 to ±10 V) or current input (0/4–20 mA).



NOTE: Thermistors may be connected to either an analog or a digital input.

6-00 Live Zero Timeout Time

Default value:	10 s	Parameter type:	Range, 0 - 99 s
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the live zero timeout in s. Live zero timeout time is active for analog inputs, that is terminal 53 or terminal 54, used as reference or feedback sources. If the reference signal value associated with the selected current input drops below 50% of the value set in:

- Parameter **6-10 Terminal 53 Low Voltage**
- Parameter **6-12 Terminal 53 Low Current**
- Parameter **6-20 Terminal 54 Low Voltage**
- Parameter **6-22 Terminal 54 Low Current**

for a time period longer than the time set in parameter **6-00 Live Zero Timeout Time**, the function selected in parameter **6-01 Live Zero Timeout Function** is activated.

6-01 Live Zero Timeout Function

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the timeout function. If the input signal on terminal 53 or 54 is below 50% of the value in

- Parameter **6-10 Terminal 53 Low Voltage**
- Parameter **6-12 Terminal 53 Low Current**
- Parameter **6-20 Terminal 54 Low Voltage**
- Parameter **6-22 Terminal 54 Low Current**

for a time period defined in parameter **6-00 Live Zero Timeout Time**, then the function set in parameter **6-01 Live Zero Timeout Function** is activated. If several timeouts occur simultaneously, the drive prioritizes the timeout functions as follows:

- Parameter **6-01 Live Zero Timeout Function**
- Parameter **8-04 Control Word Timeout Function**

Option	Name	Description
[0]*	Off	
[1]	Freeze output	Frozen at the present value.
[2]	Stop	Overruled to stop.
[3]	Jogging	Overruled to jog speed.
[4]	Max. speed	Overruled to maximum speed.
[5]	Stop and trip	Overruled to stop with subsequent trip.
[20]	Coast	
[21]	Coast and trip	
[30]	Warning only	

6-02 Emergency Mode Live Zero Timeout Function

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the timeout function when emergency mode is active. The function set in this parameter is activated if the input signal on analog inputs is below 50% of the low value for a period defined in parameter **6-00 Live Zero Timeout Time**.

Option	Name	Description
[0]*	Off	
[1]	Freeze output	Frozen at the present value.
[2]	Stop	Overruled to stop.
[3]	Jogging	Overruled to jog speed.
[4]	Max. speed	Overruled to maximum speed.

6.8.2 6-1* Analog Input 1

Parameters for configuring the scaling and limits for analog input 1 (terminal 53).




Figure 73: Analog Input 1

6-10 Terminal 53 Low Voltage

Default value:	Size related	Parameter type:	Range, -10.00 - par. 6-11 V
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Enter the low voltage value. This analog input scaling value should correspond to the minimum reference value set in parameter **6-14 Terminal 53 Low Ref./Feedb. Value**.

6-11 Terminal 53 High Voltage

Default value:	10 V	Parameter type:	Range, par. 6-10 V - 10 V
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Enter the high voltage value. This analog input scaling value should correspond to the high reference feedback value set in parameter **6-15 Terminal 53 High Ref./Feedb. Value**.

6-12 Terminal 53 Low Current

Default value:	0.14 mA	Parameter type:	Range, 0 - par. 6-13 mA
Setup:	All setups	Conversion index:	-5
Data type:	Int16	Change during operation:	True

Enter the low current value. This reference signal should correspond to the minimum reference value, set in parameter **3-02 Minimum Reference**. Set the value to exceed 2 mA to activate the live zero timeout function in parameter **6-01 Live Zero Timeout Function**.

6-13 Terminal 53 High Current

Default value:	20 mA	Parameter type:	Range, par. 6-12 mA - 20 mA
Setup:	All setups	Conversion index:	-5
Data type:	Int16	Change during operation:	True

Enter the high current value corresponding to the high reference/feedback set in parameter **6-15 Terminal 53 High Ref./Feedb. Value**.

6-14 Terminal 53 Low Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the analog input scaling value that corresponds to the low voltage/low current set in parameter **6-10 Terminal 53 Low Voltage** and parameter **6-12 Terminal 53 Low Current**.

6-15 Terminal 53 High Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the analog input scaling value that corresponds to the maximum reference feedback value set in parameter **6-11 Terminal 53 High Voltage** and parameter **6-13 Terminal 53 High Current**.

6-16 Terminal 53 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	-3
Data type:	UInt16	Change during operation:	True



NOTE: This parameter cannot be adjusted while the motor is running.

Enter the filter time constant. This constant is a first-order digital low-pass filter time for suppressing electrical noise in terminal 53. A high value improves dampening but also increases the delay through the filter.

6.8.3 6-2* Analog Input 2

This parameter group contains parameters for configuring the scaling and limits for analog input 2 (terminal 54).

6-20 Terminal 54 Low Voltage

Default value:	Size related	Parameter type:	Range, -10 - par. 6-21 V
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Enter the low voltage value. This analog input scaling value should correspond to the minimum reference value set in parameter **3-02 Minimum Reference**.

6-21 Terminal 54 High Voltage

Default value:	10 V	Parameter type:	Range, par. 6-20 V - 10 V
Setup:	All setups	Conversion index:	-2

Data type:	Int16	Change during operation:	True

Enter the high voltage value. This analog input scaling value should correspond to the high reference feedback value set in parameter **6-25 Terminal 54 High Ref./Feedb. Value**.

6-22 Terminal 54 Low Current

Default value:	Size related	Parameter type:	Range, 0 - par. 6-23 mA
Setup:	All setups	Conversion index:	-5
Data type:	Int16	Change during operation:	True

Enter the low current value. This reference signal should correspond to the minimum reference value, set in parameter **3-02 Minimum Reference**. Enter the value that exceeds 2 mA to activate the live zero timeout function in parameter **6-01 Live Zero Timeout Function**.

6-23 Terminal 54 High Current

Default value:	20 mA	Parameter type:	Range, par. 6-22 mA - 20 mA
Setup:	All setups	Conversion index:	-5
Data type:	Int16	Change during operation:	True

Enter the high current value corresponding to the high reference feedback value set in parameter **6-25 Terminal 54 High Ref./Feedb. Value**.

6-24 Terminal 54 Low Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the analog input scaling value that corresponds to the minimum reference feedback value set in parameter **3-02 Minimum Reference**.

6-25 Terminal 54 High Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the analog input scaling value that corresponds to the maximum reference feedback value set in parameter **3-03 Maximum Reference**.

6-26 Terminal 54 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	-3
Data type:	UInt16	Change during operation:	True



NOTE: This parameter cannot be adjusted while the motor is running.

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal 54. Increasing the value improves dampening but also increases the time delay through the filter.

6.8.4 6-3* Analog Input 3 General Purpose I/O MCB 101

This parameter group contains parameters for configuring the scale and limits for analog input 3 (X30/11) in VLT® General Purpose I/O MCB 101.

6-30 Terminal X30/11 Low Voltage

Default value:	0.07 V	Parameter type:	Range, 0 - setting in par. 6-31 V
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Sets the analog input scaling value to correspond to the low reference feedback value (set in parameter **6-34 Term. X30/11 Low Ref./Feedb. Value**).

6-31 Terminal X30/11 High Voltage

Default value:	10 V	Parameter type:	Range, par. 6-30 V - 10 V
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Sets the analog input scaling value to correspond to the high reference feedback value (set in parameter **6-35 Term. X30/11 High Ref./Feedb. Value**).

6-34 Term. X30/11 Low Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Sets the analog input scaling value to correspond to the low voltage value (set in parameter **6-30 Terminal X30/11 Low Voltage**).

6-35 Term. X30/11 High Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Sets the analog input scaling value to correspond to the high-voltage value (set in parameter **6-31 Terminal X30/11 High Voltage**).

6-36 Term. X30/11 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True



NOTE: This parameter cannot be adjusted while the motor is running.

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X30/11. Increasing the value improves dampening but also increases the time delay through the filter.

6.8.5 6-4* Analog Input X30/12

This parameter group contains parameters for configuring the scale and limits for analog input 4 (X30/12) in VLT® General Purpose I/O MCB 101.

6-40 Terminal X30/12 Low Voltage

Default value:	0.07 V	Parameter type:	Range, 0 - setting in par. 6-41 V
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Sets the analog input scaling value to correspond to the low reference feedback value set in parameter **6-44 Term. X30/12 Low Ref./Feedb. Value**.

6-41 Terminal X30/12 High Voltage

Default value:	10 V	Parameter type:	Range, par. 6-40 V - 10 V
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Sets the analog input scaling value to correspond to the high reference feedback value set in parameter **6-45 Term. X30/12 High Ref./Feedb. Value**.

6-44 Term. X30/12 Low Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Sets the analog output scaling value to correspond to the low voltage value set in parameter **6-40 Terminal X30/12 Low Voltage**.

6-45 Term. X30/12 High Ref./Feedb. Value

Default value:	Size related	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3

Data type:	Int32	Change during operation:	True

Sets the analog input scaling value to correspond to the high voltage value set in parameter **6-41 Terminal X30/12 High Voltage**.

6-46 Term. X30/12 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True



NOTE: This parameter cannot be adjusted while the motor is running.

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X30/12. Increasing the value improves dampening but also increases the time delay through the filter.

6.8.6 6-5* Analog Output 1

This parameter group contains parameters for configuring the scaling and limits for analog output 1, that is terminal 42. Analog outputs are current outputs of 0/4–20 mA. Common terminal (terminal 39) is the same terminal and has the same electrical potential for analog common and digital common connection. The resolution on analog output is 12 bit.

6-50 Terminal 42 Output

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the function of terminal 42 as an analog current output. Depending on the selection, the output is either a 0–20 mA or 4–20 mA output. The current value can be read out in the LCP in parameter **16-65 Analog Output 42 [mA]**.

Option	Name	Description
[0]	No operation	Indicates no signal on the analog output.
[52]	MCO	The analog value is set by the MCO 305 application program using the command OUTDA.
[53]	MCO 4–20mA	The analog value is set by the MCO 305 application program using the command OUTDA.
[58]	Actual position	NOTE: This option is available only with software version 48.0X or newer. The actual position. 0–20 mA corresponds to parameter 3-06 Minimum Position to parameter 3-07 Maximum Position .
[59]	Actual position 4–20 mA	NOTE: This option is available only with software version 48.0X. The actual position. 4–20 mA corresponds to parameter 3-06 Minimum Position to parameter 3-07 Maximum Position .
[100]	Output frequency	0 Hz = 0 mA; 100 Hz = 20 mA.

Option	Name	Description
[101]	Reference	Parameter 3-00 Reference Range [Min - Max] 0% = 0 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max - Max] -100% = 0 mA; 0% = 10 mA; +100% = 20 mA.
[102]	Feedback	
[103]	Motor current	The value is taken from parameter 16-37 Inv. Max. Current. The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160 % = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{20 \text{ mA} \times 22 \text{ A}}{38.4 \text{ A}} = 11.46 \text{ mA}$ When the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, \text{ MAX}} \times 100}{I_{\text{Motor, Nom}}} = \frac{38.4 \times 100}{22} = 175 \%$
[104]	Torque rel to limit	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[105]	Torque relate to rated	The torque is related to the motor torque setting.
[106]	Power	Taken from parameter 1-20 Motor Power [kW] .
[107]	Speed	Taken from parameter 3-03 Maximum Reference . 20 mA equals the value in parameter 3-03 Maximum Reference .
[108]	Torque	Torque reference related to 160% torque.
[109]	Max out freq	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[113]	PID clamped output	
[117]	Shaft power	
[118]	Shaft power 4–20mS	
[119]	Torque % lim	
[123]	Speed both dir	
[124]	Speed both dir 4–20 mA	
[130]	Output freq. 4–20mA	0 Hz = 4 mA, 100 Hz = 20 mA.
[131]	Reference 4–20mA	Parameter 3-00 Reference Range [Min-Max] 0% = 4 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max-Max] -100% = 4 mA; 0% = 12 mA; +100% = 20 mA.
[132]	Feedback 4–20mA	
[133]	Motor cur. 4–20mA	The value is taken from parameter 16-37 Inv. Max. Current. The inverter maximum current (160% current) is equal to 16 mA. Example: Inverter normal current (11 kW) is 24 A. 160% = 38.4 A. Motor normal current is 22 A, the readout is 13.17 mA. $\frac{16 \text{ mA} \times 22 \text{ A}}{38.4 \text{ A}} = 13.17 \text{ mA}$ If the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, \text{ MAX}} \times 100}{I_{\text{Motor, Nom}}} = \frac{38.4 \times 100}{22} = 175 \%$

Option	Name	Description
[134]	Torq.% lim 4–20mA	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[135]	Torq.% nom 4–20mA	The torque setting is related to the motor torque setting.
[136]	Power 4–20mA	Taken from parameter 1-20 Motor Power [kW] .
[137]	Speed 4–20mA	Taken from parameter 3-03 Maximum Reference . 20 mA = value in parameter 3-03 Maximum Reference .
[138]	Torque 4–20mA	Torque reference related to 160% torque.
[139]	Bus ctrl.	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[140]	Bus ctrl. 4-20mA	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[141]	Bus ctrl t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[142]	Bus ctrl 4-20mA t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[147]	Main act val	An output value based on main actual value from serial communication.
[148]	Main act val 4-20mA	An output value based on main actual value from serial communication.
[149]	Torque % lim 4-20mA	Analog output at 0 torque is 12 mA. Motoring torque increases the output current to maximum torque limit 20 mA (set in parameter 4-16 Torque Limit Motor Mode). Generating torque decreases the output to torque limit in generator mode (set in parameter 4-17 Torque Limit Generator Mode) Example: Parameter 4-16 Torque Limit Motor Mode = 200% and parameter 4-17 Torque Limit Generator Mode = 200%. 20 mA = 200% motoring and 4 mA = 200% generating.
[150]	Max Out Fr 4-20mA	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[158]	Motor Volt.	An output value based on actual motor voltage.
[159]	Motor Volt. 4-20mA	An output value based on actual motor voltage.
[184]	Mirror AI53 mA	
[185]	Mirror AI54 mA	
[254]	DC link	With this parameter selected, the terminal output shows the scaled DC-link voltage. See also the next 2 tables and the following drawing.
[255]	DC link 4-20mA	The function is the same as [254] DC Link 0–20 mA .

6-51 Terminal 42 Output Min Scale

Default value:	0%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Scale for the minimum output (0 mA or 4 mA) of the analog signal at terminal 42. Set the value to be the percentage of the full range of the variable selected in parameter **6-50 Terminal 42 Output**.

6-52 Terminal 42 Output Max Scale

Default value:	100%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Scale the maximum output of the selected analog signal at terminal 42. Set the value to the maximum value of the current signal output. Scale the output to give a current lower than 20 mA at full scale; or 20 mA at an output below 100% of the maximum signal value. If 20 mA is the required output current at a value 0–100% of the full-scale output, program the percentage value in the parameter, that is 50% = 20 mA. If a current 4–20 mA is required at maximum output (100%), calculate the percentage value as follows: 20 mA/desired maximum current x 100%

$$10\text{mA} : \frac{20}{10} \times 100 = 200\%$$




Figure 74: Output Maximum Scale

6-53 Term 42 Output Bus Ctrl

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

Holds the level of output 42 if controlled by bus.

6-54 Term 42 Output Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	-2
Data type:	UInt16	Change during operation:	True

Holds the preset level of output 42. If a timeout function is selected in parameter **6-50 Terminal 42 Output**, the output is preset to this level if a fieldbus timeout occurs.

6-55 Analog Output Filter

Default value:	[0] Off	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The following readout parameters from selection in parameter **6-50 Terminal 42 Output** have a filter selected when parameter **6-55 Analog Output Filter** is on.

Table 39: Readout Parameters

Selection	0–20 mA	4–20 mA
Motor current ($I_{\max}$)	[103]	[133]
Torque limit ($0-T_{\lim}$)	[104]	[134]
Rated torque ($0-T_{\text{nom}}$)	[105]	[135]
Power ($0-P_{\text{nom}}$)	[106]	[136]
Speed ($0-\text{Speed}_{\max}$)	[107]	[137]

Option	Name	Description
[0]*	Off	Filter off.
[1]	On	Filter on.

6.8.7 6-6* Analog Output 2 MCB 101

Analog outputs are current outputs: 0/4–20 mA. Common terminal (terminal X30/8) is the same terminal and electrical potential for analog common communication. The resolution on analog output is 12 bit.

6-60 Terminal X30/8 Output

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the function of terminal X30/8 as an analog current output. Depending on the selection, the output is either a 0–20 mA or 4–20 mA output. The current value can be read out in the LCP in parameter **16-65 Analog Output 42 [mA]**.

Option	Name	Description
[0]	No operation	Indicates no signal on the analog output.
[52]	MCO	The analog value is set by the MCO 305 application program using the command OUTDA.
[100]	Output frequency	0 Hz = 0 mA; 100 Hz = 20 mA.
[101]	Reference	Parameter 3-00 Reference Range [Min - Max] 0% = 0 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max - Max] -100% = 0 mA; 0% = 10 mA; +100% = 20 mA.
[102]	Feedback	

Option	Name	Description
[103]	Motor current	The value is taken from parameter 16-37 Inv. Max. Current. The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160 % = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{20 \text{ mA} \times 22 \text{ A}}{38.4 \text{ A}} = 11.46 \text{ mA}$ When the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, MAX} \times 100}{I_{Motor, Nom}} = \frac{38.4 \times 100}{22} = 175 \%$
[104]	Torque rel to limit	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[105]	Torque relate to rated	The torque is related to the motor torque setting.
[106]	Power	Taken from parameter 1-20 Motor Power [kW] .
[107]	Speed	Taken from parameter 3-03 Maximum Reference . 20 mA equals the value in parameter 3-03 Maximum Reference .
[108]	Torque	Torque reference related to 160% torque.
[109]	Max out freq	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[113]	PID clamped output	
[117]	Shaft power	
[118]	Shaft power 4–20mS	
[119]	Torque % lim	
[123]	Speed both dir	
[124]	Speed both dir 4–20 mA	
[130]	Output freq. 4–20mA	0 Hz = 4 mA, 100 Hz = 20 mA.
[131]	Reference 4–20mA	Parameter 3-00 Reference Range [Min-Max] 0% = 4 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max-Max] -100% = 4 mA; 0% = 12 mA; +100% = 20 mA.
[132]	Feedback 4–20mA	
[133]	Motor cur. 4–20mA	The value is taken from parameter 16-37 Inv. Max. Current. The inverter maximum current (160% current) is equal to 16 mA. Example: Inverter normal current (11 kW) is 24 A. 160% = 38.4 A. Motor normal current is 22 A, the readout is 13.17 mA. $\frac{16 \text{ mA} \times 22 \text{ A}}{38.4 \text{ A}} = 13.17 \text{ mA}$ If the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, MAX} \times 100}{I_{Motor, Nom}} = \frac{38.4 \times 100}{22} = 175 \%$
[134]	Torq.% lim 4–20mA	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[135]	Torq.% nom 4–20mA	The torque setting is related to the motor torque setting.
[136]	Power 4–20mA	Taken from parameter 1-20 Motor Power [kW] .

Option	Name	Description
[137]	Speed 4–20mA	Taken from parameter 3-03 Maximum Reference . 20 mA = value in parameter 3-03 Maximum Reference .
[138]	Torque 4–20mA	Torque reference related to 160% torque.
[139]	Bus ctrl.	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[140]	Bus ctrl. 4-20mA	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[141]	Bus ctrl t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[142]	Bus ctrl 4-20mA t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[147]	Main act val	An output value based on main actual value from serial communication.
[148]	Main act val 4-20mA	An output value based on main actual value from serial communication.
[149]	Torque % lim 4-20mA	Analog output at 0 torque is 12 mA. Motoring torque increases the output current to maximum torque limit 20 mA (set in Parameter 4-16 Torque Limit Motor Mode). Generating torque decreases the output to torque limit in generator mode (set in parameter 4-17 Torque Limit Generator Mode) Example: Parameter 4-16 Torque Limit Motor Mode = 200% and parameter 4-17 Torque Limit Generator Mode = 200%. 20 mA = 200% motoring and 4 mA = 200% generating.
[150]	Max Out Fr 4-20mA	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[158]	Motor Volt.	An output value based on actual motor voltage.
[159]	Motor Volt. 4-20mA	An output value based on actual motor voltage.
[254]	DC link	
[255]	DC link 4–20mA	

6-61 Terminal X30/8 Min. Scale

Default value:	0%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Scales the minimum output of the selected analog signal on terminal X30/8. Scale the minimum value as a percentage of the maximum signal value. For example, enter the value 25% if the output should be 0 mA at 25% of the maximum output value. The value cannot exceed the corresponding setting in parameter **6-62 Terminal X30/8 Max. Scale** if the value is below 100%. This parameter is active when VLT® General Purpose I/O MCB 101 is mounted in the drive.

6-62 Terminal X30/8 Max. Scale

Default value:	100%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2

Data type:	Int16	Change during operation:	True

Scales the maximum output of the selected analog signal on terminal X30/8. Scale the value to the required maximum value of the current signal output. Scale the output to give a lower current than 20 mA at full scale or 20 mA at an output below 100% of the maximum signal value. If 20 mA is the required output current at a value between 0–100% of the fullscale output, program the percentage value in the parameter, that is 50%=20 mA. If a current 4–20 mA is required at maximum output (100%), calculate the percentage value as follows: 20 mA/desired maximum current x 100%.

$$10\text{mA} : \frac{20-4}{10} \times 100 = 160\%$$

6-63 Terminal X30/8 Bus Control

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

Holds the level of output X30/8 if controlled by bus.

6-64 Terminal X30/8 Output Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Holds the preset level of output X30/8. If a timeout function is selected in parameter **6-60 Terminal X30/8 Output**, the output is preset to this level if a fieldbus timeout occurs.

6.8.8 6-7* Analog Output 3 MCB 113

This parameter group contains parameters for configuring the scaling and limits for analog output 3, terminals X45/1 and X45/2. Analog outputs are current outputs: 0/4–20 mA. The resolution of analog output is 12 bit.

6-70 Terminal X45/1 Output

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8		

Select the function of terminal X45/1 as an analog current output.

Option	Name	Description
[0]*	No operation	Indicates no signal on the analog output.
[52]	MCO	The analog value is set by the MCO 305 application program using the command OUTDA.
[100]	Output frequency	0 Hz = 0 mA; 100 Hz = 20 mA.
[101]	Reference	Parameter 3-00 Reference Range [-Max - Max] 0% = 0 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max - Max] -100% = 0 mA; 0% = 10 mA; +100% = 20 mA.
[102]	Feedback	

Option	Name	Description
[103]	Motor current	The value is taken from parameter 16-37 Inv. Max. Current. The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160 % = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{20\text{mA} \times 22\text{A}}{38.4\text{A}} = 11.46\text{mA}$ When the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, \text{MAX}} \times 100}{I_{\text{Motor, Nom}}} = \frac{38.4 \times 100}{22} = 175\%$
[104]	Torque rel to limit	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[105]	Torque relate to rated	The torque is related to the motor torque setting.
[106]	Power	Taken from parameter 1-20 Motor Power [kW] .
[107]	Speed	Taken from parameter 3-03 Maximum Reference . 20 mA equals the value in parameter 3-03 Maximum Reference .
[108]	Torque	Torque reference related to 160% torque.
[109]	Max out freq	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[113]	PID clamped output	
[117]	Shaft power	
[118]	Shaft power 4–20mA	
[119]	Torque % lim	
[123]	Speed both dir	
[124]	Speed both dir 4–20mA	
[130]	Output freq. 4–20mA	0 Hz = 4 mA, 100 Hz = 20 mA.
[131]	Reference 4–20mA	Parameter 3-00 Reference Range [Min-Max] 0% = 4 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max-Max] -100% = 4 mA; 0% = 12 mA; +100% = 20 mA.
[132]	Feedback 4–20mA	
[133]	Motor cur. 4–20mA	The value is taken from parameter 16-37 Inv. Max. Current. The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160% = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{16\text{mA} \times 22\text{A}}{38.4\text{A}} = 11.46\text{mA}$ If the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, \text{MAX}} \times 100}{I_{\text{Motor, Nom}}} = \frac{38.4 \times 100}{22} = 175\%$
[134]	Torq.% lim 4–20mA	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[135]	Torq.% nom 4–20mA	The torque setting is related to the motor torque setting.
[136]	Power 4–20mA	Taken from parameter 1-20 Motor Power [kW] .

Option	Name	Description
[137]	Speed 4–20mA	Taken from parameter 3-03 Maximum Reference . 20 mA = value in parameter 3-03 Maximum Reference .
[138]	Torque 4–20mA	Torque reference related to 160% torque.
[139]	Bus ctrl.	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[140]	Bus ctrl. 4–20mA	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[141]	Bus ctrl t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[142]	Bus ctrl 4-20mA t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[147]	Main act val	
[148]	Main act val 4-20mA	
[149]	Torque % lim 4-20mA	Analog output at 0 torque is 12 mA. Motoring torque increases the output current to maximum torque limit 20 mA (set in parameter 4-16 Torque Limit Motor Mode). Generating torque decreases the output to torque limit in generator mode (set in parameter 4-17 Torque Limit Generator Mode) Example: Parameter 4-16 Torque Limit Motor Mode = 200% and parameter 4-17 Torque Limit Generator Mode = 200%. 20 mA = 200% motoring and 4 mA = 200% generating.
[150]	Max Out Fr 4-20mA	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[158]	Motor Volt.	
[159]	Motor Volt. 4-20mA	
[254]	DC link	
[255]	DC link 4–20mA	

6-71 Terminal X45/1 Min. Scale

Default value:	0%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Scale the minimum output of the selected analog signal at terminal X45/1 as a percentage of the maximum signal value. For example, if 0 mA (or 0 Hz) is required at 25% of the maximum output value, then program 25%. Scaling values up to 100% cannot exceed the corresponding setting in parameter **6-72 Terminal X45/1 Max. Scale**.

6-72 Terminal X45/1 Max. Scale

Default value:	100%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Scale the maximum output of the selected analog signal at terminal X45/1. Set the value to the maximum value of the current signal output. Scale the output to give a current lower than 20 mA at full scale, or 20 mA at an output below 100% of the maximum signal value. If 20 mA is the required output current at a value between 0–100% of the full-scale output, program the percentage value in the parameter, for example 50% = 20 mA. If a current 4–20 mA is required at maximum output (100%), calculate the percentage value as follows (example where required maximum output is 10 mA):

$$\frac{I_{\text{RANGE}}[\text{mA}]}{I_{\text{DESIREDMAX}}[\text{mA}]} \times 100\% = \frac{20 - 4 \text{ mA}}{10 \text{ mA}} \times 100\% = 160\%$$




Figure 75: Output Maximum Scale

6-73 Terminal X45/1 Bus Control

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

Holds the level of analog output 3 (terminal X45/1) if controlled by bus.

6-74 Terminal X45/1 Output Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Holds the preset level of analog output 3 (terminal X45/1). If there is a fieldbus timeout and a timeout function is selected in parameter **6-70 Terminal X45/1 Output**, the output is preset to this level.

6.8.9 6-8* Analog Output 4 MCB 113

This parameter group contains parameters for configuring the scaling and limits for analog output 4, terminals X45/3 and X45/4. Analog outputs are current outputs: 0/4–20 mA. The resolution on analog output is 11 bit.

6-80 Terminal X45/3 Output

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the function of terminal X45/3 as an analog current output.

Option	Name	Description
[0]	No operation	Indicates no signal on the analog output.
[52]	MCO	The analog value is set by the MCO 305 application program using the command OUTDA.
[100]	Output frequency	0 Hz = 0 mA; 100 Hz = 20 mA.
[101]	Reference	Parameter 3-00 Reference Range [Min - Max] 0% = 0 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max - Max] -100% = 0 mA; 0% = 10 mA; +100% = 20 mA.
[102]	Feedback	
[103]	Motor current	The value is taken from parameter 16-37 Inv. Max. Current . The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160 % = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{20\text{mA} \times 22\text{A}}{38.4\text{A}} = 11.46\text{mA}$ When the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{\text{VLT, MAX}} \times 100}{I_{\text{Motor, Nom}}} = \frac{38.4 \times 100}{22} = 175\%$
[104]	Torque rel to limit	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[105]	Torque relate to rated	The torque is related to the motor torque setting.
[106]	Power	Taken from parameter 1-20 Motor Power [kW] .
[107]	Speed	Taken from parameter 3-03 Maximum Reference . 20 mA equals the value in parameter 3-03 Maximum Reference .
[108]	Torque	Torque reference related to 160% torque.
[109]	Max out freq	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[113]	PID clamped output	
[117]	Shaft power	
[118]	Shaft power 4–20mA	
[119]	Torque % lim	
[123]	Speed both dir	
[124]	Speed both dir 4–20mA	
[130]	Output freq. 4–20mA	0 Hz = 4 mA, 100 Hz = 20 mA.
[131]	Reference 4–20mA	Parameter 3-00 Reference Range [Min-Max] 0% = 4 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max-Max] -100% = 4 mA; 0% = 12 mA; +100% = 20 mA.
[132]	Feedback 4–20mA	

Option	Name	Description
[133]	Motor cur. 4–20mA	The value is taken from parameter 16-37 Inv. Max. Current. The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160% = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{16\text{mA} \times 22\text{A}}{38.4\text{A}} = 11.46\text{mA}$ If the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{\text{VLT, MAX}} \times 100}{I_{\text{Motor, Nom}}} = \frac{38.4 \times 100}{22} = 175\%$
[134]	Torq.% lim 4–20mA	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[135]	Torq.% nom 4–20mA	The torque setting is related to the motor torque setting.
[136]	Power 4–20mA	Taken from parameter 1-20 Motor Power [kW] .
[137]	Speed 4–20mA	Taken from parameter 3-03 Maximum Reference . 20 mA = value in parameter 3-03 Maximum Reference .
[138]	Torque 4–20mA	Torque reference related to 160% torque.
[139]	Bus ctrl.	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[140]	Bus ctrl. 4–20mA	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[141]	Bus ctrl t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[142]	Bus ctrl 4-20mA t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[147]	Main act val	
[148]	Main act val 4-20mA	
[149]	Torque % lim 4-20mA	Analog output at 0 torque is 12 mA. Motoring torque increases the output current to maximum torque limit 20 mA (set in parameter 4-16 Torque Limit Motor Mode). Generating torque decreases the output to torque limit in generator mode (set in parameter 4-17 Torque Limit Generator Mode) Example: Parameter 4-16 Torque Limit Motor Mode = 200% and parameter 4-17 Torque Limit Generator Mode = 200%. 20 mA = 200% motoring and 4 mA = 200% generating.
[150]	Max Out Fr 4-20mA	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[158]	Motor Volt.	
[159]	Motor Volt. 4-20mA	
[254]	DC link	
[255]	DC link 4–20mA	

6-81 Terminal X45/3 Min. Scale

Default value:	0%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2

Data type:	Int16	Change during operation:	True

Scales the minimum output of the selected analog signal on terminal X45/3. Scale the minimum value as a percentage of the maximum signal value, for example, 0 mA (or 0 Hz) is required at 25% of the maximum output value and 25% is programmed. The value cannot exceed the corresponding setting in parameter **6-82 Terminal X45/3 Max. Scale** if the value is below 100%. This parameter is active when VLT® Extended Relay Card MCB 113 is mounted in the drive.

6-82 Terminal X45/3 Max. Scale

Default value:	100%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Scale the maximum output of the selected analog signal at terminal X45/3. Set the value to the maximum value of the current signal output. Scale the output to give a current lower than 20 mA at full scale, or 20 mA at an output below 100% of the maximum signal value. If 20 mA is the required output current at a value between 0–100% of the full-scale output, program the percentage value in the parameter, for example 50% = 20 mA. If a current 4–20 mA is required at maximum output (100%), calculate the percentage value as follows (example where required maximum output is 10 mA):

$$\frac{I_{\text{RANGE}}[\text{mA}]}{I_{\text{DESIREDMAX}}[\text{mA}]} \times 100\% = \frac{20 - 4 \text{ mA}}{10 \text{ mA}} \times 100\% = 160\%$$

6-83 Terminal X45/3 Bus Control

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

Holds the level of analog output 4 (terminal X45/3) if controlled by bus.

6-84 Terminal X45/3 Output Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	-2
Data type:	UInt16	Change during operation:	True

Holds the preset level of output 4 (X45/3). If there is a fieldbus timeout and a timeout function is selected in parameter **6-80 Terminal X45/3 Output**, the output is preset to this level.

6.9 Parameter Group 7-** Controllers

6.9.1 Speed PID Droop

This feature implements precise torque sharing between multiple motors on a common mechanical shaft. Speed PID droop is useful for marine and mining applications where redundancy and higher dynamics are required. Speed PID droop reduces inertia by utilizing multiple small motors instead of 1 large motor.




Figure 76: Concept of Speed PID Droop

The value in parameter **7-01 Speed PID Droop** ensures that the load is shared equally between the motors. If the torque on the motor is 100% of nominal motor torque, the drive reduces its output to this motor by 100% of the value in parameter **7-01 Speed PID Droop**. If the torque is 50% of nominal motor torque, the drive reduces its output to this motor by 50% of the value in parameter **7-01 Speed PID Droop**. This ensures that the motors share the load evenly. A side effect of using speed PID droop is that the actual shaft speed does not match the reference exactly. Speed PID droop is not efficient in low-speed applications because the adjustment range may be insufficient.

Use the speed trim function if the application requires the following features:

- Accurate speed (the actual shaft speed matches the reference speed).
- Precise speed adjustment down to 0 RPM.

Enabling PID droop

To enable speed PID droop:

- Run the drive in 1 of the following modes:
 - Flux closed loop (parameter **1-01 Motor Control Principle**, [3] *Flux w/ motor feedb*).
 - Flux sensorless (parameter **1-01 Motor Control Principle**, [2] *Flux sensorless*).
- Run the drive in speed mode (parameter **1-00 Configuration Mode**, option [0] *Speed open loop* or [1] *Speed closed loop*).
- Ensure that parameter **1-62 Slip Compensation** contains the default value (0%).
- Ensure that all drives in the torque sharing system use the same speed reference and start and stop signal.
- Ensure that all drives in the torque sharing system use the same parameter settings.
- Adjust the value in parameter **7-01 Speed PID Droop**.



NOTE: Do not use overvoltage control when using the PID droop function (select **[0] Disabled** in parameter **2-17 Over-voltage Control**).



NOTE: If the speed reference is lower than the value in parameter **7-01 Speed PID Droop**, the drive makes the PID droop factor equal to the speed reference.

6.9.2 Speed Trim

The speed trim function is an add-on to the speed PID droop. The speed trim provides torque sharing with precise speed down to 0 RPM. The function requires wiring of analog signals.

In speed trim, the master drive runs normal speed PID without droop. The follower drives use the speed PID droop, but instead of reacting on their own load, they compare their own load to the load of other drives in the system. The follower drives then use that data as input for the speed PID droop. A setup with a single source, where the master drive sends information about torque to all followers, is limited by the number of available analog outputs on the master drive. It is possible to use a cascade principle which overcomes this limitation, but makes the control slower and less accurate. The master drive operates in speed mode. The follower drives operate in speed mode with the speed trim. The trim function uses torque data from all drives in the system.




Figure 77: Concept of Speed Trim

The drawing shows a single-source setup where the master sends the torque signal to all followers. The number of available analog outputs on the master limits this setup. To overcome the limitation of the number of analog outputs, use a cascade principle. The cascade principle makes the control slower and less accurate compared with the setup using analog outputs.

6.9.3 7-0* Speed PID Ctrl.



NOTE: If separate encoders are used (FC 302 only), adjust the ramp-related parameters according to the gear ratio between the 2 encoders.

7-00 Speed PID Feedback Source

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False

Option	Name	Description
[0]	Motor feedb. P1-02	Use the feedback source selected as motor feedback in parameter 1-02 Flux Motor Feedback Source . NOTE: This option is only available FC 302.
[1]	24V encoder 32/33	Single signal generated from 24 V High Threshold Logic (HTL) encoder connected to terminals 32 and 33. Configure the 24 V encoder interface in parameter group 5-7* 24V Encoder Input . Program terminals 32/33 to [0] No operation .
[2]	MCB 102	This is only available for VLT® Encoder Option MCB 102. Configure the encoder interface in parameter groups 17-0* Encoder Interface , 17-1* Inc. Enc. Interface , and 17-2* Abs. Inc. Interface .
[3]	MCB 103	This is only available for VLT® Resolver Option MCB 103. Configure the resolver interface in parameter group 17-5* Resolver Interface .
[4]	MCO Encoder 1 X56	The MCO encoder 1 X56 is only available with motion control options MCO 305, MCO 350, and MCO 351. Configure the encoder interface in parameter group 32-3* Encoder 1 .
[5]	MCO Encoder 2 X55	The MCO encoder 1 X56 is only available with motion control options MCO 305, MCO 350, and MCO 351. Configure the encoder interface in parameter group 32-0* Encoder 2 .
[6]	Analog input 53	Feedback source from analog input 53.
[7]	Analog input 54	Feedback source from analog input 54.
[8]	Frequency input 29	 NOTE: This option is only available FC 302. Feedback source from frequency input 29.
[9]	Frequency input 33	Feedback source from frequency input 33.
[11]	MCB15X	
[12]	MCB 102 Absolute	 NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer. The option is only available for VLT® Encoder Option MCB 102 module option with version 4.00 and newer and when parameter 17-00 Encoders Connected is set to [1] Two Encoders .

Option	Name	Description
[13]	24V encoder 27/29	 NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer. Single signal generated from 24 V High Threshold Logic (HTL) encoder connected to terminals 27 and 29. Configure the 24 V encoder interface in parameter group 5-7* 24V Encoder Input . Program terminals 27/29 to [0] No operation .
[20]	None	 NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer.

7-01 Speed PID Droop

Default value:	0 RPM	Parameter type:	Range, 0 - 200 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

The droop function allows the drive to decrease the motor speed proportional to the load. The droop value is directly proportional to the load value. Use the droop function when several motors are mechanically connected and the load on motors can differ. Ensure that parameter **1-62 Slip Compensation** has a default setting. Enter the droop value at 100% load.

7-02 Speed PID Proportional Gain

Default value:	0.015	Parameter type:	Range, 0 - 1
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Enter the speed controller proportional gain. The proportional gain amplifies the error (that is the deviation between the feedback signal and the setpoint). This parameter is used with parameter **1-00 Configuration Mode [0] Speed open loop** and **[1] Speed closed loop control**. Quick control is obtained at high amplification. Increasing amplification makes the process less stable. For values with 4 decimals, use parameter **30-83 Speed PID Proportional Gain**.

7-03 Speed PID Integral Time

Default value:	Size related	Parameter type:	Range, 1.0 - 20000 ms
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True

Enter the speed controller integral time, which determines the time the internal PID control takes to correct errors. The greater the error, the more quickly the gain increases. The integral time causes a delay of the signal and therefore a dampening effect and can be used to eliminate steady-state speed error. Obtain quick control through a short integral time, though if the integral time is too short, the process becomes unstable. An excessively long integral time disables the integral action, leading to major deviations from the required reference, since the process regulator takes too long to regulate errors. This parameter is used with **[0] Speed open loop** and **[1] Speed closed loop control**, set in parameter **1-00 Configuration Mode**.

7-04 Speed PID Differentiation Time

Default value:	Size related	Parameter type:	Range, 0 - 200 ms

Setup:	All setups	Conversion index:	-4
Data type:	Uint16	Change during operation:	True

Enter the speed controller differentiation time. The differentiator does not react to constant error. It provides gain proportional to the rate of change of the speed feedback. The quicker the error changes, the stronger the gain from the differentiator. The gain is proportional with the speed at which errors change. Setting this parameter to 0 disables the differentiator. This parameter is used with parameter **1-00 Configuration Mode, [1] Speed closed loop control**.

7-05 Speed PID Diff. Gain Limit

Default value:	5	Parameter type:	Range, 1 - 20
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Set a limit for the gain provided by the differentiator. Consider limiting the gain at higher frequencies. For example, set up a pure D-link at low frequencies and a constant D-link at higher frequencies. This parameter is used with parameter **1-00 Configuration Mode, [1] Speed closed loop control**.

7-06 Speed PID Lowpass Filter Time

Default value:	Size related	Parameter type:	Range, 0.1 - 100 ms
Setup:	All setups	Conversion index:	-4
Data type:	Uint16	Change during operation:	True



NOTE: Severe filtering can be detrimental to dynamic performance. This parameter is used with parameter **1-00 Configuration Mode, [1] Speed closed loop** and **[2] Torque control**. Adjust the filter time in flux sensorless to 3–5 ms.

Set a time constant for the speed control low-pass filter. The low-pass filter improves steady-state performance and dampens oscillations on the feedback signal. This is an advantage if there is a great amount of noise in the system. For example, if a time constant (τ) of 100 ms is programmed, the cut-off frequency for the low-pass filter is $1/0.1 = 10 \text{ RAD/s}$, corresponding to $(10/2 \times \pi) = 1.6 \text{ Hz}$. The PID regulator only regulates a feedback signal that varies by a frequency of less than 1.6 Hz. If the feedback signal varies by a higher frequency than 1.6 Hz, the PID regulator does not react. Practical settings of parameter **7-06 Speed PID Lowpass Filter Time** taken from the number of pulses per revolutions from encoder:

Table 40: Speed PID Low-pass Filter Time

Encoder PPR	Parameter 7-06 Speed PID Lowpass Filter Time [ms]
512	10
1024	5
2048	2
4096	1




Figure 78: Feedback Signal

7-07 Speed PID Feedback Gear Ratio

Default value:	1	Parameter type:	Range, 0.0001 - 32.0000
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	False

The drive multiplies the speed feedback by this ratio.




Figure 79: Speed PID Feedback Gear Ratio

7-08 Speed PID Feed Forward Factor

Default value:	0%	Parameter type:	Range, 0 - 500%
Setup	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The reference signal bypasses the speed controller by the amount specified. This feature increases the dynamic performance of the speed control loop.

7-09 Speed PID Error Correction w/Ramp

Default value:	Size related	Parameter type:	Range, 10 - 100000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint32	Change during operation:	True

The speed error between ramp and actual speed is held up against the setting in this parameter. If the speed error exceeds this parameter entry, the speed error is corrected via ramping in a controlled way.




Figure 80: Speed Error Between Ramp and Actual Speed

6.9.4 7-1* Torque PI Control

This parameter group contains parameters for configuring the torque PI control.

7-10 Torque PID Feedback Source

Default value:	[0] Controller off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the feedback source for the torque controller.

Option	Name	Description
[0]*	Controller off	Select to operate in open loop.
[1]	Analog input 53	Select to use torque feedback from the analog input.
[2]	Analog input 54	Select to use torque feedback from the analog input.
[3]	Estimated torque	Select to use the torque feedback estimated by the drive.

7-12 Torque PI Proportional Gain

Default value:	100%	Parameter type:	Range, 0 - 500%
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Enter the proportional gain value for the torque controller. Selection of a high value makes the controller react faster. Too high a setting leads to controller instability.

7-13 Torque PI Integration Time

Default value:	0.020 s	Parameter type:	Range, 0.002 - 2 s
Setup:	All setups	Conversion index:	-3
Data type:	UInt16	Change during operation:	True

Enter the integration time for the torque controller. Selection of a low value makes the controller react faster. Too low a setting leads to controller instability.

7-16 Torque PI Lowpass Filter Time

Default value:	5 ms	Parameter type:	Range, 0.1 - 100 ms
Setup:	All setups	Conversion index:	-4
Data type:	UInt16	Change during operation:	True

Enter the time constant for the torque control low-pass filter.

7-18 Torque PI Feed Forward Factor

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Enter the torque feed-forward factor value. The reference signal bypasses the torque controller by this value.

7-19 Current Controller Rise Time

Default value:	Size related	Parameter type:	Range, 15 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter the value for the rise time of the current controller as a percentage of the control period.

6.9.5 7-2* Process Ctrl. Feedb.

Select the feedback sources for the process PID control, and how this feedback should be handled.

7-20 Process CL Feedback 1 Resource

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The effective feedback signal is made up of the sum of up to 2 different input signals. Select which drive input should be treated as the source of the 1st of these signals. The 2nd input signal is defined in parameter **7-22 Process CL Feedback 2 Resource**.

Option	Name	Description
[0]*	No function	
[1]	Analog input 53	
[2]	Analog input 54	
[3]	Frequency input 29	
 NOTE: This option is only available in FC 302.		
[4]	Frequency input 33	
[7]	Analog input X30/11	
[8]	Analog input X30/12	
[15]	Analog input X48/2	
[16]	Analog input X49/1	
[17]	Analog input X49/3	
[18]	Analog input X49/5	
[99]	Normal feedback	

7-22 Process CL Feedback 2 Resource

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The effective feedback signal is made up of the sum of up to 2 different input signals. Select which drive input should be treated as the source of the 2nd of these signals. The 1st input signal is defined in parameter **7-20 Process CL Feedback 1 Resource**.

Option	Name	Description
[0]*	No function	
[1]	Analog input 53	
[2]	Analog input 54	
[3]	Frequency input 29	 NOTE: This option is only available in FC 302.
[4]	Frequency input 33	
[7]	Analog input X30/11	
[8]	Analog input X30/12	
[15]	Analog input X48/2	
[16]	Analog input X49/1	
[17]	Analog input X49/3	
[18]	Analog input X49/5	
[99]	Normal feedback	

6.9.6 7-3* Process PID Ctrl.

7-30 Process PID Normal/ Inverse Control

Default value:	[0] Normal	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Normal and inverse controls are implemented by introducing a difference between the reference signal and the feedback signal.

Option	Name	Description
[0]*	Normal	Set the process to increase the output frequency.
[1]	Inverse	Set the process to decrease the output frequency.

7-31 Process PID Anti Windup

Default value:	[1] On	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Normal and inverse controls are implemented by introducing a difference between the reference signal and the feedback signal.

Option	Name	Description
[0]	Off	Continue regulation of an error even when the output frequency cannot be increased or decreased.
[1]*	On	Cease regulation of an error when the output frequency can no longer be adjusted.

7-32 Process PID Start Speed

Default value:	0 RPM	Parameter type:	Range, 0 - 6000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the motor speed to be attained as a start signal for commencement of PID control. When the power is switched on, the drive starts to ramp and then operates under speed open-loop control. When the process PID start speed is reached, the drive changes to process PID control.

7-33 Process PID Proportional Gain

Default value:	Size related	Parameter type:	Range, 0 - 10
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the PID proportional gain. The proportional gain multiplies the error between the setpoint and the feedback signal.

7-34 Process PID Integral Time

Default value:	10000 s	Parameter type:	Range, 0.01 - 10000 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Enter the PID integral time. The integrator provides an increasing gain at a constant error between the setpoint and the feedback signal. The integral time is the time needed by the integrator to reach the same gain as the proportional gain.

7-35 Process PID Differentiation Time

Default value:	0 s	Parameter type:	Range, 0 - 10 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the PID differentiation time. The differentiator does not react to a constant error, but provides a gain only when the error changes. The shorter the PID differentiation time, the stronger the gain from the differentiator.

7-36 Process PID Diff. Gain Limit

Default value:	5	Parameter type:	Range, 1 - 50
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Enter a limit for the differentiator gain. If there is no limit, the differentiator gain increases when there are fast changes. To obtain a pure differentiator gain at slow changes and a constant differentiator gain where fast changes occur, limit the differentiator gain.

7-38 Process PID Feed Forward Factor

Default value:	0%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0

Data type:	Uint16	Change during operation:	True

Enter the PID feed-forward factor. The factor sends a constant fraction of the reference signal to bypass the PID control, so the PID control only affects the remaining fraction of the control signal. Any change to this parameter affects the motor speed. When the feed-forward factor is activated, it provides less overshoot and high dynamics when changing the setpoint. Parameter **7-38 Process PID Feed Forward Factor** is active when parameter **1-00 Configuration Mode** is set to **[3] Process**.

7-39 On Reference Bandwidth

Default value:	5%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the on-reference bandwidth. When the PID control error (the difference between the reference and the feedback) is less than the value of this parameter, the on-reference status bit is 1.

6.9.7 7-4* Advanced Process PID Ctrl.



NOTE: The following parameter is only available in FC 302.

This parameter group is only used if parameter **1-00 Configuration Mode** is set to **[7] Extended PID speed CI** or **[8] Extended PID speed OL**.

7-40 Process PID I-part Reset

Default value:	[0] No	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the feedback source for the torque controller.

Option	Name	Description
[0]*	No	
[1]	Yes	Select [1] Yes to reset the I-part of the process PID controller. The selection automatically returns to [0] No . Resetting the I-part makes it possible to start from a well-defined point after changing something in the process, for example changing a textile roll.

7-41 Process PID Output Neg. Clamp

Default value:	-100%	Parameter type:	Range, -100 - par. 7-42 %
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter a negative limit for the process PID controller output.

7-42 Process PID Output Pos. Clamp

Default value:	100%	Parameter type:	Range, par. 7-41 % - 100%
Setup:	All setups	Conversion index:	0

Data type:	Int16	Change during operation:	True

Enter a positive limit for the process PID controller output.

7-43 Process PID Gain Scale at Min. Ref.

Default value:	100%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter a scaling percentage to apply to the process PID output when operating at the minimum reference. The scaling percentage is adjusted linearly between the scale at minimum reference (parameter **7-43 Process PID Gain Scale at Min. Ref.**) and the scale at maximum reference (parameter **7-44 Process PID Gain Scale at Max. Ref.**).

7-44 Process PID Gain Scale at Max. Ref.

Default value:	100%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter a scaling percentage to apply to the process PID output when operating at the maximum reference. The scaling percentage is adjusted linearly between the scale at minimum reference (parameter **7-43 Process PID Gain Scale at Min. Ref.**) and the scale at maximum reference (parameter **7-44 Process PID Gain Scale at Max. Ref.**).

7-45 Process PID Feed Fwd Resource

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	No function	Select which drive input should be used as the feed-forward factor. The factor is added to the output of the PID controller. This increases dynamic performance.
[1]	Analog input 53	
[2]	Analog input 54	
[7]	Frequency input 29	
[8]	Frequency input 33	
[11]	Local bus reference	
[20]	Digital pot.meter	
[21]	Analog input X30/11	
[22]	Analog input X30/12	



NOTE: This option is only available in FC 302.

Option	Name	Description
[29]	Analog input X48/2	
[32]	Bus PCD	 NOTE: This option is only available in FC 302. Selects a fieldbus reference configured by parameter 8-02 Control Word Source . Change parameter 8-42 PCD Write Configuration for the bus used to make the feed forward available in parameter 7-48 PCD Feed Forward . Use index 1 for feed forward [748] (and index 2 for reference [1682]).

7-46 Process PID Feed Fwd Normal/Inv. Ctrl.

Default value:	[0] Normal	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Normal	Select [0] Normal to set the feed-forward factor to treat the FF resource as a positive value.
[1]	Inverse	Select [1] Inverse to treat the feed-forward resource as a negative value.

7-48 PCD Feed Forward

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter contains the value of parameter **7-45 Process PID Feed Fwd Resource**, [32] **Bus PCD**.

7-49 Process PID Output Normal/Inv. Ctrl.

Default value:	[0] Normal	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Normal	Select [0] Normal to use the resulting output from the process PID controller as is.
[1]	Inverse	Select [1] Inverse to invert the resulting output from the process PID controller. This operation is performed after the feed-forward factor is applied.

6.9.8 7-5* Ext. Process PID Ctrl.

This parameter group is only used if parameter **1-00 Configuration Mode** is set to **[7] Extended PID speed CL** or **[8] Extended PID speed OL**.

7-50 Process PID Extended PID

Default value:	[1] Enabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Disabled	Disable the extended parts of the process PID controller.
[1]*	Enabled	Enable the extended parts of the PID controller.

7-51 Process PID Feed Fwd Gain

Default value:	1	Parameter type:	Range, 0 - 100
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The feed forward is used to obtain the required level based on a well-known signal available. The PID controller then only takes care of the smaller part of the control, necessary because of unknown characters. The standard feed-forward factor in parameter **7-38 Process PID Feed Forward Factor** is always related to the reference, whereas parameter **7-51 Process PID Feed Fwd Gain** has more options. In winder applications, the feed-forward factor is typically the line speed of the system.

7-52 Process PID Feed Fwd Ramp Up

Default value:	0.01 s	Parameter type:	Range, 0.01 - 10 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Controls the dynamics of the feed-forward signal when ramping up.

7-53 Process PID Feed Fwd Ramp Down

Default value:	0.01 s	Parameter type:	Range, 0.01 - 10 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Controls the dynamics of the feed-forward signal when ramping down.

7-56 Process PID Ref. Filter Time

Default value:	0.001 s	Parameter type:	Range, 0.001 - 1 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Set a time constant for the reference first-order low-pass filter. The low-pass filter improves steady-state performance and dampens oscillations on the reference/feedback signals. However, severe filtering can be detrimental to dynamic performance.

7-57 Process PID Fb. Filter Time

Default value:	0.001 s	Parameter type:	Range, 0.001 - 1 s

Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Set a time constant for the feedback first-order low-pass filter. The low-pass filter improves steady-state performance and dampens oscillations on the reference/feedback signals. However, severe filtering can worsen dynamic performance.

6.9.9 7-7* Speed PID Ctrl. II

7-74 Speed Dependent Proportional Gain

Default value:	0	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True

Specify the proportional gain values for the speed controller at different speeds. The controller will interpolate between these values based on the speed points defined in parameter *7-75 Speed Dep. P-Gain Associated Speed*.

7-75 Speed Dep. P-Gain Associated Speed

Default value:	0%	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Define the speed breakpoints (as a percentage of nominal speed) where the proportional gain values from parameter *7-74 Speed Dependent Proportional Gain* should apply. The controller will interpolate between these points.

7-76 Speed PID Feed Forward Filter Time

Default value:	0.0 ms	Parameter type:	Range, 0.0 - 100.0 ms
Setup:	All setups	Conversion index:	-4
Data type:	Uint16	Change during operation:	True

Set a time constant for the speed control feed forward low-pass filter. The low-pass filter improves steady-state performance and dampens noise or oscillations on the reference signal.

7-77 Speed PID Damping Gain

Default value:	0.000 ms	Parameter type:	Range, 0.000 - 1.000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

The damping gain works on the speed error, similar to the proportional gain. However, before it is used, the error goes through a bandpass filter controlled by parameters *7-78 Speed PID Damping Time Const Low* and *7-79 Speed PID Damping Time Const High*.

7-78 Speed PID Damping Gain Const Low

Default value:	50 ms	Parameter type:	Range, 5 - 500 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

This parameter sets the low time constant, which determines the high-frequency cutoff of the bandpass filter used by the damping gain in parameter **7-77 Speed PID Damping Gain**.

7-79 Speed PID Damping Time Const High

Default value:	2000 ms	Parameter type:	Range, 200 - 20000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

This parameter sets the high time constant, which determines the low-frequency cutoff of the bandpass filter used by the damping gain in parameter **7-77 Speed PID Damping Gain**.

6.9.10 7-9* Position PI Ctrl.

7-90 Position PI Feedback Source

Default value:	[0] Motor feedb. P1-02	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available with software version 48.0X or newer.

Select the feedback source for the position PI controller.

Option	Name	Description
[0]*	Motor feedb. P1-02	Use the feedback source selected as motor feedback in parameter 1-02 Flux Motor Feedback Source .
[1]	24V encoder 32/33	Single signal generated from 24 V High Threshold Logic (HTL) encoder connected to terminals 32 and 33. Configure the 24 V encoder interface in parameter group 5.7* 24V Encoder Input . Program terminals 32/33 to [0] No operation .
[2]	MCB 102	This is only available for VLT® Encoder Option MCB 102. Configure the encoder interface in parameter groups 17-0* Encoder Interface , 17-1* Inc. Enc. Interface , and 17-2* Abs. Enc. Interface .
[3]	MCB 103	This is only available for VLT® Resolver Option MCB 103. Configure the resolver interface in parameter group 17-5* Resolver Interface .
[4]	MCO encoder 1 X56	The MCO encoder 1 X56 is only available with motion control options MCO 305, MCO 350, and MCO 351. Configure the encoder interface in parameter group 32-3* Encoder 1 .
[5]	MCO encoder 2 X55	The MCO encoder 2 X55 is only available with motion control options MCO 305, MCO 350, and MCO 351. Configure the encoder interface in parameter group 32-0* Encoder 2 .
[6]	Analog input 53	
[7]	Analog input 54	
[8]	Frequency input 29	
[9]	Frequency input 33	

Option	Name	Description
[11]	MCB 15X	
[12]	MCB 102 absolute	The option is only available for VLT® Encoder Option MCB 102 with version 4.00 and newer and when parameter 17-00 Encoders Connected is set to [1] Two Encoders .
[13]	24V encoder 27/29	Single signal generated from 24 V High Threshold Logic (HTL) encoder connected to terminals 27 and 29. Configure the 24 V encoder interface in parameter group 5.7* 24V Encoder Input . Program terminals 27/29 to [0] No operation .
[20]	None	No position feedback is received. This means that actual position remains unchanged. For example, when the drive is used for operating a 2nd motor without change in position via setup change.

7-91 Position PI Droop

Default value:	0.0°	Parameter type:	Range, 0.0 - 360.0°
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available with software version 48.4X or newer.

Enter the motor angle deviation at 100% load in a load sharing system. The system is 2 or more mechanically connected motors in positioning or synchronization mode. In positioning mode, configure parameter **7-01 Speed PID Droop** to allow a speed deviation.

7-92 Position PI Proportional Gain

Default value:	0.0150	Parameter type:	Range, 0.000 - 1.000
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True



NOTE: This parameter is only available with software version 48.0X or newer.

Enter the proportional gain for the position PI controller. Increasing the gain value makes the control more dynamic but less stable. 0=Off.

7-93 Position PI Integral Time

Default value:	20000.0 ms	Parameter type:	Range, 1.0 - 20000.0 ms
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True



NOTE: This parameter is only available with software version 48.0X or newer.

Enter the integral time for the position PI controller. Decreasing the value makes the control more dynamic but less stable. 20000=Off.

7-94 Position PI Feedback Scale Numerator

Default value:	1	Parameter type:	Range, -2000000000 - 2000000000
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available with software version 48.0X or newer.

This parameter is the numerator in the equation which defines the gear ratio between the motor and the feedback device when the feedback device is not mounted on the motor shaft. Encoder revolutions = $\frac{\text{Par.7-94}}{\text{Par.7-95}} \times \text{Motor revolutions}$

7-95 Position PI Feedback Scale Denominator

Default value:	1	Parameter type:	Range, -2000000000 - 2000000000
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available with software version 48.0X or newer.

See parameter **7-94 Position PI Feedback Scale Numerator**.

7-97 Position PI Max Speed Above Master

Default value:	100 RPM	Parameter type:	Range, 0 - 1500 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available with software version 48.0X.

Enter the value by which the follower speed is allowed to exceed the actual master speed. Valid only in synchronization mode.

7-98 Position PI Feed Forward Factor

Default value:	98%	Parameter type:	Range, 0 - 110%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available with software version 48.0X or newer.

Enter the amount by which the speed reference calculated by the profile generator is allowed to bypass the position PI controller.

7-99 Position PI Minimum Ramp Time

Default value:	0.010 s	Parameter type:	Range, 0.000 - 3600.000 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True



NOTE: This parameter is only available with software version 48.0X or newer.

Enter the shortest ramp time for the output of the Position PI controller. Use this parameter to limit acceleration when correcting large position deviations, for example when starting synchronization with a running master or after recovering from an overload situation during positioning.

6.10 Parameter Group 8-** Communications and Options

6.10.1 8-0* General Settings

8-01 Control Site

Default value:	[0] Digital and ctrl. word	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The setting in this parameter overrides the settings in parameter **8-50 Coasting Select** to parameter **8-56 Preset Reference Select**.

Option	Name	Description
[0]*	Digital and ctrl.word	Use both digital input and control word.
[1]	Digital only	Use digital inputs only.
[2]	Controlword only	Use control word only.

8-02 Control Word Source

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the source of the control word: 1 of 2 serial interfaces or 4 installed options. During initial power-up, the drive automatically sets this parameter to **[3] Option A** if it detects a valid fieldbus option installed in slot A. When the option is removed, the drive detects a configuration change, sets parameter **8-02 Control Word Source** to default setting **[1] FC RS485**, and trips. If an option is installed after initial power-up, the setting of parameter **8-02 Control Word Source** does not change, but the drive trips and shows: *Alarm 67, Option Changed*. When retrofitting a bus option into a drive that did not have a bus option installed earlier, change the control to bus-based. This change is required for safety reasons to avoid an unintended change.

Option	Name	Description
[0]	None	Control via serial communication is disabled.
[1]	FC RS485	Control via RS-485 terminals 68/69 on the control card.
[2]	FC USB	Control via USB on the control card.
[3]	Option A	Control via option A.

Option	Name	Description
[4]	Option B	Control via option B.
[5]	Option C0	Control via option C0.
[6]	Option C1	Control via option C1.
[30]	External Can	Internal
[35]	Option A fast	NOTE: This option is only available in FC 302. Same as option [3] Option A. The reference is transferred faster and without jitter, which ensures more stability and dynamic control. Moreover, all other references are ignored, which means that the drive is controlled by the A-option reference only.
[37]	Option C0 fast	NOTE: This option is only available in FC 302. Same as option [5] Option C0. The reference is transferred faster and without jitter, which ensures more stability and dynamic control. Moreover, all other references are ignored, which means that the drive is controlled by the C-option reference only.

8-03 Control Word Timeout Time

Default value:	Size related	Parameter type:	Range, 0.1 - 18000 s
Setup:	1 setup	Conversion index:	-1
Data type:	Uint32	Change during operation:	True

Enter the maximum time expected to pass between the reception of 2 consecutive telegrams. If this time is exceeded, it indicates that the serial communication has stopped. The function selected in parameter **8-04 Control Word Timeout Function** is then carried out. A valid control word triggers the timeout counter.

8-04 Control Word Timeout Function

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the timeout function. The timeout function activates when the control word is not updated within the time period specified in parameter **8-03 Control Word Timeout Time**.



NOTE:

To change the setup after a timeout, configure as follows:

1. Set parameter **0-10 Active Set-up** to [9] **Multi setup**.
2. Select the relevant link in parameter **0-12 This Set-up Linked to**.

Option	Name	Description
[0]	Off	Resumes control via fieldbus (fieldbus or standard), using the most recent control word.
[1]	Freeze output	Freezes output frequency until communication resumes.
[2]	Stop	Stops with auto restart when communication resumes.
[3]	Jogging	Runs the motor at jog frequency until communication resumes.
[4]	Max. speed	Runs the motor at maximum frequency until communication resumes.
[5]	Stop and trip	Stops the motor, then resets the drive to restart: • Via the fieldbus. • Via [Reset]. • Via a digital input.
[6]	Qstop and trip	Stops the motor with the quick stop ramp (parameter 3-81 Quick Stop Ramp Time). Perform a reset to restart the drive.
[7]	Select setup 1	Changes the setup after a control word timeout. If communication resumes after a timeout, parameter 8-05 End-of-Timeout Function either resumes the setup used before the timeout, or retains the setup endorsed by the timeout function.
[8]	Select setup 2	See [7] Select set-up 1 .
[9]	Select setup 3	See [7] Select set-up 1 .
[10]	Select setup 4	See [7] Select set-up 1 .
[26]	Trip	Only available with VLT® Motion Controller Option MCO 302.

8-05 End-of-Timeout Function

Default value:	[1] Resume set-up	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the action after receiving a valid control word following a timeout. This parameter is active only when parameter **8-04 Control Word Timeout Function** is set to:

- [7] **Setup 1**
- [8] **Setup 2**
- [9] **Setup 3**
- [10] **Setup 4**

Option	Name	Description
[0]	Hold set-up	Retains the setup selected in parameter 8-04 Control Word Timeout Function and shows a warning until parameter 8-06 Reset Control Word Timeout toggles. Then the drive resumes its original setup.
[1]*	Resume setup	Resumes the setup that was active before the timeout.

8-06 Reset Control Word Timeout

Default value:	[0] Do not reset	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter is active only when **[0] Hold set-up** has been selected in parameter **8-05 End-of-Timeout Function**.

Option	Name	Description
[0]*	Do not reset	Retains the setup specified in parameter 8-04 Control Word Timeout Function , following a control word timeout.
[1]	Do reset	Restores the drive to the original setup following a control word timeout. The drive resets and then immediately reverts to the [0] Do not reset setting.

8-07 Diagnosis Trigger

Default value:	[0] Disable	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter has no function for DeviceNet.

Option	Name	Description
[0]*	Disable	
[1]	Trigger on alarms	
[2]	Trigger alarm/warn.	

8-08 Readout Filtering

Default value:	–	Parameter type:	Option, Array [1]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use this function if the speed feedback value readouts on the fieldbus fluctuate. Select **[1] Motor Data LP-Filter** if the function is required. A power cycle is required for changes to take effect.

Option	Name	Description
[0]	Motor data Std-Filt.	Normal fieldbus readouts.
[1]	Motor data LP-Filter	Filtered fieldbus readouts of the following parameters: - Parameter 16-10 Power [kW] - Parameter 16-11 Power [hp] - Parameter 16-12 Motor Voltage - Parameter 16-14 Motor current - Parameter 16-16 Torque [Nm] - Parameter 16-17 Speed [RPM] - Parameter 16-22 Torque [%] - Parameter 16-25 Torque [Nm] High

6.10.2 8-1* Ctrl. Word Settings

8-10 Control Word Profile

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the interpretation of the control and status words corresponding to the installed fieldbus. Only the selections valid for the fieldbus installed in slot A are visible in the LCP display. For guidelines in selection of **[0] FC profile** and **[1] PROFIdrive profile**, refer to the product-specific design guide. For more guidelines in the selection of **[1] PROFIdrive profile**, refer to the Installation Guide for the installed fieldbus.

Option	Name	Description
[0]	FC profile	
[1]	PROFIdrive profile	
[3]	FC motion profile	 NOTE: This option is only available with software version 48.0X. Assigns motion-specific functions to various control and status word bits. This option is available when [9] Positioning or [10] Synchronization is selected in parameter 1-00 Configuration Mode .
[5]	ODVA	
[7]	CANopen DSP 402	
[8]	MCO	
[22]	PROFIdrive v4_2 profile	
[24]	VIK-NAMUR	

8-13 Configurable Status Word STW

Default value:	–	Parameter type:	Option, Array [16]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the interpretation of the control and status words corresponding to the installed fieldbus. Only the selections valid for the fieldbus installed in slot A are visible in the LCP display. For more guidelines in the selection of **[1] PROFIdrive profile**, refer to the installation guide for the installed fieldbus.

Option	Name	Description
[0]	No function	The input is always low.
[1]	Profile default	Dependent on the profile set in parameter 8-10 Control Profile .
[2]	Alarm 68 Only	The input goes high whenever <i>Alarm 68 Safe Stop Activated</i> is active and goes low whenever <i>Alarm 68 Safe Stop Activated</i> is not active.
[3]	Trip excl Alarm 68	
[4]	Position error	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. The position is outside its limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position .
[5]	Position limit	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. The position error exceeds the value in parameter 4-71 Maximum Position for the time set in parameter 4-72 Position Error Timeout .
[6]	Touch on target	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Target position is reached in touch probe position mode.
[7]	Touch activated	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Touch probe positioning is active. The drive monitors the touch probe sensor input.
[8]	Touch sensor found	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer. The touch sensor has been detected.
[9]	Vir. master on ref	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer. The virtual master is running on the set reference.
[10]	T18DI status	The bit indicates the status of terminal 18. 0 indicates that the terminal is low. 1 indicates that the terminal is high.
[11]	T19DI status	The bit indicates the status of terminal 19. 0 indicates that the terminal is low. 1 indicates that the terminal is high.
[12]	T27DI status	The bit indicates the status of terminal 27. 0 indicates that the terminal is low. 1 indicates that the terminal is high.
[13]	T29DI status	The bit indicates the status of terminal 29. 0 indicates that the terminal is low. 1 indicates that the terminal is high.

Option	Name	Description
[14]	T32DI status	The bit indicates the status of terminal 32. 0 indicates that the terminal is low. 1 indicates that the terminal is high.
[15]	T33DI status	The bit indicates the status of terminal 33. 0 indicates that the terminal is low. 1 indicates that the terminal is high.
[16]	T37DI status	The input goes high whenever T37 has 0 V and goes low whenever T37 has 24 V.
[17]	X30/2 DI status	
[18]	X30/3 DI status	
[19]	X30/4 DI status	
[20]	CTW timeout toggle inverse	
[21]	Thermal warning	The thermal warning turns on when the temperature exceeds the limit in the motor, drive, brake resistor, or thermistor.
[22]	Execution distance extended	 NOTE: This option is only available in FC 302 with IMC software version 48.95 or newer. Indicates that the offset execution distance (set in parameter 17-95 Offset Execution Distance) has been extended due to speed/ramp limitation.
[29]	Protection mode	
[30]	Brake fault (IGBT)	Output logic 1 when the brake IGBT is short-circuited. Use this function to protect the drive if there is a fault on the brake modules. Use the output/relay to cut out the main voltage from the drive.
[40]	Out of ref range	
[49]	Derate active	
[54]	Running	
[59]	On reference	
[60]	Comparator 0	See parameter group 13-1* Comparators . If comparator 0 is evaluated as true, the output goes high. Otherwise, it is low.
[61]	Comparator 1	See parameter group 13-1* Comparators . If comparator 1 is evaluated as true, the output goes high. Otherwise, it is low.
[62]	Comparator 2	See parameter group 13-1* Comparators . If comparator 2 is evaluated as true, the output goes high. Otherwise, it is low.
[63]	Comparator 3	See parameter group 13-1* Comparators . If comparator 3 is evaluated as true, the output goes high. Otherwise, it is low.
[64]	Comparator 4	See parameter group 13-1* Comparators . If comparator 4 is evaluated as true, the output goes high. Otherwise, it is low.
[65]	Comparator 5	See parameter group 13-1* Comparators . If comparator 5 is evaluated as true, the output goes high. Otherwise, it is low.
[66]	Comparator 6	See parameter group 13-1* Comparators . If comparator 6 is evaluated as true, the output goes high. Otherwise, it is low.

Option	Name	Description
[67]	Comparator 7	See parameter group 13-1* Comparators . If comparator 7 is evaluated as true, the output goes high. Otherwise, it is low.
[68]	Comparator 8	See parameter group 13-1* Comparators . If comparator 8 is evaluated as true, the output goes high. Otherwise, it is low.
[69]	Comparator 9	See parameter group 13-1* Comparators . If comparator 9 is evaluated as true, the output goes high. Otherwise, it is low.
[70]	Logic rule 0	See parameter group 13-4* Logic Rules . If logic rule 0 is evaluated as true, the output goes high. Otherwise, it is low.
[71]	Logic rule 1	See parameter group 13-4* Logic Rules . If logic rule 1 is evaluated as true, the output goes high. Otherwise, it is low.
[72]	Logic rule 2	See parameter group 13-4* Logic Rules . If logic rule 2 is evaluated as true, the output goes high. Otherwise, it is low.
[73]	Logic rule 3	See parameter group 13-4* Logic Rules . If logic rule 3 is evaluated as true, the output goes high. Otherwise, it is low.
[74]	Logic rule 4	See parameter group 13-4* Logic Rules . If logic rule 4 is evaluated as true, the output goes high. Otherwise, it is low.
[75]	Logic rule 5	See parameter group 13-4* Logic Rules . If logic rule 5 is evaluated as true, the output goes high. Otherwise, it is low.
[76]	Logic rule 6	See parameter group 13-4* Logic Rules . If logic rule 6 is evaluated as true, the output goes high. Otherwise, it is low.
[77]	Logic rule 7	See parameter group 13-4* Logic Rules . If logic rule 7 is evaluated as true, the output goes high. Otherwise, it is low.
[78]	Logic rule 8	See parameter group 13-4* Logic Rules . If logic rule 8 is evaluated as true, the output goes high. Otherwise, it is low.
[79]	Logic rule 9	See parameter group 13-4* Logic Rules . If logic rule 9 is evaluated as true, the output goes high. Otherwise, it is low.
[80]	SL digital out A	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [38] Set digital out A high is executed. The output goes low whenever the smart logic action [32] Set digital out A low is executed.
[81]	SL digital out B	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [39] Set digital out B high is executed. The output goes low whenever the smart logic action [33] Set digital out B low is executed.
[82]	SL digital out C	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [40] Set digital out C high is executed. The output goes low whenever the smart logic action [34] Set digital out C low is executed.
[83]	SL digital out D	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [41] Set digital out D high is executed. The output goes low whenever the smart logic action [35] Set digital out D low is executed.

Option	Name	Description
[84]	SL digital out E	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [42] Set digital out E high is executed. The output goes low whenever the smart logic action [36] Set digital out E low is executed.
[85]	SL digital out F	See parameter 13-52 SL Controller Action . The output goes high whenever the smart logic action [43] Set digital out F high is executed. The output goes low whenever the smart logic action [37] Set digital out F low is executed.
[86]	ATEX ETR cur. alarm	
[87]	ATEX ETR freq. alarm	
[88]	ATEX ETR cur. warning	
[89]	ATEX ETR freq. warning	
[90]	Safe function active	
[91]	Safe opt. reset. req.	
[92]	IGBT-cooling	
[96]	Reverse after ramp	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer. Indicates if the direction of rotation should be reversed. Depends on whether the speed reference is positive or negative after the ramp specified in parameter 16-48 Speed Ref. After Ramp [RPM].
[100]	Sensor 1 S2	
[101]	Sensor 2 S2	
[102]	Sensor 3 S2	
[103]	Sensor 4 S2	
[104]	Sensor 1	
[105]	Sensor 2	
[106]	Sensor 3	
[107]	Sensor 4	
[108]	Sensor 1 thld at max/min	
[109]	Sensor 2 thld at max/min	
[110]	Sensor 3 thld at max/min	
[111]	Sensor 4 thld at max/min	
[112]	Stator fault	
[113]	Stator fault 2	
[114]	Stator fault thld	
[115]	Load envelope	
[116]	Load envelope 2	
[117]	Load envelope low	
[118]	Load envelope 2 low	

Option	Name	Description
[119]	Load envelope thld	
[120]	Baseline run active	
[121]	Cavitation	
[122]	Cavitation S2	
[123]	Cavitation thld at max/min	
[181]	Prev. maintenance	
[196]	Emcy mode is active	The drive is operating in emergency mode. See parameter group 24-0* Emergency Mode .
[197]	Emcy mode was active	The drive has been operating in emergency mode.
[198]	Emcy mode limits	During emergency mode operation, 1 of the critical alarms has been activated and suppressed by emergency mode. This may lead to reduced drive performance and expected operation lifetime before service is required.
[200]	User defined alerts	
[210]	Pos. set acknowledge	 NOTE: This option is only available in FC 302 with IMC software version 48.9X or newer. Acknowledge activation of the set target position.
[231]	In power lim. mot.	 NOTE: This option is only available in FC 302. See parameter group 4-8* Power Limit. Use this option in motor mode only.
[232]	In power lim. gen.	 NOTE: This option is only available in FC 302. See parameter group 4-8* Power Limit. Use this option in generating mode only.
[233]	In power limit	 NOTE: This option is only available in FC 302. See parameter group 4-8* Power Limit. Use this option in both motor and generating modes.
[234]	Emcy m. OPR unexpected	Emergency mode is not operating as expected, for example, live zero monitoring on an analog input is activated.
[254]	Testing emcy mode	Emergency mode was activated in a special test mode where the drive stops on all alarms.

8-14 Configurable Control Word CTW

Default value:	[1] Profile default	Parameter type:	Option, Array [16]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

This is an array parameter with 16 elements, 1 element for each bit in range 0–15. Each of the bits can be configured to any of the following options.

Option	Name	Description
[0]	None	The drive ignores the information in this bit.
[1]*	Profile default	Dependent on the profile set in parameter 8-10 Control Profile .
[2]	CTW valid, active low	If set to 1, the drive ignores the remaining bits of the control word.
[3]	Safe option reset	This function is only available in bits 12–15 of the control word if a safety option is mounted in the drive. The reset is executed on a 0⇒1 transition and resets the safety option as set in parameter 42-24 Restart behavior .
[4]	PID error inverse	Inverts the resulting error from the process PID controller. Available only if parameter 1-00 Configuration Mode is set to [6] Surface Winder , [7] Extended PID Speed OL , or [8] Extended PID Speed CL .
[5]	PID reset I part	Resets the I-part of the process PID controller. Equivalent to parameter 7-40 Process PID I-part Reset . Available only if parameter 1-00 Configuration Mode is set to [6] Surface Winder , [7] Extended PID Speed OL , or [8] Extended PID Speed CL .
[6]	PID enable	Enables the extended process PID controller. Equivalent to parameter 7-50 Process PID Extended PID . Available only if parameter 1-00 Configuration Mode is set to [6] Surface Winder , [7] Extended PID Speed OL , or [8] Extended PID Speed CL .
[7]	External interlock	
[10]	Bit 10 = 0>CTW timeout	
[11]	Start homing	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Starts the homing function selected in parameter 17-80 Homing Function. Must remain high until homing is done, otherwise homing is aborted.
[12]	Activate touch	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Activates monitoring of the touch sensor input.
[13]	Sync. to pos mode	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Select positioning in synchronization mode.
[14]	Ramp 2	NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer. Select between ramp 1 (parameter group 3-4* Ramp 1) and ramp 2 (parameter group 3-5* Ramp 2).
[15]	Relay 1	Control relay 1.
[16]	Relay 2	Control relay 1.

Option	Name	Description
[17]	Speed mode	NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Select the speed mode when [9] Positioning or [10] Synchronization is selected in parameter 1-00 Configuration Mode. Speed reference is set by reference resource 1 or fieldbus REF1 relative to parameter 3-03 Maximum Reference.
[18]	Enable vir. master	NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Enable the signal for the virtual master function. The option is applicable when [10] Synchronization is selected in parameter 1-00 Configuration Mode.
[19]	Enable mast. offset	NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer. Activates the master offset selected in parameter 3-26 Master Offset when parameter 17-93 Master Offset Selection has a selection from [1] Absolute to [5] Relative Touch Sensor.
[20]	Control word toggle command	Changes the sign of the set target position. For example, if the set target is 1000, the activation of this option changes the value to -1000.
[21]	Target inverse	NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer. Changes the sign of the set target position. For example, if the set target is 1000, the activation of this option changes the value to -1000.
[22]	Digital out 27	
[23]	Digital out 29	
[24]	Digital out X30/6	
[25]	Digital out X30/7	
[26]	Home sensor	NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer. NOTE: Accuracy of the home position depends on the delay in transferring the signals. The home sensor is connected via fieldbus master.

Option	Name	Description
[27]	Touch sensor	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.  NOTE: Accuracy of the home position depends on the delay in transferring the signals. The touch sensor is connected via fieldbus master.
[28]	Position vir. master	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer. Activates position-controlled virtual master when [9] Positioning or [10] Synchronization is selected in parameter 1-00 Configuration Mode. When the option is selected, the following occurs: • Target position is set by Fieldbus Pos Ref or preset target is as defined in parameter 3-20 Preset Target. • Speed is set relative to parameter 3-27 Virtual Master Max Ref by the source selected in parameter 3-15 Reference Resource 1 or fieldbus REF1. • Acceleration and deceleration are set as defined in parameter group 3-6* Ramp 3.
[29]	Set master home	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer. Sets the actual master position as defined in parameter 17-88 Master Home Position.
[30]	Set vir. mas. pos. to actual	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer. Bit for setting the virtual master position = the actual follower position. This is needed for setting the correct starting position for position-controlled virtual master ensuring that the virtual master ensuring that the virtual master position is aligned with the physical position of the follower.
[31]	Activate CAM table	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer. Signal for activating a new CAM table while running with bumpless transfer.
[32]	Halt	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[33]	Bit 10 = 0 > CTW TO always	

Option	Name	Description
[34]	Activate CAM cycles	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer. Activates the number of CAM cycles set in parameter 17-97 Number of CAM Cycles.
[78]	Reset preventive maintenance word	
[94]	Light load detection	Use this option to ensure drive runs in the direction which requires least energy (UPS capacity), during an emergency.
[95]	Evacuation mode	Use this function to operate the drive at reduced DC voltage for evacuating people in case of power failure.
[189]	Emergency mode	
[190]	Emcy mode ref bit 0	Enables a choice between 1 of the 8 preset references.
[191]	Emcy mode ref bit 1	Enables a choice between 1 of the 8 preset references.
[192]	Emcy mode ref bit 2	Enables a choice between 1 of the 8 preset references.
[195]	Test emcy mode	Emergency mode is activated in a special test mode where the drive stops on all alarms.
[231]	Power limit mot.	NOTE: This option is only available in FC 302. See parameter group 4-8* Power Limit. Use this option in the motor mode only.
[232]	Power limit gen.	NOTE: This option is only available in FC 302. See parameter group 4-8* Power Limit. Use this option in the generating mode only.
[233]	Power limit both	NOTE: This option is only available in FC 302. See parameter group 4-8* Power Limit. Use this option in both the motor and the generating modes.
[234]	Light load+evacuation	NOTE: This option is only available in FC 302. Use this option to ensure that the drive runs in the direction which requires least energy (UPS capacity), during an emergency and to operate the drive at reduced DC-voltage for evacuating people in case of power failure.
[235]	Setup bit 0	
[236]	Setup bit 1	

8-17 Configurable Alarm and Warningword

Default value:	–	Parameter type:	Option, Array [16]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

The configurable alarm and warning word has 16 bits (0–15). Each of those bits can be configured to any of the following options.

Option	Name	Description
[0]	Off	
[1]	10 Volts low warning	
[2]	Live zero warning	
[3]	No motor warning	
[4]	Mains phase loss warning	
[5]	DC link voltage high warning	
[6]	DC link voltage low warning	
[7]	DC overvoltage warning	
[8]	DC undervoltage warning	
[9]	Inverter overloaded warning	
[10]	Motor ETR overtemp warning	
[11]	Motor thermistor overtemp warning	
[12]	Torque limit warning	
[13]	Over current warning	
[14]	Earth fault warning	
[17]	Controlword timeout warning	
[19]	Discharge temp high warning	
[22]	Hoist mech brake warning	
[23]	Internal fans warning	
[24]	External fans warning	
[25]	Brake resistor short circuit warning	
[26]	Brake powerlimit warning	
[27]	Brake chopper short circuit warning	
[28]	Brake check warning	
[29]	Heatsink temperature warning	
[30]	Motor phase U warning	
[31]	Motor phase V warning	
[32]	Motor phase W warning	
[34]	Fieldbus communication warning	
[36]	Mains failure warning	
[40]	T27 overload warning	
[41]	T29 overload warning	
[45]	Earth fault 2 warning	
[47]	24V supply low warning	
[58]	AMA internal fault warning	
[59]	Current limit warning	

Option	Name	Description
[60]	External interlock warning	
[61]	Feedback error warning	
[62]	Frequency max warning	
[64]	Voltage limit warning	
[65]	Controlboard overtemp warning	
[66]	Heatsink temp low warning	
[68]	Safe stop warning	
[73]	Safe stop autorestart warning	
[76]	Power unit setup warning	
[77]	Reduced powermode warning	
[78]	Tracking error warning	
[89]	Mech brake sliding warning	
[163]	ATEX ETR cur limit warning	
[165]	ATEX ETR freq limit warning	
[10002]	Live zero error alarm	
[10003]	No motor alarm	
[10004]	Mains phase loss alarm	
[10007]	DC overvoltage alarm	
[10008]	DC undervoltage alarm	
[10009]	Inverter overload alarm	
[10010]	ETR overtemperature alarm	
[10011]	Thermistor overtemp alarm	
[10012]	Torque limit alarm	
[10013]	Overcurrent alarm	
[10014]	Earth fault alarm	
[10016]	Short circuit alarm	
[10017]	CTW timeout alarm	
[10022]	Hoist brake alarm	
[10026]	Brake powerlimit alarm	
[10027]	Brakechopper shortcircuit alarm	
[10028]	Brake check alarm	
[10029]	Heatsink temp alarm	
[10030]	Phase U missing alarm	
[10031]	Phase V missing alarm	
[10032]	Phase W missing alarm	
[10033]	Inrush fault alarm	
[10034]	Fieldbus com fault alarm	

Option	Name	Description
[10035]	Option fault alarm	
[10036]	Mains failure alarm	
[10037]	Phase imbalance alarm	
[10038]	Internal fault	
[10039]	Heatsink sensor alarm	
[10045]	Earth fault 2 alarm	
[10046]	Powercard supply alarm	
[10047]	24V supply alarm	
[10048]	1.8V supply low alarm	
[10049]	Speed limit alarm	
[10060]	Ext interlock alarm	
[10061]	Feedback error alarm	
[10063]	Mech brake low alarm	
[10065]	Controlboard overtemp alarm	
[10067]	Option config changed alarm	
[10068]	Safe stop alarm	
[10069]	Powercard temp alarm	
[10073]	Safestop auto restart alarm	
[10074]	PTC thermistor alarm	
[10075]	Illegal profile alarm	
[10078]	Tracking error alarm	
[10079]	Illegal PS config alarm	
[10081]	CSIV corrupt alarm	
[10082]	CSIV param error alarm	
[10084]	No safety option alarm	
[10090]	Feedback monitor alarm	
[10091]	AI54 settings alarm	
[10129]	I2C comm failure	
[10164]	ATEX ETR current lim alarm	
[10166]	ATEX ETR freq limit alarm	
[10201]	Misc. alarm	

8-18 Add Fieldbus ref. to Reference

Default value:	[1] Yes	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	Yes

This parameter specifies whether to use the fieldbus reference in reference calculations.

Option	Name	Description
[0]	No	The fieldbus reference is ignored, and only the fieldbus control word is used for reference calculations.
[1]*	Yes	The fieldbus reference is used for reference calculations.

8-19 Product Code

Default value:	Size related	Parameter type:	Array [2]
Setup:	1 setup	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Select 0 to read out the actual fieldbus product code according to the mounted fieldbus option. Select 1 to read out the actual vendor ID.

6.10.3 8-2* Counters

8-20 Invalid Memory Write Counter

Default value:	0 N/A	Parameter type:	Range, 0 - 65535
Setup:	1 setup	Conversion index:	–
Data type:	Uint16	Change during operation:	True

The error counter is incremented each time the Ethernet-based fieldbus options writes to an invalid memory.

6.10.4 8-3* FC Port Settings

8-30 Protocol

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the protocol to be used. Changing protocol is not effective until after powering off the drive.

Option	Name	Description
[0]	FC	
[1]	FC MC	
[2]	Modbus RTU	

8-31 Address

Default value:	1	Parameter type:	Range, 1 - 247
Setup:	1 setup	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the address for the drive (standard) port. Valid range: Depends on the selected protocol.

8-32 FC Port Baud Rate

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	2400 Baud	Baud rate selection for the FC (standard) port.
[1]	4800 Baud	
[2]	9600 Baud	
[3]	19200 Baud	
[4]	38400 Baud	
[5]	57600 Baud	
[6]	76800 Baud	
[7]	115200 Baud	

8-33 Parity/Stop Bits

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Even parity, 1 stop bit	
[1]	Odd parity, 1 stop bit	
[2]	No parity, 1 stop bit	
[3]	No parity, 2 stop bits	

8-34 Estimated Cycle Time

Default value:	0 ms	Parameter type:	Range, 0 - 1000000 ms
Setup:	2 setups	Conversion:	-3
Data type:	Uint32	Change during operation:	True

In noisy environments, the interface may be blocked due to overload or bad frames. This parameter specifies the time between 2 consecutive frames on the network. If the interface does not detect valid frames in that time, it flushes the receive buffer.

8-35 Minimum Response Delay

Default value:	10 ms	Parameter type:	Range, 1 - 10000 ms
Setup:	1 setup	Conversion index:	-3
Data type:	Unt16	Change during operation:	True

Specify the minimum delay time between receiving a request and transmitting a response. This is used for overcoming modem turnaround delays.

8-36 Max Response Delay

Default value:	Size related	Parameter type:	Range, 11 - 10001 ms
Setup:	1 setup	Conversion index:	-3
Data type:	UInt16	Change during operation:	True

Specify the maximum allowed delay time between transmitting a request and receiving a response. If a response from the drive exceeds the time setting, it is discarded.

8-37 Max Inter-Char Delay

Default value:	Size related	Parameter type:	Range, 0.00 - 35.00 ms
Setup:	1 setup	Conversion index:	-5
Data type:	UInt16	Change during operation:	True

Specify the maximum allowed time interval between receipt of 2 bytes. This parameter activates timeout if transmission is interrupted. This parameter is active only when parameter **8-30 Protocol** is set to **[1] FC MC protocol**.

8-39 Protocol/Profile Firmware Version

Default value:	0	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	0
Data type:	VisStr [10]	Change during operation:	False

This parameter shows the firmware revision as follows:

Index	Name
[0]	FC
[1]	Modbus
[2]	Metasys N2
[3]	FLN
[4]	BACnet
[5]	Future native protocol
[6]	PROFIdrive profile
[7]	DS402 profile

6.10.5 8-4* FC MC Protocol Select

8-40 Telegram Selection

Default value:	[1] Standard telegram 1	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Enables use of freely configurable telegrams or standard telegrams for the FC port.

Option	Name	Description
[1]*	Standard telegram 1	
[20]	Standard telegram 20	
[100]	None	
[101]	PPO 1	
[102]	PPO 2	
[103]	PPO 3	
[104]	PPO 4	
[105]	PPO 5	
[106]	PPO 6	
[107]	PPO 7	
[108]	PPO 8	
[109]	PPO 9	
[200]	Custom telegram 1	
[202]	Custom telegram 3	

8-41 Parameters for Signals

Default value:	[0] None	Parameter type:	Readout, Array [1000]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	False

Option	Name	Description
[0]*	None	
[15]	Readout: actual setup	
[109]	Mode of operation	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[302]	Minimum reference	
[303]	Maximum reference	
[311]	Jog speed [Hz]	
[312]	Catch up/slow down value	
[319]	Jog speed [RPM]	
[321]	Touch target	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[322]	Master scale numerator	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.

Option	Name	Description
[323]	Master scale denominator	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[326]	Master offset	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[328]	Master offset speed ref	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[330]	Min. speed ramp time	
[341]	Ramp 1 ramp up time	
[342]	Ramp 1 ramp down time	
[351]	Ramp 2 ramp up time	
[352]	Ramp 2 ramp down time	
[361]	Ramp 3 ramp up time	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[362]	Ramp 3 ramp down time	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[380]	Jog/homing ramp time	
[381]	Quick stop ramp time	
[411]	Motor speed low limit [RPM]	
[412]	Motor speed low limit [Hz]	
[413]	Motor speed high limit [RPM]	
[414]	Motor speed high limit [Hz]	
[416]	Torque limit motor mode	
[417]	Torque limit generator mode	
[482]	Power limit motor mode	
[483]	Power limit generator mode	
[491]	Positive speed limit [RPM]	
[492]	Positive speed limit [Hz]	
[493]	Negative speed limit [RPM]	
[494]	Negative speed limit [Hz]	
[495]	Positive torque limit	
[496]	Negative torque limit	
[553]	Term. 29 high ref./feedb. value	
[558]	Term. 33 high ref./feedb. value	

Option	Name	Description
[590]	Digital & relay bus control	
[593]	Pulse out #27 bus control	
[595]	Pulse out #29 bus control	
[597]	Pulse out #X30/6 bus control	
[615]	Terminal 53 high ref./feedb. value	
[625]	Terminal 54 high ref./feedb. value	
[653]	Term 42 output bus ctrl	
[663]	Terminal X30/8 bus control	
[673]	Terminal X54/1 bus control	
[683]	Terminal X54/3 bus control	
[702]	Speed PID proportional gain	
[703]	Speed PID integral time	
[708]	Speed PID feed forward factor	
[748]	PCD feed forward	
[890]	Bus jog 1 speed	
[891]	Bus jog 2 speed	
[1397]	Alert alarm word	
[1398]	Alert warning word	
[1399]	Alert status word	
[1444]	d-axis reference gain	
[1472]	Legacy alarm word	
[1473]	Legacy warning word	
[1474]	Leg. ext. status word	
[1500]	Operating hours	
[1501]	Running hours	
[1502]	kWh counter	
[1583]	Motor Ud	View the motor voltage on the d-axis. The value is a calculated value used for controlling the motor.
[1584]	Motor Uq	View the motor voltage on the q-axis. The value is a calculated value used for controlling the motor.
[1585]	Motor Id	View the motor d-axis current measured as a mean value, I_{RMS} .
[1586]	Motor Iq	View the motor q-axis current measured as a mean value, I_{RMS} .
[1600]	Control word	
[1601]	Reference [unit]	
[1602]	Reference %	
[1603]	Status word	
[1605]	Main actual value [%]	

Option	Name	Description
[1606]	Actual position	
[1607]	Target position	
[1608]	Position error	
[1609]	Custom readout	
[1610]	Power [kW]	
[1611]	Power [hp]	
[1612]	Motor voltage	
[1613]	Frequency	
[1614]	Motor current	
[1615]	Frequency [%]	
[1616]	Torque [Nm]	
[1617]	Speed [RPM]	
[1618]	Motor thermal	
[1619]	Thermistor sensor temperature	
[1620]	Motor angle	
[1621]	Torque [%] high res.	
[1622]	Torque [%]	
[1623]	Motor shaft power [kW]	
[1624]	Calibrated	
[1625]	Torque [Nm] high	
[1628]	Angle error	
[1630]	DC link voltage	
[1632]	Brake energy /s	
[1633]	Brake energy average	
[1634]	Heatsink temp.	
[1635]	Inverter thermal	
[1638]	SL controller state	
[1639]	Control card temp.	
[1642]	Service log counter	
[1644]	Speed error [RPM]	
[1645]	Motor phase U current	
[1646]	Motor phase V current	
[1647]	Motor phase W current	
[1648]	Speed ref. after ramp [RPM]	
[1650]	External reference	
[1651]	Pulse reference	
[1652]	Feedback [Unit]	

Option	Name	Description
[1653]	Digi pot reference	
[1657]	Feedback [RPM]	
[1660]	Digital input	
[1661]	Terminal 53 switch setting	
[1662]	Analog input 53	
[1663]	Terminal 54 switch setting	
[1664]	Analog input 54	
[1665]	Analog output 42 [mA]	
[1666]	Digital output [bin]	
[1667]	Freq. input #29 [Hz]	
[1668]	Freq. input #33 [Hz]	
[1669]	Pulse output #27 [Hz]	
[1670]	Pulse output #29 [Hz]	
[1671]	Relay output [bin]	
[1672]	Counter A	
[1673]	Counter B	
[1674]	Prec. stop counter	
[1675]	Analog in X30/11	
[1676]	Analog in X30/12	
[1677]	Analog out X30/8 [mA]	
[1678]	Analog out X45/1 [mA]	
[1679]	Analog out X45/3 [mA]	
[1680]	Fieldbus CTW 1	
[1681]	Fieldbus sync. REF	
[1682]	Fieldbus REF 1	
[1683]	Fieldbus pos. REF	
 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.		
[1684]	Comm. option STW	
[1685]	FC port CTW 1	
[1686]	FC port REF 1	
[1687]	Bus readout alarm/warning	
[1688]	Fieldbus torque FF	
[1689]	Configurable alarm/warning word	
[1690]	Alarm word	
[1691]	Alarm word 2	
[1692]	Warning word	

Option	Name	Description
[1693]	Warning word 2	
[1694]	Ext. status word	
[1695]	Ext. status word 2	
[1696]	Maintenance word	
[1697]	Alarm word 3	
[1698]	Warning word 3	
[1699]	Ext. status word 3	
[1728]	SSI status bits	
[1740]	Fieldbus sync. delta	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1741]	Fieldbus profile velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1742]	Fieldbus velocity FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1743]	Fieldbus acceleration FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1744]	Fieldbus target velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1766]	SSI status	
[1767]	Raw inc. quad counter	
[1768]	Raw abs. pos. low	
[1769]	Raw abs. pos. high	
[1782]	Home position	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[1783]	Homing speed	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1788]	Master home position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1797]	Number of CAM cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.

Option	Name	Description
[1804]	Mech brake count	
[1820]	Commanded position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1821]	Master position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1823]	Virtual master pos.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1824]	Marker pos. offset	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1825]	Latched actual pos	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1826]	Fieldbus sync. delta REF	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1827]	Safe opt. est. speed	
[1828]	Safe opt. meas. speed	
[1829]	Safe opt. speed error	
[1836]	Analog input X48/2 [mA]	
[1837]	Temp. input X48/4	
[1838]	Temp. input X48/7	
[1839]	Temp. input X48/10	
[1840]	Analog input X49/1	
[1841]	Analog input X49/3	
[1842]	Analog input X49/5	
[1843]	Analog out X49/7	
[1844]	Analog out X49/9	
[1845]	Analog out X49/11	
[1846]	X49 digital output [bin]	
[1847]	X9 digital output [bin]	
[1848]	Last warning count	
[1860]	Digital input 2	
[1861]	Temp. input X48 max	
[1864]	Power based speed limit	

Option	Name	Description
[1866]	Actual switching frequency	
[1867]	Alarm word 4	
[1868]	Warning word 4	
[1889]	Mode of operation display	
[1898]	Expected time to ramp down	
[1899]	Speed PID torque FF. [Nm]	
[2470]	Min. ref. change	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[2471]	Rope length	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[2472]	Period of swing	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[2473]	Max speed change per swing	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[3310]	Sync factor master	
[3311]	Sync factor slave	
[3401]	PCD 1 write to MCO	
[3402]	PCD 2 write to MCO	
[3403]	PCD 3 write to MCO	
[3404]	PCD 4 write to MCO	
[3405]	PCD 5 write to MCO	
[3406]	PCD 6 write to MCO	
[3407]	PCD 7 write to MCO	
[3408]	PCD 8 write to MCO	
[3409]	PCD 9 write to MCO	
[3410]	PCD 10 write to MCO	
[3421]	PCD 1 read from MCO	
[3422]	PCD 2 read from MCO	
[3423]	PCD 3 read from MCO	
[3424]	PCD 4 read from MCO	
[3425]	PCD 5 read from MCO	
[3426]	PCD 6 read from MCO	
[3427]	PCD 7 read from MCO	
[3428]	PCD 8 read from MCO	

Option	Name	Description
[3429]	PCD 9 read from MCO	
[3430]	PCD 10 read from MCO	
[3440]	Digital inputs	
[3441]	Digital outputs	
[3450]	Actual position	
[3451]	Commanded position	
[3452]	Actual master position	
[3453]	Slave index position	
[3454]	Master index position	
[3455]	Curve position	
[3456]	Track error	
[3457]	Synchronizing error	
[3458]	Actual velocity	
[3459]	Actual master velocity	
[3460]	Synchronizing status	
[3461]	Axis status	
[3462]	Program status	
[3464]	MCO 302 status	
[3465]	MCO 302 control	
[3466]	SPI error counter	
[3470]	MCO alarm word 1	
[3471]	MCO alarm word 2	
[3644]	Terminal X49/7 bus control	
[3654]	Terminal X49/9 bus control	
[3664]	Terminal X49/11 bus control	
[4027]	Back EMF voltage	
[4029]	B-EMF protection log readout	
[4030]	Acc. delta speed	
[4031]	Acc. delta time	
[4032]	Dec. delta speed	
[4033]	Dec. delta time	
[4034]	Error code	
[4035]	DS402 Qstop	
[4036]	DS402 current actual	
[4037]	Motor current	
[4038]	Motor power	
[4039]	Motor torque	

Option	Name	Description
[4280]	Safe option status	
[4281]	Safe option status 2	
[4282]	Safe control word	
[4283]	Safe status word	
[4285]	Active safe func.	
[4287]	Time until manual test	
[4520]	Type	
[4521]	Status	
[4523]	Baseline result info	
[4589]	Cavitation [%]	
[4590]	Stator [%]	
[4591]	Load [%]	
[4592]	Sensor 1 [%]	
[4593]	Sensor 1 [unit]	
[4594]	Sensor 2 [%]	
[4595]	Sensor 2 [unit]	
[4596]	Sensor 3 [%]	
[4597]	Sensor 3 [unit]	
[4598]	Sensor 4 [%]	
[4599]	Sensor 4 [unit]	
[4901]	Autonomous status	
[4902]	Autonomous capacitance value	
[4911]	Baseline status	

8-42 PCD Write Configuration

Default value:	Size related	Parameter type:	Array [64]
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Select the parameters to be assigned to the telegrams of the PCD. The number of available PCDs depends on the telegram type. The values in the PCDs are then written to the selected parameters as data values.

8-43 PCD Read Configuration

Default value:	Size related	Parameter type:	Array [64]
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Select the parameters to be assigned to the PCDs of the telegrams. The number of available PCDs depends on the telegram type. PCDs contain the actual data values of the selected parameters.

8-45 BTM Transaction Command

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Option	Name	Description
[0]*	Off	
[1]	Write to active setup	
[2]	Commit transaction	Commit all parameters that have been sent during BTM mode.
[3]	Clear error	When parameter 8-46 BTM Transaction Status shows an error (3–8), the parameter must be cleared by setting this value.
[4]	Write to setup 1	 NOTE: This option is only available with software version 9.XX and newer.
[5]	Write to setup 2	 NOTE: This option is only available with software version 9.XX and newer.
[6]	Write to setup 3	 NOTE: This option is only available with software version 9.XX and newer.
[7]	Write to setup 4	 NOTE: This option is only available with software version 9.XX and newer.
[8]	Cancel BTM transaction	 NOTE: This option is only available with software version 9.XX and newer. Abort any BTM activity. Parameters are not committed.

8-46 BTM Transaction Status

Default value:	[0] Off	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Off	
[1]	Transaction started	
[2]	Commit transaction	
[3]	Transaction timeout	

Option	Name	Description
[4]	Err. non-existing par.	
[5]	Err. par. out of range	
[6]	Transaction failed	
[7]	SO config check	
[8]	SO config check done	

8-47 BTM Timeout

Default value:	60 s	Parameter type:	Range, 1 - 360 s
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Select the BTM timeout after a BTM transaction has been started. Timeout is between each acyclic write of parameters.

8-48 BTM Maximum Errors

Default value:	21	Parameter type:	Range, 0 - 21
Setup:	1 setup	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Select the maximum allowed number of bulk transfer mode errors before aborting. If it is set to maximum, there is no abort.

8-49 BTM Error Log

Default value:	Size related	Parameter type:	Array [22]
Setup:	1 setup	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

List of parameters that failed during bulk transfer mode. The value after the decimal break is the fault code (255 stands for no error).

6.10.6 8-5* Digital/Bus

This parameter group contains parameters for configuring the control word merging.

8-50 Coasting Select

Default value:	[3] Logic OR	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the trigger for the coasting function.

Option	Name	Description
[0]	Digital input	A digital input triggers the coasting function.
[1]	Bus	A serial communication port or the fieldbus triggers the coasting function.

Option	Name	Description
[2]	Logic AND	The fieldbus/serial communication port and a digital input trigger the coasting function.
[3]*	Logic OR	The fieldbus/serial communication port or a digital input triggers the coasting function.

8-51 Quick Stop Select

Default value:	[3] Logic OR	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the trigger for the quick stop function.

Option	Name	Description
[0]	Digital input	A digital input triggers the quick stop function.
[1]	Bus	A serial communication port or the fieldbus triggers the quick stop function.
[2]	Logic AND	The fieldbus/serial communication port and a digital input trigger the quick stop function.
[3]*	Logic OR	The fieldbus/serial communication port or a digital input triggers the quick stop function.

8-52 DC Brake Select

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select control of the DC brake via the terminals (digital input) and/or via the fieldbus.



NOTE: When parameter **1-10 Motor Construction** is set to **[1] PM non-salient SPM**, only selection **[0] Digital input** is available.

Option	Name	Description
[0]	Digital input	Activate a start command via a digital input.
[1]	Bus	Activate a start command via a serial communication port or fieldbus option.
[2]	Logic AND	Activate a start command via the fieldbus/serial communication port and also via 1 of the digital inputs.
[3]	Logic OR	Activate a start command via the fieldbus/serial communication port or via 1 of the digital inputs.

8-53 Start Select

Default value:	[3] Logic OR	Parameter type:	Option

Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the trigger for the start function.

Option	Name	Description
[0]	Digital input	A digital input triggers the start function.
[1]	Bus	A serial communication port or the fieldbus triggers the start function.
[2]	Logic AND	The fieldbus/serial communication port and a digital input trigger the start function.
[3]*	Logic OR	The fieldbus/serial communication port or a digital input triggers the start function.

8-54 Reversing Select

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the trigger for the reversing function.

Option	Name	Description
[0]	Digital input	A digital input triggers the reversing function.
[1]	Bus	A serial communication port or the fieldbus triggers the reversing function.
[2]	Logic AND	The fieldbus/serial communication port and a digital input trigger the reversing function.
[3]	Logic OR	The fieldbus/serial communication port or a digital input triggers the reversing function.

8-55 Set-up Select

Default value:	[3] Logic OR	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the trigger for the setup selection.

Option	Name	Description
[0]	Digital input	A digital input triggers the setup selection.
[1]	Bus	A serial communication port or the fieldbus triggers the setup selection.

Option	Name	Description
[2]	Logic AND	The fieldbus/serial communication port and a digital input trigger the setup selection.
[3]*	Logic OR	The fieldbus/serial communication port or a digital input triggers the setup selection.

8-56 Preset Reference Select

Default value:	[3] Logic OR	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the trigger for the preset reference selection.

Option	Name	Description
[0]	Digital input	A digital input triggers the preset reference selection.
[1]	Bus	A serial communication port or the fieldbus triggers the preset reference selection.
[2]	Logic AND	The fieldbus/serial communication port and a digital input trigger the preset reference selection.
[3]*	Logic OR	The fieldbus/serial communication port or a digital input triggers the preset reference selection.

8-57 PROFIdrive OFF2 Select

Default value:	[3] Logic OR	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select control of the drive OFF2 selection via the terminals (digital input) and/or via the fieldbus. This parameter is active only when parameter **8-01 Control Site** is set to **[0] Digital and ctrl. word** and parameter **8-10 Control Word Profile** is set to **[1] PROFIdrive profile**.

Option	Name	Description
[0]	Digital input	
[1]	Bus	
[2]	Logic AND	
[3]*	Logic OR	

8-58 PROFIdrive OFF3 Select

Default value:	[3] Logic OR	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select control of the drive OFF3 selection via the terminals (digital input) and/or via the fieldbus. This parameter is active only when parameter **8-01 Control Site** is set to **[0] Digital and ctrl. word** and parameter **8-10 Control Word Profile** is set to **[1] PROFIdrive profile**.

Option	Name	Description
[0]	Digital input	
[1]	Bus	
[2]	Logic AND	
[3]*	Logic OR	

6.10.7 8-8* FC Port Diagnostics

This parameter group contains parameters for monitoring the bus communication via the drive RS-485 port terminals 68 and 69.

8-80 Bus Message Count

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter shows the number of valid telegrams detected on the bus.

8-81 Bus Error Count

Default value:	0	Parameter type:	Readout, Array [6]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter shows the number of telegrams with faults (for example, CRC fault) detected on the bus.

8-82 Slave Messages Rcvd

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter shows the number of valid telegrams addressed to the slave sent by the drive.

8-83 Slave Error Count

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter shows the number of error telegrams which are not executed by the drive.

6.10.8 8-9* Bus Jog

8-90 Bus Jog 1 Speed

Default value:	Size related	Parameter type:	Range, 0 - par. 4-13 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the jog speed. Activate this fixed jog speed via the serial port or fieldbus option.

8-91 Bus Jog 2 Speed

Default value:	Size related	Parameter type:	Range, 0 - par. 4-13 RPM
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Enter the jog speed. Activate this fixed jog speed via the serial port or fieldbus option.

6.11 Parameter Group 9-** PROFIBUS

9-00 Setpoint

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter receives cyclic references from a master class 2. If the control priority is set to master class 2, the reference for the drive is taken from this parameter, whereas the cyclic reference is ignored.

9-07 Actual Value

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter delivers the MAV for a master class 2. The parameter is valid if the control priority is set to master class 2.

9-15 PCD Write Configuration

Default value:	–	Parameter type:	Option, Array [20]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Select the parameters to be assigned to PCD 3–10 of the telegrams. The number of available PCDs depends on the telegram type. Values in PCD 3–10 are written to the selected parameters as data. For standard PROFIBUS telegrams, see parameter **9-22 Telegram Selection**.

Option	Name	Description
[0]	None	
[109]	Mode of operation	
[302]	Minimum reference	
[303]	Maximum reference	
[311]	Jog speed [Hz]	
[312]	Catch up/slow down value	
[319]	Jog speed [RPM]	
[321]	Touch target	

Option	Name	Description
[322]	Master scale numerator	
[323]	Master scale denominator	
[326]	Master Offset	
[328]	Master offset speed ref	
[330]	Min. speed ramp time	
[341]	Ramp 1 ramp up time	
[342]	Ramp 1 ramp down time	
[351]	Ramp 2 ramp up time	
[352]	Ramp 2 ramp down time	
[361]	Ramp 3 ramp up time	
[362]	Ramp 3 ramp down time	
[380]	Jog/homing ramp time jog ramp time	
[381]	Quick stop ramp time	
[411]	Motor speed low limit [RPM]	
[412]	Motor speed low limit [Hz]	
[413]	Motor speed high limit [RPM]	
[414]	Motor speed high limit [Hz]	
[416]	Torque limit motor mode	
[417]	Torque limit generator mode	
[482]	Power limit motor mode	
[483]	Power limit generator mode	
[491]	Positive speed limit [RPM]	
[492]	Positive speed limit [Hz]	
[493]	Negative speed limit [RPM]	
[494]	Negative speed limit [Hz]	
[495]	Positive torque limit	
[496]	Negative torque limit	
[553]	Term. 29 high ref./feedb. value	
[558]	Term. 33 high ref./feedb. value	
[590]	Digital & relay bus control	
[593]	Pulse out #27 bus control	
[595]	Pulse out #29 bus control	
[597]	Pulse out #30/6 bus control	
[615]	Terminal 53 high ref./feedb. value	
[625]	Terminal 54 high ref./feedb. value	
[653]	Term 42 output bus ctrl	
[663]	Terminal X30/8 bus control	

Option	Name	Description
[673]	Terminal X45/1 bus control	
[683]	Terminal X45/3 bus control	
[702]	Speed PID proportional gain	
[703]	Speed PID integral time	
[708]	Speed PID feed forward factor	
[748]	PCD feed forward	
[890]	Bus jog 1 speed	
[891]	Bus jog 2 speed	
[1444]	d-axis reference gain	
[1680]	Fieldbus CTW 1	
[1681]	Fieldbus sync. REF	
[1682]	Fieldbus REF 1	
[1683]	Fieldbus pos. REF	
[1685]	FC port CTW 1	
[1686]	FC port REF 1	
[1688]	Fieldbus torque FF.	
[1728]	SSI status bits	
[1740]	Fieldbus sync. delta	 NOTE: This option is only available in FC 302 with IMC software version 48.7X and newer.
[1741]	Fieldbus profile velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X and newer.
[1742]	Fieldbus velocity FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X and newer.
[1743]	Fieldbus acceleration FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X and newer.
[1744]	Fieldbus target velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X and newer.
[1782]	Home position	 NOTE: This option is only available in FC 302 with IMC software version 48.3X and newer.
[1783]	Homing speed	 NOTE: This option is only available in FC 302 with IMC software version 48.4X and newer.

Option	Name	Description
[1788]	Master home position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X and newer.
[1797]	Number of CAM cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.96 and newer.

9-16 PCD Read Configuration

Default value:	–	Parameter type:	Option, Array [20]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Select the parameters to be assigned to PCD 3–10 of the telegrams. The number of available PCDs depends on the telegram type. Values in PCD 3–10 are written to the selected parameters as data. For standard PROFIBUS telegrams, see parameter **9-22 Telegram Selection**.

Option	Name	Description
[0]	None	
[15]	Readout: actual setup	
[1397]	Alert alarm word	
[1398]	Alert warning word	
[1399]	Alert status word	
[1444]	d-axis reference gain	
[1472]	Legacy alarm word	
[1473]	Legacy warning word	
[1474]	Leg. ext. status word	
[1500]	Operating hours	
[1501]	Running hours	
[1502]	kWh counter	
[1583]	Motor Ud	View the motor voltage on the d-axis. The value is a calculated value used for controlling the motor.
[1584]	Motor Uq	View the motor voltage on the q-axis. The value is a calculated value used for controlling the motor.
[1585]	Motor Id	View the motor d-axis current measured as a mean value, I_{RMS} .
[1586]	Motor Iq	View the motor q-axis current measured as a mean value, I_{RMS} .
[1600]	Control word	
[1601]	Reference [unit]	
[1602]	Reference %	
[1603]	Status word	
[1605]	Main actual value [%]	

Option	Name	Description
[1606]	Actual position	
[1607]	Target position	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[1608]	Position error	
[1609]	Custom readout	
[1610]	Power [kW]	
[1611]	Power [hp]	
[1612]	Motor voltage	
[1613]	Frequency	
[1614]	Motor current	
[1615]	Frequency [%]	
[1616]	Torque [Nm]	
[1617]	Speed [RPM]	
[1618]	Motor thermal	
[1619]	Thermistor sensor temperature	
[1620]	Motor angle	
[1621]	Torque [%] high res.	
[1622]	Torque [%]	
[1623]	Motor shaft power [kW]	
[1624]	Calibrated stator resistance	
[1625]	Torque [Nm] high	
[1628]	Angle error	
[1630]	DC link voltage	
[1632]	Brake energy /s	
[1633]	Brake energy average	
[1634]	Heatsink temp.	
[1635]	Inverter thermal	
[1638]	SL controller state	
[1639]	Control card temp.	
[1642]	Service log counter	
[1644]	Speed error [RPM]	
[1645]	Motor phase U current	
[1646]	Motor phase V current	
[1647]	Motor phase W current	
[1648]	Speed ref. after ramp [RPM]	
[1650]	External reference	

Option	Name	Description
[1651]	Pulse reference	
[1652]	Feedback[Unit]	
[1653]	Digi pot reference	
[1657]	Feedback [RPM]	
[1660]	Digital input	
[1661]	Terminal 53 switch setting	
[1662]	Analog input 53	
[1663]	Terminal 54 switch setting	
[1664]	Analog input 54	
[1665]	Analog output 42 [mA]	
[1666]	Digital output [bin]	
[1667]	Freq. input #29 [Hz]	
[1668]	Freq. input #33 [Hz]	
[1669]	Pulse output #27 [Hz]	
[1670]	Pulse output #29 [Hz]	
[1671]	Relay output [bin]	
[1672]	Counter A	
[1673]	Counter B	
[1674]	Prec. stop counter	
[1675]	Analog in X30/11	
[1676]	Analog in X30/12	
[1677]	Analog out X30/8 [mA]	
[1678]	Analog out X45/1 [mA]	
[1679]	Analog out X45/3 [mA]	
[1684]	Comm. option STW	
[1687]	Bus readout alarm/warning	
[1689]	Configurable alarm/warning word	
[1690]	Alarm word	
[1691]	Alarm word 2	
[1692]	Warning word	
[1693]	Warning word 2	
[1694]	Ext. status word	
[1695]	Ext. status word 2	
[1696]	Maintenance word	
[1697]	Alarm word 3	
[1698]	Warning word 3	
[1699]	Ext. status word 3	

Option	Name	Description
[1728]	SSI status bits	
[1766]	SSI status	
[1767]	Raw inc. quad counter	
[1768]	Raw abs. pos. low	
[1769]	Raw abs. pos. high	
[1804]	Mech brake count	
[1820]	Commanded position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1821]	Master position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1823]	Virtual master pos.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1824]	Marker pos. offset	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1825]	Latched actual pos.	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1826]	Actual velocity [pu/s]	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1827]	Safe opt. est. speed	
[1828]	Safe opt. meas. speed	
[1829]	Safe opt. speed error	
[1836]	Analog input X48/2 [mA]	
[1837]	Temp. input X48/4	
[1838]	Temp. input X48/7	
[1839]	Temp. input X48/10	
[1840]	Analog input X49/1	
[1841]	Analog input X49/3	
[1842]	Analog input X49/5	
[1843]	Analog input X49/7	
[1844]	Analog out X49/9	
[1845]	Analog out X49/11	
[1846]	X49 digital output [bin]	

Option	Name	Description
[1847]	Last warning	
[1848]	Last warning count	
[1860]	Digital input 2	
[1861]	Temp. input X48 max	
[1864]	Power based speed limit	
[1866]	Actual switching frequency	
[1867]	Alarm word 4	
[1868]	Warning word 4	
[1889]	Mode of operation display	NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1898]	Expected time to ramp down	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[1899]	Speed PID torque FF. [Nm]	

9-18 Node Address

Default value:	126	Parameter type:	Range, 1 - 126
Setup:	1 setup	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the station address in this parameter or, alternatively, in the hardware switch. To adjust the station address in this parameter, set the hardware switch to 126 or 127 (that is all switches set to ON). Otherwise, this parameter shows the actual setting of the switch.

9-19 Drive Unit System Number

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint16	Change during operation:	True

For PROFINET, select which profile to be used with standard telegrams and drive-specific telegrams.

Option	Name	Description
[1]	PROFIDRIVE/FC telegrams	
[2]	FCD302	
[1034]	Danfoss FC series	
[1035]	FCD302	
[1687]	FID2000	
[15008]	VIK-NAMUR	

9-22 Telegram Selection

Default value:	[100] None	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select a standard PROFIBUS telegram configuration for the drive as an alternative to the freely configurable telegrams in parameter **9-15 PCD Write Configuration** and parameter **9-16 PCD Read Configuration**.

Option	Name	Description
[1]	Standard telegram 1	
[20]	Standard telegram 20	
[100]*	None	
[101]	PPO 1	
[102]	PPO 2	
[103]	PPO 3	
[104]	PPO 4	
[105]	PPO 5	
[106]	PPO 6	
[107]	PPO 7	
[108]	PPO 8	
[109]	PPO 9	

9-23 Parameters for Signals

Default value:	[0] None	Parameter type:	Readout, Array [1000]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

This parameter contains a list of signals available for selection in parameter **9-15 PCD Write Configuration** and parameter **9-16 PCD Read Configuration**.

Option	Name	Description
[0]*	None	
[15]	Readout: actual setup	
[109]	Mode of operation	
		 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[302]	Minimum reference	
[303]	Maximum reference	
[311]	Jog speed [Hz]	
[312]	Catch up/slow down value	
[319]	Jog speed [RPM]	

Option	Name	Description
[321]	Touch target	
[322]	Master scale numerator	
[323]	Master scale denominator	
[326]	Master Offset	
[328]	Master offset speed ref	
[330]	Mn. speed ramp time	
[341]	Ramp 1 ramp up time	
[342]	Ramp 1 ramp down time	
[351]	Ramp 2 ramp up time	
[352]	Ramp 2 ramp down time	
[361]	Ramp 3 ramp up time	
[362]	Ramp 3 ramp down time	
[380]	Jog/homing ramp time jog ramp time	
[381]	Quick stop ramp time	
[411]	Motor speed low limit [RPM]	
[412]	Motor speed low limit [Hz]	
[413]	Motor speed high limit [RPM]	
[414]	Motor speed high limit [Hz]	
[416]	Torque limit motor mode	
[417]	Torque limit generator mode	
[482]	Power limit motor mode	
[483]	Power limit generator mode	
[491]	Positive speed limit [RPM]	
[492]	Positive speed limit [Hz]	
[493]	Negative speed limit [RPM]	
[494]	Negative speed limit [Hz]	
[495]	Positive torque limit	
[496]	Negative torque limit	
[553]	Term. 29 high ref./feedb. value	
[558]	Term. 33 high ref./feedb. value	
[590]	Digital & relay bus control	
[593]	Pulse out #27 bus control	
[595]	Pulse out #29 bus control	
[597]	Pulse out #30/6 bus control	
[615]	Terminal 53 high ref./feedb. value	
[625]	Terminal 54 high ref./feedb. value	
[653]	Term 42 output bus ctrl	

Option	Name	Description
[663]	Terminal X30/8 bus control	
[673]	Terminal X45/1 bus control	
[683]	Terminal X45/3 bus control	
[702]	Speed PID proportional gain	
[703]	Speed PID integral time	
[708]	Speed PID feed forward factor	
[748]	PCD feed forward	
[890]	Bus jog 1 speed	
[891]	Bus jog 2 speed	
[1397]	Alert alarm word	
[1398]	Alert warning word	
[1399]	Alert status word	
[1444]	d-axis reference gain	
[1472]	Legacy alarm word	
[1473]	Legacy warning word	
[1474]	Leg. ext. status word	
[1500]	Operating hours	
[1501]	Running hours	
[1502]	kWh counter	
[1583]	Motor Ud	View the motor voltage on the d-axis. The value is a calculated value used for controlling the motor.
[1584]	Motor Uq	View the motor voltage on the q-axis. The value is a calculated value used for controlling the motor.
[1585]	Motor Id	View the motor d-axis current measured as a mean value, I_{RMS} .
[1586]	Motor Iq	View the motor q-axis current measured as a mean value, I_{RMS} .
[1600]	Control word	
[1601]	Reference [unit]	
[1602]	Reference %	
[1603]	Status word	
[1605]	Main actual value [%]	
[1606]	Actual position	
[1607]	Target position	
[1608]	Position error	
[1609]	Custom readout	
[1610]	Power [kW]	
[1611]	Power [hp]	
[1612]	Motor voltage	

Option	Name	Description
[1613]	Frequency	
[1614]	Motor current	
[1615]	Frequency [%]	
[1616]	Torque [Nm]	
[1617]	Speed [RPM]	
[1618]	Motor thermal	
[1619]	Thermistor sensor temperature	
[1620]	Motor angle	
[1621]	Torque [%] high res.	
[1622]	Torque [%]	
[1623]	Motor shaft power [kW]	
[1624]	Calibrated stator resistance	
[1625]	Torque [Nm] high	
[1628]	Angle error	
[1630]	DC link voltage	
[1632]	Brake energy /s	
[1633]	Brake energy average	
[1634]	Heatsink temp.	
[1635]	Inverter thermal	
[1638]	SL controller state	
[1639]	Control card temp.	
[1642]	Service log counter	
[1644]	Speed error [RPM]	
[1645]	Motor phase U current	
[1646]	Motor phase V current	
[1647]	Motor phase W current	
[1648]	Speed ref. after ramp [RPM]	
[1650]	External reference	
[1651]	Pulse reference	
[1652]	Feedback[unit]	
[1653]	Digi pot reference	
[1657]	Feedback [RPM]	
[1660]	Digital input	
[1661]	Terminal 53 switch setting	
[1662]	Analog input 53	
[1663]	Terminal 54 switch setting	
[1664]	Analog input 54	

Option	Name	Description
[1665]	Analog output 42 [mA]	
[1666]	Digital output [bin]	
[1667]	Freq. input #29 [Hz]	
[1668]	Freq. input #33 [Hz]	
[1669]	Pulse output #27 [Hz]	
[1670]	Pulse output #29 [Hz]	
[1671]	Relay output [bin]	
[1672]	Counter A	
[1673]	Counter B	
[1674]	Prec. stop counter	
[1675]	Analog in X30/11	
[1676]	Analog in X30/12	
[1677]	Analog out X30/8 [mA]	
[1678]	Analog out X45/1 [mA]	
[1679]	Analog out X45/3 [mA]	
[1680]	Fieldbus CTW 1	
[1681]	Fieldbus sync. REF	
[1682]	Fieldbus REF 1	
[1683]	Fieldbus pos. REF	
[1684]	Comm. option STW	
[1685]	FC port CTW 1	
[1686]	FC port REF 1	
[1687]	Bus readout alarm/warning	
[1688]	Fieldbus torque FF.	
[1689]	Configurable alarm/warning word	
[1690]	Alarm word	
[1691]	Alarm word 2	
[1692]	Alarm word	
[1693]	Alarm word 2	
[1694]	Ext. status word	
[1695]	Ext. status word 2	
[1696]	Maintenance word	
[1697]	Alarm word 3	
[1698]	Warning word 3	
[1699]	Ext. status word 3	
[1728]	SSI status bits	

Option	Name	Description
[1740]	Fieldbus sync. delta	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[1741]	Fieldbus profile velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1742]	Fieldbus velocity FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1743]	Fieldbus acceleration FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1744]	Fieldbus target velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1766]	SSI status	
[1767]	Raw. inc. quad counter	
[1768]	Raw abs. pos. low	
[1769]	Raw abl. pos. high	
[1782]	Home position	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[1783]	Homing speed	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1788]	Master home position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1797]	Number of CAM cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.6X or newer.
[1804]	Mech brake count	
[1820]	Commanded position	
[1821]	Master position	
[1823]	Virtual master pos.	
[1824]	Master pos. offset	
[1825]	Latched actual pos.	
[1826]	Actual velocity [pu/s]	
[1827]	Safe opt. est. speed	

Option	Name	Description
[1828]	Safe opt. meas. speed	
[1829]	Safe opt. speed error	
[1836]	Analog input X48/2[mA]	
[1837]	Temp. input X48/4	
[1838]	Temp. input X48/7	
[1839]	Temp. input X48/10	
[1840]	Analog input X49/1	
[1841]	Analog input X49/3	
[1842]	Analog input X49/5	
[1843]	Analog out X49/7	
[1844]	Analog out X49/9	
[1845]	Analog out X49/11	
[1846]	X49 Digital output [bin]	
[1847]	Last warning	
[1848]	Last warning count	
[1860]	Digital input 2	
[1861]	Temp. input X48 max	
[1864]	Power based speed limit	
[1866]	Actual switching frequency	
[1867]	Alarm word 4	
[1868]	Warning word 4	
[1889]	Mode of operation display	
[1898]	Expected time to ramp down	
[1899]	Speed PID torque FF. [Nm]	
[2470]	Min. ref. change	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[2471]	Rope length	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[2472]	Period of swing	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[2473]	Max speed change per swing	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[3310]	Sync factor master	
[3311]	Sync factor slave	

Option	Name	Description
[3401]	PCD 1 write to MCO	
[3402]	PCD 2 write to MCO	
[3403]	PCD 3 write to MCO	
[3404]	PCD 4 write to MCO	
[3405]	PCD 5 write to MCO	
[3406]	PCD 6 write to MCO	
[3407]	PCD 7 write to MCO	
[3408]	PCD 8 write to MCO	
[3409]	PCD 9 write to MCO	
[3410]	PCD 10 write to MCO	
[3421]	PCD 1 read from MCO	
[3422]	PCD 2 read from MCO	
[3423]	PCD 3 read from MCO	
[3424]	PCD 4 read from MCO	
[3425]	PCD 5 read from MCO	
[3426]	PCD 6 read from MCO	
[3427]	PCD 7 read from MCO	
[3428]	PCD 8 read from MCO	
[3429]	PCD 9 read from MCO	
[3430]	PCD 10 read from MCO	
[3440]	Digital inputs	
[3441]	Digital outputs	
[3450]	Actual position	
[3451]	Commanded position	
[3452]	Actual master position	
[3453]	Slave index position	
[3454]	Master index position	
[3455]	Curve position	
[3456]	Track error	
[3457]	Synchronizing error	
[3458]	Actual velocity	
[3459]	Actual master velocity	
[3460]	Synchronizing status	
[3461]	Axis status	
[3462]	Program status	
[3464]	MCO 302 status	
[3465]	MCO 303 control	

Option	Name	Description
[3466]	SPI error counter	
[3470]	MCO alarm word 1	
[3471]	MCO alarm word 2	
[3644]	Terminal X49/7 bus control	
[3654]	Terminal X49/9 bus control	
[3664]	Terminal X49/11 bus control	
[4027]	Back EMF voltage	
[4029]	B-EMF protection log readout	
[4030]	Acc. delta speed	
[4031]	Acc. delta time	
[4032]	Dec. delta speed	
[4033]	Dec. delta time	
[4034]	Error code	
[4035]	DS402 Qstop	
[4036]	DS402 current actual	
[4037]	Motor current	
[4038]	Motor power	
[4039]	Motor torque	
[4280]	Safe option status	
[4281]	Safe option status 2	
[4282]	Safe control word	
[4283]	Safe status word	
[4285]	Active safe func.	
[4287]	Time until manual test	
[4520]	Type	
[4521]	Status	
[4523]	Baseline failure	
[4589]	Cavitation [%]	
[4590]	Stator [%]	
[4591]	Load [%]	
[4592]	Sensor 1 [%]	
[4593]	Sensor 1 [unit]	
[4594]	Sensor 2 [%]	
[4595]	Sensor 3 [unit]	
[4596]	Sensor 3 [%]	
[4597]	Sensor 3 [unit]	
[4598]	Sensor 4 [%]	

Option	Name	Description
[4599]	Sensor 4 [unit]	
[4901]	Autonomous status	
[4902]	Autonomous capacitance value	
[4911]	Baseline status	

9-27 Parameter Edit

Default value:	[1] Enabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint16	Change during operation:	False

Parameters can be edited via:

- PROFIBUS
- The standard RS-485 interface
- The LCP

Option	Name	Description
[0]	Disabled	
[1]*	Enabled	

9-28 Process Control

Default value:	[1] Enable cyclic master	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Process control (setting of control word, speed reference, and process data) is possible via either PROFIBUS or standard fieldbus, but not both simultaneously. Local control is always possible via the LCP. Control via process control is possible via either terminals or fieldbus depending on the settings in parameter **8-50 Coasting Select** to parameter **8-56 Preset Reference Select**.

Option	Name	Description
[0]	Disable	
[1]*	Enable cyclic master	

9-44 Fault Message Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Indicates the number of fault events presently stored in parameter **9-45 Fault Code**. The buffer capacity is maximum 8 error events. The buffer and counter are set to 0 by reset or power-up.

9-45 Fault Code

Default value:	0	Parameter type:	Readout, Array [64]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This buffer contains the alarm word for all alarms and warnings that have occurred since the last reset or power-up. The buffer capacity is maximum 8 error events.

9-47 Fault Number

Default value:	0	Parameter type:	Readout, Array [64]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This buffer contains the alarm word for all alarms and warnings that have occurred since the last reset or power-up. The buffer capacity is maximum 8 error events.

9-52 Fault Situation Counter

Default value:	0	Parameter type:	Range, 0 - 1000
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Indicates the number of fault events that have occurred since the last reset or power-up.

9-53 PROFIBUS Warning Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	True

This parameter shows PROFIBUS communication warnings.

Table 41: PROFIBUS Warning Word

Bit	Description
0	Connection with DP-master is not OK.
1	Not used.
2	FDL (fieldbus data link layer) is not OK.
3	Clear data command received.
4	Actual value is not updated.
5	Baud rate search.
6	PROFIBUS ASIC is not transmitting.
7	Initializing of PROFIBUS is not OK.
8	Drive is tripped.
9	Internal CAN error.

Table 41: PROFIBUS Warning Word - (continued)

Bit	Description
10	Wrong configuration data from PLC.
11	Wrong ID sent by PLC.
12	Internal fault occurred.
13	Not configured.
14	Timeout active.
15	Warning 34, Fieldbus Fault is active.

9-63 Actual Baud Rate

Default value:	[255] No baud rate found	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter shows the actual PROFIBUS baud rate. The PROFIBUS master automatically sets the baud rate.

Index	Name
[0]	9,6 kbit/s
[1]	19,2 kbit/s
[2]	93,75 kbit/s
[3]	187,5 kbit/s
[4]	500 kbit/s
[6]	1500 kbit/s
[7]	3000 kbit/s
[8]	6000 kbit/s
[9]	12000 kbit/s
[10]	31,25 kbit/s
[11]	45,45 kbit/s
[255]*	No baud rate found

9-64 Device Identification

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is not visible via LCP.

The device identification parameter. The data type is array [n] of unsigned16. The assignment of the 1st subindexes is defined and shown in the following table.

Index	Content	Value
[0]	Manufacturer	128 (for Danfoss)
[1]	Device type	1
[2]	Version	xyyy
[3]	Firmware date year	yyyy
[4]	Firmware date month	ddmm
[5]	No. of axes	Variable
[6]	Vendor specific: PB version	xyyy
[7]	Vendor specific: Database version	xyyy
[8]	Vendor specific: AOC version	xyyy
[9]	Vendor specific: MOC version	xyyy

9-65 Profile Number

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	OctStr[2]	Change during operation:	True



NOTE: This parameter is not visible via LCP.

This parameter contains the profile identification. Byte 1 contains the profile number. Byte 2 contains the number of the profile.

9-67 Control Word 1

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

This parameter accepts the control word from a master class 2 in the same format as PCD 1.

9-68 Status Word 1

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	True

This parameter delivers the status word for a master class 2 in the same format as PCD 2.

9-70 Edit Set-up

Default value:	[1] Set-up 1	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the setup in which programming (change of data) is performed during operation. It is possible to program the 2 setups independently of the setup selected as the active setup. Parameter access from each master is directed to the setup selected by the individual master (cyclic, acyclic MCL1, 1st acyclic MCL2, 2nd acyclic MCL2, 3rd acyclic MCL2).

Option	Name	Description
[0]	Factory setup	
[1]*	Set-up 1	
[2]	Set-up 2	
[3]	Set-up 3	
[4]	Set-up 4	
[9]	Active set-up	

9-71 PROFIBUS Save Data Value

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Parameter values changed via RS-485 are not automatically stored in a non-volatile memory. Use this parameter to activate a function that stores parameter values in the EEPROM non-volatile memory, so changed parameter values are retained at power-down.

Option	Name	Description
[0]*	Off	
[1]	Store all setups	
[2]	Store all setups	

9-72 PROFIBUSDriveReset

Default value:	[0] No action	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: Resets the VLT® PROFIBUS DP-V1 MCA 101 option only.

Option	Name	Description
[0]*	No action	
[1]	Power-on reset	
[2]	Power-on reset prep	
[3]	Comm option reset	

9-75 DO Identification

Default value:	0	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	0

Data type:	Uint16	Change during operation:	True

Provides information about the DO (direct object). This parameter is for PROFINET only.

9-80 Defined Parameters (1)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter shows a list of all the defined drive parameters available for PROFIBUS.

9-81 Defined Parameters (2)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter shows a list of all the defined drive parameters available for PROFIBUS.

9-82 Defined Parameters (3)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter shows a list of all the defined drive parameters available for PROFIBUS.

9-83 Defined Parameters (4)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter shows a list of all the defined drive parameters available for PROFIBUS.

9-84 Defined Parameters (5)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter shows a list of all the defined drive parameters available for PROFIBUS.

9-85 Defined Parameters (6)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setup	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter shows a list of all the defined drive parameters available for PROFIBUS.

9-90 Changed Parameters (1)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameters shows a list of all the drive parameters deviating from the default setting.

9-91 Changed Parameters (2)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameters shows a list of all the drive parameters deviating from default setting.

9-92 Changed Parameters (3)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Change during operation:	False		

This parameters shows a list of all the drive parameters deviating from default setting.

9-93 Changed Parameters (4)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameters shows a list of all the drive parameters deviating from default setting.

9-94 Changed Parameters (5)

Default value:	0	Parameter type:	Readout, Array [116]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameters shows a list of all the drive parameters deviating from default setting.

9-99 PROFIBUS Revision Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Readout of revision count.

6.12 Parameter Group 10-** CAN Fieldbus

6.12.1 10-0* Common Settings

10-00 CAN Protocol

Default value:	–	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

The options available depend on the installed option card.

Option	Name	Description
[0]	CANopen	
[1]	DeviceNet	

10-01 Baud Rate Select

Default value:	–	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the fieldbus transmission speed. The selection must correspond to the transmission speed of the master and of the other fieldbus nodes.

Option	Name	Description
[16]	10 Kbps	
[17]	20 Kbps	
[18]	50 Kbps	
[19]	100 Kbps	
[20]	125 Kbps	
[21]	250 Kbps	
[22]	500 Kbps	

10-02 MAC ID

Default value:	Size related	Parameter type:	Range, 1 - 127 N/A
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Select the station address. Every station connected to the same network must have an unambiguous address.

10-05 Readout Transmit Error Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

View the number of CAN control transmission errors since the last power-up.

10-06 Readout Receive Error Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

View the number of CAN control receipt errors since the last power-up.

10-07 Readout Bus Off Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

View the number of fieldbus off events since the last power-up.

6.12.2 10-1* DeviceNet

10-10 Process Data Type Selection

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the instance (telegram) for data transmission. The instances available depend on the setting of parameter **8-10 Control Word Profile**. When parameter **8-10 Control Word Profile** is set to **[0] FC Profile**, options **[0] INSTANCE 100/150** and **[1] INSTANCE 101/151** in this parameter are available. When parameter **8-10 Control Word Profile** is set to **[5] ODVA**, options **[2] INSTANCE 20/70** and **[3] INSTANCE 21/71** in this parameter are available. Instances 100/150 and 101/151 are specific. Instances 20/70 and 21/71 are ODVA-specific AC motor profiles. For guidelines in telegram selection, refer to the VLT® DeciveNet MCA 104 Installation Guide.



NOTE: A change to this parameter is executed immediately.

Option	Name	Description
[0]	Instance 100/150	
[1]	Instance 101/151	
[2]	Instance 20/70	
[3]	Instance 21/71	
[6]	Instance 102/152	

10-11 Process Data Config Write

Default value:	–	Parameter type:	Option, Array [4]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Option	Name	Description
[0]	None	
[109]	Mode of operation	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[302]	Minimum reference	
[303]	Maximum reference	
[311]	Jog speed [Hz]	
[312]	Catch up/slow down value	
[319]	Jog speed [RPM]	
[321]	Touch target	
[322]	Master scale numerator	
[323]	Master scale denominator	
[326]	Master Offset	
[328]	Master offset speed ref	
[330]	Min. speed ramp time	
[341]	Ramp 1 ramp up time	
[342]	Ramp 1 ramp down time	
[351]	Ramp 2 ramp up time	
[352]	Ramp 2 ramp down time	
[361]	Ramp 3 ramp up time	
[362]	Ramp 3 ramp down time	
[380]	Jog/homing ramp time jog ramp time	
[381]	Quick stop ramp time	
[411]	Motor speed low limit [RPM]	
[412]	Motor speed low limit [Hz]	
[413]	Motor speed high limit [RPM]	
[414]	Motor speed high limit [Hz]	
[416]	Torque limit motor mode	
[417]	Torque limit generator mode	
[482]	Power limit motor mode	
[483]	Power limit generator mode	
[491]	Positive speed limit [RPM]	
[492]	Positive speed limit [Hz]	
[493]	Negative speed limit [RPM]	
[494]	Negative speed limit [Hz]	
[495]	Positive torque limit	
[496]	Negative torque limit	

Option	Name	Description
[553]	Term. 29 high ref./feedb. value	
[558]	Term. 33 high ref./feedb. value	
[590]	Digital & relay bus control	
[593]	Pulse out #27 bus control	
[595]	Pulse out #29 bus control	
[597]	Pulse out #30/6 bus control	
[615]	Terminal 53 high ref./feedb. value	
[625]	Terminal 54 high ref./feedb. value	
[653]	Term 42 output bus ctrl	
[663]	Terminal X30/8 bus control	
[673]	Terminal X45/1 bus control	
[683]	Terminal X45/3 bus control	
[702]	Speed PID proportional gain	
[703]	Speed PID integral time	
[708]	Speed PID feed forward factor	
[748]	PCD feed forward	
[890]	Bus jog 1 speed	
[891]	Bus jog 2 speed	
[1444]	d-axis reference gain	
[1680]	Fieldbus CTW 1	
[1681]	Fieldbus sync. REF	
[1682]	Fieldbus REF 1	
[1683]	Fieldbus pos. REF	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[1685]	FC port CTW 1	
[1686]	FC port REF 1	
[1688]	Fieldbus torque FF.	
[1728]	SSI status bits	
[1740]	Fieldbus sync. delta	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[1741]	Fieldbus profile velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1742]	Fieldbus velocity FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.

Option	Name	Description
[1743]	Fieldbus acceleration FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1744]	Fieldbus target velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1782]	Home position	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[1783]	Homing speed	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1788]	Master home position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1797]	Number of CAM cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.

10-12 Process Data Config Read

Default value:	Size related	Parameter type:	Option, Array [4]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Option	Name	Description
[0]	None	
[15]	Readout: actual setup	
[1397]	Alert alarm word	
[1398]	Alert warning word	
[1399]	Alert status word	
[1444]	d-axis reference gain	
[1472]	Legacy alarm word	
[1473]	Legacy warning word	
[1474]	Leg. ext. status word	
[1500]	Operating hours	
[1501]	Running hours	
[1502]	kWh counter	
[1583]	Motor Ud	View the motor voltage on the d-axis. The value is a calculated value used for controlling the motor.

Option	Name	Description
[1584]	Motor Uq	View the motor voltage on the q-axis. The value is a calculated value used for controlling the motor.
[1585]	Motor Id	View the motor d-axis current measured as a mean value, I_{RMS} .
[1586]	Motor Iq	View the motor q-axis current measured as a mean value, I_{RMS} .
[1600]	Control word	
[1601]	Reference [unit]	
[1602]	Reference %	
[1603]	Status word	
[1605]	Main actual value [%]	
[1606]	Actual position	
[1607]	Target position	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[1608]	Position error	
[1609]	Custom readout	
[1610]	Power [kW]	
[1611]	Power [hp]	
[1612]	Motor voltage	
[1613]	Frequency	
[1614]	Motor current	
[1615]	Frequency [%]	
[1616]	Torque [Nm]	
[1617]	Speed [RPM]	
[1618]	Motor thermal	
[1619]	Thermistor sensor temperature	
[1620]	Motor angle	
[1621]	Torque [%] high res.	
[1622]	Torque [%]	
[1623]	Motor shaft power [kW]	
[1624]	Calibrated stator resistance	
[1625]	Torque [Nm] high	
[1628]	Angle error	
[1630]	DC link voltage	
[1632]	Brake energy /s	
[1633]	Brake energy average	
[1634]	Heatsink temp.	
[1635]	Inverter thermal	

Option	Name	Description
[1638]	SL controller state	
[1639]	Control card temp.	
[1642]	Service log counter	
[1644]	Speed error [RPM]	
[1645]	Motor phase U current	
[1646]	Motor phase V current	
[1647]	Motor phase W current	
[1648]	Speed ref. after ramp [RPM]	
[1650]	External reference	
[1651]	Pulse reference	
[1652]	Feedback[Unit]	
[1653]	Digi pot reference	
[1657]	Feedback [RPM]	
[1660]	Digital input	
[1661]	Terminal 53 switch setting	
[1662]	Analog input 53	
[1663]	Terminal 54 switch setting	
[1664]	Analog input 54	
[1665]	Analog output 42 [mA]	
[1666]	Digital output [bin]	
[1667]	Freq. input #29 [Hz]	
[1668]	Freq. input #33 [Hz]	
[1669]	Pulse output #27 [Hz]	
[1670]	Pulse output #29 [Hz]	
[1671]	Relay output [bin]	
[1672]	Counter A	
[1673]	Counter B	
[1674]	Prec. stop counter	
[1675]	Analog in X30/11	
[1676]	Analog in X30/12	
[1677]	Analog out X30/8 [mA]	
[1678]	Analog out X45/1 [mA]	
[1679]	Analog out X45/3 [mA]	
[1684]	Comm. option STW	
[1687]	Bus readout alarm/warning	
[1689]	Configurable alarm/warning word	
[1690]	Alarm word	

Option	Name	Description
[1691]	Alarm word 2	
[1692]	Warning word	
[1693]	Warning word 2	
[1694]	Ext. status word	
[1695]	Ext. status word 2	
[1696]	Maintenance word	
[1697]	Alarm word 3	
[1698]	Warning word 3	
[1699]	Ext. status word 3	
[1728]	SSI status bits	
[1766]	SSI status	
[1767]	Raw inc. quad counter	
[1768]	Raw abs. pos. low	
[1769]	Raw abs. pos. high	
[1804]	Mech brake count	
[1820]	Commanded position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1821]	Master position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1823]	Virtual master pos.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1824]	Marker pos. offset	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1825]	Latched actual pos.	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1826]	Actual velocity [pu/s]	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1827]	Safe opt. est. speed	
[1828]	Safe opt. meas. speed	
[1829]	Safe opt. speed error	
[1836]	Analog input X48/2 [mA]	
[1837]	Temp. input X48/4	

Option	Name	Description
[1838]	Temp. input X48/7	
[1839]	Temp. input X48/10	
[1840]	Analog input X49/1	
[1841]	Analog input X49/3	
[1842]	Analog input X49/5	
[1843]	Analog input X49/7	
[1844]	Analog out X49/9	
[1845]	Analog out X49/11	
[1846]	X49 digital output [bin]	
[1847]	Last warning	
[1848]	Last warning count	
[1860]	Digital input 2	
[1861]	Temp. input X48 max	
[1864]	Power based speed limit	
[1866]	Actual switching frequency	
[1867]	Alarm word 4	
[1868]	Warning word 4	
[1889]	Mode of operation display	NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1898]	Expected time to ramp down	NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[1899]	Speed PID torque FF. [Nm]	
[3421]	PCD 1 read from MCO	
[3422]	PCD 2 read from MCO	
[3423]	PCD 3 read from MCO	
[3424]	PCD 4 read from MCO	
[3425]	PCD 5 read from MCO	
[3426]	PCD 6 read from MCO	
[3427]	PCD 7 read from MCO	
[3428]	PCD 8 read from MCO	
[3429]	PCD 9 read from MCO	
[3430]	PCD 10 read from MCO	
[3440]	Digital inputs	
[3441]	Digital outputs	
[3450]	Actual position	

Option	Name	Description
[3451]	Commanded position	
[3452]	Actual master position	
[3453]	Slave index position	
[3454]	Master index position	
[3455]	Curve position	
[3456]	Track error	
[3457]	Synchronizing error	
[3458]	Actual velocity	
[3459]	Actual master velocity	
[3460]	Synchronizing status	
[3461]	Axis status	
[3462]	Program status	
[3464]	MCO 302 status	
[3465]	MCO 302 control	
[3466]	SPI error counter	
[3470]	MCO alarm word 1	
[3471]	MCO alarm word 2	
[4027]	Back EMF voltage	
[4029]	B-EMF protection log readout	
[4030]	Acc. delta speed	
[4031]	Acc. delta time	
[4032]	Dec. delta speed	
[4033]	Dec. delta time	
[4034]	Error code	
[4035]	DS402 Qstop	
[4036]	DS402 actual current	
[4037]	Motor current	
[4038]	Motor power	
[4039]	Motor torque	
[4280]	Safe option status	
[4281]	Safe option status 2	
[4282]	Safe control word	
[4283]	Safe status word	
[4285]	Active safe func.	
[4287]	Time until manual reset	
[4521]	Status	
[4523]	Baseline failure	

Option	Name	Description
[4589]	Cavitation [%]	
[4590]	Stator [%]	
[4591]	Load [%]	
[4592]	Sensor 1 [%]	
[4593]	Sensor 1 [unit]	
[4594]	Sensor 2 [%]	
[4595]	Sensor 2 [unit]	
[4596]	Sensor 3 [%]	
[4597]	Sensor 3 [unit]	
[4598]	Sensor 4 [%]	
[4599]	Sensor 4 [unit]	
[4901]	Autonomous status	
[4902]	Autonomous capacitance value	
[4911]	Baseline status	

10-13 Warning Parameter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

View a DeviceNet-specific warning word. One bit is assigned to every warning. Refer to the *VLT® DeviceNet MCA 104 Installation Guide* for further information.

Table 42: Warning Bits

Bit	Description
0	Bus not active
1	Explicit connection timeout
2	I/O connection
3	Retry limit reached
4	Actual is not updated
5	CAN bus off
6	I/O send error
7	Initialization error
8	No bus supply
9	Bus off
10	Error passive
11	Error warning
12	Duplicate MAC ID error
13	RX queue overrun

Table 42: Warning Bits - (continued)

Bit	Description
14	TX queue overrun
15	CAN overrun

10-14 Net Reference

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the reference source in instances 21/71 and 20/70.

Option	Name	Description
[0]*	Off	
[1]	On	

10-15 Net Control

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the control source in instances 21/71 and 20/70.

Option	Name	Description
[0]*	Off	
[1]	On	

6.12.3 10-2* COS Filters

10-20 COS Filter 1

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Sets up the filter mask for the status word. When operating in COS (change-of-state), it is possible to filter out bits in the status word that should not be sent if they change.

10-21 COS Filter 2

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Sets up the filter mask for the main actual value. When operating in COS (change-of-state), it is possible to filter out bits in the main actual value that should not be sent if they change.

10-22 COS Filter 3

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Sets up the filter mask for PCD 3. When operating in COS (change-of-state), it is possible to filter out bits in PCD 3 that should not be sent if they change.

10-23 COS Filter 4

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Sets up the filter mask for PCD 4. When operating in COS (change-of-state), it is possible to filter out bits in PCD 4 that should not be sent if they change.

6.12.4 10-3* Parameter Access

10-30 Array Index

Default value:	0	Parameter type:	Range, 0 - 255
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

View array parameters. This parameter is only valid when a VLT® DeviceNet MCA 104 is installed.

10-31 Store Data Value

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter is used to activate a function that stores all parameter values in the non-volatile memory. The changed parameter values are retained at power-down.

Option	Name	Description
[0]*	Off	Deactivates the non-volatile storage function.
[1]	Store all setups	Stores all parameter values from the active setups in the non-volatile memory. The selection returns to [0] Off when all values have been stored.
[2]	Store all setups	Stores all parameter values for all setups in the non-volatile memory. The selection returns to [0] Off when all parameter values have been stored.

10-32 Devicenet Revision

Default value:	0	Parameter type:	Readout, Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

The DeviceNet revision number. This parameter is used for EDS file creation.

10-33 Store Always

Default value:	[0] Off	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data value:	Uint8	Change during operation:	True

This parameter is used to select whether parameter data received via the DeviceNet option should always be stored in non-volatile memory.

Option	Name	Description
[0]*	Off	Deactivates non-volatile storage of data.
[1]	On	Stores parameter data received via VLT® DeviceNet MCA 104 in EEPROM non-volatile memory as default.

10-34 DeviceNet Product Code

Default value:	Size related	Parameter type:	Range, 0 - 65535
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Use this parameter for reading out the actual DeviceNet product code.

10-39 Devicenet F Parameters

Default value:	0	Parameter type:	Readout, Array [1000]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Use this parameter to configure the drive via DeviceNet and build the EDS file.

6.12.5 10-5* CANopen

10-50 Process Data Config Write

Default value:	–	Parameter type:	Option, Array [8]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Only elements [2] and [3] of this array can be selected. [0] and [1] are fixed.

Option	Name	Description
[0]	None	
[109]	Mode of operation	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[302]	Minimum reference	
[303]	Maximum reference	
[311]	Jog speed [Hz]	
[312]	Catch up/slow down value	
[319]	Jog speed [RPM]	
[321]	Touch target	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[322]	Master scale numerator	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[323]	Master scale denominator	 NOTE: This option is only available in FC 302 with IMC software version 48.X11X or newer.
[326]	Master Offset	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[328]	Master offset speed ref	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[330]	Min. speed ramp time	
[341]	Ramp 1 ramp up time	
[342]	Ramp 1 ramp down time	
[351]	Ramp 2 ramp up time	
[352]	Ramp 2 ramp down time	
[361]	Ramp 3 ramp up time	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[362]	Ramp 3 ramp down time	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[380]	Jog/homing ramp time jog ramp time	
[381]	Quick stop ramp time	
[411]	Motor speed low limit [RPM]	
[412]	Motor speed low limit [Hz]	

Option	Name	Description
[413]	Motor speed high limit [RPM]	
[414]	Motor speed high limit [Hz]	
[416]	Torque limit motor mode	
[417]	Torque limit generator mode	
[482]	Power limit motor mode	
[483]	Power limit generator mode	
[491]	Positive speed limit [RPM]	
[492]	Positive speed limit [Hz]	
[493]	Negative speed limit [RPM]	
[494]	Negative speed limit [Hz]	
[495]	Positive torque limit	
[496]	Negative torque limit	
[553]	Term. 29 high ref./feedb. value	
[558]	Term. 33 high ref./feedb. value	
[590]	Digital & relay bus control	
[593]	Pulse out #27 bus control	
[595]	Pulse out #29 bus control	
[597]	Pulse out #30/6 bus control	
[615]	Terminal 53 high ref./feedb. value	
[625]	Terminal 54 high ref./feedb. value	
[653]	Term 42 output bus ctrl	
[663]	Terminal X30/8 bus control	
[673]	Terminal X45/1 bus control	
[683]	Terminal X45/3 bus control	
[702]	Speed PID proportional gain	
[703]	Speed PID integral time	
[708]	Speed PID feed forward factor	
[748]	PCD feed forward	
[890]	Bus jog 1 speed	
[891]	Bus jog 2 speed	
[1680]	Fieldbus CTW 1	
[1681]	Fieldbus sync. REF	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[1682]	Fieldbus REF 1	

Option	Name	Description
[1683]	Fieldbus pos. REF	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[1685]	FC port CTW 1	
[1686]	FC port REF 1	
[1688]	Fieldbus torque FF.	
[1728]	SSI status bits	
[1740]	Fieldbus sync. delta	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[1741]	Fieldbus profile velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1742]	Fieldbus velocity FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1743]	Fieldbus acceleration FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1744]	Fieldbus target velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1782]	Home position	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[1783]	Homing speed	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1788]	Master home position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1797]	Number of CAM cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.

10-51 Process Data Config Read

Default value:	–	Parameter type:	Option, Array [8]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Only elements [2] and [3] of this array can be selected. [0] and [1] are fixed.

Option	Name	Description
[0]	None	
[15]	Readout: actual setup	
[1397]	Alert alarm word	
[1398]	Alert warning word	
[1399]	Alert status word	
[1444]	d-axis reference gain	
[1472]	Legacy alarm word	
[1473]	Legacy warning word	
[1474]	Leg. ext. status word	
[1500]	Operating hours	
[1501]	Running hours	
[1502]	kWh counter	
[1583]	Motor Ud	View the motor voltage on the d-axis. The value is a calculated value for controlling the motor.
[1584]	Motor Uq	View the motor voltage on the q-axis. The value is a calculated value for controlling the motor.
[1585]	Motor Id	View the motor d-axis current measured as a mean value, I_{RMS} .
[1586]	Motor Iq	View the motor q-axis current measured as a mean value, I_{RMS} .
[1600]	Control word	
[1601]	Reference [unit]	
[1602]	Reference %	
[1603]	Status word	
[1605]	Main actual value [%]	
[1606]	Actual position	
[1607]	Target position	
[1608]	Position error	
[1609]	Custom readout	
[1610]	Power [kW]	
[1611]	Power [hp]	
[1612]	Motor voltage	
[1613]	Frequency	
[1614]	Motor current	
[1615]	Frequency [%]	
[1616]	Torque [Nm]	
[1617]	Speed [RPM]	
[1618]	Motor thermal	

Option	Name	Description
[1619]	Thermistor sensor temperature	
[1620]	Motor angle	
[1621]	Torque [%] high res.	
[1622]	Torque [%]	
[1623]	Motor shaft power [kW]	
[1624]	Calibrated stator resistance	
[1625]	Torque [Nm] high	
[1628]	Angle error	
[1630]	DC link voltage	
[1632]	Brake energy /s	
[1633]	Brake energy average	
[1634]	Heatsink temp.	
[1635]	Inverter thermal	
[1638]	SL controller state	
[1639]	Control card temp.	
[1642]	Service log counter	
[1644]	Speed error [RPM]	
[1645]	Motor phase U current	
[1646]	Motor phase V current	
[1647]	Motor phase W current	
[1648]	Speed ref. after ramp [RPM]	
[1650]	External reference	
[1651]	Pulse reference	
[1652]	Feedback[Unit]	
[1653]	Digi pot reference	
[1657]	Feedback [RPM]	
[1660]	Digital input	
[1661]	Terminal 53 switch setting	
[1662]	Analog input 53	
[1663]	Terminal 54 switch setting	
[1664]	Analog input 54	
[1665]	Analog output 42 [mA]	
[1666]	Digital output [bin]	
[1667]	Freq. input #29 [Hz]	
[1668]	Freq. input #33 [Hz]	
[1669]	Pulse output #27 [Hz]	
[1670]	Pulse output #29 [Hz]	

Option	Name	Description
[1671]	Relay output [bin]	
[1672]	Counter A	
[1673]	Counter B	
[1674]	Prec. stop counter	
[1675]	Analog in X30/11	
[1676]	Analog in X30/12	
[1677]	Analog out X30/8 [mA]	
[1678]	Analog out X45/1 [mA]	
[1679]	Analog out X45/3 [mA]	
[1684]	Comm. option STW	
[1687]	Bus readout alarm/warning	
[1689]	Configurable alarm/warning word	
[1690]	Alarm word	
[1691]	Alarm word 2	
[1692]	Warning word	
[1693]	Warning word 2	
[1694]	Ext. status word	
[1695]	Ext. status word 2	
[1696]	Maintenance word	
[1697]	Alarm word 3	
[1698]	Warning word 3	
[1699]	Extended status word 3	
[1728]	SSI status bits	
[1766]	SSI status	
[1767]	Raw inc. quad counter	
[1768]	Raw abs. pos. low	
[1769]	Raw abs. pos. high	
[1804]	Mech brake count	
[1820]	Commanded position	NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1821]	Master position	NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1823]	Virtual master pos.	NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.

Option	Name	Description
[1824]	Marker pos. offset	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1825]	Latched actual pos.	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1826]	Actual velocity [pu/s]	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1827]	Safe opt. est. speed	
[1828]	Safe opt. meas. speed	
[1829]	Safe opt. speed error	
[1836]	Analog input X48/2 [mA]	
[1837]	Temp. input X48/4	
[1838]	Temp. input X48/7	
[1839]	Temp. input X48/10	
[1840]	Analog input X49/1	
[1841]	Analog input X49/3	
[1842]	Analog input X49/5	
[1843]	Analog input X49/7	
[1844]	Analog out X49/9	
[1845]	Analog out X49/11	
[1846]	X49 digital output [bin]	
[1847]	Last warning	
[1848]	Last warning counter	
[1860]	Digital input 2	
[1861]	Temp. input X48 max	
[1864]	Power based speed limit	
[1866]	Actual switching frequency	
[1867]	Alarm word 4	
[1868]	Warning word 4	
[1889]	Mode of operation display	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1898]	Expected time to ramp down	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[1899]	Speed PID torque FF. [Nm]	

6.13 Parameter Group 12-** Ethernet

6.13.1 12-0* IP Settings

12-00 IP Address Assignment

Default value:	–	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the method for assigning the IP address.

Option	Name	Description
[0]	Manual	Set the IP address in parameter 12-01 IP Address .
[1]	DHCP	Assign the IP address via DHCP server.
[2]	BOOTP	Assign the IP address via BOOTP server.
[10]	DCP	Assign the IP address via DCP server.
[20]	From node ID	

12-01 IP Address

Default value:	0	Parameter type:	Range, 0 - 4294967295
Setup:	1 setup	Conversion index:	0
Data type:	OctStr[4]	Change during operation:	True

Configure the IP address of the option. Read-only if parameter **12-00 IP Address Assignment** is set to **[1] DHCP**, **[2] BOOTP**, or via DIP switches. In POWERLINK, the IP address follows the last by of parameter **12-60 Node ID** and the 1st part is fixed to 192.168.100 (node ID).

12-02 Subnet Mask

Default value:	0	Parameter type:	Range, 0 - 4294967295
Setup:	1 setup	Conversion index:	0
Data type:	OctStr[4]	Change during operation:	True

Configure the IP subnet mask of the option. Read-only if parameter **12-00 IP Address Assignment** is set to **[1] DHCP** or **[2] BOOTP**.

12-03 Default Gateway

Default value:	0	Parameter type:	Range, 0 - 4294967295
Setup:	1 setup	Conversion index:	0
Data type:	OctStr[4]	Change during operation:	True

Configure the IP default gateway of the option. Read-only if parameter **12-00 IP Address Assignment** set to **[1] DHCP** or **[2] BOOTP**. In a non-routed network, this address is set to the IP address of the I/O device.

12-04 DHCP Server

Default value:	0	Parameter type:	Range, 0 - 2147483647

Setup:	2 setups	Conversion index:	0
Data type:	OctStr[4]	Change during operation:	True



NOTE: A power cycle is necessary after setting the IP parameters manually.

This parameter is read-only. It shows the IP address of the found DHCP or BOOTP server.

12-05 Lease Expires

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeDifferenceWithDateIndication	Change during operation:	True

This parameter is read-only. It shows the lease time for the current DHCP-assigned IP address.

12-06 Name Servers

Default value:	0	Parameter type:	Array [2]
Setup:	1 setup	Conversion index:	0
Data type:	OctStr[4]	Change during operation:	True

IP addresses of the domain name servers. Can be automatically assigned when using DHCP.

12-07 Domain Name

Default value:	0	Parameter type:	Range, 0 - 48
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[48]	Change during operation:	True

Domain name of the attached network. Can be automatically assigned when using DHCP network.

12-08 Host Name

Default value:	0	Parameter type:	Range, 0 - 48
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[48]	Change during operation:	True



NOTE: The display of the drive only shows the 1st 19 characters, but the remaining characters are stored in the drive.

Logical (given) name of the option.

12-09 Physical Address

Default value:	0	Parameter type:	Range, 0 - 17
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[17]	Change during operation:	True

This parameter is read-only. It shows the physical (MAC) address of the option.

6.13.2 12-1* Ethernet Link Parameters

12-10 Link Status

Default value:	[0] No link	Parameter type:	Readout, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter is read-only. It shows the link status of the Ethernet ports. Index [0] is used for port 1, and index [1] is used for port 2. For EtherCAT, index [0] is for the in-port, and index [1] is for the out-port.

Index	Description
[0]*	No link
[1]	Link

12-11 Link Duration

Default value:	Size related	Parameter type:	Readout, Array [2]
Setup:	All setups	Conversion index:	0
Data type:	TimeDifferenceWithDateIndication	Change during operation:	True

Shows the duration of the present link on each port in dd:hh:mm:ss.

12-12 Auto Negotiation

Default value:	Size related	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Configures auto negotiation of Ethernet link parameters, for each port: ON or OFF. Link Speed and Link Duplex can be configured in parameter **12-13 Link Speed** and parameter **12-14 Link Duplex**.

Option	Name	Description
[0]	Off	
[1]	On	

12-13 Link Speed

Default value:	–	Parameter type:	Option, Array [2]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Forces the link speed for each port in 10 Mbps or 100 Mbps. If parameter **12-12 Auto Negotiation** is set to **[0] On**, this parameter is read-only and shows the actual link speed. If no link is present, None is shown.

Option	Name	Description
[0]	None	
[1]	10 Mbps	
[2]	100 Mbps	

12-14 Link Duplex

Default value:	–	Parameter type:	Option, Array [2]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: In POWERLINK, this parameter is locked to half duplex.

Forces the duplex for each port to full or half duplex. If parameter **12-12 Auto Negotiation** is set to **[1] On**, this parameter is read-only.

Option	Name	Description
[0]	Half duplex	
[1]	Full duplex	

12-18 Supervisor MAC

Default value:	0	Parameter type:	Array [2]
Setup:	2 setups	Conversion index:	0
Data type:	OctStr[6]	Change during operation:	True

MAC addresses of currently active supervisors.

12-19 Supervisor IP Addr.

Default value:	0	Parameter type:	Array [2]
Setup:	2 setups	Conversion index:	0
Data type:	OctStr[4]	Change during operation:	True

IP addresses of currently active supervisors.

6.13.3 12-2* Process Data

12-20 Control Instance

Default value:	Size related	Parameter type:	Range, 0 - 255
Setup:	1 setup	Conversion index:	0
Data type:	Uint8	Change during operation:	True

This parameter is read-only. It shows the connection to the master.

- In Ethernet/IP: If no CIP connection is present, None is shown.
- In EtherCAT: If no connection is active, None is shown, otherwise it shows the active PDO.

- In POWERLINK: If no connection is active, None is shown, otherwise it shows the active PDO (23).

12-21 Process Data Config Write

Default value:	Size related	Parameter type:	Option, Array [20]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Option	Name	Description
[0]	None	
[109]	Mode of operation	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[302]	Minimum reference	
[303]	Maximum reference	
[311]	Jog speed [Hz]	
[312]	Catch up/slow down value	
[319]	Jog speed [RPM]	
[321]	Touch target	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[322]	Master scale numerator	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[323]	Master scale denominator	 NOTE: This option is only available in FC 302 with IMC software version 48.1X or newer.
[326]	Master Offset	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[328]	Master offset speed ref	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[330]	Min. speed ramp time	
[341]	Ramp 1 ramp up time	
[342]	Ramp 1 ramp down time	
[351]	Ramp 2 ramp up time	
[352]	Ramp 2 ramp down time	
[361]	Ramp 3 ramp up time	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.

Option	Name	Description
[362]	Ramp 3 ramp down time	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[380]	Jog/homing ramp time jog ramp time	
[381]	Quick stop ramp time	
[411]	Motor speed low limit [RPM]	
[412]	Motor speed low limit [Hz]	
[413]	Motor speed high limit [RPM]	
[414]	Motor speed high limit [Hz]	
[416]	Torque limit motor mode	
[417]	Torque limit generator mode	
[482]	Power limit motor mode	
[483]	Power limit generator mode	
[491]	Positive speed limit [RPM]	
[492]	Positive speed limit [Hz]	
[493]	Negative speed limit [RPM]	
[494]	Negative speed limit [Hz]	
[495]	Positive torque limit	
[496]	Negative torque limit	
[553]	Term. 29 high ref./feedb. value	
[558]	Term. 33 high ref./feedb. value	
[590]	Digital & relay bus control	
[593]	Pulse out #27 bus control	
[595]	Pulse out #29 bus control	
[597]	Pulse out #30/6 bus control	
[615]	Terminal 53 high ref./feedb. value	
[625]	Terminal 54 high ref./feedb. value	
[653]	Term 42 output bus ctrl	
[663]	Terminal X30/8 bus control	
[673]	Terminal X45/1 bus control	
[683]	Terminal X45/3 bus control	
[702]	Speed PID proportional gain	
[703]	Speed PID integral time	
[708]	Speed PID feed forward factor	
[748]	PCD feed forward	
[890]	Bus jog 1 speed	
[891]	Bus jog 2 speed	

Option	Name	Description
[1444]	d-axis reference gain	
[1680]	Fieldbus CTW 1	
[1681]	Fieldbus sync. REF	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[1682]	Fieldbus REF 1	
[1683]	Fieldbus pos. REF	 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.
[1685]	FC port CTW 1	
[1686]	FC port REF 1	
[1688]	Fieldbus torque FF.	
[1728]	SSI status bits	
[1740]	Fieldbus sync. delta	 NOTE: This option is only available in FC 302 with IMC software version 48.7X or newer.
[1741]	Fieldbus profile velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1742]	Fieldbus velocity FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1743]	Fieldbus acceleration FF.	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1744]	Fieldbus target velocity	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1782]	Home position	 NOTE: This option is only available in FC 302 with IMC software version 48.3X or newer.
[1783]	Homing speed	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1788]	Master home position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1797]	Number of CAM cycles	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.

12-22 Process Data Config Read

Default value:	–	Parameter type:	Option, Array [20]
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Option	Name	Description
[0]	None	
[15]	Readout: actual setup	
[1397]	Alert alarm word	
[1398]	Alert warning word	
[1399]	Alert status word	
[1444]	d-axis reference gain	
[1472]	Legacy alarm word	
[1473]	Legacy warning word	
[1474]	Leg. ext. status word	
[1500]	Operating hours	
[1501]	Running hours	
[1502]	kWh counter	
[1583]	Motor Ud	View the motor voltage on the d-axis. The value is a calculated value for controlling the motor.
[1584]	Motor Uq	View the motor voltage on the q-axis. The value is a calculated value for controlling the motor.
[1585]	Motor Id	View the motor d-axis current measured as a mean value, I_{RMS} .
[1586]	Motor Iq	View the motor q-axis current measured as a mean value, I_{RMS} .
[1600]	Control word	
[1601]	Reference [unit]	
[1602]	Reference %	
[1603]	Status word	
[1605]	Main actual value [%]	
[1606]	Actual position	
[1607]	Target position	
 NOTE: This option is only available in FC 302 with IMC software version 48.0X or newer.		
[1608]	Position error	
[1609]	Custom readout	
[1610]	Power [kW]	
[1611]	Power [hp]	
[1612]	Motor voltage	
[1613]	Frequency	

Option	Name	Description
[1614]	Motor current	
[1615]	Frequency [%]	
[1616]	Torque [Nm]	
[1617]	Speed [RPM]	
[1618]	Motor thermal	
[1619]	Thermistor sensor temperature	
[1620]	Motor angle	
[1621]	Torque [%] high res.	
[1622]	Torque [%]	
[1623]	Motor shaft power [kW]	
[1624]	Calibrated stator resistance	
[1625]	Torque [Nm] high	
[1628]	Angle error	
[1630]	DC link voltage	
[1632]	Brake energy /s	
[1633]	Brake energy average	
[1634]	Heatsink temp.	
[1635]	Inverter thermal	
[1638]	SL controller state	
[1639]	Control card temp.	
[1642]	Service log counter	
[1644]	Speed error [RPM]	
[1645]	Motor phase U current	
[1646]	Motor phase V current	
[1647]	Motor phase W current	
[1648]	Speed ref. after ramp [RPM]	
[1650]	External reference	
[1651]	Pulse reference	
[1652]	Feedback[Unit]	
[1653]	Digi pot reference	
[1657]	Feedback [RPM]	
[1660]	Digital input	
[1661]	Terminal 53 switch setting	
[1662]	Analog input 53	
[1663]	Terminal 54 switch setting	
[1664]	Analog input 54	
[1665]	Analog output 42 [mA]	

Option	Name	Description
[1666]	Digital output [bin]	
[1667]	Freq. input #29 [Hz]	
[1668]	Freq. input #33 [Hz]	
[1669]	Pulse output #27 [Hz]	
[1670]	Pulse output #29 [Hz]	
[1671]	Relay output [bin]	
[1672]	Counter A	
[1673]	Counter B	
[1674]	Prec. stop counter	
[1675]	Analog in X30/11	
[1676]	Analog in X30/12	
[1677]	Analog out X30/8 [mA]	
[1678]	Analog out X45/1 [mA]	
[1679]	Analog out X45/3 [mA]	
[1684]	Comm. option STW	
[1687]	Bus readout alarm/warning	
[1689]	Configurable alarm/warning word	
[1690]	Alarm word	
[1691]	Alarm word 2	
[1692]	Warning word	
[1693]	Warning word 2	
[1694]	Ext. status word	
[1695]	Ext. status word 2	
[1696]	Maintenance word	
[1697]	Alarm word 3	
[1698]	Warning word 3	
[1699]	Ext. status word 3	
[1728]	SSI status bits	
[1766]	SSI status	
[1767]	Raw inc. quad counter	
[1768]	Raw abs. pos. low	
[1769]	Raw abs. pos. high	
[1804]	Mech brake count	
[1820]	Commanded position	



NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.

Option	Name	Description
[1821]	Master position	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1823]	Virtual master pos.	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1824]	Marker pos. offset	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1825]	Latched actual pos.	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1826]	Actual velocity [pu/s]	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1827]	Safe opt. est. speed	
[1828]	Safe opt. meas. speed	
[1829]	Safe opt. speed error	
[1836]	Analog input X48/2 [mA]	
[1837]	Temp. input X48/4	
[1838]	Temp. input X48/7	
[1839]	Temp. input X48/10	
[1840]	Analog input X49/1	
[1841]	Analog input X49/3	
[1842]	Analog input X49/5	
[1843]	Analog input X49/7	
[1844]	Analog out X49/9	
[1845]	Analog out X49/11	
[1846]	X49 digital output [bin]	
[1847]	Last warning	
[1848]	Last warning counter	
[1860]	Digital input 2	
[1861]	Temp. input X48 max	
[1864]	Power based speed limit	
[1866]	Actual switching frequency	
[1867]	Alarm word 4	
[1868]	Warning word 4	

Option	Name	Description
[1889]	Mode of operation display	 NOTE: This option is only available in FC 302 with IMC software version 48.8X or newer.
[1898]	Expected time to ramp down	 NOTE: This option is only available in FC 302 with IMC software version 48.96 or newer.
[1899]	Speed PID torque FF. [Nm]	

12-23 Process Data Config Write Size

Default value:	16	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

 NOTE: This parameter is only valid for EtherCat.

Use this parameter to configure the PCD write size in bits. Only values of multiples of 8 are valid.

12-24 Process Data Config Read Size

Default value:	16	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

 NOTE: This parameter is only valid for EtherCAT.

Use this parameter to configure the PCD read size in bits. Only values of multiples of 8 are valid.

12-27 Master Address

Default value:	0	Parameter type:	Array [2]
Setup:	2 setups	Conversion index:	0
Data type:	OctStr[4]	Change during operation:	False

This parameter holds the valid ip addresses for masters that are allowed to control this follower. If both indexes are set to 0.0.0.0, all masters have access.

12-28 Store Data Values

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter activates a function that stores all parameter values in the non-volatile memory (EEPROM) thus retaining parameter values at power-down. The parameter returns to **[0] Off**.

Option	Name	Description
[0]*	Off	
[1]	Store all setups	
[2]	Store all setups	

12-29 Store Always

Default value:	[0] Off	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Activates a function that always stores received parameter data in the non-volatile memory (EEPROM).

Option	Name	Description
[0]*	Off	
[1]	On	

6.13.4 12-3* EtherNet/IP

12-30 Warning Parameter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type	Uint32	Change during operation:	True

This parameter is read-only. It shows the EtherNet/IP-specific 16-bit status word.

Table 43: 16-Bit Status Word, EtherNet/IP

Bit	Description
0	Owned
1	Not used
2	Configured
3	Not used
4	Not used
5	Not used
6	Not used
7	Not used
8	Minor recoverable fault
9	Minor unrecoverable fault
10	Major recoverable fault
11	Major unrecoverable fault
12	Not used

Table 43: 16-Bit Status Word, EtherNet/IP - (continued)

Bit	Description
13	Not used
14	Not used
15	Not used

12-31 Net Reference

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Shows the reference source in instance 21/71.

Option	Name	Description
[0]*	Off	
[1]	On	

12-32 Net Control

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uin8	Change during operation:	True

Shows the control source in instance 21/71.

Option	Name	Description
[0]*	Off	
[1]	On	

12-33 CIP Revision

Default value:	Size related	Parameter type:	Readout, Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter is read-only. It shows the CIP version of the option software.

12-34 CIP Product Code

Default value:	Size related	Parameter type:	Range, 0 - 65535
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter is read-only. It shows the CIP product code.

12-35 EDS Parameter

Default value:	0	Parameter type:	Readout, Array [1000]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter is used to configure the drive via DeviceNet and build the EDS-file.

12-37 COS Inhibit Timer

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Read-only change-of-state inhibit timer. If the option is configured for COS operation, this inhibit timer can be configured in the forward open telegram to prevent the continuously changing PCD data from generating extensive network traffic. The inhibit time is in ms. 0 = disabled.

12-38 COS Filter

Default value:	0	Parameter type:	Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Change-of-state PCD filters. Sets up a filter mask for each word of process data when operating in COS mode. Single bits in the PCDs can be filtered in/out.

6.13.5 12-4* Modbus TCP

12-40 Status Parameter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter is read-only. It shows the Modbus TCP-specific 16-bit status word.

Table 44: 16-Bit Status Word, Modbus TCP

Bit	Description	Bit = [0]	Bit = [1]
0	Link status port 1	Disconnected	Connected
1	Link status port 2	Disconnected	Connected
2	Link speed	0/10 Mbps	100 Mbps
3	Link duplex	Half	Full
4	Port 502 communication	No	Yes
5	UNUSED	–	–
6	Valid IP address	No	Yes
7	Modbus timeout (30 s)	No	Yes

Table 44: 16-Bit Status Word, Modbus TCP - (continued)

Bit	Description	Bit = [0]	Bit = [1]
8	Duplicate IP	No	Yes
9	Register 7 error	No	Yes
10	FTP server	Disabled	Enabled
11	HTTP server	Disabled	Enabled
12	SMTP server	Disabled	Enabled
13	Cable diagnosis	Disabled	Enabled
14	Auto crossover	Disabled	Enabled
15	IPMG	Disabled	Enabled

12-41 Slave Message Count

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter is read-only. It shows the number of Modbus messages received and processed by the follower drive.

12-42 Slave Exception Message Count

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter is read-only. It shows the number of Modbus messages for which the follower has sent an exception response.

6.13.6 12-4* Fieldbus Extension

12-49 Ethernet Extended Status

Default value:	0hex	Parameter type:	Array [20], Array [16] for IMC
Setup:	1 setup	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter provides extra information from Ethernet-based communication.

6.13.7 12-5* EtherCAT

12-50 Configured Station Alias

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Changes are first active after a power cycle. If the DIP switches are all set to ON or all to OFF, the display setting has priority over the DIP switch. Otherwise, the DIP switch settings have priority over the parameter. In this case, the parameter reflects the setting of the DIP switches. Changes to the DIP switch setting are active after a power-up.

12-51 Configured Station Address

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter shows the configured station address. The parameter can only be set by the master at power-up.

12-59 EtherCAT Status

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter contains status information on the EtherCAT interface. Each of the 32 bits is linked to a status information of the EtherCAT interface.

- Bits 0–7 contain information from ESC register 0x0130 (AL status).
- Bits 8–15 are reserved for future use.
- Bits 16–27 contain information from the ESC register 0x0110 and 0x0111 (DL status).
- Bits 28–31 are reserved for future use.

Table 45: Bit Interpretation

Bit	Description	Bit = [0]	Bit = [1]
0	EtherCAT statemachine state	–	Init State
1	EtherCAT statemachine state	–	Pre-OP
2	EtherCAT statemachine state	–	Safe-OP
3	EtherCAT statemachine state	–	Reserved
4	Reserved	–	–
5	Reserved	–	–
6	Reserved	–	–
7	Reserved	–	–
8	Reserved	–	–
9	Reserved	–	–
10	Reserved	–	–
11	Reserved	–	–
12	Reserved	–	–
13	Reserved	–	–
14	Reserved	–	–
15	Reserved	–	–

Table 45: Bit Interpretation - (continued)

Bit	Description	Bit = [0]	Bit = [1]
16	PDI operational	EEPROM not loaded, PDI not operational	EEPROM loaded correctly, PDI operational
17	PDI watchdog status	Watchdog expired	Watchdog reloaded
18	Enhanced link detection	Deactivated for all ports	Activated for all ports
19	–	–	Reserved
20	Physical link on port 0	No link	Link detected
21	Physical link on port 1	No link	Link detected
22	Reserved	–	–
23	Reserved	–	–
24	Loop port 0	Open	Closed
25	Communication on port 0	No stable communication	Communication established
26	Loop port 1	Open	Closed
27	Communication on port 1	No stable communication	Communication established
28	Reserved	–	–
29	Reserved	–	–
30	Reserved	–	–
31	Reserved	–	–

6.13.8 12-6* Ethernet POWERLINK

12-60 Node ID

Default value:	1	Parameter type:	Range, 1 - 239
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the node ID in this parameter or alternatively in the hardware switch. To adjust the node ID in this parameter, set the hardware switch to 0 or to 255 (all switches set to [ON] or to [OFF]). Otherwise, this parameter shows the actual setting of the switch. The settings of this parameter take effect at the next power-up cycle.

12-62 SDO Timeout

Default value:	15000 ms	Parameter type:	Range, 0 - 2000000000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

This parameter is the SDO Timeout in ms. The value of this parameter is read during communication initialization into Object 1300h.

12-63 Basic Ethernet Timeout

Default value:	5000.000 ms	Parameter type:	Range, 0 - 2000000.000 ms
Setup:	All setups	Conversion index:	-3

Data type:	Uint32	Change during operation:	True

This parameter is the basic Ethernet timeout in ms. This parameter is mapped to Object 1F99h. If the POWERLINK interface does not receive a SoC frame within the specified time, the interface shifts to standard Ethernet mode. This feature is available from version 2.00 of the POWERLINK interface.

12-66 Threshold

Default value:	15	Parameter type:	Array [6]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter holds 6 threshold values. If 1 of these thresholds are exceeded, the POWERLINK interface exits operational mode. The parameters are set to optimal settings and should not be changed. The actual value of the counters can be read out via parameter **12-67 Threshold Counters**.

12-67 Threshold Counters

Default value:	0	Parameter type:	Array [6]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter holds 6 counters. The counter reflects the actual value in the POWERLINK interface. Counters increase with a count of 8 at detection of an error and decrease with a count of 1 when no errors are detected. The values are read-only.

12-68 Cumulative Counters

Default value:	0	Parameter type:	Array [6]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Loss of SoC Cumulative. This parameter reflects the value in object 1C0Bh, sub-index 1.

12-69 Ethernet POWERLINK Status

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter shows various status and error conditions for the Ethernet POWERLINK connection.

6.13.9 12-8* Other Ethernet Services

12-80 FTP Server

Default value:	[0] Disabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Enables/disables the built-in FTP server.

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	

12-81 HTTP Server

Default value:	[0] Disabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Enables/disables the built-in HTTP (web) server.

Option	Name	Description
[0]*	Disabled	Disable the built-in HTTP (web) server.
[1]	Enabled	Enable the built-in HTTP (web) server.

12-82 SMTP Service

Default value:	[0] Disabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Enables/disables the built-in SMTP (e-mail) service on the option.

Option	Name	Description
[0]*	Disabled	Disable the SMTP (e-mail) service on the option.
[1]	Enabled	Enable the SMTP (e-mail) service on the option.

12-83 SNMP Agent

Default value:	[1] Enabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use this parameter to either enable or disable the SNMP agent.

Option	Name	Description
[0]	Disabled	Disable the SNMP agent.
[1]*	Enabled	Enable the SNMP agent.

12-84 Address Conflict Detection

Default value:	[1] Enabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use this parameter to detect and resolve IP address conflict.

Option	Name	Description
[0]	Disabled	
[1]*	Enabled	

12-85 ACD Last Conflict

Default value:	0	Parameter type:	Range, 0 - 2147483647
Setup:	2 setups	Conversion index:	0
Data type:	OctStr[35]	Change during operation:	True

The name of the IP address causing the most recent address conflict.

12-86 NTP Host Server

Default value:	0	Parameter type:	Array [2]
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[48]	Change during operation:	True

Enter the IPv4/IPv6 address, the FQDN, or the hostname of the NTP server.

12-87 SNTP Time Sync

Default value:	60 min	Parameter type:	Range, 1 - 65535 min
Setup:	1 setup	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Synchronize the clock via NTP at a defined interval.

12-89 Transparent Socket Channel Port

Default value:	Size related	Parameter type:	Range, 0 - 65535
Setup:	2 setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Configures the TCP port number for the transient socket channel. This enables FC telegrams to be sent transiently on Ethernet via TCP. 0 indicates that the function is disabled.

6.13.10 12-9* Advanced Ethernet Services

12-90 Cable Diagnostics

Default value:	[0] Disabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Enables/disables advanced cable diagnosis function. If enabled, the distance to cable errors can be read out in parameter **12-93 Cable Error Length**. The parameter resumes to the default setting **[0] Disable** after the diagnostics have finished.



NOTE: The cable diagnostics function is only issued on ports where there is no link (see parameter **12-10 Link Status**).

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	

12-91 Auto Cross Over

Default value:	[1] Enabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: Disabling of the auto-crossover function requires crossed Ethernet cables for daisy-chaining the options.

Option	Name	Description
[0]	Disabled	
[1]*	Enabled	

12-92 IGMP Snooping

Default value:	[1] Enabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Enabling the IGMP snooping function prevents flooding of the Ethernet protocol stack. Multicast packets are only forwarded to ports that are a member of the multicast group.

Option	Name	Description
[0]	Disabled	The IGMP snooping function is disabled.
[1]*	Enabled	The IGMP snooping function is enabled.

12-93 Cable Error Length

Default value:	0	Parameter type:	Array [2]
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

If cable diagnostics is enabled in parameter **12-90 Cable Diagnostic**, the built-in switch is possible via time domain reflectometry (TDR). This is a measurement technique which detects common cabling problems such as open circuits, short circuits, and impedance mismatches or breaks in transmission cables. The distance from the option to the error is shown in meters with an accuracy of ± 2 m (6.6 ft). The value 0 means no errors detected.

12-94 Broadcast Storm Protection

Default value:	-1%	Parameter type:	Range, -1 - 20%

Setup:	2 setups	Conversion index:	0
Data type:	Int8	Change during operation:	True

The built-in switch is capable of protecting the switch system from receiving too many broadcast packages, which can use up network resources. The value indicates a percentage of the total bandwidth that is allowed for broadcast messages. Example: OFF means that the filter is disabled - all broadcast messages are passed through. The value 0% means that no broadcast messages are passed through. A value of 10% means that 10% of the total bandwidth is allowed for broadcast messages. If the amount of broadcast messages exceeds the 10% threshold, they are blocked.

12-95 Inactivity Timeout

Default value:	120	Parameter type:	Range, 0 - 3600
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Applies to parameter **12-94 Broadcast Storm Protection**, if the broadcast storm protection also includes multicast telegrams.

12-96 Port Config

Default value:	[0] Normal	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Enable or disable the port-mirroring function. The function is used for troubleshooting with a network analyzer tool.

Option	Name	Description
[0]*	Normal	
[1]	Mirror port 1 to 2	
[2]	Mirror port 2 to 1	
[10]	Port 1 disabled	
[11]	Port 2 disabled	
[254]	Mirror int. port to 1	 NOTE: This option is only available in FC 302 with IMC software version 48.0X.
[255]	Mirror int. port to 2	 NOTE: This option is only available in FC 302 with IMC software version 48.0X.

12-97 QoS Priority

Default value:	Size related	Parameter type:	Array [7]
Setup:	2 setups	Conversion index:	0
Data type:	Int8	Change during operation:	True

Each index sets the DSCP value of different types of QoS prioritized messages.

12-98 Interface Counters

Default value:	4000	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter is read-only. Advanced interface counters from a built-in switch can be used for low-level troubleshooting. The parameter shows a sum of port 1 + port 2.

12-99 Media Counters

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter is read-only. Advanced interface counters from a built-in switch can be used for low-level troubleshooting. The parameter shows a sum of port 1 + port 2.

Table 46: Parameter Indices

Index	Description
[0]	Alignment errors
[1]	FCS errors
[2]	Single collisions
[3]	Multiple collisions
[4]	SQE test errors
[5]	Deferred transmissions
[6]	Late collisions
[7]	Excessive collisions
[8]	MAC transmit errors
[9]	Carrier sense errors

6.14 Parameter Group 13-** Smart Logic Control

6.14.1 Introduction to Smart Logic Control

With SLC, it is possible to run up to 4 sequences in parallel. Link between the sequences to create customer- and application-specific behaviors by using logic rules. In active fire mode/emergency mode, operation related to the motor control is disabled.

Smart logic control (SLC) is a sequence of user-defined actions (see parameter **13-52 SL Controller 1 Action**) executed by the SLC when the associated user-defined event (see parameter **13-51 SL Controller 1 Event**) is evaluated as true by the SLC. The condition for an event can be a particular status, or that the output from a logic rule or a comparator operand becomes true. That leads to an associated action as illustrated:




Figure 81: Smart Logic Control (SLC)

Events and actions are each numbered and linked in pairs (states). This means that when the 1st event is fulfilled (becomes true), the 1st action is executed. After this, the conditions of the 2nd event are evaluated and if evaluated true, the 2nd action is executed, and so on. Only 1 event is evaluated at any time. If an event is evaluated as false, nothing happens (in the SLC) during the current scan interval and no other events are evaluated. This means that when the SLC starts, it evaluates the 1st event (and only the 1st event) in each scan interval. Only when the 1st event is evaluated as true, the SLC executes the 1st action and starts evaluating the 2nd event. It is possible to program 1–20 events and actions. When the last event/action has been executed, the sequence starts over again from the 1st event/action.

Four concurring sequences can be defined with each up to 20 event and action pairs. The sequences are executed at the same time but operate separately. For example, sequence 1 may have executed 3 actions, while sequence 2 still waits for its 1st event to occur. In this example, parameter **13-00 SL Controller Mode [0]**, parameter **13-01 Start Event [1]**, and parameter **13-02 Stop Event [2]** correspond to sequence 1, sequence 2, sequence 3.



NOTE: Comparators, flip-flops, timers, and logic rules are shared between sequences.




Figure 82: Example of Events and Actions

Starting and stopping the SLC

Start and stop the SLC by selecting **[1] On** or **[0] Off** in parameter **13-00 SL Controller Mode**. The SLC always starts in state 0 (where it evaluates event [0]). The SLC starts when the start event (defined in parameter **13-01 Start Event**) is evaluated as true (provided that **[1] On** is selected in parameter **13-00 SL Controller Mode**). The SLC stops when the stop event (parameter **13-02 Stop Event**) is true. **13-03 Reset SLC** resets all SLC parameters and starts programming from scratch.



NOTE: SLC is only active in auto-on mode, not in hand-on mode.

6.14.2 13-0* SLC Settings

Use the SLC settings to activate, deactivate, and reset the smart logic control sequence. The logic functions and comparators are always running in the background, which opens for separate control of digital inputs and outputs.

13-00 SL Controller Mode

Default value:	–	Parameter type:	Option, Array [4]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

An array with 4 elements [0]–[3] is shown in the display.

Option	Name	Description
[0]	Off	Disables the smart logic controller.
[1]	On	Enables the smart logic controller.

13-01 Start Event

Default value:	–	Parameter type:	Option, Array [4]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the boolean (true or false) input to activate smart logic control.

Option	Name	Description
[0]	False	Select the boolean (true or false) input to activate smart logic control. Enters the fixed value <i>False</i> .
[1]	True	Enters the fixed value <i>True</i> .
[2]	Running	The motor runs.
[3]	In range	The motor runs within the programmed current and speed ranges set in parameter 4-50 Warning Current Low to parameter 4-53 Warning Speed High .
[4]	On reference	The motor runs on reference.
[5]	Torque limit	The torque limit set in parameter 4-16 Torque Limit Motor Mode or parameter 4-17 Torque Limit Generator Mode is exceeded.
[6]	Current limit	The motor current limit set in parameter 4-18 Current Limit is exceeded.

Option	Name	Description
[7]	Out of current range	The motor current is outside the range set in parameter 4-18 Current Limit .
[8]	Below I_{low}	The motor current is lower than set in parameter 4-50 Warning Current Low .
[9]	Above I_{high}	The motor current is higher than set in parameter 4-51 Warning Current High .
[10]	Out of speed range	The speed is outside the range set in parameter 4-52 Warning Speed Low and parameter 4-53 Warning Speed High .
[11]	Below speed low	The output speed is lower than the setting in parameter 4-52 Warning Speed Low .
[12]	Above speed high	The output speed is higher than the setting in parameter 4-53 Warning Speed High .
[13]	Out of feedb. range	The feedback is outside the range set in parameter 4-56 Warning Feedback Low and parameter 4-57 Warning Feedback High .
[14]	Below feedb. low	The feedback is below the limit set in parameter 4-56 Warning Feedback Low .
[15]	Above feedb. high	The feedback is above the limit set in parameter 4-57 Warning Feedback High .
[16]	Thermal warning	The thermal warning turns on when the temperature exceeds the limit in the motor, the drive, the brake resistor, or the thermistor.
[17]	Mains out of range	The mains voltage is outside the specified voltage range.
[18]	Reversing	The output is high when the drive is running counterclockwise (the logical product of the status bits running AND reverse).
[19]	Warning	A warning is active.
[20]	Alarm (trip)	A (trip) alarm is active.
[21]	Alarm (trip lock)	A (trip lock) alarm is active.
[22]	Comparator 0	Use the result of comparator 0.
[23]	Comparator 1	Use the result of comparator 1.
[24]	Comparator 2	Use the result of comparator 2.
[25]	Comparator 3	Use the result of comparator 3.
[26]	Logic rule 0	Use the result of logic rule 0.
[27]	Logic rule 1	Use the result of logic rule 1.
[28]	Logic rule 2	Use the result of logic rule 2.
[29]	Logic rule 3	Use the result of logic rule 3.
[33]	Digital input DI18	Use the result of digital input 18.
[34]	Digital input DI19	Use the result of digital input 19.
[35]	Digital input DI27	Use the result of digital input 27.
[36]	Digital input DI29	 NOTE: This option is only available in FC 302. Use the result of digital input 29.

Option	Name	Description
[37]	Digital input DI32	Use the result of digital input 32.
[38]	Digital input DI33	Use the result of digital input 33.
[39]	Start command	A start command is issued. This is the default option.
[40]	Drive stopped	A stop command (jog, stop, quick stop, coast) is issued - and not from SLC itself.
[41]	Reset trip	A reset is issued.
[42]	Auto-reset trip	An auto reset is performed.
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	Use the result of comparator 4.
[51]	Comparator 5	Use the result of comparator 5.
[60]	Logic rule 4	Use the result of logic rule 4.
[61]	Logic rule 5	Use the result of logic rule 5.
[76]	Digital input X30/2	Use the value of X30/2 (VLT® General Purpose I/O MCB 101).
[77]	Digital input X30/3	Use the value of X30/3 (VLT® General Purpose I/O MCB 101).
[78]	Digital input X30/4	Use the value of X30/4 (VLT® General Purpose I/O MCB 101).
[79]	Digital input X46/1	Use the value of X46/1 (VLT® Extended Relay Card MCB 113).
[80]	Digital input X46/3	Use the value of X46/3 (VLT® Extended Relay Card MCB 113).
[81]	Digital input X46/5	Use the value of X46/5 (VLT® Extended Relay Card MCB 113).
[82]	Digital input X46/7	Use the value of X46/7 (VLT® Extended Relay Card MCB 113).
[83]	Digital input X46/9	Use the value of X46/9 (VLT® Extended Relay Card MCB 113).
[84]	Digital input X46/11	Use the value of X46/11 (VLT® Extended Relay Card MCB 113).
[85]	Digital input X46/13	Use the value of X46/13 (VLT® Extended Relay Card MCB 113).
[94]	RS Flipflop 0	See parameter group 13-1* Comparators .
[95]	RS Flipflop 1	See parameter group 13-1* Comparators .
[96]	RS Flipflop 2	See parameter group 13-1* Comparators .
[97]	RS Flipflop 3	See parameter group 13-1* Comparators .
[98]	RS Flipflop 4	See parameter group 13-1* Comparators .
[99]	RS Flipflop 5	See parameter group 13-1* Comparators .
[100]	RS Flipflop 6	See parameter group 13-1* Comparators .
[101]	RS Flipflop 7	See parameter group 13-1* Comparators .
[212]	Emergency mode	

Option	Name	Description
[222]	Homing OK	 NOTE: This option is only available in FC 302 with IMC software version 48.2X.
[223]	On target	 NOTE: This option is only available in FC 302 with IMC software version 48.2X.
[224]	Position error	 NOTE: This option is only available in FC 302 with IMC software version 48.2X.
[225]	Position limit	 NOTE: This option is only available in FC 302 with IMC software version 48.2X.
[226]	Touch on target	 NOTE: This option is only available in FC 302 with IMC software version 48.2X.
[227]	Touch activated.	 NOTE: This option is only available in FC 302 with IMC software version 48.2X.
[228]	Comparator 6	Use the result of comparator 6.
[229]	Comparator 7	Use the result of comparator 7.
[230]	Comparator 8	Use the result of comparator 8.
[231]	Comparator 9	Use the result of comparator 9.
[232]	Logic rule 6	Use the result of logic rule 6.
[233]	Logic rule 7	Use the result of logic rule 7.
[234]	Logic rule 8	Use the result of logic rule 8.
[235]	Logic rule 9	Use the result of logic rule 9.
[238]	RS flipflop 8	See parameter group 13-1* Comparators .
[239]	RS flipflop 9	See parameter group 13-1* Comparators .

13-02 Stop Event

Default value:	–	Parameter type:	Option, Array [4]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the boolean (true or false) input to deactivate smart logic control.

Option	Name	Description
[0]	False	For descriptions of options [0] False–[61] Logic rule 5 , see parameter 13-01 Start Event .
[1]	True	

Option	Name	Description
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I_{low}	
[9]	Above I_{high}	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL timeout 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	 NOTE: This option is only available in FC 302.
[37]	Digital input DI32	

Option	Name	Description
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	
[44]	Reset key	
[45]	Left key	
[46]	Right key	
[47]	Up key	
[48]	Down key	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL time-out 3	Smart logic controller time 3 is timed out.
[71]	SL time-out 4	Smart logic controller time 4 is timed out.
[72]	SL time-out 5	Smart logic controller time 5 is timed out.
[73]	SL time-out 6	Smart logic controller time 6 is timed out.
[74]	SL time-out 7	Smart logic controller time 7 is timed out.
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input X46/1	
[80]	Digital input X46/3	
[81]	Digital input X46/5	
[82]	Digital input X46/7	
[83]	Digital input X46/9	
[84]	Digital input X46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If the <i>alarm 164, ATEX ETR cur.lim.alarm</i> is active, the output is 1.
[91]	ATEX ETR cur. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166, ATEX ETR freq.lim.alarm</i> is active, the output is 1.

Option	Name	Description
[92]	ATEX ETR freq. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163</i> , ATEX ETR <i>cur.lim.warning</i> is active, the output is 1.
[93]	ATEX ETR freq. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165</i> , ATEX ETR <i>freq.lim.warning</i> is active, the output is 1.
[94]	RS flipflop 0	See parameter group 13-1* Comparators .
[95]	RS flipflop 1	See parameter group 13-1* Comparators .
[96]	RS flipflop 2	See parameter group 13-1* Comparators .
[97]	RS flipflop 3	See parameter group 13-1* Comparators .
[98]	RS flipflop 4	See parameter group 13-1* Comparators .
[99]	RS flipflop 5	See parameter group 13-1* Comparators .
[100]	RS flipflop 6	See parameter group 13-1* Comparators .
[101]	RS flipflop 7	See parameter group 13-1* Comparators .
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[223]	On target	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[224]	Position error	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[225]	Position limit	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[226]	Touch on target	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.

Option	Name	Description
[227]	Touch activated	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comarator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

13-03 Reset SLC

Default value:	[0] Do not reset SLC	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Do not reset SLC	Retain programmed settings in parameter group 13-** Smart Logic .
[1]	Reset SLC	Reset all parameters in parameter group 13-** Smart Logic .

6.14.3 13-1* Comparators

Comparators are used for comparing continuous variables (that is output frequency, output current, analog input, and so on) to fixed preset values.




Figure 83: Comparators

There are digital values that are compared to fixed time values. See the explanation in parameter **13-10 Comparator Operand**. Comparators are evaluated once in each scan interval. Use the result (true or false) directly. All parameters in this parameter group are array parameters with index 0–9. Select index 0 to program comparator 0, select index 1 to program comparator 1, and so on.

13-10 Comparator Operand

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Options **[1] Reference %** to **[31] Counter B** are variables which are compared based on their values. Options **[50] FALSE** to **[186] Drive in auto mode** are digital values (true/false) where the comparison is based on the amount of time during which they are set to true or false. See parameter **13-11 Comparator Operator**.

Option	Name	Description
[0]	DISABLED	The comparator is disabled.
[1]	Reference %	The resulting remote reference in %.
[2]	Feedback %	[RPM] or [Hz], as set in parameter 0-02 Motor Speed Unit .
[3]	Motor speed	[RPM] or [Hz], as set in parameter 0-02 Motor Speed Unit .
[4]	Motor current	
[5]	Motor torque	
[6]	Motor power	
[7]	Motor voltage	
[8]	DC-link voltage	
[9]	Motor thermal	The value is in %.
[10]	Drive thermal	The value is in %.
[11]	Heat sink temp.	The value is in %.
[12]	Analog input AI53	The value is in %.
[13]	Analog input AI54	The value is in %.
[14]	Analog input AIFB10	AIFB10 is internal 10 V supply.
[15]	Analog input AIS24V	AIS24V is a 24 V switch mode power supply.
[17]	Analog input AICCT	Value is in [°]. AICCT is control card temperature.
[18]	Pulse input FI29	



NOTE: This option is only available in FC 302.

The value is in %.

Option	Name	Description
[19]	Pulse input FI33	The value is in %.
[20]	Alarm number	 NOTE: With this selection, it is not possible to use < and > as comparator operators.  NOTE: Several alarms/warnings can be present at the same time. As the alarm/warning numbers are not grouped in a predefined order, defining a range is not relevant. Shows the actual alarm number.
[21]	Warning number	 NOTE: With this selection, it is not possible to use < and > as comparator operators.  NOTE: Several alarms/warnings can be present at the same time. As the alarm/warning numbers are not grouped in a predefined order, defining a range is not relevant. Shows the actual warning number.
[22]	Analog input X30/11	
[23]	Analog input X30/12	
[30]	Counter A	
[31]	Counter B	
[32]	Process PID error	Value of the PID error (parameter 18-90 Process PID Error).
[33]	Process PID Output	Value of the PID output (parameter 18-91 Process PID Output).
[34]	Analog input X48/2	
[35]	Temp input X48/4	
[36]	Temp input X48/7	
[37]	Temp input X48/10	
[38]	Actual position	 NOTE: This option is only available in FC 302 with IMC software version 48.2X or newer.
[39]	Safe opt. speed error	
[43]	Analog input X49/1	
[44]	Analog input X49/3	
[45]	Analog input X49/5	
[50]	FALSE	Use to enter the fixed value <i>False</i> in the comparator.
[51]	TRUE	Use to enter <i>True</i> in the comparator.
[52]	Control ready	The control board receives supply voltage.
[53]	Drive ready	The drive is ready for operation and applies a signal on the control board.
[54]	Running	The motor runs.

Option	Name	Description
[55]	Reversing	The output is active when the drive runs counterclockwise (the logical product of the status bits running AND reverse).
[56]	In range	The motor runs within the programmed current and speed ranges set in parameter 4-50 Warning Current Low to parameter 4-53 Warning Speed High .
[60]	On reference	The motor runs on reference.
[61]	Below reference, low	The motor runs at a reference which is less than the value in parameter 4-54 Warning Reference Low .
[62]	Above ref, high	The motor runs at a reference which exceeds the value in parameter 4-55 Warning Reference High .
[65]	Torque limit	The torque exceeds the value in parameter 4-16 Torque Limit Motor Mode or parameter 4-17 Torque Limit Generator Mode .
[66]	Current limit	The motor current exceeds the value in parameter 4-18 Current Limit .
[67]	Out of current range	The motor current is outside the range set in parameter 4-18 Current Limit .
[68]	Below I low	The motor current is lower than the value in parameter 4-50 Warning Current Low .
[69]	Above I high	The motor current is higher than the value in parameter 4-51 Warning Current High .
[70]	Out of speed range	The speed is outside the range set in parameter 4-52 Warning Speed Low and parameter 4-53 Warning Speed High .
[71]	Below speed low	The output speed is lower than the value in parameter 4-52 Warning Speed Low .
[72]	Above speed high	The output speed is higher than the value in parameter 4-53 Warning Speed High .
[75]	Out of feedback range	The feedback is outside the range set in parameter 4-56 Warning Feedback Low and parameter 4-57 Warning Feedback High .
[76]	Below feedback low	The feedback is lower than the limit set in parameter 4-56 Warning Feedback Low .
[77]	Above feedback high	The feedback exceeds the limit set in parameter 4-57 Warning Feedback High .
[80]	Thermal warning	This operand becomes true when the drive detects any thermal warning, for instance when the temperature exceeds the limit in the motor, the drive, the brake resistor, or thermistor.
[82]	Mains out of range	The mains voltage is outside the specified voltage range.
[85]	Warning	If a warning is triggered, this operand gets the warning number.
[86]	Alarm (trip)	A trip alarm is active.
[87]	Alarm (trip lock)	A trip lock alarm is active.
[90]	Bus OK	Active communication (no timeout) via the serial communication port.

Option	Name	Description
[91]	Torque limit & stop	If the drive has received a stop signal and is at the torque limit, the signal is logic 0.
[92]	Brake fault (IGBT)	The brake IGBT is short-circuited.
[93]	Mech. brake control	The mechanical brake is active.
[94]	Safe stop active	 NOTE: This option is only available in FC 302.
[100]	Comparator 0	The result of comparator 0.
[101]	Comparator 1	The result of comparator 1.
[102]	Comparator 2	The result of comparator 2.
[103]	Comparator 3	The result of comparator 3.
[104]	Comparator 4	The result of comparator 4.
[105]	Comparator 5	The result of comparator 5.
[106]	Comparator 6	The result of comparator 6.
[107]	Comparator 7	The result of comparator 7.
[108]	Comparator 8	The result of comparator 8.
[109]	Comparator 9	The result of comparator 9.
[110]	Logic rule 0	The result of logic rule 0.
[111]	Logic rule 1	The result of logic rule 1.
[112]	Logic rule 2	The result of logic rule 2.
[113]	Logic rule 3	The result of logic rule 3.
[114]	Logic rule 4	The result of logic rule 4.
[115]	Logic rule 5	The result of logic rule 5.
[116]	Logic rule 6	The result of logic rule 6.
[117]	Logic rule 7	The result of logic rule 7.
[118]	Logic rule 8	The result of logic rule 8.
[119]	Logic rule 9	The result of logic rule 9.
[120]	SL time-out 0	The result of the SLC timer 0.
[121]	SL time-out 1	The result of the SLC timer 1.
[122]	SL time-out 2	The result of the SLC timer 2.
[123]	SL time-out 3	The result of the SLC timer 3.
[124]	SL time-out 4	The result of the SLC timer 4.
[125]	SL time-out 5	The result of the SLC timer 5.
[126]	SL time-out 6	The result of the SLC timer 6.
[127]	SL time-out 7	The result of the SLC timer 7.
[128]	SL time-out 8	The result of the SLC timer 8.
[129]	SL time-out 9	The result of the SLC timer 9.
[130]	Digital input DI18	Digital input 18 (high=true).

Option	Name	Description
[131]	Digital input DI19	Digital input 19 (high=true).
[132]	Digital input DI27	Digital input 27 (high=true).
[133]	Digital input DI29	Digital input 29 (high=true)
[134]	Digital input DI32	Digital input 32 (high=true).
[135]	Digital input DI33	Digital input 33 (high=true).
[136]	RS flipflop 0	
[137]	RS flipflop 1	
[138]	RS flipflop 2	
[139]	RS flipflop 3	
[140]	RS flipflop 4	
[141]	RS flipflop 5	
[142]	RS flipflop 6	
[143]	RS flipflop 7	
[144]	RS flipflop 8	
[145]	RS flipflop 9	
[150]	SL digital output A	Use the result of the SLC output A.
[151]	SL digital output B	Use the result of the SLC output B.
[152]	SL digital output C	Use the result of the SLC output C.
[153]	SL digital output D	Use the result of the SLC output D.
[154]	SL digital output E	Use the result of the SLC output E.
[155]	SL digital output F	Use the result of the SLC output F.
[160]	Relay 1	Relay 1 is active.
[161]	Relay 2	Relay 2 is active.
[162]	Relay 3	
[163]	Relay 4	
[164]	Relay 5	
[165]	Relay 6	
[166]	Relay 7	
[167]	Relay 8	
[168]	Relay 9	
[180]	Local reference active	Active when parameter 3-13 Reference Site is [2] Local or when parameter 3-13 Reference Site is [0] Linked to hand/auto , at the same time as the LCP is in hand-on mode.
[181]	Remote reference active	Active when parameter 3-13 Reference Site is [1] Remote or [0] Linked to hand/auto , while the LCP is in auto-on mode.
[182]	Start command	Active when there is an active start command and no stop command.

Option	Name	Description
[183]	Drive stopped	A stop command (jog, stop, qstop, coast) is issued – and not from the SLC itself.
[185]	Drive in hand mode	Active when the drive is in hand-on mode.
[186]	Drive in auto mode	Active when the drive is in auto-on mode.
[187]	Start command given	
[190]	Digital input X30/2	
[191]	Digital input X30/3	
[192]	Digital input X30/4	
[193]	Digital input X46/1	
[194]	Digital input X46/3	
[195]	Digital input X46/5	
[196]	Digital input X46/7	
[197]	Digital input X46/9	
[198]	Digital input X46/11	
[199]	Digital input X46/13	
[212]	Emergency mode	
[222]	Homing OK	 NOTE: This option is only available with software version 48.2X and newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).
[223]	On target	 NOTE: This option is only available with software version 48.2X and newer. Positioning is completed and the on-target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	 NOTE: This option is only available with software version 48.2X and newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position limit	 NOTE: This option is only available with software version 48.2X and newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.

Option	Name	Description
[226]	Touch on target	 NOTE: This option is only available with software version 48.2X and newer. Target position is reached in touch probe position mode.
[227]	Touch activated	 NOTE: This option is only available with software version 48.2X and newer. Touch probe positioning is active. The drive monitors the touch probe sensor input.
[249]	Therm. sensor temp.	

13-11 Comparator Operator

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the operator to be used in the comparison. This is an array parameter containing comparator operators 0–5.

Option	Name	Description
[0]	<	 NOTE: If [20] <i>Alarm number</i> or [21] <i>Warning number</i> is selected in parameter 13-10 Comparator Operand , [0] < cannot be selected in this parameter. The result of the evaluation is true when the variable selected in parameter 13-10 Comparator Operand is smaller than the fixed value in parameter 13-12 Comparator Value . The result is false if the variable selected in parameter 13-10 Comparator Operand is greater than the fixed value in parameter 13-12 Comparator Value .
[1]	≈ (equal)	The result of the evaluation is true when the variable selected in parameter 13-10 Comparator Operand is approximately equal to the fixed value in parameter 13-12 Comparator Value .
[2]	>	 NOTE: If [20] <i>Alarm number</i> or [21] <i>Warning number</i> is selected in parameter 13-10 Comparator Operand , [2] > cannot be selected in this parameter. Inverse logic of option [0] <.
[5]	TRUE longer than..	
[6]	FALSE longerthan..	
[7]	TRUE shorter than..	
[8]	FALSE shorter than..	

13-12 Comparator Value

Default value:	Size related	Parameter type:	Array [10]

Setup:	2 setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the trigger level for the variable that is monitored by this comparator. This is an array parameter containing comparator values 0–9.

6.14.4 13-1* RS Flip Flops

The reset/set flip flops hold the signal until set/reset.




Figure 84: Reset/Set Flip Flops

Two parameters are used and the output can be used in the logic rules and as events.




Figure 85: Flip Flop Outputs

The 2 operators can be selected from a long list. As a special case, the same digital input can be used as both set and reset, making it possible to use the same digital input as start/stop. The following settings can be used to set up the same digital input (for example, DI32) as start/stop.

Table 47: Operators

Parameter	Setting	Notes
Parameter 13-00 SL Controller Mode	[1] On	–
Parameter 13-01 Start Event [0]	True	–
Parameter 13-02 Stop Event [0]	False	–
Parameter 13-40 Logic Rule Boolean 1 [0]	[37] Digital input DI32	–
Parameter 13-42 Logic Rule Boolean 2 [0]	[2] Running	–
Parameter 13-41 Logic Rule Operator 1 [0]	[3] AND NOT	–
Parameter 13-40 Logic Rule Boolean 1 [1]	[37] Digital input DI32	–
Parameter 13-42 Logic Rule Boolean 2 [1]	[2] Running	–
Parameter 13-41 Logic Rule Operator 1 [1]	[1] AND	–

Table 47: Operators - (continued)

Parameter	Setting	Notes
Parameter 13-15 RS-FF Operand S [0]	[26] Logic rule 0	Output from parameter 13-41 Logic Rule Operator 1 [0].
Parameter 13-16 RS-FF Operand R [0]	[27] Logic rule 1	Output from parameter 13-41 Logic Rule Operator 1 [1].
Parameter 13-51 SL Controller 1 Event [0]	[94] RS Flipflop 0	Output from parameter 13-15 RSFF Operand S and parameter 13-16 RSFF Operand R .
Parameter 13-52 SL Controller 1 Action [0]	[22] Run	–
Parameter 13-51 SL Controller 1 Event [1]	[27] Logic rule 1	–
Parameter 13-52 SL Controller 1 Action [1]	[24] Stop	–

13-15 RS-FF Operand S

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	False	
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	

Option	Name	Description
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	
 NOTE: This option is only available in FC 302.		
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL time-out 3	

Option	Name	Description
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input 46/1	
[80]	Digital input 46/3	
[81]	Digital input 46/5	
[82]	Digital input 46/7	
[83]	Digital input 46/9	
[84]	Digital input 46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	
[91]	ATEX ETR cur. alarm	
[92]	ATEX ETR freq. warning	
[93]	ATEX ETR freq. alarm	
[94]	RS Flipflop 0	
[95]	RS Flipflop 1	
[96]	RS Flipflop 2	
[97]	RS Flipflop 3	
[98]	RS Flipflop 4	
[99]	RS Flipflop 5	
[100]	RS Flipflop 6	
[101]	RS Flipflop 7	
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	

Option	Name	Description
[222]	Homing OK	 NOTE: This option is only available with software version 48.2X and newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).
[223]	On target	 NOTE: This option is only available with software version 48.2X and newer. Positioning is completed and the on-target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window .
[224]	Position error	 NOTE: This option is only available with software version 48.2X and newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout .
[225]	Position limit	 NOTE: This option is only available with software version 48.2X and newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position .
[226]	Touch on target	 NOTE: This option is only available with software version 48.2X and newer. Target position is reached in touch probe position mode.
[227]	Touch activated	Touch probe positioning active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	

Option	Name	Description
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

13-16 RS-FF Operand R

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	False	
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	

Option	Name	Description
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	 NOTE: This option is only available in FC 302.
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL time-out 3	
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	

Option	Name	Description
[78]	Digital input X30/4	
[79]	Digital input 46/1	
[80]	Digital input 46/3	
[81]	Digital input 46/5	
[82]	Digital input 46/7	
[83]	Digital input 46/9	
[84]	Digital input 46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	
[91]	ATEX ETR cur. alarm	
[92]	ATEX ETR freq. warning	
[93]	ATEX ETR freq. alarm	
[94]	RS Flipflop 0	
[95]	RS Flipflop 1	
[96]	RS Flipflop 2	
[97]	RS Flipflop 3	
[98]	RS Flipflop 4	
[99]	RS Flipflop 5	
[100]	RS Flipflop 6	
[101]	RS Flipflop 7	
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	 NOTE: This option is only available with software version 48.2X and newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).

Option	Name	Description
[223]	On target	 NOTE: This option is only available with software version 48.2X and newer. Positioning is completed and the on-target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	 NOTE: This option is only available with software version 48.2X and newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position limit	 NOTE: This option is only available with software version 48.2X and newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	 NOTE: This option is only available with software version 48.2X and newer. Target position is reached in touch probe position mode.
[227]	Touch activated	 NOTE: This option is only available with software version 48.2X and newer. Touch probe positioning active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	

Option	Name	Description
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

6.14.5 13-2* Timers

Use the result (true or false) from timers directly to define an event (see parameter **13-51 Controller Event**), or as boolean input in a logic rule (see parameter **13-40 Logic Rule Boolean 1**, parameter **13-42 Logic Rule Boolean 2**, or parameter **13-44 Logic Rule Boolean 3**). A timer is only false when started by an action, for example, **[29] Start timer 1**, until the timer value entered in this parameter has elapsed. Then it becomes true again. All parameters in this parameter group are array parameters with indexes 0–9. Select index 0 to program timer 0, select index 1 to program timer 1, and so on.

13-20 SL Controller Timer

Default value:	Size related	Parameter type:	Array [10]
Setup:	1 setup	Conversion index:	-3
Data type:	Timediff w/o DateID	Change during operation:	True

Enter the value to define the duration of the false output from the programmed timer. A timer is only false if it is started by an action (that is **[29] Start timer 1**) and until the given timer value has elapsed.

6.14.6 13-4* Logic Rules

Combine up to 3 boolean inputs (true/false inputs) from timers, comparators, digital inputs, status bits, and events using the logical operators AND, OR, and NOT. Select boolean inputs for the calculation in parameter **13-40 Logic Rule Boolean 1**, parameter **13-42 Logic Rule Boolean 2**, and parameter **13-44 Logic Rule Boolean 3**. Define the operators used to logically combine the selected inputs in parameter **13-41 Logic Rule Operator 1** and parameter **13-43 Logic Rule Operator 2**.




Figure 86: Logic Rules

Priority of calculation

The results of parameter **13-40 Logic Rule Boolean 1**, parameter **13-41 Logic Rule Operator 1**, and parameter **13-42 Logic Rule Boolean 2** are calculated first. The outcome (true/false) of this calculation is combined with the settings of parameter **13-43 Logic Rule Operator 2** and parameter **13-44 Logic Rule Boolean 3**, yielding the final result (true/false) of the logic rule.

13-40 Logic Rule Boolean 1

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	False	Select the 1st boolean (true or false) input for the selected logic rule. See parameter 13-01 Start Event and parameter 13-02 Stop Event for more information.
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	

Option	Name	Description
[35]	Digital input DI27	
[36]	Digital input DI29	 NOTE: This option is only available in FC 302.
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	Use the result of comparator 4.
[51]	Comparator 5	Use the result of comparator 5.
[60]	Logic rule 4	Use the result of logic rule 4.
[61]	Logic rule 5	Use the result of logic rule 5.
[70]	SL time-out 3	
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input X46/1	
[80]	Digital input X46/3	
[81]	Digital input X46/5	
[82]	Digital input X46/7	
[83]	Digital input X46/9	
[84]	Digital input X46/11	
[85]	Digital input X46/13	

Option	Name	Description
[90]	ATEX ETR cur. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 164</i> , ATEX ETR <i>cur.lim.alarm</i> is active, the output is 1.
[91]	ATEX ETR cur. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166</i> , ATEX ETR <i>freq.lim.alarm</i> is active, the output is 1.
[92]	ATEX ETR freq. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163</i> , ATEX ETR <i>cur.lim.warning</i> is active, the output is 1.
[93]	ATEX ETR freq. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165</i> , ATEX ETR <i>freq.lim.warning</i> is active, the output is 1.
[94]	RS Flipflop 0	See parameter group 13-1* Comparators .
[95]	RS Flipflop 1	See parameter group 13-1* Comparators .
[96]	RS Flipflop 2	See parameter group 13-1* Comparators .
[97]	RS Flipflop 3	See parameter group 13-1* Comparators .
[98]	RS Flipflop 4	See parameter group 13-1* Comparators .
[99]	RS Flipflop 5	See parameter group 13-1* Comparators .
[100]	RS Flipflop 6	See parameter group 13-1* Comparators .
[101]	RS Flipflop 7	See parameter group 13-1* Comparators .
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	 NOTE: This option is only available with software version 48.2X or newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).

Option	Name	Description
[223]	On target	 NOTE: This option is only available with software version 48.2X or newer. Positioning is completed and the on target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	 NOTE: This option is only available with software version 48.2X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position limit	 NOTE: This option is only available with software version 48.2X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	 NOTE: This option is only available with software version 48.2X or newer. Target position is reached in touch probe position mode.
[227]	Touch activated	Touch probe positioning is active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	

Option	Name	Description
[244]	SL digital output E	
[245]	SL digital output F	

13-41 Logic Rule Operator 1

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the 1st logical operator to use on the boolean inputs from parameter **13-40 Logic Rule Boolean 1** and parameter **13-42 Logic Rule Boolean 2**. Parameter numbers in square brackets stand for the boolean inputs of parameters in parameter group **13-** Smart Logic Control**.

Option	Name	Description
[0]	DISABLED	Ignores - Parameter 13-42 Logic Rule Boolean 2. - Parameter 13-43 Logic Rule Operator 2. - Parameter 13-44 Logic Rule Boolean 3.
[1]	AND	Evaluates the expression [13-40] AND [13-42].
[2]	OR	Evaluates the expression [13-40] OR [13-42].
[3]	AND NOT	Evaluates the expression [13-40] AND NOT [13-42].
[4]	OR NOT	Evaluates the expression [13-40] OR NOT [13-42].
[5]	NOT AND	Evaluates the expression NOT [13-40] AND [13-42].
[6]	NOT OR	Evaluates the expression NOT [13-40] OR [13-42].
[7]	NOT AND NOT	Evaluates the expression NOT [13-40] AND NOT [13-42].
[8]	NOT OR NOT	Evaluates the expression NOT [13-40] OR NOT [13-42].

13-42 Logic Rule Boolean 2

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	False	Select the 2nd boolean (true or false) input for the selected logic rule. See parameter 13-01 Start Event and parameter 13-02 Stop Event for more information.
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	

Option	Name	Description
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	
		 NOTE: This option is only available in FC 302.
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	

Option	Name	Description
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	Use the result of comparator 4.
[51]	Comparator 5	Use the result of comparator 5.
[60]	Logic rule 4	Use the result of logic rule 4.
[61]	Logic rule 5	Use the result of logic rule 5.
[70]	SL time-out 3	
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input X46/1	
[80]	Digital input X46/3	
[81]	Digital input X46/5	
[82]	Digital input X46/7	
[83]	Digital input X46/9	
[84]	Digital input X46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 164, ATEX ETR cur.lim.alarm</i> is active, the output is 1.
[91]	ATEX ETR cur. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166, ATEX ETR freq.lim.alarm</i> is active, the output is 1.
[92]	ATEX ETR freq. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163, ATEX ETR cur.lim.warning</i> is active, the output is 1.
[93]	ATEX ETR freq. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165, ATEX ETR freq.lim.warning</i> is active, the output is 1.

Option	Name	Description
[94]	RS Flipflop 0	See parameter group 13-1* Comparators .
[95]	RS Flipflop 1	See parameter group 13-1* Comparators .
[96]	RS Flipflop 2	See parameter group 13-1* Comparators .
[97]	RS Flipflop 3	See parameter group 13-1* Comparators .
[98]	RS Flipflop 4	See parameter group 13-1* Comparators .
[99]	RS Flipflop 5	See parameter group 13-1* Comparators .
[100]	RS Flipflop 6	See parameter group 13-1* Comparators .
[101]	RS Flipflop 7	See parameter group 13-1* Comparators .
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	 NOTE: This option is only available with software version 48.2X or newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).
[223]	On target	 NOTE: This option is only available with software version 48.2X or newer. Positioning is completed and the on target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	 NOTE: This option is only available with software version 48.2X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position limit	 NOTE: This option is only available with software version 48.2X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.

Option	Name	Description
[226]	Touch on target	 NOTE: This option is only available with software version 48.2X or newer. Target position is reached in touch probe position mode.
[227]	Touch activated	Touch probe positioning is active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

13-43 Logic Rule Operator 2

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the 2nd logical operator to be used on the boolean input calculated in:

- Parameter **13-40 Logic Rule Boolean 1**.
- Parameter **13-41 Logic Rule Operator 1**.
- Parameter **13-42 Logic Rule Boolean 2**.

[13-44] signifies the boolean input of parameter **13-44 Logic Rule Boolean 3**. [13-40/13-42] signifies the boolean input calculated in:

- Parameter **13-40 Logic Rule Boolean 1**.
- Parameter **13-41 Logic Rule Operator 1**.
- Parameter **13-42 Logic Rule Boolean 2**.

Option	Name	Description
[0]	DISABLED	
[1]	AND	
[2]	OR	
[3]	AND NOT	
[4]	OR NOT	
[5]	NOT AND	
[6]	NOT OR	
[7]	NOT AND NOT	
[8]	NOT OR NOT	

13-44 Logic Rule Boolean 3

Default value:	–	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	False	Select the 3rd boolean (true or false) input for the selected logic rule. See parameter 13-01 Start Event (options [0] <i>False</i> –[61] <i>Logic rule 5</i>) and parameter 13-02 Stop Event (options [70] <i>SL Time-out 3</i> –[75] <i>Start command given</i>) for more information.
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	

Option	Name	Description
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	 NOTE: This option is only available in FC 302.
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	Use the result of comparator 4.
[51]	Comparator 5	Use the result of comparator 5.
[60]	Logic rule 4	Use the result of logic rule 4.
[61]	Logic rule 5	Use the result of logic rule 5.
[70]	SL time-out 3	
[71]	SL time-out 4	

Option	Name	Description
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input X46/1	
[80]	Digital input X46/3	
[81]	Digital input X46/5	
[82]	Digital input X46/7	
[83]	Digital input X46/9	
[84]	Digital input X46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 164, ATEX ETR cur.lim.alarm</i> is active, the output is 1.
[91]	ATEX ETR cur. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166, ATEX ETR freq.lim.alarm</i> is active, the output is 1.
[92]	ATEX ETR freq. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163, ATEX ETR cur.lim.warning</i> is active, the output is 1.
[93]	ATEX ETR freq. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165, ATEX ETR freq.lim.warning</i> is active, the output is 1.
[94]	RS Flipflop 0	See parameter group 13-1* Comparators .
[95]	RS Flipflop 1	See parameter group 13-1* Comparators .
[96]	RS Flipflop 2	See parameter group 13-1* Comparators .
[97]	RS Flipflop 3	See parameter group 13-1* Comparators .
[98]	RS Flipflop 4	See parameter group 13-1* Comparators .
[99]	RS Flipflop 5	See parameter group 13-1* Comparators .
[100]	RS Flipflop 6	See parameter group 13-1* Comparators .
[101]	RS Flipflop 7	See parameter group 13-1* Comparators .
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.

Option	Name	Description
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	NOTE: This option is only available with software version 48.2X or newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).
[223]	On target	NOTE: This option is only available with software version 48.2X or newer. Positioning is completed and the on target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	NOTE: This option is only available with software version 48.2X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position limit	NOTE: This option is only available with software version 48.2X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	NOTE: This option is only available with software version 48.2X or newer. Target position is reached in touch probe position mode.
[227]	Touch activated	Touch probe positioning is active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	

Option	Name	Description
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

6.14.7 13-5* States

13-51 SL Controller Event

Default value:	–	Parameter type:	Option, Array [20]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	False	Select the boolean input (true or false) to define the smart logic controller event. See parameter 13-01 Start Event (options [0] False –[61] Logic rule 5) and parameter 13-02 Stop Event (options [70] SL Time-out 3 –[74] SL Time-out 7) for more information.
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	

Option	Name	Description
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	
 NOTE: This option is only available in FC 302.		
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	Use the result of comparator 4.
[51]	Comparator 5	Use the result of comparator 5.
[60]	Logic rule 4	Use the result of logic rule 4.

Option	Name	Description
[61]	Logic rule 5	Use the result of logic rule 5.
[70]	SL time-out 3	
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input X46/1	
[80]	Digital input X46/3	
[81]	Digital input X46/5	
[82]	Digital input X46/7	
[83]	Digital input X46/9	
[84]	Digital input X46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 164</i> , ATEX ETR <i>cur.lim.alarm</i> is active, the output is 1.
[91]	ATEX ETR cur. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166</i> , ATEX ETR <i>freq.lim.alarm</i> is active, the output is 1.
[92]	ATEX ETR freq. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163</i> , ATEX ETR <i>cur.lim.warning</i> is active, the output is 1.
[93]	ATEX ETR freq. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165</i> , ATEX ETR <i>freq.lim.warning</i> is active, the output is 1.
[94]	RS Flipflop 0	See parameter group 13-1* Comparators .
[95]	RS Flipflop 1	See parameter group 13-1* Comparators .
[96]	RS Flipflop 2	See parameter group 13-1* Comparators .
[97]	RS Flipflop 3	See parameter group 13-1* Comparators .
[98]	RS Flipflop 4	See parameter group 13-1* Comparators .
[99]	RS Flipflop 5	See parameter group 13-1* Comparators .
[100]	RS Flipflop 6	See parameter group 13-1* Comparators .
[101]	RS Flipflop 7	See parameter group 13-1* Comparators .
[102]	Relay 1	
[103]	Relay 2	

Option	Name	Description
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	 NOTE: This option is only available with software version 48.2X or newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).
[223]	On target	 NOTE: This option is only available with software version 48.2X or newer. Positioning is completed and the on target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	 NOTE: This option is only available with software version 48.2X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position limit	 NOTE: This option is only available with software version 48.2X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	 NOTE: This option is only available with software version 48.2X or newer. Target position is reached in touch probe position mode.
[227]	Touch activated	Touch probe positioning is active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	

Option	Name	Description
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

13-52 SL Controller Action

Default value:	–	Parameter type:	Option, Array [20]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the action corresponding to the SLC event. Actions are executed when the corresponding event (defined in parameter **13-51 SL Controller 1 Event**) is evaluated as true.

Option	Name	Description
[0]	DISABLED	
[1]	No action	
[2]	Select set-up 1	Changes the active setup (parameter 0-10 Active Set-up) to 1. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[3]	Select set-up 2	Changes the active setup (parameter 0-10 Active Set-up) to 2. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[4]	Select set-up 3	Changes the active setup (parameter 0-10 Active Set-up) to 3. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[5]	Select set-up 4	Changes the active setup (parameter 0-10 Active Set-up) to 4. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[10]	Select preset ref 0	Selects preset reference 0. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.

Option	Name	Description
[11]	Select preset ref 1	Selects preset reference 1. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[12]	Select preset ref 2	Selects preset reference 2. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[13]	Select preset ref 3	Selects preset reference 3. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[14]	Select preset ref 4	Selects preset reference 4. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[15]	Select preset ref 5	Selects preset reference 5. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[16]	Select preset ref 6	Selects preset reference 6. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[17]	Select preset ref 7	Selects preset reference 7. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[18]	Select ramp 1	Selects ramp 1.
[19]	Select ramp 2	Selects ramp 2.
[20]	Select ramp 3	Selects ramp 3.
[21]	Select ramp 4	Selects ramp 4.
[22]	Run	Issues a start command to the drive.
[23]	Run reverse	Issues a start reverse command to the drive.
[24]	Stop	Issues a stop command to the drive.
[25]	Qstop	Issues a quick stop command to the drive.
[26]	Dcstop	Issues a DC stop command to the drive.
[27]	Coast	The drive coasts immediately. All stop commands including the coast command stop the SLC.
[28]	Freeze output	Freezes the output frequency of the drive.
[29]	Start timer 0	Starts timer 0, see parameter 13-20 SL Controller Timer for further description.
[30]	Start timer 1	Starts timer 1, see parameter 13-20 SL Controller Timer for further description.
[31]	Start timer 2	Starts timer 2, see parameter 13-20 SL Controller Timer for further description.
[32]	Set digital out A low	Any output with smart logic output A is low.
[33]	Set digital out B low	Any output with smart logic output B is low.
[34]	Set digital out C low	Any output with smart logic output C is low.

Option	Name	Description
[35]	Set digital out D low	Any output with smart logic output D is low.
[36]	Set digital out E low	Any output with smart logic output E is low.
[37]	Set digital out F low	Any output with smart logic output F is low.
[38]	Set digital out A high	Any output with smart logic output A is high.
[39]	Set digital out B high	Any output with smart logic output B is high.
[40]	Set digital out C high	Any output with smart logic output C is high.
[41]	Set digital out D high	Any output with smart logic output D is high.
[42]	Set digital out E high	Any output with smart logic output E is high.
[43]	Set digital out F high	Any output with smart logic output F is high.
[60]	Reset Counter A	Resets counter A to 0.
[61]	Reset Counter B	Resets counter B to 0.
[62]	Counter A (up)	
[63]	Counter A (down)	
[64]	Counter B (up)	
[65]	Counter B (down)	
[70]	Start timer 3	Starts timer 3, see parameter 13-20 SL Controller Timer for further description.
[71]	Start timer 4	Starts timer 4, see parameter 13-20 SL Controller Timer for further description.
[72]	Start timer 5	Starts timer 5, see parameter 13-20 SL Controller Timer for further description.
[73]	Start timer 6	Starts timer 6, see parameter 13-20 SL Controller Timer for further description.
[74]	Start timer 7	Starts timer 7, see parameter 13-20 SL Controller Timer for further description.
[75]	Start timer 8	Starts timer 8, see parameter 13-20 SL Controller Timer for further description.
[76]	Start timer 9	Starts timer *, see parameter 13-20 SL Controller Timer for further description.
[100]	Reset alarms	
[120]	Start homing	 NOTE: This option is available only with software version 48.20 and newer. Activates the homing mode and starts the homing function selected in parameter 17-80 Homing Function. Must remain active until the homing is completed otherwise the homing is aborted.
[121]	Stop homing	 NOTE: This option is available only with software version 48.20 and newer. Deactivates the homing mode, an active homing function is aborted if the homing is not completed.

Option	Name	Description
[122]	Enable reference	 NOTE: This option is available only with software version 48.20 and newer. Sets the enable reference mode.
[123]	Disable reference	 NOTE: This option is available only with software version 48.20 and newer. Disables the enable reference mode.
[124]	Relative position	 NOTE: This option is available only with software version 48.20 and newer. Selects the relative position mode instead of the absolute position mode.
[125]	Absolute position	 NOTE: This option is available only with software version 48.20 and newer. Selects the absolute position mode instead of the relative position mode.
[126]	Activate touch	 NOTE: This option is available only with software version 48.20 and newer. Activates the touch probe positioning mode.
[127]	Deactivate touch	 NOTE: This option is available only with software version 48.20 and newer. Deactivates the touch probe positioning mode.
[128]	Target inverse	 NOTE: This option is available only with software version 48.20 and newer. Changes the sign of the active target position value.
[129]	Target	 NOTE: This option is available only with software version 48.20 and newer. The active target position is not changed.
[130]	Act. speed mode	 NOTE: This option is available only with software version 48.20 and newer. Activates the speed mode when option [9] Positioning or option [10] Synchronization is selected in parameter 1-00 Configuration Mode.
[131]	Deact. speed mode	 NOTE: This option is available only with software version 48.20 and newer. Deactivates the speed mode and activates the option selected in parameter 1-00 Configuration Mode.

13-53 SL Controller 2 Event

Default value:	–	Parameter type:	Option, Array [20]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	False	Select the boolean input (true or false) to define the smart logic controller event. See parameter 13-01 Start Event (options [0] False –[61] Logic rule 5) and parameter 13-02 Stop Event (options [70] SL Time-out 3 –[74] SL Time-out 7) for more information.
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	

Option	Name	Description
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	 NOTE: This option is only available in FC 302.
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	Use the result of comparator 4.
[51]	Comparator 5	Use the result of comparator 5.
[60]	Logic rule 4	Use the result of logic rule 4.
[61]	Logic rule 5	Use the result of logic rule 5.
[70]	SL time-out 3	
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input X46/1	
[80]	Digital input X46/3	
[81]	Digital input X46/5	
[82]	Digital input X46/7	

Option	Name	Description
[83]	Digital input X46/9	
[84]	Digital input X46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 164</i> , ATEX ETR <i>cur.lim.alarm</i> is active, the output is 1.
[91]	ATEX ETR cur. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166</i> , ATEX ETR <i>freq.lim.alarm</i> is active, the output is 1.
[92]	ATEX ETR freq. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163</i> , ATEX ETR <i>cur.lim.warning</i> is active, the output is 1.
[93]	ATEX ETR freq. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165</i> , ATEX ETR <i>freq.lim.warning</i> is active, the output is 1.
[94]	RS Flipflop 0	See parameter group 13-1* Comparators .
[95]	RS Flipflop 1	See parameter group 13-1* Comparators .
[96]	RS Flipflop 2	See parameter group 13-1* Comparators .
[97]	RS Flipflop 3	See parameter group 13-1* Comparators .
[98]	RS Flipflop 4	See parameter group 13-1* Comparators .
[99]	RS Flipflop 5	See parameter group 13-1* Comparators .
[100]	RS Flipflop 6	See parameter group 13-1* Comparators .
[101]	RS Flipflop 7	See parameter group 13-1* Comparators .
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	 NOTE: This option is only available with software version 48.2X or newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).

Option	Name	Description
[223]	On target	 NOTE: This option is only available with software version 48.2X or newer. Positioning is completed and the on target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	 NOTE: This option is only available with software version 48.2X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position limit	 NOTE: This option is only available with software version 48.2X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	 NOTE: This option is only available with software version 48.2X or newer. Target position is reached in touch probe position mode.
[227]	Touch activated	Touch probe positioning is active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	

Option	Name	Description
[244]	SL digital output E	
[245]	SL digital output F	

13-54 SL Controller 2 Action

Default value:	–	Parameter type:	Option, Array [20]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the action corresponding to the SLC event. Actions are executed when the corresponding event (defined in parameter **13-53 SL Controller 2 Event**) is evaluated as true.

Option	Name	Description
[0]	DISABLED	
[1]	No action	
[2]	Select set-up 1	Changes the active setup (parameter 0-10 Active Set-up) to 1. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[3]	Select set-up 2	Changes the active setup (parameter 0-10 Active Set-up) to 2. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[4]	Select set-up 3	Changes the active setup (parameter 0-10 Active Set-up) to 3. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[5]	Select set-up 4	Changes the active setup (parameter 0-10 Active Set-up) to 4. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[10]	Select preset ref 0	Selects preset reference 0. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[11]	Select preset ref 1	Selects preset reference 1. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[12]	Select preset ref 2	Selects preset reference 2. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[13]	Select preset ref 3	Selects preset reference 3. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[14]	Select preset ref 4	Selects preset reference 4. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[15]	Select preset ref 5	Selects preset reference 5. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.

Option	Name	Description
[16]	Select preset ref 6	Selects preset reference 6. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[17]	Select preset ref 7	Selects preset reference 7. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[18]	Select ramp 1	Selects ramp 1.
[19]	Select ramp 2	Selects ramp 2.
[20]	Select ramp 3	Selects ramp 3.
[21]	Select ramp 4	Selects ramp 4.
[22]	Run	Issues a start command to the drive.
[23]	Run reverse	Issues a start reverse command to the drive.
[24]	Stop	Issues a stop command to the drive.
[25]	Qstop	Issues a quick stop command to the drive.
[26]	Dcstop	Issues a DC stop command to the drive.
[27]	Coast	The drive coasts immediately. All stop commands including the coast command stop the SLC.
[28]	Freeze output	Freezes the output frequency of the drive.
[29]	Start timer 0	Starts timer 0, see parameter 13-20 SL Controller Timer for further description.
[30]	Start timer 1	Starts timer 1, see parameter 13-20 SL Controller Timer for further description.
[31]	Start timer 2	Starts timer 2, see parameter 13-20 SL Controller Timer for further description.
[32]	Set digital out A low	Any output with smart logic output A is low.
[33]	Set digital out B low	Any output with smart logic output B is low.
[34]	Set digital out C low	Any output with smart logic output C is low.
[35]	Set digital out D low	Any output with smart logic output D is low.
[36]	Set digital out E low	Any output with smart logic output E is low.
[37]	Set digital out F low	Any output with smart logic output F is low.
[38]	Set digital out A high	Any output with smart logic output A is high.
[39]	Set digital out B high	Any output with smart logic output B is high.
[40]	Set digital out C high	Any output with smart logic output C is high.
[41]	Set digital out D high	Any output with smart logic output D is high.
[42]	Set digital out E high	Any output with smart logic output E is high.
[43]	Set digital out F high	Any output with smart logic output F is high.
[60]	Reset Counter A	Resets counter A to 0.
[61]	Reset Counter B	Resets counter B to 0.
[62]	Counter A (up)	

Option	Name	Description
[63]	Counter A (down)	
[64]	Counter B (up)	
[65]	Counter B (down)	
[70]	Start timer 3	Starts timer 3, see parameter 13-20 SL Controller Timer for further description.
[71]	Start timer 4	Starts timer 4, see parameter 13-20 SL Controller Timer for further description.
[72]	Start timer 5	Starts timer 5, see parameter 13-20 SL Controller Timer for further description.
[73]	Start timer 6	Starts timer 6, see parameter 13-20 SL Controller Timer for further description.
[74]	Start timer 7	Starts timer 7, see parameter 13-20 SL Controller Timer for further description.
[75]	Start timer 8	Starts timer 8, see parameter 13-20 SL Controller Timer for further description.
[76]	Start timer 9	Starts timer 9, see parameter 13-20 SL Controller Timer for further description.
[100]	Reset alarms	
[120]	Start homing	NOTE: This option is available only with software version 48.20 and newer. Activates the homing mode and starts the homing function selected in parameter 17-80 Homing Function. Must remain active until the homing is completed otherwise the homing is aborted.
[121]	Stop homing	NOTE: This option is available only with software version 48.20 and newer. Deactivates the homing mode, an active homing function is aborted if the homing is not completed.
[122]	Enable reference	NOTE: This option is available only with software version 48.20 and newer. Sets the enable reference mode.
[123]	Disable reference	NOTE: This option is available only with software version 48.20 and newer. Disables the enable reference mode.
[124]	Relative position	NOTE: This option is available only with software version 48.20 and newer. Selects the relative position mode instead of the absolute position mode.

Option	Name	Description
[125]	Absolute position	NOTE: This option is available only with software version 48.20 and newer. Selects the absolute position mode instead of the relative position mode.
[126]	Activate touch	NOTE: This option is available only with software version 48.20 and newer. Activates the touch probe positioning mode.
[127]	Deactivate touch	NOTE: This option is available only with software version 48.20 and newer. Deactivates the touch probe positioning mode.
[128]	Target inverse	NOTE: This option is available only with software version 48.20 and newer. Changes the sign of the active target position value.
[129]	Target	NOTE: This option is available only with software version 48.20 and newer. The active target position is not changed.
[130]	Act. speed mode	NOTE: This option is available only with software version 48.20 and newer. Activates the speed mode when option [9] Positioning or option [10] Synchronization is selected in parameter 1-00 Configuration Mode.
[131]	Deact. speed mode	NOTE: This option is available only with software version 48.20 and newer. Deactivates the speed mode and activates the option selected in parameter 1-00 Configuration Mode.

13-55 SL Controller 3 Event

Default value:	–	Parameter type:	Option, Array [20]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True
Option	Name	Description	
[0]	False	Select the boolean input (true or false) to define the smart logic controller event. See parameter 13-01 Start Event (options [0] False – [61] Logic rule 5) and parameter 13-02 Stop Event (options [70] SL Time-out 3 – [74] SL Time-out 7) for more information.	
[1]	True		

Option	Name	Description
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	
[37]	Digital input DI32	
[38]	Digital input DI33	

Option	Name	Description
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	Use the result of comparator 4.
[51]	Comparator 5	Use the result of comparator 5.
[60]	Logic rule 4	Use the result of logic rule 4.
[61]	Logic rule 5	Use the result of logic rule 5.
[70]	SL time-out 3	
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input X46/1	
[80]	Digital input X46/3	
[81]	Digital input X46/5	
[82]	Digital input X46/7	
[83]	Digital input X46/9	
[84]	Digital input X46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 164, ATEX ETR cur.lim.alarm</i> is active, the output is 1.
[91]	ATEX ETR cur. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166, ATEX ETR freq.lim.alarm</i> is active, the output is 1.

Option	Name	Description
[92]	ATEX ETR freq. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163</i> , ATEX ETR <i>cur.lim.warning</i> is active, the output is 1.
[93]	ATEX ETR freq. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165</i> , ATEX ETR <i>freq.lim.warning</i> is active, the output is 1.
[94]	RS Flipflop 0	See parameter group 13-1* Comparators .
[95]	RS Flipflop 1	See parameter group 13-1* Comparators .
[96]	RS Flipflop 2	See parameter group 13-1* Comparators .
[97]	RS Flipflop 3	See parameter group 13-1* Comparators .
[98]	RS Flipflop 4	See parameter group 13-1* Comparators .
[99]	RS Flipflop 5	See parameter group 13-1* Comparators .
[100]	RS Flipflop 6	See parameter group 13-1* Comparators .
[101]	RS Flipflop 7	See parameter group 13-1* Comparators .
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	 NOTE: This option is only available with software version 48.2X or newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).
[223]	On target	 NOTE: This option is only available with software version 48.2X or newer. Positioning is completed and the on target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	 NOTE: This option is only available with software version 48.2X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.

Option	Name	Description
[225]	Position limit	 NOTE: This option is only available with software version 48.2X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	 NOTE: This option is only available with software version 48.2X or newer. Target position is reached in touch probe position mode.
[227]	Touch activated	Touch probe positioning is active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

13-56 SL Controller 3 Action

Default value:	–	Parameter type:	Option, Array [20]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the action corresponding to the SLC event. Actions are executed when the corresponding event (defined in parameter **13-55 SL Controller 3 Event**) is evaluated as true.

Option	Name	Description
[0]	DISABLED	
[1]	No action	
[2]	Select set-up 1	Changes the active setup (parameter 0-10 Active Set-up) to 1. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[3]	Select set-up 2	Changes the active setup (parameter 0-10 Active Set-up) to 2. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[4]	Select set-up 3	Changes the active setup (parameter 0-10 Active Set-up) to 3. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[5]	Select set-up 4	Changes the active setup (parameter 0-10 Active Set-up) to 4. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[10]	Select preset ref 0	Selects preset reference 0. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[11]	Select preset ref 1	Selects preset reference 1. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[12]	Select preset ref 2	Selects preset reference 2. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[13]	Select preset ref 3	Selects preset reference 3. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[14]	Select preset ref 4	Selects preset reference 4. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[15]	Select preset ref 5	Selects preset reference 5. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[16]	Select preset ref 6	Selects preset reference 6. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[17]	Select preset ref 7	Selects preset reference 7. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[18]	Select ramp 1	Selects ramp 1.
[19]	Select ramp 2	Selects ramp 2.
[20]	Select ramp 3	Selects ramp 3.
[21]	Select ramp 4	Selects ramp 4.
[22]	Run	Issues a start command to the drive.
[23]	Run reverse	Issues a start reverse command to the drive.

Option	Name	Description
[24]	Stop	Issues a stop command to the drive.
[25]	Qstop	Issues a quick stop command to the drive.
[26]	Dcstop	Issues a DC stop command to the drive.
[27]	Coast	The drive coasts immediately. All stop commands including the coast command stop the SLC.
[28]	Freeze output	Freezes the output frequency of the drive.
[29]	Start timer 0	Starts timer 0, see parameter 13-20 SL Controller Timer for further description.
[30]	Start timer 1	Starts timer 1, see parameter 13-20 SL Controller Timer for further description.
[31]	Start timer 2	Starts timer 2, see parameter 13-20 SL Controller Timer for further description.
[32]	Set digital out A low	Any output with smart logic output A is low.
[33]	Set digital out B low	Any output with smart logic output B is low.
[34]	Set digital out C low	Any output with smart logic output C is low.
[35]	Set digital out D low	Any output with smart logic output D is low.
[36]	Set digital out E low	Any output with smart logic output E is low.
[37]	Set digital out F low	Any output with smart logic output F is low.
[38]	Set digital out A high	Any output with smart logic output A is high.
[39]	Set digital out B high	Any output with smart logic output B is high.
[40]	Set digital out C high	Any output with smart logic output C is high.
[41]	Set digital out D high	Any output with smart logic output D is high.
[42]	Set digital out E high	Any output with smart logic output E is high.
[43]	Set digital out F high	Any output with smart logic output F is high.
[60]	Reset Counter A	Resets counter A to 0.
[61]	Reset Counter B	Resets counter B to 0.
[62]	Counter A (up)	
[63]	Counter A (down)	
[64]	Counter B (up)	
[65]	Counter B (down)	
[70]	Start timer 3	Starts timer 3, see parameter 13-20 SL Controller Timer for further description.
[71]	Start timer 4	Starts timer 4, see parameter 13-20 SL Controller Timer for further description.
[72]	Start timer 5	Starts timer 5, see parameter 13-20 SL Controller Timer for further description.
[73]	Start timer 6	Starts timer 6, see parameter 13-20 SL Controller Timer for further description.

Option	Name	Description
[74]	Start timer 7	Starts timer 7, see parameter 13-20 SL Controller Timer for further description.
[75]	Start timer 8	Starts timer 8, see parameter 13-20 SL Controller Timer for further description.
[76]	Start timer 9	Starts timer 9, see parameter 13-20 SL Controller Timer for further description.
[100]	Reset alarms	
[120]	Start homing	 NOTE: This option is available only with software version 48.20 and newer. Activates the homing mode and starts the homing function selected in parameter 17-80 Homing Function. Must remain active until the homing is completed otherwise the homing is aborted.
[121]	Stop homing	 NOTE: This option is available only with software version 48.20 and newer. Deactivates the homing mode, an active homing function is aborted if the homing is not completed.
[122]	Enable reference	 NOTE: This option is available only with software version 48.20 and newer. Sets the enable reference mode.
[123]	Disable reference	 NOTE: This option is available only with software version 48.20 and newer. Disables the enable reference mode.
[124]	Relative position	 NOTE: This option is available only with software version 48.20 and newer. Selects the relative position mode instead of the absolute position mode.
[125]	Absolute position	 NOTE: This option is available only with software version 48.20 and newer. Selects the absolute position mode instead of the relative position mode.
[126]	Activate touch	 NOTE: This option is available only with software version 48.20 and newer. Activates the touch probe positioning mode.
[127]	Deactivate touch	 NOTE: This option is available only with software version 48.20 and newer. Deactivates the touch probe positioning mode.

Option	Name	Description
[128]	Target inverse	 NOTE: This option is available only with software version 48.20 and newer. Changes the sign of the active target position value.
[129]	Target	 NOTE: This option is available only with software version 48.20 and newer. The active target position is not changed.
[130]	Act. speed mode	 NOTE: This option is available only with software version 48.20 and newer. Activates the speed mode when option [9] Positioning or option [10] Synchronization is selected in parameter 1-00 Configuration Mode .
[131]	Deact. speed mode	 NOTE: This option is available only with software version 48.20 and newer. Deactivates the speed mode and activates the option selected in parameter 1-00 Configuration Mode .

13-57 SL Controller 4 Event

Default value:	–	Parameter type:	Option, Array [20]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	False	Select the boolean input (true or false) to define the smart logic controller event. See parameter 13-01 Start Event (options [0] False – [61] Logic rule 5) and parameter 13-02 Stop Event (options [70] SL Time-out 3 – [74] SL Time-out 7) for more information.
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	

Option	Name	Description
[12]	Above speed high	
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	
 NOTE: This option is only available in FC 302.		
[37]	Digital input DI32	
[38]	Digital input DI33	
[39]	Start command	
[40]	Drive stopped	
[41]	Reset trip	
[42]	Auto-reset trip	
[43]	OK key	[OK] is pressed. Only available on the graphical LCP.
[44]	Reset key	[Reset] is pressed. Only available on the graphical LCP.
[45]	Left key	[◀] is pressed. Only available on the graphical LCP.
[46]	Right key	[▶] is pressed. Only available on the graphical LCP.
[47]	Up key	[▲] is pressed. Only available on the graphical LCP.

Option	Name	Description
[48]	Down key	[▼] is pressed. Only available on the graphical LCP.
[50]	Comparator 4	Use the result of comparator 4.
[51]	Comparator 5	Use the result of comparator 5.
[60]	Logic rule 4	Use the result of logic rule 4.
[61]	Logic rule 5	Use the result of logic rule 5.
[70]	SL time-out 3	
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[75]	Start command given	
[76]	Digital input X30/2	
[77]	Digital input X30/3	
[78]	Digital input X30/4	
[79]	Digital input X46/1	
[80]	Digital input X46/3	
[81]	Digital input X46/5	
[82]	Digital input X46/7	
[83]	Digital input X46/9	
[84]	Digital input X46/11	
[85]	Digital input X46/13	
[90]	ATEX ETR cur. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 164, ATEX ETR cur.lim.alarm</i> is active, the output is 1.
[91]	ATEX ETR cur. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 166, ATEX ETR freq.lim.alarm</i> is active, the output is 1.
[92]	ATEX ETR freq. warning	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>alarm 163, ATEX ETR cur.lim.warning</i> is active, the output is 1.
[93]	ATEX ETR freq. alarm	Available if parameter 1-90 Motor Thermal Protection is set to [20] ATEX ETR or [21] Advanced ETR . If <i>warning 165, ATEX ETR freq.lim.warning</i> is active, the output is 1.
[94]	RS Flipflop 0	See parameter group 13-1* Comparators .
[95]	RS Flipflop 1	See parameter group 13-1* Comparators .
[96]	RS Flipflop 2	See parameter group 13-1* Comparators .
[97]	RS Flipflop 3	See parameter group 13-1* Comparators .
[98]	RS Flipflop 4	See parameter group 13-1* Comparators .
[99]	RS Flipflop 5	See parameter group 13-1* Comparators .

Option	Name	Description
[100]	RS Flipflop 6	See parameter group 13-1* Comparators .
[101]	RS Flipflop 7	See parameter group 13-1* Comparators .
[102]	Relay 1	
[103]	Relay 2	
[104]	Relay 3	X47/VLT® Extended Relay Card MCB 113.
[105]	Relay 4	X47/VLT® Extended Relay Card MCB 113.
[106]	Relay 5	X47/VLT® Extended Relay Card MCB 113.
[107]	Relay 6	X47/VLT® Extended Relay Card MCB 113.
[108]	Relay 7	X34/VLT® Relay Card MCB 105.
[109]	Relay 8	X34/VLT® Relay Card MCB 105.
[110]	Relay 9	X34/VLT® Relay Card MCB 105.
[212]	Emergency mode	
[222]	Homing OK	NOTE: This option is only available with software version 48.2X or newer. Homing is completed with the selected homing function (parameter 17-80 Homing Function).
[223]	On target	NOTE: This option is only available with software version 48.2X or newer. Positioning is completed and the on target signal is sent when the actual position is within parameter 3-05 On Reference Window for the duration of parameter 3-09 On Target Time and the actual speed does not exceed parameter 3-05 On Reference Window.
[224]	Position error	NOTE: This option is only available with software version 48.2X or newer. The position error exceeds the value in parameter 4-71 Maximum Position Error for the time set in parameter 4-72 Position Error Timeout.
[225]	Position limit	NOTE: This option is only available with software version 48.2X or newer. The position is outside the limits set in parameter 3-06 Minimum Position and parameter 3-07 Maximum Position.
[226]	Touch on target	NOTE: This option is only available with software version 48.2X or newer. Target position is reached in touch probe position mode.
[227]	Touch activated	Touch probe positioning is active. The drive monitors the touch probe sensor input.
[228]	Comparator 6	

Option	Name	Description
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

13-58 SL Controller 4 Action

Default value:	–	Parameter type:	Option, Array [20]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the action corresponding to the SLC event. Actions are executed when the corresponding event (defined in parameter **13-57 SL Controller 4 Event**) is evaluated as true.

Option	Name	Description
[0]	DISABLED	
[1]	No action	
[2]	Select set-up 1	Changes the active setup (parameter 0-10 Active Set-up) to 1. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[3]	Select set-up 2	Changes the active setup (parameter 0-10 Active Set-up) to 2. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[4]	Select set-up 3	Changes the active setup (parameter 0-10 Active Set-up) to 3. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.
[5]	Select set-up 4	Changes the active setup (parameter 0-10 Active Set-up) to 4. If the setup is changed, it merges with other setup commands coming from either the digital inputs or via a fieldbus.

Option	Name	Description
[10]	Select preset ref 0	Selects preset reference 0. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[11]	Select preset ref 1	Selects preset reference 1. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[12]	Select preset ref 2	Selects preset reference 2. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[13]	Select preset ref 3	Selects preset reference 3. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[14]	Select preset ref 4	Selects preset reference 4. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[15]	Select preset ref 5	Selects preset reference 5. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[16]	Select preset ref 6	Selects preset reference 6. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[17]	Select preset ref 7	Selects preset reference 7. If the active preset reference is changed, it merges with other preset reference commands coming from either the digital inputs or via a fieldbus.
[18]	Select ramp 1	Selects ramp 1.
[19]	Select ramp 2	Selects ramp 2.
[20]	Select ramp 3	Selects ramp 3.
[21]	Select ramp 4	Selects ramp 4.
[22]	Run	Issues a start command to the drive.
[23]	Run reverse	Issues a start reverse command to the drive.
[24]	Stop	Issues a stop command to the drive.
[25]	Qstop	Issues a quick stop command to the drive.
[26]	Dcstop	Issues a DC stop command to the drive.
[27]	Coast	The drive coasts immediately. All stop commands including the coast command stop the SLC.
[28]	Freeze output	Freezes the output frequency of the drive.
[29]	Start timer 0	Starts timer 0, see parameter 13-20 SL Controller Timer for further description.
[30]	Start timer 1	Starts timer 1, see parameter 13-20 SL Controller Timer for further description.
[31]	Start timer 2	Starts timer 2, see parameter 13-20 SL Controller Timer for further description.

Option	Name	Description
[32]	Set digital out A low	Any output with smart logic output A is low.
[33]	Set digital out B low	Any output with smart logic output B is low.
[34]	Set digital out C low	Any output with smart logic output C is low.
[35]	Set digital out D low	Any output with smart logic output D is low.
[36]	Set digital out E low	Any output with smart logic output E is low.
[37]	Set digital out F low	Any output with smart logic output F is low.
[38]	Set digital out A high	Any output with smart logic output A is high.
[39]	Set digital out B high	Any output with smart logic output B is high.
[40]	Set digital out C high	Any output with smart logic output C is high.
[41]	Set digital out D high	Any output with smart logic output D is high.
[42]	Set digital out E high	Any output with smart logic output E is high.
[43]	Set digital out F high	Any output with smart logic output F is high.
[60]	Reset Counter A	Resets counter A to 0.
[61]	Reset Counter B	Resets counter B to 0.
[62]	Counter A (up)	
[63]	Counter A (down)	
[64]	Counter B (up)	
[65]	Counter B (down)	
[70]	Start timer 3	Starts timer 3, see parameter 13-20 SL Controller Timer for further description.
[71]	Start timer 4	Starts timer 4, see parameter 13-20 SL Controller Timer for further description.
[72]	Start timer 5	Starts timer 5, see parameter 13-20 SL Controller Timer for further description.
[73]	Start timer 6	Starts timer 6, see parameter 13-20 SL Controller Timer for further description.
[74]	Start timer 7	Starts timer 7, see parameter 13-20 SL Controller Timer for further description.
[75]	Start timer 8	Starts timer 8, see parameter 13-20 SL Controller Timer for further description.
[76]	Start timer 9	Starts timer 9, see parameter 13-20 SL Controller Timer for further description.
[100]	Reset alarms	
[120]	Start homing	 NOTE: This option is available only with software version 48.20 and newer. Activates the homing mode and starts the homing function selected in parameter 17-80 Homing Function. Must remain active until the homing is completed otherwise the homing is aborted.

Option	Name	Description
[121]	Stop homing	 NOTE: This option is available only with software version 48.20 and newer. Deactivates the homing mode, an active homing function is aborted if the homing is not completed.
[122]	Enable reference	 NOTE: This option is available only with software version 48.20 and newer. Sets the enable reference mode.
[123]	Disable reference	 NOTE: This option is available only with software version 48.20 and newer. Disables the enable reference mode.
[124]	Relative position	 NOTE: This option is available only with software version 48.20 and newer. Selects the relative position mode instead of the absolute position mode.
[125]	Absolute position	 NOTE: This option is available only with software version 48.20 and newer. Selects the absolute position mode instead of the relative position mode.
[126]	Activate touch	 NOTE: This option is available only with software version 48.20 and newer. Activates the touch probe positioning mode.
[127]	Deactivate touch	 NOTE: This option is available only with software version 48.20 and newer. Deactivates the touch probe positioning mode.
[128]	Target inverse	 NOTE: This option is available only with software version 48.20 and newer. Changes the sign of the active target position value.
[129]	Target	 NOTE: This option is available only with software version 48.20 and newer. The active target position is not changed.

Option	Name	Description
[130]	Act. speed mode	NOTE: This option is available only with software version 48.20 and newer. Activates the speed mode when option [9] Positioning or option [10] Synchronization is selected in parameter 1-00 Configuration Mode.
[131]	Deact. speed mode	NOTE: This option is available only with software version 48.20 and newer. Deactivates the speed mode and activates the option selected in parameter 1-00 Configuration Mode.

6.14.8 13-9* User-defined Alerts and Readouts

Parameters in this group allow the configuration of application-specific triggers for triggering the drive to perform a certain action, show the status on the LCP, and represent it accordingly in parameter **13-97 Alert Alarm Word**, parameter **13-98 Alert Warning Word**, and parameter **13-99 Alert Status Word**. In parameter **13-91 Alert Action**, it is possible to select drive functionalities such as *info only*, *stop*, *running to max*, and *force drive to trip*.

Use the following parameters to configure the drive to show a message and perform an action when a specific event occurs:

- Parameter **13-90 Alert Trigger** – the event that triggers the user-defined action and message.
- Parameter **13-91 Alert Action** – the action that the drive performs when the event defined in parameter **13-90 Alert Trigger** occurs.
- Parameter **13-92 Alert Text** – the text that the drive shows in the display when the event defined in parameter **13-90 Alert Trigger** occurs.

For example, consider the following use case: If there is an active signal on digital input 32, the drive shows the message *Valve 5 open* and ramps down to a stop. To achieve this configuration, make the following settings:

- Parameter **13-90 Alert Trigger** = **[37] Digital input DI32**.
- Parameter **13-91 Alert Action** = **[5] Stop & warning**.
- Parameter **13-92 Alert Text** = *Valve 5 open*.

Actions reflected in parameter **16-03 Status Word** and alert parameters

When an action containing trip is selected and triggered, the drive trips, bit 3 in the basic status word is set, and the corresponding hex value is shown in parameter **13-97 Alert Alarm Word**.

The alarm for *User Alert* is logged as alarm value = 124 in parameter **15-30 Fault Log: Error Code**, index [0]–[9].

When an action containing warning info is selected and triggered, bit 7 in the basic status word is set, and the corresponding hex value is shown in parameter **13-98 Alert Warning Word**.

Other actions selected are not indicated in the basic status word, but the corresponding hex value is shown in parameter **13-99 Alert Status Word**.

Example of setting up digital inputs as triggers, actions, and readouts

Refer to the following table to understand the 3 examples in this section.

Table 48: Example of Setting up Triggers, Actions, and Readouts

ID	Name	Setup 1
1390.0	Alert Trigger	[34] Digital input DI19
1390.1	Alert Trigger	[37] Digital input DI32

Table 48: Example of Setting up Triggers, Actions, and Readouts - (continued)

ID	Name	Setup 1
1390.2	Alert Trigger	[0] False
1390.3	Alert Trigger	[0] False
1390.4	Alert Trigger	[0] False
1390.5	Alert Trigger	[0] False
1390.6	Alert Trigger	[0] False
1390.7	Alert Trigger	[0] False
1390.8	Alert Trigger	[38] Digital input DI33
1390.9	Alert Trigger	[0] False
1391.0	Alert Action	[0] Info
1391.1	Alert Action	[1] Warning
1391.2	Alert Action	[0] Info
1391.3	Alert Action	[0] Info
1391.4	Alert Action	[0] Info
1391.5	Alert Action	[0] Info
1391.6	Alert Action	[0] Info
1391.7	Alert Action	[0] Info
1391.8	Alert Action	[12] Trip
1391.9	Alert Action	[0] Info
1392.0	Alert Text	Dig In 19
1392.1	Alert Text	Dig In 32
1392.2	Alert Text	User Alert
1392.3	Alert Text	User Alert
1392.4	Alert Text	User Alert
1392.5	Alert Text	User Alert
1392.6	Alert Text	User Alert
1392.7	Alert Text	User Alert
1392.8	Alert Text	Dig In 33
1392.9	Alert Text	User Alert

Example 1: In parameter **13-90 Alert Trigger**, index [0], DI19 is selected as trigger. The digital value is 0000 0001. The corresponding action, Info, is set in parameter **13-91 Alert Action**, index [0] and is shown as 1 hex in parameter **13-99 Alert Status Word**.

Example 2: In parameter **13-90 Alert Trigger**, index [1], DI32 is selected as trigger. The digital value is 0000 0010. The corresponding action, Warning, is set in parameter **13-91 Alert Action**, index [1] and is shown as 2 hex in parameter **13-98 Alert Warning Word**.

Example 3: In parameter **13-90 Alert Trigger**, index [8], DI33 is selected as trigger. The digital value is 0001 0000 0000. The corresponding action, Trip, is set in parameter **13-91 Alert Action**, index [8] and is shown as 100 hex in parameter **13-97 Alert Alarm Word**.

When 1 of the 3 digital inputs shown in this example is activated, the text shown in the LCP is the one defined in parameter **13-92 Alert Text**, index [0], [1], and [8].

NOTICE

The action setting of an active trigger cannot be changed. For example, if DI19 is selected as trigger and the input is high, the action cannot be changed from *Stop* to *Log*.

13-90 Alert Trigger

Default value:	[0] False	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the event that triggers the user-defined action and message.

Option	Name	Description
[0]*	False	
[1]	True	
[18]	Reversing	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	
[37]	Digital input DI32	
[38]	Digital input DI33	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL time-out 3	
[71]	SL time-out 4	



NOTE: This option is only available in FC 302.

Option	Name	Description
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[94]	RS flipflop 0	
[95]	RS flipflop 1	
[96]	RS flipflop 2	
[97]	RS flipflop 3	
[98]	RS flipflop 4	
[99]	RS flipflop 5	
[100]	RS flipflop 6	
[101]	RS flipflop 7	
[228]	Comparator 6	
[229]	Comparator 7	
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	

13-91 Alert Action

Default value:	[0] Info	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True



NOTE: For safety reasons, this parameter cannot be changed when there is an active alarm.

Select the action that the drive performs when the event defined in parameter **13-90 Alert Trigger** occurs.

Option	Name	Description
[0]*	Info	
[1]	Warning	
[2]	Freeze output	
[3]	Freeze output & warn	

Option	Name	Description
[4]	Stop	
[5]	Stop & warning	
[6]	Jogging	
[7]	Jogging & warning	
[8]	Max speed	
[9]	Max speed & warn	
[10]	Stop and trip	
[11]	Stop and trip w manual reset	
[12]	Trip	
[13]	Trip w manual reset	
[14]	Trip lock	

13-92 Alert Text

Default value:	Size related	Parameter type:	Array [10]
Setup:	2 setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	True

Enter the text that the drive shows in the display when the event defined in parameter **13-90 Alert Trigger** occurs.

13-97 Alert Alarm Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt32	Change during operation:	False

Shows the alarm word of a user-defined alarm in hex code.

13-98 Alert Warning Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt32	Change during operation:	False

Shows the warning word of a user-defined alarm in hex code.

13-99 Alert Status Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt32	Change during operation:	False

Shows the status word of a user-defined alarm in hex code.

6.15 Parameter Group 14-** Special Functions

6.15.1 14-0* Inverter Switching

14-00 Switching Pattern

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the switching pattern: 60° AVM or SFAVM.



NOTE: The drive may adjust the switching pattern automatically to avoid a trip.

Option	Name	Description
[0]	60 AVM	
[1]	SFAVM	

14-01 Switching Frequency

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the drive switching frequency. Changing the switching frequency reduces acoustic noise from the motor. Default values depend on power rating.



NOTE: The output frequency value of the drive must not exceed 10% of the switching frequency. When the motor is running, adjust the switching frequency in parameter **14-01 Switching Frequency** to minimize motor noise.



NOTE: To avoid a trip, the drive can adjust the switching frequency automatically.

Option	Name	Description
[0]	1.0 kHz	
[1]	1.5 kHz	Default switching frequency for 355–1200 kW [500–1600 hp], 690 V.
[2]	2.0 kHz	Default switching frequency for 250–800 kW [350–1075 hp], 400 V, and 37–315 kW [50–450 hp], 690 V.
[3]	2.5 kHz	
[4]	3.0 kHz	Default switching frequency for 18.5–37 kW [25–50 hp], 200 V, and 37–200 kW [50–300 hp], 400 V.
[5]	3.5 kHz	
[6]	4.0 kHz	Default switching frequency for 5.5–15 kW [7.5–20 hp], 200 V, and 11–30 kW [15–40 hp], 400 V.

Option	Name	Description
[7]	5.0 kHz	Default switching frequency for 0.25–3.7 kW [0.34–5 hp], 200 V, and 0.37–7.5 kW [0.5–10 hp], 400 V.
[8]	6.0 kHz	
[9]	7.0 kHz	
[10]	8.0 kHz	
[11]	10.0 kHz	
[12]	12.0 kHz	
[13]	14.0 kHz	
[14]	16.0 kHz	

14-02 Switching Pattern Shift Frequency

Default value:	Size related	Parameter type:	Range, 15 - 590 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Set the frequency where the switching pattern shifts between SFAVM and 60° AVM. Set a value to keep high-speed motors in SFAVM mode during ramp-up and during low-speed operation. The value to set is motor-dependent. The pattern shift frequency can be set when parameter **14-00 Switching Pattern** is set to **[0] 60 AVM**.

14-03 Overmodulation

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: Overmodulation leads to increased torque ripple as harmonics increase.

Option	Name	Description
[0]	Off	Select [0] Off for no overmodulation of the output voltage to avoid torque ripple on the motor shaft. This feature may be useful for applications such as grinding machines.
[1]	On	Select [1] On to enable the overmodulation function for the output voltage. This is the right option when it is required that the output voltage is higher than 95% of the input voltage (typically when running over-synchronously). The output voltage is increased according to the degree of overmodulation. Control in flux control principle provides an output current of up to 98% of the input current, regardless of parameter 14-03 Overmodulation .

Option	Name	Description
[2]	User defined	Modulation index refers to the relation between motor voltage and DC-link voltage. High overmodulation increases the motor voltage and optimizes the motor torque and efficiency by reducing the motor current. A high modulation index increases the risk of torque ripple on the motor shaft. In applications where the torque ripple occur, it can be beneficial to disable the overmodulation. It is possible to configure the setup in the range defined in parameter 40-55 Modulation Index .
[3]	Limit output voltage	This option limits the motor voltage to the nominal motor voltage in parameter 1-22 Motor Voltage .

14-04 Acoustic Noise Reduction

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Off	No change of the acoustic motor switching noise.
[1]	On	Select to reduce the acoustic noise from the motor.

14-05 PWM Generation

Default value:	[0] Standard	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use this parameter in VVC+ and U/f mode only. When running with low ratio between switch frequency and output frequency (especially close to or <10:1), it is possible to improve the resolution of the PWM modulation and optimize the output voltage.

Option	Name	Description
[0]*	Standard	Use this setting for standard motors.
[1]	Double update	Updates the PWM pattern twice per switch period. Select this option to achieve a more optimal sinus-wave and a slight increase of the output voltage.

14-06 Dead Time Compensation

Default value:	[1] On	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Off	No compensation.
[1]*	On	Activates dead-time compensation.

6.15.2 14-1* Mains On/Off



NOTE:

The following parameter is only available in FC 302:

- Parameter **14-16 Kin. Back-up Gain**

Parameter for configuring the monitoring and handling of a mains failure. If a mains failure appears, the drive tries to continue in a controlled way until the power in the DC link is exhausted.

14-10 Mains Failure

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

When parameter **1-00 Configuration Mode** is set to **[2] Torque**, the following options are inactive:

- **[1] Ctrl. ramp-down**
- **[2] Ctrl. ramp-down, trip**
- **[5] Kinetic back-up, trip**
- **[7] Kin. back-up, trip w recovery**



NOTE: This parameter cannot be changed while the motor is running.

Parameter **14-10 Mains Failure** is typically used where short mains interruptions (voltage dips) are present. At 100% load and a short voltage interruption, the DC voltage on the main capacitors drops quickly. For larger drives, it only takes a few milliseconds before the DC level drops to about 373 V DC, and the IGBTs cut off and lose the control of the motor. When mains is restored, and the IGBTs start again, the output frequency and voltage vector do not correspond to the speed/frequency of the motor, and the result is normally an overvoltage or overcurrent, mostly resulting in a trip lock. Parameter **14-10 Mains Failure** can be programmed to avoid this situation. Select the function according to which the drive must act when the threshold in parameter **14-11 Mains Fault Voltage Level** is reached.

Option	Name	Description
[0]	No function	The drive does not compensate for a mains interruption. The voltage on the DC link drops quickly and motor control is lost within milliseconds to seconds. This situation results in a trip lock.
[1]	Ctrl. ramp-down	Control of the motor remains with the drive, and the drive performs a controlled ramp down from parameter 14-11 Mains Fault Voltage Level . If parameter 2-10 Brake Function is [0] Off or [2] AC brake , the ramp follows the overvoltage ramping. If parameter 2-10 Brake Function is [1] Resistor Brake , the ramp follows the setting in parameter 3-81 Quick Stop Ramp Time . This selection is useful in pump applications, where the inertia is low and the friction is high. When mains is restored, the output frequency ramps the motor up to the reference speed. If the mains interruption is prolonged, the controlled ramp down may bring the output frequency down to 0 RPM, and when the mains is restored, the application is ramped up from 0 RPM to the previous reference speed via the normal ramp-up. If the energy in the DC

Option	Name	Description
		link disappears before the motor is ramped to 0, the motor is coasted. Limitation: See the introduction text in this parameter.
[2]	Ctrl. ramp-down, trip	The functionality is the same as in [1] <i>Ctrl. ramp-down</i> , except in this option a reset is necessary for starting up after power-up.
[3]	Coasting	Centrifuges can run for 1 hour without supply. In those situations, it is possible to select a coast function at mains interruption, together with a flying start, which occurs when the mains is restored.
[4]	Kinetic back-up	Kinetic back-up ensures that the drive keeps running as long as there is energy in the system due to the inertia from motor and load. This is done by converting the mechanical energy to the DC link and maintaining control of the drive and motor. This can extend the controlled operation, depending on the inertia in the system. For fans, it is typically several seconds; for pumps up to 2 s; and for compressors only for a fraction of a second. Many industry applications can extend controlled operation for many seconds, which is often enough time for the mains to return.





Figure 87: Kinetic Back-up

A	Normal operation	B	Mains failure
C	Kinetic back-up	D	Mains return
E	Normal operation: Ramping		

The DC level during [4] *Kinetic backup* equals parameter **14-11 Mains Fault Voltage Level** x 1.35. If the mains does not return, U_{DC} is maintained as long as possible by ramping the speed down towards 0 RPM. Finally, the drive coasts. If the mains returns while in kinetic back-up mode, U_{DC} increases above parameter **14-11 Mains Fault Voltage Level** x 1.35. This is detected in 1 of the following ways:

- If $U_{DC} > \text{parameter } 14-11 \text{ Mains Fault Voltage Level} \times 1.35 \times 1.05$.
- If the speed is above the reference. This is relevant if the mains comes back at a lower level than before, for example parameter **14-11 Mains Fault Voltage Level** x 1.35 x 1.02. This does not fulfill the criterion in point 1, and the drive tries to

Option	Name	Description								
		reduce U_{DC} to parameter 14-11 Mains Fault Voltage Level x 1.35 by increasing the speed. This cannot be done as the mains cannot be lowered. If the motor runs mechanically. The same mechanism as in point 2 applies, but the inertia prevents the speed from going above the reference speed. This leads to the motor running mechanically until the speed is above the reference speed and the situation in point 2 occurs. Instead of waiting for that criterion, point 3 is introduced.								
[5]	Kinetic back-up, trip	The difference between kinetic back-up with and without trip is that the latter always ramps down to 0 RPM and trips, regardless of whether mains returns or not. The function does not detect if mains returns. This is the reason for the relatively high level on the DC link during ramp-down.  Figure 88: Kinetic Back-up Trip <table><tr><td>A</td><td>Normal operation</td><td>B</td><td>Mains failure</td></tr><tr><td>C</td><td>Kinetic back-up</td><td>D</td><td>Trip</td></tr></table>	A	Normal operation	B	Mains failure	C	Kinetic back-up	D	Trip
A	Normal operation	B	Mains failure							
C	Kinetic back-up	D	Trip							
[6]	Alarm									
[7]	Kin. back-up, trip w recovery	This option is valid in VVC+ only. Kinetic back-up with recovery combines the features of kinetic back-up and kinetic back-up with trip. This feature makes it possible to select between kinetic back-up and kinetic back-up with trip, based on a recovery speed, configurable in Parameter 14-15 Kin. Back-up Trip Recovery Level. If mains does not return, the drive ramps down to 0 RPM and trips. If mains returns while in kinetic back-up at a speed above the value in Parameter 14-15 Kin. Back-up Trip Recovery Level, normal operation is resumed. This is equal to [4] Kinetic Back-up. The DC level during [7] Kin. back-up, trip w recovery is parameter 14-11 Mains Fault Voltage Level x 1.35.								

Option	Name	Description




Figure 89: Kinetic Back-up Trip w/Recovery, Mains Returns Above Parameter 14-15 Kin. Back-up Trip Recovery Level

A	Normal operation	B	Mains Failure
C	Kinetic back-up	D	Mains return
E	Normal operation: Ramping		

If mains returns while in kinetic back-up at a speed below Parameter 14-15 Kin. Back-up Trip Recovery Level, the drive ramps down to 0 RPM using the ramp and then trips. If the ramp is slower than the system ramping down on its own, the ramping is done mechanically and U_{DC} is at the normal level ($U_{DC,m} \times 1.35$).




Figure 90: Kinetic Back-up Trip w/Recovery, Slow Ramp, Mains Returns Below Parameter 14-15 Kin. Back-up Trip Recovery Level

A	Normal operation	B	Mains failure
C	Kinetic back-up	D	Mains return
E	Kinetic back-up, ramping to trip	F	Trip

If the ramp is quicker than the ramp-down speed of the application, the ramping generates current. This results in a higher U_{DC} , which is limited using the brake chopper/resistor brake.

Option	Name	Description												
		Figure 91: Kinetic Back-up Trip w/Recovery, Quick Ramp, Mains Returns Below Parameter 14-15 Kin. Back-up Trip Recovery Level <table><tr><td>A</td><td>Normal operation</td><td>B</td><td>Mains failure</td></tr><tr><td>C</td><td>Kinetic back-up</td><td>D</td><td>Mains return</td></tr><tr><td>E</td><td>Kinetic back-up ramping to trip</td><td>F</td><td>Trip</td></tr></table>	A	Normal operation	B	Mains failure	C	Kinetic back-up	D	Mains return	E	Kinetic back-up ramping to trip	F	Trip
A	Normal operation	B	Mains failure											
C	Kinetic back-up	D	Mains return											
E	Kinetic back-up ramping to trip	F	Trip											
[8]	Fast Active Power Derating	NOTE: This option is not available with IMC.												
[9]	Kinetic back-up, coast	NOTE: This option is not available with IMC. The purpose of this function is to avoid mains failure trips (<i>Alarm 36</i>), for example, where mains is weak or can be disturbed by other motors being started directly. When the drive detects mains failure, the drive ramps down the motor using kinetic back-up and coasts the drive. The drive remains coasted for the time set in parameter 40-14 Mains Loss Duration - the actual ramp-down time in KB. If mains returns after that time, the drive ramps up again. When parameter 40-14 Mains Loss Duration = 60, the drive immediately restarts the ramp parameter up if the start command is still valid from PLC and mains voltage is back. When 40-14 Mains Loss Duration = <60, the drive waits for the timer in parameter 40-14 Mains Loss Duration to expire before restarting ramp up. This delay prevents an unintentional restart if the drive detects that mains is back at an acceptable level, but not being consistently back.												
[10]	Quick ramp-down	NOTE: This option is not available with IMC. The purpose of this function is to handle mains drop in low inertia applications, where the drive must continue running to make a ride-through by reducing the speed until the grid returns to full voltage. During the voltage drop, the speed ramps down using parameter 3-81 Quick Stop Ramp Time until voltage returns. After that, normal ramp up is used. The DC link is not regulated												

Option	Name	Description
		since this is not possible in a low-inertia application without any generative power in the motor/load. The selection is valid for IPM and SPM motors in Flux. To ensure that the function is activated, set parameter 14-11 Mains Failure Voltage Level higher than the expected voltage drop level. The quick ramp down must be set fast enough to endure a significant load drop to allow the control to run at reduced voltage, and it must be slow enough not to reach standstill before voltage returns - if possible. If speed reaches 0, it stays there until voltage returns and ramps up. If an alarm is required at standstill, it can be programmed in the SLC. An optional delay, set in parameter 40-14 Mains Loss Duration, can be activated before ramping up to bypass and ripple on the DC link when power returns.

14-11 Mains Fault Voltage Level

Default value:	Size related	Parameter type:	Range, 140 - 800 V
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter defines the threshold voltage at which the function in parameter **14-10 Mains Failure** is activated. Select the detection level depending on the supply quality. For a supply of 380 V, set parameter **14-11 Mains Fault Voltage Level** to 342 V. This results in a DC detection level of 462 V (parameter **14-11 Mains Fault Voltage Level** x 1.35).



NOTE: Converting from VLT 5000 to FC 300: Even though the setting of the mains voltage at mains fault is the same for VLT 5000 and FC 300, the detection level is different. Use the following formula to obtain the same detection level as in VLT 5000: Parameter **14-11 Mains Fault Voltage Level** (VLT 5000 level) = value used in VLT 5000 x 1.35/sqrt(2).

14-12 Response to Mains Imbalance

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: Make sure that the setting in parameter **0-03 Regional Setting** matches the actual grid.

Operation under severe mains imbalance conditions reduces the lifetime of the motor. Conditions are considered severe if the motor is operated continuously near nominal load (for example, a pump or a fan running near full speed). Select the level of operation when mains imbalance conditions occur. Options **[5] Fast trip lock** to **[7] Fast warning** are based on a principle which ensures detection of a missing mains phase within 2 s and responds according to the selection. See parameter **14-17 Fast Mains Phase Loss** and parameter **14-18 Fast Mains Phase Loss Min Power**. A minimum load on the drive of 2% nominal power is required for detection of missing mains phase.

Option	Name	Description
[0]	Trip Lock	A trip lock is triggered upon a mains phase imbalance.
[1]	Warning	A warning is issued upon a mains phase imbalance.

Option	Name	Description
[2]	Disabled	Mains failure detection is disabled.
[3]	Derate	The drive derates upon a mains phase imbalance.
[4]	Trip	The drive trips.
[5]	Fast Trip Lock	A trip lock occurs when a mains input phase is missing.
[6]	Fast Trip	The drive trips when a mains input phase is missing.
[7]	Fast Warning	A warning occurs when a mains input phase is missing.
[8]	Fast derate	

14-14 Kin. Back-up Time-up

Default value:	60 s	Parameter type:	Range, 0 - 60 s
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

This parameter defines the kinetic backup timeout in flux mode when running on low voltage grids. If the supply voltage does not exceed the value defined in parameter **14-11 Mains Fault Voltage Level** +5% within the specified time, the drive automatically runs a controlled ramp-down profile before stop.

14-15 Kin. Back-up Trip Recovery Level

Default value:	Size related	Parameter type:	Range, 0 - 60000.000 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

This parameter specifies the kinetic backup trip recovery level. The unit is defined in parameter **0-02 Motor Speed Unit**.

14-16 Kin. Back-up Gain

Default value:	Size related	Parameter type:	Range, 0 - 500%
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Enter the kinetic backup gain value in %.

14-17 Fast Mains Phase Loss Level

Default value:	100%	Parameter type:	Range, 0 - 500%
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the level at which the functions Fast Mains Phase Loss Trip or Fast Mains Phase Loss Warning (see parameter **14-12 Response to Mains Imbalance**) should be activated.



NOTE: A lower level than the default might cause false alarms as it increases sensitivity.

14-18 Fast Mains Phase Loss Min Power

Default value:	2%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the minimum power level (% of nominal power) at which the functions Fast Mains Phase Loss Trip or Fast Mains Phase Loss Warning (see parameter **14-12 Response to Mains Imbalance**) should be activated.



NOTE: A minimum power level of 2% is a prerequisite for the Fast Mains Phase Loss function to work.

6.15.3 14-2* Trip Reset

Parameters for configuring auto reset handling, special trip handling, and control card self-test or initialization.

14-20 Reset Mode

Default value:	[0] Manual reset	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the reset function after tripping. Once reset, the drive can be restarted.



NOTE: The motor may start without warning. If the specified number of automatic resets is reached within 10 minutes, the drive enters **[0] Manual reset** mode. After the manual reset is performed, the setting of parameter **14-20 Reset Mode** returns to the original selection. If the number of automatic resets are not reached within 10 minutes, or when a manual reset is performed, the internal automatic reset counter returns to 0.

Option	Name	Description
[0]*	Manual reset	Select [0] Manual reset to perform a reset via [Reset] or via the digital inputs.
[1]	Automatic reset x 1	Select [1]-[12] Automatic reset x 1... x20 to perform 1–20 automatic resets after tripping.
[2]	Automatic reset x 2	
[3]	Automatic reset x 3	
[4]	Automatic reset x 4	
[5]	Automatic reset x 5	
[6]	Automatic reset x 6	
[7]	Automatic reset x 7	
[8]	Automatic reset x 8	
[9]	Automatic reset x 9	
[10]	Automatic reset x 10	
[11]	Automatic reset x 15	
[12]	Automatic reset x 20	

Option	Name	Description
[13]	Infinite auto reset	Select this option for continuous resetting after tripping.
[14]	Reset at power-up	

14-21 Automatic Restart Time

Default value:	Size related	Parameter type:	Range, 0 - 3600 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter the time interval from trip to start of the automatic reset function. This parameter is active when parameter **14-20 Reset Mode** is set to **[1]–[13] Automatic reset**.

14-22 Operation Mode

Default value:	[0] Normal operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use this parameter to specify normal operation, to perform tests, or to initialize all parameters except parameter **15-03 Power Up's**, parameter **15-04 Over Temp's**, and parameter **15-05 Over Volt's**. This function is active only when the power is cycled to the drive. Select **[0] Normal operation** for normal operation of the drive with the motor in the selected application. Select **[1] Control card test** to test the analog and digital inputs and outputs and the +10 V control voltage. The test requires a test connector with internal connections. Use the following procedure for the control card test:

- Select **[1] Control card test**.
- Disconnect the mains supply and wait for the indicator light in the display to go out.
- Set switches S201 (A53) and S202 (A54) to ON/I.
- Insert the test plug.
- Connect to mains supply.
- Carry out various tests.
- The results are shown on the LCP and the drive moved into an infinite loop.
- Parameter **14-22 Operation Mode** is automatically set to normal operation. Carry out a power cycle to start up in normal operation after a control card test.

If the test is OK	LCP readout: Control card OK. Disconnect the mains supply and remove the test plug. The green indicator light on the control card lights up.
If the test fails	LCP readout: Control card I/O failure. Replace the drive or control card. The red indicator light on the control card is turned on. Test plugs (connect the following terminals to each other): 18 - 27 - 32; 19 - 29 - 33; 42 - 53 - 54.




Figure 92: Test Plugs

Select **[2] Initialisation** to reset all parameter values to default settings, except for: Parameter **15-03 Power Up's**, parameter **15-04 Over Temp's**, and parameter **15-05 Over Volt's**. The drive resets during the next power-up. Parameter **14-22 Operation Mode** also returns to the default setting **[0] Normal operation**.

Option	Name	Description
[0]*	Normal operation	
[1]	Control card test	Remember to set switches S201 (A53) and S202 (A54) as specified in the parameter description when performing a control card test. Otherwise, the test fails.
[2]	Initialisation	Select this option to perform initialization. This option does not clear the service logs.
[3]	Boot mode	
[4]	Initialize all parameters	
[5]	Clear service logs	 NOTE: Save the log information using MCT 10 Set-up Software before clearing the service logs. Select this option and perform a power cycle to clear the log.
[6]	Clear param. log	

14-24 Trip Delay at Current Limit

Default value:	60 s	Parameter type:	Range, 0 - 60 s
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the current limit trip delay in s. When the output current reaches the current limit (parameter **4-18 Current Limit**), a warning is triggered. When the current limit warning has been continuously present for the period specified in this parameter, the drive trips. To run continuously in current limit without tripping, set the parameter to 60 s. Thermal monitoring of the drive remains active.

14-25 Trip Delay at Torque Limit

Default value:	60 s	Parameter type:	Range, 0 - 60 s
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the torque limit trip delay in s. When the output torque reaches the torque limits (parameter **4-16 Torque Limit Motor Mode** and parameter **4-17 Torque Limit Generator Mode**), a warning is triggered. When the torque limit warning has been continuously present for the period specified in this parameter, the drive trips. Disable the trip delay by setting the parameter to 60 s. Thermal monitoring of the drive remains active.

14-26 Trip Delay at Inverter Fault

Default value:	Size related	Parameter type:	Range, 0 - 35 s
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

When the drive detects an overvoltage in the set time, a trip is effected after the set time. If the value is 0, protection mode is disabled.



NOTE: Disable protection mode in hoisting applications.

6.15.4 14-3* Current Limit Control



NOTE:

The following parameters are only available in FC 302:

- Parameter **14-33 Torque Change Detection**
- Parameter **14-36 Field-weakening Function**
- Parameter **14-37 Fieldweakening Speed**
- Parameter **14-38 Field Weakening Controller Gain**
- Parameter **14-39 Torque Change Threshold Limit**

The drive features an integral current limit controller, which is activated when the motor current, and thus the torque, exceeds the torque limit set in parameter **4-16 Torque Limit Motor Mode** and parameter **4-17 Torque Limit Generator Mode**. When the current limit is reached during motor operation or regenerative operation, the drive tries to reduce torque below the preset torque limits as quickly as possible without losing control of the motor. While the current control is active, the drive can only be stopped by setting a digital input to **[2] Coast inverse** or **[3] Coast and reset inv**. Any signals on terminals 18–33 are not active until the drive is no longer near the current

limit. By using a digital input set to **[2] Coast inverse** or **[3] Coast and reset inv**, the motor does not use the ramp-down time, since the drive is coasted. If a quick stop is necessary, use the mechanical brake control function along with an external electromechanical brake attached to the application.

14-30 Current Lim Ctrl, Proportional Gain

Default value:	Size related	Parameter type:	Range, 0 - 500%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Enter the proportional gain value for the current limit controller. Selection of a high value makes the controller react faster. Too high a setting leads to controller instability.

14-31 Current Lim Ctrl, Integration Time

Default value:	Size related	Parameter type:	Range, 0.002 - 2 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	False

Controls the current limit control integration time. Selection of a low value makes it react faster. Too low a value leads to controller instability.

14-32 Current Lim Ctrl, Filter Time

Default value:	Size related	Parameter type:	Range, 1 - 100 ms
Setup:	All setups	Conversion index:	-4
Data type:	Uint16	Change during operation:	True

Controls the current limit control low-pass filter. This makes it possible to react to peak values or to average values. When selecting average values, it is sometimes possible to run with higher output current and instead trip on the hardware limit for current. However, the control reacts slower as it does not react on immediate values.

14-33 Torque Change Detection

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Disabled	
[1]	Enable	Use this function in VVC+, flux, and in speed mode. The torque load is minimum 15% of nominal torque and the actual speed equals to the reference. Parameter 14-39 Torque Change Threshold Limit is used for threshold limit generation.

14-34 Stall Protection Adjustment Factor

Default value:	100%	Parameter type:	Range, 50 - 200%
Setup:	All setups	Conversion index:	-4

Data type: Uint8 **Change during operation:** True

Set this parameter to avoid overvoltage and overcurrent alarms occurring in the field-weakening area. Decrease the setting to reduce risk of overcurrent and overvoltage trips. Increase the setting if the stall protection is overprotecting and the torque is too low, for example, due to wrong motor data.



NOTE: This parameter is active when parameter **14-35 Stall Protection** is set to **[1] Enabled** and parameter **14-36 Field-weakening Function** is set to **[1] 1/x**.

14-35 Stall Protection

Default value: [1] Enabled **Parameter type:** Option
Setup: All setups **Conversion index:** –
Data type: Uint8 **Change during operation:** False



NOTE: This parameter is active in flux mode only.

Option	Name	Description
[0]	Disabled	Disables stall protection in field weakening flux mode and may cause loss of motor control.
[1]*	Enabled	Enables stall protection in field weakening flux mode.

14-36 Field-weakening Function

Default value: [0] Auto **Parameter type:** Option
Setup: All setups **Conversion index:** –
Data type: Uint8 **Change during operation:** True

Select the field-weakening function mode in flux mode.

Option Number	Option Name	Description
[0]*	Auto	In this mode, the drive calculates the optimal torque output. Measured DC-link voltage determines the phase-to-phase motor voltage. Magnetizing reference is based on the actual voltage and utilizes the information about the model of the motor.
[1]	1/x	The drive reduces torque output. The drive sets the magnetizing reference inversely proportional to the speed using a static curve that shows the relationship between DC-link voltage and the speed.

14-37 Fieldweakening Speed

Default value: Size related **Parameter type:** Range, 10 - 60000 RPM
Setup: All setups **Conversion index:** 67
Data type: Uint16 **Change during operation:** True

Enter the start speed for option [1] [1/x] in parameter **14-36 Fieldweakening Function**.

14-38 Field Weakening Controller Gain

Default value:	20%	Parameter type:	Range, 10 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the integral gain for the field weakening controller.

14-39 Torque Change Threshold Limit

Default value:	Size related	Parameter type:	Range, 10 - 100%
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Set the torque change threshold limit in % of the actual torque. When the actual torque exceeds the torque threshold value, the drive trips within 10 ms.

6.15.5 14-4* Energy Optimizing

This parameter group contains parameters for adjusting the energy optimization level in both variable torque (VT) and automatic energy optimization (AEO) mode in parameter **1-03 Torque Characteristics**.

14-40 VT Level

Default value:	66%	Parameter type:	Range, 40 - 90%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.



NOTE: This parameter is not active when parameter **1-10 Motor Construction** is set to [1] **PM non-salient SPM**.

Enter the level of motor magnetization at low speed. Selection of a low value reduces energy loss in the motor but also reduces load capability.

14-41 AEO Minimum Magnetization

Default value:	Size related	Parameter type:	Range, 30 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is not active when parameter **1-10 Motor Construction** is set to [1] **PM non-salient SPM**.

Enter the minimum allowable magnetization for AEO. Selection of a low value reduces energy loss in the motor but can also reduce resistance to sudden load changes.

14-42 Minimum AEO Frequency

Default value:	Size related	Parameter type:	Range, 0 - 255 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is not active when parameter **1-10 Motor Construction** is set to **[1] PM non-salient SPM**.

Enter the minimum frequency at which the automatic energy optimization (AEO) is to be active.

14-43 Motor Cosphi

Default value:	Size related	Parameter type:	Range, 0.40 - 0.95
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The Cos(phi) setpoint is automatically set for optimum AEO performance. This parameter should normally not be altered. However, in some situations it may be necessary to enter a new value to fine-tune.

14-44 d-axis Reference Gain

Default value:	100%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Adjustment parameter for the d-axis current. 100% indicates maximum torque per ampere value based on the motor parameters. Increasing the maximum torque can improve the power factor of the machine, which may increase the current consumption. The adjustment parameter allows to:

- Adjust minimum current consumption, allowing for tolerances in the motor parameters.
- Obtain the optimal balance between current consumption and power factor of the machine at a given point of operation.

14-46 PROFIenergy Times

Default value:	Size related	Parameter type:	Array [3]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Parameter with an array of 3. *[0] Time to pause, [1] Time min stay, [2] Time regular operate.*

14-47 PROFIenergy State

Default value:	[255] Ready to operate	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[1]	LCP off	
[4]	Internal fan off	
[7]	Gatedrive off	
[10]	Mains off	
[13]	External fan off	
[255]*	Ready to operate	

14-48 PROFIEnergy Desired State

Default value:	[255] Ready to operate	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[1]	LCP off	
[4]	Internal fan off	
[7]	Gatedrive off	
[10]	Mains off	
[13]	External fan off	
[255]*	Ready to operate	

14-49 PROFIEnergy Info

Default value:	0	Parameter type:	Array [115]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Read-out information about PROFIEnergy.

6.15.6 14-5* Environment

AMA and motor filters

The following table details the recommended AMA options when motor filters are connected between the drive and the motor. AMA is independent of the selection made in parameter **1-00 Configuration Mode** and parameter **1-01 Motor Control Principle**.

Table 49: Motor Filter Types

Motor construction	Filter type	
	MCC 102 dU/dt filters	MCC 101 Sine-wave filters and MCC 201 All-mode filters
	Valid options in parameter 1-29 Automatic Motor Adaptation (AMA)	
Induction and SPM	[1] Complete AMA	[2] Reduced AMA
	[2] Reduced AMA	[4] Enabled reduced AMA II
	[4] Enable reduced AMA II	–
IPM	[1] Complete AMA	[2] Reduced AMA
	[2] Reduced AMA	AMA II not available
	AMA II not available	–


NOTE:

The following parameter is only available in FC 302:

- Parameter 14-59 Actual Number of Inverter Units



NOTE: Perform a power cycle after changing any of the parameters in this parameter group.

Use these parameters when operating the drive under special environmental conditions.

14-50 RFI Filter

Default value:	[1] On	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Turn the RFI filter on or off. The RFI filter ensures that the drive complies with EMC standards. Select [0] Off only when the drive is connected to an isolated mains source (IT mains).

Option	Name	Description
[0]	Off	
[1]*	On	

14-51 DC-link Compensation

Default value:	–	Parameter type:	Option
Setup:	All setups	Data type:	Uint8
Change during operation:	True		

The rectified AC-DC voltage in the DC link of the drive is associated with voltage ripples. These ripples can increase in magnitude with increased load. These ripples are undesirable because they can generate current and torque ripples. A compensation method is used to reduce these voltage ripples in the DC link. In general, DC-link compensation is recommended for most applications, but pay attention when operating in field weakening as it can generate speed oscillations at the motor shaft. In field weakening, turn off DC-link compensation.

Option	Name	Description
[0]	Off	Disables DC-link compensation.
[1]	On	Enables DC-link compensation.
[2]	Advanced	Improved compensation of DC-link ripple caused by mains frequency and phase imbalance.


NOTE: Parameter **0-03 Regional Setting** must be set correctly according to the actual mains grid.

14-52 Fan Control

Default value:	[0] Auto	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the minimum speed of the main fan.

Option	Name	Description
[0]*	Auto	Select [0] Auto to run fan only when internal temperature in the drive is in the range from 35 °C (95 °F) to approximately 55 °C (131 °F). The fan runs at low speed below 35 °C (95 °F), and at full speed at approximately 55 °C (131 °F).
[1]	On 50%	The fan always runs at 50% speed or above. The fan runs at 50% speed at 35 °C (95 °F), and at full speed at approximately 55 °C (131 °F).
[2]	On 75%	The fan always runs at 75% speed or above. The fan runs at 75% speed at 35 °C (95 °F), and at full speed at approximately 55 °C (131 °F).
[3]	On 100%	The fan always runs at 100% speed.
[4]	Auto (Low temp env.)	This option is the same as [0] Auto , but with special considerations around and below 0 °C (32 °F). In option [0] Auto there is a risk that the fan starts running around 0 °C as the drive detects a sensor fault and thus protects the drive while reporting <i>warning 66, Heat sink Temperature Low</i> . Option [4] Auto (Low temp env.) can be used in very cold environments and prevents the negative effects of this further cooling and avoids <i>warning 66, Heat sink Temperature Low</i> .

14-53 Fan Monitor

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–

Data type:	Uint8	Change during operation:	True

Select the drive action if a fan fault is detected.

Option	Name	Description
[0]	Disabled	
[1]	Warning	
[2]	Trip	

14-55 Output Filter

Default value:	[0] No filter	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

CAUTION

OVERHEATING OF FILTER OR AC DRIVE

Incorrect setting of parameter **14-55 Output Filter** can lead to overheating and cause equipment damage and personal injury.

- Always set parameter **14-55 Output Filter** to **[2] Sine-wave fixed** when using a sine-wave filter.

 NOTE: This parameter cannot be adjusted while the motor is running.

 NOTE: Reset the drive after selecting **[2] Sine-wave filter fixed**.

Select the type of output filter connected.

Option	Name	Description
[0]*	No filter	Set the parameter when VLT® MCC 102 dU/dt filters or VLT® MCC 105 high-frequency common-mode filters are connected to the drive.

[1]	Sine-wave filter

NOTICE

COMPATIBILITY SETTING

Set the option to support backward compatibility with the VLT® 5000–8000 Series drives.

- Do not use the setting when VLT® MCC 101 Sine-wave Filters and VLT® MCC 201 All-mode Filters are connected.

Use the setting for backward compatibility purposes. Set parameter **14-56 Capacitance Output Filter** and parameter **14-57 Inductance Output Filter**. Setting the parameter does not limit the range of the switching frequency.

Option	Name	Description
[2]	Sine-Wave Filter Fixed	NOTICE SINE-WAVE FILTER FIXED SETTING Ensures that the filter is operated within the safe range of switching frequencies. Use the setting only for VLT® MCC 101 Sine-wave Filters. When setting the option for VLT® MCC 101 Sine-wave filters, the parameter sets a minimum allowed limit to the switching frequency and ensures the filter is operated within the safe range of switching frequencies. The option supports all control principle operations of the filter. Set parameter 14-56 Capacitance Output Filter and parameter 14-57 Inductance Output Filter. Setting the option allows the modulation pattern to be set to stator flux asynchronous vector modulation (SFAVM), which reduces the acoustic switching noise from the filter.
[5]	All-mode Filter	NOTICE ALL-MODE FILTERING Enables all-mode filter operating condition and ensures that the filter is operated within the safe range of switching frequencies. Use this setting only for VLT® MCC 201 All-Mode Filters. When setting the option for VLT® MCC 201 All-mode Filter, the parameter enables all-mode filter operating conditions, which include settings for a minimum allowed limit to the switching frequency and ensure the filter is operated within the safe range of switching frequencies. The option supports all control principle operations of the filter. Set parameter 14-56 Capacitance Output Filter and parameter 14-57 Inductance Output Filter. Setting the option allows the modulation pattern to be set to stator flux asynchronous vector modulation (SFAVM), which reduces the acoustic switching noise from the filter.

14-56 Capacitance Output Filter

Default value:	Size related	Parameter type:	Range, 0.1 - 6500 uF
Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	False

Set the C_y (capacitance) value of the output filter in uF, when using VLT® MCC 101 Sine-wave filter and VLT® MCC 201 All-mode filter. See the filter product label for the capacitance value. The value is the equivalent star-connected capacitance of the filter. When the filters are installed in parallel, enter the combined capacitance value of the paralleled filter. The value is the equivalent star-connected capacitance (C_y) of the filter multiplied by the number of installed paralleled filters.

NOTICE

SETTING FOR VLT® MCC 101 SINE-WAVE FILTER AND VLT® MCC 201 ALL-MODE FILTER

Enables accurate flux compensation when option **[2] Flux sensorless** or option **[3] Flux w/motor feedback** is selected in parameter **1-01 Motor Control Principle**.

- Enter the correct capacitance value of the connected filter.

14-57 Inductance Output Filter

Default value:	Size related	Parameter type:	Range, 0.001 - 65 mH
Setup:	All setups	Conversion index:	-6
Data type:	Uint16	Change during operation:	False

Set the inductance of the output filter in mH, when using VLT® MCC 101 Sine-wave Filter and VLT® MCC 201 All-mode Filter. See the product label of the filter for the value of inductance. When filters are installed in parallel, enter the combined inductance value of the installed paralleled filters. The inductance value in the parameter is the inductance value of the filter divided by the number of paralleled filters.

NOTICE

SETTING FOR VLT® MCC 201 ALL-MODE AND VLT® MCC 101 SINE-WAVE FILTERS

Enables accurate flux control compensation when option **[2] Flux Sensorless** or option **[3] Flux w/Motor Feedback** is selected in parameter **1-01 Motor Control Principle**.

- Enter the correct inductance value of the connected filter.

14-59 Actual Number of Inverter Units

Default value:	Size related	Parameter type:	Range, 1 - 1
Setup:	1 setup	Conversion index:	0
Data type:	Uint8	Change during operation:	False

Set the actual number of power units.

6.15.7 14-6* Auto Derate

This parameter group contains parameters for derating the drive if the ambient temperature is high.

No trip at inverter overload

In some systems, the drive has not been sized properly to yield the current needed in all points of the operational flow-head characteristic. At these points, the motor needs a current higher than the rated current of the drive. The drive can yield 110% of the rated current continuously for 60 s. If still overloaded, the drive normally trips (causing the motor to stop by coasting) and issues an alarm.




Figure 93: Output Current in Overload Condition

If the motor is unable to run continuously with the demanded capacity, run it at reduced speed for a while.

Select parameter **14-61 Function at Inverter Overload** to automatically reduce motor speed until the output current is below 100% of the rated current (set in parameter **14-62 Inv. Overload Derate Current**). Parameter **14-61 Function at Inverter Overload** is an alternative to letting the drive trip.

The drive estimates the load on the power section with an inverter load counter, which causes a warning at 98% and a reset of the warning at 90%. At the value 100%, the drive trips and issues an alarm. Status for the counter can be read in parameter **16-35 Inverter Thermal**.

If parameter **14-61 Function at Inverter Overload** is set to **[3] Derate**, the motor speed is reduced when the counter exceeds 98%, and stays reduced until the counter has dropped below 90.7%. If parameter **14-62 Inv. Overload Derate Current** is set to for example 95%, a steady overload causes the pump speed to fluctuate between values corresponding to 110% and 95% of rated output current for the drive.

14-60 Function at Over Temperature

Default value:	[0] Trip	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

If either heat sink or control card temperature exceeds a factory-programmed temperature limit, a warning is activated. If the temperature increases further, select whether the drive should trip (trip lock) or derate the output current.

Option	Name	Description
[0]*	Trip	The drive trips (trip lock) and generates an alarm. Cycle power to reset the alarm. The motor restarts when the heat sink temperature has dropped below the alarm limit.
[1]	Derate	If the critical temperature is exceeded, the output current is reduced until the allowable temperature has been reached.

14-61 Function at Inverter Overload

Default value:	[0] Trip	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use if there is a steady overload beyond the thermal limits (110% for 60 s).

Option	Name	Description
[0]*	Trip	Select [0] Trip to make the drive trip and issue an alarm.
[1]	Derate	Reduces the motor speed to decrease the load on the power section and allowing it to cool down.

14-62 Inv. Overload Derate Current

Default value:	95%	Parameter type:	Range, 50 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter the current level (in % of rated output current for the drive) when running with reduced motor speed after load on the drive has exceeded the allowable limit (110% for 60 s).

14-68 Power Derating Ratio

Default value:	Size related	Parameter type:	Range, 30 - 250%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Adjust the fast active power derating gain during low voltage ride through. High derating gain values cannot increase the torque beyond the limits set in either parameter **4-16 Torque Limit Motor Mode** or parameter **4-17 Torque Limit Generator Mode**.

6.15.8 14-7* Compatibility

This parameter group contains parameters for compatibility of VLT 3000 and VLT 5000 with FC 300.

14-72 Legacy Alarm Word

Default value:	0	Parameter type:	Range, 0 - 4294967295
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Readout of the alarm word corresponding to VLT 5000.

14-73 Legacy Warning Word

Default value:	0	Parameter type:	Range, 0 - 4294967295
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Readout of the warning word corresponding to VLT 5000.

14-74 Leg. Ext. Status Word

Default value:	0	Parameter type:	Range, 0 - 4294967295
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Readout of the external status word corresponding to VLT 5000.

6.15.9 14-8* Options

14-80 Option Supplied by External 24VDC

Default value:	[1] Yes	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: To activate the parameter change, perform a power cycle.

Option	Name	Description
[0]	No	Select this option to use the 24 V DC supply of the drive.
[1]*	Yes	Select this option if a 24 V DC external supply is used to power the option. Inputs/outputs are galvanically isolated from the drive when operated from an external supply.

14-88 Option Data Storage

Default value:	0	Parameter type:	Array [24]
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter stores information about options over a power cycle.

14-89 Option Detection

Default value:	[0] Protect option config.	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Selects the behavior of the drive when a change in the option configuration is detected.

Option	Name	Description
[0]*	Protect option config.	Freezes the current settings and prevents unwanted changes when missing or defective options are detected.
[1]	Enable option change	Changes drive settings and is used when modifying the system configuration. This parameter setting returns to [0] Protect option config. after an option change.

6.15.10 14-9* Fault Settings

14-90 Fault Level

Default value:	–	Parameter type:	Array [29]
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This is an array parameter with 26 elements. Each of the bits can be configured to any of the following options. Use this parameter to customize fault levels.

Option	Name	Description
[0]	Off	Use [0] Off with caution as it ignores all warnings and alarms for the selected source.
[1]	Warning	
[2]	Trip	Changing a fault level from default option [3] Trip Lock to [2] Trip leads to the automatic reset of the alarm. For alarms involving overcurrent, the drive has a hardware protection that issues a 3-minute recovery after 2 consecutive overcurrent incidents. This hardware protection cannot be overruled.
[3]	Trip lock	
[4]	Trip w. delayed reset	This option adds a delay between automatic resets, otherwise it is the same as option [2] Trip . The delay prevents a situation where reset is attempted repeatedly for an overcurrent situation. Hardware protection of the drive forces the 3-minute recovery time after 2 consecutive overcurrents (within a short time window).

Table 50: Possible Actions when Selected Alarms Appear

Failure	Parameter	Alarm	Off	Warning	Trip	Trip lock	Trip with delayed reset
10 V low	1490.0	1	X ⁽¹⁾	D ⁽²⁾	–	–	–
24 V low	1490.1	47	X	–	–	D	–
1.8 V low	1490.2	48	X	–	–	D	–
Voltage limit	1490.3	64	X	D	–	–	–
Ground fault during ramping	1490.4	14	–	–	D	X	–
Ground fault 2 during continuous operation	1490.5	45	–	–	D	X	–
Torque limit	1490.6	12	X	D	–	–	–
Overcurrent	1490.7	13	–	–	–	D	X
Short circuit	1490.8	16	–	–	X	D	–

Table 50: Possible Actions when Selected Alarms Appear - (continued)

Failure	Parameter	Alarm	Off	Warning	Trip	Trip lock	Trip with delayed reset
Heat sink temp.	1490.9	29	–	–	X	D	–
Heat sink sensor	1490.10	39	–	–	X	D	–
Control card temp.	1490.11	65	–	–	X	D	–
Power card temp.	1490.12	69	–	(3)	X	D	–
Heat sink temperature ⁽⁴⁾	1490.13	244	–	–	X	D	–
Heat sink sensor ⁽⁴⁾	1490.14	245	–	–	X	D	–
Power card temperature ⁽⁴⁾	1490.15	247	–	–	X	D	–
Motor phase U missing	1490.16	30	–	–	X	D	–
Motor phase V missing	1490.16	31	–	–	X	D	–
Motor phase W missing	1490.16	32	–	–	X	D	–
Derag limit fault	1490.17	100	–	–	–	D	–
Inverter over-load	1490.18	9	–	–	–	D	–
Current limit ⁽⁵⁾	1490.19	59	X	D	–	–	–
Locked rotor	1490.20	99	–	–	D	X	–
AIC earth fault	1490.21	407	X	X	X	D	X
DC-link voltage out of range	1490.22	404	X	X	X	D	X
Mains contactor fault	1490.23	300	X	X	X	D	X
Not used	1490.24	x	X	X	X	D	X
Fan contactor	1490.25	431	–	–	X	D	–
Inrush fault	1490.26	33	X	X	X	D	X
Fieldbus fault	1490.27	34	X	D	–	–	–
Protection mode	1490.28	217	X				

Table 50: Possible Actions when Selected Alarms Appear - (continued)

Failure	Parameter	Alarm	Off	Warning	Trip	Trip lock	Trip with delayed reset
Power limit motor	1490.29	157		X			
Power limit generator	1490.30	158		X			

1) X = Possible selection

2) D = Default value

3) In small and medium power drives, alarm 69, Power card temperature is only a warning.

4) Only high-power drives.

5) Warning 59 is configured in 1490.19. The current limit warning can be shown by choice. The alarm cannot be configured.

VLT® Motion Control Tool MCT 10 has the element numbers listed in the column ID. Use this table with MCT 10 to get information about specific fault levels.

6.16 Parameter Group 15-** Drive Information

6.16.1 15-0* Operating Data

15-00 Operating Hours

Default value:	0 h	Parameter type:	Readout
Setup:	All setups	Conversion index:	74
Data type:	Uint32	Change during operation:	False

View for how many hours the drive has run. The value is saved when the drive is turned off.

15-01 Running Hours

Default value:	0 h	Parameter type:	Readout
Setup:	All setups	Conversion index:	74
Data type:	Uint32	Change during operation:	False

View how many hours the motor has run. Reset the counter in parameter **15-07 Reset Running Hours Counter**. The value is saved when the drive is turned off.

15-02 kWh Counter

Default value:	0 kWh	Parameter type:	Readout
Setup:	All setups	Conversion index:	75
Data type:	Uint32	Change during operation:	False

Register the power consumption of the motor as an average value over 1 hour. Reset the counter in parameter **15-06 Reset kWh Counter**.

15-03 Power Up's

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0

Data type:	Uint32	Change during operation:	False

View the number of times the drive has been powered up.

15-04 Over Temp's

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View the number of drive temperature faults.

15-05 Over Volt's

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View the number of drive overvoltage events.

15-06 Reset kWh Counter

Default value:	[0] Do not reset	Parameter type:	Option
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Do not reset	No reset of the kWh counter is required.
[1]	Reset counter	Press [OK] to reset the kWh counter to 0 (see parameter 15-02 kWh Counter). The reset date is stored in parameter 15-28 kWh Counter Reset Time .

15-07 Reset Running Hours Counter

Default value:	[0] Do not reset	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Do not reset	
[1]	Reset counter	To reset the running hours counter to 0, select [1] Reset and press [OK] (see parameter 15-01 Running Hours). This parameter cannot be selected via the serial port, RS-485. Select [0] Do not reset if no reset of the running-hours counter is required.

6.16.2 15-1* Data Log Settings

The data log enables continuous logging of up to 4 data sources (parameter **15-10 Logging Sources**) at individual rates (parameter **15-11 Logging Interval**). A trigger event (parameter **15-12 Trigger Event**) and window (parameter **15-14 Samples Before Trigger**) are used to start and stop the logging conditionally.

15-10 Logging Source

Default value:	[0] None	Parameter type:	Option, Array [4]
Setup:	2 setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Select the variables to be logged.

Option	Name	Description
[0]*	None	
[15]	Readout: Actual setup	
[1397]	Alert alarm word	
[1398]	Alert warning word	
[1399]	Alert status word	
[1472]	Legacy alarm word	
[1473]	Legacy warning word	
[1474]	Leg. ext. status word	
[1583]	Motor Ud	View the motor voltage on the d-axis. The value is a calculated value used for controlling the motor.
[1584]	Motor Uq	View the motor voltage on the q-axis. The value is a calculated value used for controlling the motor.
[1585]	Motor Id	View the motor d-axis current measured as a mean value, I_{RMS} .
[1586]	Motor Iq	View the motor q-axis current measured as a mean value, I_{RMS} .
[1600]	Control word	
[1601]	Reference [Unit]	
[1602]	Reference %	
[1603]	Status word	
[1606]	Actual position	
[1607]	Target position	 NOTE: This option is only available with software version 48.0X or newer.
[1608]	Position error	 NOTE: This option is only available with software version 48.0X or newer.
[1610]	Power [kW]	
[1611]	Power [hp]	
[1612]	Motor voltage	

Option	Name	Description
[1613]	Frequency	
[1614]	Motor current	
[1616]	Torque [Nm]	
[1617]	Speed [RPM]	
[1618]	Motor thermal	
[1620]	Motor angle	
[1621]	Torque [%] high res.	
[1622]	Torque [%]	
[1624]	Calibrated stator resistance	
[1625]	Torque [Nm] high	
[1628]	Angle error	
[1630]	DC link voltage	
[1632]	Brake energy /s	
[1633]	Brake energy average	
[1634]	Heatsink temp.	
[1635]	Inverter thermal	
[1644]	Speed error [RPM]	
[1645]	Motor phase U current	
[1646]	Motor phase V current	
[1647]	Motor phase W current	
[1648]	Speed ref. after ramp [RPM]	
[1650]	External reference	
[1651]	Pulse reference	
[1652]	Feedback[Unit]	
[1657]	Feedback [RPM]	
[1660]	Digital input	
[1662]	Analog input 53	
[1664]	Analog input 54	
[1665]	Analog output 42 [mA]	
[1666]	Digital output [bin]	
[1675]	Analog in X30/11	
[1676]	Analog in X30/12	
[1677]	Analog out X30/8 [mA]	
[1687]	Bus readout alarm/warning	
[1689]	Configurable alarm/warning word	
[1690]	Alarm word	
[1692]	Warning word	

Option	Name	Description
[1694]	Ext. status word	
[1695]	Ext. status word 2	
[1697]	Alarm word 3	
[1698]	Warning word 3	
[1699]	Ext. status word 3	
[1766]	SSI status	
[1767]	Raw inc. quad counter	
[1768]	Raw abs. pos. low	
[1769]	Raw abs. pos. high	
[1820]	Commanded position	NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1821]	Master position	NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1823]	Virtual master pos.	NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[1824]	Marker pos. offset	NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1825]	Latched actual pos.	NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[1827]	Safe opt. est. speed	
[1828]	Safe opt. meas. speed	
[1829]	Safe opt. speed error	
[1840]	Analog input X49/1	
[1841]	Analog input X49/3	
[1842]	Analog input X49/5	
[1843]	Analog out X49/7	
[1844]	Analog out X49/9	
[1845]	Analog out X49/11	
[1846]	X49 digital output [bin]	
[1860]	Digital input 2	
[1866]	Actual switching frequency	
[1867]	Alarm word 4	
[1868]	Warning word 4	

Option	Name	Description
[1889]	Mode of operation display	
[1899]	Speed PID torque FF. [Nm]	
[3110]	Bypass status word	
[3466]	SPI error counter	
[3470]	MCO alarm word 1	
[3471]	MCO alarm word 2	
[4280]	Safe option status	
[4281]	Safe option status 2	

15-11 Logging Interval

Default value:	Size related	Parameter type:	Array [4]
Setup:	2 setups	Conversion index:	-3
Data type:	Time diff wo DateID[4]	Change during operation:	True

Enter the interval in ms between each sampling of the variables to be logged.

15-12 Trigger Event

Default value:	[0] False	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the trigger event. When the trigger event occurs, a window is applied to freeze the log. The log then retains a specified percentage of samples before the occurrence of the trigger event (parameter **15-14 Samples Before Trigger**).

Option	Name	Description
[0]*	False	
[1]	True	
[2]	Running	
[3]	In range	
[4]	On reference	
[5]	Torque limit	
[6]	Current limit	
[7]	Out of current range	
[8]	Below I low	
[9]	Above I high	
[10]	Out of speed range	
[11]	Below speed low	
[12]	Above speed high	
[13]	Out of feedb. range	

Option	Name	Description
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	
[17]	Mains out of range	
[18]	Reversing	
[19]	Warning	
[20]	Alarm (trip)	
[21]	Alarm (trip lock)	
[22]	Comparator 0	
[23]	Comparator 1	
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	
 NOTE: This option is only available in FC 302.		
[37]	Digital input DI32	
[38]	Digital input DI33	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	

15-13 Logging Mode

Default value:	[0] Log always	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Log always	Select [0] Log always for continuous logging.
[1]	Log once on trigger	Select [1] Log once on trigger to start and stop logging conditionally using parameter 15-12 Trigger Event and parameter 15-14 Samples Before Trigger .

15-14 Samples Before Trigger

Default value:	50	Parameter type:	Range, 0 - 100
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Before a trigger event, enter the percentage of all samples which should be retained in the log. See also parameter **15-12 Trigger Event** and parameter **15-13 Logging Mode**.

15-15 Info Message: "Service Log Full"

Default value:	[0] Disabled	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

See Service log. By enabling this parameter, a text message is shown in the drive when the service log runs full: *Clear logs, Service log full: 28 [M26]*. The message recommends to clear the log.

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	Enable message.

15-17 Service Log Trigger Alarm

Default value:	0	Parameter type:	Range, 0=Off - 9999
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Enter alarm number that triggers the Service Log write to flash. By default Service Log will log motor specific data during motor related alarms. Using Displayline parameters **0-20 Display Line 1.1 Small**, **0-21 Display Line 1.2 Small**, and **0-22 Display Line 1.3 small** with current parameter, the Service Log can be configured for custom data logging events.

15-18 Service Log Trigger SLC

Default value:	[0] False	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The service log can be used for troubleshooting. The SLC operands trigger the service log when an event occurs. The maximum numbers of service logs is 24. To clear the service logs, use parameter **14-22 Operation Mode** followed by a power cycle.

Option	Name	Description
[0]*	False	
[18]	Reversing	
[19]	Warning	
[22]	Comparator 0	
[23]	Comparator 1	

Option	Name	Description
[24]	Comparator 2	
[25]	Comparator 3	
[26]	Logic rule 0	
[27]	Logic rule 1	
[28]	Logic rule 2	
[29]	Logic rule 3	
[30]	SL time-out 0	
[31]	SL time-out 1	
[32]	SL time-out 2	
[33]	Digital input DI18	
[34]	Digital input DI19	
[35]	Digital input DI27	
[36]	Digital input DI29	
 NOTE: This option is only available in FC 302.		
[37]	Digital input DI32	
[38]	Digital input DI33	
[50]	Comparator 4	
[51]	Comparator 5	
[60]	Logic rule 4	
[61]	Logic rule 5	
[70]	SL time-out 3	
[71]	SL time-out 4	
[72]	SL time-out 5	
[73]	SL time-out 6	
[74]	SL time-out 7	
[90]	ECB drive mode	
[91]	ECB bypass mode	
[94]	RS flipflop 0	
[95]	RS flipflop 1	
[96]	RS flipflop 2	
[97]	RS flipflop 3	
[98]	RS flipflop 4	
[99]	RS flipflop 5	
[100]	RS flipflop 6	
[101]	RS flipflop 7	
[228]	Comparator 6	
[229]	Comparator 7	

Option	Name	Description
[230]	Comparator 8	
[231]	Comparator 9	
[232]	Logic rule 6	
[233]	Logic rule 7	
[234]	Logic rule 8	
[235]	Logic rule 9	
[236]	SL time-out 8	
[237]	SL time-out 9	
[238]	RS flipflop 8	
[239]	RS flipflop 9	
[240]	SL digital output A	
[241]	SL digital output B	
[242]	SL digital output C	
[243]	SL digital output D	
[244]	SL digital output E	
[245]	SL digital output F	

6.16.3 Service Log

The service log is a data logger extension (alarm data saved in drive memory and exportable to VLT® Motion Control Tool MCT 10). If certain alarms occur, the system saves a detailed log in 5 s increments.

Service technicians can analyze this information to troubleshoot and optimize the drive.

The drive saves up to 24 service log records in the flash memory. If the RTC (real-time clock) has been set in the drive, all errors and log files are date- and time-stamped.

The relevant service log file can then be analyzed as a scope in MCT 10. Danfoss specifies the channels. All scope functions such as Auto-scale and Diagnostics can be used. The HEX ad binary value can be shown, which also helps with the analysis.

Table 51: Alarms Triggering a Service Log Record

Alarm	Alarm log data	Parameter
1	Time of trip (1 of the values): - Priority RTC (if available). - Priority operating time (if RTC is not available).	0-89 Date and Time Readout or parameter 15-32 Fault Log: Time
2	Alarm code	15-30 Fault Log: Error Code
3	Frequency	16-13 Frequency
4	Speed (RPM)	16-17 Speed [RPM]
5	Reference %	16-02 Reference %
7	DC-link voltage	16-30 DC Link Voltage
9	Motor phase U current	16-45 Motor Phase U Current
10	Motor phase V current	16-46 Motor Phase V Current

Table 51: Alarms Triggering a Service Log Record - (continued)

Alarm	Alarm log data	Parameter
11	Motor phase W current	16-47 Motor Phase W Current
12	Motor phase voltage	16-12 Motor Current
15	Control word	16-00 Control Word
16	Status word	16-03 Status Word

Application-dependent trips/alarms such as Safe Torque Off (STO), do not trigger a service log record.

Sampling rate

There are 2 periods with different sampling rates:

- Slow samples: 20 samples at a rate of 250 ms resulting in 5 s of history before the trip.
- Fast samples: 50 samples at a rate of 5 ms resulting in 250 ms of detailed history before the trip.



NOTE: To enable the real-time clock (RTC) stamp, use the real-time clock module. If real-time clock is not available, the operating time in parameter **15-32 Fault Log: Time** is recorded.

Table 52: Logged Channels

Polling	Color	Name
CH 1	Light gray	Frequency
CH 2	Dark gray	Speed [RPM]
CH 3	Red	Reference [%]
CH 4	Orange	DC-link voltage
CH 5	Yellow	Motor current
CH 6	Khaki	Motor voltage
CH 7	Light green	Control word
CH 8	Light blue	Status word
CH 9	Dark blue	[20] Operating hours
CH 10	Purple	[21] Running hours
CH 11	Magenta	[22] kWh counter

Channels 1–8 are fixed channels with unfiltered signals and cannot be changed. Channels 9–11 are filtered and refer to parameter **0-20** to **0-22**, which are reflected in the 3 upper lines in the LCP.

6.16.4 Clearing the Service Log

The flash memory stores up to 24 records. To save new logs, clear the service log memory.

Save the service log records using the VLT® Motion Control Tool MCT 10 before clearing the service log.

The service log is stored in EEPROM in the control card and will be erased by initialization, that is when changing the power card. Before changing the power card:

1. Click the Service Log icon to read the service log from the drive.
2. Copy parameters to a project in MCT 10.

3. Save the parameters including the service log in the project.
 - a. When loading the parameters back into the drive, the service log is not included.
4. Clear the service log after a commissioning to remove any alarms that occurred during testing.

Procedure

1. Select option **[5] Clear Service Log** in parameter **14-22 Operation Mode**.
2. Power cycle the drive. Clearing the service log extends the power-up time by approximately 1 s.

6.16.5 Service Log Indication

Parameter **16-42 Service Log Counter** shows the number of service logs stored in the memory.

The drive indicates a full service log memory in 1 of the following ways:

- The LCP shows the message: *Clear logs Service log full: 28 [M26]*.
- Bit 25 is set high in parameter **16-96 Maintenance Word** (0x2000000).

Performing the drive initialization does not clear the service log memory.

6.16.6 Alarms that Trigger a Service Log Record

Table 53: Alarms Triggering a Service Log Record

#	Alarm title
4	Mains phase loss
5	DC voltage high
6	DC voltage low
7	DC overvoltage
8	DC undervoltage
9	Inverter overId.
10	Motor ETR over
12	Torque limit
13	Over current
14	Earth (ground) fault
16	Short circuit
18	Start failed
25	Brake resistor
26	Brake overload
27	Brake IGBT
28	Brake check
30	U phase loss
31	V phase loss
32	W phase loss
36	Mains failure
37	Phase imbalance
44	Earth (ground) fault AL44

Table 53: Alarms Triggering a Service Log Record - (continued)

#	Alarm title
45	Earth (ground) fault 2
59	Current



NOTE: If an alarm has 2 states (warning/alarm), it only triggers a service log record when going into the alarm state.

6.16.7 15-2* Historic Log

View up to 50 logged data items via the array parameters in this parameter group. Data is logged every time an event occurs (not to be confused with SLC events). Events in this context are defined as a change in 1 of the following areas:

- Digital inputs
- Digital outputs
- Warning word
- Alarm word
- Status word
- Control word
- Extended status word

Events are logged with value and time stamps in ms. The time interval between 2 events depends on how often events occur (maximum once every scan time). Data logging is continuous, but if an alarm occurs, the log is saved and the values can be viewed on the display. This feature is useful, for example, when carrying out a service following a trip. View the historic log contained in this parameter via the serial communication port or via the display.

15-20 Historic Log: Event

Default value:	[0] No event	Parameter type:	Readout, Array [50]
Setup:	All setups	Conversion index:	0
Data type:	UInt8	Change during operation:	False

View the event type of the logged events.

Option	Name	Description
[0]*	No event	
[1]	Digital input	
[2]	Digital output	
[3]	Warning word	
[4]	Alarm word	
[5]	Status word	
[6]	Control word	
[7]	Extended status word	
[8]	Warning word 2	
[9]	Alarm word 2	

Option	Name	Description
[10]	Extended status word 2	
[11]	Warning word 3	
[12]	Alarm word 3	
[14]	Alarm word 4	
[15]	Warning word 4	
[17]	Safe option status	
[18]	Safe option status 2	

15-21 Historic Log: Value

Default value:	0	Parameter type:	Readout, Array [50]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

View the value of the logged event. Interpret the event values as below:

Digital input	Decimal value. See parameter 16-60 Digital Input for a description after converting to binary value.
Digital output (not monitored in this SW release)	Decimal value. See parameter 16-66 Digital Output [bin] for a description after converting to binary value.
Warning word	Decimal value. See parameter 16-92 Warning Word for a description.
Alarm word	Decimal value. See parameter 16-90 Alarm Word for a description.
Status word	Decimal value. See parameter 16-03 Status Word for a description after converting to binary value.
Control word	Decimal value. See parameter 16-00 Control Word for a description.
Extended status word	Decimal value. See parameter 16-94 Ext. Status Word for a description.

15-22 Historic log: Time

Default value:	0 ms	Parameter type:	Readout, Array [50]
Setup:	All setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	False

View the time at which the logged event occurred. Time is measured in ms since drive start. This is an array parameter containing event times 0-49.

15-28 kWh Counter Reset Time

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

View the date and time for the last kWh counter reset.

15-29 Running Hour Reset Time

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

View the date and time for the last running hour counter reset.

6.16.8 15-3* Alarm Log

Parameters in this group are array parameters where up to 10 fault logs can be viewed. 0 is the most recent logged data and 9 is the oldest. Fault codes, values, and time stamps can be viewed for all logged data.

15-30 Fault Log: Error Code

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View the fault code and look up its meaning in *chapter Troubleshooting*.

15-31 Fault Log: Value

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View an extra description of the error. This parameter is mostly used with *alarm 38, internal fault*.

15-32 Fault Log: Time

Default value:	0 s	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

View the time when the logged event occurred. Time is measured in s from start-up of the drive.

15-33 Fault Log: Date and Time

Default value:	Size related	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

Array parameter; Date & Time 0–9: This parameter shows when the logged event occurred.

15-38 Alarm Log: Speed

Default value:	0 RPM	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	67

Data type:	Int32	Change during operation:	False

View the actual motor speed value when the logged event occurred.

6.16.9 15-4* Drive Identification



NOTE:

The following parameter is only available in FC 302:

- Parameter **15-58 Smart Setup Filename**

This parameter group contains parameters with read-only information about the hardware and software configuration of the drive.

15-40 FC Type

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[6]	Change during operation:	False

View the drive type. The readout is identical to the drive power field of the type code definition, characters 1–6.

15-41 Power Section

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the power section. The readout is identical to the drive power field of the type code definition, characters 7–10.

15-42 Voltage

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the voltage. The readout is identical to the drive power field of the type code definition, characters 11–12.

15-43 Software Version

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[5]	Change during operation:	False

View the combined SW version (or package version) consisting of power SW and control SW.

15-44 Ordered Typecode String

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[40]	Change during operation:	False

View the type code string used for reordering the drive in its original configuration.

15-45 Actual Typecode String

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[40]	Change during operation:	False

View the actual type code string.

15-46 Frequency Converter Ordering No

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[8]	Change during operation:	False

View the 8-digit code number used for reordering the drive in its original configuration. To restore the order number after the power card exchange, see parameter **14-29 Service Code**.

15-47 Power Card Ordering No

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[8]	Change during operation:	False

View the power card code number.

15-48 LCP ID No

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the LCP ID number.

15-49 SW ID Control Card

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the control card software version number.

15-50 SW ID Power Card

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the power card software version number.

15-51 Frequency Converter Serial Number

Default value:	0	Parameter type:	Range, 0 - 10
Setup:	All setups	Conversion index:	0
Data type:	VisStr[10]	Change during operation:	False

View the drive serial number.

15-53 Power Card Serial Number

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[19]	Change during operation:	False

View the power card serial number.

15-54 Config File Name

Default value:	Size related	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[16]	Change during operation:	False

Shows the special configuration file names.

15-58 Smart Setup Filename

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[16]	Change during operation:	True

Shows the Smart Setup file name.

15-59 Filename

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[16]	Change during operation:	False

Shows the currently used customer-specific initial values (CSIV) file name.

6.16.10 15-6* Option Ident.

This read-only parameter group contains information about the hardware and software configuration of the options installed in slots A, B, C0, and C1.

15-60 Option Mounted

Default value:	0	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[30]	Change during operation:	False

View the type of installed option.

15-61 Option SW Version

Default value:	0	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the installed option software version.

15-62 Option Ordering No

Default value:	0	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[8]	Change during operation:	False

View the code number for the installed options.

15-63 Option Serial No

Default value:	0	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[18]	Change during operation:	False

View the installed option serial number.

15-70 Option in Slot A

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[30]	Change during operation:	False

View the type code string for the option installed in slot A and a translation of the type code string. For example, for type code string AX, the translation is *No option*.

15-71 Slot A Option SW Version

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the software version for the option installed in slot A.

15-72 Option in Slot B

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[30]	Change during operation:	False

View the type code string for the option installed in slot B and a translation of the type code string. For example, for type code string *BX*, the translation is *No option*.

15-73 Slot B SW Version

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the software version for the option installed in slot B.

15-74 Option in Slot C0/E0

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[30]	Change during operation:	False

View the type code string for the option installed in slot C and a translation of the type code string. For example, for type code string *CXXXX*, the translation is *No option*.

15-75 Slot C0/E0 Option SW Version

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the software version for the option installed in slot C.

15-76 Option in Slot C1/E1

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[30]	Change during operation:	False

View the type code string for the option installed in slot C1 and a translation of the type code string. For example, for type code string *CXXXX*, the translation is *No option*.

15-77 Slot C1/E1 Option SW Version

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	False

View the software version for the installed option in option slot C.

6.16.11 15-8* Operating Data II

15-80 Fan Running Hours

Default value:	0 h	Parameter type:	Readout

Setup:	All setups	Conversion index:	74
Data type:	Uint32	Change during operation:	True

View for how many hours the heat sink fan has run (increments for every hour). The value is saved when the drive is turned off.

15-81 Preset Fan Running Hours

Default value:	0 h	Parameter type:	Range, 0 - 99999 h
Setup:	All setups	Conversion index:	74
Data type:	Uint32	Change during operation:	True

Enter the preset fan running hours counter, see parameter *15-80 Fan Running Hours*. This parameter cannot be selected via the serial port RS-485.

15-83 Motor Ud

Default value:	0.0 V	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the motor voltage on the d-axis. The value is a calculated value used for controlling the motor.

15-84 Motor Uq

Default value:	0.0 V	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the motor voltage on the q-axis. The value is a calculated value used for controlling the motor.

15-85 Motor Id

Default value:	0.0 A	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the motor d-axis current measured as a mean value, I_{RMS} .

15-86 Motor Iq

Default value:	0.0 A	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the motor q-axis current measured as a mean value, I_{RMS} .

15-87 kWh Counter Hires

Default value:	0 kWh	Parameter type:	Readout

Setup:	All setups	Conversion index:	75
Data type:	Uint32	Change during operation:	False

Register the power consumption of the motor as an average value over 1 hour. Reset the counter in parameter **15-06 Reset kWh Counter**. The decimal places are reset at power-up.

15-89 Configuration Change Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

6.16.12 15-9* Parameter Info

15-92 Defined Parameters

Default value:	0	Parameter type:	Readout, Array [2000]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View a list of all defined parameters in the drive. The list ends with 0.

15-93 Modified Parameters

Default value:	0	Parameter type:	Readout, Array [1000]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View a list of the parameters that have been changed from their default setting. The list ends with 0. Changes may not be visible until up to 30 s after implementation.

15-94 Extended Version

Default value:	Size related	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[65]	Change during operation:	True

ID	Description
[0]	Product name
[1]	Application SW
[2]	Motor control SW
[3]	Bootloader
[4]	Testmonitor

15-98 Drive Identification

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	VisStr[40]	Change during operation:	False

This parameter contains data used by the VLT® Motion Control Tool MCT 10.

15-99 Parameter Metadata

Default value:	0	Parameter type:	Readout, Array [35]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter contains data used by the VLT® Motion Control Tool MCT 10.

6.17 Parameter Group 16-** Data Readouts

6.17.1 16-0* General Status

16-00 Control Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

View the control word sent to the drive via the serial communication port in hex code.

16-01 Reference [Unit]

Default value:	0 ReferenceFeedbackUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False

View the present reference value applied on impulse or analog basis in the unit resulting from the configuration selected in parameter **1-00 Configuration Mode** (Hz, Nm, or RPM).

16-02 Reference %

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the total reference. The total reference is the sum of digital, analog, preset, bus, and freeze references plus catch up and slow down.

16-03 Status Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

View the status word sent from the drive via the serial communication port in hex code.

16-05 Main Actual Value [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	False

View the 2-byte word sent with the status word to the fieldbus master reporting the main actual value.

16-06 Actual Position

Default value:	0 AbsolutePositionUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

Shows the actual position in position units defined in parameter group **17-7* Position Scaling**. The value is based on the encoder feedback in closed loop or on the angle calculated by the motor control in open loop. For information about configuring the readouts, see parameter group **17-7* Position Scaling**.

16-07 Target Position

Default value:	0 AbsolutePositionUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False



NOTE: This parameter is only valid with software version 48.0X or newer.

Shows the actual end target position for the active positioning command in position units. Position units are defined in parameter group **17-7* Position Scaling**.

16-08 Position Error

Default value:	0 AbsolutePositionUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False



NOTE: This parameter is only valid with software version 48.0X or newer.

Shows the actual position error in position units defined in parameter group **17-7* Position Scaling**. Position error is the difference between the actual position and the commanded position. The position error is the input for the position PI controller.

16-09 Customer Readout

Default value:	0 CustomReadoutUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	False

View the value of custom readout from parameter **0-30 Unit for Userdefined Readout** to parameter **0-32 Custom Readout Max Value**.

6.17.2 16-1* Motor Status



NOTE:

The following parameter is only available in FC 302:

- Parameter **16-24 Calibrated Stator Resistance**

16-10 Power [kW]

Default value:	0 kW	Parameter type:	Readout
Setup:	All setups	Conversion index:	1
Data type:	Int32	Change during operation:	False

Shows motor power in kW. The value shown is calculated based on the actual motor voltage and motor current. The value is filtered, and therefore approximately 1.3 s may pass from when an input value changes to when the data readout values change. The resolution of readout value on fieldbus is in 10-W steps. The base unit is W.

16-11 Power [hp]

Default value:	0 hp	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	False

Shows motor power in hp. The value shown is calculated based on the actual motor voltage and motor current. The value is filtered, and therefore approximately 1.3 ms may pass from when an input value changes to when the data readout values change.

16-12 Motor Voltage

Default value:	0 V	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	UInt16	Change during operation:	False

View the motor voltage as a calculated value used for controlling the motor.

16-13 Frequency

Default value:	0 Hz	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	UInt16	Change during operation:	False

View the motor frequency without resonance damping.

16-14 Motor Current

Default value:	0 A	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	False

View the motor current measured as an average value, I_{RMS} . The value is filtered, and thus approximately 1.3 s may pass from when an input value changes to when the data readout values change.

16-15 Frequency [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	False

View a 2-byte word reporting the actual motor frequency (without resonance damping) as a percentage (scale 0000–4000 hex) of parameter **4-19 Max Output Frequency**. Set parameter **9-16 PCD Read Configuration** index 1 to send it with the status word instead of the MAV.

16-16 Torque [Nm]

Default value:	0 Nm	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the torque value with sign, applied to the motor shaft. Linearity is not exact between 160% motor current and torque in relation to the rated torque. Some motors supply more than 160% torque. Therefore, the minimum value and the maximum value depend on the maximum motor current and the motor used. The value is filtered, and thus approximately 30 ms may pass from when an input changes value to when the data readout values change. In flux control principle, this readout is compensated for in parameter **1-68 Motor Inertia** for improved accuracy.

16-17 Speed [RPM]

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Int32	Change during operation:	False

View the actual motor RPM. In open-loop or closed-loop process control, the motor RPM is estimated. In speed closed-loop modes, the motor RPM is measured.

16-18 Motor Thermal

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt8	Change during operation:	False

View the calculated thermal load on the motor. The cutout limit is 100%. The basis for calculation is the ETR function selected in parameter **1-90 Motor Thermal Protection**.

16-19 Thermistor Sensor Temperature

Default value:	0 °C	Parameter type:	Readout
Setup:	All setups	Conversion index:	100
Data type:	Int16	Change during operation:	False

Returning the actual temperature on KTY sensor built into the motor. See parameter group **1-9* Motor Temperature**.

16-20 Motor Angle

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

View the current encoder/resolver angle offset relative to the index position. The value range of 0–65535 corresponds to 0–2xpi (radian).

16-21 Torque [%] High Res.

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

The value shown is the torque in percentage of nominal torque, with sign and 0.1% resolution, applied to the motor shaft.

16-22 Torque [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	False

The value shown is the torque in percent of nominal torque, with sign, applied to the motor shaft.

16-23 Motor Shaft Power [kW]

Default value:	0 kW	Parameter type:	Readout
Setup:	All setups	Conversion index:	1
Data type:	Int32	Change during operation:	True

Readout of the mechanical power applied to the motor shaft. The base unit is in W.

16-24 Calibrated Stator Resistance

Default value:	0.0000 Ohm	Parameter type:	Readout
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True

Shows the calibrated stator resistance.

16-25 Torque [Nm] High

Default value:	0 Nm	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int32	Change during operation:	False

View the torque value with sign, applied to the motor shaft. Some motors supply more than 160% torque. Therefore, the minimum value and the maximum value depend on the maximum motor current as well as the motor used. This specific readout has been adapted to be able to show higher values than the standard readout in parameter **16-16 Torque [Nm]**.

16-28 Angle Error

Default value:	0°	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	False

Readout of the deviation between sensorless rotor angle estimation by motor controller and real rotor angle based on encoder reading. The parameter is only activated if options in parameter **1-01 Motor Control Principle** is set to **[2] Flux Sensorless** and parameter **1-10 Motor Construction** is set to **[1] PM, non salient SPM** or **[2] PM, salient IPM**. The encoder source used for comparison must be selected in parameter **7-00 Speed PID Feedback Source**. To obtain an accurate reading of parameter **16-28 Angle Error**, the motor angle offset must be set in parameter **1-41 Motor Angle Offset**. Rotor detection is configured in parameter **7-90 Position PI Feedback Source**, which is activated using the setting in parameter **1-70 Start Mode** in Flux with motor feedback. Parameter **7-90 Position PI Feedback Source** must be set to **[0] Motor feedb.P1-02**. The encoder is then only used for comparison while position control is based on the estimated sensorless position. This enables the measurement of the accuracy of position control in sensorless mode.

6.17.3 16-3* Drive Status



NOTE:

The following parameter is only available in FC 302:

- Parameter **16-49 Current Fault Source**

16-30 DC Link Voltage

Default value:	0 V	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View a measured value. The value is filtered with a 30 ms time constant.

16-32 Brake Energy/s

Default value:	0 kW	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

View the brake power transmitted to an external brake resistor, stated as an instant value.

16-33 Brake Energy Average

Default value:	0 kW	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

View the brake power transmitted to an external brake resistor. The mean power is calculated on an average level based on the selected time period within parameter **2-13 Brake Power Monitoring**.

16-34 Heatsink Temp.

Default value:	0 °C	Parameter type:	Readout

Setup:	All setups	Conversion index:	100
Data type:	Uint8	Change during operation:	False

View the drive heat sink temperature. The cutout limit is $90 \pm 5 \text{ }^{\circ}\text{C}$ ($194 \pm 9 \text{ }^{\circ}\text{F}$), and the motor cuts back in at $60 \pm 5 \text{ }^{\circ}\text{C}$ ($140 \pm 9 \text{ }^{\circ}\text{F}$).

16-35 Inverter Thermal

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

View the percentage load on the inverter.

16-36 Inv. Nom. Current

Default value:	Size related	Parameter type:	Range, 0.01 - 10000 A
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	False

View the inverter nominal current, which must match the nameplate data on the connected motor. The data is used for calculation of torque, motor overload protection, and so on.

16-37 Inv. Max. Current

Default value:	Size related	Parameter type:	Range, 0.01 - 10000 A
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	False

View the inverter maximum current, which must match the nameplate data on the connected motor. The data is used for calculation of torque, motor overload protection, and so on.

16-38 SL Controller State

Default value:	0	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

View the state of the event under execution by the SL controller.

16-39 Control Card Temp.

Default value:	0 $^{\circ}\text{C}$	Parameter type:	Readout
Setup:	All setups	Conversion index:	100
Data type:	Uint8	Change during operation:	False

View the temperature on the control card, stated in $^{\circ}\text{C}$.

16-40 Logging Buffer Full

Default value:	[0] No	Parameter Type:	Readout

Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

View whether the logging buffer is full (see parameter group **15-1* Data Log Settings**). The logging buffer is never full when parameter **15-13 Logging Mode** is set to **[0] Log always**.

Index	Name
[0]*	No
[1]	Yes

16-42 Service Log Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Shows the number of service logs stored in the ServiceLog file. If the ServiceLog file is full, clear the logged data by selecting option **[5] Clear** service logs in parameter **14-22 Operation Mode**. The logged data is deleted on the next power-up.

16-43 Timed Actions Status

Default value:	[0] Timed actions auto	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

View the mode of time-based actions.

Index	Name
[0]*	Timed actions auto
[1]	Timed actions disabled
[2]	Constant on action
[3]	Constant off actions

16-44 Speed Error [RPM]

Default value:	0.000 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Int32	Change during operation:	True

Shows the difference between the speed reference and the actual speed.

16-45 Motor Phase U Current

Default value:	0 A	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	True

Shows the motor phase U_{RMS} current. Facilitates monitoring of imbalance in the motor currents, detection of weak motor cables or imbalance in the motor windings.

16-46 Motor Phase V Current

Default value:	0 A	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	True

Shows the motor phase V_{RMS} current. Facilitates monitoring of imbalance in the motor currents, detection of weak motor cables or imbalance in the motor windings.

16-47 Motor Phase W Current

Default value:	0 A	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	True

Shows the motor phase W_{RMS} current. Facilitates monitoring of imbalance in the motor currents, detection of weak motor cables or imbalance in the motor windings.

16-48 Speed Ref. After Ramp [RPM]

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Int32	Change during operation:	False

This parameter specifies the reference given to the drive after the speed ramp.

16-49 Current Fault Source

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt8	Change during operation:	True

Value indicates source of current faults including short circuit, overcurrent, and imbalance of supply voltage (from left):

- 1–4 Inverter
- 5–8 Rectifier
- 0 No fault recorded

6.17.4 16-5* Ref. & Feedb.

16-50 External Reference

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the total reference, the sum of digital, analog, preset, fieldbus, and freeze references, plus catch up and slow down.

16-51 Pulse Reference

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the reference value from programmed digital inputs. The readout can also reflect the impulses from an incremental encoder.

16-52 Feedback[Unit]

Default value:	0 ReferenceFeedbackUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False

View the feedback unit resulting from the selection of unit and scaling in parameter **3-00 Reference Range**, parameter **3-01 Reference/Feedback Unit**, parameter **3-02 Minimum Reference**, and parameter **3-03 Maximum Reference**.

16-53 Digi Pot Reference

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	False

View the contribution of the digital potentiometer to the actual reference.

16-57 Feedback [RPM]

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Int32	Change during operation:	False

Readout parameter where the actual motor RPM from the feedback source can be read in both closed loop and open loop. The feedback source is selected in parameter **7-00 Speed PID Feedback Source**.

6.17.5 16-6* Inputs and Outputs



NOTE:

The following parameters are only available in FC 302:

- Parameter **16-67 Freq. Input #29 [Hz]**
- Parameter **16-70 Pulse Output #29 [Hz]**

16-60 Digital Input

Default value:	0	Parameter type:	Readout
Setup:	All setup	Conversion index:	0
Data type:	UInt16	Change during operation:	False

View the signal states from the active digital inputs. Example: Input 18 corresponds to bit number 5, 0 = no signal, 1 = connected signal. Bit 6 works in the opposite way, on = 0, off = 1 (Safe Torque Off input).

Table 54: Active Digital Inputs

Bit	Input
0	Digital input terminal 33.
1	Digital input terminal 32.
2	Digital input terminal 29.
3	Digital input terminal 27.
4	Digital input terminal 19.
5	Digital input terminal 18.
6	Digital input terminal 37.
7	Digital input VLT® General Purpose I/O MCB 101 terminal X30/4.
8	Digital input VLT® General Purpose I/O MCB 101 terminal X30/3.
9	Digital input VLT® General Purpose I/O MCB 101 terminal X30/2.
Bit 10–63	Reserved for future terminals.




Figure 94: Relay Settings

16-61 Terminal 53 Switch Setting

Default value:	[0] Current	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False

View the setting of input terminal 53.

Index	Name
[0]*	Current
[1]	Voltage

16-62 Analog Input 53

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False

View the actual value at input 53.

16-63 Terminal 54 Switch Setting

Default value:	[0] Current	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False

View the setting of terminal 54.

Index	Name
[0]*	Current
[1]	Voltage

16-64 Analog Input 54

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Changes during operation:	False

View the actual value at input 54.

16-65 Analog Output 42 [mA]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	False

View the actual value at output 42 in mA. The value shown reflects the selection in parameter **6-50 Terminal 42 Output**.

16-66 Digital Output [bin]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	False

View the binary value of all digital outputs.

16-67 Freq. Input #29 [Hz]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

View the actual frequency rate on terminal 29.

16-68 Freq. Input #33 [Hz]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

View the actual value of the frequency applied at terminal 33 as an impulse input.

16-69 Pulse Output #27 [Hz]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

View the actual value of pulses applied to terminal 27 in digital output mode.

16-70 Pulse Output #29 [Hz]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

View the actual value of pulses at terminal 29 in digital output mode.

16-71 Relay Output [bin]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	False

View the settings of all relays.

Readout choice (P16-71):

Relay output (bin):




Figure 95: Relay Settings

16-72 Counter A

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

View the present value of counter A. Counters are useful as comparator operands, see parameter **13-10 Comparator Operand**. Reset or change the value either via digital inputs (parameter group **5-1* Digital Inputs**) or by using an SLC action (parameter **13-52 SL Controller Action**).

16-73 Counter B

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

View the present value of counter B. Counters are useful as comparator operands, see parameter **13-10 Comparator Operand**. Reset or change the value either via digital inputs (parameter group **5-1* Digital Inputs**) or by using an SLC action (parameter **13-52 SL Controller Action**).

16-74 Prec. Stop Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt32	Change during operation:	True

Returns the actual counter value of precise counter (parameter **1-84 Precise Stop Counter Value**).

16-75 Analog In X30/11

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False

View the actual value at input X30/11 of VLT® General Purpose I/O MCB 101.

16-76 Analog In X30/12

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False

View the actual value at input X30/12 of VLT® General Purpose I/O MCB 101.

16-77 Analog Out X30/8 [mA]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	False

View the actual value at input X30/8 in mA.

16-78 Analog Out X45/1 [mA]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	False

Shows the actual output value at terminal X45/1. The value shown reflects the selection in parameter **6-70 Terminal X45/1 Output**.

16-79 Analog Out X45/3 [mA]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	False

Shows the actual output value at terminal X45/3. The value shown reflects the selection in parameter **6-80 Terminal X45/3 Output**.

6.17.6 16-8* Fieldbus & FC Port

16-80 Fieldbus CTW 1

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

View the 2-byte control word (CTW) received from the bus-master. Interpretation of the CTW depends on the fieldbus option installed and the CTW profile selected in parameter **8-10 Control Word Profile**. For more information, refer to the relevant fieldbus manual.

16-81 Fieldbus Sync. REF

Default value:	0	Parameter type:	Range, -2147783648 - 2147483647
Setup:	1 setup	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.3X.

Select an independent fieldbus synchronization reference which can be used when parameter **8-02 Control Word Source** is set to **[35] Option A fast**.

16-82 Fieldbus REF 1

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	N2	Change during operation:	False

View the 2-byte word sent with the control word from the bus-master to set the reference value. For more information, refer to the relevant fieldbus manual.

16-83 Fieldbus Pos. REF

Default value:	0 AbsolutePositionUnit	Parameter type:	Range, -2147483648 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	N2	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Shows the 32-bit position reference sent in PCD 2 and PCD 3. In parameters related to PCD 2 and PCD 3, select **[1683] Fieldbus Pos REF** for the fieldbus which is used by the drive. The value is in position units defined in parameter group **17-7* Position Scaling**.

16-84 Comm. Option STW

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

Shows the status word of the extended fieldbus communication option. For more information, refer to the relevant fieldbus manual.

16-85 FC Port CTW 1

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

View the 2-byte control word (CTW) received from the fieldbus master. Interpretation of the control word depends on the fieldbus option installed and the control word profile selected in parameter **8-10 Control Word Profile**.

16-86 FC Port REF 1

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	N2	Change during operation:	False

View the 2-byte status word (STW) sent to the fieldbus master. Interpretation of the status word depends on the fieldbus option installed and the control word profile selected in parameter **8-10 Control Word Profile**.

16-87 Bus Readout Alarm/Warning

Default value:	0	Parameter type:	Readout, Array [3]
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	False

Alarm and warning numbers in hex as shown in the alarm log. The alarm number is the 1st that occurred after the last reset.

Index	Description
[0]	The high byte contains the alarm, the low byte contains the warning.
[1]	Warning number only
[2]	Alarm number only

16-88 Fieldbus Torque FF

Default value:	0	Parameter type:	Range, -200 - 200
Setup:	1 setup	Conversion index:	0
Data type:	N2	Change during operation:	True

parameter A PCD write reference parameter. This parameter allows the PLC to adjust the Torque FF over the fieldbus continuously as a percentage of motor nominal torque, see parameter *1-26 Motor Cont. Rated Torque*.

16-89 Configurable Alarm/Warning Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This alarm/warning word is configured in parameter *8-17 Configurable Alarm and Warningword* to match the actual requirements.

6.17.7 16-9* Diagnosis Readouts

Use the parameters to show alarm, warning, and extended status words.

16-90 Alarm Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Show the alarm word sent via the serial communication port in hex code.

16-91 Alarm Word 2

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Shows the alarm word sent via the serial communication port in hex code.

16-92 Warning Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Shows the warning word sent via the serial communication port in hex code.

16-93 Warning Word 2

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Show the warning word sent via the serial communication port in hex code.

16-94 Ext. Status Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Returns the extended warning word sent via the serial communication port in hex code.

16-95 Ext. Status Word 2

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Returns the extended warning word sent via the serial communication port in hex code.

16-96 Maintenance Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Readout of the preventive maintenance word. The bits reflect the status for the programmed preventive maintenance events in parameter group **23-1* Maintenance**. 13 bits show combinations of all the possible items:

- Bit 0: Motor bearings
- Bit 1: Pump bearings
- Bit 2: Fan bearings
- Bit 3: Valve
- Bit 4: Pressure transmitter
- Bit 5: Flow transmitter
- Bit 6: Temperature transmitter
- Bit 7: Pump seals
- Bit 8: Fan belt
- Bit 9: Filter
- Bit 10: Drive cooling fan
- Bit 11: Drive system health check
- Bit 12: Warranty
- Bit 13: Maintenance text 0

- Bit 14: Maintenance text 1
- Bit 15: Maintenance text 2
- Bit 16: Maintenance text 3
- Bit 17: Maintenance text 4

The following table details the display of the maintenance word.

Table 55: Maintenance Word

Position 4⇒	Valve	Fan bearings	Pump bearings	Motor bearings
Position 3⇒	Pump seals	Temperature transmitter	Flow transmitter	Pressure transmitter
Position 2⇒	Drive system health check	Drive cooling fan	Filter	Fan belt
Position 1⇒	–	–	–	Warranty
0 _{hex}	–	–	–	–
1 _{hex}	–	–	–	+
2 _{hex}	–	–	+	–
3 _{hex}	–	–	+	+
4 _{hex}	–	+	–	–
5 _{hex}	–	+	–	+
6 _{hex}	–	+	+	–
7 _{hex}	–	+	+	+
8 _{hex}	+	–	–	–
9 _{hex}	+	–	–	+
A _{hex}	+	–	+	–
B _{hex}	+	–	+	+
C _{hex}	+	+	–	–
D _{hex}	+	+	–	+
E _{hex}	+	+	+	–
F _{hex}	+	+	+	+

Example: The preventive maintenance word shows 040A_{hex}:

Position	1	2	3	4
Hex value	0	4	0	A

- The 1st digit 0 indicates that no items from the 4th row require maintenance.
- The 2nd digit 4 refers to the 3rd row indicating that the drive cooling fan requires maintenance.
- The 3rd digit 0 indicates that no items for the 2nd row require maintenance.
- The 4th digit A refers to the top row indicating that the valve and the pump bearings require maintenance.

16-97 Alarm Word 3

Default value:	0	Parameter type:	Readout

Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Shows the alarm word sent via the serial communication port in hex code.

16-98 Warning Word 3

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Shows the warning word sent via the serial communication port in hex code.

16-99 Ext. Status Word 3

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

View the extended status word 3 as a hexadecimal value.

6.18 Parameter Group 17-** Feedback

6.18.1 17-0* Encoder Interface

17-00 Encoders Connected

Default value:	[0] One encoder	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.3X or newer.



NOTE: This parameter is only available with VLT® Encoder Option MCB 102 version 4.00 or newer.

Select if 1 or 2 encoders are connected to MCB 102.

Option	Name	Description
[0]*	One encoder	Only 1 encoder is connected. The encoder can be any of the supported encoder types.
[1]	Two encoders	Two encoders are connected. The encoders must be 1 incremental (TTL or SinCos) and 1 absolute (SSI or Endat) without incremental channel.

17-01 Standby Encoder

Default value:	[0] None	Parameter type:	Option

Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Select the source for the standby encoder which will be used as feedback if the primary encoder fails.

Option	Name	Description
[0]*	None	No standby encoder.
[1]	Standby encoder to T32/33	Standby encoder connected to terminals 32 and 33.
[2]	Standby encoder to T27/29	 NOTE: This option is only available in FC 302 with IMC software version 48.6X or newer. Standby encoder connected to terminals 27 and 29.

6.18.2 17-1* Inc. Enc. Interface



NOTE: Do not use incremental encoders with PM motors. In a closed-loop control, consider absolute encoders or resolvers.



NOTE: These parameters cannot be adjusted while the motor is running.

This parameter group contains parameters for configuring the incremental interface of the VLT® Encoder Input MCB 102. Both the incremental and absolute interfaces are active at the same time.

17-10 Signal Type

Default value:	[1] RS422 (5V TTL)	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Select this parameter if 1 or 2 encoders are connected to MCB 102.

Option	Name	Description
[0]	None	
[1]*	RS422 (5V TTL)	
[2]	Sinoidal 1Vpp	

17-11 Resolution (PPR)

Default value:	1024	Parameter type:	Range, 10 - 16384
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Enter the number of pulses or periods per revolution (the incremental track).

6.18.3 17-2* Abs. Enc. Interface

This parameter group contains parameters for configuring the absolute interface of the VLT® Encoder Input MCB 102. Both the incremental and absolute interfaces are active at the same time.

17-20 Protocol Selection

Default value:	[0] None	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be changed while the motor is running.

Option	Name	Description
[0]*	None	Select [0] None if the feedback sensor is an incremental encoder only.
[1]	HIPERFACE	Select [1] HIPERFACE if the encoder is absolute only.
[2]	EnDat	
[4]	SSI	
[8]	Z pulse	Select 0 pulse as "absolute" track when using incremental encoder with 0 pulse.

17-21 Resolution (Positions/Rev)

Default value:	Size related	Parameter type:	Range, 4 - 1073741824
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Select the resolution of the absolute encoder, that is the number of counts per revolution. The value depends on setting in parameter **17-20 Protocol Selection**.

17-22 Multiturn Revolutions

Default value:	1	Parameter type:	Range, 1 - 16777216
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Select the number of multi-turn revolutions. Select value 1 for single-turn type encoders.

17-24 SSI Data Length

Default value:	13	Parameter type:	Range, 1 - 32
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

Set the number of bits for the SSI telegram. Select 13 bits for singleturn encoders and 25 bits for multiturn encoders.

17-25 Clock Rate

Default value:	260 kHz	Parameter type:	Range, 100 - 260 kHz
Setup:	All setups	Conversion index:	3
Data type:	Uint16	Change during operation:	False

Set the SSI clock rate. With long encoder cables, the clock rate must be reduced.

17-26 SSI Data Format

Default value:	[0] Gray code	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	Gray code	
[1]	Binary code	Set the data format of the SSI data.

17-28 SSI Status Bits

Default value:	0	Parameter type:	Range, 0 - 8
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

Set the number of status/error bits for the SSI telegram.

17-34 HIPERFACE Baudrate

Default value:	[4] 9600	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the motor is running.

Select the baud rate of the attached encoder. The parameter is only accessible when parameter **17-20 Protocol Selection** is set to **[1] HIPERFACE**.

Option	Name	Description
[0]	600	
[1]	1200	
[2]	2400	
[3]	4800	
[4]*	9600	
[5]	19200	
[6]	38400	

6.18.4 17-4* Fieldbus Reference 2

17-40 Fieldbus Sync. Delta

Default value:	0	Parameter type:	Range, -2147483648 - 2147483647
Setup:	1 setup	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available with software version 48.7X or newer.

Shows the fieldbus synchronizing master position change, which is master speed when transferred by PCD from fieldbus master.

17-41 Fieldbus Profile Velocity

Default value:	0 pu/s	Parameter type:	Range, 0 - 2147483647 pu/s
Setup:	1 setup	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available with software version 48.8X or newer.

Velocity reference for the profile generator in positioning mode or when using Mode of operation and Profile positioning mode.

17-42 Fieldbus Velocity FF.

Default value:	0 pu/s	Parameter type:	Range, -2147483648 - 2147483647 pu/s
Setup:	1 setup	Conversion index:	0
Data type:	Int32	Change during operation:	False



NOTE: This parameter is only available with software version 48.8X or newer.

Velocity feedforward when running in cyclic sync. position mode.

17-43 Fieldbus Acceleration FF.

Default value:	0 pu/s ²	Parameter type:	Range, -2147483648 - 2147483647 pu/s ²
Setup:	1 setup	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available with software version 48.8X or newer.

Acceleration feedforward when running cyclic sync. position or cyclic sync. velocity mode.

17-44 Fieldbus Target Velocity

Default value:	0 pu/s	Parameter type:	Range, -2147483648 - 2147483647 pu/s
Setup:	1 setup	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available with software version 48.8X or newer.

Velocity reference when running cyclic sync. velocity mode.

6.18.5 17-5* Resolver Interface

This parameter group is used for setting parameters for the VLT® Resolver Input MCB 103. Usually, the resolver feedback is used as motor feedback from permanent magnet motors with parameter **1-01 Motor Control Principles** set to **[3] Flux w/motor feedback**. Resolver parameters cannot be adjusted while the motor is running.

17-50 Poles

Default value:	2	Parameter type:	Range, 2 - 64
Setup:	1 setup	Conversion index:	0
Data type:	UInt8	Change during operation:	False

Set the pole number on the resolver. The value is stated in the datasheet for resolvers.

17-51 Input Voltage

Default value:	7 V	Parameter type:	Range, 2 - 8 V
Setup:	1 setup	Conversion index:	-1
Data type:	UInt8	Change during operation:	False

Set the input voltage to the resolver. The voltage is stated as RMS value. The value is stated in the datasheet for resolvers.

17-52 Input Frequency

Default value:	10 kHz	Parameter type:	Range, 2 - 15 kHz
Setup:	1 setup	Conversion index:	2
Data type:	UInt8	Change during operation:	False

Set the input frequency to the resolver. The value is stated in the datasheet for resolvers.

17-53 Transformation Ratio

Default value:	0.5	Parameter type:	Range, 0.1 - 1.1
Setup:	1 setup	Conversion index:	-1
Data type:	UInt8	Change during operation:	False

Set the transformation ratio for the resolver. The transformation ratio is:

$$T_{\text{ratio}} = \frac{V_{\text{out}}}{V_{\text{in}}}$$

The value is stated in the datasheet for resolvers.

17-56 Encoder Sim. Resolution

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Set the resolution and activate the encoder emulation function (generation of encoder signals from the measured position from a resolver). Use this function to transfer the speed or position information from 1 drive to another. To disable the function, select **[0] Disabled**.

Option	Name	Description
[0]*	Disabled	
[1]	512	
[2]	1024	
[3]	2048	
[4]	4096	
[5]	Enable encoder sim. adv.	Set the encoder simulation resolution via parameter 17-58 Encoder Sim. Resolution Adv.

17-58 Encoder Sim. Resolution Adv.

Default value:	0	Parameter type:	Range, 0 - 16384
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Set the encoder simulation resolution as a continuous value in steps of 1. This parameter is only active when **[5] Enable encoder sim. adv.** is selected in parameter **17-56 Encoder Sim. Resolution**.

17-59 Resolver Interface

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Activate the VLT® Resolver Input MCB 103 when the resolver parameters are selected. To avoid damage to resolvers, adjust parameter **17-50 Poles** and parameter **17-53 Transformation Ratio** before enabling this parameter.

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	

6.18.6 17-6* Monitoring and Application



NOTE: The following parameters are only available in FC 302:

- Parameter **17-67 Raw Inc. Quad Counter**
- Parameter **17-68 Raw Abs. Pos. Low**
- Parameter **17-69 Raw Abs. Pos. High**

This parameter group is for selecting extra functions when VLT® Encoder Input MCB 102 or VLT® Resolver Input MCB 103 is fitted into option B slot as speed feedback. Monitoring and application parameters cannot be adjusted while the motor is running.

17-60 Feedback Direction

Default value:	[0] Clockwise	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter cannot be adjusted while the motor is running.

Change the detected encoder rotation direction without changing the wiring to the encoder.

Option	Name	Description
[0]*	Clockwise	
[1]	Counter clockwise	

17-61 Feedback Signal Monitoring

Default value:	[1] Warning	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Select which action the drive should take if a faulty encoder signal is detected. The encoder function in parameter **17-61 Feedback Signal Monitoring** is an electrical check of the hardware circuit in the encoder system.

Option	Name	Description
[0]	Disabled	
[1]*	Warning	
[2]	Trip	
[3]	Jog	
[4]	Freeze output	
[5]	Max speed	
[6]	Switch to open loop	
[7]	Select setup 1	
[8]	Select setup 2	
[9]	Select setup 3	

Option	Name	Description
[10]	Select setup 4	
[11]	Stop & trip	
[12]	Trip/warning	
[13]	Trip/catch	

17-66 SSI Status

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

This parameter shows a readout of the SSI status/error bits on VLT® Encoder Input MCB 102.

17-67 Raw Inc. Quad Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Shows the raw incremental counter value in quad counts (4 times pulse count) of an encoder connected to VLT® Encoder Input MCB 102. It can be an incremental encoder or the incremental part of a dual-channel absolute encoder. MCB 102 must be selected as feedback source in parameter **1-02 Flux Motor Feedback Source**, parameter **7-00 Speed PID Feedback Source**, or parameter **7-90 Position PI Feedback Source**.

17-68 Raw Abs. Pos. Low

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

This parameter shows the least significant 32 bits of the position value read from an absolute encoder connected to VLT® Encoder Input MCB 102. MCB 102 must be selected as feedback source in parameter **1-02 Flux Motor Feedback Source**, parameter **7-00 Speed PID Feedback Source**, or parameter **7-90 Position PI Feedback Source**.

17-69 Raw Abs. Pos. High

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

This parameter shows the most significant 32 bits of the position value read from an absolute encoder connected to VLT® Encoder Input MCB 102. MCB 102 must be selected as feedback source in parameter **1-02 Flux Motor Feedback Source**, parameter **7-00 Speed PID Feedback Source**, or parameter **7-90 Position PI Feedback Source**.

6.18.7 17-7* Position Scaling

Parameters in this group define how the drive scales and handles the position values.

17-70 Position Unit

Default value:	[0] pu	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Select the physical unit for showing the position values on the LCP.

Option	Name	Description
[0]*	pu	Position unit.
[1]	m	Meters.
[2]	mm	Millimeters
[3]	inc	Increments.
[4]	°	Degrees.
[5]	rad	Radian.
[6]	%	Percent.
[7]	qc	Quad count, which is ¼ of an encoder pulse when using quadrature encoder signal.

17-71 Position Unit Scale

Default value:	0	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Int8	Change during operation:	False

Enter the scaling factor for the position values. The scaling function multiplies the readout values by 10^x , where x is the value of this parameter. For example, if x = 2, the value 5 is shown as 500. The elements of the array are:

- Index 0 is the scaling factor for readout and settings of position values in parameters or in a fieldbus. Index 1 contains exceptions.
- Index 1 is the scaling factor for readout of position error (parameter **16-08 Position Error**) and for the value of parameter **3-08 On Target Window**.

17-72 Position Unit Numerator

Default value:	1024	Parameter type:	Range, -2147483648 - 2147483647
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

This parameter is the numerator in the equation which defines the relation between 1 motor revolution and physical movement of machine. Example: Consider a turn table application. The motor makes 10 revolutions when the table makes 1 revolution. The position unit is a degree. For this setup, enter the following values:

$$\text{Positionunit} = \frac{\text{Par.17-72}}{\text{Par.17-73}} \times \text{Motorrevolutions}$$

- Parameter **17-72 Position Unit Numerator** = 360
- Parameter **17-73 Position Unit Denominator** = 10

Set the physical unit for position values in parameter **17-70 Position Unit**.

17-73 Position Unit Denominator

Default value:	1	Parameter type:	Range, -2147483648 - 2147483647
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

See parameter **17-72 Position Unit Numerator**.

17-74 Position Offset

Default value:	0	Parameter type:	Range, -2147483648 - 2147483647
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

Enter the absolute encoder position offset. Use this parameter to adjust the 0 position of the encoder without physically moving the encoder. Set the physical unit for position values in parameter **17-70 Position Unit**.

17-75 Position Recovery at Power-up

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available with software version 48.0X or newer.

Select the actual position after power-up when using open loop or incremental encoders.

Option	Name	Description
[0]*	Off	The actual position is 0 after power-up.
[1]	On	This drive stores the actual position at power-down and uses it as the actual position when powered up.

17-76 Position Axis Mode

Default value:	[0] Linear axis	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available with software version 48.0X or newer.

Select the axis type for position counting.

Option	Name	Description
[0]*	Linear axis	The motion is within a position range defined by parameter 3-06 Minimum Position and parameter 3-07 Maximum Position .
[1]	Rotary 0 - Max	Continuous motion, where the position changes between 0 and parameter 3-07 Maximum Position . When passing the maximum position, the reading restarts from 0.
[2]	Rotary min - max	 NOTE: This option is available only with software version 48.20 and newer. Continuous motion, where the position changes between parameter 3-06 Minimum Position and parameter 3-07 Maximum Position. When passing the maximum position, the reading restarts from the minimum position.

17-77 Position Feedback Mode

Default value:	[0] Relative	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

 **NOTE:** This parameter is only available with software version 48.20.

Select the mode for handling absolute encoders. Select **[0] Relative** if the application requires tracking the position when the position value exceeds the measuring range of the encoder, for example, when using single-turn encoders for linear motion. Select **[1] Absolute** if the position values are always within the measuring range of the encoder, for example, when using a laser distance-measuring device.

Option	Name	Description
[0]*	Relative	The actual position is set to the absolute position read from the encoder at power-up, and then the drive uses only the position changes for calculating the actual position. In this mode, the actual position values are between -2147483648 and 2147483647 even when the values exceed the measuring range of the encoder. To save and use the absolute position values outside the measuring range of the encoder after power-down, set parameter 17-75 Position Recovery at Power-up to [1] On . The position value is accurate if the encoder does not move by more than half of the encoder measuring range when the drive is powered down.
[1]	Absolute	The drive uses the absolute position from the encoder as actual position continuously. In this mode, the actual position values are between 0 and the maximum position of the encoder. The maximum position is determined by the number of bits, for example, the SSI encoder has 25 bits and its maximum value is $2^{25} = 33554432$. Set parameter 3-07 Maximum Position to the maximum value of the encoder scaled according to parameter 7-94 Position PI Feedback Scale Numerator , parameter 7-95 Position PI Feedback Scale Denominator , parameter 17-72 Position Unit Numerator , and parameter 17-73 Position Unit Denominator . If the position exceeds the measuring range of the encoder, the absolute position reference is lost. For example, use this option if there is a laser distance-measuring device and there is a risk that some external objects may occasionally interfere with the laser beam. In this case, the absolute positioning will work correctly when the external disturbance disappears.

17-78 Active Position Counter

Default value:	[0] Counter 0	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False

The drive has 4 individual position counters. Only the selected counter is updated. Allows tracking position of up to 4 motors controlled by 1 drive, 1 motor at a time. The active counter can be selected by this parameter in the same setup or by setup change when selecting between motors.

Option	Name	Description
[0]*	Counter 0	
[1]	Counter 1	
[2]	Counter 2	
[3]	Counter 3	

17-79 Fieldbus Pos. Vel. Accel. Ref. Type

Default value:	[0] DINT	Parameter type:	Option
Setup:	All setups	Conversion index:	–

Data type:	UInt8	Change during operation:	False

When parameter **8-02 Control Word Source** is set to **[35] Option A fast**, the fieldbus position, velocity, and acceleration can be sent as a standard 32-bit signed integer, DINT, or a IEEE 754-2008 32-bit floating point, REAL.

Option	Name	Description
[0]*	DINT	Standard 32-bit signed integer.
[1]	REAL	IEEE 754-2008 32-bit floating point.

6.18.8 17-8* Position Homing

This parameter group contains parameters for configuring the homing function. The homing function creates a reference in the physical machine.

17-80 Homing Function

Default value:	[0] No homing	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Select the homing function. The homing function creates a position reference in the physical machine. The selected homing function can be activated with a digital input or a fieldbus bit. Homing is not required when using absolute encoders. All homing functions except **[2] Home Sync Function** require a start homing signal.

Option	Name	Description
[0]*	No homing	No homing function. The actual position is 0 after power-up, independent of the physical machine position.
[1]	Home position	Actual position is set to the value of parameter 17-82 Home Position , index 0.
[2]	Home sync function	Homing position is synchronized with the homing sensor according to the setting in parameter 17-81 Home Sync Function . Manual homing is done with 1 of the 3 homing-on-sensor functions, [9] Direction with sensor , [10] Forward with sensor , or [11] Reverse with sensor . The direction follows the selection in parameter 17-81 Home Sync Function . When home sync in both directions is selected, the direction follows the reversing signal.
[3]	Analog input 53	Use the value of analog input 53 as the actual position. The value is scaled according to parameter 3-06 Minimum Position and parameter 3-07 Maximum Position .
[4]	Analog input 54	Same as [3] Analog input 53 , but for analog input 54.
[5]	Home latch function	Only latching of the actual position every time the home sensor is detected without executing any homing function. The result is updated in parameter 18-25 latched Actual Pos .

Option	Name	Description
[9]	Direction with sensor	Perform a search for the homing sensor in the direction defined by the forward/reverse signal on a digital input or fieldbus, using the settings in parameter 17-83 Homing Speed and parameter 17-84 Homing Torque Limit . When the drive detects the homing sensor input (configured in parameter group 5-1* Digital Inputs), it sets the actual position to the value of parameter 17-82 Home Position , index 0. The drive then switches to the positioning mode with a target defined in parameter 17-82 Home Position , index 0 + index 1. If reversing is required for going to the target position, set parameter 4-10 Motor Speed Direction to [2] Both directions .
[10]	Forward with sensor	Perform a search for the homing sensor in forward direction using the settings in parameter 17-83 Homing Speed and parameter 17-84 Homing Torque Limit . When the drive detects the homing sensor input (configured in parameter group 5-1* Digital Inputs), it sets the actual position to the value of parameter 17-82 Home Position , index 0. The drive then switches to the positioning mode with a target defined in 17-82 Home Position , index 0 + index 1. If reversing is required for going to the target position, set parameter 4-10 Motor Speed Direction to [2] Both directions .
[11]	Reverse with sensor	Same as [10] Forward with sensor , but with the search in the reverse direction. Set parameter 4-10 Motor Speed Direction to [1] Counter clockwise or [2] Both directions .
[12]	Forward torque limit	With this option selected, the drive does the following: - Runs forward with the set homing speed (parameter 17-83 Homing Speed). - When the torque reaches the limit set in parameter 17-84 Homing Torque Limit, and the speed is lower than the value in parameter 3-05 On Reference Window, the actual position is set to the value of parameter 17-82 Home Position, index 0. - The drive positions to the target defined in parameter 17-82 Home Position, index 0 + index 1. Only available in flux closed loop. See also parameter 17-85 Homing Timeout .
[13]	Reverse torque limit	Same as [12] Forward Torque Limit but in reverse direction. Set parameter 4-10 Motor Speed Direction to [1] Counter clockwise or [2] Both directions . Only available in flux closed loop.
[14]	Direction with Z pulse	Same as [9] Direction with Sensor but with encoder zero pulse as home sensor.
[15]	Forward with Z pulse	Same as [10] Forward with Sensor but with encoder zero pulse as home sensor.
[16]	Reverse with Z pulse	Same as [11] Reverse with Sensor but with encoder zero pulse as home sensor.
[17]	Direction with S & Z	Same as [9] Direction with Sensor but moving to encoder zero pulse after finding the home sensor.
[18]	Forward with S & Z	Same as [10] Forward with Sensor but moving to encoder zero pulse after finding the home sensor.

Option	Name	Description
[19]	Reverse with S & Z	Same as [11] Reverse with Sensor but moving to encoder zero pulse after finding the home sensor.
[20]	Fwd. II with sensor	When on the correct side of the home sensor, performs a search for home sensor in forward direction using the settings in parameter 17-83 Homing Speed , and then reverses with 10% of Homing Speed when home sensor is detected. The falling edge of home sensor signal is set to the value defined in parameter 17-82 Home Position , index 0. When on the wrong side of the home sensor, the positive end limit switch is reached without detecting the home sensor, the drive reverses until home sensor is passed. After the home sensor is detected, the search for home sensor is performed in forward direction, as described.
[21]	Rev. II with sensor	When on the correct side of the home sensor, perparameter forms a search for home sensor in the reverse direction using the settings in 17-83 Homing Speed , and then moves forward with 10% of Homing Speed when home sensor is detected. The falling edge of home sensor signal is set to the value defined in parameter 17-82 Home Position , index 0. When on the wrong side of the home sensor, a negative end limit switch is reached without detecting the home sensor, the drive operates in forward direction until home sensor is passed. After the home sensor is detected, the search for home sensor is performed in reverse, as described.
[22]	Home sync II function	 NOTE: This option is only available in IMC software version 48.93 and newer. The function is the same as in [2] Home sync function, but the manual homing differs. Manual homing is done with 1 of the 2 homing II-on-sensor functions, [20] Fwd. II with sensor or [21] Rev. II with sensor where the direction follows the selection in parameter 17-81 Home Sync. Function. When home sync in both directions is selected, the direction follows the reversing signal.
[23]	Fwd. only with sensor	 NOTE: This option is only available in IMC software version 48.96 or newer. For rotary mode only running in 1 direction. Perform home sensor search in forward direction with set homing speed. When home sensor is found, movement continues in the same direction with 10% of homing speed. At the same time, the actual position is set to the home position at the falling edge of the home sensor. Moving back can be avoided by setting a home offset.
[24]	Rev. only with sensor	 NOTE: This option is only available in IMC software version 48.96 or newer. This works as in [23] Fwd. only with sensor, but in reverse direction.

17-81 Home Sync Function

Default value:	[0] 1st time after power	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Select the trigger for the homing synchronization function. Only active when **[2] Home Sync Function** is selected in parameter **17-80 Homing Function**. The homing synchronization function sets the actual position to the value of parameter **17-82 Home Position**:

- Index 0 if the homing sensor is approached in the forward direction.
- Index 1 if the homing sensor is approached in the reverse direction.

Option	Name	Description
[0]*	1st time after power	After power-up, the 1st detection of the homing sensor triggers the function.
[1]	1st t. aft.pow. forward	After power-up, the 1st detection of the homing sensor in the forward direction triggers the function.
[2]	1st t. aft.pow. reverse	After power-up, the 1st detection of the homing sensor in the reverse direction triggers the function.
[3]	1st time after start	After start, the 1st detection of the homing sensor triggers the function.
[4]	1st t. aft.str. forward	After start, the 1st detection of the homing sensor in the forward direction triggers the function.
[5]	1st t. aft.str. reverse	After start, the 1st detection of the homing sensor in the reverse direction triggers the function.
[6]	Every time	Every detection of the homing sensor triggers the function.
[7]	Every time forward	Every detection of the homing sensor in the forward direction triggers the function.
[8]	Every time reverse	Every detection of the homing sensor in the reverse direction triggers the function.

17-82 Home Position

Default value:	0 AbsolutePositionUnit	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Set the homing position in position units defined in parameter group **17-7* Position Scaling**. This is an array parameter with 2 elements. Indices in this parameter have a different meaning in the following situations:

- If parameter **17-80 Homing Function** is set to options [10]–[13], index 0 of this parameter defines the actual home position and index 1 is used as the homing offset, which defines where to stop.

- If parameter **17-80 Homing Function** is set to **[2] Home Sync Function**, and parameter **17-81 Home Sync Function** is set to **[0] 1st time after power**, **[3] 1st time after start**, or **[6] Every time**, then indices have the following meaning:
 - Index 0 is the homing position when the homing sensor is approached in the forward direction.
 - Index 1 is the homing position when the homing sensor is approached in the reverse direction.

17-83 Homing Speed

Default value:	150 RPM	Parameter type:	Range,m -32000 - 32000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Int16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Enter the speed for the homing functions (parameter **17-80 Homing Function**, options [10]–[13]).

17-84 Homing Torque Limit

Default value:	160%	Parameter type:	Range, 0 - 500%
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Enter the torque limit for the homing functions (parameter **17-80 Homing Function**, options [10]–[13]).

17-85 Homing Timeout

Default value:	60.0 s	Parameter type:	Range, -0.1 - 6000.0 s
Setup:	All setups	Conversion index:	-1
Data type:	UInt16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Enter the timeout for the homing functions (parameter **17-80 Homing Function**, options [10]–[13]). If the drive does not detect the homing sensor or does not reach the torque limit within the timeout time, it aborts the homing process and trips.

17-86 Homing Flag Behavior

Default value:	[0] Clear at power-up	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X and newer.

Select when the Homing OK signal is cleared.

Option	Name	Description
[0]*	Clear at power-up	<i>Homing Ok</i> is cleared at power-up and a new homing is needed for subsequent positioning operations. The option is a typical selection when using an incremental encoder and the position tracking is lost at power-down only.
[1]	Clear at coast	<i>Homing Ok</i> is cleared at every motor coast and a new homing is needed. The option is a typical selection for sensorless control as position tracking is lost when the motor is coasted.
[2]	Clear at coast running	<i>Homing Ok</i> is cleared at motor coast only while motor is running and a new homing is needed. The option is a typical selection for sensorless control with a mechanical brake holding the position at stand still.
[3]	Clear at homing only	<i>Homing Ok</i> is only cleared at new start of the selected homing function. The option is a typical selection for absolute encoders. After completing the selected homing function, parameter 17-74 Position Offset is automatically set to the offset calculated by: $\text{Parameter } 17-74 \text{ Position Offset} = (\text{Parameter } 17-82.0 \text{ Home Position}) - (\text{Position value read from encoder})$. Start a new homing to recalculate parameter 17-74 Position Offset , for example, after replacing the encoder.
[4]	Clear at coast running or homing	NOTE: This option is only available in IMC software version 48.98 or newer. Combines [2] Clear at coast running and [3] Clear at homing only . Homing OK is cleared when coasting while running and when starting a new homing. This is a typical selection for sensorless control with mechanical holding brake and using parameter 17-75 Position Recovery at Power-up to store the actual position at power-down.

17-87 Homing Activation

Default value:	[0] Manual	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X.

Activation manner of drive homing and master homing. Master homing can be activated by a *Set Master Home* signal or the *Start Homing* signal by selecting options **[2] Manual and Master** and **[3] Auto and Master**.

Option	Name	Description
[0]*	Manual	Activates homing function selected in parameter 17-80 Homing Function using the <i>Start Homing</i> signal.
[1]	Auto	Homing function selected in parameter 17-80 Homing Function is activated automatically when the <i>Homing OK</i> signal is low and start signal is applied.

Option	Name	Description
[2]	Manual and master	Activates homing function selected in parameter 17-80 Homing Function and sets the actual master position as defined in parameter 17-88 Master Home Position , using <i>Start Homing</i> signal.
[3]	Auto and master	Homing function selected in parameter 17-80 Homing Function is activated automatically when the <i>Homing OK</i> signal is low and start signal is applied. The actual master position is set as defined in parameter 17-88 Master Home Position .

17-88 Master Home Position

Default value:	0 AbsolutePositionUnit	Parameter type:	Range, -2147483648 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X.

Set the master home position in position units which are used by master homing function.

6.18.9 17-9* Position Configuration

17-90 Absolute Position Mode

Default value:	[0] Standard	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Select the behavior when executing consecutive absolute positioning commands.

Option	Name	Description
[0]*	Standard	When the drive receives a new absolute positioning command while the previous command is still in progress, it executes the new positioning command immediately without completing the previous positioning.
[1]	Buffered	When the drive receives a new absolute positioning command while the previous positioning command is still in progress, it completes the previous command and then executes the new positioning command. Only 1 positioning command can be buffered at a time.

17-91 Relative Position Mode

Default value:	[0] Target position	Parameter type:	Option

Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

Select which reference to use for relative positioning commands.

Option	Name	Description
[0]*	Target position	The drive uses the latest target position as reference for the new positioning command. The drive executes the new positioning command immediately without completing the previous positioning. The new target is calculated with the formula: New target = previous target + position reference.
[1]	Buffered target pos.	The drive uses the latest target position as reference for the new positioning command. The drive executes the new positioning command when it completes the previous command. Only 1 positioning command can be buffered at a time.
[2]	Commanded position	The drive uses the commanded position as reference for the new positioning command. The drive executes the new positioning command immediately without completing the previous positioning. The new target is calculated with the formula: New target = commanded position + position reference.
[3]	Actual position	The drive uses the actual position as reference for the new positioning command. The drive executes the new positioning command immediately without completing the previous positioning. The new target is calculated with the formula: New target = actual position + position reference.

17-92 Position Control Selection

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.0X.

This parameter allows to select the position control mode without using a digital input signal or a fieldbus bit.

Option	Name	Description
[0]*	No operation	Use a digital input signal or a fieldbus bit to activate the enable-reference mode and the relative position mode.
[1]	Relative position	This option selects the relative position mode permanently. All positioning commands are considered to be relative. Toggling option [113] Enable Reference on a digital input or the enable reference fieldbus bit triggers relative positioning.
[2]	Enable reference	This option selects the enable-reference mode permanently. Any new position reference triggers an absolute positioning command with the selected position reference as target. This option cannot be used with relative positioning.

17-93 Master Offset Selection

Default value:	[0] Absolute enabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.1X.

Select the behavior of the master offset in synchronization mode.

Option	Name	Description
[0]*	Absolute enabled	The drive adds the master offset (parameter 3-26 Master Offset) to the position at synchronization start. The offset command is executed at every new synchronization start.
[1]	Absolute	The drive adds the master offset (parameter 3-26 Master Offset) to the position at synchronization start. The offset command is executed with every enable master offset signal.
[2]	Relative	The drive adds the master offset (parameter 3-26 Master Offset) to the actual synchronization position with every enable master offset signal.
[3]	Selection	The master offset (parameter 3-26 Master Offset) is relative or absolute depending on the relative position signal on a digital input or the fieldbus bit.
[4]	Relative home sensor	The master offset (parameter 3-26 Master Offset) is relative to the home sensor signal. The offset command is executed with the next home sensor signal when the enable master offset signal is active.
[5]	Relative touch sensor	The master offset (parameter 3-26 Master Offset) is relative to the touch sensor signal. The offset command is executed with the next touch sensor signal when the enable master offset signal is active.

17-94 Rotary Absolute Direction

Default value:	[0] Shortest	Parameter type:	Option

Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X.

Select the rotation direction for the absolute position mode when parameter **17-76 Position Axis Mode** is set to **[1] Rotary Axis**. To use this parameter, set parameter **4-10 Motor Speed Direction** to **[2] Both directions**.

Option	Name	Description
[0]*	Shortest	The drive selects the rotation direction that provides the shortest route to the target position.
[1]	Forward	Move to the target position in the forward direction.
[2]	Reverse	Move to the target position in the reverse direction.
[3]	Direction	The forward/reverse signal on a digital input or fieldbus determines the rotation direction.

17-95 Offset Execution Distance

Default value:	0 AbsolutePositionUnit	Parameter type:	Range, 0 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.9X.

With the dynamic offset feature, it is possible to distribute execution of relative master offset and marker correction while synchronizing over a specific distance instead of using Ramp 1 (parameter group **3-4* Ramp 1**) and parameter **3-28 Master Offset Speed Ref**. With this feature, an offset execution profile is calculated based on:

- Offset execution distance
- Parameter **4-24 Max Speed**
- Actual master speed
- Parameter **7-99 Min Ramp Time**

The offset execution distance can be related to the distance traveled by the master or the follower, selected in parameter **17-96 Execution Distance Relation**. The execution distance relation is automatically extended if required due to speed/ramp limitation. This situation can be signaled in the fieldbus status word by selecting **[22] Execution distance extended** in parameter **8-13 Configurable Status Word STW**.

17-96 Execution Distance Relation

Default value:	[0] Master related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.9X.

Select whether the value set in parameter **17-95 Offset Execution Distance** is related to the distance traveled by the master or by the follower.

Option	Name	Description
[0]*	Master related	Offset execution is distributed over the offset execution distance traveled by the master.
[1]	Follower related	Offset execution is distributed over the offset execution distance traveled by the follower.

17-97 Number of CAM Cycles

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.96 and newer.

Set the number of CAM cycles which is executed by the **Activate CAM cycles** signal on a digital input or fieldbus control word bit.

17-98 CAM Cycles Start Delay

Default value:	0 AbsolutePositionUnit	Parameter type:	Range, 0 - 2147483647 AbsolutePositionUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.96 and newer.

Set a delay in absolute position units for the **Activate CAM cycles** signal.

6.19 Parameter Group 18-** Data Readouts 2

6.19.1 18-0* Maintenance Log



NOTE:

The following parameters are only available in FC 302:

- Parameter **18-00 Maintenance Log: Item**
- Parameter **18-01 Maintenance Log: Action**
- Parameter **18-02 Maintenance Log: Time**
- Parameter **18-03 Maintenance Log: Date and Time**

This parameter group contains the last 10 preventive maintenance events. Maintenance log 0 is the latest and maintenance log 9 is the oldest. By selecting 1 of the logs and pressing [OK], the maintenance item, action, and time of the occurrence are shown in parameter **18-00 Maintenance Log: Item** – parameter **18-03 Maintenance Log: Date and Time**.

The alarm log key allows access to both alarm log and maintenance log.

18-00 Maintenance Log: Item

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

Shows the fault code. See the different maintenance items in parameter **23-10 Maintenance Item**.

18-01 Maintenance Log: Action

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

Shows the fault code. See the different maintenance actions in parameter **23-11 Maintenance Action**.

18-02 Maintenance Log: Time

Default value:	0 s	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Shows when the logged event occurred. Time is measured in s since last power-up.

18-03 Maintenance Log: Date and Time

Default value:	Size related	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

Shows when the logged event occurred.



NOTE: For this parameter to show the time of the logged event, date and time must be programmed in parameter **0-70 Date and Time**.

Date format depends on the setting in parameter **0-71 Date Format**, while the time format depends on the setting in parameter **0-72 Time Format**.



NOTE: The drive has no back-up of the clock function. The set date/time resets to default (2000-01-01 00:00) after a power-down unless a real-time clock module with back-up is installed. In parameter **0-79 Clock Fault**, it is possible to program a warning in case the clock has not been set properly, for example after a power-down. Incorrect setting of the clock affects the time stamps for the maintenance events.



NOTE: When mounting a VLT® Analog I/O MCB 109 option card, a battery back-up of date and time is included.

18-04 Mech Brake Count

Default value:	0	Parameter type:	Readout

Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Number of times the mechanical brake has been engaged.

6.19.2 18-1* Emergency Mode Log

The emergency log covers operation of emergency mode with start and stop activities and if critical alarms are suppressed during emergency mode. The log contains the 10 latest activations of emergency mode or the alarm number of the critical alarm that was suppressed as this affects the warranty of the drive. Suppressed alarm numbers are stored and can only be reset by a Danfoss service inspection.

18-10 Emergency Mode Log: Event

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

This parameter contains an array with 10 elements. The number read represents a fault code, which corresponds to a specific alarm. Refer to *Alarm/Warning Code List* in *chapter Troubleshooting*.

18-11 Emergency Mode Log: Time

Default value:	0 s	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

This parameter shows at which time the logged event occurred. Time is measured in seconds since the drive was started.

18-12 Emergency Mode Log: Date and Time

Default value:	Size related	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

This parameter shows at which date and time the logged event occurred. The date and time rely on the internal clock in parameter group 0-7* *Clock Settings*.

6.19.3 18-1* Parameter Log

18-13 Parameter Number

Default value:	0 N/A	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Shows the parameter which is most recently changed. Index 0 shows the latest change in the parameter.

18-14 Parameter Index

Default value:	0 N/A	Parameter type:	Readout, Array [10]

Setup:	All setups	Conversion index:	–
Data type:	Uint16	Change during operation:	False

This parameter shows the index of the parameter which was changed.

18-15 Change Time

Default value:	Size related	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

Shows the date and time stamp when a parameter was most recently changed. It is recommended to set the time and date in the drive to ensure the right time is logged.

18-16 Operating Hours

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Shows operating hours of the drive at the instance when the parameter was changed.

18-17 Running Hours

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

Shows running hours of the motor when the parameter is changed.

18-18 Value Before Change as Integer

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

Shows the previous value of the parameter as integer, without scaling or unit conversion. The parameter only shows integer data.

18-19 Value Before Change

Default value:	Size related	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[30]	Change during operation:	False

Shows the previous value of the parameter with units. Only applicable for integer values.

6.19.4 18-2* Motor Readouts

This parameter group contains more references and feedback readouts including Safe Option speeds.

18-20 Commanded Position

Default value:	0 AbsolutePositionUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X and newer.

Shows the position reference for the position PI controller which is calculated every millisecond by the profile generator. Commanded position in position units as defined in parameter group **17-0* Position Scaling**.

18-21 Master Position

Default value:	0 AbsolutePositionUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X or newer.

Shows the actual master position based on the source selected in parameter **3-16 Reference Resource 2**. Master position is converted to follower position units by the master scale set in parameter **3-22 Master Scale Numerator** and parameter **3-23 Master Scale Denominator**.

18-23 Virtual Master Pos.

Default value:	0 AbsolutePositionUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.4X or newer.

Shows the current virtual master position which is calculated by the virtual master profile generator. Virtual master position in position units as defined in parameter group **17-0* Position Scaling**. Virtual master position is converted to follower position units by the master scale set in parameter **3-22 Master Scale Numerator** and parameter **3-23 Master Scale Denominator**.

18-24 Marker Pos. Offset

Default value:	0 AbsolutePositionUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.8X or newer.

Shows the position difference between master marker and follower marker in position units as defined in parameter group **17-0* Position Scaling**. The value is calculated by: Marker Pos. Offset = Master marker position – Follower marker position.

18-25 Latched Actual Pos.

Default value:	0 AbsolutePositionUnit	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.8X or newer.

Shows the actual position latched by the latest detected sensor, that is home sensor, touch sensor, or follower marker.

18-26 Actual Velocity [pu/s]

Default value:	0 pu/s	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.8X or newer.

Shows the actual speed in position units per second.

18-27 Safe Opt. Speed

Default value:	0 RPM	Parameter type:	Range, -30000 - 30000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Int32	Change during operation:	True

Shows the speed that the drive estimates and sends to the VLT® Safety Option MCB 15X.

Parameter 18-28 Safe Opt. Meas. Speed

Default value:	0 RPM	Parameter type:	Range, -30000 - 30000 RPM
Setup:	All setups	Conversion index:	67
Data type:	Int32	Change during operation:	True

Shows the speed measured by the VLT® Safety Option MCB 15X.

18-29 Safe Opt. Speed Error

Default value:	0 RPM	Parameter type:	Range, -30000 - 30000 RPM
Setup:	All setups	Conversion index:	67
Data type:	In t32	Change during operation:	True

Shows the difference between the speed measured by the VLT® Safety Option MCB 15X and the speed estimated by the drive.

6.19.5 18-3* Analog Readouts

Parameters in this group show data related to analog inputs.

18-36 Analog Input X48/2 [mA]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

View the actual current measured at input X48/2.

18-37 Temp. Input X48/4

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

View the actual temperature measured at input X48/4. The temperature unit is based on the selection in parameter **35-00 Term. X48/4 Temperature Unit**.

18-38 Temp. Input X48/7

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

View the actual temperature measured at input X48/7. The temperature unit is based on the selection in parameter **35-02 Term. X48/7 Temperature Unit**.

18-39 Temp. Input X48/10

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

View the actual temperature measured at input X48/10. The temperature unit is based on the selection in parameter **35-04 Term. X48/10 Temperature Unit**.

6.19.6 18-4* PGIO Data Readouts



NOTE:

The following parameters are only available in FC 302:

- Parameter **18-40 Analog Input X49/1**
- Parameter **18-41 Analog Input X49/3**
- Parameter **18-42 Analog Input X49/5**
- Parameter **18-46 X49 Digital Output [bin]**

This parameter group contains parameters for configuring the readout of VLT® Programmable I/O MCB 115.

18-40 Analog Input X49/1

Default value:	0	Parameter type:	Readout

Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False

View the actual value at input X49/1 either as a voltage, current or a temperature value.

18-41 Analog Input X49/3

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False

View the actual value at input X49/3 either as a voltage, current, or a temperature value.

18-42 Analog Input X49/5

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	False

View the actual value at input X49/5 either as a voltage, current, or a temperature value.

18-43 Analog Input X49/7

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	False

Shows the actual value at output of terminal X49/7 in V or mA. The value reflects the selection in parameter **36-40 Terminal X49/7 Analog Output**.

18-44 Analog Input X49/9

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	False

Shows the actual value at output of terminal X49/9 in V or mA. The value reflects the selection in parameter **36-50 Terminal X49/9 Analog Output**.

18-45 Analog Input X49/11

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	False

Shows the actual value at output of terminal X49/11 in V or mA. The value reflects the selection in parameter **36-60 Terminal X49/11 Analog Output**.

18-46 X49 Digital Output [bin]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	False

Shows the binary value of all programmable I/O digital outputs.

6.19.7 18-4* Last Warning

18-47 Last Warning

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

This parameter shows which was the latest warning.

18-48 Last Warning Count

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

This parameter shows how many times the last warning has been active.

6.19.8 18-5* Active Alarms/Warnings

The parameters in this group show the number of currently active alarms or warnings.

18-55 Active Alarm Numbers

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

This parameter contains an array of up to 20 alarms that are currently active. The value 0 means no alarm.

18-56 Active Warning Numbers

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

This parameter contains an array of up to 20 warnings that are currently active. The value 0 means no warning.

6.19.9 18-6* Inputs & Outputs 2

18-60 Digital Input 2

Default value:	0	Parameter type:	Readout

Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Shows the signal states from the active digital inputs.

- 0 = No signal
- 1 = Connected signal

6.19.10 18-6* Motor Status 2

18-64 Power Based Speed Limit

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

When [3] *Calculate speed limit* is selected as power limit function in parameter **4-80 Power Limit Func. Motor Mode** or parameter **4-81 Power Limit Func. Generator Mode**, the speed limit is calculated during ramp up based on power limit value and actual torque. This readout shows which speed can be reached with the actual load.

18-65 AMA Status

Default value:	[0] AMA not performed	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter shows the latest AMA execution status.

Index	Name
[0]*	AMA not performed
[1]	AMA running
[2]	AMA interrupted
[3]	AMA complete

18-66 Actual Switching Frequency

Default value:	0 kHz	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

View the actual switching frequency value. The value may differ from the value set in parameter **14-01 Switching Frequency** due to internal derating.

6.19.11 18-6* Diagnosis Readout 2

18-67 Alarm Word 4

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0

Data type:	Uint32	Change during operation:	False

View alarm word 4 as a hexadecimal value.

18-68 Warning Word 4

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

View warning word 4 as a hexadecimal value.

6.19.12 18-7* Rectifier Status



NOTE: This parameter group is only available in FC 302.

18-70 Mains Voltage

Default value:	0 V	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter shows the mains line-to-line voltage.

Index	Name
[0]	Average
[1]	Phase R to S
[2]	Phase S to T
[3]	Phase T to R

18-71 Mains Frequency

Default value:	0 Hz	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	True

Shows the mains frequency.

18-72 Mains Imbalance

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Shows the maximum imbalance for the 3 mains line-to-line measurements.

18-73 Worst Inrush

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter identifies which active inrush produces the data shown in parameter **18-70 Mains Voltage**, parameter **18-71 Mains Frequency**, parameter **18-72 Mains Imbalance**, and parameter **18-75 Rectifier DC Volt**. 1 = inrush 1, 2 = inrush 2, and so on.

18-74 Inrush Mode

Default value:	0	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter shows the reported mode of each inrush board. The values are:

- 0 = unknown
- 1 = inrush
- 2 = running

Index	Name
[0]	Inrush1
[1]	Inrush2
[2]	Inrush3
[3]	Inrush4

18-75 Rectifier DC Volt

Default value:	0 V	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the DC voltage measured on the rectifier module.

18-76 Mains Voltage 2

Default value:	0 V	Parameter type:	Readout, Array [16]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

View the mains line-to-line measurements. The values are RMS.

Index	Name
[0]	Inrush1 average
[1]	Inrush2 average
[4]	Inrush1 L1
[5]	Inrush2 L1

Index	Name
[8]	Inrush1 L2
[9]	Inrush2 L2
[12?]	Inrush1 L3
[13?]	Inrush2 L3

18-77 Mains Frequency 2

Default value:	0 Hz	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

View the mains frequency measurement.

Index	Name
[0]	Inrush1
[1]	Inrush2
[2]	Inrush3
[3]	Inrush4

18-78 Mains Imbalance 2

Default value:	0%	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

View the maximum measured imbalance for the 3 mains line-to-line measurements.

Index	Name
[0]	Inrush1
[1]	Inrush2
[2]	Inrush3
[3]	Inrush4

18-79 Rectifier DC Volt. 2

Default value:	0 V	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

View the DC voltage measurement from the rectifier module.

Index	Name
[0]	Inrush1
[1]	Inrush2

Index	Name
[2]	Inrush3
[3]	Inrush4

6.19.13 18-8* General Status

18-86 Service Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

View the service word configuration from the drive in hex code.

18-89 Mode of Operation Display

Default value:	[0] No mode change	Parameter type:	Option
Setup:	All setups	Conversion index_	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available with software version 48.8X.

Shows the active mode of operation which is selected in parameter *1-09 Mode of Operation*.

Option	Name	Description
[0]*	No mode change	
[1]	Profile position mode	
[2]	Velocity mode (vl)	
[6]	Homing mode	
[8]	Cyclic sync position mode	
[9]	Cyclic sync velocity mode	
[249]	Gear mode	
[250]	Cam mode	

6.19.14 18-9* PID Readouts

18-90 Process PID Error

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

Gives the present error value used by the process PID controller.

18-91 Process PID Output

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

Gives the present raw output value from the process PID controller.

18-92 Process PID Clamped Output

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

Gives the present output value from the process PID controller after the clamp limits have been observed.

18-93 Process PID Gain Scaled Output

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

Gives the present output value from the process PID controller after the clamp limits have been observed, and the resulting value has been gain scaled.

18-98 Expected Time to Ramp Down


Default value:	0.00 s	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	UInt16	Change during operation:	True

View the time it takes to ramp down to zero speed based on the ramp settings.

18-99 Speed Torque FF. [Nm]

Default value:	0 Nm	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Readout of the total command torque feed forward [Nm]. The parameter shows the sum of parameter **16-88 Fieldbus Torque FF** and parameter **1-69 Maximum Inertia** x parameter **7-08 Speed PID Feed Forward Factor**.



e30bk115:10

Figure 96: Torque Feed Forward Diagram

6.20 Parameter Group 19-** Application Parameters

Parameters in this group are available when VLT® Motion Control Option MCO 305 is installed in the drive. For more information about the option, refer to the VLT® Motion Control Option MCO 305 Operating Instructions.

6.21 Parameter Group 22-** Appl. Functions

6.21.1 22-0* Miscellaneous

22-00 External Interlock Delay

Default value:	0 s	Parameter type:	Range, 0 - 600 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the delay time for the external interlock command.

22-03 Start Command Delay

Default value:	0 ms	Parameter type:	Range, 0 - 100 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

This parameter is suited for lift applications and can be set to suppress contact bounce or delay the start command. Start will only be activated when the signal has been stable for the time set in this parameter. The function is active on digital input, FC port, and fieldbus options.

6.22 Parameter Group 23-** Time-based Functions

6.22.1 23-0* Timed Actions



NOTE: This parameter group is only available in FC 302.

Use timed actions for actions performed on a daily or weekly basis, for example different references for working hours/non-working hours. Up to 10 timed actions can be programmed in the drive. Select the timed action number from the list when entering parameter group 23-** **Time-based Functions** from the LCP. Parameter **23-00 ON Time** and **parameter 23-04 Occurrence** then refer to the selected timed action number. Each timed action is divided into an ON time and an OFF time, in which 2 different actions may be performed.

Display lines 2 and 3 in the LCP show the status for timed actions mode (parameter **0-23 Display Line 2 Large** and parameter **0-24 Display Line 3 Large**, setting **[1643] Timed Actions Status**).



NOTE: A change in mode via the digital inputs can only take place if parameter **23-08 Timed Actions Mode** is set to **[0] Times Actions Auto**. If commands are applied simultaneously to the digital inputs for constant OFF and constant ON, the timed actions mode changes to timed actions auto and the 2 commands are disregarded. If parameter **0-70 Date and Time** is not set or the drive is set to hand-on mode or OFF mode (for example via the LCP), the timed actions mode is changed to **[0] Disabled**. The timed actions have a higher priority than the same actions/commands activated by the digital inputs or the smart logic controller.

The actions programmed in timed actions are merged with corresponding actions from digital inputs, control word via bus, and smart logic controller, according to merge rules set up in parameter group **8-5* Digital/Bus**.



NOTE: Program the clock (parameter group **0-7* Clock Settings**) correctly for timed actions to function.



NOTE: The PC-based configuration tool VLT® Motion Control Tool MCT 10 comprises a special guide for easy programming of timed actions.

23-00 ON Time

Default value:	Size related	Parameter type:	Array [10]
Setup:	2 setups	Conversion index:	0
Data type:	TimeOfDayWoDate	Change during operation:	True

Sets the ON time for the desired action.



NOTE: The drive has no back-up of the clock function. The set date/time resets to default (2000-01-01 00:00) after a power-down unless a real-time clock module with back-up is installed. In parameter **0-79 Clock Fault**, it is possible to program a warning if the clock has not been set properly, for example after a power-down.

23-01 ON Action

Default value:	[0] Disabled	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: For options **[32] Set digital out A low**–**[43] Set digital out F high**, see also parameter group **5-3* Digital Outputs** and parameter group **5-4* Relays**.

Select the action during ON time. See parameter **13-52 SL Controller Action** for descriptions of the options.

Option	Name	Description
[0]*	Disabled	
[1]	No action	
[2]	Select set-up 1	
[3]	Select set-up 2	
[4]	Select set-up 3	
[5]	Select set-up 4	
[10]	Select preset ref 0	
[11]	Select preset ref 1	
[12]	Select preset ref 2	
[13]	Select preset ref 3	
[14]	Select preset ref 4	
[15]	Select preset ref 5	
[16]	Select preset ref 6	
[17]	Select preset ref 7	
[18]	Select ramp 1	
[19]	Select ramp 2	
[20]	Select ramp 3	
[21]	Select ramp 4	
[22]	Run	
[23]	Run reverse	
[24]	Stop	
[25]	Qstop	
[26]	Dcstop	
[27]	Coast	
[28]	Freeze output	
[29]	Start timer 0	
[30]	Start timer 1	
[31]	Start timer 2	
[32]	Set digital out A low	
[33]	Set digital out B low	
[34]	Set digital out C low	
[35]	Set digital out D low	
[36]	Set digital out E low	
[37]	Set digital out F low	
[38]	Set digital out A high	
[39]	Set digital out B high	
[40]	Set digital out C high	

Option	Name	Description
[41]	Set digital out D high	
[42]	Set digital out E high	
[43]	Set digital out F high	
[60]	Reset counter A	
[61]	Reset counter B	
[62]	Counter A (up)	
[63]	Counter A (down)	
[64]	Counter B (up)	
[65]	Counter B (down)	
[70]	Start timer 3	
[71]	Start timer 4	
[72]	Start timer 5	
[73]	Start timer 6	
[74]	Start timer 7	
[75]	Start timer 8	
[76]	Start timer 9	
[100]	Reset alarms	
[120]	Start homing	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[121]	Stop homing	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[122]	Enable reference	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[123]	Disable reference	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[124]	Relative position	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[125]	Absolute position	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[126]	Activate touch	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.

Option	Name	Description
[127]	Deactivte touch	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[128]	Target inverse	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[129]	Target	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[130]	Act. speed mode	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.
[131]	Deact. speed mode	 NOTE: This option is only available in FC 302 with IMC software version 48.5X or newer.

23-02 OFF Time

Default value:	Size related	Parameter type:	Array [10]
Setup:	2 setups	Conversion index:	0
Data type:	TimeOfDayWoDate	Change during operation:	True

Sets the OFF time for the desired action.



NOTE: The drive has no back-up of the clock function. The set date/time resets to default (2000-01-01 00:00) after a power-down unless a real-time clock module with back-up is installed. In parameter **0-79 Clock Fault**, it is possible to program a warning if the clock has not been set properly, for example after a power-down.

23-03 OFF Action

Default value:	[1] No action	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the action during OFF time. See parameter **13-52 SL Controller Action** for descriptions of the options.

Option	Name	Description
[1]*	No action	
[2]	Select set-up 1	
[3]	Select set-up 2	
[4]	Select set-up 3	
[5]	Select set-up 4	
[10]	Select preset ref 0	

Option	Name	Description
[11]	Select preset ref 1	
[12]	Select preset ref 2	
[13]	Select preset ref 3	
[14]	Select preset ref 4	
[15]	Select preset ref 5	
[16]	Select preset ref 6	
[17]	Select preset ref 7	
[18]	Select ramp 1	
[19]	Select ramp 2	
[20]	Select ramp 3	
[21]	Select ramp 4	
[22]	Run	
[23]	Run reverse	
[24]	Stop	
[25]	Qstop	
[26]	Dcstop	
[27]	Coast	
[28]	Freeze output	
[29]	Start timer 0	
[30]	Start timer 1	
[31]	Start timer 2	
[32]	Set digital out A low	
[33]	Set digital out B low	
[34]	Set digital out C low	
[35]	Set digital out D low	
[36]	Set digital out E low	
[37]	Set digital out F low	
[38]	Set digital out A high	
[39]	Set digital out B high	
[40]	Set digital out C high	
[41]	Set digital out D high	
[42]	Set digital out E high	
[43]	Set digital out F high	
[60]	Reset counter A	
[61]	Reset counter B	
[62]	Counter A (up)	
[63]	Counter A (down)	

Option	Name	Description
[64]	Counter B (up)	
[65]	Counter B (down)	
[70]	Start timer 3	
[71]	Start timer 4	
[72]	Start timer 5	
[73]	Start timer 6	
[74]	Start timer 7	
[75]	Start timer 8	
[76]	Start timer 9	
[100]	Reset alarms	
[120]	Start homing	
[121]	Stop homing	
[122]	Enable reference	
[123]	Disable reference	
[124]	Relative position	
[125]	Absolute position	
[126]	Activate touch	
[127]	Deactivate touch	
[128]	Target inverse	
[129]	Target	
[130]	Act. speed mode	
[131]	Deact. speed mode	

23-04 Occurrence

Default value:	[0] All days	Parameter type:	Option, Array [10]
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select which days the timed action applies to. Specify working/non-working days in:

- Parameter **0-81 Working Days**.
- Parameter **0-82 Additional Working Days**.
- Parameter **0-83 Additional Non-Working Days**.

Option	Name	Description
[0]*	All days	
[1]	Working days	
[2]	Non-working days	
[3]	Monday	

Option	Name	Description
[4]	Tuesday	
[5]	Wednesday	
[6]	Thursday	
[7]	Friday	
[8]	Saturday	
[9]	Sunday	
[10]	Day 1 of month	
[11]	Day 2 of month	
[12]	Day 3 of month	
[13]	Day 4 of month	
[14]	Day 5 of month	
[15]	Day 6 of month	
[16]	Day 7 of month	
[17]	Day 8 of month	
[18]	Day 9 of month	
[19]	Day 10 of month	
[20]	Day 11 of month	
[21]	Day 12 of month	
[22]	Day 13 of month	
[23]	Day 14 of month	
[24]	Day 15 of month	
[25]	Day 16 of month	
[26]	Day 17 of month	
[27]	Day 18 of month	
[28]	Day 19 of month	
[29]	Day 20 of month	
[30]	Day 21 of month	
[31]	Day 22 of month	
[32]	Day 23 of month	
[33]	Day 24 of month	
[34]	Day 25 of month	
[35]	Day 26 of month	
[36]	Day 27 of month	
[37]	Day 28 of month	
[38]	Day 29 of month	
[39]	Day 30 of month	
[40]	Day 31 of month	

6.22.2 23-0* Timed Actions Settings

23-08 Timed Actions Mode

Default value:	[0] Timed actions auto	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Enable and disable automatic timed actions.

Option	Name	Description
[0]*	Timed actions auto	Enable timed actions.
[1]	Timed actions disabled	Disable timed actions, normal operation according to control commands.
[2]	Constant on actions	Disable timed actions. Constant on actions are activated.
[3]	Constant off actions	Disable timed actions. Constant off actions are activated.

23-09 Timed Actions Reactivation

Default value:	[1] Enabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Disabled	After an update of: • power cycling • setting date • time • change of summertime • change of Hand Auto mode • change of Constant On and Off • setup change where all activated ON actions are overridden to OFF actions until passing the next time for an ON action. Any OFF actions remain unchanged.
[1]*	Enabled	After an update of time/condition On and OFF actions are immediately set to the actual time programming of ON and OFF actions.




Figure 97: Example of Reactivation Test

6.22.3 23-1* Maintenance

Wear and tear calls for periodic inspection and service of elements in the application, for example, motor bearings, feedback sensors, seals, and filters. With preventive maintenance, the service intervals may be programmed into the drive. The drive gives a message when maintenance is required. 20 preventive maintenance events can be programmed into the drive.

Specify the following for each event:

- Maintenance item (for example, motor bearings).
- Maintenance action (for example, replacement).
- Maintenance time base (for example, running hours or a specific date and time).
- Maintenance time interval or the date and time of the next maintenance.



TIP: To disable a preventive maintenance event, set the associated parameter **23-12 Maintenance Base** to **[0] Disabled**.

Preventive maintenance can be programmed from the LCP, but use the PC-based VLT® Motion Control Tool MCT 10 is recommended.

Untitled - MCT 10 SET - up Software						
File Edit View Insert Communication Tools OptionsHelp						
Network Project VLT AQUA DRIVE All Parameters Operation/Display Load/Motor Brakes Reference / Ramps Limits / Warnings Analog In/Out Comm. and Options Smart logic Special Functions Drive Information Data Readouts Info & Readouts Drive Closed Loop Ext. Closed Loop Application Functions Time-based Functions Timed Actions Maintenance Maintenance Reset Energy Log Trending Payback Counter Cascade Controller Water Application Functions Cascade Controller						
ID	Name	Setup 1	Setup 2	Setup 3	Setup 4	
2310.0	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.1	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.2	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.3	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.4	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.5	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.6	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.7	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.8	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.9	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.10	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.11	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.12	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.13	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.14	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.15	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.16	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.17	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.18	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2310.19	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings	
2311.0	Maintenance Action	Lubricate	Lubricate	Lubricates	Lubricate	
2311.2	Maintenance Action	Lubricate	Lubricate	Lubricates	Lubricate	
2311.3	Maintenance Action	Lubricate	Lubricate	Lubricates	Lubricate	
2311.4	Maintenance Action	Lubricate	Lubricate	Lubricates	Lubricate	
2311.5	Maintenance Action	Lubricate	Lubricate	Lubricates	Lubricate	
2311.6	Maintenance Action	Lubricate	Lubricate	Lubricates	Lubricate	

e30ba492.11

The LCP indicates (with a wrench icon and letter M) when it is time for preventive maintenance action and can be programmed to be indicated on a digital output in parameter group 5-3* **Digital Outputs**. The preventive maintenance status is shown in parameter **16-96 Maintenance Word**. A preventive maintenance indication can be reset from a digital input, the FC bus, or manually from the LCP through parameter **23-15 Reset Maintenance Word**.



NOTE: The preventive maintenance events are defined in a 20-element array. Hence, each preventive maintenance event must use the same array element in parameter **23-10 Maintenance Item** to parameter **23-14 Maintenance Date and Time**.

23-10 Maintenance Item

Default value:	[1] Motor bearings	Parameter type:	Option, Array [6]
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Array with 20 elements shown below the parameter number in the display. Press [OK] and step between elements with [◀], [▶], [▲], and [▼]. Select the item to be associated with the preventive maintenance event.

Option	Name	Description
[1]*	Motor bearings	
[11]	Drive cooling fan	
[12]	System health check	
[13]	Warranty	
[14]	Mech brake	
[20]	Maintenance text 0	
[21]	Maintenance text 1	
[22]	Maintenance text 2	

Option	Name	Description
[23]	Maintenance text 3	
[24]	Maintenance text 4	
[25]	Maintenance text 5	
[26]	Service log full	

23-11 Maintenance Action

Default value:	[1] Lubricate	Parameter type:	Option, Array [6]
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the action to be associated with the preventive maintenance event.

Option	Name	Description
[1]*	Lubricate	
[2]	Clean	
[3]	Replace	
[4]	Inspect/check	
[5]	Overhaul	
[6]	Renew	
[7]	Check	
[20]	Maintenance text 0	
[21]	Maintenance text 1	
[22]	Maintenance text 2	
[23]	Maintenance text 3	
[24]	Maintenance text 4	
[25]	Maintenance text 5	
[28]	Clear logs	

23-12 Maintenance Base

Default value:	–	Parameter type:	Option, Array [6]
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the time base to be associated with the preventive maintenance event.

Option	Name	Description
[0]	Disabled	Disables the preventive maintenance event.
[1]	Running hours	The number of hours the motor has run. Running hours are not reset at power-on. Specify the maintenance time interval in parameter 23-13 Maintenance Interval .

Option	Name	Description
[2]	Operating hours	The number of hours the drive has run. Operating hours are not reset at power-on. Specify the maintenance time interval in parameter 23-13 Maintenance Interval .
[3]	Date & time	Uses the internal clock. Specify the date and time of the next maintenance occurrence in parameter 23-14 Maintenance Date and Time .
[4]	No of counts	

23-13 Maintenance Interval

Default value:	1	Parameter type:	Array [6]
Setup:	1 setup	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Set the interval associated with the current preventive maintenance event. This parameter is only used if **[1] Running Hours** or **[2] Operating Hours** is selected in parameter **23-12 Maintenance Base**. The timer is reset in parameter **23-15 Reset Maintenance Word**.

23-14 Maintenance Date and Time

Default value:	Size related	Parameter type:	Array [6]
Setup:	1 setup	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

Set the date and time for the next maintenance occurrence if the preventive maintenance event is based on date/time. Date format depends on the setting in parameter **0-71 Date Format** while the time format depends on the setting in parameter **0-72 Time Format**.



NOTE: The drive has no back-up of the clock function. The set date/time is reset to default (2000-01-01 00:00) after a power-down. In parameter **0-79 Clock Fault**, it is possible to program a warning if the clock has not been set properly, for example after a power-down. Set the time at least 1 hour later than actual time.



NOTE: When mounting a VLT® Analog I/O option MCB 109 option card, a battery back-up of the date and time is included.

6.22.4 23-1* Maintenance Reset

23-15 Reset Maintenance Word

Default value:	[0] Do not reset	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: When messages are reset, maintenance item, action, and maintenance date/time are not canceled. Parameter **23-12 Maintenance Time Base** is set to **[0] Disabled**.

Set this parameter to **[1] Do reset** to reset the maintenance word in parameter **16-96 Maintenance Word** and reset the message shown in the LCP. This parameter changes back to **[0] Do not reset** when pressing [OK].

Option	Name	Description
[0]*	Do not reset	
[1]	Do reset	

23-16 Maintenance Text

Default value:	0	Parameter type:	Array [6]
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[20]	Change during operation:	True

6 individual texts (Maintenance Text 0...Maintenance Text 5) can be written for use in either parameter **23-10 Maintenance Item** or parameter **23-11 Maintenance Action**. The text is written according to the guidelines in parameter **0-37 Display Text 1**.

23-18 Reset Mechanical Brake Counter

Default value:	[0] Do not reset	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Do not reset	Select this option to disable the reset of the mechanical brake counter.
[1]	Do reset	Select this option to enable the reset of the mechanical brake counter. After resetting the mechanical brake counter, the parameter is set to [0] Do not reset , which is the default option.

6.23 Parameter Group 24-** Application Functions 2

6.23.1 24-0* Emergency Mode



NOTE: The drive is only 1 component of an entire application system. Correct function of emergency mode depends on the correct design and selection of system components. Non-interruption of the drive due to emergency-mode operation could cause overpressure and damage the system and components. The drive itself could be damaged, or may cause damage or fire. Danfoss accepts no responsibility for errors, malfunctions, personal injury, or any damage to the drive itself or the components herein, application systems and components herein, or other property when the drive has been programmed for emergency mode. In no event shall Danfoss be liable to the end user or any other party for any direct or indirect, special, or consequential damage, or loss suffered by such party, which has occurred due to the drive being programmed and operated in emergency mode. Danfoss warranty is only affected or reduced if a critical alarm occurs during emergency-mode operation, and the drive is programmed to continue even though the application system would be damaged eventually.

If critical alarms have been activated during emergency mode operation, the drive informs the user that its performance and expected lifetime may be affected (*W280*), where an inspection of the drive may be needed to secure maximum operation in a new critical situation.

Background

Emergency mode is for use in critical situations where it is imperative for the motor to keep running, regardless of the normal protective functions of the drive. These situations could be ventilation fans in tunnels or stairwells, for instance, where continued operation of fan facilitates safe evacuation of personnel and protection of inventory if a fire occurs. Some selections of the emergency-mode function cause alarms and trip conditions to be disregarded, enabling the motor to run without interruption.

Activation

Emergency mode can be activated via digital input and/or over the fieldbus network. In digital activation, normal or inverse signals levels can be selected as continual fixed signals or as trigger pulse activation to fit the overall fire control system. It can operate in open loop with up to 8 different preset speeds or in closed loop with an external signal reference and feedback source. See parameter group **5-1* Digital Inputs** and parameter **24-43 Emergency Mode Signal Operation**.

Messages in display

When emergency mode is activated, the display shows a status message *Emergency Mode* and a warning *Emergency Mode*. Once the emergency mode is deactivated, the status messages disappear and the warning is replaced by the warning *Emergency M Was Active*.

Digital and relay outputs can be configured for the status emergency mode messages, see parameter group **5-3* Digital Outputs** and parameter group **5-4* Relays**. Emergency mode messages can also be accessed in the warning word via serial communication (see relevant documentation). Access the status messages *Emergency Mode* via the extended status word.

Table 56: Messages in Display

Messages	Type	LCP	Messages in display	Alarm word 1–3	Warning word 2	Warning word 3	Ext. status word 2
<i>W200 Emergency Mode</i>	Warning	+	+	–	–	+ (bit 7)	+ (bit 25)
<i>W201 Emerg. M Was Active</i>	Warning	+	+	–	+ (bit 3)	+ (bit 8)	–
<i>W202 Emerg. M Limits Exceeded</i>	Alarm (log)	+	+	–	–	+ (bit 9)	+ (bit 27)
<i>W280 Emcy M Service Warning</i>	Alarm (log)	+	+	–	–	+ (bit 10)	–
<i>W281 Emcy OPR unexpected</i>	Warning	+	+	–	–	+ (bit 11)	–

Log

To see an overview of the emergency mode-related events, view the emergency mode log, parameter group **18-1* Emergency Mode Log**, or press *[Alarm Log]* on the LCP. The log includes up to 10 of the latest events. Warranty-affecting alarms have a higher priority than the other 2 types of events.

The emergency mode alarm log can only be reset by a Danfoss authorized service partner. To secure the emergency mode operation documentation, the 1st critical alarms can never be removed.

The following events are logged:

- W200 - Emergency mode.
- W201 - Emerg. M mode was act. (deactivated).
- W202 - Emerg. M limits exceeded covered by the activated critical alarm number.
- (W280) - Emcy M service warning - service is needed.

- (W281) - Emcy OPR unexpected - emergency mode does not work as expected.

All alarms are logged as usual, and critical emergency mode alarms are logged in the emergency mode log in parameter group **18-1*** *Emergency Mode Log*.



NOTE: During emergency-mode operation, all stop commands to the drive are ignored, including coast/coast inverse and external interlock. The keypad is also locked during emergency mode to prevent user interference during operation of the safety system. However, if Safe Torque Off is available in the drive, this function is still active.



NOTE: Emergency mode has a special live zero function for handling lost analog signal inputs used for emergency mode setpoint/feedback, for example, for handling a burnt cable. How emergency mode should continue in these live zero situations is configured in parameter **6-02 Emergency Mode Live Zero Timeout Function**. If live zero is activated, *Emergency mode not working as expected* is activated so that a redundant system can take over or a setup change can be activated. A warning for live zero has a higher priority than the warning *Emergency mode* and will replace that information in the display.



NOTE: If setting the command [11] *Start Reversing* on a digital input terminal in parameter **5-10 Terminal 18 Digital Input**, the drive understands this as a reversing command.

24-00 Emergency Mode Function

Default value:	[0] Disabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: Alarms are produced or ignored in accordance with the selection in parameter **24-09 Emergency Mode Alarm Handling**.

Option	Name	Description
[0]*	Disabled	The emergency-mode function is not active.
[1]	Enabled-run forward	In this mode, the motor continues to operate in a clockwise direction. Works only in open loop. Set parameter 24-01 Emergency Mode Configuration to [0] <i>Open Loop</i> .
[2]	Enable-run reverse	In this mode, the motor continues to operate in a counterclockwise direction. Works only in open loop. Set parameter 24-01 Emergency Mode Configuration to [0] <i>Open Loop</i> .
[3]	Enabled-coast	In this mode, the output is disabled, and the motor is allowed to coast to stop.
[4]	Enable-run Fwd/Rev	
[8]	Alarm suppression	In this mode, the drive continues operation as normal, meaning on standard parameters and control operation, but where the alarms are suppressed as in normal emergency mode. The emcy LCP information and status word is updated as the emergency mode operation is logged in the emergency mode log.

24-01 Emergency Mode Configuration

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: Before adjusting the PID controller, set parameter **24-09 Emergency Mode Alarm Handling** to **[9] Trip, all alarms/test**.



NOTE: If **[2] Enable-run reverse** is selected in parameter **24-00 Emergency Mode Function**, **[3] Closed loop** cannot be selected in parameter **24-01 Emergency Mode Configuration**.

The emergency mode can be controlled in open loop with up to 8 different preset values (zones), or in closed loop by a reference and feedback signal. The reference and feedback signal can come via drive input signals or over the fieldbus.

Option	Name	Description
[0]	Speed open loop	When emergency mode is active, the motor runs with a fixed speed based on a reference set. The unit is the same as selected in parameter 0-02 Motor Speed Unit .
[1]	Speed closed loop	When emergency mode is active, the built-in PID controller controls the speed based on the setpoint and a feedback signal selected in parameter 24-07 Emergency Mode Feedback Source . Select the unit in parameter 24-02 Emergency Mode Unit . For PID controller settings, use parameter group 20-** FC Closed Loop as for normal operation. The same PID configuration can be selected for both normal and emergency mode, and the operation can be continued as setup 1–4.
[3]	Process	

24-02 Emergency Mode Unit

Default value:	Size related	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

By default, emergency mode is configured for open-loop control where only the motor unit is selected in parameter **0-02 Motor Speed Unit**. For closed-loop operation, select any of the following options.

Option	Name	Description
[0]	None	
[1]	%	
[2]	RPM	
[3]	Hz	
[4]	Nm	
[5]	PPM	

Option	Name	Description
[10]	1/min	
[11]	RPM	
[12]	Pulse/s	
[20]	l/s	
[21]	l/min	
[22]	l/h	
[23]	m ³ /s	
[24]	m ³ /min	
[25]	m ³ /h	
[30]	kg/s	
[31]	kg/min	
[32]	kg/h	
[33]	t/min	
[34]	t/h	
[40]	m/s	
[41]	m/min	
[45]	m	
[60]	°C	
[70]	mbar	
[71]	bar	
[72]	Pa	
[73]	kPa	
[74]	m WG	
[80]	kW	
[120]	GPM	
[121]	gal/s	
[122]	gal/min	
[123]	gal/h	
[124]	CFM	
[125]	ft ³ /s	
[126]	ft ³ /min	
[127]	ft ³ /h	
[130]	lb/s	
[131]	lb/min	
[132]	lb/h	
[140]	ft/s	

Option	Name	Description
[141]	ft/min	
[145]	ft	
[150]	lb ft	
[160]	°F	
[170]	psi	
[171]	lb/in ²	
[172]	in WG	
[173]	ft WG	
[176]	kpsi	
[177]	MPa	
[178]	kBar	
[180]	HP	

24-03 Emergency Mode Min Reference

Default value:	Size related	Parameter type:	Range, -999999.999 - par. 24-04 EmergencyModeMaxReference
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

The minimum value to the reference/setpoint (limiting the sum of values in parameter **24-05 Emergency Mode Preset Reference** and value of signal on input selected in parameter **24-06 Emergency Mode Reference Source**). If running in open loop when emergency mode is active, the unit is selected by the setting parameter **0-02 Motor Speed Unit**. For closed loop, select the unit in parameter **24-02 Emergency Mode Unit**.

24-04 Emergency Mode Max Reference

Default value:	Size related	Parameter type:	Range, par. 24-03 - 999999.999 EmergencyModeMinReference
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

This parameter defines the maximum speed reference which the emergency mode can operate to, although the motor limits in parameter **4-10 Motor Speed Direction** have the highest priority. This maximum value is also used as reference value for the 8 preset values calculations in %. If running in open loop when emergency mode is active, the unit is selected by setting parameter **0-02 Motor Speed Unit**. For closed loop, select the unit in parameter **24-02 Emergency Mode Unit**.

24-05 Emergency Mode Preset Reference

Default value:	0%	Parameter type:	Array [8]
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

A parameter array with 8 elements (0–7). The 8 present values (zones) are for open-loop control. Index [0] is used for basic emergency mode control. Indexes 1–7 are used to enhance emergency mode control, which also overwrites the basic control. More reference value can be added via parameter group **24-** Application Functions 2**.

24-06 Emergency Mode Reference Source

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the external reference input to be used for emergency mode. In open-loop mode, this signal value is added to the preset values in parameter **24-05 Emergency Mode Preset Reference**. There may be a different units scaling between preset and external values.

Option	Name	Description
[0]*	No function	
[1]	Analog input 53	
[2]	Analog input 54	
[7]	Pulse input 29	 NOTE: This option is only available in FC 302.
[8]	Pulse input 33	
[11]	Local bus reference	Serial inputs from internal COM interfaces.
[20]	Digital pot.meter	
[21]	Analog input X30/11	
[22]	Analog input X30/12	
[37]	Analog input X49/1	
[38]	Analog input X49/3	
[39]	Analog input X49/5	
[133]	Fieldbus REF 1	A reference value can also come via selected fieldbus.

24-07 Emergency Mode Feedback Source

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

In emergency mode closed-loop operation, feedback is requested for the internal PID controller. Select the feedback input to be used for the feedback signal.

Option	Name	Description
[0]*	No function	
[1]	Analog input 53	
[2]	Analog input 54	
[3]	Frequency input 29	 NOTE: This option is only available in FC 302.

Option	Name	Description
[4]	Frequency input 33	
[7]	Analog input X30/11	
[8]	Analog input X30/12	
[16]	Analog input X49/1	
[17]	Analog input X49/3	
[18]	Analog input X49/5	
[99]	Normal feedback	

24-09 Emergency Mode Alarm Handling

Default value:	[0] Trip+reset, critical alarms	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: Warranty-affecting alarms. Certain alarms can affect the lifetime of the drive. Should 1 of these ignored alarms occur while in emergency mode, the alarms are logged and stored in the emergency-mode log.



NOTE: The setting in parameter **14-20 Reset Mode** is disregarded if emergency mode is active (see parameter group **24-0* Emergency Mode**).

Select an option to define the response to alarms when emergency mode is active and an alarm is issued.

Option	Name	Description
[0]*	Trip+reset, critical alarms	Alarms are ignored even though damage may be caused, except for the critical alarms mentioned in the following table. When these alarms occur, the drive trips immediately, followed by an automatic reset and restarts even if the operation leads to an infinite loop of trip and restart.
[1]	Trip, critical alarms	Alarms are ignored even though damage may be caused, except for the critical alarms mentioned in the following table. For the critical alarms, a trip is caused. A manual reset is required before restart. A manual restart requires disabling emergency mode and enabling emergency mode again.
[2]	Trip, all alarms/test	Option for testing emergency mode operation without compromising the normal handling of warnings and alarms. All alarms are handled as normally defined in the Warning/Alarm Code List in the chapter <i>Troubleshooting</i> .

Table 57: Emergency Mode Alarm Handling

Alarm number	Description	Emergency mode alarm handling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip.			Warranty-affecting alarms in emergency mode
		[0] Trip+reset	[1] Trip	[2] Test	
4	Mains phase loss	Ignore	Ignore	(Warning/trip)	X
7	DC voltage high	Trip+reset	Trip	Warning/trip	
8	DC voltage low	Trip+reset	Trip	Warning/trip	
9	Inverter overld.	Ignore	Ignore	(Warning/trip)	X
13	Over current	Trip+reset	Trip	(Warning/trip/trip lock)	
14	Ground fault	Trip+reset	Trip	(Warning/trip/trip lock)	
16	Short circuit	Trip+reset	Trip	(Trip/trip lock)	
29	Power module temp	Ignore	Ignore	(Warning/trip/trip lock)	X
33	Inrush fault	Ignore	Ignore	Trip/trip lock	X
38	Internal fault	Ignore	Ignore	Trip/trip lock	X
39	Heatsink sensor	Ignore	Ignore	(Trip/trip lock)	X
45	Ground fault 2	Ignore	Ignore		
65	Ctrl. card temp	Ignore	Ignore	Warning/trip/(trip lock)	X
68	Safe stop	Trip	Trip	Trip	
69	Pwr card temp.	Ignore	Ignore	Trip/(trip lock)	X
79	Illegal PS config	Ignore	Ignore		
101	Speed monitor (FC 302)	Ignore	Ignore		
200	Emergency mode	Ignore	Ignore		
201	Emerg. M was active	Ignore	Ignore		
202	Emerg. M limits exceeded	Ignore	Ignore		
244	Heatsink temp	Ignore	Ignore	(Trip/trip lock)	X
245	Heatsink sensor	Ignore	Ignore	(Trip/trip lock)	X
247	Pwr.card temp	Ignore	Ignore	(Trip/trip lock)	X
280	Emergency m service warning	Ignore	Ignore		
281	Emcy OPR unexpected	Ignore	Ignore		

6.23.2 24-4* Emergency Mode 2

Configure the ramp parameters for emergency mode:

- Ramp type

- Ramping times (duration of acceleration and deceleration)
- Level of jerk compensation for S-ramps

Start by setting the linear ramping times corresponding to [Figure 98](#) and [Figure 99](#).




Figure 98: Linear Ramping Times

If S-ramps are selected, set the level of non-linear jerk compensation required. Set jerk compensation by defining the proportion of ramp-up and ramp-down times where acceleration and deceleration are variable (that is, increasing or decreasing). The S-ramp acceleration and deceleration settings are defined as a percentage of the actual ramp time.




Figure 99: Non-linear Ramping Times

24-40 Emergency Mode Ramp Up Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

This ramp time is used for acceleration while emergency mode is active.

24-41 Emergency Mode Ramp Down Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Changes during operation:	True

This ramp time is used for deceleration while emergency mode is active.

24-42 Timeout for Emergency Mode Test

Default value:	10 min	Parameter type:	Range, 1 - 60 min
Setup:	All setups	Conversion index:	70
Data type:	Uint8	Change during operation:	True

A digital impulse triggers the emergency mode operation with stop on all alarms as option **[2] Trip, all alarms/test** in parameter **24-09 Emergency Mode Alarms Handling**. This test impulse signal can only activate 1 test time period and the normal emergency mode operation takes over as soon as the test time ends, or it stops the test period if the emergency mode signal disappears. Only "normal high impulse" signals can trigger the test timer and test information is included in the LCP and status word, as emergency mode output "not operating as expected" is activated.

24-43 Emergency Mode Signal Operation

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: Ensure that the correct input selections and connections are in place as it is not possible to operation the LCP while emergency mode is activated.



NOTE: If signal handling is set to inverse, a low **[196] EM active** and a low **[197] EM was active** indicate that the drive is off or power cycling, which can be used to activate a redundant system.

Select how emergency mode input and output signals are handled. Before changing this parameter, disable parameter **24-00 Emergency Mode Function**.

Option	Name	Description
[0]	Standard, active-high	Normal high input and output signals operate the emergency mode function as long as they are active (high).
[1]	Inverse, active-low	This option adds safety rules to ensure that emergency mode still operates if a signal is lost.
[2]	Impulse, set-reset	This option activates and stops the emergency mode operation on high signal impulse. Operation mode is defined and activated by selected input signals and is frozen 2 s after the 1st signal activation. Reset signal has the highest priority and is required to stop operation or switch to a new operation configuration. A valid signal impulse has to be active for minimum 2 s.



NOTE: LCP copy and software download only accept parameter changes if parameter **24-00 Emergency Mode** is set to **[0] Disabled**.

6.23.3 24-5* Digi CAM Switch A

24-50 Switch Source A

Default value:	[0] Actual position	Parameter type:	Option

Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.94 and newer.

Select the position source for activation of the digital CAM switch A. Digital CAM switch A can be assigned to a digital output using the selections *[100] Digi. CAM switch A* or *[101] Digi. CAM sw. A. inv..*

Option	Name	Description
[0]*	Actual position	
[1]	Commanded position	
[2]	Master position	
[3]	Vir. master position	

24-51 Axis Direction A

Default value:	[2] Both directions	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.94 or newer.

Select for which speed directions digital CAM switch A is to be active.

Option	Name	Description
[0]	Clockwise	Digital CAM switch A is only set when approaching the CAM switch position in clockwise direction.
[1]	Counter clockwise	Digital CAM switch A is only set when approaching the CAM switch position in counterclockwise direction.
[2]*	Both directions	Digital CAM switch A is set when approaching the CAM switch position in both directions.

24-52 First Position A

Default value:	0 AbsolutePositionUnit	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.94 or newer.

Select the 1st position defining the digital CAM switch A.

24-53 Last Position A

Default value:	0 AbsolutePositionUnit	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.94 or newer.

Select the last position defining the digital CAM switch A.

24-54 On Compensation A

Default value:	0 ms	Parameter type:	Range, 0 - 10000 ms
Setup:	All setups	Conversion index:	-3
Data type:	UInt16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.94 or newer.

Enables compensation for delay in the component switched by the digital CAM switch output. The drive calculates the distance it will move within the *On compensation* time based on the actual speed. The output will be switched on at this distance before the set first or last position.

24-55 Off Compensation A

Default value:	0 ms	Parameter type:	Range, 0 - 10000 ms
Setup:	All setups	Conversion index:	-3
Data type:	UInt16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.94 or newer.

Enables compensation for delay in the component switched by the digital CAM switch output. The drive calculates the distance is will move within the *off compensation* time based on the actual speed. The output will then be switched off at this distance before the set first or last position.

6.23.4 24-6* Digi. CAM Switch B



NOTE: This parameter group is only available in FC 302 with IMC software version 48.95 and newer.

24-60 Switch Source B

Default value:	[0] Actual position	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select the position source for activation of the digital CAM switch B. Digital CAM switch B can be assigned to a digital output using the selections **[102] Digi. CAM switch B** or **[103] Digi. CAM sw. B inv.**

Option	Name	Description
[0]*	Actual position	
[1]	Commanded position	
[2]	Master position	
[3]	Vir. master position	

24-61 Axis Direction B

Default value:	[2] Both directions	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select for which speed directions digital CAM switch B is to be active.

Option	Name	Description
[0]	Clockwise	Digital CAM switch B is only set when approaching the CAM switch position in clockwise direction.
[1]	Counter clockwise	Digital CAM switch B is only set when approaching the CAM switch position in counterclockwise direction.
[2]*	Both directions	Digital CAM switch B is set when approaching the CAM switch position in both direction.

24-62 First Position B

Default value:	0 AbsolutePositionUnit	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Select the 1st position defining the digital CAM switch B.

24-63 Last Position B

Default value:	0 AbsolutePositionUnit	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Select the last position defining digital CAM switch B.

24-64 On Compensation B

Default value:	0 ms	Parameter type:	Range, 0 - 10000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Enables compensation for delay in the component switched by the digital CAM switch output. The drive calculates the distance it will move within the *On compensation* time based on the actual speed. The output will be switched on at this distance before the set first or last position.

24-65 Off Compensation B

Default value:	0 ms	Parameter type:	Range, 0 - 10000 ms
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Enables compensation for delay in the component switched by the digital CAM switch output. The drive calculates the distance is will move within the *off compensation* time based on the actual speed. The output will then be switched off at this distance before the set first or last position.

6.23.5 24-7* Anti-sway Ramp

24-70 Min Ref. Change

Default value:	50 RPM	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.96 or newer.

Set the minimum reference change for using the anti-sway ramp. A linear ramp is used for speed references changes below the set value.

24-71 Rope Length

Default value:	5.00 m	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.96 or newer.

Set the length of the rope carrying the load. This is needed to calculate the anti-sway ramp profile. Alternatively, the period of swing can be set in parameter **24-72 Period of Swing**.

24-72 Period of Swing

Default value:	0.00 s	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.96 or newer.

Set the period of swing for the hanging load. This can be used to calculate the anti-sway ramp profile instead of parameter **24-71 Rope Length**, which is used when this parameter is set to 0.00.

24-73 Max Speed Change per Swing

Default value:	0 RPM	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only available in FC 302 with IMC software version 48.98 or newer.

With anti-oscillation ramp times, this parameter defines the maximum speed change within 1 swing period defined in parameter **24-72 Period of Swing**. The complete acceleration time is always a multiple of the swing periods. 0 means that the ramp time is 1 period of swing.

24-74 Notch Filter Bandwidth

Default value:	100%	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True



NOTE: This parameter only available in FC 302 with IMC software version 48.98 and newer.

When using Anti-Oscillation ramp types, there is a *Notch Filter* with a center frequency of $1/\text{Period of Swing}$ after the ramp generator. With 100% settings, the width of this filter corresponds to that center frequency.

6.24 Parameter Group 30-** Special Features

6.24.1 30-0* Wobble Function

The wobble function is primarily used for synthetic yarn winding applications. The wobble option is installed in the drive controlling the traverse drive. The yarn moves back and forth in a diamond pattern across the surface of the yarn package. To prevent a build-up of yarn at the same points at the surface, this pattern must be altered. The wobble option can accomplish this by continuously varying the traverse velocity in a programmable cycle. The wobble function is created by superimposing a delta frequency around a center frequency. To compensate for the inertia in the system, a quick frequency jump can be included. Suitable for elastic yarn applications, the option features a randomized wobble ratio.




Figure 100: Wobble Function

30-00 Wobble Mode

Default value:	[0] Abs. freq., abs. time	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be changed while the motor is running.

The standard speed open-loop mode in parameter **1-00 Configuration Mode** is extended with a wobble function. In this parameter, it is possible to select which method to be used for the wobbler. Set the parameters as absolute values (direct frequencies) or as relative values (percentage of other parameter). Set the wobble cycle time as an absolute value or as independent up and down times. When using an absolute cycle time, the up and down times are configured through the wobble ratio.

Option	Name	Description
[0]*	Abs. freq., abs. time	
[1]	Abs. freq., up/down time	
[2]	Rel. freq., abs. time	
[3]	Rel. freq., up/down time	

30-01 Wobble Delta Frequency [Hz]

Default value:	5 Hz	Parameter type:	Range, 0 - 25 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

The delta frequency determines the magnitude of the wobble frequency. The delta frequency is superimposed on the center frequency. Parameter **30-01 Wobble Delta Frequency [Hz]** contains both the positive and negative delta frequency. The setting of parameter **30-01 Wobble Delta Frequency [Hz]** must thus not exceed the setting of the center frequency. The initial ramp-up time from standstill until the wobble sequence runs is determined in parameter group **3-1* References**.

30-02 Wobble Delta Frequency [%]

Default value:	25%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

The delta frequency can also be expressed as a percentage of the center frequency and can thus be maximum 100%. The function is the same as for parameter **30-01 Wobble Delta Frequency [Hz]**.

30-03 Wobble Delta Freq. Scaling Resource

Default value:	[0] No function	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the drive input to be used for scaling the delta frequency setting.

Option	Name	Description
[0]*	No function	
[1]	Analog input 53	
[2]	Analog input 54	
[3]	Frequency input 29	 NOTE: This option is only available in FC 302.
[4]	Frequency input 33	
[7]	Analog input X30/11	
[8]	Analog input X30/12	
[15]	Analog input X48/2	
[16]	Analog input X49/1	
[17]	Analog input X49/3	
[18]	Analog input X49/5	
[99]	Normal feedback	

30-04 Wobble Jump Frequency [Hz]

Default value:	0 Hz	Parameter type:	Range, 0 - 20.0 Hz
Setup:	All setups	Conversion index:	-1
Data type:	UInt8	Change during operation:	True

The jump frequency is used to compensate for the inertia in the traverse system. If a jump in the output frequency is required at the boundaries of the wobble sequence, the frequency jump is set in this parameter. If the traverse system has a very high inertia, a high jump frequency may create a torque limit warning or trip or an overvoltage warning or trip. This parameter can only be changed in stop mode.

30-05 Wobble Jump Frequency [%]

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	UInt8	Change during operation:	True

The jump frequency can also be expressed as a percentage of the center frequency. The function is the same as for parameter **30-04 Wobble Jump Frequency [Hz]**.

30-06 Wobble Jump Time

Default value:	0.001	Parameter type:	Range, 0.001 - 5.000 s
Setup:	All setups	Conversion index:	-3
Data type:	UInt16	Change during operation:	True

This parameter determines the slope of the jump ramp at the maximum and minimum wobble frequency.

30-07 Wobble Sequence Time

Default value:	10 s	Parameter type:	Range, 1 - 1000 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

This parameter determines the wobble sequence period. This parameter can only be changed in stop mode.

$$\text{Wobbletime} = t_{up} + t_{down}$$

30-08 Wobble Up/Down Time

Default value:	5 s	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	True

Defines the individual up and down times for each wobble cycle.

30-09 Wobble Random Function

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Off	
[1]	On	

30-10 Wobble Ratio

Default value:	1	Parameter type:	Range, 0.1 - 10
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

If the ratio 0.1 is selected: t_{down} is 10 times greater than t_{up} . If the ratio 10 is selected: t_{up} is 10 times greater than t_{down} .

30-11 Wobble Random Ratio Max.

Default value:	10	Parameter type:	Range, par. 17-53 - 10
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

Enter the maximum allowed wobble ratio.

30-12 Wobble Random Ratio Min.

Default value:	0.1	Parameter type:	Range, 0.1 - par. 30-11
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

Enter the minimum allowed wobble ratio.

30-19 Wobble Delta Freq. Scaled

Default value:	0 Hz	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Uint16	Change during operation:	False

Readout parameter. View the actual wobble delta frequency after scaling has been applied.

6.24.2 30-2* Adv. Start Adjust



NOTE: This parameter group is only available in FC 302.

30-20 High Starting Torque Time [s]

Default value:	Size related	Parameter type:	Range, 0 - 60 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Define for how long the increased high starting torque current defined in parameter **30-21 High Starting Torque Current** should be applied.

30-21 High Starting Torque Current [%]

Default value:	Size related	Parameter type:	Range, 0 - 200.0%
Setup:	All setups	Conversion index:	-1
Data type:	Uint32	Change during operation:	True

Set the high starting current that should be applied for the time specified in parameter **30-20 High Starting Torque Time**. The increased current will improve the starting torque and starting performance in demanding applications. The high starting torque current is valid for VVC+ and flux in speed open loop. The parameter can be used with the following motors:

- SPM
- IPM
- SynRM
- PMaSynRM

30-22 Locked Rotor Protection

Default value:	–	Parameter type:	Option
Setupe:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Available for PM motors only, in flux sensorless mode and VVC+ open-loop mode.

Option	Name	Description
[0]	Off	
[1]	On	Protects the motor from the locked rotor condition. The control algorithm detects a possible locked rotor condition in the motor and trips the drive to protect the motor.

30-23 Locked Rotor Detection Time [s]

Default value:	Size related	Parameter type:	Range, 0.05 - 1 s
Setup:	All setups	Conversion size	-2
Data type:	Uint8	Change during operation:	True

Time period for detecting the locked rotor condition. A low parameter value leads to faster detection.

30-24 Locked Rotor Detection Speed Error [%]

Default value:	25%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	-1
Data type:	Uint32	Change during operation:	True

Detects locked rotor condition for SPMSM at high speed.

6.24.3 30-2* Light Load Detection

30-25 Measurement Duration

Default value.	0.000 s	Parameter type:	Range, 0.000 - 10.000 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

Duration of current integration measurement. The measurement is done in both directions. The direction with the lowest measurement value is selected by the drive.

30-26 Delay Before Measurements

Default value:	0.000 s	Parameter type:	Range, 0.000 - 10.000 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Delay before current measurement. Allows to avoid mismatch in measurements caused by mechanical friction during opening of mechanical brakes.

30-27 Light Load Speed [%]

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Use this parameter when the light-load detection is active to define the speed during current measurement. Enter the reference speed during the light-load detection. The value is a percentage of nominal motor speed in parameter **1-25 Motor Nominal Speed**. For standard asynchronous motors, the synchronous speed is used instead of parameter **1-25 Motor Nominal Speed** due to slip.

30-28 Evacuation Speed [%]

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Speed for evacuation after detection of light-load direction.

30-29 Ramp Time

Default value:	Size related	Parameter type:	Range, 0.01 - 3600 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Ramp times during evacuation and measurement sequences.

6.24.4 30-5* Unit Configuration



NOTE: The following parameter is only available in FC 302:

- Parameter **30-50 Heat Sink Fan Mode**

This parameter group contains parameters for configuring the operation of internal units that communicate with the drive. The settings affect the behavior of hardware components inside the drive.

30-50 Heat Sink Fan Mode

Default value:	–	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select how the heat sink fan responds to operating conditions. Use parameter **14-52 Fan Control** to control the minimum fan speed.

Option	Name	Description
[0]	Simple profile	The simple profile is a passive fan control based on the current temperature state of the drive. This option represents the classic operating behavior of fans.
[1]	Reduced acoustics	
[2]	Standard	
[3]	Cooler operation	

6.24.5 30-7* Power Low Monitor Protection

30-70 Power Low Monitoring

Default value:	[0] Disabled	Parameter type:	Option

Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Disabled	Disables the power-low monitoring feature.
[1]	Enabled	Enables the power-low monitoring feature.

30-71 PLM Detection Time

Default value:	10 s	Parameter type:	Range, 4 - 100 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the detection time window for power integration.

30-72 PLM Min. Speed

Default value:	25%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter shows the minimum detection speed above which the PLM algorithm is allowed to act. The speed is given in % relative to parameter **1-25 Motor Nominal Speed**.

30-73 PLM Detection Factor

Default value:	5	Parameter type:	Range, 2 - 100
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter gives a detection sensitivity factor for the PLM feature - a copper loss multiplier. The PLM flags a blocked motor when the monitored energy throughout the time window is lower than the copper loss energy multiplied by this sensitivity parameter.

6.24.6 30-8* Compatibility (I)



NOTE: The following parameter is only available in FC 302:

- Parameter **30-80 d-axis Inductance**

30-80 d-axis Inductance (Ld)

Default value:	Size related	Parameter type:	Range, 0.001 - 1000.000 mH
Setup:	All setups	Conversion index:	-6
Data type:	Int32	Change during operation:	False

Enter the value of the d-axis inductance. Obtain the value from the permanent magnet motor datasheet. The d-axis inductance cannot be found by performing an AMA.

30-81 Brake Resistor (ohm)

Default value:	Size related	Parameter type:	Range, 0.01 - 65535.00 ohm
Setup:	1 setup	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Set the brake resistor value in Ω . This value is used for monitoring the power to the brake resistor in parameter **2-13 Brake Power Monitoring**. This parameter is only active in drives with an integral dynamic brake.

30-83 Speed PID Proportional Gain

Default value:	Size related	Parameter type:	Range, 0 - 1
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True

Enter the speed controller proportional gain. Quick control is obtained at high amplification. However, if amplification is too great, the process may become unstable.

30-84 Process PID Proportional Gain

Default value:	Size related	Parameter type:	Range, 0 - 10
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Enter the process controller proportional gain. Quick control is obtained at high amplification. However, if amplification is too great, the process may become unstable.

30-85 Motor Frequency

Default value:	Size related	Parameter type:	Range, 5.0 - 1000.0 Hz
Setup:	All setups	Conversion index:	-1
Data type:	Uint32	Change during operation:	False



NOTE: Changing this parameter affects the settings of other parameters.

Enter the motor frequency from the motor nameplate data.

Parameter 30-88 System Inertia

Default value:	Size related	Parameter type:	Range, 0.000000 - 2000.000000 kgm^2
Setup:	All setups	Conversion index:	-6
Data value:	Uint32	Change during operation:	False



NOTE: This parameter is only available with software version 48.82 and newer.

Enables setting the system inertia with 6 decimals for small motors (parameter **1-69 System Inertia** only has 4 decimals).

30-89 Trip Delay at Current Limit

Default value:	60.00 s	Parameter type:	Range, 0 - 60.00 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

When the output current reaches the current limit set in parameter **4-18 Current Limit**, a warning is triggered. If the current limit warning is continuously present for the time specified in this parameter, the drive trips. Enter 60 s to disable the feature.

6.25 Parameter Group 31-** Bypass Option



NOTE: This parameter group is only available in FC 302.

31-00 Bypass Mode

Default value:	[0] Drive	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the bypass operating mode.

Option	Name	Description
[0]*	Drive	The drive operates the motor.
[1]	Bypass	The motor is operated at full speed during bypass mode.

31-01 Bypass Start Time Delay

Default value:	30 s	Parameter type:	Range, 0 - 60 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Setting the time delay to pass from the bypass receives a run command until it starts the motor at full speed. A countdown timer shows the remaining time.

31-02 Bypass Trip Time Delay

Default value:	0 s	Parameter type:	Range, 0 - 300 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Setting the time delay to pass from the drive experiences an alarm that stops it and until the motor is automatically switched to bypass control. If the delay is set to 0, a drive alarm does not automatically switch the motor to bypass control.

31-03 Test Mode Activation

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Disabled	Test mode is disabled.
[1]	Enabled	The motor runs in bypass while the drive can be tested into an open circuit. In this mode, keypad does not control start/stop of bypass.

31-10 Bypass Status Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	74
Data type:	V2	Change during operation:	False

View the status of the bypass as a hexadecimal value.

31-11 Bypass Running Hours

Default value:	0 h	Parameter type:	Readout
Setup:	All setups	Conversion index:	74
Data type:	UInt32	Change during operation:	False

View the number of hours in which the motor has run in bypass mode. The counter can be reset in parameter **15-07 Reset Running Hours Counter**. The value is saved when the drive is turned off.

31-19 Remote Bypass Activation

Default value:	[0] Disabled	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	

6.26 Parameter Group 32-** MCO Basic Settings

6.27 32-0* Encoder 2

32-00 Incremental Signal Type

Default value:	[1] RS422 (5V TTL)	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	None	
[1]*	RS422 (5V TTL)	

Option	Name	Description
[2]	Sinusoidal 1Vpp	
[3]	CAN encoder	

32-01 Incremental Resolution

Default value:	1024	Parameter type:	Range, 1 - 1073741823
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Set the resolution of the incremental encoder connected to terminal X55. The maximum frequency must not exceed 410 kHz.

32-02 Absolute Protocol

Default value:	[0] None	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	None	
[1]	HIPERFACE	
[2]	EnDat	
[4]	SSI	
[5]	SSI with filter	
[6]	BiSS-C	
[7]	BiSS-B	

32-03 Absolute Resolution

Default value:	8192	Parameter type:	Range, 0 - 1073741823
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

The encoder resolution is used for calculating velocity in RPM. Set the resolution of the absolute encoder connected to terminal X55 in positions per revolution. Find the encoder resolution on the encoder nameplate.

32-04 Absolute Encoder Baudrate X55

Default value:	[4] 9600	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Select the baud rate of the attached encoder.

Option	Name	Description
[0]	600	
[1]	1200	
[2]	2400	
[3]	4800	
[4]*	9600	
[5]	19200	
[6]	38400	

32-05 Absolute Encoder Data Length

Default value:	25	Parameter type:	Range, 8 - 37
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Specify the number of data bits for the connected absolute encoder, see encoder datasheet. This specification is required for VLT® Motion Control Option MCO 305 and VLT® Motion Control Option MCO 302 to generate the correct number of clock bits.

32-06 Absolute Encoder Clock Frequency

Default value:	262	Parameter type:	Range, 78.125 - 2000 kHz
Setup:	2 setups	Conversion index:	3
Data type:	Uint32	Change during operation:	True

Specifies the frequency of the absolute encoder clock signal generated by VLT® Motion Control Option MCO 305 and VLT® Motion Control Option MCO 302. Set a frequency appropriate for the connected encoder.

32-07 Absolute Encoder Clock Generation

Default value:	[1] On	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Off	Select [0] Off when more MCOs are connected to the same absolute encoder. Only 1 MCO is allowed to generate the clock signal when multiple MCOs are interconnected.
[1]*	On	Select [1] On when 1 MCO is connected to 1 absolute encoder.

32-08 Absolute Encoder Cable Length

Default value:	0 m	Parameter type:	Range, 0 - 300 m
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the total cable length (in meters) to avoid that the absolute encoder (SSI) signals come out of synchronization due to signal delays caused by long encoder cables. VLT® Motion Control Option MCO 305 and VLT® Motion Control Option MCO 302 compensate for the cable delay when the cable length is known.

32-09 Encoder Monitoring

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	Off	
[1]	3 channels	
[2]	2 channels	
[3]	Warning	
[4]	Alarm	

32-10 Rotational Direction

Default value:	[1] No action	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Normally, a positive reference value brings about a positive change of the position. If this is not the case, the reference value can be reversed internally.

Option	Name	Description
[1]*	No action	
[2]	Reference reversed	
[3]	User units reserved	
[4]	Uu and ref reversed	

32-11 User Unit Denominator

Default value:	1	Parameter type:	Range, 1 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	UInt32	Change during operation:	True

All target positions are made in user units and are converted to quad-counts internally. By selecting scaling units, it is possible to work with any measurement unit (for example mm). This factor consists of a numerator and denominator.

32-12 User Units Numerator

Default value:	1	Parameter type:	1 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	UInt32	Change during operation:	True

All target positions are made in user units and are converted to quad-counts internally. By selecting scaling units, it is possible to work with any measurement unit (for example mm). This factor consists of a numerator and denominator.

32-13 Enc.2 Control

Default value:	[0] No soft changing	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Enables bump-less changing of feedback encoder in software while running and setting position to 0 without losing the actual position.

Option	Name	Description
[0]*	No soft changing	
[1]	Encoder soft changing enable	
[2]	Soft zero setting enable	
[3]	Encoder soft changing and soft zero enable	

32-14 Enc.2 Node ID

Default value:	127	Parameter type:	Range, 1 - 127
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the node ID for the feedback CAN encoder.

32-15 Enc.2 CAN Guard

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select if the feedback CAN encoder guardians should be off or on.

Option	Name	Description
[0]*	Off	
[1]	On	

6.28 32-3* Encoder 1

32-30 Incremental Signal Type

Default value:	[1] RS422 (5V TTL)	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	None	
[1]*	RS422 (5V TTL)	
[3]	CAN encoder	

32-31 Incremental Resolution

Default value:	1024	Parameter type:	Range, 1 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Set the resolution of the incremental encoder connected to terminal X56. The maximum frequency must not exceed 410 kHz.

32-32 Absolute Protocol

Default value:	[0] None	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	None	
[1]	HIPERFACE	
[2]	EnDat	
[4]	SSI	
[5]	SSI with filter	
[6]	BiSS-C	
[7]	BiSS-B	

32-33 Absolute Resolution

Default value:	8192	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

The encoder resolution is used for calculating velocity in RPM. Set the resolution of the absolute encoder connected to terminal X56 in positions per revolution. Find the encoder resolution on the encoder nameplate.

32-35 Absolute Encoder Data Length

Default value:	25	Parameter type:	Range, 8 - 37
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Specify the number of data bits for the connected absolute encoder, see encoder datasheet. This specification is required for VLT® Motion Control Option MCO 305 and VLT® Motion Control Option MCO 302 to generate the correct number of clock bits.

32-36 Absolute Encoder Clock Frequency

Default value:	262	Parameter type:	Range, 78.125 - 2000 kHz
Setup:	2 setups	Conversion index:	3
Data type:	Uint32	Change during operation:	True

Specifies the frequency of the absolute encoder clock signal generated by VLT® Motion Control Option MCO 305 and VLT® Motion Control Option MCO 302. Set a frequency appropriate for the connected encoder.

32-37 Absolute Encoder Clock Generation

Default value:	[1] On	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Off	Select [0] Off when more MCOs are connected to the same absolute encoder. Only 1 MCO is allowed to generate the clock signal when multiple MCOs are interconnected.
[1]*	On	Select [1] On when 1 MCO is connected to 1 absolute encoder.

32-38 Absolute Encoder Cable Length

Default value:	0 m	Parameter type:	Range, 0 - 300 m
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the total cable length (in meters) to avoid that the absolute encoder (SSI) signals come out of synchronization due to signal delays caused by long encoder cables. VLT® Motion Control Option MCO 305 and VLT® Motion Control Option MCO 302 compensate for the cable delay when the cable length is known.

32-39 Encoder Monitoring

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Off	
[1]	3 channels	
[2]	2 channels	
[3]	Warning	
[4]	Alarm	

32-40 Encoder Termination

Default value:	[1] On	Parameter type:	Option

Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Off	
[1]*	On	

32-43 Enc.1 Control

Default value:	[0] No soft changing	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No soft changing	
[1]	Encoder soft changing enable	
[2]	Soft zero setting enable	
[3]	Encoder soft changing and soft zero enable	

32-44 Enc.1 Node ID

Default value:	127	Parameter type:	Range, 1 - 127
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Enter the node ID for the feedback CAN encoder.

32-45 Enc.1 CAN Guard

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select if the feedback CAN encoder guardians should be off or on.

Option	Name	Description
[0]*	Off	
[1]	On	

6.29 32-5* Feedback Source

32-50 Source Slave

Default value:	[2] Encoder 2 X55	Parameter type:	Option
Setup:	2 setups	Conversion index:	–

Data type:	UInt8	Change during operation:	True
Option	Name	Description	
[1]	Encoder 1 X56		
[2]*	Encoder 2 X55		
[3]	Motor control		

32-51 MCO 302 Last Will

Default value:	[1] Trip	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True
Option	Name	Description	
[1]*	Trip		

32-52 Source Master

Default value:	[1] Encoder 1 X56	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True
Option	Name	Description	
[1]*	Encoder 1 X56		
[2]	Encoder 2 X55		
[3]	Motor control		

6.30 32-6* PID Controller

32-60 Proportional Factor

Default value:	30	Parameter type:	Range, 0 - 100000
Setup:	2 setups	Conversion index:	0
Data type:	UInt32	Change during operation:	True

The proportional factor indicates the linear correction factor with which the deviation between the current set and actual position is evaluated. The motor speed is then corrected accordingly.

32-61 Derivative Factor

Default value:	0	Parameter type:	Range, 0 - 100000
Setup:	2 setups	Conversion index:	0
Data type:	UInt32	Change during operation:	True

The derivative value is the correction factor with which the changing speed of a motor position error is evaluated. The derivative value prevents overswing due to a high P-share and dampens the system.

32-62 Integral Factor

Default value:	0	Parameter type:	Range, 0 - 100000
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

The integral factor is the weighting factor with which, at time n, the sum of all motor position errors are evaluated.

32-63 Limit Value for Integral Sum

Default value:	1000	Parameter type:	Range, 0 - 1000
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

This parameter limits the integral sum to avoid instability and PID wind-up if a feedback error occurs.

32-64 PID Bandwidth

Default value:	1000	Parameter type:	Range, 0 - 1000
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

The value 1000 means that the PID filter can output the full command value. For a Bandwidth of 500 only 50 % of the set value is output.

32-65 Velocity Feed-Forward

Default value:	0	Parameter type:	Range, 0 - 100000
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Velocity Feed-forward is a scaling factor that is multiplied with the derivative of the setpoint position (the velocity of the setpoint). Use this function to get a more dynamic controller.

32-66 Acceleration Feed-Forward

Default value:	0	Parameter type:	Range, 0 - 100000
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Acceleration Feed-forward is multiplied with the 2nd derivative of the setpoint position (the acceleration of the setpoint), and the result is added to the control signal. Use this function to give an extra boost during acceleration.

32-67 Max. Tolerated Position Error

Default value:	20000	Parameter type:	Range, 1 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter defines the maximum error allowed between the actual position and the calculated command position. If the actual error exceeds the value set in this parameter, the position control fault alarm is triggered.

32-68 Reverse Behavior for Slave

Default value:	[0] Reversing	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Reversing allowed	
[1]	Rev. when master	
[2]	Reversing blocked	

32-69 Sampling Time for PID Control

Default value:	1 ms	Parameter type:	Range, 1 - 1000 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Sample time of the PID controller. Increase the time if the controller is unstable because of a low-resolution feedback signal or very high load inertia.

32-70 Scan Time for Profile Generator

Default value:	1 ms	Parameter type:	Range, 1 - 5 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Uint8	Change during operation:	True

Sample time of the profile generator. Increasing the time speeds up the execution of the application program execution. However, it also reduces control performance so the sample time should not be increased too much if dynamic control is required.

32-71 Size of the Control Window (Activation)

Default value:	0	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

32-72 Size of the Control Window (Deactiv.)

Default value:	0	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

32-73 Integral Limit Filter Time

Default value:	0 ms	Parameter type:	Range, -10000 - 10000 ms
Setup:	2 setups	Conversion index:	-3

Data type:	Int16	Change during operation:	True

32-74 Position Error Filter Time

Default value:	0 ms	Parameter type:	Range, 0 - 10000 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Int16	Change during operation:	True

The position error is only activated if the position error value set in parameter **32-67 Max. Tolerated Position Error** is exceeded for a time longer than the setting in this parameter.

6.31 32-8* Velocity & Accel.

32-80 Maximum Velocity (Encoder)

Default value:	1500 RPM	Parameter type:	Range, 1 - 100000 RPM
Setup:	2 setups	Conversion index:	67
Data type:	UInt32	Change during operation:	True

This parameter defines the maximum velocity in RPM during motion control.

32-81 Shortest Ramp

Default value:	1 s	Parameter type:	Range, 0.001 - 3600 s
Setup:	2 setups	Conversion index:	0
Data type:	UInt32	Change during operation:	True

This parameter defines the quick-stop ramp time from the maximum allowed velocity to 0 for motion control.

32-82 Ramp Type

Default value:	[0] Linear	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	Linear	
[1]	S-ramp const jerk	
[2]	S-ramp const time	
[4]	Linear anti-sway	



NOTE: This option is only available in FC 302 with IMC software version 48.96 and newer.

Option	Name	Description
[5]	Linear anti-oscillate	 NOTE: This option is only available in FC 302 with IMC software version 49.10 and newer.
[6]	S-ramp anti-oscillate	 NOTE: This option is only available in FC 302 with IMC software version 49.10 and newer.

32-83 Velocity Resolution

Default value:	100	Parameter type:	Range, 1 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

32-84 Default Velocity

Default value:	50	Parameter type:	Range, 1 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

32-85 Default Acceleration

Default value:	50	Parameter type:	Range, 1 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

32-86 Acc. Up for Limited Jerk

Default value:	100 ms	Parameter type:	Range, 0 - 1073741823 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

32-87 Acc. Down for Limited Jerk

Default value:	0 ms	Parameter type:	Range, 0 - 1073741823 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

32-88 Dec. Up for Limited Jerk

Default value:	0 ms	Parameter type:	Range, 0 - 1073741823 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

32-89 Dec. Down for Limited Jerk

Default value:	0 ms	Parameter type:	Range, 0 - 1073741823 ms

Setup:	2 setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

6.32 Parameter Group 33-** MCO Adv. Settings

6.32.1 33-0* Home Motion

33-00 Force HOME

Default value:	[0] Home not forced	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Home not forced	
[1]	Home forced	

33-01 Zero Point Offset from Home Pos.

Default value:	0	Parameter type:	Range, -1073741824 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Use this parameter to set an offset of 0 (home position) compared to the position after homing.

33-02 Ramp for Home Motion

Default value:	10	Parameter type:	Range, -1 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

This parameter defines the ramp time (in ms) from standstill to the value set in parameter **32-80 Maximum Allowed Velocity**.

33-03 Velocity for Home Motion

Default value:	10	Parameter type:	Range, -100 - 100
Setup:	2 setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

This parameter defines the velocity of homing. It must not exceed parameter **32-80 Maximum Allowed Velocity**.

33-04 Behavior During HomeMotion

Default value:	[0] Reverse and index	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Define the behavior when the home switch is found: Reversing without index (0 pulse) search, or forwarding without index search.

Option	Name	Description
[0]*	Revers and index	
[1]	Revers no index	
[2]	Forward and index	
[3]	Forward no index	

6.32.2 33-1* Synchronization

33-10 Sync Factor Master

Default value:	1	Parameter type:	Range, -1073741824 - 1073741823
Setup:	2 setups	Conversion index:	–
Data type:	Int32	Change during operation:	True

33-11 Sync Factor Slave

Default value:	1	Parameter type:	Range, -1073741824 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

33-12 Position Offset for Synchronization

Default value:	0	Parameter type:	Range, -1073741824 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

33-13 Accuracy Window for Position Sync.

Default value:	1000	Parameter type:	Range, -1073741824 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

33-14 Relative Slave Velocity Limit

Default value:	0%	Parameter type:	0 - 100%
Setup:	2 setups	Conversion index:	0
Default value:	UInt8	Change during operation:	True

33-15 Marker Number for Master

Default value:	1	Parameter type:	Range, 1 - 10000
Setup:	2 setups	Conversion index:	0

Data type:	Uint16	Change during operation:	True

33-16 Marker Number for Slave

Default value:	1	Parameter type:	Range, 1 - 10000
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

33-17 Master Marker Distance

Default value:	4096	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

33-18 Slave Marker Distance

Default value:	4096	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

33-19 Master Marker Type

Default value:	[0] Encoder Z positive	Parameter type:	Option, Array [4]
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Encoder Z positive	
[1]	Encoder Z negative	
[2]	Ext. marker positive	
[3]	Ext. marker negative	

33-20 Slave Marker Type

Default value:	[0] Encoder Z positive	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Encoder Z positive	
[1]	Encoder Z negative	
[2]	Ext. marker positive	
[3]	Ext. marker negative	

33-21 Master Marker Tolerance Window

Default value:	0	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

33-22 Slave Marker Tolerance Window

Default value:	0	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

33-23 Start Behavior for Marker Sync

Default value:	[0] Leading marker	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint16	Change during operation:	True

Option	Name	Description
[0]*	Leading marker	
[1]	Following marker	
[2]	Closest marker	
[3]	Master vel/ldg mrk	
[4]	Master vel/flw mrk	
[5]	Master vel/cls mrk	
[6]	Next 2 markers	
[7]	Start with poly5	
[1000]	Ldg mrk late offs	
[1001]	Flw mrk late offs	
[1002]	Cls mark late offs	
[1003]	Mv/ldg mrk/lt off	
[1004]	Mv/flw mrk/lt off	
[1005]	Mv/cls mrk/lt off	
[1006]	Next 2 mrk/lt off	
[1007]	Poly5/late offs	
[2000]	Camstart mast mrk	

33-24 Marker Number for Fault

Default value:	10	Parameter type:	Range, 0 - 10000
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

33-25 Marker Number for Ready

Default value:	1	Parameter type:	Range, 0 - 10000
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

33-26 Velocity Filter

Default value:	0 us	Parameter type:	Range, -1073741824 - 1073741823 us
Setup:	2 setups	Conversion index:	-6
Data type:	Int32	Change during operation:	True

33-27 Offset Filter Time

Default value:	0 ms	Parameter type:	Range, 0 - 1073741823 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

33-28 Marker Filter Configuration

Default value:	[0] Marker Filter 1	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Marker filter 1	
[1]	Marker filter 2	
[2]	Correction syncfact	
[4]	Correction time	
[16]	No marker dist. corr	

33-29 Filter Time for Marker Filter

Default value:	0 ms	Parameter type:	Range, -1073741824 - 1073741823 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

33-30 Maximum Marker Correction

Default value:	0	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

33-31 Synchronization Type

Default value:	[0] Standard	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Standard	
[1]	Look ahead	

33-32 Feed Forward Velocity Adaptation

Default value:	0	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

33-33 Velocity Filter Window

Default value:	0	Parameter type:	Range, 0 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

33-34 Slave Marker Filter Time

Default value:	0 ms	Parameter type:	Range, 0 - 1073741823 ms
Setup:	2 setups	Conversion index:	-3
Data type:	Uint32	Change during operation:	True

6.32.3 33-4* Limit Handling

33-40 Behavior atEnd Limit Switch

Default value:	[0] Call error handler	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Call error handler	
[1]	Controlled stop	

33-41 Negative Software End Limit

Default value:	-500000	Parameter type:	Range, -1073741824 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

This parameter is active only during positioning if parameter **33-42 Negative Software Limit Active** is set to **[1] Active**. When parameter **34-50 Actual Position** reaches below the negative software limit set in this parameter, a position control fault alarm is reported.

33-42 Positive Software End Limit

Default value:	500000	Parameter type:	Range, -1073741824 - 1073741823
Setup:	2 setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

This parameter is active only during positioning if parameter **33-42 Negative Software Limit Active** is set to **[1] Active**. When parameter **34-50 Actual Position** reaches below the negative software limit set in this parameter, a position control fault alarm is reported.

33-43 Negative Software End Limit Active

Default value:	[0] Inactive	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	Inactive	
[1]	Active	

33-44 Positive Software End Limit Active

Default value:	[0] Inactive	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

When this parameter is set to active, the drive continuously checks whether the target position is above the positive software limit. If the position is outside the limit, an error is issued and the drive control is switched off.

Option	Name	Description
[0]*	Inactive	
[1]	Active	

33-45 Time in Target Window

Default value:	0 ms	Parameter type:	Range, 0 - 10 ms
Setup:	2 setups	Conversion index:	-3
Data type:	UInt8	Change during operation:	True

33-46 Target Window LimitValue

Default value:	1	Parameter type:	Range, 1 - 10000
Setup:	2 setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

33-47 Size of Target Window

Default value:	0	Parameter type:	Range, 0 - 10000
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Defines the size of the target window with user unit. A position is only viewed as reached when the actual position is within this window.

6.32.4 33-5* I/O Configuration

33-50 Terminal X57/1 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-51 Terminal X57/2 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	

Option	Name	Description
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-52 Terminal X57/3 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-53 Terminal X57/4 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-54 Terminal X57/5 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	

Option	Name	Description
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-55 Terminal X57/6 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-56 Terminal X57/7 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-57 Terminal X57/8 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	

Option	Name	Description
[14]	Start prog. exe nc	
[15]	Program select	

33-58 Terminal X57/9 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-59 Terminal X57/10 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Changing during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	

Option	Name	Description
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-60 Terminal X59/1 and X59/2 Mode

Default value:	[1] Output	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]	Input	
[1]*	Output	

33-61 Terminal X59/1 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	

Option	Name	Description
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-62 Terminal X59/2 Digital Input

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Home switch no	
[2]	Home switch nc	
[3]	Neg. end switch no	
[4]	Neg. end switch nc	
[5]	Posi. end switch no	
[6]	Posi. end switch nc	
[7]	Error clear no	
[8]	Error clear nc	
[9]	Break prog. exe no	
[10]	Break prog. exe nc	
[11]	Cont. prog. exe no	
[12]	Cont. prog. exe nc	
[13]	Start prog. exe no	
[14]	Start prog. exe nc	
[15]	Program select	

33-63 Terminal X59/1 Digital Output

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Moving no	
[2]	Moving nc	
[3]	Error no	
[4]	Error nc	
[5]	Brake control no	
[6]	Brake control nc	

33-64 Terminal X59/2 Digital Output

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–

Option	Name	Description
[0]*	No function	
[1]	Moving no	
[2]	Moving nc	
[3]	Error no	
[4]	Error nc	
[5]	Brake control no	
[6]	Brake control nc	

33-65 Terminal X59/3 Digital Output

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Moving no	
[2]	Moving nc	
[3]	Error no	
[4]	Error nc	
[5]	Brake control no	
[6]	Brake control nc	

33-66 Terminal X59/4 Digital Output

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–

Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Moving no	
[2]	Moving nc	
[3]	Error no	
[4]	Error nc	
[5]	Brake control no	
[6]	Brake control nc	

33-67 Terminal X59/5 Digital Output

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Moving no	
[2]	Moving nc	
[3]	Error no	
[4]	Error nc	
[5]	Brake control no	
[6]	Brake control nc	

33-68 Terminal X59/6 Digital Output

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Coinversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Moving no	
[2]	Moving nc	
[3]	Error no	
[4]	Error nc	
[5]	Brake control no	
[6]	Brake control nc	

33-69 Terminal X59/7 Digital Output

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Moving no	
[2]	Moving nc	
[3]	Error no	
[4]	Error nc	
[5]	Brake control no	
[6]	Brake control nc	

33-70 Terminal X59/8 Digital Output

Default value:	[0] No function	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No function	
[1]	Moving no	
[2]	Moving nc	
[3]	Error no	
[4]	Error nc	
[5]	Brake control no	
[6]	Brake control nc	

6.32.5 33-8* Global Parameters

33-80 Activated Program Number

Default value:	-1	Parameter type:	Range, -1 - 127
Setup:	2 setups	Conversion index:	0
Data type:	Int8	Change during operation:	True

33-81 Power-up State

Default value:	[1] Motor on	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Motor off	
[1]*	Motor on	

33-82 Drive Status Monitoring

Default value:	[1] On	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Off	
[1]*	On	

33-83 Behavior afterError

Default value:	[0] Coast	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Coast	
[1]	Coast and brake	
[2]	Controlled stop	
[3]	Contr.stop + brake	
[5]	Only errorhandler	

33-84 Behavior afterEsc.

Default value:	[0] Controlled stop	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Controlled stop	
[1]	Contr. stop + outp=0	
[2]	Contr. stop + outp=1	

33-85 MCO Supplied by External 24VDC

Default value:	[0] No	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No	
[1]	Yes	

33-86 Terminal at Alarm

Default value:	[0] Relay 1	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Relay 1	
[1]	Relay 2	
[2]	Terminal 27 digital output	
[3]	Terminal 29 digital output	

33-87 Terminal State at Alarm

Default value:	[0] Do nothing	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Do nothing	
[1]	High	
[2]	Low	

33-88 Status Word at Alarm

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

6.32.6 33-9* MCO Port Settings

33-90 X62 MCO CAN node ID

Default value:	127	Parameter type:	Range, 0 - 127
Setup:	2 setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

33-91 X62 MCO CAN Baud Rate

Default value:	[20] 125 Kbps	Parameter type:	Option
Setup:	2 setups	Conversion index:	–

Data type:	Uint8	Change during operation:	True

Option	Name	Description
[16]	10 Kbps	
[17]	20 Kbps	
[18]	50 Kbps	
[19]	100 Kbps	
[20]*	125 Kbps	
[21]	250 Kbps	
[22]	500 Kbps	
[24]	1000 Kbps	

33-94 X60 MCO RS485 Serial Termination

Default value:	[0] Off	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Off	
[1]	On	

33-95 X60 MCO RS485 Serial Baud Rate

Default value:	[2] 9600 Baud	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	2400 Baud	
[1]	4800 Baud	
[2]*	9600 Baud	
[3]	19200 Baud	
[4]	38400 Baud	
[5]	57600 Baud	
[6]	76800 Baud	
[7]	115200 Baud	

6.33 Parameter Group 34-** MCO Data Readouts

6.33.1 34-0* PCD Write Par.

34-01 PCD 1 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD1 of the fieldbus telegram.

34-02 PCD 2 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD2 of the fieldbus telegram.

34-03 PCD 3 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD3 of the fieldbus telegram.

34-04 PCD 4 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD4 of the fieldbus telegram.

34-05 PCD 5 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD5 of the fieldbus telegram.

34-06 PCD 6 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD6 of the fieldbus telegram.

34-07 PCD 7 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD7 of the fieldbus telegram.

34-08 PCD 8 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD8 of the fieldbus telegram.

34-09 PCD 9 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD9 of the fieldbus telegram.

34-10 PCD 10 Write to MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value received in PCD10 of the fieldbus telegram.

6.33.2 34-2* PCD Read Par.

34-21 PCD 1 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD1 of the fieldbus telegram.

34-22 PCD 2 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD2 of the fieldbus telegram.

34-23 PCD 3 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Shows the value sent in PCD2 of the fieldbus telegram.

34-24 PCD 4 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD4 of the fieldbus telegram.

34-25 PCD 5 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD5 of the fieldbus telegram.

34-26 PCD 6 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD6 of the fieldbus telegram.

34-27 PCD 7 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD7 of the fieldbus telegram.

34-28 PCD 8 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD8 of the fieldbus telegram.

34-29 PCD 9 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD9 of the fieldbus telegram.

34-30 PCD 10 Read from MCO

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Shows the value sent in PCD10 of the fieldbus telegram.

6.33.3 34-4* Inputs & Outputs

34-40 Digital Inputs

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

34-41 Digital Outputs

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

6.33.4 34-5* Process Data

34-50 Actual Position

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

View the actual position in user unit.

34-51 Commanded Position

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-52 Actual Master Position

Default value:	0	Parameter type:	Readout

Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-53 Slave Index Position

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-54 Master Index Position

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-55 Curve Position

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-56 Track Error

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Readout of the error between the calculated command position and the actual position in user unit.

34-57 Synchronizing Error

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-58 Actual Velocity

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-59 Actual Master Velocity

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-60 Synchronizing Status

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-61 Axis Status

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-62 Program Status

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

34-64 MCO 302 Status

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

34-65 MCO 302 Control

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

34-66 SPI Error Counter

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt32	Change during operation:	False

6.33.5 34-7* Diagnosis Readouts

34-70 MCO Alarm Word 1

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	UInt32	Change during operation:	False

34-71 MCO Alarm Word 2

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0

Data type:	Uint32	Change during operation:	False

6.34 Parameter Group 35-** Sensor Input Option

6.34.1 35-0* Temp. Input Mode

35-00 Term. X48/4 Temperature Unit

Default value:	[60] °C	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the unit to be used with temperature input X48/4 settings and readouts.

Option	Name	Description
[60]*	°C	
[160]	°F	

35-01 Term. X48/4 Input Type

Default value:	[0] Not connected	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

View the temperature sensor type detected at input X48/4.

Index	Name
[0]*	Not connected
[1]	PT100 2-wire
[3]	PT1000 2-wire
[5]	PT100 3-wire
[7]	PT1000 3-wire

35-02 Term. X48/7 Temperature Unit

Default value:	[60] °C	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the unit to be used with temperature input X48/7 settings and readouts.

Option	Name	Description
[60]*	°C	
[160]	°F	

35-03 Term. X48/7 Input Type

Default value:	[0] Not connected	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

View the temperature sensor type detected at input X48/7.

Option	Name
[0]*	Not connected
[1]	PT100 2-wire
[3]	PT1000 2-wire
[5]	PT100 3-wire
[7]	PT1000 3-wire

35-04 Term. X48/10 Temperature Unit

Default value:	[60] °C	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the unit to be used with temperature input X48/10 settings and readouts.

Option	Name	Description
[60]*	°C	
[160]	°F	

35-05 Term. X48/10 Input Type

Default value:	[0] Not connected	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

View the temperature sensor type detected at input X48/10.

Option	Name
[0]*	Not connected
[1]	PT100 2-wire
[3]	PT1000 2-wire
[5]	PT100 3-wire
[7]	PT1000 3-wire

35-06 Temperature Sensor Alarm Function

Default value:	[5] Stop and trip	Parameter type:	Option
Setup:	All setups	Conversion index:	–

Data type:	Uint8	Change during operation:	True

Set the alarm function.

Option	Name	Description
[0]	Off	
[2]	Stop	
[5]*	Stop and trip	
[27]	Forced stop and trip	

6.34.2 35-1* Temp. Input X48/4

35-14 Term. X48/4 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X48/4. A high time constant value improves dampening but also increases the time delay through the filter.

35-15 Term. X48/4 Temp. Monitor

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter facilitates the possibility of enabling or disabling the temperature monitor for terminal X48/4. Set the temperature limits in parameter *35-16 Term. X48/4 Low Temp. Limit* and parameter *35-17 Term. X48/4 High Temp. Limit*.

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	

35-16 Term. X48/4 Low Temp. Limit

Default value:	Size related	Parameter type:	Range, -50 - par. 35-17 Term. X48/4 High Temp. Limit
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the minimum temperature reading that is expected for normal operation of the temperature sensor at terminal X48/4.

35-17 Term. X48/4 High Temp. Limit

Default value:	Size related	Parameter type:	Range, par. 35-16 Term. X48/4 Low Temp. Limit - 204
Setup:	All setups	Conversion index:	0

Data type:	Int16	Change during operation:	True

Enter the maximum temperature reading that is expected for normal operation of the temperature sensor at terminal X48/4.

6.34.3 35-2* Temp. Input X48/7

35-24 Term. X48/7 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X48/7. A high time constant value improves dampening but also increases the time delay through the filter.

35-25 Term. X48/7 Temp. Monitor

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter facilitates the possibility of enabling or disabling the temperature monitor for terminal X48/4. Set the temperature limits in parameter **35-26 Term. X48/7 Low Temp. Limit** and parameter **35-27 Term. X48/7 High Temp. Limit**.

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	

35-26 Term. X48/7 Low Temp. Limit

Default value:	Size related	Parameter type:	Range, -50 - par. 35-27 Term. X48/7 High Temp. Limit
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the minimum temperature reading that is expected for normal operation of the temperature sensor at terminal X48/7.

35-27 Term. X48/7 High Temp. Limit

Default value:	Size related	Parameter type:	Range, par. 35-26 Term. X48/7 Low Temp. Limit - 204
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the maximum temperature reading that is expected for normal operation of the temperature sensor at terminal X48/7.

6.34.4 35-3* Temp. Input X48/10

35-34 Term. X48/10 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X48/10. A high time constant value improves dampening but also increases the time delay through the filter.

35-35 Term. X48/10 Temp. Monitor

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter facilitates the possibility of enabling or disabling the temperature monitor for terminal X48/4. Set the temperature limits in parameter **35-36 Term. X48/10 Low Temp. Limit** and parameter **35-37 Term. X48/10 High Temp. Limit**.

Option	Name	Description
[0]*	Disabled	
[1]	Enabled	

35-36 Term. X48/10 Low Temp. Limit

Default value:	Size related	Parameter type:	Range, -50 - par. 35-37 Term. X48/10 High Temp. Limit
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the minimum temperature reading that is expected for normal operation of the temperature sensor at terminal X48/10.

35-37 Term. X48/10 High Temp. Limit

Default value:	Size related	Parameter type:	Range, par. 35-36 Term. X48/10 Low Temp. Limit - 204
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the maximum temperature reading that is expected for normal operation of the temperature sensor at terminal X48/10.

6.34.5 35-4* Analog Input X48/2

35-42 Term. X48/2 Low Current

Default value:	4 mA	Parameter type:	Range, 0 - 20 mA
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

Enter the current (mA) that corresponds to the low reference value set in parameter **35-44 Term. X48/2 Low Ref./Feedb. Value**. The value must be more than 2 mA to activate the live zero timeout function in parameter **6-01 Live Zero Timeout Function**.

35-43 Term. X48/2 High Current

Default value:	20 mA	Parameter type:	Range, 0 - 20 mA
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	True

Enter the current (mA) that corresponds to the high reference value set in parameter **35-45 Term. X48/2 High Ref./Feedb. Value**.

35-44 Term. 48/2 Low Ref./Feedb. Value

Default value:	0 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the reference or feedback value (in RPM, Hz, bar, and so on) that corresponds to the voltage or current set in parameter **35-42 Term. X48/2 Low Current**.

35-45 Term. 48/2 High Ref./Feedb. Value

Default value:	100 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the reference or feedback value (in RPM, Hz, bar, and so on) that corresponds to the voltage or current set in parameter **35-43 Term. X48/2 High Current**.

35-46 Term. X48/2 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X48/2. A high time constant value improves dampening but also increases the time delay through the filter.

6.35 Parameter Group 36-** Programmable I/O Option

6.35.1 36-0* I/O Mode



NOTE: The following parameters are only available in FC 302:

- Parameter **36-00 Terminal X49/1 Mode**
- Parameter **36-01 Terminal X49/3 Mode**
- Parameter **36-02 Terminal X49/5 Mode**

36-00 Term. X49/1 Mode

Default value:	[1] Voltage	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the output mode of analog terminal X49/1.

Option	Name	Description
[0]	Current	
[1]*	Voltage	
[2]	PT1000 [°C]	
[3]	PT1000 [°F]	
[4]	Ni 1000 [°C]	
[5]	Ni 1000 [°F]	

36-01 Term. X49/3 Mode

Default value:	[1] Voltage	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the output mode of analog terminal X49/3.

Option	Name	Description
[0]	Current	
[1]*	Voltage	
[2]	PT1000 [°C]	
[3]	PT1000 [°F]	
[4]	Ni 1000 [°C]	
[5]	Ni 1000 [°F]	

36-02 Term. X49/5 Mode

Default value:	[1] Voltage	Parameter type:	Option

Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the output mode of analog terminal X49/5.

Option	Name	Description
[0]	Current	
[1]*	Voltage	
[2]	PT1000 [°C]	
[3]	PT1000 [°F]	
[4]	Ni 1000 [°C]	
[5]	Ni 1000 [°F]	

36-03 Term. X49/7 Mode

Default value:	[0] Voltage 0–10 V	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the output mode of analog terminal X49/7.

Option	Name	Description
[0]*	Voltage 0–10V	
[1]	Voltage 2–10V	
[2]	Current 0–20mA	
[3]	Current 4–20mA	
[4]	Digital	

 **NOTE:** This option is only available in FC 302.

36-04 Term. X49/9 Mode

Default value:	[0] Voltage 0–10V	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the output mode of analog terminal X49/9.

Option	Name	Description
[0]*	Voltage 0–10V	
[1]	Voltage 2–10V	
[2]	Current 0–20mA	
[3]	Current 4–20mA	
[4]	Digital	

 **NOTE:** This option is only available in FC 302.

36-05 Term. X49/11 Mode

Default value:	[0] Voltage 0–10V	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the output mode of analog terminal X49/11.

Option	Name	Description
[0]*	Voltage 0–10V	
[1]	Voltage 2–10V	
[2]	Current 0–20mA	
[3]	Current 4–20mA	
[4]	Digital	



NOTE: This option is only available in FC 302.

6.35.2 36-1* Analog Input X49/1



NOTE: This parameter group is only available in FC 302.

36-10 Terminal X49/1 Low Voltage

Default value:	0.07 V	Parameter type:	Range, 0 - 10 V
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the voltage corresponding to the low reference value set in parameter **36-14 Term. X49/1 Low Ref./Feedb. Value**.

36-11 Terminal X49/1 Low Current

Default value:	4 mA	Parameter type:	Range, 0 - 20 mA
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	True

Enter the current (mA) corresponding to the low reference value set in parameter **36-14 Term. X49/1 Low Ref./Feedb. Value**.

36-12 Terminal X49/1 High Voltage

Default value:	10 V	Parameter type:	Range, 0 - 10 V
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the voltage corresponding to the high reference value set in parameter **36-15 Term. X49/1 High Ref./Feedb. Value**.

36-13 Terminal X49/1 High Current

Default value:	20 mA	Parameter type:	Range, 0 - 20 mA

Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	True

Enter the current (mA) corresponding to the high reference value set in parameter **36-15 Term- X49/1 High Ref./Feedb. Value**.

36-14 Terminal X49/1 Low Ref./Feedb. Value

Default value:	0 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the reference or feedback value (in RPM, Hz, bar, and so on) corresponding to the voltage or current set in parameter **36-10 Terminal X49/1 Low Voltage** or parameter **36-11 Terminal X49/1 Low Current**.

36-15 Terminal X49/1 High Ref./Feedb. Value

Default value:	100 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the reference or feedback value (in RPM, Hz, bar, and so on) corresponding to the voltage or current set in parameter **36-12 Terminal X49/1 High Voltage** or parameter **X49/1 High Current**.

36-16 Term. X49/1 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X49/1. A high time constant value improves dampening but it also increases the time delay through the filter.

6.35.3 36-2* Analog Input X49/3



NOTE: This parameter group is only available in FC 302.

36-20 Terminal X49/3 Low Voltage

Default value:	0.007 V	Parameter type:	Range, 0 - 10 V
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the voltage corresponding to the low reference value set in parameter **36-24 Term. X49/3 Low Ref./Feedb. Value**.

36-21 Terminal X49/3 Low Current

Default value:	4 mA	Parameter type:	Range, 0 - 20 mA
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	True

Enter the current (mA) corresponding to the low reference value set in parameter **36-24 Term. X49/3 Low Ref./Feedb. Value**.

36-22 Terminal X49/3 High Voltage

Default value:	10 V	Parameter type:	Range, 0 - 10 V
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the voltage corresponding to the high reference value set in parameter **36-25 Term. X49/3 High Ref./Feedb. Value**.

36-23 Terminal X49/3 High Current

Default value:	20 mA	Parameter type:	Range, 0 - 20 mA
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	True

Enter the current (mA) corresponding to the high reference value set in parameter **36-25 Term. X49/3 High Ref./Feedb. Value**.

36-24 Terminal X49/3 Low Ref./Feedb. Value

Default value:	0 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the reference or feedback value (in RPM, Hz, bar, and so on) corresponding to the voltage or current set in parameter **36-20 Terminal X49/1 Low Voltage** or parameter **36-21 Terminal X49/1 Low Current**.

36-25 Terminal X49/3 High Ref./Feedb. Value

Default value:	100 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the reference or feedback value (in RPM, Hz, bar, and so on) corresponding to the voltage or current set in parameter **36-22 Terminal X49/3 High Voltage** or parameter **36-23 Terminal X49/3 High Current**.

36-26 Term. X49/3 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	0

Data type:	Uint16	Change during operation:	True

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X49/3. A high time constant value improves dampening but also increases the time delay through the filter.

6.35.4 36-3* Analog Input X49/5



NOTE: This parameter group is only available in FC 302.

36-30 Terminal X49/5 Low Voltage

Default value:	0.07 V	Parameter type:	Range, 0 - 10 V
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the voltage corresponding to the low reference value set in parameter **36-34 Term. X49/5 Low Ref./Feedb. Value.**

36-31 Terminal X49/3 Low Current

Default value:	4 mA	Parameter type:	Range, 0 - 20 mA
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	True

Enter the current (mA) corresponding to the low reference value set in parameter **36-34 Term. X49/5 Low Ref./Feedb. Value.**

36-32 Terminal X49/5 High Voltage

Default value:	10 V	Parameter type:	Range, 0 - 10 V
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Enter the voltage corresponding to the high reference value set in parameter **36-35 Term. X49/5 High Ref./Feedb. Value.**

36-33 Terminal X49/5 High Current

Default value:	20 mA	Parameter type:	Range, 0 - 20 mA
Setup:	All setups	Conversion index:	-3
Data type:	Int16	Change during operation:	True

Enter the current (mA) corresponding to the high reference value set in parameter **36-35 Term. X49/5 High Ref./Feedb. Value.**

36-34 Terminal X49/5 Low Ref./Feedb. Value

Default value:	0 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the reference or feedback value (in RPM, Hz, bar, and so on) corresponding to the voltage or current set in parameter **36-30 Terminal X49/5 Low Voltage** or parameter **36-31 Terminal X49/4 Low Current**.

36-35 Terminal X49/5 High Ref./Feedb. Value

Default value:	100 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	True

Enter the reference or feedback value (in RPM, Hz, bar, and so on) corresponding to the voltage or current set in parameter **36-32 Terminal X49/5 High Voltage** or parameter **36-33 Terminal X49/5 High Current**.

36-36 Term. X49/5 Filter Time Constant

Default value:	0.001 s	Parameter type:	Range, 0.001 - 10 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Enter the filter time constant. This is a first-order digital low-pass filter time constant for suppressing electrical noise in terminal X49/5. A high time constant value improves dampening but also increases the time delay through the filter.

6.35.5 36-4* Output X49/7



NOTE: The following parameter is only available in FC 302:

- Parameter **36-41 Terminal X49/7 Digital Output**

Use the parameters in this group to configure the mode of inputs and outputs of VLT® Programmable I/O MCB 115.

36-40 Terminal X49/7 Analogue Output

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the functionality of terminal X49/7.

Option	Name	Description
[0]*	No operation	Indicates no signal on the analog output.
[52]	MCO	
[100]	Output frequency	0 Hz = 0 mA; 100 Hz = 20 mA.
[101]	Reference	Parameter 3-00 Reference Range [Min - Max] 0% = 0 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max - Max] -100% = 0 mA; 0% = 10 mA; +100% = 20 mA.
[102]	Feedback	

Option	Name	Description
[103]	Motor current	The value is taken from parameter 16-37 Inv. Max. Current. The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160 % = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{20\text{mA} \times 22\text{A}}{38.4\text{A}} = 11.46\text{mA}$ When the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, \text{MAX}} \times 100}{I_{\text{Motor, Nom}}} = \frac{38.4 \times 100}{22} = 175\%$
[104]	Torque rel to limit	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[105]	Torque relate to rated	The torque is related to the motor torque setting.
[106]	Power	Taken from parameter 1-20 Motor Power [kW] .
[107]	Speed	Taken from parameter 3-03 Maximum Reference . 20 mA equals the value in parameter 3-03 Maximum Reference .
[108]	Torque	Torque reference related to 160% torque.
[109]	Max out freq	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[113]	PID clamped output	
[117]	Shaft power	
[119]	Torque % lim	
[123]	Speed both dir	
[139]	Bus ctrl	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[141]	Bus ctrl t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[147]	Main act val	
[158]	Motor Volt.	
[254]	DC link	

36-41 Terminal X49/7 Digital Output

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]*	No operation	
[1]	Control ready	
[2]	Drive ready	
[3]	Drive rdy/rem ctrl	
[4]	Enable/no warning	
[5]	Running	

Option	Name	Description
[6]	Running/no warning	
[7]	Run in range/no warn	
[8]	Run on ref/no warn	
[9]	Alarm	
[10]	Alarm or warning	
[11]	At torque limit	
[12]	Out of current range	
[13]	Below current, low	
[14]	Above current, high	
[15]	Out of speed range	
[16]	Below speed, low	
[17]	Above speed, high	
[18]	Out of feedb. range	
[19]	Below feedback, low	
[20]	Above feedback, high	
[21]	Thermal warning	
[22]	Ready,no thermal W	
[23]	Remote,ready, no TW	
[24]	Ready, Voltage OK	
[25]	Reverse	
[26]	Bus OK	
[27]	Torque limit & stop	
[28]	Brake, no brake war	
[29]	Brake ready, no fault	
[30]	Brake fault (IGBT)	
[31]	Relay 123	
[32]	Mech brake ctrl	
[33]	Safe stop active	
[35]	External interlock	
[38]	Motor feedback error	
[39]	Tracking error	
[40]	Out of ref range	
[41]	Below reference, low	
[42]	Above ref, high	
[43]	Extended PID Limit	
[45]	Bus ctrl.	
[46]	Bus ctrl, 1 if timeout	

Option	Name	Description
[47]	Bus ctrl, 0 if timeout	
[50]	On reference	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[51]	MCO controlled	
[59]	Remote, enable, no TW	
[60]	Comparator 0	
[61]	Comparator 1	
[62]	Comparator 2	
[63]	Comparator 3	
[64]	Comparator 4	
[65]	Comparator 5	
[66]	Comparator 6	
[67]	Comparator 7	
[68]	Comparator 8	
[69]	Comparator 9	
[70]	Logic rule 0	
[71]	Logic rule 1	
[72]	Logic rule 2	
[73]	Logic rule 3	
[74]	Logic rule 4	
[75]	Logic rule 5	
[76]	Logic rule 6	
[77]	Logic rule 7	
[78]	Logic rule 8	
[79]	Logic rule 9	
[80]	SL digital output A	
[81]	SL digital output B	
[82]	SL digital output C	
[83]	SL digital output D	
[84]	SL digital output E	
[85]	SL digital output F	
[90]	kWh counter pulse	
[96]	Reverse after ramp	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.

Option	Name	Description
[98]	Virtual master dir	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[120]	Local ref active	
[121]	Remote ref active	
[122]	No alarm	
[123]	Start command activ	
[124]	Running reverse	
[125]	Drive in hand mode	
[126]	Drive in auto mode	
[150]	CBM warning	 NOTE: This option is only available in FC 302.
[151]	ATEX ETR cur. alarm	
[152]	ATEX ETR freq. alarm	
[153]	ATEX ETR cur. warning	
[154]	ATEX ETR freq. warning	
[173]	10Wh counter pulse	
[180]	Clock fault	
[181]	Prev. Maintenance	
[188]	AHF Capacitor Connect	
[189]	External Fan Control	
[190]	Safe Function active	
[191]	Safe Opt. Reset req.	
[192]	RS Flipflop 0	
[193]	RS Flipflop 1	
[194]	RS Flipflop 2	
[195]	RS Flipflop 3	
[196]	RS Flipflop 4	
[197]	RS Flipflop 5	
[198]	RS Flipflop 6	
[199]	RS Flipflop 7	
[221]	IGBT-cooling	
[222]	Homing OK	 NOTE: This option is only available with software version 48.4X or newer.

Option	Name	Description
[223]	On target	 NOTE: This option is only available with software version 48.4X or newer.
[224]	Position limit	 NOTE: This option is only available with software version 48.4X or newer.
[225]	Position error	 NOTE: This option is only available with software version 48.4X or newer.
[226]	Touch on target	 NOTE: This option is only available with software version 48.4X or newer.
[227]	Touch activated	 NOTE: This option is only available with software version 48.4X or newer.
[231]	In power lim. mot.	
[232]	In power lim. gen.	
[233]	In power limit	
[234]	PE power off	
[246]	Emergency mode was act.	
[247]	Emergency mode	
[249]	Emcy m. OPR unexpected	
[250]	Emcy mode limits	
[254]	Testing emcy mode	

36-42 Terminal X49/7 Min Scale

Default value:	0%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Int16	Change during operation:	True

Match the minimum output of terminal X49/7 with a required value. The required value is defined as a percentage of the value selected in parameter **36-40 Terminal X49/7 Analogue Output**. To know more about how this parameter works, see parameter **6-52 Terminal 42 Output Max Scale**. The following example describes how the drive uses this parameter.

Example:

- Parameter **36-03 Terminal X49/7 Mode** = [0] Voltage 0–10 V.
- Parameter **36-40 Terminal X49/7 Analogue Output** = [100] Output frequency.
- Parameter **4-19 Max Output Frequency** = 200 Hz.

Application requirement: If the output frequency is lower than 20 Hz, the output of terminal X49/7 should be 0 V. To fulfil the example requirement, enter 10% in parameter **36-42 Terminal X49/7 Min. Scale**.

36-43 Terminal X49/7 Max. Scale

Default value:	100%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Scale the maximum output of terminal X49/7. For example, the scaling is done for the following reasons:

- To provide an output value lower than the maximum possible value.
- To provide the full signal range using output values lower than a certain limit.

To know more about how this parameter works, see parameter **6-52 Terminal 42 Output Max Scale**.

Example:

- Parameter **36-03 Terminal X49/7 Mode** = [0] Voltage 0–10 V
- Parameter **36-40 Terminal X49/7 Analogue Output** = [100] Output Frequency.
- Parameter **4-19 Max Output Frequency** = 200 Hz.

Example case 1: 5 V maximum output is required when the output frequency is 200 Hz. Parameter **36-43 Terminal X49/7 Max. Scale** x 100% = 200%.

Example case 2: 10 V maximum output is required when the output frequency is 150 Hz (75% of the maximum output frequency). Parameter **36-43 Terminal X49/7 Max. Scale** = 75%.

36-44 Terminal X49/7 Bus Ctrl

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	N2	Change during operation:	True

This parameter contains the output level of terminal X49/7 if the terminal is controlled by bus.

36-45 Terminal X49/7 Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	0
Data type:	UInt16	Change during operation:	True

The drive sends the value of this parameter to the output terminal when the terminal is controlled by a fieldbus and a timeout is detected.

6.35.6 36-5* Output X49/9

Use the parameters in this group to configure the mode of inputs and outputs of VLT® Programmable I/O MCB 115.



NOTE: The following parameter is only available in FC 302:

- Parameter **36-51 Terminal X49/9 Digital Output**

36-50 Terminal X49/9 Analogue Output

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–

Data type:	Uint8	Change during operation:	True

Select the functionality of terminal X49/9.

Option	Name	Description
[0]*	No operation	Indicates no signal on the analog output.
[52]	MCO	
[100]	Output frequency	0 Hz = 0 mA; 100 Hz = 20 mA.
[101]	Reference	Parameter 3-00 Reference Range [Min - Max] 0% = 0 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max - Max] -100% = 0 mA; 0% = 10 mA; +100% = 20 mA.
[102]	Feedback	
[103]	Motor current	The value is taken from parameter 16-37 Inv. Max. Current . The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160 % = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{20\text{mA} \times 22\text{A}}{38.4\text{A}} = 11.46\text{mA}$ When the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, MAX} \times 100}{I_{Motor, Nom}} = \frac{38.4 \times 100}{22} = 175\%$
[104]	Torque rel to limit	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[105]	Torque relate to rated	The torque is related to the motor torque setting.
[106]	Power	Taken from parameter 1-20 Motor Power [kW] .
[107]	Speed	Taken from parameter 3-03 Maximum Reference . 20 mA equals the value in parameter 3-03 Maximum Reference .
[108]	Torque	Torque reference related to 160% torque.
[109]	Max out freq	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[113]	PID clamped output	
[117]	Shaft power	
[119]	Torque % lim	
[123]	Speed both dir	
[139]	Bus ctrl	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[141]	Bus ctrl t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[147]	Main act val	
[158]	Motor Volt.	
[254]	DC link	

36-51 Terminal X49/9 Digital Output

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No operation	
[1]	Control ready	
[2]	Drive ready	
[3]	Drive rdy/rem ctrl	
[4]	Enable/no warning	
[5]	Running	
[6]	Running/no warning	
[7]	Run in range/no warn	
[8]	Run on ref/no warn	
[9]	Alarm	
[10]	Alarm or warning	
[11]	At torque limit	
[12]	Out of current range	
[13]	Below current, low	
[14]	Above current, high	
[15]	Out of speed range	
[16]	Below speed, low	
[17]	Above speed, high	
[18]	Out of feedb. range	
[19]	Below feedback, low	
[20]	Above feedback, high	
[21]	Thermal warning	
[22]	Ready,no thermal W	
[23]	Remote,ready, no TW	
[24]	Ready, Voltage OK	
[25]	Reverse	
[26]	Bus OK	
[27]	Torque limit & stop	
[28]	Brake, no brake war	
[29]	Brake ready, no fault	
[30]	Brake fault (IGBT)	
[31]	Relay 123	

Option	Name	Description
[32]	Mech brake ctrl	
[33]	Safe stop active	
[35]	External interlock	
[38]	Motor feedback error	
[39]	Tracking error	
[40]	Out of ref range	
[41]	Below reference, low	
[42]	Above ref, high	
[43]	Extended PID Limit	
[45]	Bus ctrl.	
[46]	Bus ctrl, 1 if timeout	
[47]	Bus ctrl, 0 if timeout	
[50]	On reference	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[51]	MCO controlled	
[59]	Remote, enable, no TW	
[60]	Comparator 0	
[61]	Comparator 1	
[62]	Comparator 2	
[63]	Comparator 3	
[64]	Comparator 4	
[65]	Comparator 5	
[66]	Comparator 6	
[67]	Comparator 7	
[68]	Comparator 8	
[69]	Comparator 9	
[70]	Logic rule 0	
[71]	Logic rule 1	
[72]	Logic rule 2	
[73]	Logic rule 3	
[74]	Logic rule 4	
[75]	Logic rule 5	
[76]	Logic rule 6	
[77]	Logic rule 7	
[78]	Logic rule 8	
[79]	Logic rule 9	

Option	Name	Description
[80]	SL digital output A	
[81]	SL digital output B	
[82]	SL digital output C	
[83]	SL digital output D	
[84]	SL digital output E	
[85]	SL digital output F	
[90]	kWh counter pulse	
[96]	Reverse after ramp	NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[98]	Virtual master dir	NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[120]	Local ref active	
[121]	Remote ref active	
[122]	No alarm	
[123]	Start command activ	
[124]	Running reverse	
[125]	Drive in hand mode	
[126]	Drive in auto mode	
[150]	CBM warning	NOTE: This option is only available in FC 302.
[151]	ATEX ETR cur. alarm	
[152]	ATEX ETR freq. alarm	
[153]	ATEX ETR cur. warning	
[154]	ATEX ETR freq. warning	
[173]	10Wh counter pulse	
[180]	Clock fault	
[181]	Prev. Maintenance	
[188]	AHF Capacitor Connect	
[189]	External Fan Control	
[190]	Safe Function active	
[191]	Safe Opt. Reset req.	
[192]	RS Flipflop 0	
[193]	RS Flipflop 1	
[194]	RS Flipflop 2	
[195]	RS Flipflop 3	

Option	Name	Description
[196]	RS Flipflop 4	
[197]	RS Flipflop 5	
[198]	RS Flipflop 6	
[199]	RS Flipflop 7	
[221]	IGBT-cooling	
[222]	Homing OK	 NOTE: Only available with software version 48.4X or newer.
[223]	On target	 NOTE: Only available with software version 48.4X or newer.
[224]	Position limit	 NOTE: Only available with software version 48.4X or newer.
[225]	Position error	 NOTE: Only available with software version 48.4X or newer.
[226]	Touch on target	 NOTE: Only available with software version 48.4X or newer.
[227]	Touch activated	 NOTE: Only available with software version 48.4X or newer.
[231]	In power lim. mot.	
[232]	In power lim. gen.	
[233]	In power limit	
[234]	PE power off	
[246]	Emcy mode was act.	
[247]	Emergency mode	
[249]	Emcy m OPR unexpected	
[250]	Emcy mode limits	
[254]	Testing emcy mode	

36-52 Terminal X49/9 Min. Scale

Default value:	0%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Match the minimum output of terminal X49/9 with a required value. The required value is defined as a percentage of the value selected in parameter **36-50 Terminal X49/9 Analogue Output**. To know more about how this parameter works, see parameter **6-52 Terminal 42 Output Max Scale**. The following example describes how the drive uses this parameter.

Example:

- Parameter **36-04 Terminal X49/9 Mode** = [0] Voltage 0–10 V.
- Parameter **36-50 Terminal X49/9 Analogue Output** = [100] Output frequency.

- Parameter **4-19 Max Output Frequency** = 200 Hz.

Application requirement: If the output frequency is lower than 20 Hz, the output of terminal X49/9 should be 0 V. To fulfill the example requirement, enter 10% in parameter **36-52 Terminal X49/9 Min. Scale**.

36-53 Terminal X49/9 Max. Scale

Default value:	100%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Scale the maximum output of terminal X49/9. For example, the scaling is done for the following reasons:

- To provide an output value lower than the maximum possible value.
- To provide the full signal range using output values lower than a certain limit.

To know more about how this parameter works, see parameter **6-52 Terminal 42 Output Max Scale**.

Example:

- Parameter **36-04 Terminal X49/9 Mode** = [0] Voltage 0–10 V
- Parameter **36-50 Terminal X49/9 Analogue Output** = [100] Output Frequency.
- Parameter **4-19 Max Output Frequency** = 200 Hz.

Example case 1: 5 V maximum output is required when the output frequency is 200 Hz. Parameter **36-53 Terminal X49/9 Max. Scale** x 100% = 200%.

Example case 2: 10 V maximum output is required when the output frequency is 150 Hz (75% of the maximum output frequency). Parameter **36-53 Terminal X49/9 Max. Scale** = 75%.

36-54 Terminal X49/9 Bus Ctrl

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	N2	Change during operation:	True

This parameter contains the output level of terminal X49/9 if the terminal is controlled by bus.

36-55 Terminal X49/9 Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	1 setup	Conversion index:	0
Data type:	UInt16	Change during operation:	True

The drive sends the value of this parameter to the output terminal when the terminal is controlled by a fieldbus and a timeout is detected.

6.35.7 36-6* Output X49/11

Use the parameters in this group to configure the mode of inputs and outputs of VLT® Programmable I/O MCB 115.



NOTE: The following parameter is only available in FC 302:

- Parameter **36-61 Terminal X49/11 Digital Output**

36-60 Terminal X49/11 Analogue Output

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select the functionality of terminal X49/11.

Option	Name	Description
[0]*	No operation	Indicates no signal on the analog output.
[52]	MCO	
[100]	Output frequency	0 Hz = 0 mA; 100 Hz = 20 mA.
[101]	Reference	Parameter 3-00 Reference Range [Min - Max] 0% = 0 mA; 100% = 20 mA Parameter 3-00 Reference Range [-Max - Max] -100% = 0 mA; 0% = 10 mA; +100% = 20 mA.
[102]	Feedback	
[103]	Motor current	The value is taken from parameter 16-37 Inv. Max. Current . The inverter maximum current (160% current) is equal to 20 mA. Example: Inverter normal current (11 kW) is 24 A. 160 % = 38.4 A. Motor normal current is 22 A, the readout is 11.46 mA. $\frac{20\text{mA} \times 22\text{A}}{38.4\text{A}} = 11.46\text{mA}$ When the normal motor current is equal to 20 mA, the output setting of parameter 6-52 Terminal 42 Output Max Scale is: $\frac{I_{VLT, MAX} \times 100}{I_{Motor, Nom}} = \frac{38.4 \times 100}{22} = 175\%$
[104]	Torque rel to limit	The torque setting is related to the setting in parameter 4-16 Torque Limit Motor Mode .
[105]	Torque relate to rated	The torque is related to the motor torque setting.
[106]	Power	Taken from parameter 1-20 Motor Power [kW] .
[107]	Speed	Taken from parameter 3-03 Maximum Reference . 20 mA equals the value in parameter 3-03 Maximum Reference .
[108]	Torque	Torque reference related to 160% torque.
[109]	Max out freq	0 Hz = 0 mA, parameter 4-19 Max Output Frequency = 20 mA.
[113]	PID clamped output	
[117]	Shaft power	
[119]	Torque % lim	
[123]	Speed both dir	
[139]	Bus ctrl	An output value set from fieldbus process data. The output works independently of internal functions in the drive.
[141]	Bus ctrl t.o.	Parameter 4-54 Warning Reference Low defines the behavior of the analog output in case of fieldbus timeout.
[147]	Main act val	

Option	Name	Description
[158]	Motor volt.	
[254]	DC link	

36-61 Terminal X49/11 Digital Output

Default value:	[0] No operation	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	No operation	
[1]	Control ready	
[2]	Drive ready	
[3]	Drive rdy/rem ctrl	
[4]	Enable/no warning	
[5]	Running	
[6]	Running/no warning	
[7]	Run in range/no warn	
[8]	Run on ref/no warn	
[9]	Alarm	
[10]	Alarm or warning	
[11]	At torque limit	
[12]	Out of current range	
[13]	Below current, low	
[14]	Above current, high	
[15]	Out of speed range	
[16]	Below speed, low	
[17]	Above speed, high	
[18]	Out of feedb. range	
[19]	Below feedback, low	
[20]	Above feedback, high	
[21]	Thermal warning	
[22]	Ready,no thermal W	
[23]	Remote,ready, no TW	
[24]	Ready, Voltage OK	
[25]	Reverse	
[26]	Bus OK	
[27]	Torque limit & stop	

Option	Name	Description
[28]	Brake, no brake war	
[29]	Brake ready, no fault	
[30]	Brake fault (IGBT)	
[31]	Relay 123	
[32]	Mech brake ctrl	
[33]	Safe stop active	
[35]	External interlock	
[38]	Motor feedback error	
[39]	Tracking error	
[40]	Out of ref range	
[41]	Below reference, low	
[42]	Above ref, high	
[43]	Extended PID Limit	
[45]	Bus ctrl.	
[46]	Bus ctrl, 1 if timeout	
[47]	Bus ctrl, 0 if timeout	
[50]	On reference	
 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.		
[51]	MCO controlled	
[59]	Remote, enable, no TW	
[60]	Comparator 0	
[61]	Comparator 1	
[62]	Comparator 2	
[63]	Comparator 3	
[64]	Comparator 4	
[65]	Comparator 5	
[66]	Comparator 6	
[67]	Comparator 7	
[68]	Comparator 8	
[69]	Comparator 9	
[70]	Logic rule 0	
[71]	Logic rule 1	
[72]	Logic rule 2	
[73]	Logic rule 3	
[74]	Logic rule 4	
[75]	Logic rule 5	

Option	Name	Description
[76]	Logic rule 6	
[77]	Logic rule 7	
[78]	Logic rule 8	
[79]	Logic rule 9	
[80]	SL digital output A	
[81]	SL digital output B	
[82]	SL digital output C	
[83]	SL digital output D	
[84]	SL digital output E	
[85]	SL digital output F	
[90]	kWh counter pulse	
[96]	Reverse after ramp	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[98]	Virtual master dir	 NOTE: This option is only available in FC 302 with IMC software version 48.4X or newer.
[120]	Local ref active	
[121]	Remote ref active	
[122]	No alarm	
[123]	Start command activ	
[124]	Running reverse	
[125]	Drive in hand mode	
[126]	Drive in auto mode	
[150]	CBM warning	 NOTE: This option is only available in FC 302.
[151]	ATEX ETR cur. alarm	
[152]	ATEX ETR freq. alarm	
[153]	ATEX ETR cur. warning	
[154]	ATEX ETR freq. warning	
[173]	10Wh counter pulse	
[180]	Clock fault	
[181]	Prev. Maintenance	
[188]	AHF Capacitor Connect	
[189]	External Fan Control	
[190]	Safe Function active	
[191]	Safe Opt. Reset req.	

Option	Name	Description
[192]	RS Flipflop 0	
[193]	RS Flipflop 1	
[194]	RS Flipflop 2	
[195]	RS Flipflop 3	
[196]	RS Flipflop 4	
[197]	RS Flipflop 5	
[198]	RS Flipflop 6	
[199]	RS Flipflop 7	
[221]	IGBT-cooling	
[222]	Homing OK	NOTE: This option is only available with software version 48.4X or newer.
[223]	On target	NOTE: This option is only available with software version 48.4X or newer.
[224]	Position limit	NOTE: This option is only available with software version 48.4X or newer.
[225]	Position error	NOTE: This option is only available with software version 48.4X or newer.
[226]	Touch on target	NOTE: This option is only available with software version 48.4X or newer.
[227]	Touch activated	NOTE: This option is only available with software version 48.4X or newer.
[231]	In power lim. mot.	
[232]	In power lim. gen.	
[233]	In power limit	
[234]	PE power off	
[246]	Emcy mode was act.	
[247]	Emergency mode	
[249]	Emcy m. OPR unexpected	
[250]	Emcy mode limits	
[254]	Testing emcy mode	

36-62 Terminal X49/11 Min. Scale

Default value:	0%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Match the minimum output of terminal X49/11 with a required value. The required value is defined as a percentage of the value selected in parameter **36-60 Terminal X49/11 Analogue Output**. To know more about how this parameter works, see parameter **6-52 Terminal 42 Output Max Scale**. The following example describes how the drive uses this parameter.

Example:

- Parameter **36-05 Terminal X49/16 Mode** = [0] Voltage 0–10 V.
- Parameter **36-50 Terminal X49/11 Analogue Output** = [100] Output frequency.
- Parameter **4-19 Max Output Frequency** = 200 Hz.

Application requirement: If the output frequency is lower than 20 Hz, the output of terminal X49/9 should be 0 V. To fulfil the example requirement, enter 10% in parameter **36-62 Terminal X49/11 Min. Scale**.

36-63 Terminal X49/11 Max. Scale

Default value:	100%	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

Scale the maximum output of terminal X49/11. For example, the scaling is done for the following reasons:

- To provide an output value lower than the maximum possible value.
- To provide the full signal range using output values lower than a certain limit.

To know more about how this parameter works, see parameter **6-52 Terminal 42 Output Max Scale**.

Example:

- Parameter **36-05 Terminal X49/11 Mode** = [0] Voltage 0–10 V
- Parameter **36-60 Terminal X49/11 Analogue Output** = [100] Output Frequency.
- Parameter **4-19 Max Output Frequency** = 200 Hz.

Example case 1: 5 V maximum output is required when the output frequency is 200 Hz. Parameter **36-63 Terminal X49/11 Max. Scale** $100\% = 200\%$.

Example case 2: 10 V maximum output is required when the output frequency is 150 Hz (75% of the maximum output frequency). Parameter **36-63 Terminal X49/11 Max. Scale** = 75%.

36-64 Terminal X49/11 Bus Ctrl

Default value:	0%	Parameter type:	Range, 0 - 100%
Setup:	All setups	Conversion index:	0
Data type:	N2	Change during operation:	True

This parameter contains the output level of terminal X49/11 if the terminal is controlled by bus.

36-65 Terminal X49/11 Timeout Preset

Default value:	0%	Parameter type:	Range, 0 - 100%

Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

The drive sends the value of this parameter to the output terminal when the terminal is controlled by a fieldbus and a timeout is detected.

6.36 Parameter Group 40-** Special Settings

6.36.1 40-1* Aux. Functions Control

40-10 Kin. Back-up UdcRef

Default value:	Size related	Parameter type:	Range, 300 - 1080 V
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set DC-link voltage for kinetic backup mode. To set a higher DC-link voltage for riding through an unbalanced fault, set parameter **14-10 Mains Failure** to **[4] Kinetic back-up** and leave parameter **40-14 Mains Loss Duration** as set. If ride through is not required, set parameter **14-10 Mains Failure** to either **[1] Ctrl. ramp-down**, **[2] Ctrl. ramp-down, trip**, or **[5] Kinetic back-up, trip**.

40-11 Kin. Back-up Integral Time

Default value:	Size related	Parameter type:	Range, 0.001 - 1.000 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

The kinetic back-up controller integral time value enables optimizing the DC-link voltage response. If there is external capacitance on the DC link, increase the value. To obtain a fast control response, decrease the value. However, if the value is too low, the process becomes unstable.

40-12 Kin. Back-up Lead Filter Time

Default value:	Size related	Parameter type:	Range, 0.001 - 1000 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True



NOTE: This parameter is only valid in VVC+ control.

This parameter specifies the kinetic back-up controller lead filter time. Increase this value to ensure stable DC-link voltage control for high-inertia applications.

40-13 Kin. Back-up Min Run Time

Default value:	Size related	Parameter type:	Range, 0.005 - 2 s
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	True

Minimum runtime of the kinetic back-up. Kinetic backup control must run during this time, even mains voltage can come back within this time span. The purpose of this function is to avoid the drive frequently changing in and out of kinetic back-up mode, if fluctuating mains voltage occurs.

40-14 Mains Loss Duration

Default value:	60.00 s	Parameter type:	Range, 0.05 - 60.00 s
Setup:	All setups	Conversion index:	-2
Data type:	UInt16	Change during operation:	True

Enter the maximum value of mains loss duration. When parameter **14-10 Mains Failure = [4] Kinetic Back-up**, the DC-link voltage boosts to the value set in parameter **40-10 Kin. Back-up UdcRef**. The drive then returns to normal operation. The drive allows 2 successive mains faults. A 3rd mains fault triggers a trip. Setting this parameter to 60 s disables the function.

40-15 Kin.Back-up Start Off

Default value:	Size related	Parameter type:	Range, -200.0 - 200.0 V
Setup:	All setups	Conversion index:	-1
Data type:	UInt16	Change during operation:	True

Set the voltage offset to be added to the kinetic back-up reference to boost the gain when kinetic back-up is activated. This function is used in low-inertia applications.

6.36.2 40-2* PM Motor Specific



NOTE: The following parameters are only available in FC 302:

- Parameter **40-28 Back EMF Protection**
- Parameter **40-29 B-EMF Protection Log Readout**

40-26 Individual Currents

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select whether or not to use individual axis currents for induction calculations.

Option	Name	Description
[0]*	Off	
[1]	On	

40-27 Back EMF Voltage

Default value:	0.0 V	Parameter type:	Readout
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the calculated back EMF voltage.

40-28 Back EMF Protection

Default value:	[1] Enabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

The drive is protected by default from Back EMF, which can be generated by IPM or SPM motor types due to calculated speed limitation. The actual limitation is based on parameter **1-40 Back EMF at 1000 RPM** and protects the drive from motor-generated overvoltage.

CAUTION

By disabling the speed limitation, a risk of destructive effect on the IGBTs can be encountered when the drive loses the motor. If the function is disabled, ensure to protect the drive by other means to prevent motor-generated overvoltage.

Option	Name	Description
[0]	Disabled	
[1]*	Enabled	

40-29 B-EMF Protection Log Readout

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Readout parameter to log events if the Back EMF has been enabled or disabled. The range of the readout parameter is between [0x0 -0xFFFF] hex. The value indicates the bit pattern to identify the current state of Back EMF in the drive. Bit 1 is set: When Back EMF is enabled, the bit is set to 1. Once enabled the Back EMF cannot be reversed. Bit 1 and bit 2: Motor frequency exceeded Back EMF limitation. Bit 2 can be reversed. Bit 1, bit 2, and bit 3: The drive has been coasted as motor frequency exceeded the Back EMF limitation. Bit 1, bit 2, bit 3, bit 4: The drive has generated an overvoltage alarm because the drive has coasted as the motor frequency exceeded Back EMF limitation.

6.36.3 40-3* Fieldbus Profile

40-30 Acc. Delta Speed

Default value:	0	Parameter type:	Range, 0 - 2147483647
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Define the value of delta speed in either rotations per minute or user-defined velocity units. To achieve the best resolution, use the motor synchronous RMP x 100.

40-31 Acc. Delta Time

Default value:	0 s	Parameter type:	Range, 0 - 65535 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Define the value of delta time in seconds. To achieve the best resolution, use values >100.

40-32 Dec. Delta Speed

Default value:	0	Parameter type:	Range, 0 - 2147483647
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Define the value of delta speed in rotations per minute or in user-defined velocity units.

To achieve the best resolution, use the motors synchronous RMP x 100.

40-33 Dec. Delta Time

Default value:	0 s	Parameter type:	Range, 0 - 65535 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Define the value of delta time in seconds. To achieve the best resolution, use values >100.

40-34 Error Code

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

View the error code of the last error which occurred in the drive.

40-35 DS402 Qstop

Default value:	0.01 s	Parameter type:	Range, 0.01 - 3600.00 s
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

40-36 DS 402 Current Actual

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

View the actual current with respect to the rated motor current of the motor current.

40-37 Motor Current

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

View the current in percent of the motor current set in parameter **1-24 Motor Current**.

40-38 Motor Power

Default value:	0%	Parameter type:	Readout
Conversion index:	-2	Data type:	N2
Change during operation:	True		

View the power in percent of the motor power set in parameter *1-20 Motor Power [kW]*.

40-39 Motor Torque

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	N2	Change during operation:	True

View the torque in percent of the rated torque set in parameter *1-26 Motor Cont. Rated Torque*.

6.36.4 40-4* Extend. Fault Log

Parameters in this group are array parameters, where up to 10 alarm logs can be viewed. [0] is the most recently logged data, and [9] is the oldest. This parameter group provides details on reference, frequency, motor current, voltage, DC-link voltage, status, and control word values at the time an alarm occurred.

40-40 Fault Log: Ext. Reference

Default value:	0%	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the present reference value applied on impulse or analog basis when the logged event occurred.

40-41 Alarm Log: Frequency

Default value:	0 Hz	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the actual motor frequency when the logged event occurred.

40-42 Fault Log: Current

Default value:	0 A	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

View the motor current measured when the logged event occurred.

40-43 Fault Log: Voltage

Default value:	0 V	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0

Data type:	Uint16	Change during operation:	False

View the motor voltage when the logged event occurred.

40-44 Fault Log: DC Link Voltage

Default value:	0 V	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View the DC-link voltage when the logged event occurred.

40-45 Fault Log: Control Word

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

View the control word sent from the drive when the logged event occurred.

40-46 Fault Log: Status Word

Default value:	0	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

View the status word sent from the drive when the logged event occurred.

40-47 Alarm Log: Torque

Default value:	0 Nm	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	-1
Data type:	Int32	Change during operation:	False

View the actual motor torque when the logged event occurred.

40-48 Alarm Log: CBM Value

Default value:	0%	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	False

View the actual CBM value for this alarm.

40-49 Alarm Log: CBM Threshold

Default value:	0%	Parameter type:	Readout, Array [10]
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	False

View the CBM threshold for this alarm.

6.36.5 40-5* Advanced Control Settings

This parameter group contains parameters for configuring the advanced motor control settings.

40-50 Flux Sensorless Model Shift

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use this parameter to enable or disable the shifting between flux model 1 and flux model 2 at low speed. See also parameter **1-66 Min. Current at Low Speed**.

Option	Name	Description
[0]	Off	Shifting between flux models 1 and 2 is disabled.
[1]	On	Shifting between flux models 1 and 2 is enabled.

40-51 Flux Sensorless Corr. Gain

Default value:	Size related	Parameter type:	Range, 0.1 - 200.0
Setup:	All setups	Conversion index:	-1
Data type:	Uint32	Change during operation:	True

Adjust the flux correction gain used at low speed.

40-52 Speed PID Anti Windup Gain

Default value:	Size related	Parameter type:	Range, 0 - 500%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

This Flux parameter is active in the drive when the following parameters are set to 1 of the values listed here:

- Parameter **1-00 Configuration Mode**
 - [0] *Speed open loop* or
 - [1] *Speed closed loop* or
 - [4] *Torque open loop*
- Parameter **1-01 Motor Control Principle**
 - [2] *Flux sensorless* or
 - [3] *Flux w/motor feedback*
- Parameter **1-10 Motor Construction**
 - [0] *Asynchron* or
 - [1] *PM, non-salient SPM* or
 - [2] *PM, salient IPM*

40-53 Current PID Anti Windup Gain

Default value:	Size related	Parameter type:	Range, 0 - 500%
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	True

This Flux parameter is active in the drive when the following parameters are set to 1 of the values listed here:

- Parameter **1-00 Configuration Mode**
 - [0] *Speed open loop* or
 - [1] *Speed closed loop* or
 - [4] *Torque open loop*
- Parameter **1-01 Motor Control Principle**
 - [2] *Flux sensorless* or
 - [3] *Flux w/motor feedback*
- Parameter **1-10 Motor Construction**
 - [0] *Asynchron* or
 - [1] *PM, non-salient SPM* or
 - [2] *PM, salient IPM*

40-54 Flux /w Feedback Dynamic Mode

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter is only available in FC 302 with IMC software version 48.8X.

The position and speed controllers are executed on the fastest control task (up to 7 kHz depending on the switching frequency) in flux with motor feedback for PM motors and on the 1 ms task for induction motors. In dynamic mode, the position and speed controllers are also executed on the fastest control task for induction motors. This mode significantly improves control performance for induction motors.

Option	Name	Description
[0]*	Off	Dynamic mode is not activated.
[1]	On	Dynamic mode is activated.

40-55 Modulation Index

Default value:	100%	Parameter type:	Range, 80 - 106%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True



NOTE: This parameter is for IPM and SPM motors in VVC+ control principle only.

Activate this parameter by setting parameter **14-03 Overmodulation** to **[2] User Defined**. Use this parameter to set the maximum modulation index and thus trim the application, especially if running with high-power motors without sine-wave filters. Increasing the maximum modulation index increases the motor voltage and improves efficiency and stability. Setting the modulation index too high may lead to torque ripples on the motor shaft.

40-58 Control Word Source Internal

Default value:	[1] FC RS485	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	UInt8	Change during operation:	False

Option	Name	Description
[0]	None	
[1]*	FC RS485	
[2]	FC USB	
[3]	Option A	
[4]	Option B	
[5]	Option C0	
[6]	Option C1	
[30]	External Can	
[35]	Option A fast	NOTE: This option is only available in FC 302.
[37]	Option C0 fast	NOTE: This option is only available in FC 302.

6.37 Parameter Group 42-** Safety Functions

6.37.1 Introduction to Safety Functions

The parameters in this parameter group are available when a safety option is installed in the drive. For information about the safety-related parameters, see the installation guides for the safety options:

- VLT® Safety Option MCB 150/151 Installation Guide
- VLT® Safety Option MCB 152 Installation Guide

6.37.2 42-0* Speed Performance

42-00 Speed Deviation Timer

Default value:	10 ms	Parameter type:	Range, 10 - 5000 ms
Setup:	2 setups	Conversion index:	-3
Data type:	UInt16	Change during operation:	False

Enter the time for which a speed deviation above 120 RPM between estimated and measured speed is allowed.

42-01 Fast Ramp

Default value:	[0] No	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	No	
[1]	Yes	

6.37.3 42-1* Speed Monitoring

42-10 Measured Speed Source

Default value:	–	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]	None	
[1]	Safe option	

42-11 Encoder Resolution

Default value:	1024	Parameter type:	Range, 1 - configuration dependent
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Encoder or proximity switch resolution of the encoder connected to the MCB 150 TTL and MCB 151 HTL.

42-12 Encoder Direction

Default value:	[0] Clockwise	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	Clockwise	
[1]	Counterclockwise	

42-13 Gear Ratio

Default value:	1	Parameter type:	Range, 0.0001 - 1000.0000
Setup:	1 setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True



NOTE: Only use this parameter when the drive is gear-mounted.

Set the ratio between motor speed and encoder speed.

42-14 Feedback Type

Default value:	[0] With direction info	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	With direction info	
[1]	Without direction info	

42-15 Feedback Filter

Default value:	200 Hz	Parameter type:	Range, 0.01 - 200 Hz
Setup:	2 setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Frequency of the feedback filter. The default value is 200 Hz (off) if the encoder resolution is higher than 150 PPR. A filter value of 200 Hz is selected, meaning the filter is off. The use of filters depends on the given encoder resolution, gear ratio, and feedback type.

42-16 Mounting Type

Default value:	[0] Motor shaft mounted	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	Motor shaft mounted	
[1]	Application mounted	
[2]	Sensorless	

42-17 Tolerance Error

Default value:	120 RPM	Parameter type:	Range, 1 - 600 RPM
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Enter the maximum allowed difference between the speed measured by the encoder and the speed estimated by the drive.

42-18 Zero Speed Timer

Default value:	8760 h	Parameter type:	Range, 0 - 10000 h
Setup:	1 setup	Conversion index:	74

Data type:	Uint16	Change during operation:	False

Time period where the option is allowed to be below 120 RPM when SLS is active before STO is activated.

42-19 Zero Speed Limit

Default value:	120 RPM	Parameter type:	Range, 1 - 600 RPM
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Enter the zero-speed limit. If SLS is active, and if the motor speed is lower than this limit, parameter **42-18 Zero Speed Timer** is activated.

6.37.4 42-2* Safe Input

42-20 Safe Function

Default value:	–	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Enable any of the safety options or disable safety option for the digital safe inputs.

Option	Name	Description
[0]	STO	
[1]	SS1-a	
[2]	SS1-b	
[3]	SLS-a	
[4]	SLS-b	
[5]	Disable	
[8]	SO mon	

42-21 Type

Default value:	[0] NCNC	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	NCNC	
[1]	Antivalent	
[2]	NC	
[3]	NO	

42-22 Discrepancy Time

Default value:	10 ms	Parameter type:	Array [2]

Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	False

An adjustable filter time prevents faults caused by temporary discrepancy.

42-23 Stable Signal Time

Default value:	10 ms	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	-3
Data type:	Uint16	Change during operation:	False

An adjustable signal filter in the safety option suppresses temporary signal changes using test pulse pattern.

42-24 Restart Behaviour

Default value:	[0] Manual	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	Manual	
[1]	Automatic	

6.37.5 42-3* General

42-30 External Failure Reaction

Default value:	[0] STO	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	STO	
[1]	SS1-a	
[2]	SS1-b	

42-31 Reset Source

Default value:	[0] Drive reset	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	Drive reset	
[1]	Drive safe reset	
[2]	Safe option DI2_A	

42-33 Parameter Set Name

Default value:	Size related	Parameter type:	Range, 0 - 8
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[8]	Change during operation:	False

Name of the safe parameter set. It is recommended to enter text with characters to avoid bad customization data error.

42-35 S-CRC Value

Default value:	Size related	Parameter type:	Range, 0 - 65535
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View the S-CRC value of all safety parameters. This parameter is the unique identifier of the safety configuration.

42-36 Level 1 Password

Default value:	Size related	Parameter type:	Range, 0 - 8
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[8]	Change during operation:	False

Enter the level 1 password. This password protects the safety configuration set.

42-37 Level 1 Password Buffer

Default value:	Size related	Parameter type:	Range, 0 - 8
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[8]	Change during operation:	False

Customization via bus. Write the level 1 password that protects the safety configuration set.

6.37.6 42-4* SS1

42-40 Type

Default value:	[0] Delay	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Use this parameter to select the type of SS1 safety function.

Option	Name	Description
[0]*	Delay	
[1]	Ramp (slope)	
[2]	Ramp (time)	

42-41 Ramp Profile

Default value:	[0] Linear	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	Linear	
[2]	S-ramp const time	

42-42 Delay Time

Default value:	1 s	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Configure the time during which STO must be activated.

42-43 Delta T

Default value:	2%	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

T subtracts from the time in parameter **42-42 Delay Time** to get the motor to stop before the timer expires.

42-44 Deceleration Rate

Default value:	1500/s	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Deceleration rate for the SS1 slope-based ramp type.

42-45 Delta V

Default value:	120 RPM	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	False

Tolerance between calculated and actual speed that the safety option allows.

42-46 Zero Speed

Default value:	10 RPM	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	False

When this speed is reached, the safety option activates the STO.

42-47 Ramp Time

Default value:	1 s	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The time it takes to ramp down to 0 RPM.

42-48 S-ramp Ratio at Decel. Start

Default value:	50%	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

The proportion of the total ramp-down time (parameter **42-42 Delay Time**) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

42-49 S-ramp Ratio at Decel. End

Default value:	50%	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	False

The proportion of the total ramp-down time (parameter **42-42 Delay Time**) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

6.37.7 42-5* SLS

42-50 Cut Off Speed

Default value:	270 RPM	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	False

Speed at which the fail-safe reaction gets activated. This should be the value of parameter **42-51 Speed Limits** plus a tolerance.

42-51 Speed Limit

Default value:	150 RPM	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	False

Maximum speed allowed when the SLS function is active.

42-52 Fail Safe Reaction

Default value:	[0] STO	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	STO	
[1]	SS1-a	
[2]	SS1-b	

42-53 Start Ramp

Default value:	[0] No	Parameter type:	Option, Array [2]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	No	
[1]	Yes	

42-54 Ramp Down Time

Default value:	1 s	Parameter type:	Array [2]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

Ramp-down time for the start ramp.

6.37.8 42-6* Safe Fieldbus

42-60 Telegram Selection

Default value:	[0] None	Parameter type:	Option
Setup:	1 setup	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Select the fieldbus type and a telegram configuration for the VLT® Safety Option MCB 15x.

Option	Name	Description
[0]*	None	
[1]	PROFIsafe Std. Tel. 30	

42-61 Destination Address

Default value:	1	Parameter type:	Range, 1 - 65535
Setup:	1 setup	Conversion index:	
Data type:	Uint16	Change during operation:	False

Enter the safe destination address within the safe network.

6.37.9 42-7* SMS

42-70 Activation

Default value:	[0] Inactive	Parameter type:	Option
Setup:	2 setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Option	Name	Description
[0]*	Inactive	
[1]	Active	

42-71 Cut Off Speed

Default value:	1500 RPM	Parameter type:	Range, 120 - 20000 RPM
Setup:	2 setups	Conversion index:	67
Data type:	Uint16	Change during operation:	False

Maximum allowed speed.

6.37.10 42-8* Status

42-80 Safe Option Status

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Shows the safety option status word as a hexadecimal value.

42-81 Safe Option Status 2

Default value:	0	Parameter type:	Range, 0 - 2147483647
Setup:	1 setup	Conversion index:	0
Data type:	Uint32	Change during operation:	True

Shows the safety option status word 2 as a hexadecimal value. For example, it contains DI1, DI2, and blank initial state status.

42-82 Safe Control Word

Default value:	0	Parameter type:	Readout

Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

View the safe control word as a hexadecimal value.

42-83 Safe Status Word

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	True

View the safe status word as a hexadecimal value.

42-85 Active Safe Func.

Default value:	[10] None	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Option	Name	Description
[0]	STO	
[1]	SS1-a	
[2]	SS1-b	
[3]	SLS-a	
[4]	SLS-b	
[8]	SO Mon	
[10]*	None	

42-86 Safe Option Info

Default value:	0	Parameter type:	Range, 0 - 25
Setup:	All setups	Conversion index:	0
Data type:	VisStr[25]	Change during operation:	True

Shows information about the safety option. Can be used on the LCP.

42-87 Time Until Manual Test

Default value:	8761 h	Parameter type:	Array [4]
Setup:	All setups	Conversion index:	
Data type:	Uint16	Change during operation:	True

View the remaining time in hours until the yearly test must be done.

- [0] indicates PUST warning.
- [1] indicates speed suspension warning.
- [2] indicates DI1 offline test required.

- [3] indicates DI2 offline test required.

42-88 Supported Customization File Version

Default value:	Size related	Parameter type:	Array [3]
Setup:	1 setup	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Shows the maximum supported configuration file version (CfgFileVers).

- [0] - the maximum version supported by the safe system (drive with the safety option).
- [1] - the maximum version supported by the safety option.
- [2] - the maximum version supported by the control card.

42-89 Customization File Version

Default value:	Size related	Parameter type:	Range, 0.00 - 99.99
Setup:	1 setup	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Stores the customization file version.

6.37.11 42-9* Special

42-90 Restart the Safe Option

Default value:	[0] No	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Select [1] Yes to restart the VLT® Safety Option MCB 15x without power cycling the drive.

Option	Name	Description
[0]*	No	
[1]	Yes	

6.38 Parameter Group 43-** Unit Readouts

6.38.1 Purpose of the Parameter Group

The parameters in this group provide readouts for monitoring the operation of drives in enclosure sizes D–F.

6.38.2 43-0* Component Status



NOTE: This parameter group is only available in FC 302:

This parameter group contains read-only information on hardware components in the power section. All parameters in this group are arrays:

- [0]: Power card 1 (the master power card in a parallel drive, or the only power card in a drive with a single inverter section).
- [1]: Power card 2 (inverter connection in a parallel drive).

- [2]: Power card 3 (inverter connection in a parallel drive).
- [3]: Power card 4 (inverter connection in a parallel drive).
- [4]: Power card 5 (rectifier connection in a parallel drive).
- [5]: Power card 6 (rectifier connection in a parallel drive).
- [6]: Power card 7 (rectifier connection in a parallel drive).
- [7]: Power card 8 (rectifier connection in a parallel drive).
- [8]: Inrush card (optional).
- [9]: Fan power card 1 (optional).
- [10]: Fan power card 2 (optional).

43-00 Component Temp.

Default value:	0 °C	Parameter type:	Readout, Array [18]
Setup:	All setups	Conversion index:	100
Data type:	Int8	Change during operation:	True

Shows the temperature of a system component. The elements of the array reference local PCB temperature sensor measurements. Parameter **16-31 System Temp** uses all elements in this array to calculate the system temperature.

43-01 Auxiliary Temp.

Default value:	0 °C	Parameter type:	Readout, Array [18]
Setup:	All setups	Conversion index:	100
Data type:	Int8	Change during operation:	True

Shows the temperature of an auxiliary component. The elements of the array reference the temperature measurements from the NTC temperature sensors connected to hardware components in the drive. Refer to the operating guide for specifications of temperature sensor placement.

43-02 Component SW ID

Default value:	0	Parameter type:	Readout, Array [18]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[18]	Change during operation:	True

Shows the software version of the installed option.

6.38.3 43-1* Power Card Status



NOTE: This parameter group is only available in FC 302.

This parameter group contains read-only information on hardware components in the power section. All parameters in this group are arrays:

- [0]: Power card 1 (the master power card in a parallel drive, or the only power card in a drive with a single inverter section).
- [1]: Power card 2 (inverter connection in a parallel drive).
- [2]: Power card 3 (inverter connection in a parallel drive).
- [3]: Power card 4 (inverter connection in a parallel drive).

- [4]: Power card 5 (rectifier connection in a parallel drive).
- [5]: Power card 6 (rectifier connection in a parallel drive).
- [6]: Power card 7 (rectifier connection in a parallel drive).
- [7]: Power card 8 (rectifier connection in a parallel drive).

43-10 HS Temp. ph.U

Default value:	0 °C	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	100
Data type:	Int8	Change during operation:	True

Shows the heat sink temperature at the location of the phase U IGBT power module. This measurement is not available in all enclosure sizes. Parameter **16-34 Heatsink Temp.** uses the value in this parameter.

43-11 HS Temp. ph.V

Default value:	0 °C	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	100
Data type:	Int8	Change during operation:	True

Shows the heat sink temperature at the location of the phase V IGBT power module. This measurement is not available in all enclosure sizes. Parameter **16-34 Heatsink Temp.** uses the value in this parameter.

43-12 HS Temp. ph.W

Default value:	0 °C	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	100
Data type:	Int8	Change during operation:	True

Shows the heat sink temperature at the location of the phase W IGBT power module. This measurement is not available in all enclosure sizes. Parameter **16-34 Heatsink Temp.** uses the value in this parameter.

43-13 PC Fan A Speed

Default value:	0 RPM	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	67
Data type:	UInt16	Change during operation:	True

Shows the measured speed of fan A on the power card. Each power card has up to 3 fan connections. Place the fan in the drive according to the operating guide. A typical placement for fan A is in the backchannel (the external fan). The value of this parameter is:

- The actual fan speed when there is a DC fan in the drive.
- Relative speed when there is an AC fan in the drive.

43-14 PC Fan B Speed

Default value:	0 RPM	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	67
Data type:	UInt16	Change during operation:	True

Shows the measured speed of fan B on the power card. Each power card has up to 3 fan connections. Place the fan in the drive according to the operating guide. A typical placement for fan B is on the enclosure door (the internal fan). The value of this parameter is:

- The actual fan speed when there is a DC fan in the drive.
- Relative speed when there is an AC fan in the drive.

43-15 PC Fan C Speed

Default value:	0 RPM	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Changing during operation:	True

Shows the measured speed of fan C on the power card. Each power card has up to 3 fan connections. Place the fan in the drive according to the operating guide. A typical placement for fan C is inside the enclosure (the mixing fan). The value of this parameter is:

- The actual fan speed when there is a DC fan in the drive.
- Relative speed when there is an AC fan in the drive.

6.38.4 43-2* Fan Pow.Card Status

NOTICE

This parameter group is only available in FC 302.

43-20 FPC Fan A Speed

Default value:	0 RPM	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Shows the speed of the power card fan A.

43-21 FPC Fan B Speed

Default value:	0 RPM	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Shows the speed of the power card fan B.

43-22 FPC Fan C Speed

Default value:	0 RPM	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Shows the speed of the power card fan C.

43-23 FPC Fan D Speed

Default value:	0 RPM	Parameter type:	Readout, Array [4]

Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Shows the speed of the power card fan D.

43-24 FPC Fan E Speed

Default value:	0 RPM	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Shows the speed of the power card fan E.

43-25 FPC Fan F Speed

Default value:	0 RPM	Parameter type:	Readout, Array [4]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Shows the speed of the power card fan F.

6.38.5 43-3* Warning Log

43-30 Warning Log: Warning Number

Default value:	0	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View the warning number and look up its meaning in the chapter *Troubleshooting*.

43-31 Warning Log: Value

Default value:	0	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	0
Data type:	Int16	Change during operation:	False

View an extra description of the warning.

43-32 Warning Log: Time

Default value:	0 s	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	0
Data type:	Uint32	Change during operation:	False

View the time when the logged event occurred. Time is measured in seconds from drive start-up.

43-33 Warning Log: Date and Time

Default value:	Size related	Parameter type:	Readout, Array [30]

Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

View at which date and time the logged event occurred.

43-38 Warning Log: Speed

Default value:	0 RPM	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	67
Data type:	Int32	Change during operation:	False

View the actual motor speed value when the logged event occurred.

43-39 Warning Log: Duration

Default value:	0 s	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	0
Data type:	Int32	Change during operation:	False

View for how long the warning was active.

43-40 Warning Log: Ext. Reference

Default value:	0%	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the present reference value applied on impulse or analog basis when the logged event occurred.

43-41 Warning Log: Frequency

Default value:	0 Hz	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	-1
Data type:	Int16	Change during operation:	False

View the actual motor frequency when the logged event occurred.

43-42 Warning Log: Current

Default value:	0 A	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	False

View the motor current measured when the logged event occurred.

43-43 Warning Log: Voltage

Default value:	0 V	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	-1

Data type:	Uint16	Change during operation:	False

View the motor voltage when the logged event occurred.

43-44 Warning: DC Link Voltage

Default value:	0 V	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

View the DC-link voltage when the logged event occurred.

43-45 Warning Log: Control Word

Default value:	0	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	0
Data type:	V2	Change during operation:	False

View the control word sent from the drive when the logged event occurred.

43-46 Warning Log: Status Word

Default value:	0	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	0
Date type:	V2	Change during operation:	False

View the status word sent from the drive when the logged event occurred.

43-47 Warning Log: Torque

Default value:	0 Nm	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	-1
Data type:	Int32	Change during operation:	False

View the actual motor torque when the logged event occurred.

43-48 Warning Log: CBM Value

Default value:	0%	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	False

View the actual CBM value for this warning.

43-49 Warning Log: CBM Threshold

Default value:	0%	Parameter type:	Readout, Array [30]
Setup:	All setups	Conversion index:	-2
Data type:	Int32	Change during operation:	False

View the CBM threshold for this warning.

6.39 Parameter Group 44-** Motor Protection

6.39.1 44-2* Check Motor



NOTE: This parameter group is only available in FC 302.

This parameter group contains parameters for configuration and readout for the "check for correct motor" functionality enabled in parameter **1-47 Torque Calibration** by selecting either **[5] 1st start check motor** or **[6] Every st. check motor**.

44-20 Max Cable Resistance

Default value:	0.0 Ohm	Parameter type:	Range, 0.0 - 100.0000 Ohm
Setup:	All setups	Conversion index:	-4
Data type:	Uint32	Change during operation:	True

Enter the resistance to be used as an offset for the Rs maximum value used in parameter **1-47 Torque Calibration**, options **[5] 1st start check motor** and **[6] Every st. check motor**.

44-27 Estimated D-axis Inductance (Ld)

Default value:	0.000 mH	Parameter type:	Range, 0.000 - 1000000.000
Setup:	All setups	Conversion index:	-6
Data type:	Uint32	Change during operation:	True

When **[5] 1st start check motor** or **[6] Every st. check motor** is selected in parameter **1-47 Torque Characteristics**, the last estimated Ld is shown.

44-29 Estimated Back EMF at 1000 RPM

Default value:	0 V	Parameter type:	Range, 0 - 65000 V
Setup:	All setups	Conversion index:	-1
Data type:	Uint32	Change during operation:	True

When **[5] 1st start check motor** or **[6] Every st. check motor** is selected in parameter **1-47 Torque Characteristics**, the last estimated Back EMF at 1000 RPM is shown.

6.40 Parameter Group 45-** Condition Based Monitoring

6.40.1 45-0* Cockpit: Monitor

Use this parameter group to enable condition-based monitoring, define units, baseline computation, input sources, view baseline status, and progress.

45-00 Function

Default value:	–	Parameter type:	Option, Array [7]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

Set the notification level and enable monitoring of the drive.

Option	Name	Description
[0]	Off	Notification is disabled.
[1]	Warning	Warning notifications are triggered.
[2]	Alarm & warning	Both alarm and warning notifications are triggered.

Table 58: Parameter Index

Parameter ID	Description
45-00.0	Select the required option to enable stator winding monitoring.
45-00.1	Select the required option to enable load envelope.
45-00.2	Select the required option to enable sensor 1 vibration.
45-00.3	Select the required option to enable sensor 2 vibration.
45-00.4	Select the required option to enable sensor 3 vibration.
45-00.5	Select the required option to enable sensor 4 vibration.
45-00.6	Select the required option to enable cavitation monitoring.

45-01 Status

Default value:	[0] Off	Parameter type:	Readout, Array [7]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

The parameter shows the status of the monitor function, also when it is pending baseline completion.

Index	Name	Description
[0]*	Off	Status is disabled.
[1]	On	Shows current monitoring status.
[2]	Waiting for baseline	Baseline computation is in progress.
[3]	On - while baseline	Monitoring of cavitation is active during the online baseline, based on earlier thresholds.
[4]	Hold - speed fluctuation	Due to fluctuation in pump speed, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuation disappears, the monitoring resumes. Resolution: Wait for the fluctuation to end, investigate the reason for the fluctuation. Alternatively, increase the value of parameter 45-83.1 Speed Fluctuation Limits to a proper level.
[5]	Hold - load fluctuation	Due to fluctuation in pump loading, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuation disappears, the monitoring resumes. Resolution: Wait for the fluctuation to end, investigate the reason for the fluctuation. Alternatively, increase the value of parameter 45-83.2 Load Fluctuation Limits to a proper level.

Index	Name	Description
[6]	Hold - grid fluctuation	Due to fluctuation in magnitude of the power supply frequency, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuation disappears, the monitoring resumes. Resolution: Wait for the fluctuation to end, investigate the reason for fluctuation and address the issue. Alternatively, increase the value of parameter 45-83.3 Grid Fluctuation Limits to a proper level.
[7]	Hold - load+speed fluctuation	Due to concurrent fluctuations of both pump speed and loading conditions, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuations end, the monitoring resumes. Resolution: Wait for the fluctuations to end, investigate the reasons for the fluctuations and address the issue. Alternatively, increase the values of parameter 45-83.1 Speed Fluctuation Limits and/or parameter 45-83.2 Load Fluctuation Limits to proper levels.
[8]	Hold - grid+load fluctuation	Due to concurrent fluctuations of both pump loading condition and power supply, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuations end, the monitoring resumes. Resolution: Wait for the fluctuations to end, investigate the reasons for the fluctuations and address the issue. Alternatively, increase the values of parameter 45-83.2 Load Fluctuation Limits and/or parameter 45-83.3 Grid Fluctuation Limits to proper levels.
[9]	Hold - grid+speed fluctuation	Due to concurrent fluctuations of both pump speed and power supply, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuations end, the monitoring resumes. Resolution: Wait for the fluctuations to disappear, investigate the reasons for the fluctuations and address the issue. Alternatively, increase the values of parameter 45-83.1 Speed Fluctuation Limits and/or parameter 45-83.3 Grid Fluctuation Limits to proper levels.
[10]	Hold - grid+load+speed fluct.	Due to concurrent fluctuations of both pump speed, loading condition, and power supply, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuations end, the monitoring resumes. Resolution: Wait for the fluctuations to end, investigate the reason for the fluctuations and address the issue. Alternatively, increase the value of parameter 45-83.1 Speed Fluctuation Limits, parameter 45-83.2 Load Fluctuation Limits, and/or parameter 45-83.3 Grid Fluctuation Limits to proper levels.

Index	Name	Description
[11]	Hold - switching freq. transient	Due to fluctuation of the switching frequency of the drive, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuation disappears, the monitoring resumes. Wait for the fluctuation to end, investigate the reason for the fluctuation and address the issue.
[12]	Hold - DC bus transient	Due to fluctuation in the DC-link voltage of the drive, cavitation monitoring is put on hold to avoid false-positive warnings of cavitation. After the fluctuation disappears, the monitoring resumes. Resolution: Wait for the fluctuation to end, investigate the reason for the fluctuation. Alternatively, increase the values of parameter 45-83.1 Speed Fluctuation Limits, parameter 45-83.2 Load Fluctuation Limits, and/or parameter 45-83.3 Grid Fluctuation Limits to proper levels.
[13]	Hold - Sig. gain modified	Cavitation monitoring is disabled as parameter 45-81 Signature Gain is modified, and the value is now different from the one used during baseline. Another possibility is attempting to start cavitation monitoring without having a valid baseline. Resolution: Change the gain to the same value as used during baseline. Alternatively, run a new baseline with the new gain value.
[14]	Hold - Filter TC modified	Cavitation monitoring is disabled as parameter 45-82 Filter Time Constant is modified, and the value is now different from the one used during baseline. Resolution: Change the filter time constant to the same value as used during baseline. Alternatively, run a new baseline with the new filter time constant value.

Table 59: Parameter Index

Parameter ID	Description
45-01.0	Select the required option to view the status of the stator winding monitoring.
45-01.1	Select the required option to view the status of load envelope.
45-01.2	Select the required option to view the status of sensor 1 vibration.
45-01.3	Select the required option to view the status of sensor 2 vibration.
45-01.4	Select the required option to view the status of sensor 3 vibration.
45-01.5	Select the required option to view the status of sensor 4 vibration.
45-01.6	Select the required option to view the status of the cavitation function.

45-02 Start Time

Default value:	Size related	Parameter type:	Readout, Array [7]
Setup:	All setups	Conversion index:	0

Data type: TimeOfDay **Change during operation:** True

This parameter shows at which date and time the monitoring function was started.

Table 60: Parameter Index

Parameter ID	Description
45-02.0	View the timestamp for starting the stator winding monitoring.
45-02.1	View the timestamp for starting the load envelope monitoring.
45-02.2	View the timestamp for starting the sensor 1 vibration monitoring.
45-02.3	View the timestamp for starting the sensor 2 vibration monitoring.
45-02.4	View the timestamp for starting the sensor 3 vibration monitoring.
45-02.5	View the timestamp for starting the sensor 4 vibration monitoring.
45-02.6	View the timestamp for starting the cavitation monitoring.

45-03 Stop Time

Default value: Size related **Parameter type:** Readout, Array [7]
Setup: All setups **Conversion index:** 0
Data type: TimeOfDay **Change during operation:** True

This parameter shows at which date and time the monitoring function was stopped.

Table 61: Parameter Index

Parameter ID	Description
45-03.0	View the timestamp for stopping the stator winding monitoring.
45-03.1	View the timestamp for stopping the load envelope monitoring.
45-03.2	View the timestamp for stopping the sensor 1 vibration monitoring.
45-03.3	View the timestamp for stopping the sensor 2 vibration monitoring.
45-03.4	View the timestamp for stopping the sensor 3 vibration monitoring.
45-03.5	View the timestamp for stopping the sensor 4 vibration monitoring.
45-03.6	View the timestamp for stopping the cavitation monitoring.

45-09 Readout Setting

Default value: [0] Actual **Parameter type:** Array [7]
Setup: All setups **Conversion index:** –
Data type: Uint8 **Change during operation:** True

Set the readout setting.

Option	Name	Description
[0]*	Actual	
[1]	Actual rel. To S1 High	
[2]	Actual rel. To S2 High	

Option	Name	Description
[3]	Actual rel. To Alarm High	
[4]	Actual rel. To S1 Low (Only For Load)	
[5]	Actual rel. To S2 Low (Only For Load)	
[6]	Actual rel. To Alarm Low (Only For Load)	
[7]	Actual rel. to Act.B.Mean	
[8]	Actual rel. to Prev.B.Mean	

Table 62: Parameter Index

Parameter ID	Description
45-09.0	Select the readout setting for stator winding monitoring.
45-09.1	Select the readout setting for load envelope monitoring.
45-09.2	Select the readout setting for sensor 1 vibration monitoring.
45-09.3	Select the readout setting for sensor 2 vibration monitoring.
45-09.4	Select the readout setting for sensor 3 vibration monitoring.
45-09.5	Select the readout setting for sensor 4 vibration monitoring.
45-09.6	Select the readout setting for cavitation monitoring

6.40.2 45-1* Cockpit: ActI Status

Use the parameters in this group to compare the actual monitor values to all thresholds at the current motor output speed.

45-10 Alarm High Threshold

Default value:	0%	Parameter type:	Readout, Array [9]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The parameter shows the maximum threshold limit. The drive triggers a notification when threshold limit is exceeded.

Table 63: Parameter Index

Parameter ID	Description
45-10.0	Actual status of stator winding
45-10.1	Actual status of stator resonance active
45-10.2	Actual status of stator resonance load
45-10.3	Actual status of load envelope
45-10.4	Actual status of sensor 1 vibration
45-10.5	Actual status of sensor 2 vibration
45-10.6	Actual status of sensor 3 vibration
45-10.7	Actual status of sensor 4 vibration
45-10.8	Actual status of cavitation

45-11 Warning S2 High Threshold

Default value:	0%	Parameter type:	Readout, Array [9]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The parameter shows the maximum threshold limit for warning stage 2 for the index. The drive triggers a warning notification when threshold limit is exceeded.

Table 64: Parameter Index

Parameter ID	Description
45-11.0	Actual status of stator winding
45-11.1	Actual status of stator resonance active
45-11.2	Actual status of stator resonance load
45-11.3	Actual status of load envelope
45-11.4	Actual status of sensor 1 vibration
45-11.5	Actual status of sensor 2 vibration
45-11.6	Actual status of sensor 3 vibration
45-11.7	Actual status of sensor 4 vibration
45-11.8	Actual status of cavitation

45-12 Warning S1 High Threshold

Default value:	0%	Parameter type:	Readout, Array [9]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The parameter shows the maximum threshold limit for warning stage 1 in the parameter index. The drive triggers a warning notification when threshold limit is exceeded. Entering a value in the parameter indicates a user specified threshold limit.

Table 65: Parameter Index

Parameter ID	Description
45-12.0	Actual status of stator winding
45-12.1	Actual status of stator resonance active
45-12.2	Actual status of stator resonance load
45-12.3	Actual status of load envelope
45-12.4	Actual status of sensor 1 vibration
45-12.5	Actual status of sensor 2 vibration
45-12.6	Actual status of sensor 3 vibration
45-12.7	Actual status of sensor 4 vibration
45-12.8	Actual status of cavitation

45-13 Actual Monitor Value

Default value:	0%	Parameter type:	Readout, Array [9]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the current value of selected signal.

Table 66: Parameter Index

Parameter ID	Description
45-13.0	Actual status of stator winding
45-13.1	Actual status of stator resonance active
45-13.2	Actual status of stator resonance load
45-13.3	Actual status of load envelope
45-13.4	Actual status of sensor 1 vibration
45-13.5	Actual status of sensor 2 vibration
45-13.6	Actual status of sensor 3 vibration
45-13.7	Actual status of sensor 4 vibration
45-13.8	Actual status of cavitation

45-14 Warning S1 Low Threshold

Default value:	0%	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The parameter shows the minimum threshold limit for warning stage 1 notification in the parameter index. The drive triggers a notification when the actual monitoring value falls below the minimum threshold limit.

Table 67: Parameter Index

Parameter ID	Description
45-14.0	Actual status of stator winding
45-14.1	Actual status of stator resonance active
45-14.2	Actual status of stator resonance load
45-14.3	Actual status of load envelope
45-14.4	Actual status of sensor 1 vibration
45-14.5	Actual status of sensor 2 vibration
45-14.6	Actual status of sensor 3 vibration
45-14.7	Actual status of sensor 4 vibration

45-15 Warning S2 Low Threshold

Default value:	0%	Parameter type:	Readout, Array [8]
Setup:	All setups	Conversion index:	-2

Data type: Uint16 **Change during operation:** True

The parameter shows the minimum threshold limit for warning stage 2 notification in the parameter index. The drive triggers a warning stage 2 notification when the actual monitoring value falls below the threshold limit specified in the parameter.

Table 68: Parameter Index

Parameter ID	Description
45-15.0	Actual status of stator winding
45-15.1	Actual status of stator resonance active
45-15.2	Actual status of stator winding load
45-15.3	Actual status of load envelope
45-15.4	Actual status of sensor 1 vibration
45-15.5	Actual status of sensor 2 vibration
45-15.6	Actual status of sensor 3 vibration
45-15.7	Actual status of sensor 4 vibration

45-16 Alarm Low Threshold

Default value: 0% **Parameter type:** Readout, Array [8]
Setup: All setups **Conversion index:** -2
Data type: Uint16 **Change during operation:** True

The parameter shows the minimum threshold limit in the parameter index. The drive triggers an alarm notification when the actual value falls below the minimum threshold limit.

Table 69: Parameter Index

Parameter ID	Description
45-16.0	Actual status of stator winding
45-16.1	Actual status of stator resonance active
45-16.2	Actual status of stator resonance load
45-16.3	Actual status of load envelope
45-16.4	Actual status of sensor 1 vibration
45-16.5	Actual status of sensor 2 vibration
45-16.6	Actual status of sensor 3 vibration
45-16.7	Actual status of sensor 4 vibration

6.40.3 45-2* Baseline Settings

Use the parameters in this group to configure how to capture baseline data.

45-20 Type

Default value: [0] Off **Parameter type:** Option
Setup: All setups **Conversion index:** –
Data type: Uint8 **Change during operation:** True

Use the parameter to select type of baseline computation.

Option	Name	Description
[0]*	Off	Baseline computation type is not set.
[1]	Baseline Run	Select the option when the application can operate from minimum to maximum speed in one sweep. On enabling this option, the condition-based monitoring function sets speed points. On completion of baseline computation, the motor is ramped down to 0. The option can only operate when Hand On mode is set via control panel.
[2]	Online Baseline	Select the option in applications where baseline run cannot be utilized. In this type of baseline computation, the drive is controlled by the application baseline and speed points are recorded and saved during the duration specified in parameter 45-24 Duration . The option can only operate when Auto-on mode is set via control panel.

45-21 Status

Default value:	[0] Not started	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter shows the current status of baseline capturing. The baseline must be completed before enabling any monitoring functions.

Index	Name
[0]*	Not started
[1]	Baseline run running
[2]	Online baseline running
[3]	Baseline completed
[4]	Baseline failed
[5]	Online inadequate data

45-22 Progress

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Shows the progress of baseline computation. 0% indicates that the baseline computation is not started, and 100% indicates that baseline computation is completed.

45-23 Baseline Result Info

Default value:	[0] None	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

The parameter shows the status of the baseline result, that is, showing the reasons for failure or inadequate data at baseline run an online baseline.

Index	Name
[0]*	None
[1]	Baseline run OFF
[2]	Reverse direction
[3]	Speed limit exceeded
[4]	Speed diff low
[5]	Step ramp timeout
[6]	Stator supply imbalance
[7]	Online baseline OFF
[8]	Online baseline count limit
[9]	Not allowed - motor running

45-24 Duration

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select a suitable duration for baseline computation. If a value is not selected, by default, the system considers 2 minutes for baseline run and 1 hour for online baseline.

Option	Name	Description
[0]	1 min	
[1]	2 mins	
[3]	4 mins	
[6]	10 mins	
[9]	30 mins	
[13]	1 hour	
[16]	2 hours	
[19]	4 hours	
[23]	8 hours	
[27]	1 day	
[30]	2 days	
[33]	5 days	
[36]	1 week	
[40]	2 weeks	
[43]	1 month	
[46]	2 months	

Option	Name	Description
[49]	4 months	
[52]	6 months	

45-25 Online Speed Band

Default value:	5%	Parameter type:	Range, 0 - 5%
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

Use this parameter to define a window to capture the baseline data for different speed points when the speed of drive is within the specified band percentage. Setting the parameter increases a chance to capture all speed points in online baseline mode.

45-26 Min. Speed

Default value:	Size related	Parameter type:	Range, 0 - 35700 [RPM]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Use this parameter to set the minimum speed of the drive to begin condition-based monitoring functions. Ensure to set a value which exceeds the minimum speed limit of motor. The minimum limit of motor speed corresponds to the setting in parameter **4-11 Motor Speed Low Limit [RPM]**. For more information, refer to the drive-specific programming guide.

45-27 Max. Speed

Default value:	Size related	Parameter type:	Range, 100 - 35700 [RPM]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

Use this parameter to set the maximum speed of the drive for condition-based monitoring functions. Setting the minimum and maximum speed defines the speed range for condition-based monitoring functions to perform effectively. Ensure to set a value which does not exceed the maximum limit of motor speed. The maximum limit of motor speed corresponds to the setting in parameter **4-13 Motor Speed High Limit [RPM]**. For more information, refer to the drive-specific programming guide.

45-28 Speed Points

Default value:	Size related	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	67
Data type:	Uint32	Change during operation:	True

Shows the baseline speed points calculated within the range defined in parameter **45-26 Min. Speed** and parameter **45-27 Max. speed**.

6.40.4 45-3* Threshold Config.

45-30 Baseline Statistics

Default value:	[3] Mean $\pm$ 3 standard deviation	Parameter type:	Option, Array [7]
Setup:	All setups	Conversion index:	–

Data type: Uint8 **Change during operation:** True

Select the type of baseline statistical data for visualizing calculated threshold limits for each parameter index. The calculated threshold is used for monitoring purposes.

Option	Name	Description
[1]	Mean	Average of the baseline data is shown.
[2]	Maximum/minimum	Maximum and minimum of the baseline data is shown.
[3]*	Mean +/- 3 standard deviation	Mean and +/-3 standard deviations of the baseline data is shown.

Table 70: Parameter Index

Parameter ID	Description
45-30.0	Threshold configuration of stator winding
45-30.1	Threshold configuration of load envelope
45-30.2	Threshold configuration of sensor 1 vibration
45-30.3	Threshold configuration of sensor 2 vibration
45-30.4	Threshold configuration of sensor 3 vibration
45-30.5	Threshold configuration of sensor 4 vibration
45-30.6	Threshold configuration of cavitation

45-31 Warning Mode

Default value: [1] Offset **Parameter type:** Option, Array [7]
Setup: All setups **Conversion index:** –
Data type: Uint8 **Change during operation:** True

Select a mode to define threshold limit for warnings.

Option	Name	Description
[0]	Absolute	Absolute value is considered as threshold limit.
[1]*	Offset	Calculates threshold as a sum of the computed baseline data and the offset values.
[2]	Factor	Calculates threshold as baseline data x factor.

The values can be specified in parameter **45-34 Warning S2 High**, parameter **45-35 Warning S1 High**, parameter **45-36 Warning S1 Low**, and parameter **45-37 Warning S2 Low**. For example, if selecting **[0] Absolute**, a warning S2 low value of 200, and a warning S1 high value of 300, the threshold limit for warning stage 2 ranges from 200–300.

Table 71: Parameter Index

Parameter ID	Description
45-31.0	Threshold configuration of stator winding
45-31.1	Threshold configuration of load envelope
45-31.2	Threshold configuration of sensor 1 vibration
45-31.3	Threshold configuration of sensor 2 vibration

Table 71: Parameter Index - (continued)

Parameter ID	Description
45-31.4	Threshold configuration of sensor 3 vibration
45-31.5	Threshold configuration of sensor 4 vibration
45-31.6	Threshold configuration of cavitation

45-32 Alarm Mode

Default value:	–	Parameter type:	Option, Array [7]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select a mode to define the threshold limits for alarms.

Option	Name	Description
[0]	Absolute	Absolute value is considered as threshold.
[1]	Offset	Calculates threshold as a sum of the computed baseline data and the offset values.
[2]	Factor	Calculates threshold as baseline data * factor.

The values can be specified in parameter **45-33 Alarm High** and parameter **45-38 Alarm Low**. For example, if selecting **[0] Absolute**, setting an alarm low value of 200, and an alarm high value of 300, the threshold limit for alarms ranges from 200 to 300.

Table 72: Parameter Index

Parameter ID	Description
45-32.0	Threshold configuration of stator winding
45-32.1	Threshold configuration of load envelope
45-32.2	Threshold configuration sensor 1 vibration
45-32.3	Threshold configuration of sensor 2 vibration
45-32.4	Threshold configuration of sensor 3 vibration
45-32.5	Threshold configuration of sensor 4 vibration
45-32.6	Threshold configuration of cavitation

45-33 Alarm High

Default value:	Size related	Parameter type:	Array [7]
Setup:	All setup	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Type the threshold value for high alarm notification. Based on the type of alarm mode selected by the user, a high alarm threshold is calculated.

Table 73: Parameter Index

Parameter ID	Description
45-33.0	Threshold configuration of stator winding
45-33.1	Threshold configuration of load envelope
45-33.2	Threshold configuration of sensor 1 vibration
45-33.3	Threshold configuration of sensor 2 vibration
45-33.4	Threshold configuration of sensor 3 vibration
45-33.5	Threshold configuration of sensor 4 vibration
45-33.6	Threshold configuration of cavitation

45-34 Warning S2 High

Default value:	Size related	Parameter type:	Array [7]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during option:	True

Type the threshold value for computing a warning S2 high notification. Based on the type of warning mode selected by the user, a warning S2 high threshold is calculated.

Table 74: Parameter Index

Parameter ID	Description
45-34.0	Threshold configuration of stator winding
45-34.1	Threshold configuration of load envelope
45-34.2	Threshold configuration of sensor 1 vibration
45-34.3	Threshold configuration of sensor 2 vibration
45-34.4	Threshold configuration of sensor 3 vibration
45-34.5	Threshold configuration of sensor 4 vibration
45-34.6	Threshold configuration of cavitation

45-35 Warning S1 High

Default value:	Size related	Parameter type:	Array [7]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Type the threshold value for computing a warning S1 high notification. Based on the type of warning mode selected by the user, a warning S1 high threshold is calculated.

Table 75: Parameter Index

Parameter ID	Description
45-35.0	Threshold configuration of stator winding
45-35.1	Threshold configuration of load envelope
45-35.2	Threshold configuration of sensor 1 vibration
45-35.3	Threshold configuration of sensor 2 vibration

Table 75: Parameter Index - (continued)

Parameter ID	Description
45-35.4	Threshold configuration of sensor 3 vibration
45-35.5	Threshold configuration of sensor 4 vibration
45-35.6	Threshold configuration of cavitation

45-36 Warning S1 Low

Default value:	Size related	Parameter type:	Array [6]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Type the threshold value for computing a warning S1 low notification. Based on the type of warning mode selected by the user, a warning S1 low threshold is calculated.

Table 76: Parameter Index

Parameter ID	Description
45-36.0	Threshold configuration of stator winding
45-36.1	Threshold configuration of load envelope
45-36.2	Threshold configuration of sensor 1 vibration
45-36.3	Threshold configuration of sensor 2 vibration
45-36.4	Threshold configuration of sensor 3 vibration
45-36.5	Threshold configuration of sensor 4 vibration

45-37 Warning S2 Low

Default value:	Size related	Parameter type:	Array [6]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Type the threshold value for computing a warning S2 low notification. Based on the type of warning mode selected by the user, a warning S2 low threshold is calculated.

Table 77: Parameter Index

Parameter ID	Description
45-37.0	Threshold configuration of stator winding
45-37.1	Threshold configuration of load envelope
45-37.2	Threshold configuration of sensor 1 vibration
45-37.3	Threshold configuration of sensor 2 vibration
45-37.4	Threshold configuration of sensor 3 vibration
45-37.5	Threshold configuration of sensor 4 vibration

45-38 Alarm Low

Default value:	Size related	Parameter type:	Array [6]

Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Type the threshold value for computing a low alarm notification. Based on the type of alarm mode selected, a low alarm threshold is calculated.

Table 78: Parameter Index

Parameter ID	Description
45-38.0	Threshold configuration of stator winding
45-38.1	Threshold configuration of load envelope
45-38.2	Threshold configuration of sensor 1 vibration
45-38.3	Threshold configuration of sensor 2 vibration
45-38.4	Threshold configuration of sensor 3 vibration
45-38.5	Threshold configuration of sensor 4 vibration

45-39 Online Baseline Counter

Default value:	2	Parameter type:	Array [7]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Type the minutes during which monitoring values are captured for a speed point during baseline generation. Speed points are captured for different types of condition-based monitoring during the minutes specified in this parameter.

Table 79: Parameter Index

Parameter ID	Description
45-39.0	Threshold configuration of stator winding
45-39.1	Threshold configuration of load envelope
45-39.2	Threshold configuration of sensor 1 vibration
45-39.3	Threshold configuration of sensor 2 vibration
45-39.4	Threshold configuration of sensor 3 vibration
45-39.5	Threshold configuration of sensor 4 vibration
45-39.6	Threshold configuration of cavitation

45-40 Extend Factor

Default value:	1.00f	Parameter type:	Array [7]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

In this parameter, consider the extended factor required for setting the extended threshold generation via parameter **45-45 Threshold Generation**.

Table 80: Parameter Index

Parameter ID	Description
45-40.0	Threshold configuration of stator winding
45-40.1	Threshold configuration of load envelope
45.40.2	Threshold configuration of sensor 1 vibration
45.40.3	Threshold configuration of sensor 2 vibration
45-40.4	Threshold configuration of sensor 3 vibration
45-40.5	Threshold configuration of sensor 4 vibration
45-40.6	Threshold configuration of cavitation

6.40.5 45-4* Threshold Generation

The parameters in this parameter group support the generation of the CBM thresholds.

45-45 Threshold Generation

Default value:	[0] Off	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Off	Not applicable.
[1]	Generate now	Based on the selections, generate threshold for all functions from actual baseline data.
[2]	Auto generate	Not applicable.
[3]	Generate now - previous	Based on the selections, generate threshold for all functions from previous baseline data.
[4]	Gen. now - stator	Based on the selections, generate threshold for stator from actual baseline data.
[5]	Gen. now - load	Based on the selections, generate threshold for the load from actual baseline data.
[6]	Gen. now - sensor 1	Based on the selections, generate threshold for sensor 1 from actual baseline data.
[7]	Gen. now - sensor 2	Based on the selections, generate threshold for sensor 2 from actual baseline data.
[8]	Gen. now - sensor 3	Based on the selections, generate threshold for sensor 3 from actual baseline data.
[9]	Gen. now - sensor 4	Based on the selections, generate threshold for sensor 4 from actual baseline data.
[10]	Extend auto gen.	After baseline has finished successfully, generate all function thresholds from the actual baseline data factored with the extend factor value.
[11]	Gen. now - cavitation	Based on the selections, generate cavitation thresholds from the actual baseline date.

45-46 Threshold Limits

Default value:	[0] Limits OK	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Clear the threshold limit warning when the threshold is at an acceptable level.

Option	Name	Description
[0]*	Limits OK	
[1]	Limits Exceeded	

6.40.6 45-5* Sensor Config.

Select the analog input for sensor and unit configuration.

45-50 Source

Default value:	[0] None	Parameter type:	Option, Array [4]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Select an analog input source for receiving sensor signals. Scaling of analog inputs is performed as defined in parameter group **6-** Analog In/Out**. For more information on parameter group **6-** Analog In/Out**, refer to the drive-specific programming guide.

Option	Name	Description
[0]*	None	
[1]	Analog Input 53	
[2]	Analog Input 54	
[3]	Analog Input X30/11	
[4]	Analog Input X30/12	
[5]	Analog Input X42/1	
[6]	Analog Input X42/3	
[7]	Analog Input X42/5	
[8]	Analog Input X48/2	
[9]	Analog Input X49/1	
[10]	Analog Input X49/3	
[11]	Analog Input X49/5	

Table 81: Parameter Index

Parameter ID	Description
45-50.0	Sensor 1 vibration configuration
45-50.1	Sensor 2 vibration configuration
45-50.2	Sensor 3 vibration configuration
45-50.3	Sensor 4 vibration configuration

45-51 Sensor 1 Unit

Default value:	[0] None	Parameter type:	Option, Array [4]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use the parameter to set unit of monitoring signals from the sensor. The unit is specified on the vibration sensor.

Option	Name	Description
[0]*	None	
[1]	mm/s	
[2]	inch/s	
[3]	m/s ²	
[4]	g	
[5]	bar	
[6]	psi	
[7]	Pa	
[8]	kPa	
[9]	MPa	
[10]	kg/cm ²	
[11]	inHg	
[12]	m ³ /h	
[13]	US gpm	
[14]	l/h	
[15]	cfm	

Table 82: Parameter Index

Parameter ID	Description
45-50.0	Sensor 1 vibration configuration
45-50.1	Sensor 2 vibration configuration
45-50.2	Sensor 3 vibration configuration
45-50.3	Sensor 4 vibration configuration

6.40.7 45-6* Stator Res. Setting

45-60 Active Threshold

Default value:	2%	Parameter type:	0 - 100%
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Use this parameter to activate the resonance region supply imbalance control. Enter the threshold offset value from the baseline data.

45-61 Load Mode

Default value:	[0] Absolute	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]*	Absolute	Absolute value specified in parameter 45-33 Alarm High is considered as notification threshold.
[1]	Offset	Notification threshold is a sum of the computed baseline data and the offset values specified in parameter 45-33 Alarm High through parameter 45-38 Alarm Low .
[2]	Factor	Threshold limits is calculated as baseline data * factor value specified in parameter 45-33 Alarm High through parameter 45-38 Alarm Low .

45-62 Load Threshold

Default value:	Size related	Parameter type:	Range, 0 - 200%
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

45-63 Imbalance Limit

Default value:	0.50%	Parameter type:	Range, 0.05 - 10%
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

45-64 Imbalance Value

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the actual value of the supply imbalance.

45-65 DC-link Ripple Limit

Default value:	0.35%	Parameter type:	0.05 - 10%
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

When the motor output frequency matches the frequency of the DC-link voltage ripple, the threshold offset value activates.

45-66 DC-link Ripple Value

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2

Data type:	Uint16	Change during operation:	True

View the actual value of the DC-link voltage ripple.

6.40.8 45-8* Cavitation Config.

45-81 Signature Gain

Default value:	1.0	Parameter type:	Range, 0.1 - 10.0
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

The cavitation signature varies depending on the pump type, size, and construction. Set a gain value for adjusting the magnitude of the cavitation signature. If the cavitation signature is higher than 10–20%, set a lower gain. Changing the gain requires repeating the baseline.

45-82 Filter Time Constant

Default value:	3.0 s	Parameter type:	0.1 - 25.0 s
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

The cavitation signature varies depending on pump type, size, and construction. Set a time constant for filtering the cavitation signature. If very dynamic cavitation signature occurs, select a high time constant value as it provides heavy filtering. Changing the time constant requires that the baseline is repeated.

45-83 Fluctuation Limits

Default value:	Size related	Parameter type:	Array [3]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Rapid changes in pump speed, load, or grid voltage magnitude can create false-positive events of cavitation. Set the limit for accepted fluctuation within speed, load, and grid. If the limit is exceeded, the cavitation detection function is put on hold until the fluctuation disappears.

Table 83: Parameter index

Parameter ID	Description
45-83.1	Speed fluctuation limits. Default value is 0.1.
45-83.2	Load fluctuation limits. Default value is 1.5.
45-83.3	Grid fluctuation limits. Default value is 3.0.

45-89 Cavitation [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Readout of cavitation signature, which indicates the level of turbulence in the pump. This value is used for baseline and monitoring.

6.40.9 45-9* Actual Readouts

The parameters in this group are readout parameters showing the actual monitoring values.

45-90 Stator [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the actual stator monitor value at motor output speed.

45-91 Load [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the actual load monitor value at motor output speed.

45-92 Sensor 1 [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the actual sensor 1 monitor value in % at motor output speed.

45-93 Sensor 1 [Unit]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

This parameter shows the actual sensor 1 monitor value in the selected unit at motor output speed.

45-94 Sensor 2 [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the actual sensor 2 monitor value in % at motor output speed.

45-95 Sensor 2 [Unit]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

This parameter shows the actual sensor 2 monitor value in the selected unit at motor output speed.

45-96 Sensor 3 [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the actual sensor 3 value in % at motor output speed.

45-97 Sensor 3 [Unit]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

This parameter shows the actual sensor 3 monitor value in the selected unit at motor output speed.

45-98 Sensor 4 [%]

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the actual sensor 4 monitor value in % at motor output speed.

45-99 Sensor 4 [Unit]

Default value:	0	Parameter type:	Readout
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

This parameter shows the actual sensor 4 monitor value in the selected unit at motor output speed.

6.41 Parameter Group 46-** CBM Adv. Thresholds

6.41.1 46-0* History

The parameters in this group hold threshold history, such as timestamps of the last modification.

46-00 Last Change Time

Default value:	Size related	Parameter type:	Readout, Array [7]
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

This parameter shows the time stamp of the latest modification to a notification threshold.

Table 84: Parameter Index

Index	Description
[0]	Threshold history of stator winding.
[1]	Threshold history of load envelope
[2]	Threshold history of sensor 1 vibration
[3]	Threshold history of sensor 2 vibration
[4]	Threshold history of sensor 3 vibration
[5]	Threshold history of sensor 4 vibration
[6]	Threshold history of cavitation

6.41.2 46-0* General

46-07 Monitoring Min Speed

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

This parameter monitors the minimum speed as defined in parameter **45-45 Threshold Generation**.

46-08 Monitoring Max Speed

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

This parameter monitors the maximum speed as defined in parameter **45-45 Threshold Generation**.

46-09 Monitoring Speeds

Default value:	0 RPM	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	67
Data type:	Int32	Change during operation:	True

This parameter shows the 20 speed points in RPM. By default, the baseline minimum speed is considered.

6.41.3 46-1* Timing

46-10 Alarm Time

Default value:	10 s	Parameter type:	Array [7]
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Set the time in seconds to define the duration during which the alarm is not triggered. When the value which is monitored exceeds or falls below the alarm threshold for more than the time specified in the parameter, an alarm is triggered. Alarm time is the amount of time in seconds a monitoring state should be over the alarm threshold before triggering an alarm.

Table 85: Parameter Index

Parameter ID	Description
46-10.0	Timing of stator winding
46-10.1	Timing of load envelope
46-10.2	Timing of sensor 1 vibration
46-10.3	Timing of sensor 2 vibration
46-10.4	Timing of sensor 3 vibration
46-10.5	Timing of sensor 4 vibration
46-10.6	Timing of cavitation

46-11 Warning S2 Time

Default value:	10 s	Parameter type:	Array [7]
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Set the time in seconds to define the duration during which the warning S2 is not triggered. When the value which is monitored exceeds or falls below the warning S2 threshold for more than the time specified in the parameter, a warning S2 is triggered.

Table 86: Parameter Index

Parameter ID	Description
46-11.0	Timing of stator winding
46-11.1	Timing of load envelope
46-11.2	Timing sensor 1 vibration
46-11.3	Timing sensor 2 vibration
46-11.4	Timing sensor 3 vibration
46-11.5	Timing sensor 4 vibration
46-11.6	Timing of cavitation

46-12 Warning S1 Time

Default value:	10 s	Parameter type:	Array [7]
Setup:	All setups	Conversion index:	-2
Data type:	Uint32	Change during operation:	True

Set the time in seconds to define the duration during which the warning S1 is not triggered. When the value, which is monitored, exceeds or falls below the warning S1 threshold for more than the time specified in the parameter, a warning S1 is triggered.

Table 87: Parameter Index

Parameter ID	Description
46-12.0	Timing of stator winding
46-12.1	Timing of load envelope
46-12.2	Timing of sensor 1 vibration
46-12.3	Timing of sensor 2 vibration

Table 87: Parameter Index - (continued)

Parameter ID	Description
46-12.4	Timing of sensor 3 vibration
46-12.5	Timing of sensor 4 vibration
46-12.6	Timing of cavitation

46-13 Interpolation Type

Default value:	[0] Linear	Parameter type:	Option, Array [7]
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Set the type of interpolation parameter to construct accurate speed points.

Option	Name	Description
[0]*	Linear	Select this option for stator and load monitoring.
[1]	Staircase	Select this option for vibration monitoring.

Table 88: Parameter Index

Parameter ID	Description
46-13.0	Interpolation type of stator winding
46-13.1	Interpolation type of load envelope
46-13.2	Interpolation type of sensor 1 vibration
46-13.3	Interpolation type of sensor 2 vibration
46-13.4	Interpolation type of sensor 3 vibration
46-13.5	Interpolation type of sensor 4 vibration
46-13.6	Interpolation type of cavitation

6.41.4 46-2* Stator

46-20 Alarm High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a high alarm for stator monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a high alarm is triggered. The parameter contains 20 index values to manually configure Stator Winding Monitoring Alarm High Threshold for each individual speed point.

46-21 Warning S2 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a warning S2 alarm for stator monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in warning S2 time, a high warning S2 is triggered. The parameter contains 20 index values to manually configure Stator Winding Monitoring Warning S2 High Threshold for each individual speed point.

46-22 Stator Warning S1

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a high warning S1 for stator monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in warning S1 time, a high warning S1 is triggered. The parameter contains 20 index values which can be used to manually configure Stator Winding Monitoring Warning S1 High Threshold for each individual speed point.

46-23 Resonance Active

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

46-24 Resonance Load

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

6.41.5 46-3* Load

Use the parameters in this group to enter, adjust, and display threshold values for load envelope monitoring function.

46-30 Alarm High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a high alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a high alarm is triggered. The parameter contains 20 index values which can be used to manually configure Load Alarm High Threshold for each individual speed point.

46-31 Warning S2 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a high warning S2 for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in warning S2 time, a warning S2 high is triggered. The parameter contains 20 index values which can be used to manually configure Load Warning S2 High Threshold for each individual speed point.

46-32 Warning S1 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a high warning S1 for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in warning S1 time, a high warning S1 is triggered. The parameter contains 20 index values which can be used to manually configure Load Warning S1 High Threshold for each individual speed point.

46-33 Warning S1 Low

Default value	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low S1 warning for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in warning S1 time, a low S1 warning is triggered. The parameter contains 20 index values which can be used to manually configure Load Warning S1 Low Threshold for each individual speed point.

46-34 Warning S2 Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low S2 warning for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in warning S2 time, a low S2 warning is triggered. The parameter contains 20 index values which can be used to manually configure Load Warning S2 Low Threshold for each individual speed point.

46-35 Alarm Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a low alarm is triggered. The parameter contains 20 index values which can be used to manually configure Load Alarm Low Threshold for each individual speed point.

6.41.6 46-4* Sensor 1

Use the parameters in this group to enter, adjust, and display threshold values for Sensor 1 monitoring function.

46-40 Alarm High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a low alarm is triggered. The parameter contains 20 index values which can be used to manually configure Vibration 1 Alarm High Threshold for each individual speed point.

46-41 Warning S2 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a low alarm is triggered. The parameter contains 20 index values which can be used to manually configure Vibration 1 Warning S2 High Threshold for each individual speed point.

46-42 Warning S1 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a low alarm is triggered. The parameter contains 20 index values which can be used to manually configure Vibration 1 Warning S2 High Threshold for each individual speed point.

46-43 Warning Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

46-44 Alarm Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

6.41.7 46-5* Sensor 2

Use the parameters in this group to enter, adjust, and display threshold values for Sensor 2 monitoring function.

46-50 Alarm High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a low alarm is triggered. The parameter contains 20 index values which can be used to manually configure Vibration 2 Alarm High Threshold for each individual speed point.

46-51 Warning S2 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a low alarm is triggered. The parameter contains 20 index values which can be used to manually configure Vibration 2 Warning S2 High Threshold for each individual speed point.

46-52 Warning S1 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a low alarm is triggered. The parameter contains 20 index values which can be used to manually configure Vibration 2 Alarm High Threshold for each individual speed point.

46-53 Warning Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

46-54 Alarm Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

6.41.8 46-6* Sensor 3

Use the parameters in this group to enter, adjust, and display threshold values for Sensor 3 monitoring function.

46-60 Alarm High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a low alarm for load envelope monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a low alarm is triggered. The parameter contains 20 index values which can be used to manually configure Vibration 2 Alarm High Threshold for each individual speed point.

46-61 Warning S2 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a warning S2 notification for monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a warning S2 high is triggered. The parameter contains 20 index values which can be used to manually configure warning S2 high threshold for each individual speed point.

46-62 Warning S1 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a warning stage 1 high notification for monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a high warning is triggered. The parameter contains 20 index values which can be used to manually configure Warning S1 High Threshold for each individual speed point.

46-63 Warning Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

46-64 Alarm Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

6.41.9 46-7* Sensor 4

Use the parameters in this group to enter, adjust, and show threshold values for Sensor 4 monitoring function.

46-70 Alarm High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a alarm high notification for monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a high alarm is triggered. The parameter contains 20 index values which can be used to manually configure alarm high threshold for each individual speed point.

46-71 Warning S2 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a warning stage 2 high notification for monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a high warning is triggered. The parameter contains 20 index values which can be used to manually configure Warning stage 2 high threshold for each individual speed point.

46-72 Warning S1 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Set the threshold value which defines a warning stage 1 high notification for monitoring. When the value of the monitored value exceeds the threshold specified in the parameter for the duration of time specified in alarm time, a high warning is triggered. The parameter contains 20 index values which can be used to manually configure warning stage 1 high threshold for each individual speed point.

46-73 Warning Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

46-74 Alarm Low

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

6.41.10 46-8* Cavitation

46-80 Alarm High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Upper threshold limit for cavitation monitoring at each monitoring speed points. An alarm high notification is issued if the threshold is exceeded.

46-81 Warning S2 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Upper threshold limit for cavitation monitoring at each monitoring speed points. A warning S2 high notification is issued if the threshold is exceeded.

46-82 Warning S1 High

Default value:	0%	Parameter type:	Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Upper threshold limit for cavitation monitoring at each monitoring speed points. A warning S1 high notification is issued if the threshold is exceeded.

6.42 Parameter Group 47-** CBM Baseline Data

6.42.1 47-0* History

The parameters in this group hold the baseline history of start and stop timestamps of the active and previous baseline.

47-00 Actual Start Time

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

This parameter shows a timestamp of when the actual baseline capturing was started.

47-01 Actual Time Stop

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

This parameter shows a timestamp of when the actual baseline capturing was stopped.

47-02 Previous Start Time

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

This parameter shows a timestamp of when the previous baseline capturing was started.

47-03 Previous Stop Time

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	True

This parameter shows a timestamp of when the previous baseline capturing was stopped.

6.42.2 47-0* Speeds

The parameters in this group show the baseline speed points of active and previous baseline data.

47-04 Actual Speed

Default value:	0 RPM	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	67
Change during operation:	True		

This parameter shows the baseline speed points of the actual baseline data captured.

47-05 Previous Speed

Default value:	0 RPM	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

This parameter shows the baseline speed points of the previous baseline data captured.

6.42.3 47-0* Stator

47-06 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the maximum stator winding readings for the active baseline.

47-07 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the mean and 3 standard deviations of stator winding readings for the active baseline.

47-08 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the average of stator winding readings for the active baseline.

47-09 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The parameter shows the minimum value of motor stator windings for active baseline.

47-10 Actual Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the active minutes to capture monitoring values for speed points.

47-11 Previous Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the maximum stator winding readings for the previous baseline.

47-12 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the mean and 3 standard deviations of stator winding readings for the previous baseline.

47-13 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

This parameter shows the average of stator winding readings for the previous baseline.

47-14 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

The parameter shows the minimum value of motor stator windings for previous baseline.

47-15 Previous Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the previous minutes to capture monitoring values for speed points.

6.42.4 47-1* Stator Res. Active

47-16 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the active stator resistance.

47-17 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean and 3 standard deviations of stator resistance readings for the active baseline.

47-18 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

Shows the mean of stator resistance recordings for active load in the active baseline.

47-19 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

Shows the minimum of all stator resistance recordings for active load in the active baseline.

47-20 Previous Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum stator resistance readings for the previous baseline.

47-21 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean and 3 standard deviations of stator resistance readings for the previous baseline.

47-22 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average of stator resistance readings for the previous baseline.

47-23 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the minimum value of motor stator resistance for previous baseline.

6.42.5 47-2* Stator Res. Load

47-24 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum load dependent stator resonance. An indexed parameter with 20 pointers showing stator resonance load recordings from minimum to maximum.

47-25 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average and standard deviation of the stator resonance load recordings for the active baseline.

47-26 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average of the stator resonance load recordings for the active baseline.

47-27 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the minimum value of the stator resonance load recordings for the active baseline.

47-28 Previous Max

Default value:	0%	Parameter Type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum stator resonance readings for the previous baseline.

47-29 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean and 3 standard deviations of stator resonance readings for the previous baseline.

47-30 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average of stator resonance readings for the previous baseline.

47-31 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the minimum value of motor stator resonance for the previous baseline.

6.42.6 47-3* Load

47-32 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum positive load envelope recordings for the active baseline. An indexed parameter with 20 pointers of positive load envelope recordings with minimum to maximum.

47-33 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the active mean and 3 standard deviation of load envelope recordings for active baseline.

47-34 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the active mean of load envelope recordings for the active baseline.

47-35 Actual Mean - 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the active mean minus 3 standard deviation of load envelope recordings for the active baseline.

47-36 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the minimum value of load envelope recordings for the active baseline.

47-37 Actual Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the active minutes to capture monitoring values for load envelope.

47-38 Previous Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum value for load envelope readings for the previous baseline.

47-39 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean and 3 standard deviations of load envelope readings for the previous baseline.

47-40 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average of load envelope readings for the previous baseline.

47-41 Previous Mean - 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean minus 3 standard deviations of load envelope readings for the previous baseline.

47-42 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the minimum value of load envelope for the previous baseline.

47-43 Previous Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the previous minutes to capture monitoring values for load envelope.

6.42.7 47-4* Sensor 1

47-44 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum recordings from vibration sensors for the active baseline.

47-45 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average and 3 standard deviations for upper threshold of recordings from vibration sensors for active baseline.

47-46 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average value of recordings from vibration sensors for the active baseline.

47-47 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the minimum value of recordings from vibration sensors for the active baseline.

47-48 Actual Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the active minutes to capture monitoring values for Sensor 1.

47-49 Previous Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum value for Sensor 1 readings for the previous baseline.

47-50 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean and 3 standard deviations of Sensor 1 readings for the previous baseline.

47-51 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average of Sensor 1 readings for the previous baseline.

47-52 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the minimum value of Sensor 1 for the previous baseline.

47-53 Previous Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the previous minutes to capture monitoring values for Sensor 1.

6.42.8 47-5* Sensor 2

47-54 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum recordings from vibration sensors for the active baseline.

47-55 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average and 3 standard deviations for upper threshold of recordings from vibration sensors for active baseline.

47-56 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

Shows the average value of recordings from vibration sensors for active baseline.

47-57 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the minimum value of recordings from vibration sensors for active baseline.

47-58 Actual Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the active minutes to capture monitoring values for Sensor 2.

47-59 Previous Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum value for Sensor 2 readings for the previous baseline.

47-60 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean and 3 standard deviations of Sensor 2 readings for the previous baseline.

47-61 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average of Sensor 2 readings for the previous baseline.

47-62 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the minimum value of Sensor 2 for the previous baseline.

47-63 Previous Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the previous minutes to capture monitoring values for Sensor 2.

6.42.9 47-6* Sensor 3

47-64 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum recordings from vibration sensors for the active baseline.

47-65 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average and 3 standard deviations for upper threshold of recordings from vibration sensors for active baseline.

47-66 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

Shows the average value of recordings from vibration sensors for active baseline.

47-67 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the minimum value of recordings from vibration sensors for active baseline.

47-68 Actual Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the active minutes to capture monitoring values for Sensor 3.

47-69 Previous Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum value for Sensor 3 readings for the previous baseline.

47-70 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean and 3 standard deviations of Sensor 3 readings for the previous baseline.

47-71 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average of Sensor 3 readings for the previous baseline.

47-72 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the minimum value of Sensor 3 for the previous baseline.

47-73 Previous Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the previous minutes to capture monitoring values for Sensor 3.

6.42.10 47-7* Sensor 4

47-74 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum recordings from vibration sensors for the active baseline.

47-75 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average and 3 standard deviations for upper threshold of recordings from vibration sensors for active baseline.

47-76 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

Shows the average value of recordings from vibration sensors for active baseline.

47-77 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the minimum value of recordings from vibration sensors for active baseline.

47-78 Actual Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the active minutes to capture monitoring values for Sensor 4.

47-79 Previous Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the maximum value for Sensor 4 readings for the previous baseline.

47-80 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the mean and 3 standard deviations of Sensor 4 readings for the previous baseline.

47-81 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average of Sensor 4 readings for the previous baseline.

47-82 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the minimum value of Sensor 4 for the previous baseline.

47-83 Previous Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the previous minutes to capture monitoring values for Sensor 4.

6.42.11 47-8* Cavitation

47-84 Actual Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the maximum value of the actual baseline statistical data captured for cavitation values.

47-85 Actual Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the mean + 3 times standard deviation value of the actual baseline statistical data captured for cavitation values.

47-86 Actual Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the mean value of the actual baseline statistical data captured for cavitation values.

47-87 Actual Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the minimum value of the actual baseline statistical data captured for cavitation values.

47-88 Actual Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the online baseline count for the actual baseline data for cavitation values.

47-89 Previous Max

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the maximum value of the previous baseline statistical data captured for cavitation values.

47-90 Previous Mean + 3 Std. Dev.

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the mean + 3 standard deviation value of the previous baseline statistical data captured for cavitation values.

47-91 Previous Mean

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter shows the mean value of the previous baseline statistical data captured for cavitation values.

47-92 Previous Min

Default value:	0%	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

The parameter displays the minimum value of the previous baseline statistical data captured for cavitation values.

47-93 Previous Counter

Default value:	0	Parameter type:	Readout, Array [20]
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	False

The parameter shows the online baseline for the previous baseline data for cavitation values.

6.42.12 47-9* Min Max Speed

47-95 Actual Min Speed

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

This parameter shows the minimum speed of the actual baseline data.

47-96 Actual Max Speed

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

This parameter shows the maximum speed of the actual baseline data.

47-97 Previous Min Speed

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

This parameter shows the minimum speed of the previous baseline data.

47-98 Previous Max Speed

Default value:	0 RPM	Parameter type:	Readout
Setup:	All setups	Conversion index:	67
Data type:	Uint16	Change during operation:	True

This parameter shows the maximum speed of the previous baseline data.

6.43 Parameter Group 48-** CBM Applications

6.43.1 48-0* Cavitation Control

48-00 Function

Default value:	[0] Disabled	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Use cavitation control to lower the pump speed if a cavitation warning appears. For standalone operation, set the parameter manually. For remote operation, set the parameter via fieldbus.

Option	Name	Description
[0]*	Disabled	This selection disables cavitation control.
[1]	Enabled	This selection enables cavitation control.

48-01 Status

Default value:	[0] Disabled - local	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

This parameter shows the status of the cavitation controller.

Table 89: Parameter Index

ID	Status value	Description
[0]	Disabled - local	The cavitation control is disabled by a local command via the LCP or MCT 10.
[1]	Disabled - remote	The cavitation control is disabled by a remote command via fieldbus.
[2]	Enabled - local ref.	The cavitation control is enabled. The drive in hand-on mode and follows the local speed reference as there is no cavitation detected yet.
[3]	Enabled - remote ref.	The cavitation control is enabled. The drive is in auto-on mode and follows the remote speed reference as there is no cavitation detected yet.
[5]	Standby - drive coasted	The cavitation control is on standby as the drive is coasted. The algorithm re-enables itself automatically when the drive is back in normal operation.

Table 89: Parameter Index - (continued)

ID	Status value	Description
[6]	Standby - drive standby	The cavitation control is on standby as the drive is in standby state. The algorithm re-enables itself automatically when the drive is back in normal operation.
[7]	Standby - drive off	The cavitation control is on standby as the drive is in off state. The algorithm re-enables itself automatically when the drive is back in normal operation.
[8]	Standby - drive alarm	The cavitation control is on standby due to various alarms. The algorithm re-enables itself automatically when the drive is back in normal operation.
[9]	Standby - BL running	The cavitation control is disabled for the entire duration of the baseline. Allow baseline to finish correctly and perform a proper threshold generation for cavitation. The cavitation control re-enables itself automatically when the drive is back in normal operation.
[10]	Standby - not in cavit ctrl range	The actual speed is outside the range allowed for cavitation control, which puts the cavitation control in standby. Resolution: The algorithm re-enables itself automatically when the actual speed returns to its baseline range. Alternatively, check if the limits in the following parameters are set correctly: - Parameter 48-05 Minimum Speed [RPM]/parameter 48-06 Minimum Speed [Hz]. - Parameter 4-11 Motor Speed Low Limit [RPM]/parameter 4-12 Motor Speed Low Limit [Hz]. - Parameter 3-02 Minimum Reference. - Parameter 45-26 CBM Baseline Min Speed.
[11]	Standby - not in BL speed range	The actual speed is outside of the baseline speed range, which puts cavitation control on standby due to lack of cavitation data. Resolution: The algorithm re-enables itself automatically when the actual speed returns into its baseline range. Alternatively, check if the limits in the following parameters are set correctly: - Parameter 48-05 Minimum Speed [RPM]/parameter 48-06 Minimum Speed [Hz]. - Parameter 4-11 Motor Speed Low Limit [RPM]/parameter 4-12 Motor Speed Low Limit [Hz]. - Parameter 3-02 Minimum Reference. - Parameter 45-26 CBM Baseline Min Speed.
[12]	Standby - other priority task	The application is under an operating condition which requires another function of a higher priority to take control of the pump, for example, jogging, deragging, and dry run. This forces the cavitation control into standby mode. The algorithm re-enables itself automatically when the drive returns to normal operation.

Table 89: Parameter Index - (continued)

ID	Status value	Description
[13]	Ramp down - cavit. detected	Cavitation control lowers the speed because of detecting cavitation. The speed decreases according to parameter 48-02 Step Change in Speed . The LCP indicates that the speed reference is controlled by cavitation control. Resolution: Verify the reasons for cavitation warnings.
[14]	Ramp up - no cavit.	Cavitation control sets the speed towards the actual speed reference since cavitation is no longer present. The actual speed reference can be local or remote. The speed increases according to parameter 48-02 Step Change in Speed . The LCP indicates that the speed reference is still controlled by cavitation control. Resolution: Allow sufficient time for cavitation control to reach its actual speed reference.
[15]	At min speed - cavit. detected	Cavitation control reached its minimum allowed speed while cavitation is still present. The cavitation remains at this value for the time that cavitation persists. The LCP indicates that the speed reference is controlled by cavitation control. Resolution: Verify the reasons for cavitation warnings. Alternatively, check if the speed limit is set correctly.
[16]	At no return speed	Cavitation control avoided cavitation by lowering the speed and stays at the actual speed because parameter 48-04 Return to Reference is set to [0] No . The LCP indicates that the speed reference is controlled by cavitation control. Resolution: Verify the reasons for cavitation warnings. Alternatively, check if the parameter is set correctly.

48-02 Step Change in Speed

Default value:	3%	Parameter type:	Range, 0.1 - 20%
Setup:	All setups	Conversion index:	-1
Data type:	Uint8	Change during operation:	True

Set the value of the speed change which the cavitation control performs at each step time. The value is defined in percent of the motor nominal speed set in parameter **1-25 Motor Nominal Speed**.

48-03 Step Time

Default value:	15 s	Parameter type:	Range, 1 - 600 s
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

Set the discrete periodical control time of the cavitation control. The value must be equal to or greater than any of the timers defined in parameter **46-12.6 Warning S1 Time** or parameter **46-11.6 Warning S2 Time**.

48-04 Return to Reference

Default value:	[1] Yes	Parameter type:	Option
Setup:	All setups	Conversion index:	–

Data type:	UInt8	Change during operation:	True

Select if the cavitation control should remain at the last speed reference that avoided the cavitation, or if it should gradually return to the actual speed reference while continuously checking that the cavitation has disappeared.

Option	Name	Description
[0]	No	With this selection, cavitation control does not return to the actual speed reference, but remains at the last speed reference that avoided the cavitation.
[1]*	Yes	This selection, the cavitation control gradually returns to the actual speed reference.

48-05 Minimum Speed [RPM]

Default value:	Size related	Parameter type:	Range, par. 4-11 - par. 4-13 RPM
Setup:	All setups	Conversion index:	67
Data type:	UInt16	Change during operation:	True

Specify the minimum RPM limit for cavitation control to regulate the speed reference. This value must not be lower than any of the following:

- Parameter **4-11 Motor Speed Low Limit [RPM]**
- Parameter **3-02 Minimum Reference**
- Parameter **45-26 CBM Baseline Min Speed**

48-06 Minimum Speed [Hz]

Default value:	Size related	Parameter type:	Range, Par. 4-12 - par. 4-14
Setup:	All setups	Conversion index:	-1
Data type:	UInt16	Change during operation:	True

Specify the minimum Hz limit for cavitation control to regulate the speed reference. This value must not be lower than any of the following:

- Parameter **4-12 Motor Speed Low Limit [Hz]**
- Parameter **3-02 Minimum Reference**
- Parameter **45-26 CBM Baseline Min Speed**

6.44 Parameter Group 49-** CBM-SWF

6.44.1 49-0* Cockpit: Monitoring

Use the parameters in this group for configuring and providing overall status of the sine-wave filter monitoring functions.

49-00 Autonomous Function

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Autonomous monitoring function for CBM-SWF. Select **[1] Warning** or **[2] Alarm & warning** notification to start the monitoring of the sine-wave filter.

For manual testing and immediate, on-demand measurements (bypassing the default 2-day waiting period), toggle this parameter from **[1] Warning** or **[2] Alarm and warning** to **[0] Off** and then back to the original option.

Option	Name	Description
[0]	Off	
[1]	Warning	
[2]	Alarm & warning	

49-01 Autonomous Status

Default value:	[0] Disabled	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False

This parameter shows the status of the monitoring function.

Index	Name	Description
[0]*	Disabled	The autonomous monitoring function is disabled. There is no check of the SWF capacitors.
[1]	Ready - latest available	Measurement is done successfully, and the latest results are available for readout.
[2]	Measurement in progress	Measurement is in progress. Notification and data will be available shortly.
[3]	Waiting for new measurement	The result of the latest measurement requires further verification. A new measurement will start at the time set in parameter 49-03 Next Measurement .
[4]	Standby - baseline in progress	Baseline is in progress and monitoring cannot be enabled. Allow the baseline to finish before enabling monitoring.
[5]	Standby - voltage limit	The voltage limit is reached, which temporarily stops the capacitor measurement. The algorithm re-enables itself when getting inside the normal voltage range allowed for measurement.
[6]	Standby - speed out of range	The speed limit is reached, which temporarily stops the measurement. The allowed speed range is 1.5 Hz to 1.1 times the nominal frequency. The algorithm re-enables itself automatically when getting inside the normal speed range allowed for measurement.
[7]	Standby - after alarm reset	Any alarm or reset of the drive stops the autonomous monitoring immediately and stays on hold until the alarm clears. The algorithm re-enables itself automatically. Wait until the alarm clears, then check the drive and sine-wave filter for faults.
[8]	Standby - manual interrupt local	The current measurement is manually stopped while the drive is configured to use local reference from LCP. Re-enable the autonomous function.

Index	Name	Description
[9]	High Dynamic Loading	Monitoring is temporarily on hold due to too high dynamical changes of the speed or loading. The algorithm re-enables itself automatically when normal conditions are established.
[10]	Communication failed	Monitoring is temporarily on hold due to internal communication errors. Re-enable the autonomous function. If it is not successful, contact support.
[11]	Capacitor disconnect on all phases	The monitoring detected a connection problem with all 3 SWF capacitors and it temporarily on hold. The algorithm runs again to check the capacitance at the time set in parameter 49-03 Next Measurement . Check if the sine-wave filter components are disconnected or damaged.
[12]	Baseline data not available	Baseline data is missing, thus monitoring is not allowed to start. Perform a new baseline.
[13]	Capacitor disconnected on phase U	The monitoring detected a connection problem, either with the capacitor or inductor of a given phase and is temporarily on hold. The algorithm runs again to check the capacitance at the time set in parameter 49-03 Next Measurement . Check if the sine-wave filter components are disconnected or damaged.
[14]	Capacitor disconnected on phase V	Same description as [13] Capacitor disconnected on phase U .
[15]	Capacitor disconnected on phase W	Same description as [13] Capacitor disconnected on phase U .
[16]	Upper measurement limit exceeded on phase U	The monitoring detected that the measurement of a given phase falls outside of the higher limit of the measurement range. The algorithm runs again to check the capacitance measurement at the time set in parameter 49-03 Next Measurement . Check if capacitors are disconnected or damaged. Alternatively, set the operation point of the drive at a lower loading current. Another alternative is to increase parameter 49-15 Frequency Sweep Max to a higher value, for example, 1800 Hz. Then start a new baseline.
[17]	Upper measurement limit exceeded on phase V	Same description as [16] Upper measurement limit exceeded on phase U .
[18]	Upper measurement limit exceeded on phase W	Same description as [16] Upper measurement limit exceeded on phase U .
[19]	Lower measurement limit exceeded on phase U	The monitoring detected that the measurement of a given phase falls outside of the lower limit of the measurement range. The algorithm runs again to check the capacitance measurement at the time set in parameter 49-03 Next Measurement . Check if the capacitors are disconnected or damaged. Alternatively, set the operation point of the drive at a higher loading current. Another alternative is to decrease parameter 49-14 Frequency Sweep Min at a lower value, for example, 150 Hz. Then start a new baseline.
[20]	Lower measurement limit exceeded on phase V	Same description as [19] Lower measurement limit exceeded on phase U .
[21]	Lower measurement limit exceeded on phase W.	Same description as [19] Lower measurement limit exceeded on phase U .
[22]	Upper measurement limit exceeded on all phases	Same description as [16] Upper measurement limit exceeded on phase U .

Index	Name	Description
[23]	Lower measurement limit exceeded on all phases.	Same description as [19] Lower measurement limit exceeded on phase U .
[24]	Motor is not connected	The motor is not connected, and monitoring is temporarily set on hold. The drive is kept in operation without any other action. It can also happen for low drive current, for example, during AEO. Check and reconnect the motor cable and restart the application. Alternatively, allow the drive current to increase.
[25]	Standby - AMA	Measurement is on hold while AMA is running. Measurement resumes once AMA is completed.
[26]	Standby - kinetic backup	Measurement is on hold during kinetic backup. Measurement resumes once kinetic backup is completed.
[27]	Standby - mains failure	Measurement is on hold during mains failure. Measurement resumes once the mains failure is resolved.
[28]	Standby - stall limit	Measurement is on hold during stall limit. Resumes measurement once the stall limit is resolved.
[29]	Standby - active power derate	Measurement is on hold during active power derate. Measurement resumes after power derate.
[30]	Communication timeout	Measurement is halted due to an error that occurred internally. The algorithm restarts measurement at the time set in parameter 49-03 Next Measurement .
[31]	Standby - drive OFF state	Measurement is on hold as the drive is in OFF state. Start the drive with the specified speed range.
[32]	Standby - drive in standby state	Measurement is on hold as the drive is in standby state. Enable [Start] digital output pin and run the drive the specified speed range.
[33]	Standby - manual interrupt remote	Current measurement is manually stopped via fieldbus by a remote reference. Re-enable the autonomous function in parameter 49-00 Autonomous Function .
[34]	Standby - drive in coast state	Measurement is on hold due as the drive is in coast state. Start the drive with the specified speed range.

49-02 Autonomous Capacitance Value

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	UInt16	Change during operation:	False

This parameter shows the latest lowest value of U, V, W phase capacitance in percentage of parameter **49-13 Baseline Capacitance Value**.

49-03 Next Measurement

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

This parameter shows the next measurement time in the time-of-day format. The parameter is only valid if the date and time is set.

6.44.2 49-1* Baseline Settings

Use the parameters in this group for configuring how to capture baseline data. Progress and status are provided in readout parameters.

49-10 Baseline Generate

Default value:	–	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

Option	Name	Description
[0]	Baseline off	No baselining is taking place.
[1]	Baseline start	Select this option to start the initial baseline measurement of the sine-wave filter.

49-11 Baseline Status

Default value:	[0] Not started	Parameter type:	Readout
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	True

This parameter shows the status of the baseline monitoring function.

Index	Name	Description
[0]*	Not started	Baseline is not yet performed, and there is no data available to start any monitoring.
[1]	Baseline running	Baseline has started to run at the selected speed and current. After all steps are successfully completed, data is saved into EEPROM. If the baseline fails, details are available in the status code via the LCP or VLT® Motion Control Tool MCT 10.
[2]	Baseline completed	Baseline is successfully completed, and data is available for use. Monitoring can be enabled.
[3]	BL fail - no connection all phases	The capacitor of a given phase is disconnected from the sine-wave filter. Check the filter capacitors or their connection and replace if needed.
[4]	BL fail - no connection U phase	Same description as [3] BL fail - no connection all phases .
[5]	BL fail - no connection V phase	Same description as [3] BL fail - no connection all phases .
[6]	BL fail - no connection W phase	Same description as [3] BL fail - no connection all phases .
[7]	BL fail - manual interrupt remote	The baseline process is remotely stopped. Restart the baseline to get capacitance data.
[8]	BL fail - alarm	An alarm occurred during baseline. Check for correct installation of the drive and its settings and restart the baseline.
[9]	BL fail - time out	The baseline step is not able to get data in due time. Check for correct drive settings and restart the baseline.

Index	Name	Description
[10]	BL fail - low capacitance in U phase	The capacitor of the given phase is lower than 50% of the nameplate value and is considered abnormal to continue the baseline. Check for correct installation of the sine-wave filter. Measure and replace capacitors if needed and restart the baseline.
[11]	BL fail - low capacitance in V phase	Same description as [10] BL fail - low capacitance in U phase .
[12]	BL fail - low capacitance in W phase	Same description as [10] BL fail - low capacitance in U phase .
[13]	BL fail - state B comm fail	This is an internal drive error regarding communication between processors. Check for correct settings of the drive and restart the baseline.
[14]	BL fail - others	This is an internal drive error. Check for correct settings of the drive and restart the baseline.
[15]	BL fail - upper measurement limit exceeded on phase U	Measurement of a given phase is outside the higher limit of the measurement range. Check for correct installation of the sine-wave filter, measure and replace capacitors if needed. Alternatively, set the operation point of the drive at a lower loading current. Another alternative is to increase parameter 49-15 Frequency Sweep Max to a higher value, for example, 1800 Hz. Then restart the baseline.
[16]	BL fail - upper measurement limit exceeded on phase V	Same description as [15] BL fail - upper measurement limit exceeded on phase U .
[17]	BL fail - upper measurement limit exceeded on phase W	Same description as [15] BL fail - upper measurement limit exceeded on phase U .
[18]	BL fail - upper measurement limit exceeded on all phases	Same description as [15] BL fail - upper measurement limit exceeded on phase U .
[19]	BL fail - lower measurement limit exceeded on phase U	Measurement of a given phase is outside of the lower limit of the measurement range. Check for correct installation of the sine-wave filter, measure and replace capacitors if needed. Alternatively, set the operation point of the drive at a higher loading current. Another alternative is to decrease parameter 49-14 Frequency Sweep Minto to a lower value, for example, 150 Hz. Then restart the baseline.
[20]	BL fail - lower measurement limit exceeded on phase V	Same description as [19] BL fail - lower measurement limit exceeded on phase U .
[21]	BL fail - lower measurement limit exceeded on phase W	Same description as [19] BL fail - lower measurement limit exceeded on phase U .
[22]	BL fail - lower measurement limit exceeded on all phases	Same description as [19] BL fail - lower measurement limit exceeded on phase U .
[23]	BL fail - motor is not connected	The motor is not detected. The baseline stops without saving the data. It can also happen at low drive current, for example, during AEO. Check and reconnect the motor cable and restart the application. Alternatively, allow the drive current to increase by using higher loading. Restart the baseline.
[24]	BL fail - speed not in range	The speed is outside the specified range of 1.5 Hz to 110% nominal speed. Set the speed in the specified range and restart the baseline.

Index	Name	Description
[25]	BL fail - RMS current variation	The drive current changed by more than 15% during baseline. The baseline repeats the measurement 3 times and stops if conditions still are not met. Set the load profile to fit the given interval and repeat the baseline.
[26]	BL fail - Drive OFF state	The drive is in OFF state which does not allow the baseline to proceed. Start the drive in hand-on or auto-on mode within the specified speed range and restart the baseline.
[27]	BL fail - voltage limit	The drive output voltage reached the maximum voltage during the measurements. The baseline repeats the measurement 3 times and stops if conditions are still not met. Set the load profile to fit the given interval and repeat the baseline.
[28]	BL fail - high dynamic	The drive current changed rapidly during measurement. Set the load profile to fit the given interval and repeat the baseline.
[29]	BL fail - AMA running	The drive is running AMA. Disconnect SWF and run the drive to finish the AMA. When the AMA is complete, restart the baseline by connecting the SWF.
[30]	BL fail - k.backup	The drive is in kinetic backup mode. Allow the drive to finish the kinetic backup and restart the baseline.
[31]	BL fail - mains failure	Mains supply does not meet the conditions for drive operation. Restore the power supply to fulfill the normal operating conditions of the drive and restart the baseline.
[32]	BL fail - coast mode	The drive is in coast mode. Allow the drive to get out of coast mode and restart the baseline.
[33]	BL fail - stall protection	The drive is in stall mode. Allow the drive to finish stall mode and restart the baseline.
[34]	BL fail - active power derate	The drive is in active power derate mode. Allow the drive to finish the active power mode and restart the baseline.
[35]	BL fail - manual interrupt local	The baseline was interrupted manually via LCP or MCT 10. Restart the baseline to get capacitance data.
[36]	BL fail - state 1 comm fail	This is an internal drive error regarding communication between processors. Check for correct settings of the drive and try to start a new baseline.
[37]	BL fail - SWF not selected	The sine-wave filter option is not selected. If the drive starts with parameter 14-22 Operation Mode set to [2] Initialization after baseline completion, the baseline capacitance value shows incorrect data. Set parameter 14-55 Output Filter to either [1] Sine-wave filter or [2] Sine-wave filter fixed . Then set parameters 14-56 Capacitance Output Filter and 14-57 Inductance Output Filter to appropriate values before restarting the drive.
[38]	BL fail - motor type incorrect	The selected motor type is not supported. Set parameter 1-10 Motor Construction to [0] Asynchron .
[39]	BL fail - ctrl. principle incorrect	The selected motor control principle is not supported. Set parameter 1-01 Motor Control Principle to [1] VVC+ .

49-12 Baseline History

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

Time stamp of the baseline capture completion in the time-of-day format. The parameter is only valid if the date and time are set.

49-13 Baseline Capacitance Value

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the average value of the U, V, and W phase capacitance captured during baseline measurement. The average value is shown as a percentage of parameter **14-56 Capacitance Output Filter**.

49-14 Frequency Sweep Min

Default value:	300 Hz	Parameter type:	Range, 100 - 1200 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

If the measurement fails with a **Lower measurement limit exceeded**, try to lower the minimum limit.

49-15 Frequency Sweep Max

Default value:	1600 Hz	Parameter type:	Range, Par. 49-14 - 2500 Hz
Setup:	All setups	Conversion index:	0
Data type:	Uint16	Change during operation:	True

If the measurement fails with an **Upper measurement limit exceeded**, try to increase the maximum limit.

49-16 Baseline Progress

Default value:	0%	Parameter type;	Readout
Setup:	All setups	Conversion index:	0
Data type:	Uint8	Change during operation:	True

49-18 SineWave Filter Type

Default value:	[0] Danfoss	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	Uint8	Change during operation:	False



NOTE: This parameter cannot be adjusted while the drive is running.

Select the filter connection type.

Option	Name	Description
[0]*	Danfoss	Use this option for Danfoss sine-wave filters.
[1]	Delta NonDanfoss	Use this option for sine-wave filters with delta-connected capacitors.
[2]	Star NonDanfoss	Use this option for sine-wave filters with star-connected capacitors.

6.44.3 49-2* Threshold Config.

Use the parameters in this group for configuring thresholds for warnings and alarms.

49-20 Warning S1 Threshold

Default value:	90%	Parameter type:	Range, 50 - 130%
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the 1st warning threshold level, *Warning 541, SineWaveFilter*. The level for this warning must be higher than the level set in parameter **49-21 Warning S2 Threshold**.

49-21 Warning S2 Threshold

Default value:	85%	Parameter type:	Range, 50% - Par. 49-20 [%]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the 2nd warning threshold level, *Warning 531, SineWaveFilter S2*. The level for this warning must be higher than the level set in parameter **49-22 Alarm Threshold**.

49-22 Alarm Threshold

Default value:	75%	Parameter type:	Range, 50% - Par. 49-21 [%]
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	True

Enter the alarm threshold level where the drive should stop the application (*Alarm 541, SineWaveFilter*).

49-23 Warning S1 Time

Default value:	10 min	Parameter type:	Range, 0 - 180 min
Setup:	All setups	Conversion index:	70
Data type:	Uint32	Change during operation:	True

Set the monitoring delay trigger time for warning S1.

49-24 Warning S2 Time

Default value:	10 min	Parameter type:	Range, 0 - 180 min
Setup:	All setups	Conversion index:	70

Data type:	UInt32	Change during operation:	True

Set the monitoring delay trigger time for warning S2.

49-25 Alarm Time

Default value:	10 min	Parameter type:	Range, 0 - 180 min
Setup:	All setups	Conversion index:	70
Data type:	UInt32	Change during operation:	True

Set the monitoring delay trigger time for alarm.

49-26 Last Modified Time

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

This parameter shows the last modified time of the thresholds in the time-of-day format. The parameter is only valid if the date and time are set.

6.44.4 49-3* Adv Monitoring Readouts 1

Use the parameters in this group to show monitoring capacitance data.

49-30 Readout Setting

Default value:	[0] Actual	Parameter type:	Option
Setup:	All setups	Conversion index:	–
Data type:	UInt8	Change during operation:	True

Select which readout configuration to use for updating the relative readouts in parameter group **49-3* Adv Monitoring Readouts 1**.

Option	Name	Description
[0]*	Actual	This setting represents the relative actual capacitance in respect to the baseline value.

49-31 Capacitance of Phase U

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	UInt16	Change during operation:	False

This parameter shows the capacitance of the U phase measured during monitoring.

49-32 Capacitance of Phase V

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	UInt16	Change during operation:	False

This parameter shows the capacitance of the V phase measured during monitoring.

49-33 Capacitance of Phase W

Default value:	0%	Parameter type:	Readout
Setup:	All setups	Conversion index:	-2
Data type:	Uint16	Change during operation:	False

This parameter shows the capacitance of the W phase measured during monitoring.

49-34 Measurement History

Default value:	Size related	Parameter type:	Readout
Setup:	All setups	Conversion index:	0
Data type:	TimeOfDay	Change during operation:	False

This parameter shows the last time stamp of capacitance measured in the time-of-day format. The parameter is only valid if the date and time are set.

6.45 Parameter Group 50-** License

50-00 License Installed

Default value:	0	Parameter type:	Readout, Array [3]
Setup:	All setups	Conversion index:	0
Data type:	VisStr[40]	Change during operation:	False

Shows all licenses activated in the drive.

50-01 License Code

Default value:	Size related	Parameter type:	Range, 0 - 19
Setup:	1 setup	Conversion index:	0
Data type:	VisStr[19]	Change during operation:	True

Enter the license code provided by the sales representative to activate licensed features in the drive. The license code comprises 16 alphanumeric characters in the format (XXXX-XXXX-XXXX-XXXX). When the license is accepted by the drive, the parameter is shown as 0000-0000-0000-0000.



NOTE: Restart the drive after entering the new license code. Parameters relevant for configuring the new feature(s) are now shown in the drive. The new type code is reflected in parameter **15-45 Actual Typecode String**. The original type code of the drive can be viewed in parameter **15-44 Ordered Typecode String**. The activated license is shown in parameter **50-00 License Installed**.

The license code can also be set from the factory.

6.46 Parameter Group 600-** PROFIsafe

600-00 Velocity Reference Value

Default value:	1500.000 ReferenceFeedbackUnit	Parameter type:	Range, -999999.999 - 999999.999 ReferenceFeedbackUnit
Setup:	All setups	Conversion index:	-3
Data type:	Int32	Change during operation:	True

The velocity reference sets the speed value for 100% for N2/N4 normalized speed signals.

600-22 PROFIdrive/safe Tel. Selected

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

600-44 Fault Message Counter

Default value:	0	Parameter type:	Range, 0 - 65535
Setup:	1 setup	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Shows the number of safety fault buffer changes.

600-47 Fault Number

Default value:	0	Parameter type:	Array [64]
Setup:	1 setup	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Shows the internal fault number for a fault in the safety fault buffer.

600-52 Fault Situation Counter

Default value:	0	Parameter type:	Range, 0 - 1000
Setup:	1 setup	Conversion index:	0
Data type:	UInt16	Change during operation:	True

Number of fault situations that have occurred since the last reset in the safety fault buffer.

6.47 Parameter Group 601-** PROFIdrive 2

601-22 PROFIdrive Safety Channel Tel. No.

Default value:	108	Parameter type:	Range, 0 - 65535
Setup:	All setups	Conversion index:	0
Data type:	UInt16	Change during operation:	True

7 Features of the Integrated Motion Controller

7.1 Introduction to IMC



NOTE: The integrated motion control is only available with special IMC software version 48.XX. To order the drive with the IMC software, use the type code with software release version S067.

The integrated motion controller (IMC) enables position control with all motor control principles and motor types with and without feedback.

To activate the IMC functionality, select [9] *Positioning* or [10] *Synchronization* in parameter **1-00 Configuration Mode**. IMC enables the following functions:

- Positioning: Absolute, relative, and touch probe.
- Homing.
- Position synchronization.
- Virtual master.

Position control in both positioning and synchronization modes can be either sensorless or with feedback. In the sensorless control principle, the motor angle calculated by the motor controller is used as feedback. In the closed-loop control principle, VLT® AutomationDrive FC 302 supports most standard incremental encoders, absolute encoders, and resolvers. The position controller can handle both linear and rotary systems. The controller can scale positions to any relevant physical unit such as mm or degrees.

7.2 Positioning, Homing, and Synchronization

7.2.1 Positioning

The drive supports relative positioning and absolute positioning. A positioning command requires 3 inputs:

- Target position.
- Speed reference.
- Ramp times.

The 3 inputs can come from various sources, see [Figure 101](#).




Figure 101: Positioning References

In each control cycle (1 ms), the profile generator calculates position, speed, and acceleration required to do the specified movement. The outputs from the profile generator are used for the position and speed controller.

7.2.2 Homing

Homing is required for creating a reference to the physical machine position in closed-loop control principle with incremental encoder or in sensorless control principle. IMC supports various homing functions with or without a homing sensor. Select the homing function in parameter **17-80 Homing Function**. After selecting a homing function, complete homing before executing absolute positioning.

7.2.3 Synchronization

In synchronization mode, the drive follows the position of a master signal. The master signal and the offset between the master and the follower are handled as shown in [Figure 102](#).




Figure 102: Synchronization References

In each control cycle (1 ms), the profile generator calculates position, speed, and acceleration required to do the specified movement. The outputs from the profile generator are used as inputs for the position and speed controller.

7.2.4 Fieldbus References

Fieldbus references for speed and position are set via the process data (PCD) configuration as shown in the example:




Figure 103: Positioning: Default settings (PCD 1 = Fieldbus REF 1)




Figure 104: Positioning: PCD write configuration PCD 1 = Fieldbus REF 1, PCD 2 and 3 = Fieldbus Pos REF




Figure 105: Synchronizing: PCD write configuration PCD 1 = Fieldbus Sync REF

7.3 Control

7.3.1 Control Loops

In positioning and synchronization mode, 2 extra control loops control the motor in addition to the motor controller running flux control principle, sensorless, or with motor feedback. The position PI controller is the outer loop providing the setpoint for the speed PID, which provides the reference for the motor controller. For a closed loop, feedback source can be selected individually for each of 3 controllers.

For sensorless control principle, select [0] *Motor feedb. P1-02* in the following parameters:

- Speed PID: Parameter **7-00 Speed PID Feedback Source**.
- Position PI: Parameter **7-90 Position PI Feedback Source**.

With this set-up, both controllers use the motor angle calculated by the motor controller. See [Figure 106](#) for control structure and parameters affecting the control behavior.




Figure 106: Positioning and Synchronization Mode

7.3.2 Control and Status Signals

IMC control and status signals are available I/O bits and fieldbus bits.

Table 90: Control and Status Signals

Name	Function	Digital input ⁽¹⁾	Control word	Digital output	Status word
Control signals					
Enable master offset	Activates the master offset when parameter 17-93 Master Offset Selection is set to options [0]–[5].	x	x	–	–
Start homing	Starts selected homing function.	x	x	–	–
Start virtual master	Starts the virtual master.	x	x	–	–

Table 90: Control and Status Signals - (continued)

Name	Function	Digital input ⁽¹⁾	Control word	Digital output	Status word
Activate touch	Selects touch probe positioning mode.	x	x	–	–
Relative position	Selects between absolute and relative positioning.	x	x	–	–
Enable reference	Starts selected motion.	x	x	–	–
Sync. to position mode	Selects positioning in synchronizing mode.	x	x	–	–
Home sensor	Selects input for home sensor.	x	x	–	–
Home sensor inverse	Selects input for home sensor.	x	–	–	–
Touch sensor	Selects input for touch probe sensor.	x	x	–	–
Touch sensor inverse	Selects input for touch probe sensor.	x	–	–	–
Speed mode	Selects speed mode when parameter 1-00 Configuration Mode is set to [9] Positioning or [10] Synchronization .	x	x	–	–
Target inverse	Changes the sign of the set target position. For example, if the set target is 1000, the activation of this option changes the value to -1000.	x	x	–	–
Status signals					
Reverse after ramp	Indicates the sign of speed reference after the ramp.	–	–	x	–
Virtual master dir.	Controls the direction of followers.	–	–	x	–
Homing OK	Homing is completed with the selected homing function.	–	–	X	X
On target	Positioning: Target position reached. Synchronization: Follower position aligned with master position.	–	–	x	x
Position error	Maximum position error exceeded.	–	–	x	x
Position limit	A position limit is reached (parameter 3-06 Minimum Position or parameter 3-07 Maximum Position).	–	–	x	–
Touch on target	Target position is reached in touch probe position mode.	–	–	x	x
Touch activated	Touch probe positioning active.	–	–	x	x

1) For best accuracy, use fast digital inputs 18, 32, and 33 for home and touch probe sensors.

When **[3] FC Motion Profile** is selected in parameter **8-10 Control Word Profile**, the bits in the control word and the status word have the following meaning:

Table 91: Control Word

Bit	0	1
0	Preset reference LSB	–
1	Preset reference MSB	–
2 ⁽¹⁾	Preset reference EXB	–
3	Coast stop	No coast stop
4	Quick stop	No quick stop

Table 91: Control Word - (continued)

Bit	0	1
5 ⁽¹⁾	No reference	Enable reference
6	Ramp stop	Start
7	No reset	Reset
8	No jog	Jog
9 ⁽¹⁾	Absolute	Relative
10	Data not valid	Data valid
11 ⁽¹⁾	No homing	Start homing
12 ⁽¹⁾	No touch	Activate touch
13	Set-up select LSB	–
14	Set-up select MSB	–
15	No reversing	Reversing

1) Different from [0] FC Profile. Options for bits 0–2, and 12–15 in parameter 8-14 Configurable Control Word CTW:

- [11] Start Homing
- [12] Activate Touch Probe
- [13] Sync. to Pos. Mode
- [14] Ramp 2
- [15] Relay 1
- [16] Relay 2
- [17] Speed Mode
- [18] Start Virtual Master
- [19] Activate Master Offset
- [20] Target Inverse
- [26] Home Sensor
- [27] Touch Sensor

Table 92: Status Word

Bit	0	1
0	Control not ready	Control ready
1	Drive not ready	Drive ready
2	Coasting	Enable
3	No error	Trip
4 ⁽¹⁾	Not homed	Home done
5	Reserved	Reserved
6	No error	Trip lock
7	No warning	Warning
8 ⁽¹⁾	Not on target position	Target position reached
9	Local operation	Bus control
10	Out of frequency limit	Frequency limit OK
11	No operation	In operation

Table 92: Status Word - (continued)

Bit	0	1
12	Drive OK	Stopped, auto start
13	Voltage OK	Voltage exceeded
14	Torque OK	Torque exceeded
15	Timer OK	Timer exceeded

1) Different from [0] FC Profile. Options for bits 5 and 12–15 in parameter 8-13 Configurable Status Word STW:

- [4] Position Error
- [5] Position Limit
- [6] Touch on Target
- [7] Touch Activated

8 Troubleshooting

8.1 Status Messages

8.1.1 Warnings and Alarms

A warning or an alarm is signaled by the relevant indicator light on the front of the drive and indicated by a code on the display.

A warning remains active until its cause is no longer present. Under certain circumstances, operation of the motor may still be continued. Warning messages may be critical, but are not necessarily so.

In the event of an alarm, the drive trips. Reset the alarm to resume operation once the cause has been rectified.

3 ways to reset:

- Press [Reset].
- Via a digital input with the reset function.
- Via serial communication/optional fieldbus.



NOTE: After a manual reset pressing [Reset], press [Auto On] to restart the motor.

If an alarm cannot be reset, the reason may be that its cause has not been rectified, or the alarm is trip locked.

Alarms that are trip locked offer extra protection, meaning that the mains supply must be switched off before the alarm can be reset. After being switched back on, the drive is no longer blocked and can be reset once the cause has been rectified.

Alarms that are not trip locked can also be reset using the automatic reset function in parameter **14-20 Reset Mode** (Warning: Automatic wake up is possible.)

If a warning or alarm is marked against a code in the alarm/warning code list, this means that either a warning occurs before an alarm, or it is possible to specify whether a warning or an alarm should be shown for a given fault.

This is possible, for instance, in parameter **1-90 Motor Thermal Protection**. After an alarm or trip, the motor carries on coasting, and the alarm and warning flash. Once the problem has been rectified, only the alarm continues flashing until the drive is reset.



NOTE: No missing motor phase detection (numbers 30-32) and no stall detection are active when parameter **1-10 Motor Construction** is set to **[1] PM non-salient SPM**.

8.1.2 Warning/Alarm Code List



NOTE: If more selections are marked as default, it indicates that the warning changes to an alarm after a certain time.

- X = Default
- (X) = Possible selection
- – = Not relevant

Table 93: Alarm/Warning Code List

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
1	10V low	X	–	–	Parameter 14-90.0 Fault Level	Ignored	Ignored	Warning	–
2	Live zero error	(X)	(X)	–	Parameter 6-01 Live Zero Timeout Function , Parameter 6-02 Emergency Mode Live Zero Timeout Function	Ignored	Ignored	(Warning/ Trip)	–
3	No motor	(X)	–	–	Parameter 1-80 Function at Stop and parameter 4-58 Missing Motor Phase when set to [5] Motor check .	Ignored	Ignored	(Warning/ Trip)	–
4	Mains ph. loss	(X)	(X)	(X)	Parameter 14-12 Response to Mains Imbalance	Ignored	Ignored	(Warning/ Trip)	X
5	DC voltage high	X	–	–	–	Ignored	Ignored	Warning	–
6	DC voltage low	X	–	–	–	Ignored	Ignored	Warning	–
7	DC overvoltage	X	X	–	–	Trip+ Reset	Trip	Warning/ Trip	–
8	DC undervoltage	X	X	–	–	Trip+ Reset	Trip	Warning/ Trip	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
9	Inverter overld.	X	X	–	Alternatively, parameter 14-61 Function at Inverter Overload can be set to [0] De- rate	Ignored	Ignored	Warning/ Trip	X
		X	–	–	Alternatively, parameter 14-90 Fault Settings can be set to [0] Off				
10	Motor ETR over	(X)	(X)	–	Parameter 1-90 Motor Thermal Protection	Ignored	Ignored	(Warning/ Trip)	–
11	Motor th over	(X)	(X)	–	Parameter 1-90 Motor Thermal Protection	Ignored	Ignored	(Warning/ Trip)	–
12	Torque limit	X	X	–	Parameter 14-90.6 Fault level and parameter 14-25 Trip Delay at Torque Limit	Ignored	Ignored	Warning/ Trip	–
13	Overcurrent	X	X	X	–	Trip+Reset	Trip	Trip lock	–
14	Ground fault	–	X	X	Parameter 14-90.4 Fault Level	Trip+Reset	Trip	Trip	–
15	Incomp. HW	–	X	X	–	Ignored	Ignored	Trip/Trip lock	–
16	Short circuit	–	X	X	Parameter 14-90.8 Fault Level default is Trip Lock	Trip+Reset	Trip	Trip lock	–
17	Ctrl. word TO	(X)	(X)	–	Parameter 8-04 Control Word Timeout Function , default [0] Off	Ignored	Ignored	(Warning/ Trip)	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
20	Temp. input error	–	X	–	–	–	–	–	–
21	Param error	–	–	X	–	–	–	–	–
22	Hoist mech. brake	(X)	(X)	–	Parameter group 2-2* <i>Mechanical Brake</i>				
23	Internal fans	X	–	–	Parameter <i>14-53 Fan Monitor</i>	Ignored	Ignored	(Warning/ Trip)	–
24	External fans	X	–	–	Parameter <i>14-53 Fan Monitor</i>	Ignored	Ignored	(Warning/ Trip)	–
25	Brake resistor	X	–	–	–	Ignored	Ignored		–
26	Brake over- load	(X)	(X)	–	Parameter 2-13 <i>Brake Power Monitoring</i> , default [0] Off	Ignored	Ignored	(Warning/ Trip)	–
27	Brake IGBT	X	X	–	–	Ignored	Ignored	Warning/ Trip	–
28	Brake check	(X)	(X)	–	Parameter 2-15 <i>Brake Check</i>	Ignored	Ignored	(Warning/ Trip lock)	–
29	Power mod- ule temp	–	X	X	Parameter <i>14-90.9 Fault Level</i>	Ignored	Ignored	Trip lock	X
30	U phase loss	(X)	(X)	(X)	Alternatively, parameter 4-58 <i>Missing Motor Phase Function</i> can be set to [0] Disable.	Ignored	Ignored	Trip lock	–
		–	–	X	Parameter <i>14-90.16 Fault Level</i>				

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
31	V phase loss	(X)	(X)	(X)	Alternatively, parameter 4-58 <i>Missing Motor Phase Function</i> can be set to [0] Disable .	Ignored	Ignored	Trip lock	–
		–	–	X	Parameter 14-90.16 Fault Level				
32	W phase loss	(X)	(X)	(X)	Alternatively, parameter 4-58 <i>Missing Motor Phase Function</i> can be set to [0] Disable .	Ignored	Ignored	Trip lock	–
		–	–	X	Parameter 14-90.16 Fault Level				
33	Inrush fault	–	X	X	–	Ignored	Ignored	Trip lock	X
34	Fieldbus fault	X	–	–	Parameter 14-90.27 Fault Level	Ignored	Ignored	Warning/ Trip	–
35	Option fault	–	–	X	–	Ignored	Ignored	Warning	–
36	Mains failure	X	X	–	Parameter 14-10 Mains Failure , default [0] Off	Ignored	Ignored	(Warning/ Trip)	–
37	Phase imbal- ance	–	X	–					
38	Internal fault	–	X	X	–	Ignored	Ignored	Trip/Trip lock	X
39	Heat sink sen- sor	–	X	X	Parameter 14-90 Fault Settings	Ignored	Ignored	Trip lock	X
40	Overload T27	(X)	–	–	Parameter 5-00 Digital I/O Mode , parameter 5-01 <i>Terminal 27 Mode</i>	Ignored	Ignored	(Warning)	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
41	Overload T29	(X)	–	–	Parameter <i>5-00 Digital I/O Mode</i> , parameter 5-02 <i>Terminal 29 Mode</i>	Ignored	Ignored	(Warning)	–
42	OvrlD X30/6-7	(X)	–	–	–	–	–	–	–
43	Ext. supply (option)	X	–	–	–	–	–	–	–
45	Ground fault 2	–	X ⁽¹⁾	X	Parameter <i>14-90.5 Fault Level</i>	Ignored	Ignored	Trip	–
46	Pwr. card sup- ply	–	X	X	–	Ignored	Ignored	Trip/Trip lock	–
47	24 V supply low	X	X	X	Parameter <i>14-90 Fault Set- tings</i>	Ignored	Ignored	Trip lock	–
48	1.2 V supply low	–	X	X	Parameter <i>14-90 Fault Settings</i>	Ignored	Ignored	Trip lock	–
49	Speed limit	–	X	–	Parameter <i>1-86 Trip Low Speed [RPM]</i>	Ignored	Ignored	Warning/ (Trip)	–
50	AMA calibra- tion	–	X	–	–	Ignored	Ignored	Trip	–
51	AMA U _{nom} , I _{nom}	–	X	–	–	Ignored	Ignored	Trip	–
52	AMA low I _{nom}	–	X	–	–	Ignored	Ignored	Trip	–
53	AMA big mo- tor	–	X	–	–	Ignored	Ignored	Trip	–
54	AMA small mot	–	X	–	–	Ignored	Ignored	Trip	–
55	AMA par. range	–	X	–	–	Ignored	Ignored	Trip	–
56	AMA interrupt	–	X	–	–	Ignored	Ignored	Trip	–
57	AMA timeout	–	X	–	–	Ignored	Ignored	Trip	–
58	AMA internal	X	X	–	–	Ignored	Ignored	Trip	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
59	Current limit	X	X	–	Parameter 14-90 Fault Settings	Ignored	Ignored	Warning	–
60	External inter- lock	X	X	–	–	Ignored	Ignored	Warning	–
61	Feedback er- ror	(X)	(X)	–	–	–	–	–	–
62	Output freq. lim.	X	X	–	–	Ignored	Ignored	Warning	–
63	Mech. brake low	–	(X)	–	–	–	–	–	–
64	Voltage limit	X	–	–	Parameter 14-90 Fault Settings	Ignored	Ignored	Warning	–
65	Ctrl. card temp	–	X	X	Parameter 14-90.11 Fault Level	Ignored	Ignored	Trip lock	X
66	Low temp.	X	–	–	–	Ignored	Ignored	Warning	–
67	Option change	–	X	–	–	Ignored	Ignored	Trip	–
68	Safe stop	(X)	(X) ⁽¹⁾	–	Parameter 5-19 Terminal 37 Safe Stop	Trip	Trip	Trip	–
69	Pwr. card temp	–	X	X	Parameter 14-90 Fault Settings	Ignored	Ignored	Trip lock	X
70	Illegal FC con- fig	–	–	X	–	Ignored	Ignored	Trip lock	–
71	PTC 1 safe stop	X	X ⁽¹⁾	–	–	Ignored	Ignored	Warning/ Trip	–
72	Dangerous failure	–	–	X ⁽¹⁾	–	Ignored	Ignored	Trip lock	–
73	Safe stop auto restart	(X)	(X)	–	Parameter 5-19 Terminal 37 Safe Stop	Ignored	Ignored	(Warning/ Trip)	–
74	PTC thermis- tor								

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
75	Illegal profile sel.								
76	Power unit setup	X	–	–	–	Ignored	Ignored	Warning	–
77	Reduced power mode	X	–	–	Parameter 14-59 <i>Actual Number of Inverter Units</i>	–	–	–	–
78	Tracking error	(X)	(X)	–	Parameter 4-34 <i>Tracking Error Function</i>				
79	Illegal PS config	–	X	X	–	Ignored	Ignored	Trip/Trip lock	–
80	Drive initialized	–	X	–	–	Ignored	Ignored	Trip	–
81	CSIV corrupt	–	X	–	–	–	–	–	–
82	CSIV parameter error	–	X	–	–	–	–	–	–
83	Illegal option combi.	–	–	X	–				
84	Safety opt. replaced								
85	Dang fail PB								
86	Dang fail DI								
88	Option detection	–	–	X	–				
89	Mechanical brake sliding	X	–	–	–				
90	Feedback mon.	(X)	(X)	–	Parameter 17-61 <i>Feedback Signal Monitoring</i>	–	–	–	–
91	AI54 set wrong	–	–	X	S202	Ignored	Ignored	Trip lock	–
98	Clock fault	(X)	(X)	(X)	–	Ignored	Ignored	Warning	–
99	Locked rotor	–	X	X	Parameter 14-90 <i>Fault Settings</i>	Ignored	Ignored	Trip/Trip lock	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
101	Speed moni- tor	X	X	–	–	Ignored	Ignored	–	
102	Too many CAN objects								
103	Illegal axis num.								
104	Mixing fans	X	X	–	Parameter <i>14-53 Fan Monitor</i>	Ignored	Ignored	(Warning/ Trip)	–
105	Error not reset				–				
106	HOME not done								
107	Home vel zero								
108	Position error								
109	Index not found								
110	Unknown cmd.								
111	SW end limit								
112	Unknown par.								
113	FC not en- abled								
114	Too many loops								
115	Par. save failed								
116	Par. memory								
117	Progr. mem- ory								
118	Reset by CPU								
119	User aborg								
121	No more SDO channels								
122	Mot. rotat. un- exp.	–	X	–	–				
123	Check motor model	–	X	–	–				

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
124	User alert	(X)	(X)	(X)	Parameter group 13-9* <i>User Defined Alerts</i>	Ignored	Ignored	(Warning/ Trip)	–
125	HW end limit								
128	Enc. inc/abs res.								
129	I2C comm. failure	X	–	–	–	–	–	–	–
144	Inrush supply	–	–	–	–	–	–	–	–
145	Ext. SCR dis- able	–	X	–	–	–	–	–	–
146	Mains voltage	X	X	–	–	–	–	–	–
147	Mains fre- quency	X	X	–	–	–	–	–	–
148	System temp	X	X	–	–	–	–	–	–
149	Too many in- ter.								
150	No ext. 24V								
151	GOSUB>limit								
152	Return @ limit								
154	D.out over- load								
155	LINK failed								
156	Illegal double arg.								
157	Power limit mot.	–	X	–	Parameter 4-80 <i>Power Limit Func. Motor Mode</i> , parameter 4-82 <i>Power Limit Motor Mode</i>				

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
158	Power limit gen.	–	X	–	Parameter 4-81 Power Limit Func. Generator Mode , parameter 4-83 Power Limit Generator Mode				
160	Internal Intr. error								
161	Feedback not ready	X	–	–	–	–	–	–	–
162	Memory error	–	–	–	–	–	–	–	–
163	ATEX ETR cur.lim.warnin g	X	–	–	–	–	–	–	–
164	ATEX ETR cur.lim.alarm	–	X	–	–	–	–	–	–
165	ATEX ETR freq.lim.warni ng	X	–	–	–	–	–	–	–
166	ATEX ETR freq.lim.alarm	–	X	–	–	–	–	–	–
170	Array size (DIM)								
171	Array too small								
175	Out of array mem.								
176	Wrong array size								
179	WAITNDX TO.								
180	API error								
181	OEM error								
182	WD error [No]								
184	ONTIME > limit								

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling.</i> Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
187	Out of mem- ory								
188	CAN guarding error								
189	CAN send-re- ceive error								
190	Memory locked								
191	Ill. cam array								
192	Encoder error								
193	Stack over- flow								
194	Out of dyn. mem								
195	Too many test indices								
196	Code too old								
198	Limit sw. vio- lation								
199	MCO app. er- ror								
200	Emergency mode	X	–	–	–	Ignored	Ignored	Warning	–
201	Emerg. m was active	X	–	–	–	Ignored	Ignored	Warning	–
202	Emerg. m lim- its exceeded	X	–	X	–	Ignored	Ignored	Warning	–
209	Standby en- coder failed								
210	Position track- ing	X	X	–	Parameter 4-70 Position Error Function , parameter 4-71 Maximum Position Error , parameter 4-72 Position Error Timeout				

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
211	Position limit	X	X	–	Parameter 3-06 Minimum Position , parameter 3-07 Maximum Position , parameter 4-73 Position Limit Function				
212	Homing not done	–	X	–	Parameter 17-80 Homing Function				
213	Homing time- out	–	X	–	Parameter 17-85 Homing Timeout				
214	No sensor in- put	–	X	–	–				
215	Start fwd/rev	X	X	–	Parameter 4-74 Start Fwd/Rev Function				
216	Touch time- out	–	X	–	Parameter 4-75 Touch Timeout				
217	Protection mode	X	–	–	Parameter 14-90 Fault Settings	Ignored	Ignored	Warning	–
218	Stall limit	X	–	–	–	Ignored	Ignored	Warning	–
220	Overload trip	X	–	–	–	–	–	–	–
221	Bypass inter- lock	–	X	–	–	–	–	–	–
222	M2 open failed	–	–	X	–	–	–	–	–
223	M2 close failed	–	–	X	–	–	–	–	–
224	M3 open failed	–	–	X	–	–	–	–	–
225	Overload X59/3-6	X	–	–	–	–	–	–	–
226	M3 close failed	–	–	X	–	–	–	–	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
227	Bypass com error				–	–	–	–	–
228	APU low volt- age	X	–	–	–	–	–	–	–
229	Motor dis- conn.	X	–	–	–	–	–	–	–
230	Read failed	–	X	–	–	–	–	–	–
231	Read com- plete	–	X	–	–	–	–	–	–
232	Reading...	–	X	–	–	–	–	–	–
239	SAS file in- valid	–	X	–	–	–	–	–	–
240	Write failed	–	X	–	–	–	–	–	–
241	Write com- plete	–	X	–	–	–	–	–	–
242	Writeing...	–	X	–	–	–	–	–	–
243	Brake IGBT	(X)	(X)	(X)	Parameter 2-13 <i>Brake Power Monitoring</i> , default [0] Off	Ignored	Ignored	Warning/ Trip	–
244	Heat sink temp	–	–	X	Parameter 14-90 <i>Fault Settings</i>	Ignored	Ignored	Trip lock	X
245	Heat sink sen- sor	–	–	X	Parameter 14-90 <i>Fault Settings</i>	Ignored	Ignored	Trip lock	X
246	Pwr. card sup- ply	–	–	X	–	Ignored	Ignored	Trip/Trip lock	–
247	Pwr. card temp	–	–	X	Parameter 14-90 <i>Fault Settings</i>	Ignored	Ignored	Trip lock	X
248	Illegal PS con- fig	–	–	X	–	Ignored	Ignored	Trip/Trip lock	–
249	Rect. low temp.	X	–	–	–	–	–	–	–
250	New spare part	–	–	X	–	Ignored	Ignored	Trip lock	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
251	New type code	–	X	X	–	Ignored	Ignored	Trip/Trip lock	–
252	Safe option failure	–	–	–	–	–	–	–	–
253	X49/9 over- load	–	–	–	–	–	–	–	–
254	X49/11 over- load	–	–	–	–	–	–	–	–
255	X49/7 over- load								
260	AMA com- plete	–	X	–	Parameter 1-29 <i>AMA</i> config- ured via field- bus and started via fieldbus control word.	Ignored	Ignored	–	–
273	BTM error	–	–	–	–	–	–	–	–
280	Emcy m ser- vice warning	X	–	–	–	–	–	–	–
281	Emcy OPR un- expected	X	–	–	–	–	–	–	–
290	Connection to one master is lost	X	–	–	–	–	–	–	–
300	Mains cont. fault	–	–	X	Parameter 14-90 <i>Fault Settings</i>	Ignored	Ignored	Trip lock	–
301	SC cont. fault	–	–	–	–	–	–	–	–
329	Torque threshold								
421	FPC temp	–	X	–	–	–	–	–	–
423	FPC updating	–	X	–	–	–	–	–	–
424	FPC update success	–	X	–	–	–	–	–	–
425	FPC update failure	–	–	X	–	–	–	–	–
426	FPC config	–	–	X	–	–	–	–	–
427	FPC supply	–	X	–	–	–	–	–	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
432	Inrush mode error	–	X	–	–	–	–	–	–
500 ^{(2), (3)}	Stator S2	(X)	(X)	–	Parame- ter 45-00.0 <i>Function</i>	Ignored	Ignored	Ignored	–
501	Load S2	(X)	(X)	–	Parame- ter 45-00.1 <i>Function</i>	Ignored	Ignored	Ignored	–
502	Sensor 1 S2	(X)	(X)	–	Parame- ter 45-00.2 <i>Function</i>	Ignored	Ignored	Ignored	–
503	Sensor 2 S2	(X)	(X)	–	Parame- ter 45-00.3 <i>Function</i>	Ignored	Ignored	Ignored	–
504	Sensor 3 S2	(X)	(X)	–	Parame- ter 45-00.4 <i>Function</i>	Ignored	Ignored	Ignored	–
505	Sensor 4 S2	(X)	(X)	–	Parame- ter 45-00.5 <i>Function</i>	Ignored	Ignored	Ignored	–
506	Load low S2	(X)	(X)	–	Parame- ter 45-00.1 <i>Function</i>	Ignored	Ignored	Ignored	–
507	Cavitation	(X)	–	–	Parame- ter 45-00.6 <i>Function</i>	Ignored	Ignored	Ignored	–
510	Stator	(X)	(X)	–	Parame- ter 45-00.0 <i>Function</i>	Ignored	Ignored	Ignored	–
511	Load	(X)	(X)	–	Parame- ter 45-00.1 <i>Function</i>	Ignored	Ignored	Ignored	–
512	Sensor 1	(X)	(X)	–	Parame- ter 45-00.2 <i>Function</i>	Ignored	Ignored	Ignored	–
513	Sensor 2	(X)	(X)	–	Parame- ter 45-00.3 <i>Function</i>	Ignored	Ignored	Ignored	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
514	Sensor 3	(X)	(X)	–	Parame- ter 45-00.4 <i>Function</i>	Ignored	Ignored	Ignored	–
515	Sensor 4	(X)	(X)	–	Parame- ter 45-00.5 <i>Function</i>	Ignored	Ignored	Ignored	–
516	Load low	(X)	(X)	–	Parame- ter 45-00.1 <i>Function</i>	Ignored	Ignored	Ignored	–
517	Cavitation	–	X	–	Parame- ter 45-00.6 <i>Function</i>	Ignored	Ignored	Ignored	–
520	Stator thld at max/min	(X)	–	–	–	–	–	–	–
521	Load thld at max/min	(X)	–	–	–	–	–	–	–
522	Sensor 1 thld at max/min	(X)	–	–	–	–	–	–	–
523	Sensor 2 thld at max/min	(X)	–	–	–	–	–	–	–
524	Sensor 3 thld at max/min	(X)	–	–	–	–	–	–	–
525	Sensor 4 thld at max/min	(X)	–	–	–	–	–	–	–
527	Cavitation thld at max/ min	(X)	–	–	Parame- ter 45-00.6 <i>Function</i>	–	–	–	–
531	SineWave- Filter S2	(X)	–	–	Parame- ter 49-00 <i>Autonomous Function</i>	Ignored	Ignored	Ignored	–
541	SineWave- Filter	–	(X)	–	Parame- ter 49-00 <i>Autonomous Function</i>	Ignored	Ignored	Ignored	–
549	SWF out- ofrange mea- surement	(X)	–	–	Parame- ter 49-00 <i>Autonomous Function</i>	–	–	–	–

Table 93: Alarm/Warning Code List - (continued)

#	Description	Warning	Alarm/ trip	Alarm/ trip lock	Parameter ref- erence	Emergency mode alarm han- dling selected in parameter 24-09 <i>Emergency Mode Alarm Handling</i> . Critical alarms cause a trip			Warranty- affecting alarms in emergency mode
						[0] Trip + Reset	[1] Trip	[2] Test	
550	Sensor 1 low	(X)	(X)	–	Parame- ter 45-00.2 <i>Function</i>	Ignored	Ignored	Ignored	–
551	Sensor 2 low	(X)	(X)	–	Parame- ter 45-00.3 <i>Function</i>	Ignored	Ignored	Ignored	–
552	Sensor 3 low	(X)	(X)	–	Parame- ter 45-00.4 <i>Function</i>	Ignored	Ignored	Ignored	–
553	Sensor 4 low	(X)	(X)	–	Parame- ter 45-00.5 <i>Function</i>	Ignored	Ignored	Ignored	–
600	Thread timing	–	–	–	–	–	–	–	–

1) Cannot be auto reset via parameter 14-20 *Reset Mode*.

2) All warnings and alarms from 500–525 require a CBM license.

3) All CBM warnings and alarms have warning and alarm/trip, where warning is default if the CBM license is installed and monitoring is enabled.

A trip is the action following an alarm. The trip coasts the motor and is reset by pressing [Reset] or by a digital input (parameter group 5-1* *Digital Inputs*). The original event that caused an alarm cannot damage the drive or cause dangerous conditions.

A trip lock is an action when an alarm occurs, which could damage the drive or connected parts. A trip lock situation can only be reset by cycling power.

8.1.3 Indicator Light

Table 94: Indicator Light

Warning	Yellow
Alarm	Flashing red
Trip locked	Yellow and red

8.1.4 Alarm Word, Warning Word, and Extended Status Word

Table 95: Description of Alarm Word

Bit	Hex	Dec	Alarm word	Alarm word 2	Alarm word 3
			Parameter 16-90 <i>Alarm Word</i>	Parameter 16-91 <i>Alarm Word 2</i>	Parameter 16-97 <i>Alarm Word 3</i>
0	00000001	1	Brake check (A28)	Servicetrip, read/ write	Temp. input error
1	00000002	2	Pwr.card temp (A69)	Servicetrip, (reserved)	Memory module fault
2	00000004	4	Ground fault (A14)	Servicetrip, typecode/ spare part	Internal fan error

Table 95: Description of Alarm Word - (continued)

Bit	Hex	Dec	Alarm word	Alarm word 2	Alarm word 3
			Parameter 16-90 Alarm Word	Parameter 16-91 Alarm Word 2	Parameter 16-97 Alarm Word 3
3	00000008	8	Ctrl.card temp (A65)	Servicetrip, (reserved)	Sync. fault
4	00000010	16	Ctrl. word TO (A17)	Servicetrip, (reserved)	OPM fault
5	00000020	32	Overcurrent (A13)	Reserved	–
6	00000040	64	Torque limit (A12)	Reserved	Profibus converter invalid
7	00000080	128	Motor th over (A11)	Reserved	–
8	00000100	256	Motor ETR over (A10)	Reserved	–
9	00000200	512	Inverter overld. (A9)	Discharge high	–
10	00000400	1024	DC undervolt (A8)	Start failed	–
11	00000800	2048	DC overvolt (A7)	Speed limit	–
12	00001000	4096	Short circuit (A16)	External interlock	–
13	00002000	8192	Inrush fault (A33)	Illegal option combi.	–
14	00004000	16384	Mains ph. loss (A4)	No safety option	–
15	00008000	32768	AMA not OK	Reserved	–
16	00010000	65536	Live zero error (A2)	Reserved	–
17	00020000	131072	Internal fault (A38)	KTY error	–
18	00040000	262144	Brake overload (A26)	Fans error	–
19	00080000	524288	U phase loss (A30)	ECB error	–
20	00100000	1048576	V phase loss (A31)	Hoist mechanical brake (A22)	–
21	00200000	2097152	W phase loss (A32)	Reserved	–
22	00400000	4194304	Fieldbus fault (A34)	Reserved	–
23	00800000	8388608	24 V supply low (A47)	Reserved	–
24	01000000	16777216	Mains failure (A36)	Reserved	–
25	02000000	33554432	1.8 V supply low (A48)	Current limit (A59)	Emergency mode
26	04000000	67108864	Brake resistor (A25)	Motor rotating unexpectedly (A122)	Sensor 4
27	08000000	134217728	Brake IGBT (A27)	Reserved	Sensor 3
28	10000000	268435456	Option change (A67)	Reserved	Sensor 2
29	20000000	536870912	Drive initialized (A80)	Encoder loss (A90)	Sensor 1
30	40000000	1073741824	Safe stop (A68)	PTC thermistor (A74)	Load
31	80000000	2147483648	Mech. brake low (A63)	Dangerous failure (A72)	Stator

Table 96: Description of Warning Word

Bit	Hex	Dec	Warning word	Warning word 2	Warning word 3
			Parameter 16-92 Warning Word	Parameter 16-93 Warning Word 2	Parameter 16-98 Warning Word 3
0	00000001	1	Brake check (W28)	Start delayed	Temp. input error
1	00000002	2	Pwr.card temp (A69)	Stop delayed	–
2	00000004	4	Earth fault (W14)	Reserved	Internal fan warning
3	00000008	8	Ctrl.card temp (W65)	Reserved	–
4	00000010	16	Ctrl. word TO (W17)	–	–
5	00000020	32	Overcurrent (W13)	Reserved	Test MOC function
6	00000040	64	Torque limit (W12)	Reserved	Profibus converter time warning
7	00000080	128	Motor th over (W11)	Reserved	EmcymodeActive
8	00000100	256	Motor ETR over (W10)	Reserved	EmcymodeHasBeenActive
9	00000200	512	Inverter Overld (W9)	Discharge high	EmcymodeLimits active
10	00000400	1024	DC under volt (W8)	Multi-motor underload	EmcymodeServiceRequest due to limits
11	00000800	2048	DC over volt (W7)	Multi-motor overload	EmcymodeNotRedyToOperate
12	00001000	4096	DC voltage low (W6)	Compressor interlock	CBM Reserved
13	00002000	8192	DC voltage high (W5)	Mechanical brake sliding	CBM Reserved
14	00004000	16384	Mains ph. loss (W4)	Safe option warning	CBM Reserved
15	00008000	32768	No motor (W3)	Auto DC braking	CBM Reserved
16	00010000	65536	Live zero error (W2)	–	CBM Reserved
17	00020000	131072	10 V low (W1)	KTY warn	CBM Reserved
18	00040000	262144	Brake overload (W26)	Fans warn	Load low S2
19	00080000	524288	Brake resistor (W25)	ECB warn	Load low
20	00100000	1048576	Brake IGBT (W27)	Hoist mechanical brake (W22)	Sensor 4 S2
21	00200000	2097152	Speed limit (W49)	Reserved	Sensor 4
22	00400000	4194304	Fieldbus fault (W34)	Reserved	Sensor 3 S2
23	00800000	8388608	24 V supply low (W47)	Reserved	Sensor 3
24	01000000	16777216	Mains failure (W36)	Reserved	Sensor 2 S2
25	02000000	33554432	Current limit (W59)	Power Limit Motor	Sensor 2
26	04000000	67108864	Low temp (W66)	Power Limit Generator	Sensor 1 S2
27	08000000	134217728	Voltage limit (W64)	Reserved	Sensor 1
28	10000000	268435456	Encoder loss (W90)	Reserved	Load S2
29	20000000	536870912	Output freq. lim. (W62)	BackEMF too high	Load

Table 96: Description of Warning Word - (continued)

Bit	Hex	Dec	Warning word	Warning word 2	Warning word 3
			Parameter 16-92 <i>Warning Word</i>	Parameter 16-93 <i>Warning Word 2</i>	Parameter 16-98 <i>Warning Word 3</i>
30	40000000	1073741824	Safe stop (W68)	PTC thermistor (W74)	Stator S2
31	80000000	2147483648	Extended status word	–	Stator

Table 97: Description of Extended Status Word

Bit	Hex	Dec	Ext. status word	Ext. status word 2	Ext. status word 3
			Parameter 16-94 Ext. Status Word	Parameter 16-95 Ext. Status Word 2	Parameter 16-99 Ext. Status Word 3
Extended Status Word					
0	00000001	1	Ramping	Off	High pressure stop
1	00000002	2	AMA running	Hand/auto	Low pressure stop
2	00000004	4	Start CW/CCW start_possible is active, when the DI selections [12] OR [13] are active and the requested direc- tion matches the refer- ence sign	PROFIBUS OFF1 active	Defrost
3	00000008	8	Slow down slow down command ac- tive, for example via CTW bit 11 or DI	PROFIBUS OFF2 active	Pre/post lube
4	00000010	16	Catch up catch up command ac- tive, for example via CTW bit 12 or DI	PROFIBUS OFF3 active	User-defined alerts
5	00000020	32	Feedback high feedback >parameter 4-57 Warning Feedback High	Relay 123 active	–
6	00000040	64	Feedback low feedback <para- meter 4-56 Warning Feedback Low	Start prevented	–
7	00000080	128	Output current high current >parameter 4-51 Warning Current High	Control ready	–
8	00000100	256	Output current low current <parameter 4-50 Warning Current Low	Drive ready	–

Table 97: Description of Extended Status Word - (continued)

Bit	Hex	Dec	Ext. status word	Ext. status word 2	Ext. status word 3
			Parameter 16-94 Ext. Status Word	Parameter 16-95 Ext. Status Word 2	Parameter 16-99 Ext. Status Word 3
9	00000200	512	Output freq high speed >parameter 4-53 Warning Speed High	Quick stop	–
10	00000400	1024	Output freq low speed <parameter 4-52 Warning Speed Low	DC brake	–
11	00000800	2048	Brake check OK Brake test NOT OK	Stop	–
12	00001000	4096	Braking max. BrakePower > parameter 2-12 Brake Power Limit [kW]	Standby	–
13	00002000	8192	Braking	Freeze output request	–
14	00004000	16384	Out of speed range	Freeze output	–
15	00008000	32768	OVC active	Jog request	–
16	00010000	65536	AC brake	Jog	–
17	00020000	131072	Password timelock number of allowed password trials exceeded - timelock active	Start request	–
18	00040000	262144	Password protection 0-61 = ALL_NO_ACCESS OR BUS_NO_ACCESS OR BUS_READONLY	Start	–
19	00080000	524288	Reference high reference >parameter 4-55 Warning Reference High	Start applied	–
20	00100000	1048576	Reference low Reference <parameter 4-54 Warning Reference Low	Start delay	–
21	00200000	2097152	Local reference Reference site = REMOTE -> auto on pressed & active	Sleep	–
22	00400000	4194304	Protection mode	Sleep boost	–
23	00800000	8388608	Unused	Running/pipe filling	–
24	01000000	16777216	Unused	Drive bypass	–

Table 97: Description of Extended Status Word - (continued)

Bit	Hex	Dec	Ext. status word	Ext. status word 2	Ext. status word 3
			Parameter 16-94 Ext. Status Word	Parameter 16-95 Ext. Status Word 2	Parameter 16-99 Ext. Status Word 3
25	02000000	33554432	Unused	Emergency mode	–
26	04000000	67108864	Unused	Extended interlock	–
27	08000000	134217728	Unused	Emergency m limit exceeded	–
28	10000000	268435456	Unused	FlyStart active	–
29	20000000	536870912	Unused	–	–
30	40000000	1073741824	Unused	–	–
31	80000000	2147483648	Protection mode	No function	–

The alarm words, warning words and extended status words can be read out via a serial bus or optional fieldbus for diagnostics. See also parameter **16-94 Ext. Status Word**.

8.2 Descriptions of Warnings and Alarms

Warning 1, 10 Volts Low

Cause

The control card voltage is less than 10 V from terminal 50. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Maximum 15 mA or minimum 590 Ω.

A short circuit in a connected potentiometer or incorrect wiring of the potentiometer can cause this condition.

Troubleshooting

- Remove the wiring from terminal 50.
- If the warning clears, the problem is with the wiring. If the warning does not clear, replace the control card.

WARNING/ALARM 2, Live Zero Error

Cause

This warning or alarm only appears if programmed in parameter **6-01 Live Zero Timeout Function**. The signal on 1 of the analog inputs is less than 50% of the minimum value programmed for that input. Broken wiring or faulty device sending the signal can cause this condition.

Troubleshooting

- Check connections on all the analog input terminals. Control card terminals 53 and 54 for signals, terminal 55 common.
- Check that the drive programming and switch settings match the analog signal type.
- Perform the input terminal signal test.

WARNING 3, No Motor

Cause

No motor is connected to the output of the drive.

Troubleshooting

- Check the cable connection between the drive and the motor.

WARNING/ALARM 4, Mains Phase Loss

Cause

A phase is missing on the supply side, or the mains voltage imbalance is too high. This message also appears for a fault in the input rectifier. Options are programmed in parameter **14-12 Response to Mains Imbalance**.

Troubleshooting

- Check the supply voltage and supply currents to the drive.

Warning 5, DC Link Voltage High

Cause

The DC-link voltage (DC) is higher than the high-voltage warning limit. The limit depends on the drive voltage rating. The unit is still active.

Warning 6, DC Link Voltage Low

Cause

The DC-link voltage (DC) is lower than the low-voltage warning limit. The limit depends on the drive voltage rating. The unit is still active.

WARNING/ALARM 7, DC Overvoltage

Cause

If the DC-link voltage exceeds the limit, the drive trips after a time.

Troubleshooting

- Extend the ramp time.
- Change the ramp type.

WARNING/ALARM 8, DC Under Voltage

Cause

If the DC-link voltage (DC-link) drops below the undervoltage limit, the drive trips after a fixed time delay. The time delay varies with unit size.

Troubleshooting

- Check that the supply voltage matches the drive voltage.
- Perform the input voltage test.
- Perform the soft charge circuit test.

WARNING/ALARM 9, Inverter Overload

Cause

The drive is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection issues a warning at 90% and trips at 100%, while giving an alarm. The drive cannot be reset until the counter is below 90%.

The fault occurs when the drive has run with more than 100% overload for too long.

Troubleshooting

- Compare the output current shown on the LCP with the drive rated current.
- Compare the output current shown on the LCP with the measured motor current.
- Show the thermal drive load on the LCP and monitor the value. When running above the drive continuous current rating, the counter increases. When running below the drive continuous current rating, the counter decreases.

WARNING/ALARM 10, Motor ETR Overtemperature

Cause

According to the electronic thermal protection (ETR), the motor is too hot. Select whether the drive issues a warning or an alarm when the counter reaches 100% in parameter **1-90 Motor Thermal Protection**. The fault occurs when the motor runs with more than 100% overload for too long.

Troubleshooting

- Check for motor overheating.
- Check if the motor is mechanically overloaded.
- Check that the motor current set in parameter **1-24 Motor Current** is correct.
- Ensure that the motor data in parameter **1-20** to parameter **1-25** is set correctly.
- Running AMA in parameter **1-29 Automatic Motor Adaptation (AMA)** tunes the drive to the motor more accurately and reduces thermal loading.

WARNING/ALARM 11, Motor Thermistor Overtemperature

Cause

Check whether the thermistor is disconnected. Select whether the drive issues a warning or an alarm in parameter **1-90 Motor Thermal Protection**.

Troubleshooting

- Check for motor overheating.
- Check if the motor is mechanically overloaded.
- When using terminal 53 or 54, check that the thermistor is connected correctly between either terminal 53 or 54 (analog voltage input) and terminal 50 (+10 V supply). Also check that the terminal switch for 53 or 54 is set for voltage. Check that parameter **1-93 Thermistor Resource** selects terminal 53 or 54.
- When using terminal 18, 19, 31, 32, or 33 (digital inputs), check that the thermistor is connected correctly between the digital input terminal used (digital input PNP only) and terminal 50. Select the terminal to use in parameter **1-93 Thermistor Resource**.

WARNING/ALARM 13, Overcurrent

Cause

The inverter peak current limit (approximately 200% of the rated current) is exceeded. The warning lasts about 1.5 s, then the drive trips and issues an alarm. Shock loading or quick acceleration with high-inertia loads can cause this fault. If the acceleration during ramp-up is quick, the fault can also appear after kinetic backup. If extended mechanical brake control is selected, a trip can be reset externally.

Troubleshooting

- Remove power and check if the motor shaft can be turned.
- Check that the motor size matches the drive.
- Check that the motor data is correct in parameters **1-20** to **1-25**.

ALARM 14, Earth (Ground) Fault

Cause

There is current from the output phase to ground, either in the cable between the drive and the motor, or in the motor itself. The current sensors detect the ground fault by measuring current going out from the drive and current going into the drive from the motor. Ground fault is issued if the deviation of the 2 currents is too large. The current going out of the drive must be the same as the current going into the drive.

Troubleshooting

- Remove power to the drive and repair the ground fault.
- Check for ground faults in the motor by measuring the resistance to ground of the motor cables and the motor with a megohmmeter.
- Reset any potential individual offset in the 3 current sensors in the drive. Perform a manual initialization or perform a complete AMA. This method is most relevant after changing the power card.

Alarm 15, Hardware Mismatch

Cause

A fitted option is not operational with the present control card hardware or software.

Troubleshooting

- Record the values of the following parameters and contact Danfoss.
 - a. Parameter *15-40 FC Type*
 - b. Parameter *15-41 Power Section*
 - c. Parameter *15-42 Voltage*
 - d. Parameter *15-43 Software Version*
 - e. Parameter *15-45 Actual Typecode String*
 - f. Parameter *15-49 SW ID Control Card*
 - g. Parameter *15-50 SW ID Power Card*
 - h. Parameter *15-60 Option Mounted*
 - i. Parameter *15-61 Option SW Version* (for each option slot).

ALARM 16, Short Circuit

Cause

 WARNING	
	HAZARDOUS VOLTAGE Drives contain hazardous voltage when connected to the AC mains or connected on the DC terminals. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury. • Only qualified personnel must perform installation, start-up, and maintenance.

There is short-circuiting in the motor or motor wiring.

Troubleshooting

- Disconnect power before proceeding.
- Remove the power to the drive and repair the short circuit.

WARNING/ALARM 17, Control Word Timeout

Cause

There is no communication to the drive. The warning is only active when parameter **8-04 Control Word Timeout Function** is NOT set to **[0] Off**.

If parameter **8-04 Control Word Timeout Function** is set to **[5] Stop and Trip**, a warning appears. The drive then ramps down to stop and issues an alarm.

Troubleshooting

- Check the connections on the serial communication cable.
- Increase parameter **8-03 Control Word Timeout Time**.
- Check the operation of the communication equipment.
- Verify that the installation adheres to the EMC requirements.

WARNING/ALARM 20, Temp. Input Error

Cause

The temperature detected by VLT® Sensor Input Option MCB 114 exceeds the limit.

This warning/alarm is only active when **[5] Stop and trip** is selected in parameter **35-06 Temperature Sensor Alarm Function**.

Troubleshooting

- Check the settings of the following parameters:
 - a. Parameter group **35-1* Temp. Input X48/4**
 - b. Parameter group **35-2* Temp. Input X48/7**
 - c. Parameter group **35-3* Temp. Input X48/10**
- Check the feedback temperature from the following parameters:
 - a. Parameter **18-37 Temp. Input X48/4**
 - b. Parameter **18-38 Temp. Input X48/7**
 - c. Parameter **18-39 Temp. Input X48/10**

Warning/Alarm 21, Parameter Error

Cause

The parameter is out of range. The parameter number is shown in the display.

Troubleshooting

- Set the affected parameter to a valid value.

Warning/Alarm 22, Hoist Mechanical Brake

Cause

The value of this warning/alarm shows the type of warning/alarm.

- 0 = The torque reference was not reached before timeout (parameter **2-27 Torque Ramp Up Time**).
- 1 = Expected brake feedback was not received before timeout (parameter **2-23 Activate Brake Delay**, parameter **2-25 Brake Release Time**).

Warning 23, Internal Fan Fault

Cause

The fan warning function is a protective function that checks if the fan is running/mounted. The fan warning can be disabled in parameter **14-53 Fan Monitor** by selecting **[0] Disabled**.

For drives with DC fans, a feedback sensor is mounted in the fan. If the fan is commanded to run and there is no feedback from the sensor, this warning appears. For drives with AC fans, the voltage to the fan is monitored.

Troubleshooting

- Cycle for proper fan operation.
- Cycle power to the drive and check that the fan operates briefly at start-up.
- Check the sensors on the control card.

Warning 24, External Fan Fault

Cause

The fan warning function is a protective function that checks if the fan is running/mounted. The fan warning can be disabled in parameter **14-53 Fan Monitor** by selecting **[0] Disabled**.

For drives with DC fans, a feedback sensor is mounted in the fan. If the fan is commanded to run and there is no feedback from the sensor, this warning appears. For drives with AC fans, the voltage to the fan is monitored.

Troubleshooting

- Check for proper fan operation.
- Cycle power to the drive and check that the fan operates briefly at start-up.
- Check the sensors on the heat sink.

WARNING 25, Brake Resistor Short Circuit

Cause

The brake resistor is monitored during operation. If a short circuit occurs, the brake function is disabled, and the warning appears. The drive is still operational, but without the brake function.

Troubleshooting

- Remove the power to the drive and replace the brake resistor (refer to parameter **2-15 Brake Check**).

WARNING/ALARM 26, Brake Resistor Power Limit

Cause

The power transmitted to the brake resistor is calculated as an average value over the last 120 s of run time. The calculation is based on the DC-link voltage and the brake resistor value set in parameter **2-16 Brake Max. Current**. The warning is active when the dissipated braking power is higher than 90% of the brake resistor power. If **[2] Trip** is selected in parameter **2-13 Brake Power Monitoring**, the drive trips when the dissipated braking power reaches 100%.

Troubleshooting

- Decrease brake energy via lower speed or longer ramp time.

ALARM 27, Brake IGBT/Brake Chopper Short-circuited

Cause

The brake transistor is monitored during start-up. If a short circuit occurs, the brake function is disabled, and an alarm is issued. The drive is tripped.

Troubleshooting

- Remove the power to the drive and remove the brake resistor.

ALARM 28, Brake Check

Cause

The brake resistor is not connected or not working.

Troubleshooting

- Check if brake resistor is connected or it is too large for the drive.

ALARM 29, Heat Sink Temp

Cause

The maximum temperature of the heat sink is exceeded. The temperature fault is not reset until the temperature drops below a defined heat sink temperature. The trip and reset points are different, based on the drive power size.

Troubleshooting

Check for the following conditions:

- The ambient temperature is too high.
- The motor cables are too long.
- Incorrect airflow clearance above and below the drive.
- Blocked airflow around the drive.
- Damaged heat sink fan.
- Dirty heat sink.

ALARM 30, Motor Phase U Missing

Cause

WARNING



HAZARDOUS VOLTAGE

Drives contain hazardous voltage when connected to the AC mains or connected on the DC terminals. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.

Motor phase U between the drive and the motor is missing.

Troubleshooting

- Disconnect power from the drive and check motor phase U.

ALARM 31, Motor Phase V Missing

Cause

 WARNING	
	HAZARDOUS VOLTAGE Drives contain hazardous voltage when connected to the AC mains or connected on the DC terminals. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury. Only qualified personnel must perform installation, start-up, and maintenance.

Motor phase V between the drive and the motor is missing.

Troubleshooting

- Disconnect power from the drive and check motor phase V.

ALARM 32, Motor Phase W Missing

Cause

 WARNING	
	HAZARDOUS VOLTAGE Drives contain hazardous voltage when connected to the AC mains or connected on the DC terminals. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury. Only qualified personnel must perform installation, start-up, and maintenance.

Motor phase W between the drive and the motor is missing.

Troubleshooting

- Disconnect power from the drive and check motor phase W.

ALARM 33, Inrush Fault

Cause

Too many power-ups have occurred within a short time period.

Troubleshooting

- Let the unit cool to operating temperature.
- Check potential DC-link fault to ground.

WARNING/ALARM 34, Fieldbus Fault

Cause

The fieldbus on the communication option card is not working.

Troubleshooting

- Check the fieldbus communication option card.

ALARM 35, Option Fault

Cause

Fieldbus or option B detects internal faults.

Troubleshooting

- Contact the local supplier.

WARNING/ALARM 36, Mains Failure

Cause

This warning/alarm is only active if the supply voltage to the drive is lost and parameter **14-10 Mains Failure** is not set to **[0] No function**.

Troubleshooting

- Check the fuses to the drive and mains supply to the unit.

ALARM 37, Phase Imbalance

Cause

There is a current imbalance between the power units.

ALARM 38, Internal Fault

Cause

When an internal fault occurs, a code number is shown.

Table 98: Internal Fault List

Fault number	Cause	Solution
0	The serial port cannot be initialized.	Contact the Danfoss supplier or Danfoss service department.
256–258	The power EEPROM data is defective or too old.	Replace the power card.
512–519	Internal fault.	Contact the Danfoss supplier or Danfoss service department.
783	Parameter value outside of the minimum/maximum limits.	Adjust the parameter value to match the limits.
1024–1284	Internal fault.	Contact the Danfoss supplier or Danfoss service department.
1299	The option software in slot A is too old.	Upgrade the software in the drive to the latest version.
1300	The option software in slot B is too old.	Upgrade the software in the drive to the latest version.
1302	The option software in slot C1 is too old.	Upgrade the software in the drive to the latest version.
1315	The option software in slot A is not supported/allowed.	The software version of the option or the fieldbus variant is not compatible with the drive software.
1316	The option software in slot B is not supported/allowed.	The software version of the option or the fieldbus variant is not compatible with the drive software.
1318	The option software in slot C1 is not supported/allowed.	The software version of the option or the fieldbus variant is not compatible with the drive software.
1379–2819	Internal fault.	Contact the Danfoss supplier or Danfoss service department.
1792	Hardware reset of digital signal processor.	
1793	Motor-derived parameters not transferred correctly to the digital signal processor.	

Table 98: Internal Fault List - (continued)

Fault number	Cause	Solution
1794	Power data not transferred correctly at power-up to the digital signal processor.	
1795	The digital signal processor has received too many unknown SPI telegrams. The AC drive also uses this fault code if the MCO does not power up correctly.	Check for poor EMC protection and improper grounding.
1796	RAM copy error.	
2561		Replace the control card.
2820	LCP stack overflow.	
2821	Serial port overflow.	
2822	USB port overflow	
3072–5122	Parameter value is outside its limits.	Adjust the parameter value to match the limits.
5123	Option in slot A: Hardware incompatible with the control board hardware.	Change either the fieldbus hardware or the control board hardware.
5124	Option in slot B: Hardware incompatible with the control board hardware.	Change either the fieldbus hardware or the control board hardware.
5125	Option in slot C0: Hardware incompatible with the control board hardware.	Change either the fieldbus hardware or the control board hardware.
5126	Option in slot C1: Hardware incompatible with the control board hardware.	Change either the fieldbus hardware or the control board hardware.
5376–6231	Internal fault.	Contact the Danfoss supplier or Danfoss service department.

Troubleshooting

- See the above table for the causes and solutions for different internal faults. If the fault persists, contact the Danfoss supplier or service department for assistance.

ALARM 39, Heat Sink Sensor

Cause

There is no feedback from the heat sink temperature sensor. The signal from the IGBT thermal sensor is not available on the power card.

Troubleshooting

- Check the ribbon cable between the power card and the gate drive card.
- Check for a defective power card.
- Check for a defective gate drive card.

WARNING 40, Overload T27

Troubleshooting

- Check the load connected to terminal 27 or remove the short-circuit connection.
- Check parameter **5-00 Digital I/O Mode** and parameter **5-01 Terminal 27 Mode**.

WARNING 41, Overload T29

Troubleshooting

- Check the load connected to terminal 29 or remove the short-circuit connection.
- Check parameter **5-00 Digital I/O Mode** and parameter **5-02 Terminal 29 Mode**.

WARNING 42, Ovrlid X30/6-7

Troubleshooting, X30/6

- Check the load connected to the terminal or remove the short-circuit connection.
- Check parameter **5-32 Term X30/6 Digi Out (MCB 101)** (VLT® General Purpose I/O MCB 101).

Troubleshooting, X30/7

- Check the load connected to the terminal or remove the short-circuit connection.
- Check parameter **5-33 Term X30/7 Digi Out (MCB 101)** (VLT® General Purpose I/O MCB 101).

WARNING 43, Ext. Supply

Cause

VLT® Extended Relay Option MCB 113 is mounted without 24 V DC. Select 1 of the options in the troubleshooting list.

Troubleshooting

- Connect a 24 V DC external supply.
- Specify that no external supply is used via parameter **14-80 Option Supplied by External 24VDC** set to **[0] No**. A change in parameter **14-80 Option Supplied by External 24VDC** requires a power cycle.

ALARM 45, Earth (Ground) Fault 2

Cause

A ground fault has occurred.

Troubleshooting

- Check for proper grounding and loose connections.
- Check for proper wire size.
- Check the motor cables for short circuits or leakage currents.

ALARM 46, Gate Drive Voltage Fault

Cause

The supply for the gate drive on the power card is out of range. It is generated by the switch mode supply (SMPS) on the power card.

Troubleshooting

- Check for a defective power card.

WARNING/ALARM 47, 24 V Supply Low

Cause

The 24 V DC is measured on the control card.

Troubleshooting

- Check for a defective control card.

ALARM 48, 1.8 V Supply Low

Cause

The 1.8 V DC supply used on the control card is outside of the allowed limits. The supply is measured on the control card.

Troubleshooting

- Check for a defective control card.
- If an option is installed, check for overvoltage.

WARNING 49, Speed Limit

Cause

The warning is shown when the speed is outside of the specified range in parameter **4-12 Motor Speed Low Limit [Hz]** and parameter **4-14 Motor Speed High Limit [Hz]**.

Troubleshooting

- Check if the system ran outside of the speed range.
- Check if parameter **4-12 Motor Speed Low Limit [Hz]** and parameter **4-14 Motor Speed High Limit [Hz]** are set correctly.

ALARM 50, AMA Calibration

Cause

A calibration error has occurred.

Troubleshooting

- Contact a Danfoss supplier or the Danfoss service department.

ALARM 51, AMA check U_{nom} and I_{nom}

Cause

The settings for motor voltage, motor current, and motor power are wrong.

Troubleshooting

- Check the settings in parameter **1-20** to parameter **1-25**.

ALARM 52, AMA Low I_{nom}

Cause

The motor current is too low.

Troubleshooting

- Check the setting in parameter **1-24 Motor Current**.

ALARM 53, AMA Big Motor

Cause

The power size of the motor is too large for the AMA to operate.

Troubleshooting

- Check the settings in parameter group **1-2* Motor Data**.

ALARM 54, AMA Small Motor

Cause

The power size of the motor is too small for the AMA to operate.

Troubleshooting

- Check the settings in parameter group **1-2* Motor Data**.

ALARM 55, AMA Parameter Range

Cause

The parameter values of the motor are outside of the acceptable range. The AMA does not run.

Troubleshooting

- Check the settings in parameter group **1-2* Motor Data**.

ALARM 56, AMA Interrupted

Cause

The AMA is manually interrupted.

Troubleshooting

- Re-run the AMA calibration.

ALARM 57, AMA Timeout

Cause

AMA timeout.

Troubleshooting

- Try to restart the AMA. Repeated restarts can overheat the motor.

ALARM 58, AMA Internal Fault

Cause

An AMA internal fault occurs.

Troubleshooting

- Contact a local Danfoss supplier.

WARNING/ALARM 59, Current Limit

Cause

The current is higher than the value in parameter **4-18 Current Limit**.

Troubleshooting

- Ensure that the motor data in parameter **1-20** to parameter **1-25** is set correctly.
- Possibly increase the current limit.

- Be sure that the system can operate safely at a higher limit.

ALARM 60, External Interlock

Cause

A digital input signal indicates a fault condition external to the drive. An external interlock has commanded the drive to trip.

Troubleshooting

- Clear the external fault condition.
- To resume normal operation, apply 24 V DC to the terminal programmed for external interlock.
- Reset the drive.

WARNING/ALARM 61, Feedback Error

Cause

An error between calculated speed and speed measurement from feedback device.

Troubleshooting

- Check the settings for warning/alarm/disabling in parameter **4-30 Motor Feedback Loss Function**.
- Set the tolerable error in parameter **4-31 Motor Feedback Speed Error**.
- Set the tolerable feedback loss time in parameter **4-32 Motor Feedback Loss Timeout**.

WARNING/ALARM 62, Output Frequency Limit

Cause for Flux Mode

If the output frequency reaches the value set in parameter **4-19 Max Output Frequency**, the drive issues a warning. The warning ceases when the output drops below the maximum limit. If the drive is unable to limit the frequency, it trips and issues an alarm. The latter may happen in the Flux mode if the drive loses control of the motor.

Troubleshooting for Flux Mode

- Check the application for possible causes. The load torque could be too significant to drag the motor run to a high speed.
- Increase the output frequency limit. Ensure that the system can operate safely at a higher output frequency.

Cause for VVC TCL Mode

The output speed limit is reached, and the torque reference is derated. If the system is designed to reduce the speed by speed limit function, the warning only means that the speed limit is active.

Troubleshooting for VVC TCL Mode

- The system speed exceeds the speed limit, in this case, adjust the system speed or adjust the speed limit.
- If the speed limit function is used to control system speed, the warning can be ignored.

ALARM 63, Mechanical Brake Low

Cause

The actual motor current has not exceeded the release brake current within the start delay time window.

WARNING 64, Voltage Limit

Cause

The load and speed combination demands a motor voltage higher than the actual DC-link voltage.

Troubleshooting

- Check if the mains input is not high enough.
- Check if the output frequency is too high above motor nominal frequency.

WARNING/ALARM 65, Control Card Over Temperature

Cause

The cutout temperature of the control card has exceeded the upper limit.

Troubleshooting

- Check that the ambient operating temperature is within the limits.
- Check the fan operation.
- Check the control card.

WARNING 66, Heat Sink Temperature Low

Cause

The drive is too cold to operate. This warning is based on the temperature sensor in the IGBT module.

Troubleshooting

- Increase the ambient temperature of the unit.
- Supply a trickle amount of current to the drive whenever the motor is stopped by setting parameter **2-00 DC Hold/Preheat Current** to 5% and parameter **1-80 Function at Stop**.

ALARM 67, Option Module Configuration Has Changed

Cause

One or more options have either been added or removed since the last power-down.

Troubleshooting

- Check that the configuration change is intentional and reset the unit.

ALARM 68, Safe Stop Activated

Cause

The Safe Torque Off (STO) has been activated.

Troubleshooting

- To resume normal operation, apply 24 V DC to terminal 37, then send a reset signal via bus, digital I/O, or by pressing *[Reset]*.

WARNING/ALARM 69, Power Card Temperature

Cause

The cutout temperature of the power card has exceeded the upper limit.

Troubleshooting

- Check that the ambient operating temperature is within limits.
- Check fan operation.
- Check the power card.

ALARM 70, Illegal FC Configuration

Cause

The control card and power card are incompatible.

Troubleshooting

- To check compatibility, contact the Danfoss supplier with the type code from the unit nameplate and the part numbers on the cards.

ALARM 71, PTC 1 Safe Stop

Cause

Because the motor is too warm, the VLT® PTC Thermistor Card MCB 112 activated Safe Torque Off (STO).

Troubleshooting

- Once the motor temperature reaches an acceptable level, and the digital input from MCB 112 is deactivated, perform 1 of the following:
 - Send a reset signal via bus or digital I/O.
 - Press [Reset].

ALARM 72, Dangerous Failure

Cause

Safe Torque Off (STO) with trip lock. An unexpected combination of STO commands has occurred.

Troubleshooting

- VLT® PTC Thermistor Card MCB 112 enables X44/10, but STO is not enabled.
- MCB 112 is the only device using STO (specified via **[4] PTC 1 alarm** or **[5] PTC 12 warning** in parameter **5-19 Terminal 37 Safe Stop**). STO is activated, but X44/10 is not.

WARNING 73, Safe Stop Auto Restart

Cause

STO is activated.

Troubleshooting

- With automatic restart enabled, the motor can start when the fault is cleared.

ALARM 74, PTC Thermistor

Cause

The PTC is not working. This alarm is related to VLT® PTC Thermistor Card MCB 112.

ALARM 75, Illegal Profile Sel.

Cause

There was an attempt to write the parameter value while the motor was running.

Troubleshooting

- Stop the motor before writing the MCO profile to parameter **8-10 Control Word Profile**.

WARNING 76, Power Unit Setup

Cause

The required number of power units does not match the detected number of active power units.

Troubleshooting

- When replacing a drive module, this warning can occur if the power-specific data in the module power card does not match the rest of the drive. Confirm that the spare part and its power card are the correct code number.

WARNING 77, Reduced Power Mode

Cause

The drive is operating in reduced power mode (less than allowed number of inverter sections). The warning is generated on power cycle when the drive is set to run with fewer inverters and remains on.

ALARM 78, Tracking Error

Cause

The difference between setpoint value and actual value exceeds the value in parameter **4-35 Tracking Error**.

Troubleshooting

- Disable the function or select an alarm/warning in parameter **4-35 Tracking Error Function**.
- Investigate the mechanics around the load and motor. Check feedback connections from motor encoder to drive.
- Select motor feedback function in parameter **4-30 Motor Feedback Loss Function**.
- Adjust the tracking error band in parameter **4-35 Tracking Error** and parameter **4-37 Tracking Error Ramping**.

ALARM 79, Illegal Power Section Configuration

Cause

The scaling card has an incorrect code number or is not installed. The MK102 connector on the power card could not be installed.

ALARM 80, Drive Initialized to Default Value

Cause

Parameter settings are initialized to default settings after a manual reset.

Troubleshooting

- To clear the alarm, reset the unit.

ALARM 81, CSIV Corrupt

Cause

The CSIV file has syntax errors.

ALARM 82, CSIV Parameter Error

Cause

CSIV failed to initialize a parameter.

ALARM 83, Illegal Option Combination

Cause

The mounted options are incompatible.

ALARM 84, No Safety Option

Cause

The safety option was removed without applying a general reset.

Troubleshooting

- Reconnect the safety option.

ALARM 88, Option Detection

Cause

A new option configuration has been detected.

Troubleshooting

- Set parameter **14-89 Option Detection** to **[1] Enable Option Change**, and power cycle the drive to accept the new configuration.

WARNING 89, Hoist Brake Sliding

Cause

This warning occurs when the motor speed feedback is bigger than 10 RPM during torque building time before the brake is open (parameter **2-27 Torque Ramp Up Time**).

Troubleshooting

- Check if the mechanical brake is broken or opened before start.
- Check that the feedback is not zero before opening the brake.

WARNING/ALARM 90, Feedback Monitor

Cause

A feedback fault is detected by option B.

Troubleshooting

- Contact the local supplier.

ALARM 91, Analog Input 54 Wrong Settings

Troubleshooting

- Set switch S202 in position OFF (voltage input) when a KTY sensor is connected to analog input terminal 54.

WARNING 98, Clock Fault

Cause

Time is not set or the RTC clock has failed.

Troubleshooting

- Reset the clock in parameter **0-70 Date and Time**.

ALARM 99, Locked Rotor

Cause

The rotor is blocked. It is only enabled for PM motor control.

Troubleshooting

- Check if the motor shaft is locked.
- Check if the start current triggers the current limit set in parameter **4-18 Current Limit**.
- Check if it increases the value in parameter **30-23 Locked Rotor Detection Time [s]**.

WARNING/ALARM 104, Mixing Fan Fault

Cause

The fan is not operating. The fan monitor checks that the fan is spinning at power-up or whenever the mixing fan is turned on. The mixing fan fault can be configured as a warning or an alarm in parameter **14-53 Fan Monitor**.

Troubleshooting

- Cycle power to the drive to determine if the warning/alarm returns.

WARNING/ALARM 122, Mot. Rotat. Unexp.

Cause

The drive performs a function that requires the motor to be at a standstill, for example, DC hold for PM motors.

WARNING 123, Motor Mod. Changed

Cause

The motor selected in parameter **1-11 Motor Model** is not correct.

Troubleshooting

- Check the motor model.

ALARM 144, Inrush Supply

Cause

A supply voltage on the inrush card is out of range.

Troubleshooting

- See the bit field result report value for more details.
 - a. Bit 2: Vcc high
 - b. Bit 3: Vcc low
 - c. Bit 4: Vdd high
 - d. Bit 5: Vdd low

ALARM 145, External SCR Disable

Cause

The alarm indicates a series DC-link capacitor voltage imbalance.

WARNING/ALARM 146, Mains Voltage

Cause

Mains voltage is outside valid operating range.

Troubleshooting

- See the following report values for details.
 - a. Voltage too low: 0=R-S, 1=S-T, 2=T-R
 - b. Voltage too high: 3=R-S, 4=S-T, 5=T-R

WARNING/ALARM 147, Mains Frequency

Cause

Mains frequency is outside valid operating range.

Troubleshooting

- The following report values provide more information:
 - a. 0: frequency too low
 - b. 1: frequency too high

WARNING/ALARM 148, System Temp

Cause

One or more of the system temperature measurements is too high.

WARNING/ALARM 154, D.out Overload

Cause

A digital output is overloaded.

WARNING/ALARM 157, Power Limit Mot.

Cause

The output power exceeds the value defined in parameter **4-82 Power Limit Motor Mode**.

WARNING 158, Power Limit Gen

Cause

The output power exceeds the value defined in parameter **4-83 Power Limit Generator Mode**.

Troubleshooting

- Check if parameter **4-83 Power Limit Generator Mode** is set too small to fit the application.
- Check if actual generic load is bigger than parameter **4-83 Power Limit Generator Mode**.

WARNING 163, ATEX ETR Cur.Lim.Warning

Cause

The drive has run above the characteristic curve for more than 50 s. The warning is activated at 83% and deactivated at 65% of the allowed thermal overload.

Alarm 164, ATEX ETR Cur.Lim.Alarm

Cause

Running above the characteristic curve for more than 60 s within a period of 600 s activated the alarm, and the drive trips.

WARNING 165, ATEX ETR Freq.Lim.Warning

Cause

The drive has run for more than 50 s below the allowed minimum frequency as set in parameter **1-98 ATEX ETR Interpol. Points.Freq.**).

ALARM 166, ATEX ETR Freq.Lim.Alarm

Cause

The drive has run for more than 60 s in a period of 600 s below the allowed minimum frequency as set in parameter **1-98 ATEX ETR Interpol. Points. Freq.**).

Warning 200, Emergency Mode

Cause

Emergency mode is active.

Troubleshooting

- The warning clears when emergency mode is removed.
- See the emergency mode data in the alarm log.

Warning 201, Emerg. M Was Active

Cause

Emergency mode is no longer active.

Troubleshooting

- Cycle power to the unit to remove the warning. See the emergency mode data in the alarm log.

Warning 202, Emerg. M Limits Exceeded

Cause

While operating in emergency mode, 1 or more alarm conditions have been ignored, which would normally trip the unit. Operating in this condition voids the warranty of the unit.

Troubleshooting

- Cycle power to the unit to remove this warning. See the emergency mode data in the alarm log. See parameter **18-10 Emergency Mode Log** for further details.

WARNING/ALARM 210, Position Tracking

Cause

The actual position error exceeds the value in parameter **4-71 Maximum Position Error**. Parameter **4-70 Position Error Function** defines whether this is a warning or an alarm.

WARNING/ALARM 211, Position Limit

Cause

The position is outside the limits defined in parameter **3-06 Minimum Position** and parameter **3-07 Maximum Position**. Parameter **4-73 Position Limit Function** defines the function for this warning/alarm.

WARNING/ALARM 212, Homing not Done

Cause

A homing function is selected in parameter **17-80 Homing Function** and absolute positioning is executed before homing is completed.

ALARM 213, Homing Timeout

Cause

Homing was started but did not finish within the time defined in parameter **17-85 Homing Timeout**.

ALARM 214, No Sensor Input

Cause

A homing process with a homing function that requires a sensor, or a touch probe positioning is started with no input defined for the sensor.

WARNING/ALARM 215, Start Fwd/Rev

Cause

One of the hardware end-limit options, **[12] Enable Start Forward** or **[13] Enable Start Reverse** is active.

WARNING/ALARM 216, Touch Timeout

Cause

A touch probe sensor is not found within the time set in parameter **4-75 Touch Timeout**. The timeout timer is started as soon as the touch probe positioning is activated even if the application is not moving.

Warning 217, Protection Mode

Either motor current or DC voltage has reached the hardware limit.

Troubleshooting

- Check that the drive matches the motor requirements.
- Check that the motor is not overloaded.
- Check the input power supply and motor configurations.

Warning 218, Stall Limit

During torque limit, current limit, or field weakening, the drive runs in stall protection and is not able to follow the reference.

Troubleshooting

- Check that the motor is not overloaded.
- Tune the stall protection adjustment factor.

WARNING 220, Configuration File Version not Supported

Cause

The drive does not support the current configuration file version. Customization is aborted.

ALARM 243, Brake IGBT

Cause

This alarm is only for multi-drive systems. It is equivalent to *Alarm 27, Brake chopper fault*. The report value in this alarm log indicates which drive module generated the alarm. This IGBT fault can be caused by any of the following:

- The DC fuse is blown.
- The brake jumper is not in position.
- The Klaxon switch opened due to an overtemperature condition in the brake resistor.

Indication of the drive module generating the alarm:

- 1 = Left drive module.
- 2 = Second drive module from left.
- 3 = Third drive module from left (in 4-module systems).
- 4 = Fourth drive module from left (in 4-module systems).

ALARM 244, Heat Sink Temperature

Cause

The maximum temperature of the heat sink has been exceeded. The temperature fault cannot reset until the temperature drops below the defined heat sink temperature. The trip and reset points are different, based on the power size. This alarm is equivalent to *Alarm 29, Power module temp.*

Troubleshooting

- Check for the following:
 - a. Ambient temperature too high.
 - b. Motor cables too long.
 - c. Incorrect airflow clearance above or below the AC drive.
 - d. Blocked airflow around the unit.
 - e. Damaged heat sink fan.
 - f. Dirty heat sink.

ALARM 245, Heat Sink Sensor

Cause

There is no feedback from the heat sink temperature sensor. This signal from the IGBT thermal sensor is not available on the power card. This alarm is equivalent to *Alarm 39, Heat sink sensor*.

The report value in the alarm log indicates which drive module generated the alarm:

- 1 = Left drive module.
- 2 = Second drive module from the left.
- 3 = Third drive module from the left (in 4-module systems).
- 4 = Fourth drive module from the left (in 4-module systems).

Troubleshooting

- Check the power card.
- Check the gate drive card.
- Check the ribbon cable between the power card and the gate drive card.

ALARM 246, Power Card Supply

Cause

The supply on the power card is out of range. This alarm is only for multi-drive systems. It is equivalent to *Alarm 46, Power card supply*.

The report value in the alarm log indicates which drive module generated the alarm:

- 1 = Left drive module.
- 2 = Second drive module from left.
- 3 = Third drive module from left (in 4-module systems).
- 4 = Fourth drive module from left (in 4-module systems).

ALARM 247, Power Card Temperature

Cause

This alarm is only for multi-drive systems. It is equivalent to *Alarm 69, Power card temperature*.

The report value in the alarm log indicates which drive module generated the alarm:

- 1 = Left drive module.
- 2 = Second drive module from left.
- 3 = Third drive module from left (in 4-module systems).
- 4 = Fourth drive module from left (in 4-module systems).

ALARM 248, Illegal Power Section Configuration

Cause

This alarm is only for multi-drive systems. It is equivalent to *Alarm 79, Illegal power section configuration*.

The report value in the alarm log indicates which drive module generated the alarm:

- 1 = Left drive module.
- 2 = Second drive module from left.
- 3 = Third drive module from left (in 4-module systems).
- 4 = Fourth drive module from left (in 4-module systems).

Troubleshooting

- Check the current scaling cards on the MDCIC.

WARNING 249, Rect. Low Temperature

Cause

The temperature of the rectifier heat sink is too low, which indicates that the temperature sensor may be detect.

WARNING 250, New Spare Part

Cause

A component in the drive system has been replaced.

Troubleshooting

- Enter the serial number and type code for canceling the trip lock status after a power cycle.

WARNING 251, New Typecode

Cause

The power card or other components have been replaced, and the type code has changed.

Troubleshooting

- Reset the drive for normal operation.

ALARM 421, FPC Temp

Cause

A fault caused by the on-board temperature sensor is detected on the fan power card. The report values identify which fan power card detected the fault.

Troubleshooting

- Check the wiring.
- Check the on-board temperature sensor.
- Replace the fan power card.

ALARM 423, FPC Updating

Cause

The alarm is generated when the fan power card reports that it has an invalid PUD. The control card attempts to update the PUD. A subsequent alarm can result depending on the update. See *Alarm 424, FPC Update Successful* and *Alarm 425, FPC Update Failure*.

ALARM 424, FPC Update Successful

Cause

This alarm is generated when the control card has updated the fan power card PUD successfully.

Troubleshooting

- Press *[Reset]* to stop the alarm.

ALARM 425, FPC Update Failure

Cause

This alarm is generated after the control card failed to update the fan power card PUD.

Troubleshooting

- Check the fan power card wiring.
- Replace the fan power card.
- Contact supplier.

ALARM 426, FPC Config

Cause

The number of found fan power cards does not match the number of configured fan power cards. See parameter group **15-6* Option Ident** for the number of configured fan power cards.

Troubleshooting

- Check fan power card wiring.
- Replace the fan power card.

ALARM 427, FPC Supply

Cause

Supply voltage faults (5 V, 24 V, or 48 V) on the fan power card is detected.

Troubleshooting

- Check fan power card wiring.
- Replace the fan power card.

ALARM 430, PWM Disabled

Cause

The PWM on the power card is disabled.

ALARM 432, Inrush Mode Error

Cause

An active inrush card reported the wrong mode. The report value indicates which inrush card reported the alarm.

Troubleshooting

- Check inrush card wiring.
- Replace the inrush card.

Warning 500, Motor Stator Winding Warning 2

Cause

The stator winding reached condition orange. A severe fault might occur soon in the motor.

Troubleshooting

- Check the stator windings.

Warning 501, Load Envelope Warning 2

Cause

Application load has reached condition yellow.

Troubleshooting

- Investigate the root cause for the increased motor load.

Warning 502, Vibration Monitoring Warning 2

Cause

A significant increase in motor vibration is detected. The vibration levels have reached condition orange.

Troubleshooting

- Investigate the root cause for severe vibration.

Warning 506, Load Envelope Low Warning 2

The application load has reached condition orange low limit.

Troubleshooting

- Investigate the root cause for the decrease in motor load and then check the load specified for the application

Warning 507, Cavitation Warning 2

Cause

There is a further increase of turbulence in the pump, indicating the possibility of cavitation. The cavitation has reached condition orange.

Troubleshooting

- Investigate the root cause of the increased turbulence.
- Check if the pump operates as specified in datasheets at the correct pressure-flow operation point.
- Check the hydraulic system for pressure drop at the pump inlet.
- Check for clogged pipes or filters.

ALARM 510, Motor Stator Winding Alarm

Cause

Stator winding has reached condition red. A severe fault is detected in the motor.

Troubleshooting

- Check motor stator winding.

WARNING 510, Motor Stator Winding Warning 1

Cause

Stator winding reached condition yellow. An early fault is detected in the motor.

Troubleshooting

- Check the motor stator winding.

ALARM 511, Load Envelope Alarm

Cause

Application load has reached condition red.

Troubleshooting

- Check root cause for excessive overload or underload.

WARNING 511, Load Envelope Warning 1

Cause

Application load has reached condition yellow.

Troubleshooting

- Check root cause for high motor load.

Alarm 512, Sensor 1 Monitoring Alarm

Cause

There is an excessive amount of motor vibration on sensor 1. The vibration levels have reached condition red.

Troubleshooting

- Investigate the root cause for the excessive vibration. Before commissioning of condition-based monitoring, ensure to comply with the ISO10816 standard for machinery.

Warning 512, Sensor 1 Monitoring Warning 1

Cause

An increase in the Sensor 1 value is detected. The value levels in Sensor 1 have reached condition yellow.

Troubleshooting

- Investigate the root cause for the increased values.

Alarm 513, Sensor 2 Monitoring Warning 1

Cause

There is an excessive amount of motor vibration on sensor 2. The vibration levels have reached condition red.

Troubleshooting

- Investigate the root cause for the excessive vibration. Before commissioning of condition-based monitoring, ensure to comply with the ISO10816 standard for machinery.

Warning 514, Sensor 3 Monitoring Warning 1

Cause

An increase in the Sensor 3 value is detected. The value levels in Sensor 3 have reached condition yellow.

Troubleshooting

- Investigate the root cause for the increased values.

Alarm 515, Sensor 4 Monitoring Alarm

Cause

There is an excessive amount of motor vibration on sensor 4. The vibration levels have reached condition red.

Troubleshooting

- Investigate the root cause for the excessive vibration. Before commissioning of condition-based monitoring, ensure to comply with the ISO10816 standard for machinery.

Warning 515, Sensor 4 Monitoring Warning 1

Cause

An increase in the Sensor 4 value is detected. The value levels in Sensor 4 have reached condition yellow.

Troubleshooting

- Investigate the root cause for the increased values.

Alarm 516, Load Envelope Low Alarm

The application load has reached low-level condition red.

Troubleshooting

- Investigate the root cause for the decrease in motor load and then check the load specified for the application.

Warning 516, Load Envelope Low Warning 1

The application load has reached low-level condition yellow.

Troubleshooting

- Investigate the root cause for the decrease in motor load and then check the load specified for the application.

Alarm 517, Cavitation Alarm

Cause

There is an excessive turbulence at the pump, indicating the possibility of cavitation. Cavitation has reached condition red.

Troubleshooting

- Investigate the root cause of the increased turbulence.
- Check if the pump operates as specified in datasheets at the correct pressure-flow operation point.
- Check the hydraulic system for pressure drop at the pump inlet.
- Check for clogged pipes or filters.

Warning 517, Cavitation Warning 1

Cause

There is an increased turbulence at the pump, indicating the possibility of cavitation. Cavitation has reached condition yellow.

Troubleshooting

- Investigate the root cause of the increased turbulence.
- Check if the pump operates as specified in datasheets, at the correct pressure-flow operation point.
- Check the hydraulic system for pressure drop at the pump inlet.
- Check for clogged pipes or filters.

Warning 520, Stator Thld At Max/Min

Cause

The stator in the condition-based monitoring is either at its minimum or maximum limit.

Troubleshooting

- Check the threshold values at maximum or minimum in parameter group **46-** CBM Adv Thresholds** to parameter group **46-2* Stator** and adjust the values if needed.
- Acknowledge the generation by setting parameter **45-46 Threshold Limit** to **[0] Limit OK**.

Warning 521, Load Thld At Max/Min

Cause

The load threshold in the condition-based monitoring is either at its minimum or maximum.

Troubleshooting

- Check the threshold values at maximum or minimum in parameter group **46-** CBM Adv Thresholds** to parameter group **46-3* Load** and adjust the values if needed.
- Acknowledge the generation by setting parameter **45-46 Threshold Limit** to **[0] Limit OK**.

Warning 522, Sensor 1 Thld At Max/Min

Cause

The sensor 1 threshold in the condition-based monitoring is at its minimum or maximum value of the Sensor 1 function.

Troubleshooting

- Check the threshold values at maximum or minimum in parameter group **46-** CBM Adv Thresholds** to parameter group **46-4* Sensor 1** and adjust the values if needed.
- Acknowledge the generation by setting parameter **45-46 Threshold Limit** to **[0] Limit OK**.

Warning 523, Sensor 2 Thld At Max/Min

Cause

The sensor 2 threshold in the condition-based monitoring is at its minimum or maximum value of the Sensor 2 function.

Troubleshooting

- Check the threshold values at maximum or minimum in parameter group **46-** CBM Adv Thresholds** to parameter group **46-5* Sensor 2** and adjust the values if needed.
- Acknowledge the generation by setting parameter **45-46 Threshold Limit** to **[0] Limit OK**.

Warning 524, Sensor 3 Thld At Max/Min

Cause

The sensor 3 threshold in the condition-based monitoring is at its minimum or maximum value of the Sensor 3 function.

Troubleshooting

- Check the threshold values at maximum or minimum in parameter group **46-** CBM Adv Thresholds** to parameter group **46-6* Sensor 3** and adjust the values if needed.
- Acknowledge the generation by setting parameter **45-46 Threshold Limit** to **[0] Limit OK**.

Warning 525, Sensor 4 Thld At Max/Min

Cause

The sensor 4 threshold in the condition-based monitoring is at its minimum or maximum value of the Sensor 4 function.

Troubleshooting

- Check the threshold values at maximum or minimum in parameter group **46-** CBM Adv Thresholds** to parameter group **46-7* Sensor 4** and adjust the values if needed.
- Acknowledge the generation by setting parameter **45-46 Threshold Limit** to **[0] Limit OK**.

Warning 527, Cavitation Thld At Max/Min

Cause

The cavitation threshold in the condition-based monitoring is at its minimum or maximum value of the cavitation function.

Troubleshooting

- Check the threshold values at maximum or minimum in parameter group **46-** CBM Adv Thresholds** to parameter group **46-8* Cavitation** and adjust the values if needed.
- Acknowledge the generation by setting parameter **45-46 Threshold Limit** to **[0] Limit OK**.

Warning 531, Sine-wave Filter Warning 2

Cause

The sine-wave filter has reached condition orange. An increased degradation is detected on the capacitors in the output sine-wave filter. A severe fault may occur soon in the sine-wave filter.

Troubleshooting

- Investigate the root cause for the capacitor degradation, such as high ambient temperature or humidity.
- Check that the loading conditions and the drive switching frequency are within the specifications.
- Check for aging.

Alarm 541, Sine-wave Filter Alarm

Cause

The sine-wave filter has reached condition red. A severe degradation is detected on the capacitors in the output sine-wave filter. A severe fault is detected in the sine-wave filter.

Troubleshooting

- Investigate the root cause for the capacitor degradation, such as high ambient temperature or humidity.
- Check that the loading conditions and drive switching frequency are within the specifications.
- Check for aging.

Warning 541, Sine-wave Filter Warning 1

Cause

The sine-wave filter has reached condition yellow. An early degradation is detected on the capacitors in the sine-wave filter.

Troubleshooting

- Investigate the root cause for the capacitor degradation, such as high ambient temperature or humidity.
- Check that the loading conditions and drive switching frequency are within the specifications.
- Check for aging.

Alarm 550, Sensor 1 Low Monitoring Alarm

The value measured on Sensor 1 is very low and has reached condition red low.

Troubleshooting

- Investigate the root cause for the value reaching the red low level. For example, lost connection to analog inputs or no proper data communication on fieldbus sensors.

Warning 550, Sensor 1 Low Monitoring Warning 1

The value measured on Sensor 1 is very low and has reached condition yellow low.

Troubleshooting

- Investigate the root cause for the value reaching the red low level. For example, lost connection to analog inputs or no proper data communication on fieldbus sensors.

Alarm 551, Sensor 2 Low Monitoring Alarm

The value measured on Sensor 2 is very low and has reached condition red low.

Troubleshooting

- Investigate the root cause for the value reaching the red low level. For example, lost connection to analog inputs or no proper data communication on fieldbus sensors.

Warning 551, Sensor 2 Low Monitoring Warning 1

The value measured on Sensor 2 is very low and has reached condition yellow low.

Troubleshooting

- Investigate the root cause for the value reaching the red low level. For example, lost connection to analog inputs or no proper data communication on fieldbus sensors.

Alarm 552, Sensor 3 Low Monitoring Alarm

The value measured on Sensor 3 is very low and has reached condition red low.

Troubleshooting

- Investigate the root cause for the value reaching the red low level. For example, lost connection to analog inputs or no proper data communication on fieldbus sensors.

Warning 552, Sensor 3 Low Monitoring Warning 1

The value measured on Sensor 3 is very low and has reached condition yellow low.

Troubleshooting

- Investigate the root cause for the value reaching the red low level. For example, lost connection to analog inputs or no proper data communication on fieldbus sensors.

Alarm 553, Sensor 4 Low Monitoring Alarm

The value measured on Sensor 4 is very low and has reached condition red low.

Troubleshooting

- Investigate the root cause for the value reaching the red low level. For example, lost connection to analog inputs or no proper data communication on fieldbus sensors.

Warning 553, Sensor 4 Low Monitoring Warning 1

The value measured on Sensor 4 is very low and has reached condition yellow low.

Troubleshooting

- Investigate the root cause for the value reaching the red low level. For example, lost connection to analog inputs or no proper data communication on fieldbus sensors.



Danfoss Drives A/S
Ulsnaes
DK-6300 Graasten
danfoss.drives.com

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalog descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogs, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product. All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

M00131
AU275636650261en-003301
Danfoss Drives A/S © 2026.02

