

Installation Guide

ECL Comfort 310, application A333



1.0 Table of Contents

1.0 Table of Contents	1	5.0 Settings, circuit 1	74
1.1 Important safety and product information.....	2	5.1 Flow temperature.....	74
2.0 Installation	5	5.2 Return limit	76
2.1 Before you start	5	5.3 Flow / power limit	79
2.2 Identifying the system type.....	10	5.4 Optimization.....	82
2.3 Mounting	15	5.5 Control parameters 1.....	86
2.4 Placing the temperature sensors.....	18	5.6 Control parameters, refill pump(s).....	91
2.5 Electrical connections.....	20	5.7 Control parameters, circulation pump(s)	96
2.6 Inserting the ECL Application Key	50	5.8 Pump control	99
2.7 Check list	56	5.9 Refill water	102
2.8 Navigation, ECL Application Key A333	57	5.10 Refill tank.....	109
3.0 Daily use	62	5.11 Application	112
3.1 How to navigate	62	5.12 Water meter	116
3.2 Understanding the controller display	63	5.13 Flow meter	117
3.3 A general overview: What do the symbols mean?	65	5.14 S7, S8, S9, S10 pressure	120
3.4 Monitoring temperatures and system components	66	5.15 Alarm	123
3.5 Influence overview	67	6.0 Common controller settings.....	128
3.6 Manual control	68	6.1 Introduction to 'Common controller settings'	128
3.7 Schedule	69	6.2 Time & Date	129
4.0 Settings overview	70	6.3 Holiday	130
		6.4 Input overview	132
		6.5 Log	133
		6.6 Output override.....	134
		6.7 Key functions.....	135
		6.8 System	136
		7.0 Miscellaneous	140
		7.1 ECA 30 / 31 setup procedures	140
		7.2 Several controllers in the same system	148
		7.3 Frequently asked questions.....	151
		7.4 Definitions	153

Installation Guide ECL Comfort 310, application A333

1.1 Important safety and product information

1.1.1 Important safety and product information

This Installation Guide is associated with ECL Application Key A333 (order code no. 087H3818).

The functions are realized in ECL Comfort 310 for advanced solutions, e.g. M-bus, Modbus and Ethernet (Internet) communication.

The application A333 complies with ECL Comfort controllers 310 as of software version 1.11 (visible at start-up of the controller and in 'Common controller settings' in 'System').

The application A333 works with the Internal I/O module ECA 32 (order code no. 087H3202).

Additional documentation for ECL Comfort 310, modules and accessories is available on www.ecl.doc.danfoss.com.



Safety Note

To avoid injury of persons and damages to the device, it is absolutely necessary to read and observe these instructions carefully.

Necessary assembly, start-up, and maintenance work must be performed by qualified and authorized personnel only.

Local legislations must be respected. This comprises also cable dimensions and type of isolation (double isolated at 230 V).

A fuse for the ECL Comfort installation is max. 10 A typically.

The ambient temperature range for the ECL Comfort in operation is 0 - 55 °C. Exceeding this temperature range can result in malfunctions.

Installation must be avoided if there is a risk for condensation (dew).

The warning sign is used to emphasize special conditions that should be taken into consideration.




This symbol indicates that this particular piece of information should be read with special attention.



Automatic update of controller software:

The software of the controller is updated automatically when the key is inserted (as of controller version 1.11). The following animation will be shown when the software is being updated:



Progress bar

During update:

- Do not remove the KEY
If the key is removed before the hour-glass is shown, you have to start afresh.
- Do not disconnect the power
If the power is interrupted when the hour-glass is shown, the controller will not work.



As this Installation Guide covers several system types, special system settings will be marked with a system type. All system types are shown in the chapter: 'Identifying your system type'.



°C (degrees Celsius) is a measured temperature value whereas K (Kelvin) often is used for temperature differences.



The ID no. is unique for the selected parameter.

Example	First digit	Second digit	Last three digits
11174	1	1	174
	-	Circuit 1	Parameter no.
12174	1	2	174
	-	Circuit 2	Parameter no.

If an ID description is mentioned more than once, it means that there are special settings for one or more system types. It will be marked with the system type in question (e.g. 12174 - A266.9).



Parameters indicated with an ID no. like "1x607" mean a universal parameter.

Installation Guide ECL Comfort 310, application A333



Disposal Note

This product should be dismantled and its components sorted, if possible, in various groups before recycling or disposal.

Always follow the local disposal regulations.

Installation Guide ECL Comfort 310, application A333

2.0 Installation

2.1 Before you start

The A333 application key contains 3 subtypes: **A333.1**, **A333.2** and **A333.3** which are almost identical.

Different and extra functions are described additionally.

The application A333.1 is very flexible.

These are the basic principles:

Typically, the flow temperature is adjusted according to your requirements.

The flow temperature sensor S3 is the most important sensor. The desired flow temperature at S3 is calculated in the ECL controller, based on the outdoor temperature (S1) and the desired room temperature. The lower the outdoor temperature, the higher the desired flow temperature.

By means of a week schedule (up to 3 'Comfort' periods / day), the heating circuit can be in 'Comfort' or 'Saving' mode (two different temperature values for the desired room temperature).

In Saving mode the heating can be reduced or switched off totally.

The motorized control valve M1 is opened gradually when the flow temperature S3 is lower than the desired flow temperature and vice versa.

The return temperature (S5) can be limited, for example not to be too high. If so, the desired flow temperature at S3 can be adjusted (typically to a lower value), thus resulting in a gradual closing of the motorized control valve. Furthermore, the return temperature limitation can be dependent on the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted return temperature. In boiler-based heating supply the return temperature should not be too low (same adjustment procedure as above).


A connected flow or energy meter based on M-bus signal can limit the flow or energy to a set maximum value. Furthermore the limitation can be in relation to the outdoor temperature. Typically, the lower the outdoor temperature, the higher the accepted flow / power.

The circulation pumps P1 and P2 are operated alternately. One circulation pump is used as working pump and the other circulation pump is used as spare pump. The circulation pump in question is ON at heat demand or at frost protection. The alternation time can be set as a number of days and a set time on the shift day. A solution with a single circulation pump can also be selected.

By means of the pressure difference between S9 and S10 the ECL controller verifies that the circulation pump in question is operating.

The pressure difference on the secondary side is based on the static pressures at S9 and S10. The pressures are measured as 0 - 10 volt signals (from pressure transmitters) and converted (scaled) in the ECL controller to appropriate pressure values.

Application A333.1:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310 Electronic controller ECL Comfort 310

S1 Outdoor temperature sensor

S2 (Optional) Primary supply temperature sensor. For monitoring purpose

S3 Secondary flow temperature sensor

S4 (Optional) Secondary return temperature sensor. For monitoring purpose

S5 (Optional) Primary return temperature sensor

S7 (Optional) Primary supply pressure sensor. For monitoring purpose

S8 (Optional) Primary return pressure sensor. For monitoring purpose

S9 Secondary flow pressure sensor

S10 Secondary return pressure sensor

M1 Motorized control valve (3-point controlled)

P1/P2 Circulation pumps

P3/P4 Refill water pumps

V1 Refill water valve

V2 Pressure release valve

A1 Alarm

Installation Guide ECL Comfort 310, application A333

If an acceptable pressure difference is not detected, the ECL controller activates the alarm and shifts the operating command to the opposite circulation pump.

The heating can be switched OFF automatically when the outdoor temperature is higher than a selectable value.

The Frost protection mode maintains a selectable flow temperature, for example 10 °C.

In case of a too low pressure, measured by S10, the refill water function will supplement with water from a water source.

A refill pump is switched ON and the ON / OFF valve V1 opens.

The refill pumps P3 and P4 are operated alternately. One pump is used as working pump and the other pump is used as spare pump. The alternation time can be set as a number of days.


A solution with a single refill pump can also be selected.

In case of a too high pressure, measured by S10, the release valve V2 (ON / OFF) will open in order to reduce the pressure.

Installation Guide ECL Comfort 310, application A333

The application A333.2 is very flexible and works like A333.1, and with these additional features:

- * The circulation pumps P1 / P2 can, as an alternative to ON-OFF control, be speed controlled by means of a 0 - 10 volt signal. The desired pressure difference between S9 and S10 is set for the speed control procedure. A flow-meter F2 (pulse signal, analogue signal S13 or M-Bus) measures the circulation of water in the heating circuit.
- * The level in the refill water storage tank is measured by means of the pressure sensor S12. When a too low pressure is measured, the ON / OFF valve V3 opens. An acceptable pressure will close the V3 valve.
- * The refill water pumps P3 / P4 can, as an alternative to ON-OFF control, be speed controlled by means of a 0 - 10 volt signal. The desired pressure at S10 is set for the speed control procedure. A flow-meter F1 (pulse signal or M-Bus) measures the injected refill water.



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310 Electronic controller ECL Comfort 310

ECA 32 Built-in extension module

S1 Outdoor temperature sensor

S2 (Optional) Primary supply temperature sensor. For monitoring purpose

S3 Secondary flow temperature sensor

S4 (Optional) Secondary return temperature sensor. For monitoring purpose

S5 (Optional) Primary return temperature sensor

S7 (Optional) Primary supply pressure sensor. For monitoring purpose

S8 (Optional) Primary return pressure sensor. For monitoring purpose

S9 Secondary flow pressure sensor

S10 Secondary return pressure sensor

F1 (Optional) Flow meter (pulse or M-bus signal)

F2 (Optional) Flow meter (pulse, 0 - 10 volt or M-bus signal)

M1 Motorized control valve (3-point controlled)

M2 Speed control (0 - 10 volt) of P3 / P4

M3 Speed control (0 - 10 volt) of P1 / P2

P1/P2 Circulation pumps

P3/P4 Refill water pumps

V1 Refill water valve

V2 Pressure release valve

V3 Refill water tank valve


A1 Alarm

Installation Guide ECL Comfort 310, application A333

The application A333.3 is very flexible and works like A333.2, but with this feature:

- * The motorized control valve M1 is controlled by means of a 0 - 10 volt signal.

Application A333.2:



The shown diagram is a fundamental and simplified example and does not contain all components that are necessary in a system.

All named components are connected to the ECL Comfort controller.

List of components:

ECL 310 Electronic controller ECL Comfort 310

ECA 32 Built-in extension module

S1 Outdoor temperature sensor

S2 (Optional) Primary supply temperature sensor. For monitoring purpose

S3 Secondary flow temperature sensor

S4 (Optional) Secondary return temperature sensor. For monitoring purpose

S5 (Optional) Primary return temperature sensor

S7 (Optional) Primary supply pressure sensor. For monitoring purpose

S8 (Optional) Primary return pressure sensor. For monitoring purpose

S9 Secondary flow pressure sensor

S10 Secondary return pressure sensor

F1 (Optional) Flow meter (pulse or M-bus signal)

F2 (Optional) Flow meter (pulse, 0 - 10 volt or M-bus signal)

M1 Motorized control valve (0 - 10 volt controlled)

M2 Speed control (0 - 10 volt) of P3 / P4

M3 Speed control (0 - 10 volt) of P1 / P2

P1/P2 Circulation pumps

P3/P4 Refill water pumps

V1 Refill water valve

V2 Pressure release valve

V3 Refill water tank valve

A1 Alarm

Installation Guide ECL Comfort 310, application A333

Application A333 in general:

Up to two Remote Control Units, the ECA 30 can be connected to one ECL controller in order to control the ECL controller remotely.

Exercise of circulation pumps and control valve in periods without heating demand can be arranged.

Additional ECL Comfort controllers can be connected via the ECL 485 bus in order to utilize common outdoor temperature signal, time and date signals. The ECL Controllers in the ECL 485 system can work in master - slave system.

A connected flow or energy meter (based on M-bus signal) can limit the flow or energy to a set maximum and in relation to the outdoor temperature.

Unused input can, by means of an override switch, be used to override the schedule to a fixed 'Comfort' or 'Saving' mode.

Modbus communication to a SCADA system can be established. The M-bus data can furthermore be transferred to the Modbus communication.

Alarm A1 (= relay 6) can be activated:

- if the actual flow temperature differs from the desired flow temperature.
- if a temperature sensor or its connection disconnects / short circuits. (See: Common controller settings > System > Raw input overview).
- if the circulation pump(s) do(es) not generate acceptable pressure.
- if the refill water pump(s) do(es) not generate acceptable pressure.
- if measured pressures are not inside an acceptable pressure range.




The controller is pre-programmed with factory settings that are shown in the relevant chapters of this guide.

2.2 Identifying the system type

Sketch your application

The ECL Comfort controller series is designed for a wide range of heating, domestic hot-water (DHW) and cooling systems with different configurations and capacities. If your system differs from the diagrams shown here, you may want to make a sketch of the system about to be installed. This makes it easier to use the Installation Guide, which will guide you step-by-step from installation to final adjustments before the end-user takes over.

The ECL Comfort controller is a universal controller that can be used for various systems. Based on the shown standard systems, it is possible to configure additional systems. In this chapter you find the most frequently used systems. If your system is not quite as shown below, find the diagram which has the best resemblance with your system and make your own combinations.




The circulation pump(s) in heating circuit(s) can be placed in the flow as well as the return. Place the pump according to the manufacturer's specification.

Installation Guide ECL Comfort 310, application A333


A333.1, ex. a

Heating system with control of up to 2 circulation pumps and up to 2 refill water pumps



A333.1, ex. b


Basic heating system



Installation Guide ECL Comfort 310, application A333


A333.1, ex. c

Heating system with circulation pump feedback



A333.1, ex. d


Heating system with refill water system



Installation Guide ECL Comfort 310, application A333


A333.1, ex. e

Heating system with refill water and excess pressure system



A333.2, ex. a


Heating system with ON / OFF and speed control of up to 2 circulation pumps and up to 2 refill water pumps. Refill water storage control.



Installation Guide ECL Comfort 310, application A333

A333.3, ex. a

Heating system with ON / OFF and speed control of up to 2 circulation pumps and up to 2 refill water pumps. Refill water storage control. Control valve M1 is controlled by 0 - 10 volt signal.



Installation Guide ECL Comfort 310, application A333

2.3 Mounting

2.3.1 Mounting the ECL Comfort controller

For easy access, you should mount the ECL Comfort controller near the system. Select one of the following methods using the same base part (code no. 087H3230):

- Mounting on a wall
- Mounting on a DIN rail (35 mm)

The ECL Comfort 310 can only be mounted in the ECL Comfort 310 base part.

Screws, PG cable glands and rawlplugs are not supplied.

Locking the ECL Comfort controller

In order to fasten the ECL Comfort controller to its base part, secure the controller with the locking pin.



To prevent injuries to persons or the controller, the controller has to be securely locked into the base. For this purpose, press the locking pin into the base until a click is heard and the controller no longer can be removed from the base.



If the controller is not securely locked into the base part, there is a risk that the controller during operation can unlock from the base and the base with terminals (and also the 230 V a.c. connections) are exposed. To prevent injuries to persons, always make sure that the controller is securely locked into its base. If this is not the case, the controller should not be operated!




The easy way to lock the controller to its base or unlock it is to use a screw driver as lever.

Installation Guide ECL Comfort 310, application A333


Mounting on a wall

Mount the base part on a wall with a smooth surface. Establish the electrical connections and position the controller in the base part. Secure the controller with the locking pin.




Mounting on a DIN rail (35 mm)

Mount the base part on a DIN rail. Establish the electrical connections and position the controller in the base part. Secure the controller with the locking pin.



Dismounting the ECL Comfort controller

In order to remove the controller from the base part, pull out the locking pin by means of a screwdriver. The controller can now be removed from the base part.



The easy way to lock the controller to its base or unlock it is to use a screw driver as lever.



Before removing the ECL Comfort controller from the base part, ensure that the supply voltage is disconnected.

Installation Guide ECL Comfort 310, application A333

2.3.2 Mounting the Remote Control Units ECA 30 / 31


Select one of the following methods:

- Mounting on a wall, ECA 30 / 31
- Mounting in a panel, ECA 30

Screws and rawlplugs are not supplied.

Mounting on a wall


Mount the base part of the ECA 30 / 31 on a wall with a smooth surface. Establish the electrical connections. Place the ECA 30 / 31 in the base part.



Mounting in a panel

Mount the ECA 30 in a panel using the ECA 30 frame kit (order code no. 087H3236). Establish the electrical connections. Secure the frame with the clamp. Place the ECA 30 in the base part. The ECA 30 can be connected to an external room temperature sensor.

The ECA 31 must not be mounted in a panel if the humidity function is to be used.



Installation Guide ECL Comfort 310, application A333

2.4 Placing the temperature sensors

2.4.1 Placing the temperature sensors

It is important that the sensors are mounted in the correct position in your system.

The temperature sensor mentioned below are sensors used for the ECL Comfort 210 and 310 series which not all will be needed for your application!

Outdoor temperature sensor (ESMT)

The outdoor sensor should be mounted on that side of the building where it is less likely to be exposed to direct sunshine. It should not be placed close to doors, windows or air outlets.


Flow temperature sensor (ESMU, ESM-11 or ESMC)

Place the sensor max. 15 cm from the mixing point. In systems with heat exchanger, Danfoss recommends that the ESMU-type to be inserted into the exchanger flow outlet.

Make sure that the surface of the pipe is clean and even where the sensor is mounted.

Return temperature sensor (ESMU, ESM-11 or ESMC)


The return temperature sensor should always be placed so that it measures a representative return temperature.



Room temperature sensor

(ESM-10, ECA 30 / 31 Remote Control Unit)

Place the room sensor in the room where the temperature is to be controlled. Do not place it on outside walls or close to radiators, windows or doors.



Boiler temperature sensor (ESMU, ESM-11 or ESMC)

Place the sensor according to the boiler manufacturer's specification.

Air duct temperature sensor (ESMB-12 or ESMU types)

Place the sensor so that it measures a representative temperature.

DHW temperature sensor (ESMU or ESMB-12)

Place the DHW temperature sensor according to the manufacturer's specification.

Slab temperature sensor (ESMB-12)

Place the sensor in a protection tube in the slab.



ESM-11: Do not move the sensor after it has been fastened in order to avoid damage to the sensor element.



ESM-11, ESMC and ESMB-12: Use heat conducting paste for quick measurement of the temperature.




ESMU and ESMB-12: Using a sensor pocket to protect the sensor will, however, result in a slower temperature measurement.

Installation Guide ECL Comfort 310, application A333

Pt 1000 temperature sensor (IEC 751B, 1000 Ω / 0 $^{\circ}\text{C}$)

Relationship between temperature and ohmic value:




Installation Guide ECL Comfort 310, application A333

2.5 Electrical connections

2.5.1 Electrical connections 230 V a.c. in general

The common ground terminal is used for connection of relevant components (pumps, motorized control valves).




Installation Guide ECL Comfort 310, application A333

2.5.2 Electrical connections, 230 V a.c., power supply, pumps, motorized control valves etc.

Connections for A333.1 and A333.2, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.1 / A333.2



Terminal	Description	Max. load
19	Phase for ON / OFF valve / Alarm	
18 A1	Alarm	4 (2) A / 230 V a.c.*
17 V2	ON / OFF valve for pressure release	4 (2) A / 230 V a.c.*
16	Phase for refill water pump	
15 P4	Refill water pump	4 (2) A / 230 V a.c.*
14	Phase for circulation pumps / refill water pump	
13 P3	Refill water pump	4 (2) A / 230 V a.c.*
12 P2	Circulation pump	4 (2) A / 230 V a.c.*
11 P1	Circulation pump	4 (2) A / 230 V a.c.*
10	Supply voltage 230 V a.c. - neutral (N)	
9	Supply voltage 230 V a.c. - live (L)	
8	Phase for motorized control valve M1	
7 M1	Motorized control valve - opening	0.2 A / 230 V a.c.
6 M1	Motorized control valve - closing	0.2 A / 230 V a.c.
5	Phase for ON / OFF valve V1	
4 V1	ON / OFF valve for refill water	0.2 A / 230 V a.c.
3	Not to be used	
2	Not to be used	
1	Not to be used	

* Relay contacts: 4 A for ohmic load, 2 A for inductive load

Factory established jumpers:

5 to 8, 9 to 14, L to 5 and L to 9, N to 10



Wire cross section: 0.5 - 1.5 mm²
Incorrect connection can damage the electronic outputs.
Max. 2 x 1.5 mm² wires can be inserted into each screw terminal.


Installation Guide ECL Comfort 310, application A333

2.5.3 Electrical connections, 230 V a.c., power supply, pumps, motorized control valves etc.

Connections for A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.3



Terminal	Description	Max. load
19	Phase for ON / OFF valve / Alarm	
18 A1	Alarm	4 (2) A / 230 V a.c.*
17 V2	ON / OFF valve for pressure release	4 (2) A / 230 V a.c.*
16	Phase for refill water pump	
15 P4	Refill water pump	4 (2) A / 230 V a.c.*
14	Phase for circulation pumps / refill water pump	
13 P3	Refill water pump	4 (2) A / 230 V a.c.*
12 P2	Circulation pump	4 (2) A / 230 V a.c.*
11 P1	Circulation pump	4 (2) A / 230 V a.c.*
10	Supply voltage 230 V a.c. - neutral (N)	
9	Supply voltage 230 V a.c. - live (L)	
8	Not to be used	
7	Not to be used	
6	Not to be used	
5	Phase for ON / OFF valve V1	
4 V1	ON / OFF valve for refill water	0.2 A / 230 V a.c.
3	Not to be used	0.2 A / 230 V a.c.
2	Not to be used	0.2 A / 230 V a.c.
1	Not to be used	0.2 A / 230 V a.c.

* Relay contacts: 4 A for ohmic load, 2 A for inductive load

Factory established jumpers:

5 to 8, 9 to 14, L to 5 and L to 9, N to 10



Wire cross section: 0.5 - 1.5 mm²
Incorrect connection can damage the electronic outputs.
Max. 2 x 1.5 mm² wires can be inserted into each screw terminal.

Installation Guide ECL Comfort 310, application A333

2.5.4 Electrical connections, ECA 32

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Terminal		Description	Max. load
39	R10	Relay 10, not used	4 (2) A / 230 V a.c.*
40	R10		
41	R9	Relay 9, not used	4 (2) A / 230 V a.c.*
42	R9		
43	R8	Relay 8, not used	4 (2) A / 230 V a.c.*
44	R8		
45	R8		4 (2) A / 230 V a.c.*
46	R7	Relay 7	
47	R7	V3, ON / OFF valve for pressure release	
48	R7	Phase for ON / OFF valve V3	
49		Common terminal for input signals	
50	S11	Input: Position signal from M1, 0 - 10 volt	
51	S12	Input: Refill water level in storage tank, 0 - 10 volt	
52	S13	Input: F2 flow signal, 0 - 10 volt	
53		Not to be used	
54		Not to be used	
55		Not to be used	
56		Reference terminal for Analogue out 2 (M2) and 3 (M3)	
57	F1	Input: Flow-meter, pulse type	
58	F2	Input: Flow-meter, pulse type	
59	M1	Analogue out 1: 0 - 10 volt for control of motorized control valve M1 (A333.3)	2 mA **
60	M2	Analogue out 2: 0 - 10 volt for speed control of refill water pumps P3 and P4 (A333.2, A333.3)	2 mA **
61	M3	Analogue out 3: 0 - 10 volt for speed control of circulation pumps P1 and P2 (A333.2, A333.3)	2 mA **
62		Reference terminal for Analogue out 1 (M1)	
* Relay contacts: 4 A for ohmic load, 2 A for inductive load			
** Min. resistance: 5 KΩ			


Installation Guide ECL Comfort 310, application A333

2.5.5 Electrical connections, ON / OFF valve V3 controlled from relay output in ECA 32

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3




2.5.6 Electrical connections, 230 V a.c., power supply, motorized control valve M1 controlled by 0 - 10 volt from ECA 32

Connections for A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.3



The transformer for supplying the actuator must be a double-isolated version.


Installation Guide ECL Comfort 310, application A333

2.5.7 Electrical connections, 230 V a.c., power supply, control of 2 or 3 phase powered pumps

Connections for A333.1, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.1




2.5.8 Electrical connections, 230 V a.c., power supply, ON / OFF control and speed control of 1 phase powered pumps

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3




Installation Guide ECL Comfort 310, application A333

2.5.9 Electrical connections, 230 V a.c., power supply, 0 - 10 volt for speed control of 1 phase powered pumps

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3




2.5.10 Electrical connections, 230 V a.c., power supply, ON / OFF control and speed control of 2 or 3 phase powered pumps

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3




Installation Guide ECL Comfort 310, application A333

2.5.11 Electrical connections, 230 V a.c., power supply, ON / OFF control and speed control (via Frequency Converter) of 1 phase powered pumps

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3




FC = Frequency Converter

2.5.12 Electrical connections, 230 V a.c., power supply, ON / OFF control and speed control (via Frequency Converter) of 2 or 3 phase powered pumps

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3




FC = Frequency Converter

Installation Guide ECL Comfort 310, application A333

2.5.13 Electrical connections, example with external Start / Stop control of a Frequency Converter for circulation pumps P1 / P2


Application A333.2 / A333.3



FC = Frequency Converter

2.5.14 Electrical connections, example with external Start / Stop control of a Frequency Converter for refill water pumps P3 / P4

Application A333.2 / A333.3




FC = Frequency Converter

Installation Guide ECL Comfort 310, application A333

2.5.15 Electrical connections, safety thermostats, 230 V a.c. or 24 V a.c.


With safety thermostat, 1-step closing:

Motorized control valve without safety function




With safety thermostat, 1-step closing:

Motorized control valve with safety function



With safety thermostat, 2-step closing:

Motorized control valve with safety function



Installation Guide ECL Comfort 310, application A333



When ST is activated by a high temperature, the safety circuit in the motorized control valve closes the valve immediately.



When ST1 is activated by a high temperature (the TR temperature), the motorized control valve is closed gradually. At a higher temperature (the ST temperature), the safety circuit in the motorized control valve closes the valve immediately.



Wire cross section: 0.5 - 1.5 mm²
Incorrect connection can damage the electronic outputs.
Max. 2 x 1.5 mm² wires can be inserted into each screw terminal.


Installation Guide ECL Comfort 310, application A333

2.5.16 Electrical connections, 24 V a.c. (ECL 310 only), power supply, pumps, motorized valves etc.

Connections for A333.1 and A333.2, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.1 / A333.2



Terminal	Description	Max. load
19	Supply voltage (SP) for ON / OFF valve / Alarm	
18 A1	Alarm	4 (2) A / 24 V a.c.*
17 V2	ON / OFF valve for pressure release	4 (2) A / 24 V a.c.*
16	Supply voltage (SP) for refill water pump	
15 P4	Refill water pump	4 (2) A / 24 V a.c.*
14	Supply voltage (SP) for circulation pumps / refill water pump	
13 P3	Refill water pump	4 (2) A / 24 V a.c.*
12 P2	Circulation pump	4 (2) A / 24 V a.c.*
11 P1	Circulation pump	4 (2) A / 24 V a.c.*
10	Supply voltage 24 V a.c. - (SN)	
9	Supply voltage 24 V a.c. - (SP)	
8	Supply voltage (SP) for motorized control valve M1	
7 M1	Motorized control valve - opening	1 A / 24 V a.c.
6 M1	Motorized control valve - closing	1 A / 24 V a.c.
5	Supply voltage (SP) for ON / OFF valve V1	
4 V1	ON / OFF valve for refill water	1 A / 24 V a.c.
3	Not to be used	
2	Not to be used	
1	Not to be used	
* Relay contacts: 4 A for ohmic load, 2 A for inductive load		

Factory established jumpers:

5 to 8, 9 to 14, L to 5 and L to 9, N to 10

Installation Guide ECL Comfort 310, application A333



Wire cross section: 0.5 - 1.5 mm²
Incorrect connection can damage the electronic outputs.
Max. 2 x 1.5 mm² wires can be inserted into each screw terminal.



Do not connect 230 V a.c. powered components to a 24 V a.c. power supplied controller directly. Use auxiliary relays (K) to separate 230 V a.c. from 24 V a.c.


Installation Guide ECL Comfort 310, application A333

2.5.17 Electrical connections, 24 V a.c. (ECL 310 only), power supply, pumps, motorized valves etc.

Connections for A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.3



Terminal	Description	Max. load
19	Supply voltage (SP) for ON / OFF valve / Alarm	
18 A1	Alarm	4 (2) A / 24 V a.c.*
17 V2	ON / OFF valve for pressure release	4 (2) A / 24 V a.c.*
16	Supply voltage (SP) for refill water pump	
15 P4	Refill water pump	4 (2) A / 24 V a.c.*
14	Supply voltage (SP) for circulation pumps / refill water pump	
13 P3	Refill water pump	4 (2) A / 24 V a.c.*
12 P2	Circulation pump	4 (2) A / 24 V a.c.*
11 P1	Circulation pump	4 (2) A / 24 V a.c.*
10	Supply voltage 24 V a.c. - (SN)	
9	Supply voltage 24 V a.c. - (SP)	
8	Not to be used	
7	Not to be used	
6	Not to be used	
5	Supply voltage (SP) for ON / OFF valve V1	
4 V1	ON / OFF valve for refill water	1 A / 24 V a.c.
3	Not to be used	
2	Not to be used	
1	Not to be used	
* Relay contacts: 4 A for ohmic load, 2 A for inductive load		

Factory established jumpers:

5 to 8, 9 to 14, L to 5 and L to 9, N to 10

Installation Guide ECL Comfort 310, application A333



Wire cross section: 0.5 - 1.5 mm²
Incorrect connection can damage the electronic outputs.
Max. 2 x 1.5 mm² wires can be inserted into each screw terminal.



Do not connect 230 V a.c. powered components to a 24 V a.c. power supplied controller directly. Use auxiliary relays (K) to separate 230 V a.c. from 24 V a.c.

Installation Guide ECL Comfort 310, application A333

2.5.18 Electrical connections, ECA 32

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Terminal	Description	Max. load
39 R10	Relay 10, not used	4 (2) A / 24 V a.c.*
40 R10		
41 R9	Relay 9, not used	4 (2) A / 24 V a.c.*
42 R9		
43 R8	Relay 8, not used	4 (2) A / 24 V a.c.*
44 R8		
45 R8		
46 R7	Relay 7	4 (2) A / 24 V a.c.*
47 R7	V3, ON / OFF valve for pressure release	
48 R7	Phase for ON / OFF valve V3	
49	Common terminal for input signals	
50 S11	Input: Position signal from M1, 0 - 10 volt	
51 S12	Input: Refill water level in storage tank, 0 - 10 volt	
52 S13	Input: F2 flow signal, 0 - 10 volt	
53	Input: not used	
54	Input: not used	
55	Input: not used	
56	Reference terminal for Analogue out 2 (M2) and 3 (M3)	
57 F1	Input: Flow-meter, pulse type	
58 F2	Input: Flow-meter, pulse type	
59 M1	Analogue out 1: 0 - 10 volt for control of motorized control valve M1 (A333.3)	2 mA **
60 M2	Analogue out 2: 0 - 10 volt for speed control of refill water pumps P3 and P4 (A333.2, A333.3)	2 mA **
61 M3	Analogue out 3: 0 - 10 volt for speed control of circulation pumps P1 and P2 (A333.2, A333.3)	2 mA **
62	Reference terminal for Analogue out 1 (M1)	
* Relay contacts: 4 A for ohmic load, 2 A for inductive load		
** Min. resistance: 5 KΩ		


Installation Guide ECL Comfort 310, application A333

2.5.19 Electrical connections, 24 V a.c., power supply, ON / OFF valve V3 controlled from relay output in ECA 32

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3




2.5.20 Electrical connections, 24 V a.c., power supply, motorized control valve M1 controlled by 0 - 10 volt from ECA 32

Connections for A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.3



The transformer for supplying the actuator must be a double-isolated version.

The ECL Comfort 310 and the actuator for the control valve M1 must have separate transformers.


Installation Guide ECL Comfort 310, application A333

2.5.21 Electrical connections, 24 V a.c., power supply, control of 2 or 3 phase powered pumps

Connections for A333.1, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.1




2.5.22 Electrical connections, 24 V a.c., power supply, 0 - 10 volt for speed control of 1, 2 or 3 phase powered pumps

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3




Installation Guide ECL Comfort 310, application A333

2.5.23 Electrical connections, 24 V a.c., power supply, ON / OFF control and speed control (via Frequency Converter) of 1, 2 or 3 phase powered pumps

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Application A333.2 / A333.3



FC = Frequency Converter

Electrical connections for external Start / Stop control of a Frequency Converter:

See examples in "Electrical connections, 230 V a.c."

Installation Guide ECL Comfort 310, application A333

2.5.24 Electrical connections, Pt 1000 temperature sensors and signals


Connections for A333, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Terminal	Sensor / description	Type (recomm.)
29 and 30	S1 Outdoor temperature sensor*	ESMT
28 and 30	S2 Primary supply temperature sensor	ESM-11 / ESMB / ESMC / ESMU
27 and 30	S3 Secondary flow temperature sensor **	ESM-11 / ESMB / ESMC / ESMU
26 and 30	S4 Secondary return temperature sensor	ESM-11 / ESMB / ESMC / ESMU
25 and 30	S5 Primary return temperature sensor	ESM-11 / ESMB / ESMC / ESMU
24 and 30	Not used	
23 and 30	S7 Pressure signal (0 - 10 volt)	
22 and 30	S8 Pressure signal (0 - 10 volt)	
21 and 30	S9 Pressure signal (0 - 10 volt)	
20 and 30	S10 Pressure signal (0 - 10 volt)	

* If the outdoor temperature sensor is not connected or the cable is short-circuited, the controller assumes that the outdoor temperature is 0 (zero) °C.


** The sensor must always be connected in order to have the desired functionality. If the sensor is not connected or the cable is short-circuited, the motorized control valve closes (safety function).



Installation Guide ECL Comfort 310, application A333


2.5.25 Electrical connections, pressure transmitters, 0 - 10 volt types

S7, S8, S9, S10



2.5.26 Electrical connections, pressure transmitters, 4 - 20 mA types

S7, S8, S9, S10



4 - 20 mA through a resistor of 500 ohm gives a voltage of 2 - 10 volt.

Installation Guide ECL Comfort 310, application A333

2.5.27 Electrical connections, ECA 32

Connections for A333.2 and A333.3, in general:

See also the Mounting Guide (delivered with the application key) for application specific connections.

Terminal	Sensor / description	
50 and 49	S11	Position signal from M1, 0 - 10 volt
51 and 49	S12	Refill water level in storage tank, 0 - 10 volt
52 and 49	S13	F2 flow signal, 0 - 10 volt
53 and 49		Not used
54 and 49		Not used
55 and 49		Not used
56		Used for output signal
57 and 49	F1	Water meter (flow meter), pulse type
58 and 49	F2	Flow meter, pulse type

Water and flow meters, possibilities:


Water meter F1 (flow meter)	- pulse type - M-Bus
Flow meter F2 (flow meter)	- pulse type - 0 - 10 volt type - M-Bus

Installation Guide ECL Comfort 310, application A333

2.5.28 Electrical connections, ECA 32, flow meters, pulse types

A333.2 / A333.3


F1 and F2, pulse input



2.5.29 Electrical connections, ECA 32, flow meter, 0 - 10 volt type

A333.2 / A333.3

F2 to input S13 (0 - 10 volt input)




Installation Guide ECL Comfort 310, application A333

2.5.30 Electrical connections, ECA 32, pressure transmitter, 0 - 10 volt type

A333.2 / A333.3


S12, level in refill water storage tank



2.5.31 Electrical connections, ECA 32, pressure transmitter, 4 - 20 mA type

A333.2 / A333.3

S12, level in refill water storage tank




4 - 20 mA through a resistor of 500 ohm gives a voltage of 2 - 10 volt

2.5.32 Electrical connections, ECA 32, M1 valve position, 0 - 10 volt type

A333.2 / A333.3

S11, valve position indication



Installation Guide ECL Comfort 310, application A333

2.5.33 Electrical connections, ECA 30 / 31



Terminal ECL	Terminal ECA 30 / 31	Description	Type (recomm.)
30	4	Twisted pair	Cable 2 x twisted pair
31	1		
32	2		
33	3	Twisted pair	
	4	Ext. room temperature sensor*	ESM-10
	5		

* After an external room temperature sensor has been connected, ECA 30 / 31 must be repowered.

The communication to the ECA 30 / 31 must be set up in the ECL Comfort controller in 'ECA addr.'

The ECA 30 / 31 must be set up accordingly.

After application setup the ECA 30 / 31 is ready after 2–5 min. A progress bar in the ECA 30 / 31 is displayed.



If the actual application contains two heating circuits, it is possible to connect an ECA 30 / 31 to each circuit. The electrical connections are done in parallel.



Max. 2 ECA 30 / 31 can be connected to an ECL Comfort 310 controller or to ECL Comfort 310 controllers in a master-slave system.



Setup procedures for ECA 30 / 31: See section 'Miscellaneous'.



ECA information message:
 'Application req. newer ECA':
 The software of your ECA does not comply with the software of your ECL Comfort controller. Please contact your Danfoss sales office.



Some applications do not contain functions related to actual room temperature. The connected ECA 30 / 31 will only function as remote control.



Total cable length: Max. 200 m (all sensors incl. internal ECL 485 communication bus).
 Cable lengths of more than 200 m may cause noise sensibility (EMC).


Installation Guide ECL Comfort 310, application A333

2.5.34 Electrical connections, master / slave systems

The controller can be used as master or slave in master / slave systems via the internal ECL 485 communication bus (2 x twisted pair cable).

The ECL 485 communication bus is not compatible with the ECL bus in ECL Comfort 110, 200, 300 and 301!

Terminal	Description	Type (recomm.)
30	Common terminal	Cable 2 x twisted pair
31*	+12 V*, ECL 485 communication bus	
32	B, ECL 485 communication bus	
33	A, ECL 485 communication bus	
* Only for ECA 30 / 31 and master / slave communication		




Total cable length: Max. 200 m (all sensors incl. internal ECL 485 communication bus).
Cable lengths of more than 200 m may cause noise sensibility (EMC).


Installation Guide ECL Comfort 310, application A333

2.5.35 Electrical connections, communication


Electrical connections, Modbus



Electrical connections, M-bus



Example, M-bus connections



Installation Guide ECL Comfort 310, application A333

2.6 Inserting the ECL Application Key



2.6.1 Inserting the ECL Application Key

The ECL Application Key contains

- the application and its subtypes,
- currently available languages,
- factory settings: e.g. schedules, desired temperatures, limitation values etc. It is always possible to recover the factory settings,
- memory for user settings: special user / system settings.

After having powered-up the controller, different situations might be existing:

1. The controller is new from the factory, the ECL Application Key is not inserted.
2. The controller already runs an application. The ECL Application Key is inserted, but the application needs to be changed.
3. A copy of the controllers settings is needed for configuring another controller.




User settings are, among others, desired room temperature, desired DHW temperature, schedules, heat curve, limitation values etc.

System settings are, among others, communication set-up, display brightness etc.



Automatic update of controller software:

The software of the controller is updated automatically when the key is inserted (as of controller version 1.11). The following animation will be shown when the software is being updated:



Progress bar

During update:

- Do not remove the KEY
If the key is removed before the hour-glass is shown, you have to start afresh.
- Do not disconnect the power
If the power is interrupted when the hour-glass is shown, the controller will not work.



Key inserted / not inserted, description:

ECL Comfort 210 / 310, controller versions lower than 1.36:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; for 20 minutes settings can be changed.

ECL Comfort 210 / 310, controller versions 1.36 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

Installation Guide ECL Comfort 310, application A333

Application Key: Situation 1

The controller is new from the factory, the ECL Application Key is not inserted.

An animation for the ECL Application Key insertion is displayed. Insert the Application Key .

Application Key name and Version is indicated (example: A266 Ver. 1.03).

If the ECL Application Key is not suitable for the controller, a "cross" is displayed over the ECL Application Key-symbol.

Action:	Purpose:	Examples:
	Select language	
	Confirm	
	Select application	
	Confirm with 'Yes'	
	Set 'Time & Date'	
	Turn and push the dial to select and change 'Hours', 'Minutes', 'Date', 'Month' and 'Year'.	
	Choose "Next"	
	Confirm with 'Yes'	
	Go to 'Aut. daylight'	
	Choose whether 'Aut. daylight' * should be active or not	YES or NO

* 'Aut. daylight' is the automatic changeover between summer and winter time.

Depending on the contents of the ECL Application Key, procedure A or B is taking place:

A

The ECL Application key contains factory settings:

The controller reads / transfers data from the ECL Application Key to ECL controller.

The application is installed, and the controller resets and starts up.

B

The ECL Application key contains changed system settings:

Push the dial repeatedly.

'NO': Only factory settings from the ECL Application Key will be copied to the controller.

'YES*': Special system settings (differing from the factory settings) will be copied to the controller.

If the key contains user settings:


Push the dial repeatedly.

'NO': Only factory settings from the ECL Application Key will be copied to the controller.

'YES*': Special user settings (differing from the factory settings) will be copied to the controller.

* If 'YES' cannot be chosen, the ECL Application Key does not contain any special settings.

Choose 'Start copying' and confirm with 'Yes'.














Installation Guide ECL Comfort 310, application A333





Application Key: Situation 2

The controller already runs an application. The ECL Application Key is inserted, but the application needs to be changed.

To change to another application on the ECL Application Key, the current application in the controller must be erased (deleted).

Be aware that the Application Key must be inserted.

Action:	Purpose:	Examples:
	Choose 'MENU' in any circuit	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose 'Common controller settings'	
	Confirm	
	Choose 'Key functions'	
	Confirm	
	Choose 'Erase application'	
	Confirm with 'Yes'	



The controller resets and is ready to be configured.

Follow the procedure described in situation 1.

Installation Guide ECL Comfort 310, application A333

Application Key: Situation 3

A copy of the controllers settings is needed for configuring another controller.

This function is used

- for saving (backup) of special user and system settings
- when another ECL Comfort controller of the same type (210 or 310) must be configured with the same application but user / system settings differ from the factory settings.

How to copy to another ECL Comfort controller:




Action:	Purpose:	Examples:
	Choose 'MENU'	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose 'Common controller settings'	
	Confirm	
	Go to 'Key functions'	
	Confirm	
	Choose 'Copy'	
	Confirm	
	Choose 'To:'	*
	'ECL' or 'KEY' will be indicated. Choose 'ECL' or 'KEY'	'ECL' or 'KEY'
	Push the dial repeatedly to choose copy direction	
	Choose 'System settings' or 'User settings'	**
	Push the dial repeatedly to choose 'Yes' or 'No' in 'Copy'. Push to confirm.	'NO' or 'YES'
	Choose 'Start copying'	
	The Application Key or the controller is updated with special system or user settings.	

*

'ECL':	Data will be copied from the Application Key to the ECL Controller.
'KEY':	Data will be copied from the ECL Controller to the Application Key.

**

'NO':	The settings from the ECL controller will not be copied to the Application Key or to the ECL Comfort controller.
'YES':	Special settings (differing from the factory settings) will be copied to the Application Key or to the ECL Comfort controller. If YES can not be chosen, there are no special settings to be copied.



Installation Guide ECL Comfort 310, application A333

2.6.2 ECL Application Key, copying data

General principles

When the controller is connected and operating, you can check and adjust all or some of the basic settings. The new settings can be stored on the Key.

How to update the ECL Application Key after settings have been changed?

All new settings can be stored on the ECL Application Key.

How to store factory setting in the controller from the Application Key?

Please read the paragraph concerning Application Key, Situation 1: The controller is new from the factory, the ECL Application Key is not inserted.

How to store personal settings from the controller to the Key?

Please read the paragraph concerning Application Key, Situation 3: A copy of the controllers settings is needed for configuring another controller

As a main rule, the ECL Application Key should always remain in the controller. If the Key is removed, it is not possible to change settings.



Factory settings can always be restored.



Make a note of new settings in the 'Settings overview' table.



Do not remove the ECL Application Key while copying. The data on the ECL Application Key can be damaged!



It is possible to copy settings from one ECL Comfort controller to another controller provided that the two controllers are from the same series (210 or 310).



Key inserted / not inserted, description:

ECL Comfort 210 / 310, controller versions lower than 1.36:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; for 20 minutes settings can be changed.

ECL Comfort 210 / 310, controller versions 1.36 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

2.7 Check list



Is the ECL Comfort controller ready for use?

- ☐ Make sure that the correct power supply is connected to terminals 9 (Live) and 10 (Neutral).
- ☐ Check that the required controlled components (actuator, pump etc.) are connected to the correct terminals.
- ☐ Check that all sensors / signals are connected to the correct terminals (see 'Electrical connections').
- ☐ Mount the controller and switch on the power.
- ☐ Is the ECL Application Key inserted (see 'Inserting the Application Key').
- ☐ Does the ECL Comfort controller contain an existing application (see 'Inserting the Application Key').
- ☐ Is the correct language chosen (see 'Language' in 'Common controller settings').
- ☐ Is the time & date set correctly (see 'Time & Date' in 'Common controller settings').
- ☐ Is the right application chosen (see 'Identifying the system type').
- ☐ Check that all settings in the controller (see 'Settings overview') are set or that the factory settings comply with your requirements.
- ☐ Choose manual operation (see 'Manual control'). Check that valves open and close, and that required controlled components (pump etc.) start and stop when operated manually.
- ☐ Check that the temperatures / signals shown in the display match the actual connected components.
- ☐ Having completed the manual operation check, choose controller mode (scheduled, comfort, saving or frost protection).

Installation Guide ECL Comfort 310, application A333

2.8 Navigation, ECL Application Key A333

Parameter list, application A333, Heating

Home MENU	Sub-menu Heating	A333				
		ID nos.	Function	A333.1	A333.2	A333.3
Schedule			Schedule	●	●	●
Settings	Flow temperature		Heat curve	●	●	●
		11178	Temp. max.	●	●	●
		11179	Temp. min	●	●	●
	Return limit	11031	High T out X1	●	●	●
		11032	Low limit Y1	●	●	●
		11033	Low T out X2	●	●	●
		11034	High limit Y2	●	●	●
		11035	Infl. - max.	●	●	●
		11036	Infl. - min.	●	●	●
		11037	Adapt. time	●	●	●
		11085	Priority	●	●	●
		Flow/ power limit		Actual	●	●
			Actual limit	●	●	●
	11119		High T out X1	●	●	●
	11117		Low limit Y1	●	●	●
	11118		Low T out X2	●	●	●
	11116		High limit Y2	●	●	●
	11112		Adapt. time	●	●	●
	11113		Filter constant	●	●	●
	11109		Input type	●	●	●
	11115		Units	●	●	●
	Optimization	11011	Auto saving	●	●	●
		11012	Boost	●	●	●
		11013	Ramp	●	●	●
		11014	Optimizer	●	●	●
		11026	Pre stop	●	●	●
		11021	Total stop	●	●	●
		11179	Cut-out	●	●	●
	Control par. 1		Position		●	●
		15113	Filter constant		●	●
		15607	Low X		●	●
		15608	High X		●	●
		11174	Motor pr	●	●	●
		11184	Xp	●	●	●
		11185	Tn	●	●	●
		11186	M run	●	●	
		11187	Nz	●	●	●
		11189	Min. act. time	●	●	

Installation Guide ECL Comfort 310, application A333

Parameter list, application A333, Heating, continued

Home MENU	Sub-menu Heating	A333				
		ID nos.	Function	A333.1	A333.2	A333.3
Settings	Control par., P refill	11321	Pressure, des.		●	●
		13184	Xp		●	●
		13185	Tn		●	●
		13187	Nz		●	●
		13197	Td		●	●
		13165	V.out, max.		●	●
		13167	V.out, min.		●	●
		11331	Sleep level		●	●
		111332	Sleep mode time		●	●
		11330	Wake-up level		●	●
		11333	Boost		●	●
	Control par., P circ.	12322	Pressure, diff.		●	●
		12184	Xp		●	●
		12185	Tn		●	●
		12187	Nz		●	●
		12197	Td		●	●
		12165	V.out, max.		●	●
		12167	V.out, min.		●	●
	Pump control	11322	Pressure diff.	●	●	●
		11314	Chan.-over time	●	●	●
		11310	Retry time	●	●	●
		11313	Stab. time	●	●	●
		11311	Change, duration	●	●	●
		11312	Change time	●	●	●
		11022	P exercise	●	●	●
		11316	Alarm handling	●	●	●
	Refill water		Time left	●	●	●
		12311	Change duration	●	●	●
		11321	Pressure des.	●	●	●
		13322	Pressure diff.	●	●	●
		11318	Max. pressure	●	●	●
		11319	Max. press. diff.	●	●	●
		11323	Time-out	●	●	●
		11320	P exercise	●	●	●
		11325	Valve delay	●	●	●
		11326	No. of pumps	●	●	●
		12316	Alarm handling	●	●	●

Installation Guide ECL Comfort 310, application A333

Parameter list, application A333, Heating, continued

Home MENU	Sub-menu Heating	A333				
		ID nos.	Function	A333.1	A333.2	A333.3
Settings	Refill tank		Level		●	●
		16113	Filter constant		●	●
		16607	Low X		●	●
		16608	High X		●	●
		16602	Level, desired		●	●
		16194	Stop difference		●	●
		16195	Start difference		●	●
	Application	11017	Demand offset	●	●	●
		11500	Send desired T	●	●	●
		11023	M exercise	●	●	●
		11052	DHW priority	●	●	●
		11077	P frost T	●	●	●
		11078	P heat T	●	●	●
		11093	Frost pr. T	●	●	●
		11141	Ext. input	●	●	●
		11142	Ext. mode	●	●	●
	Water meter		CW consump.		●	●
		13513	Pulse value		●	●
		13514	Preset		●	●
	Flow meter		Actual		●	●
		17607	Low X		●	●
		17608	High X		●	●
		17109	Input type		●	●
		17114	Pulse		●	●
		17115	Units		●	●
	S7 pressure		Pressure	●	●	●
		14113	Filter constant	●	●	●
		14607	Low X	●	●	●
		14608	High X	●	●	●
	S8 pressure		Pressure	●	●	●
		13113	Filter constant	●	●	●
		13607	Low X	●	●	●
		13608	High X	●	●	●
	S9 pressure		Pressure	●	●	●
		12113	Filter constant	●	●	●
		12607	Low X	●	●	●
		12608	High X	●	●	●
	S10 pressure		Pressure	●	●	●
		11113	Filter constant	●	●	●
		11607	Low X	●	●	●
		11608	High X	●	●	●

Installation Guide ECL Comfort 310, application A333

Parameter list, application A333, Heating, continued

Home MENU	Sub-menu Heating	A333				
		ID nos.	Function	A333.1	A333.2	A333.3
Holiday			Holiday	●	●	●
Alarm	Temp. monitor	11147	Upper diff	●	●	●
		11148	Lower diff	●	●	●
		11149	Delay	●	●	●
		11150	Lowest temp.	●	●	●
	Refill tank	16614	Alarm high		●	●
		16615	Alarm low		●	●
		16617	Alarm time-out		●	●
	S7 pressure	14614	Alarm high	●	●	●
		14615	Alarm low	●	●	●
		14617	Alarm time-out	●	●	●
	S8 pressure	13614	Alarm high	●	●	●
		13615	Alarm low	●	●	●
		13617	Alarm time-out	●	●	●
	S9 pressure	12614	Alarm high	●	●	●
		12615	Alarm low	●	●	●
		12617	Alarm time-out	●	●	●
	S10 pressure	11614	Alarm high	●	●	●
		11615	Alarm low	●	●	●
		11617	Alarm time-out	●	●	●
	Low pressure	15615	Alarm low	●	●	●
		15617	Alarm time-out	●	●	●
		Alarm overview			●	●
Influence overview	Des. flow T		Influence source	●	●	●

Installation Guide ECL Comfort 310, application A333

Parameter list, application A333, Common controller

Home MENU	Sub-menu	A333				
	Common controller	ID nos.	Function	A333.1	A333.2	A333.3
	Time & date			●	●	●
	Input overview			●	●	●
	Log			●	●	●
	Output override			●	●	●
	Key functions		New application	●	●	●
			Application	●	●	●
			Factory setting	●	●	●
			Copy	●	●	●
			Key overview	●	●	●
	System		ECL version	●	●	●
			Extension	●	●	●
			Ethernet	●	●	●
			Portal config.	●	●	●
			M-bus config.	●	●	●
			Energy meters	●	●	●
			Raw input overview	●	●	●
			Alarm	●	●	●
			Display	●	●	●
			Communication	●	●	●
			Language	●	●	●

Installation Guide ECL Comfort 310, application A333

3.0 Daily use

3.1 How to navigate


You navigate in the controller by turning the dial left or right to the desired position (↻).

The dial has a built-in accelerator. The faster you turn the dial, the faster it reaches the limits of any wide setting range.


The position indicator in the display (▶) will always show you where you are.

Push the dial to confirm your choices (⏏).

The display examples are from a two-circuit application: One heating circuit (🏠) and one domestic hot-water (DHW) circuit (🚿). The examples might differ from your application.



Heating circuit (🏠):



Some general settings which apply to the entire controller are located in a specific part of the controller.

To enter 'Common controller settings':

Action:	Purpose:	Examples:
↻	Choose 'MENU' in any circuit	MENU
⏏	Confirm	
↻	Choose the circuit selector at the top right corner in the display	
⏏	Confirm	
↻	Choose 'Common controller settings'	🏠🚿
⏏	Confirm	

Circuit selector



Installation Guide ECL Comfort 310, application A333

3.2 Understanding the controller display

This section describes the function in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

Choosing a favorite display

Your favorite display is the display you have chosen as the default display. The favorite display will give you a quick overview of the temperatures or units that you want to monitor in general.

If the dial has not been activated for 20 min., the controller will revert to the overview display you have chosen as favorite.



To shift between displays: Turn the dial until you reach the display selector (---) at the bottom right side of the display. Push the dial and turn to choose your favorite overview display. Push the dial again.

Heating circuit

Overview display 1 informs about:
actual outdoor temperature, controller mode,
actual room temperature, desired room temperature.

Overview display 2 informs about:
actual outdoor temperature, trend in outdoor temperature,
controller mode, max. and min. outdoor temperatures since
midnight as well as desired room temperature.


Overview display 3 informs about:
date, actual outdoor temperature, controller mode, time, desired
room temperature as well as shows the comfort schedule of the
current day.

Overview display 4 informs about:
state of the controlled components, actual flow temperature,
(desired flow temperature), controller mode, return temperature
(limitation value).


Dependent on the chosen display, the overview displays for the
heating circuit inform you about:

- actual outdoor temperature (-0.5)
- controller mode (☼)
- actual room temperature (24.5)
- desired room temperature (20.7 °C)
- trend in outdoor temperature (↗ → ↘)
- min. and max. outdoor temperatures since midnight (↕)
- date (23.02.2010)
- time (7:43)
- comfort schedule of the current day (0 - 12 - 24)
- state of the controlled components (M2, P2)
- actual flow temperature (49 °C), (desired flow temperature (31))
- return temperature (24 °C) (limitation temperature (50))


Overview display 1:




Overview display 2:



Overview display 3:



Overview display 4:



The setting of the desired room temperature is important even if a room temperature sensor / Remote Control Unit is not connected.

Installation Guide ECL Comfort 310, application A333



If the temperature value is displayed as

"- -" the sensor in question is not connected.

"- - -" the sensor connection is short-circuited.


Setting the desired temperature

Depending on the chosen circuit and mode, it is possible to enter all daily settings directly from the overview displays (see also the next page concerning symbols).

Setting the desired room temperature

The desired room temperature can easily be adjusted in the overview displays for the heating circuit.

Action:	Purpose:	Examples:
	Desired room temperature	20.5
	Confirm	
	Adjust the desired room temperature	21.0
	Confirm	



This overview display informs about outdoor temperature, actual room temperature as well as desired room temperature.

The display example is for comfort mode. If you want to change the desired room temperature for saving mode, choose the mode selector and select saving.



The setting of the desired room temperature is important even if a room temperature sensor / Remote Control Unit is not connected.

Setting the desired room temperature, ECA 30 / ECA 31

The desired room temperature can be set exactly as in the controller. However, other symbols can be present in the display (please see 'What do the symbols mean?').



With the ECA 30 / ECA 31 you can override the desired room temperature set in the controller temporarily by means of the override functions:

Installation Guide ECL Comfort 310, application A333

3.3 A general overview: What do the symbols mean?

Symbol	Description	
	Outdoor temp.	Temperature
	Relative humidity indoor	
	Room temp.	
	DHW temp.	
	Position indicator	
	Scheduled mode	Mode
	Comfort mode	
	Saving mode	
	Frost protection mode	
	Manual mode	
	Standby	
	Cooling mode	
	Active output override	
	Optimized start or stop time	
	Heating	Circuit
	Cooling	
	DHW	
	Common controller settings	
	Pump ON	Controlled component
	Pump OFF	
	Actuator opens	
	Actuator closes	
	Actuator, analogue control signal	

Symbol	Description
	Alarm
	Monitoring temperature sensor connection
	Display selector
	Max. and min. value
	Trend in outdoor temperature
	Wind speed sensor
	Sensor not connected or not used
	Sensor connection short-circuited
	Fixed comfort day (holiday)
	Active influence
	Heating active
	Cooling active

Additional symbols, ECA 30 / 31:

Symbol	Description
	ECA Remote Control Unit
	Connection address (master: 15, slaves: 1 - 9)
	Day off
	Holiday
	Relaxing (extended comfort period)
	Going out (extended saving period)



In ECA 30 / 31 only the symbols that are relevant to the application in the controller are displayed.

Installation Guide ECL Comfort 310, application A333

3.4 Monitoring temperatures and system components


This section describes the function in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

Heating circuit

The overview display in the heating circuit ensures a quick overview of the actual and (desired) temperatures as well as the actual state of the system components.

Display example:


49 °C	Flow temperature
(31)	Desired flow temperature
24 °C	Return temperature
(50)	Return temperature limitation



Input overview

Another option to get a quick overview of measured temperatures is the 'Input overview' which is visible in the common controller settings (how to enter the common controller settings, see 'Introduction to common controller settings')

As this overview (see display example) only states the measured actual temperatures, it is read-only.



3.5 Influence overview

This section describes the function in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The menu gives an overview of the influences on the desired flow temperature. It differs from application to application which parameters are listed. It can be helpful in a service situation to explain unexpected conditions or temperatures among others.

If the desired flow temperature is influenced (corrected) by one or more parameters, it is indicated by a small line with arrow-down, arrow-up or double-arrow:

Arrow-down:

The parameter in question reduces the desired flow temperature.

Arrow-up:

The parameter in question increases the desired flow temperature.


Double-arrow:

The parameter in question creates an override (e.g. Holiday).

Straight line:

No active influence.

In the example, the arrow in the symbol points downwards for 'Room lim.'. This means that the actual room temperature is higher than the desired room temperature which again results in a decrease of the desired flow temperature.



Installation Guide ECL Comfort 310, application A333


3.6 Manual control

This section describes the function in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

It is possible to manually control the installed components.

Manual control can only be selected in favorite displays in which the symbols for the controlled components (valve, pump etc.) are visible.

Action:	Purpose:	Examples:
	Choose mode selector	
	Confirm	
	Choose manual mode	
	Confirm	
	Choose pump	
	Confirm	
	Switch ON the pump	
	Switch OFF the pump.	
	Confirm pump mode	
	Choose motorized control valve	
	Confirm	
	Open the valve	
	Stop opening the valve	
	Close the valve	
	Stop closing the valve	
	Confirm valve mode	



During manual operation:

- All control functions are deactivated
- Output override is not possible
- Frost protection is not active



When manual control is selected for one circuit, it is automatically selected for all circuits!

To leave manual control, use the mode selector to select the desired mode. Push the dial.

Manual control is typically used when commissioning the installation. The controlled components, valve, pump etc., can be controlled for correct function.

Installation Guide ECL Comfort 310, application A333

3.7 Schedule

3.7.1 Set your schedule















This section describes the schedule in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application. In some applications, however, there might be more than one schedule. Additional schedules can be found in 'Common controller settings'.

The schedule consists of a 7-day week:

M = Monday
T = Tuesday
W = Wednesday
T = Thursday
F = Friday
S = Saturday
S = Sunday

The schedule will day-by-day show you the start and stop times of your comfort periods (heating / DHW circuits).




Changing your schedule:

Action:	Purpose:	Examples:
	Choose 'MENU' in any of the overview displays	MENU
	Confirm	
	Confirm the choice 'Schedule'	
	Choose the day to change	▶
	Confirm*	T
	Go to Start1	
	Confirm	
	Adjust the time	
	Confirm	
	Go to Stop1, Start2 etc. etc.	
	Return to 'MENU'	MENU
	Confirm	
	Choose 'Yes' or 'No' in 'Save'	
	Confirm	

* Several days can be marked

The chosen start and stop times will be valid for all the chosen days (in this example Thursday and Saturday).

You can set max. 3 comfort periods a day. You can delete a comfort period by setting start and stop times to the same value.



Each circuit has its own schedule. To change to another circuit, go to 'Home', turn the dial and choose the desired circuit.



The start and stop times can be set in half-hourly (30 min.) intervals.

Installation Guide ECL Comfort 310, application A333

4.0 Settings overview

All parameters related to heating are listed as circuit 1.
It is recommendable to make a note of any changed settings in the empty columns.

Setting	ID	Page	Factory settings in circuit(s)						
			1	2	3				
Heat curve		74	1.0						
Temp. max. (flow temp. limit, max.)	11178	75	90 °C						
Temp. min. (flow temp. limit, min.)	11177	75	10 °C						
High T out X1 (return temp. limitation, high limit, X-axis)	11031	76	15 °C						
Low limit Y1 (return temp. limitation, low limit, Y-axis)	11032	76	40 °C						
Low T out X2 (return temp. limitation, low limit, X-axis)	11033	76	-15 °C						
High limit Y2 (return temp. limitation, high limit, Y-axis)	11034	77	60 °C						
Infl. - max. (return temp. limitation - max. influence)	11035	77	-2.0						
Infl. - min. (return temp. limitation - min. influence)	11036	77	0.0						
Adapt. time (adaptation time)	11037	78	25 s						
Priority (priority for return temp. limitation)	11085	78	OFF						
Actual (actual flow or power)	11110	79							
Actual limit (limitation value)	11111	79							
High T out X1 (flow / power limitation, high limit, X-axis)	11119	79	15 °C						
Low limit Y1 (flow / power limitation, low limit, Y-axis)	11117	80	999.9 l/h						
Low T out X2 (flow / power limitation, low limit, X-axis)	11118	80	-15 °C						
High limit Y2 (flow / power limitation, high limit, Y-axis)	11116	80	999.9 l/h						
Adapt. time (adaptation time)	11112	80	OFF						
Filter constant	11113	80	10						
Input type	11109	81	OFF						
Units	11115	81	l / h						
Auto saving (saving temp. dependent on outdoor temp.)	11011	82	-15 °C						
Boost	11012	82	OFF						
Ramp (reference ramping)	11013	83	OFF						
Optimizer (optimizing time constant)	11014	83	OFF						
Pre-stop (optimized stop time)	11026	84	ON						
Total stop	11021	84	OFF						
Cut-out (limit for heating cut-out)	11179	85	18 °C						
Position (A333.2 / A333.3)	Read-out	87	*)						
Filter constant (A333.2 / A333.3)	15113	87	2						
Low X (A333.2 / A333.3)	15607	88	2.0 V						
High X (A333.2 / A333.3)	15608	88	10.0 V						
Motor pr. (motor protection) — only A333.1, A333.2	11174	88	OFF						
Xp (proportional band)	11184	89	80 K						
Tn (integration time constant)	11185	89	30 s						
M run (running time of the motorized control valve)— only A333.1, A333.2	11186	89	50 s						
Nz (neutral zone)	11187	89	3 K						
Min. act. time (min. activation time gear motor)—	11189	90	3						
Pressure des. (A333.2 / A333.3)	11321	92	3.0 bar						
Xp (proportional band) (A333.2 / A333.3)	13184	92	25 bar						

Installation Guide ECL Comfort 310, application A333

Setting	ID	Page	Factory settings in circuit(s)							
			1	2	3					
Tn (integration time) (A333.2 / A333.3)	13185	93	25 sec							
Nz (neutral zone) (A333.2 / A333.3)	13187	93	0.4 bar							
Td (Time derivative) (A333.2 / A333.3)	13197	93	0 sec							
V out max. (A333.2 / A333.3)	13165	93	100 %							
V out min. (A333.2 / A333.3)	13167	94	0 %							
Sleep level (A333.2 / A333.3)	11331	94	20 %							
Sleep mode time (A333.2 / A333.3)	11332	94	10 sec							
Wake up level (A333.2 / A333.3)	11330	95	40 %							
Boost (A333.2 / A333.3)	11333	95	5 %							
Pressure diff. (A333.2 / A333.3)	12322	96	1.5 bar							
Xp (proportional band) (A333.2 / A333.3)	12184	97	10 bar							
Tn (integration time) (A333.2 / A333.3)	12185	97	5 sec							
Nz (neutral zone) (A333.2 / A333.3)	12187	97	1.0 bar							
Td (Time derivative) (A333.2 / A333.3)	12197	97	0 sec							
V out max. (A333.2 / A333.3)	12165	98	100 %							
V out min. (A333.2 / A333.3)	12167	98	0 %							
Pressure diff.	11322	99	1.5 bar							
Chan.-over time (change-over time)	11314	99	15 sec							
Retry time	11310	100	OFF							
Stab. time (stabilization time)	11313	100	50 sec							
Change, duration	11311	100	7 days							
Change time	11312	101	12							
P exercise (pump exercise)	11022	101	OFF							
Alarm handling	11316	101	OFF							
Tiime Left	Read-out	102	-							
Change duration	12311	103	7 days							
Pressure des.	11321	103	3.0 bar							
Pressure diff.	13322	104	1.5 bar							
Max. pressure	11318	104	40.0 bar							
Max. pressure diff.	11319	105	-0.5 bar							
Time-out	11323	106	100 sec							
P exercise (pump exercise)	11022	107	OFF							
Valve delay	11325	107	1 sec							
No. of pumps	11326	107	1							
Alarm handling	12316	108	OFF							
Level (A333.2 / A333.3)	Read-out	109	*)							
Filter constant	16113	110	4							
Low X (A333.2 / A333.3)	16607	110	2.0 V							
High X (A333.2 / A333.3)	16608	110	10.0 V							
Level, desired (A333.2 / A333.3)	16602	111	3.0 m							
Stop difference (A333.2 / A333.3)	16194	111	0.5 m							
Start difference (A333.2 / A333.3)	16195	111	-0.5 m							
Demand offset	11017	112	OFF							
Send desired T	11500	112	ON							

Installation Guide ECL Comfort 310, application A333

Setting	ID	Page	Factory settings in circuit(s)							
			1	2	3					
M exercise (valve exercise)	11023	112	OFF							
DHW priority (closed valve / normal operation)	11052	113	OFF							
P frost T	11077	113	2 °C							
P heat T (heat demand)	11078	113	20 °C							
Frost pr. T (frost protection temperature)	11093	113	10 °C							
Ext. input (external override)	11141	114	OFF							
Ext. mode (external override mode)	11142	115	COM-FORT							
CW consump. (A333.2 / A333.3)	Read-out	116	-							
Pulse value (A333.2 / A333.3)	13513	116	10.0 l							
Preset (A333.2 / A333.3)	13514	116	OFF							
Actual (A333.2 / A333.3)	Read-out	117	*)							
Low X (A333.2 / A333.3)	17607	118	2.0 V							
High X (A333.2 / A333.3)	17608	118	10.0 V							
Input type (A333.2 / A333.3)	17109	118	OFF							
Pulse (A333.2 / A333.3)	17114	119	OFF							
Units (A333.2 / A333.3)	17115	119	l/h							
Pressure (S7, S8, S9, S10)	Read-out	121	*)							
Filter constant (S7, S8, S9, S10)	1x113	121	4							
Low X (S7, S8, S9, S10)	1x607	122	2.0 V							
High X (S7, S8, S9, S10)	1x608	122	10.0 V							
Upper difference	11147	123	OFF							
Lower difference	11148	123	OFF							
Delay	11149	124	10 m							
Lowest temp.	11150	124	30 °C							
Alarm high (A333.2 / A333.3)	16614	124	25.0 m							
Alarm low (A333.2 / A333.3)	16615	125	0.0 m							
Alarm time-out (A333.2 / A333.3)	16617	125	15 s							
Alarm high	1x614	126	25.0 bar							
Alarm low	1x615	126	25.0 bar							
Alarm time-out	1x617	126	10 m							
Alarm low	15615	126	25.0 bar							
Alarm time-out	15617	127	10 s							
Backlight (display brightness)	60058	137						5		
Contrast (display contrast)	60059	137						3		
Modbus addr.	38	138						1		
ECL 485 addr. (master / slave address)	2048	138						15		
Service Pin	2150	138						0		
Ext. reset	2151	139						0		
Language	2050	139						English		
Room T Offset		141						0.0 K		
RH offset (ECA 31 only)		142						0.0 %		
Backlight (display brightness)		142						5		
Contrast (display contrast)		142						3		
Use as remote		142						*)		

Installation Guide ECL Comfort 310, application A333

Setting	ID	Page	Factory settings in circuit(s)						
			1	2	3				
Slave addr. (Slave address)		143						A	
Connection addr. (Connection address)		143						15	
Override addr. (Override address)		144						OFF	
Override circuit		145						OFF	

Installation Guide ECL Comfort 310, application A333

5.0 Settings, circuit 1

5.1 Flow temperature

The ECL Comfort controller determines and controls the flow temperature related to the outdoor temperature. This relationship is called the heat curve.

The heat curve is set by means of 6 coordinate points. The desired flow temperature is set at 6 pre-defined outdoor temperature values.

The shown value for the heat curve is an average value (slope), based on the actual settings.

Outdoor temp.	Desired flow temp.			Your settings
	A	B	C	
-30 °C	45 °C	75 °C	95 °C	
-15 °C	40 °C	60 °C	90 °C	
-5 °C	35 °C	50 °C	80 °C	
0 °C	32 °C	45 °C	70 °C	
5 °C	30 °C	40 °C	60 °C	
15 °C	25 °C	28 °C	35 °C	

A: Example for floor heating

B: Factory settings

C: Example for radiator heating (high demand)

Heat curve		
Circuit	Setting range	Factory setting
1	0.1 ... 4.0	1.0

The heat curve can be changed in two ways:

1. The value of the slope is changed (see heat curve examples on next page)
2. The coordinates of the heat curve are changed

Change the value of the slope:

Push the dial to enter / change the slope value of the heat curve (example: 1.0).

When the slope of the heat curve is changed by means of the slope value, the common point for all heat curves will be a desired flow temperature = 24.6 °C at an outdoor temperature = 20 °C

Change the coordinates:

Push the dial to enter / change the coordinates of the heat curve (example: -30,75).



The heat curve represents the desired flow temperatures at different outdoor temperatures and at a desired room temperature of 20 °C.

If the desired room temperature is changed, the desired flow temperature also changes:


$(\text{Desired room } T - 20) \times \text{HC} \times 2.5$

where "HC" is the Heat Curve slope and "2.5" is a constant.


Desired flow temperature



Slope changes



Coordinate changes



The calculated flow temperature can be influenced by the 'Boost' and 'Ramp' functions etc.


Example:

Heat curve: 1.0
 Desired flow temp.: 50 °C
 Desired room temp.: 22 °C
 Calculation $(22 - 20) \times 1.0 \times 2.5 = 5$
 Result:
 The desired flow temperature will be corrected from 50 °C to 55 °C.

Installation Guide ECL Comfort 310, application A333

Choosing a heat curve slope

The heat curves represent the desired flow temperature at different outdoor temperatures and at a desired room temperature of 20 °C.



The small arrows (▲) indicate 6 different outdoor temperature values at which you can change the heat curve.

MENU > Settings > Flow temperature

Temp. max. (flow temp. limit, max.) 11178		
Circuit	Setting range	Factory setting
	10 ... 150 °C	90 °C



The setting for 'Temp. max.' has higher priority than 'Temp. min.'.

Set the max. flow temperature for the system. The desired flow temperature will not be higher than this setting. Adjust the factory setting, if required.

MENU > Settings > Flow temperature

Temp. min. (flow temp. limit, min.) 11177		
Circuit	Setting range	Factory setting
	10 ... 150 °C	10 °C



'Temp. min.' is overruled if 'Total stop' is active in Saving mode or 'Cut-out' is active.
'Temp. min.' can be overruled by the influence from the return temperature limitation (see 'Priority').

Set the min. flow temperature for the system. The desired flow temperature will not be lower than this setting. Adjust the factory setting, if required.



The setting for 'Temp. max.' has higher priority than 'Temp. min.'.

Installation Guide ECL Comfort 310, application A333


5.2 Return limit

The return temperature limitation is based on the outdoor temperature. Typically in district heating systems a higher return temperature is accepted at a decrease in outdoor temperature. The relationship between the return temperature limits and outdoor temperature is set in two coordinates.

The outdoor temperature coordinates are set in 'High T out X1' and 'Low T out X2'. The return temperature coordinates are set in 'High limit Y2' and 'Low limit Y1'.

The controller automatically changes the desired flow temperature to obtain an acceptable return temperature when the return temperature falls below or gets higher than the calculated limit.

This limitation is based on a PI regulation where P ('Infl.' factor) responds quickly to deviations and I ('Adapt. time') responds slower and over time removes the small offsets between the desired and actual values. This is done by changing the desired flow temperature.



The calculated limit is shown in brackets () in the monitoring display. See the section "Monitoring temperatures and system components".

MENU > Settings > Return limit

High T out X1 (return temp. limitation, high limit, X-axis) 11031		
Circuit	Setting range	Factory setting
	-60 ... 20 °C	15 °C
Set the outdoor temperature for the low return temperature limitation.		

The corresponding Y coordinate is set in 'Low limit Y1'.

MENU > Settings > Return limit

Low limit Y1 (return temp. limitation, low limit, Y-axis) 11032		
Circuit	Setting range	Factory setting
	10 ... 150 °C	40 °C
Set the return temperature limitation referring to the outdoor temperature set in 'High T out X1'.		

The corresponding X coordinate is set in 'High T out X1'.

MENU > Settings > Return limit

Low T out X2 (return temp. limitation, low limit, X-axis) 11033		
Circuit	Setting range	Factory setting
	-60 ... 20 °C	-15 °C
Set the outdoor temperature for the high return temperature limitation.		

The corresponding Y coordinate is set in 'High limit Y2'.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Return limit

High limit Y2 (return temp. limitation, high limit, Y-axis)		11034
Circuit	Setting range	Factory setting
	10 ... 150 °C	60 °C
Set the return temperature limitation referring to the outdoor temperature set in 'Low T out X2'.		

The corresponding X coordinate is set in 'Low T out X2'.

MENU > Settings > Return limit


Infl. - max. (return temp. limitation - max. influence)		11035
Circuit	Setting range	Factory setting
	-9.9 ... 9.9	-2.0
Determines how much the desired flow temperature will be influenced if the return temperature is higher than the calculated limit.		

Influence higher than 0:

The desired flow temperature is increased, when the return temperature gets higher than the calculated limit.

Influence lower than 0:

The desired flow temperature is decreased, when the return temperature gets higher than the calculated limit.



If the 'Infl.' factor is too high and / or the 'Adapt. time' too low, there is a risk of unstable control.

Example

The return limit is active above 50 °C.
The influence is set to -2.0.
The actual return temperature is 2 degrees too high.
Result:
The desired flow temperature is changed by $-2.0 \times 2 = -4.0$ degrees.



Normally, this setting is lower than 0 in district heating systems to avoid a too high return temperature.
Typically, this setting is 0 in boiler systems because a higher return temperature is acceptable (see also 'Infl. - min.').

MENU > Settings > Return limit

Infl. - min. (return temp. limitation - min. influence)		11036
Circuit	Setting range	Factory setting
	-9.9 ... 9.9	0.0
Determines how much the desired flow temperature will be influenced if the return temperature is lower than the calculated limit.		

Influence higher than 0:

The desired flow temperature is increased, when the return temperature gets below the calculated limit.

Influence lower than 0:

The desired flow temperature is decreased, when the return temperature gets below the calculated limit.

Example

The return limit is active below 50 °C.
The influence is set to -3.0.
The actual return temperature is 2 degrees too low.
Result:
The desired flow temperature is changed by $-3.0 \times 2 = -6.0$ degrees.



Normally, this setting is 0 in district heating systems because a lower return temperature is acceptable.
Typically, this setting is higher than 0 in boiler systems to avoid a too low return temperature (see also 'Infl. - max.').

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Return limit

Adapt. time (adaptation time)		11037
Circuit	Setting range	Factory setting
	OFF / 1 ... 50 s	25 s
Controls how fast the return temperature adapts to the desired return temperature limit (I control).		



The adaptation function can correct the desired flow temperature with max. 8 K.

- OFF:** The control function is not influenced by the 'Adapt. time'.
- 1:** The desired temperature is adapted quickly.
- 50:** The desired temperature is adapted slowly.

MENU > Settings > Return limit

Priority (priority for return temp. limitation)		11085
Circuit	Setting range	Factory setting
	OFF / ON	OFF
Choose whether the return temperature limitation should overrule the set min. flow temperature 'Temp. min.'.		

- OFF:** The min. flow temperature limit is not overruled.
- ON:** The min. flow temperature limit is overruled.

Installation Guide ECL Comfort 310, application A333

5.3 Flow / power limit

A flow or energy meter can be connected (M-bus signal) to the ECL controller in order to limit the flow or consumed power.


The flow / power limitation can be based on the outdoor temperature. Typically, in district heating systems a higher flow or power is accepted at lower outdoor temperatures.

The relationship between the flow or power limits and the outdoor temperature is set in two coordinates.

The outdoor temperature coordinates are set in 'High T out X1' and 'Low T out X2'.

The flow or power coordinates are set in 'Low limit Y1' and 'High limit Y2'. Based on these settings, the controller calculates the limitation value.

When the flow / power gets higher than the calculated limit, the controller gradually reduces the desired flow temperature to obtain an acceptable max. flow or power consumption.



MENU > Settings > Flow / power limit

Actual (actual flow or power)		11110
Circuit	Setting range	Factory setting
	Read-out only	
The value is the actual flow or power based on the signal from flow / energy meter.		

MENU > Settings > Flow / power limit

Actual limit (limitation value)		11111
Circuit	Setting range	Factory setting
	Read-out only	
The value is the calculated limitation value.		

MENU > Settings > Flow / power limit

High T out X1 (flow / power limitation, high limit, X-axis)		11119
Circuit	Setting range	Factory setting
	-60 ... 20 °C	15 °C
Set the outdoor temperature value for the low flow / power limitation.		

The corresponding Y coordinate is set in 'Low limit Y1'.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Flow / power limit

Low limit Y1 (flow / power limitation, low limit, Y-axis) 11117		
Circuit	Setting range	Factory setting
	0.0 ... 999.9 l/h	999.9 l/h
Set the flow / power limitation referring to the outdoor temperature set in 'High T out X1'.		



The limitation function can overrule the set 'Temp. min' of the desired flow temperature.

The corresponding X coordinate is set in 'High T out X1'.

MENU > Settings > Flow / power limit

Low T out X2 (flow / power limitation, low limit, X-axis) 11118		
Circuit	Setting range	Factory setting
	-60 ... 20 °C	-15 °C
Set the outdoor temperature value for the high flow / power limitation.		

The corresponding Y coordinate is set in 'High limit Y2'.

MENU > Settings > Flow / power limit

High limit Y2 (flow / power limitation, high limit, Y-axis) 11116		
Circuit	Setting range	Factory setting
	0.0 ... 999.9 l/h	999.9 l/h
Set the flow / power limitation referring to the outdoor temperature set in 'Low T out X2'.		

The corresponding X coordinate is set in 'Low T out X2'.

MENU > Settings > Flow / power limit

Adapt. time (adaptation time) 11112		
Circuit	Setting range	Factory setting
1	OFF / 1 ... 50 sec	OFF
Controls how fast the flow / power limitation adapts to the desired limitation.		



If the 'Adapt. time' is too high, there is a risk of unstable control.

OFF: The control function is not influenced by the "Adapt. time".

Low value: The desired temperature is adapted slowly.

High value: The desired temperature is adapted quickly.

MENU > Settings > Flow / power limit

Filter constant 11113		
Circuit	Setting range	Factory setting
	1 ... 50	10
The actual filter dampens the flow / power input data by the set factor.		

1: Minor dampening (low filter constant)

50: Major dampening (high filter constant)

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Flow / power limit

Input type		11109
Circuit	Setting range	Factory setting
	OFF / EM1 ... EM5	OFF
Choice of M-bus signal from energy meter number 1 ... 5. Only possible in ECL Comfort 310.		



Flow or power limitation is based on M-bus signal (ECL Comfort 310 controllers only).

OFF: No M-bus signal acquired.

EM1 ... EM5: Energy meter number.

MENU > Settings > Flow / power limit

Units		11115
Circuit	Setting range	Factory setting
	See the list	l / h
Choice of units for measured values.		



List for setting range of 'Units':

l/h
m³/h
kW
MW
GW

Flow values are expressed as l/h or m³/h
Power values are expressed as kW, MW or GW.

Installation Guide ECL Comfort 310, application A333


5.4 Optimization

MENU > Settings > Optimization

Auto saving (saving temp. dependent on outdoor temp.) 11011		
Circuit	Setting range	Factory setting
	OFF / -29 ... 10 °C	-15 °C
Below the set value for the outdoor temperature, the saving temperature setting has no influence. Above the set value for the outdoor temperature, the saving temperature relates to the actual outdoor temperature. The function is relevant in district heating installations in order to avoid a big change in the desired flow temperature after a saving period.		

- OFF:** The saving temperature does not depend on the outdoor temperature.
- 29 ... 10:** The saving temperature depends on the outdoor temperature. When the outdoor temperature is above 10 °C, the reduction is 100%. The lower the outdoor temperature, the less the temperature reduction. When the outdoor temperature is below the set limit, there is no temperature reduction.

The comfort and the saving temperatures are set in the display overviews. The difference between the comfort and the saving temperature is considered to be 100%. Depending on the outdoor temperature, the percentage value can be lower according to the set value in 'Auto saving'.



Example:

Outdoor temp.:	-5 °C
Desired room temp. in Comfort mode:	22 °C
Desired room temp. in Saving mode:	16 °C
Setting in 'Auto saving':	-15 °C

The drawing above illustrates that the reduction percentage at an outdoor temperature of -5 °C is 40%.

The difference between Comfort and Saving temperature is (22-16) = 6 degrees.

40% of 6 degrees = 2.4 degrees

The 'Auto saving' temperature is corrected to (22-2.4) = 19.6 °C.

MENU > Settings > Optimization

Boost 11012		
Circuit	Setting range	Factory setting
	OFF / 1 ... 99%	OFF
Shortens the heating-up period by increasing the desired flow temperature by the percentage you set.		

- OFF:** The boost function is not active.
- 1-99%:** The desired flow temperature is increased temporarily with the set percentage.

In order to shorten the heating-up period after a saving temperature period, the desired flow temperature can be increased temporarily (max. 1 hour). At optimizing the boost is active in the optimization period ('Optimizer').

If a room temperature sensor or an ECA 30 / 31 is connected, the boost stops when the room temperature is reached.

Installation Guide ECL Comfort 310, application A333


MENU > Settings > Optimization

Ramp (reference ramping) 11013		
Circuit	Setting range	Factory setting
	OFF / 1 ... 99 m	OFF
The time (minutes) in which the desired flow temperature increases gradually to avoid load peaks in the heat supply.		

OFF: The ramping function is not active.

1-99 m: The desired flow temperature is increased gradually with the set minutes.

In order to avoid load peaks in the supply network, the flow temperature can be set to increase gradually after a period with saving temperature. This causes the valve to open gradually.



MENU > Settings > Optimization

Optimizer (optimizing time constant) 11014		
Circuit	Setting range	Factory setting
	OFF / 10 ... 59	OFF
Optimizes the start and stop times for the comfort temperature period to obtain the best comfort at the lowest energy consumption. The lower the outdoor temperature, the earlier the heating cut-in. The lower the outdoor temperature, the later the heating cut-out. The optimized heating cut-out time can be automatic or disabled. The calculated start and stop times are based on the setting of the optimizing time constant.		

Adjust the optimizing time constant.

The value consists of a two digit number. The two digits have the following meaning (digit 1 = Table I, digit 2 = Table II).

OFF: No optimization. The heating starts and stops at the times set in the schedule.

10 ... 59: See tables I and II.

Table I:

Left digit	Heat accumulation of the building	System type
1-	light	Radiator systems
2-	medium	
3-	heavy	
4-	medium	Floor heating systems
5-	heavy	

Table II:

Right digit	Dimensioning temperature	Capacity
-0	-50 °C	large
-1	-45 °C	.
.	.	.
-5	-25 °C	normal
.	.	.
-9	-5 °C	small

Dimensioning temperature:

The lowest outdoor temperature (usually determined by your system designer in connection with the design of the heating system) at which the heating system can maintain the designed room temperature.

Example

The system type is radiator, and the heat accumulation of the building is medium.

The left digit is 2.

The dimensioning temperature is -25 °C, and the capacity is normal.

The right digit is 5.

Result:

The setting is to be changed to 25.

Installation Guide ECL Comfort 310, application A333


MENU > Settings > Optimization

Pre-stop (optimized stop time)		11026
Circuit	Setting range	Factory setting
	OFF / ON	ON
Disable the optimized stop time.		

OFF: The optimized stop time is disabled.

ON: The optimized stop time is enabled.

Example: Optimization of Comfort from 07:00 - 22:00





MENU > Settings > Optimization

Total stop		11021
Circuit	Setting range	Factory setting
	OFF / ON	OFF
Decide whether you want a total stop during the saving temperature period.		

OFF: No total stop. The desired flow temperature is reduced according to:

- desired room temperature in saving mode
- auto saving

ON: The desired flow temperature is lowered to the set value in 'Frost pr.'. The circulation pump is stopped but frost protection is still active, see 'P frost T'.



The min. flow temperature limitation ('Temp. min.') is overruled when 'Total stop' is ON.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Optimization


Cut-out (limit for heating cut-out)		11179
Circuit	Setting range	Factory setting
	OFF / 1 ... 50 °C	18 °C

The heating can be switched OFF when the outdoor temperature is higher than the set value. The valve closes and after the post-run time, the heating circulation pump stops. 'Temp. min.' will be overruled.

The heating system switches ON again when the outdoor temperature and the accumulated (filtered) outdoor temperature become lower than the set limit.

This function can save energy.

Set the value for outdoor temperature at which you want the heating system to switch OFF.



The heating cut-out is only active when the controller mode is in scheduled operation. When the cut-out value is set to OFF, there is no heating cut-out.

Installation Guide ECL Comfort 310, application A333

5.5 Control parameters 1

The applications A333.1 and A333.2 control the motorized control valve M1 by means of 3-point control.

The application A333.3 controls the M1 by means of a 0 - 10 volt control signal.

The motorized control valve M1 is opened gradually when the flow temperature S3 is lower than the desired flow temperature and vice versa.

3-point controlled M1 (A333.1 and A333.2):

"Open" and "close" commands come from the electronic outputs of the ECL Comfort controller and control the position of M1.

The commands are expressed as "Arrow-up" (open) and "Arrow-down" (close) and displayed at the M1 symbol.

When the temperature at S3 is lower than the desired temperature, short open-commands come from the ECL Comfort controller in order to open M1 more than the moment before. By this, the S3 temperature aligns with the desired temperature.

Oppositely, when the temperature at S3 is higher than the desired temperature, short close-commands come from the ECL Comfort controller in order to close M1 more than the moment before. Again, the S3 temperature aligns with the desired temperature.

Neither open-commands nor close-commands will come as long as the flow temperature corresponds to the desired temperature.

0 - 10 volt controlled M1 (A333.3):

A control voltage between 0 and 10 volt comes from the extension module ECA 32 and controls the position of M1. The voltage is expressed as a % value and displayed at the M1 symbol.

When the temperature at S3 is lower than the desired temperature, the control voltage is gradually increased in order to open M1 more than the moment before. By this, the S3 temperature aligns with the desired temperature.

The control voltage remains on a fixed value as long as the flow temperature corresponds to the desired temperature.

Oppositely, when the temperature at S3 is higher than the desired temperature, the control voltage is gradually decreased in order to close M1 more than the moment before. Again, the S3 temperature aligns with the desired temperature.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par. 1

Position (A333.2 / A333.3)		Read-out
Circuit	Setting range	Factory setting
1	-	*)
Position of the motorized control valve M1 is indicated as a % value. A 0 - 10 volt signal comes from a position measuring in M1 and is applied to input S11 (ECA 32). This input voltage is converted to the displayed % value. Access to conversion (scale) settings.		

*) 2.0 volt = 0 %, 10.0 volt = 100 %


The position is measured by means of a 0 - 10 volt signal. The measured voltage must be converted to a position value by the controller.

The following procedure sets up the conversion:
Push the dial to see the graph and enter the value sets for the 2 input voltages and related position values.
Position value range: 0 ... 100 %

The factory set voltage values (2.0 volt and 10.0 volt) can be changed in the following two separate menus "Low X" and "High X".

Factory settings: 2.0, 0 (= 2.0 V / 0 %) and 10.0, 100 (= 10.0 V / 100 %)

This means that the "Position" is 0 % at 2.0 V and 100 % at 10.0 V. Typically, the higher the voltage, the higher the displayed position.



X = Volt

Y = Position



This scaling menu is always displayed, regardless a position signal is applied.
The position is indicated as 0 when the position signal is not applied.

MENU > Settings > Control par. 1

Filter constant (A333.2 / A333.3)		15113
Circuit	Setting range	Factory setting
1	1 - 250	2
The filter constant dampens the position signal from the position measurement in M1 in order to make a stable read-out.		


1: Minor dampening (low filter constant)

250: Major dampening (high filter constant)

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par. 1


Low X (A333.2 / A333.3)		15607
Circuit	Setting range	Factory setting
1	0.0 . . . 10.0 V	2.0 V
Definition of which voltage value corresponds to which position value. The voltage (as a 0 - 10 volt signal) comes from a position measuring in M1 and is applied to input S11 (ECA 32). This input voltage is converted to display a % value for the position of M1. See also "Position" and "High X".		



X = Volt
Y = Position
1 # = Low X

MENU > Settings > Control par. 1


High X (A333.2 / A333.3)		15608
Circuit	Setting range	Factory setting
1	0.0 . . . 10.0 V	10.0 V
Definition of which voltage value corresponds to which position value. The voltage (as a 0 - 10 volt signal) comes from a position measuring in M1 and is applied to input S11 (ECA 32). This input voltage is converted to display a % value for the position of M1. See also "Position" and "Low X".		



X = Volt
Y = Position
1 # = High X

MENU > Settings > Control par. 1

Motor pr. (motor protection) — only A333.1, A333.2		11174
Circuit	Setting range	Factory setting
1	OFF / 10 ... 59 m	OFF
Prevents the controller from unstable temperature control (and resulting actuator oscillations). This can occur at very low load. The motor protection increases the lifetime of all involved components.		



OFF: Motor protection is not activated.
10 ... 59: Motor protection is activated after the set activation delay in minutes.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par. 1

Xp (proportional band)		11184
Circuit	Setting range	Factory setting
1	5 ... 250 K	80 K

Set the proportional band. A higher value will result in a stable but slow control of the flow temperature.

MENU > Settings > Control par. 1

Tn (integration time constant)		11185
Circuit	Setting range	Factory setting
1	1 ... 999 s	30 s

Set a high integration time constant (in seconds) to obtain a slow but stable reaction to deviations.

A low integration time constant will make the controller react fast but with less stability.

MENU > Settings > Control par. 1

M run (running time of the motorized control valve)— only A333.1, A333.2		11186
Circuit	Setting range	Factory setting
1	5 ... 250 s	50 s

'M run' is the time in seconds it takes the controlled component to move from fully closed to fully open position. Set the 'M run' according to the examples or measure the running time by means of a stop watch.

How to calculate the running time of a motorized control valve

The running time of the motorized control valve is calculated using the following methods:

Seated valves

Running time = Valve stroke (mm) x actuator speed (sec. / mm)

Example: 5.0 mm x 15 sec. / mm = 75 sec.

Rotating valves

Running time = Turning degrees x actuator speed (sec. / degr.)

Example: 90 degr. x 2 sec. / degr. = 180 sec.

MENU > Settings > Control par. 1

Nz (neutral zone)		11187
Circuit	Setting range	Factory setting
1	1 ... 9 K	3 K

Set the acceptable flow temperature deviation.

Set the neutral zone to a high value if you can accept a high variation in flow temperature. When the actual flow temperature is within the neutral zone, the controller does not activate the motorized control valve.



The neutral zone is symmetrical around the desired flow temperature value, i.e. half the value is above and half the value is below this temperature.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par. 1

Min. act. time (min. activation time gear motor)— only A333.1, A333.2		11189
Circuit	Setting range	Factory setting
1	2 ... 50	3
The min. pulse period of 20 ms (milliseconds) for activation of the gear motor.		

Setting example	Value x 20 ms
2	40 ms
10	200 ms
50	1000 ms



The setting should be kept as high as acceptable to increase the lifetime of the actuator (gear motor).

5.6 Control parameters, refill pump(s)

Control parameters for refill water pump(s), applications A333.2 / A333.3

The refill water pumps P3 / P4 can be speed controlled by means of a 0 - 10 volt signal. The speed control signal comes from the output M2 (terminals 60 and 56) on the ECA 32 module.

A desired pressure at S10 is set for the speed control procedure. The control voltage is expressed as a % value and displayed at the M2 symbol.

When the pressure at S10 gets too low, a refill pump (P3 or P4) is switched ON.

The control voltage is gradually increased in order to increase the speed of the refill water pump. By this, the pressure aligns with the desired pressure.

The control voltage remains on a fixed value as long as the pressure corresponds to the desired pressure.

The control voltage can be limited to a maximum and a minimum % value.

Sleep function:

In order to protect a refill pump against a too low speed, the "Sleep function" can be used.

When the speed control voltage for M2 gets lower than "Sleep level", the control voltage is commanded to 0 % after a period ("Sleep mode time"). The refill pump stops.


After elapse of the "Sleep mode time" and a continued demand for refill, the control voltage is commanded to "Wake-up level" and starts the refill pump. A "Boost" can be added to the "Wake-up level".

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par., P refill

Pressure des. (A333.2 / A333.3)		11321
Circuit	Setting range	Factory setting
1	0.2 . . . 25.0 bar	3.0 bar
Setting of desired pressure at S10 in order to speed control the refill pump(s) P3 / P4.		

0.2 - 25.0: Set the desired pressure at S10 (in bar)



- X = Time
- Y = Pressure
- # 1 # = Pressure desired
- # 2 # = Actual pressure
- # 3 # = Pressure difference
- # 4 # = Neutral zone, Nz
- # 5 # = Refill water pump
- # 6 # = Speed control signal (0 - 10 V)



The parameter "Pressure des." is also used in application A333.1 for setting desired pressure for ON / OFF control of refill pump(s) P3 / P4.

MENU > Settings > Control par., P refill

Xp (proportional band) (A333.2 / A333.3)		13184
Circuit	Setting range	Factory setting
1	2 . . . 250 bar	25 bar
Set the proportional band for the control of the pressure at S10.		

Low value: Controller reacts fast, but with less stability

High value: Controller reacts slow and with higher stability

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par., P refill

Tn (integration time) (A333.2 / A333.3)			13185
Circuit	Setting range	Factory setting	
1	1 . . . 999 sec	25 sec	
Set the integration time for the control of the pressure at S10.			

Low value: Controller reacts fast, but with less stability

High value: Controller reacts slow and with higher stability

MENU > Settings > Control par., P refill

Nz (neutral zone) (A333.2 / A333.3)		13187
Circuit	Setting range	Factory setting
1	0.1 . . . 2.0 bar	0.4 bar
Set the acceptable pressure deviation at S10. When the actual pressure is within the neutral zone, the controller does not change the refill pump speed.		



The neutral zone is symmetrical around the desired pressure value, i.e. half the value is above and half the value is below this pressure.

Low value: A low variation in pressure is acceptable

High value: A high variation in pressure is acceptable

MENU > Settings > Control par., P refill

Td (Time derivative) (A333.2 / A333.3)		13197
Circuit	Setting range	Factory setting
1	0 . . . 250 sec	0 sec
The Td related function can avoid a too aggressive reaction in the speed control procedure.		

0: No influence

Low value: Minor influence

High value: Major influence

MENU > Settings > Control par., P refill

V out max. (A333.2 / A333.3)			13165
Circuit	Setting range	Factory setting	
1	0 . . . 100 %	100 %	
<i>The output voltage for controlling the speed of the refill pump can be limited to a maximum value. See also "V out min".</i>			

Example:

A setting of 60 % means that the output voltage will be 6 volt as a maximum.



The setting of "V.out min" has priority over "V.out max".

0 - 100: The value in % expresses the maximum voltage for controlling the analogue output for the speed control of the refill pump.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par., P refill

V out min. (A333.2 / A333.3)		13167
Circuit	Setting range	Factory setting
1	0 . . . 100 %	0 %
The output voltage for controlling the speed of the refill pump can be limited to a minimum value. See also "V out max".		

0 - 100: The value in % expresses the maximum voltage for controlling the analogue output for the speed control of the refill pump.

Example:

A setting of 15 % means that the output voltage will be 1.5 volt as a minimum.




The setting of "V.out min" has priority over "V.out max".

MENU > Settings > Control par., P refill

Sleep level (A333.2 / A333.3)		11331
Circuit	Setting range	Factory setting
1	OFF / 1 . . . 100 %	20 %
When the speed control signal gets below the "Sleep level" value, the speed will be set to 0 (zero) % after elapse of "Sleep mode time". The refill pump stops (goes into sleep mode). The set value is also the speed level at a new refill procedure. This function protects the refill pump against low speed. See also: "Sleep mode time" and "Wake up level".		

OFF: The sleep function is disabled

1 - 100: The sleep function is enabled



X = Time

Y = Speed control signal (0 - 10 V) (%)

1 # = Actual control signal

2 # = Sleep level

3 # = Wake-up level

4 # = Sleep mode time

MENU > Settings > Control par., P refill

Sleep mode time (A333.2 / A333.3)		11332
Circuit	Setting range	Factory setting
1	0 . . . 300 sec	10 sec
The "Sleep mode time" determines a delayed stop of the refill pump at too low speed. See also: "Sleep level" and "Wake up level".		

0 - 300: Set the sleep mode time (in seconds)

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par., P refill

Wake up level (A333.2 / A333.3)		11330
Circuit	Setting range	Factory setting
1	0 . . . 100 %	40 %
After elapse of the "Sleep mode" time and a continued refill demand, the refill water pump restarts with a speed level as the set value. See also: "Sleep level" and "Sleep mode time".		

0 - 100: Set the restart speed level

MENU > Settings > Control par., P refill

Boost (A333.2 / A333.3)		11333
Circuit	Setting range	Factory setting
1	0 . . . 100 %	5 %
The "Wake-up level" can be increased with a % value.		

0 - 100: Set the boost level

Example:

"Wake-up level" = 40 %

"Boost" = 15 %

Result: The increased "Wake-up level" = $40 \times 1.15 = 46$ %

Installation Guide ECL Comfort 310, application A333

5.7 Control parameters, circulation pump(s)

Control parameters for circulation pump(s), applications A333.2 / A333.3

The circulation pumps P1 / P2 can be speed controlled by means of a 0 - 10 volt signal. The speed control signal comes from the output M3 (terminals 61 and 56) on the ECA 32 module.

A desired pressure difference between S9 and S10 is set for the speed control procedure.

The control voltage is expressed as a % value and displayed at the M3 symbol.

When the pressure difference gets lower than the desired pressure difference, the control voltage is gradually increased in order to increase the speed of the circulation pump more than the moment before. By this, the pressure difference aligns with the desired pressure difference.


The control voltage remains on a fixed value as long as the pressure difference corresponds to the desired pressure difference.

The control voltage can be limited to a maximum. and a minimum % value.

MENU > Settings > Control par., P circ.

Pressure diff. (A333.2 / A333.3)		12322
Circuit	Setting range	Factory setting
1	0.1 . . . 5.0 bar	1.5 bar
Setting of desired pressure difference between S9 and S10 in order to speed control the circulation pump(s) P1 / P2.		

0.1 - 5.0: Set the desired pressure difference between S9 and S10 (in bar)



- X = Time
- Y = Pressure
- # 1 # = Pressure diff., desired
- # 2 # = Actual pressure difference
- # 3 # = Neutral zone, Nz
- # 4 # = Speed control signal (0 - 10 V)

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par., P circ.

Xp (proportional band) (A333.2 / A333.3)			12184
Circuit	Setting range	Factory setting	
1	5 . . . 250 bar	10 bar	
Set the proportional band for the control of the pressure difference between S9 and S10.			

Low value: Controller reacts fast, but with less stability

High value: Controller reacts slow and with higher stability

MENU > Settings > Control par., P circ.

Tn (integration time) (A333.2 / A333.3)			12185
Circuit	Setting range	Factory setting	
1	1 . . . 999 sec	5 sec	
Set the integration time for the control of the pressure difference between S9 and S10.			

Low value: Controller reacts fast, but with less stability

High value: Controller reacts slow and with higher stability

MENU > Settings > Control par., P circ.

Nz (neutral zone) (A333.2 / A333.3)			12187
Circuit	Setting range	Factory setting	
1	0.1 . . . 2.0 bar	1.0 bar	
Set the acceptable pressure difference deviation. When the actual pressure difference is within the neutral zone, the controller does not change the circulation pump speed.			



The neutral zone is symmetrical around the desired pressure difference value, i.e. half the value is above and half the value is below.

Low value: A low variation in pressure is acceptable

High value: A high variation in pressure is acceptable

MENU > Settings > Control par., P circ.

Td (Time derivative) (A333.2 / A333.3)			12197
Circuit	Setting range	Factory setting	
1	0 . . . 250 sec	0 sec	
The Td related function can avoid a too aggressive reaction in the speed control procedure.			

0: No influence

Low value: Minor influence

High value: Major influence

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Control par., P circ.

V out max. (A333.2 / A333.3)		12165
Circuit	Setting range	Factory setting
1	0 . . . 100 %	100 %
<i>The output voltage for controlling the speed of the circulation pump can be limited to a maximum value. See also "V out min".</i>		

0 - 100: The value in % expresses the maximum voltage for controlling the analogue output for the speed control of the circulation pump.

Example:

A setting of 60 % means that the output voltage will be 6 volt as a maximum.



The setting of "V.out min" has priority over "V.out max".

MENU > Settings > Control par., P circ.

V out min. (A333.2 / A333.3)		12167
Circuit	Setting range	Factory setting
1	0 . . . 100 %	0 %
The output voltage for controlling the speed of the refill pump can be limited to a minimum value. See also "V out max"..		

0 - 100: The value in % expresses the minimum voltage for controlling the analogue output for the speed control of the circulation pump.

Example:

A setting of 15 % means that the output voltage will be 1.5 volt as a minimum.



The setting of "V.out min" has priority over "V.out max".

Installation Guide ECL Comfort 310, application A333

5.8 Pump control


The A333 application can operate with one or two circulation pumps, P1 or P1 / P2.

When operating with two circulation pumps, the pumps are controlled alternately, according to a time set-up.

When a pump is switched ON the controller is waiting for pressure difference (S9 - S10) to build up.

If an acceptable pressure difference is not achieved, an alarm is generated and the ECL Comfort controller switches ON the other pump.

If none of the pumps can come into operation (detected by means of an unacceptable pressure difference), the alarm is activated and the motorized control valve M1 closes (a safety function).



The alarm function is disabled if the "Alarm handling" (ID no. 11316) is set to OFF.

Settings for pressure transmitter signal (0 - 10 volt) and conversion into pressure value are described in the section S7, S8, S9, S10 pressure.

MENU > Settings > Pump control

Pressure diff.		11322
Circuit	Setting range	Factory setting
1	0.1 . . . 5.0 bar	1.5 bar
Setting of acceptable pressure difference between S9 and S10 in order to feed back that the circulation pump is working properly.		


0.1 - 5.0: Set the desired pressure difference between S9 and S10 (in bar)

MENU > Settings > Pump control

Chan.-over time (change-over time)		11314
Circuit	Setting range	Factory setting
1	OFF / 1 ... 99 s	15 sec
Setting of time to elapse between the pump stop command for one pump and the start command for the other pump. The change-over time can ensure that a pump is stopped efficiently before the other pump starts.		

OFF: One circulation pump in the application.

1 ... 99: Time for change-over.



X = Time

1 # = Change-over time (sec.)

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Pump control

Retry time 11310		
Circuit	Setting range	Factory setting
1	OFF / 1... 99 m	OFF

If an alarm has been generated for the pump or alarms have been generated for both pumps, this setting will determine the time between the time of the alarm and the retry time for repeated pump start.

OFF: No retry time required after an alarm. The pump or pumps in question will not be restarted.

1 ... 99: After an alarm, the pump or pumps will be restarted after the set time.

MENU > Settings > Pump control

Stab. time (stabilization time) 11313		
Circuit	Setting range	Factory setting
1	1... 99 s	50 sec

*Setting of max. time to elapse between pump start command and feedback from differential pressure switch.
If the differential pressure switch does not give feedback within the set time, the alarm will be activated and the other pump will get a start command.*




If the chosen stabilization time ('Stab. time') is too short, the active pump will stop immediately after the stabilization time has elapsed.

MENU > Settings > Pump control

Change, duration 11311		
Circuit	Setting range	Factory setting
1	1 . . . 10 days	7 days

The number of days between shift of circulation pumps. The shift takes place at the time set in 'Change time'.



X = Time


1 # = Change duration

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Pump control

Change time		11312
Circuit	Setting range	Factory setting
1	0 ... 23	12

The exact time of the day, where the shift must take place. The day is divided into 24 hours. The factory setting here is 12 which means 12:00 (noon).



X = Time

MENU > Settings > Pump control

P exercise (pump exercise)		11022
Circuit	Setting range	Factory setting
1	OFF / 1 ... 200 sec	OFF

The time the pump is activated during exercise. Exercise takes place every day (at 12:20) when no heat demand has been present.



The feedback from the pressure difference between S9 and S10 is active and will activate the alarm in case that the pump does not start.

OFF: No pump exercise.

1 ... 200: Activation time during exercise.

MENU > Settings > Pump control

Alarm handling		11316
Circuit	Setting range	Factory setting
1	OFF / ON	OFF

Choose whether the controller must react on an unacceptable pressure difference between S9 and S10.

OFF: Alarm function is disabled. Circulation pump is not stopped although the pressure difference is too low.

ON: Alarm function is enabled. Circulation pump is stopped if the pressure difference is too low.

5.9 Refill water

Leaks on the consumers side (secondary side) will result in falling static pressure and thereby a poor supply of heating. A refill water function can inject water to increase the static pressure.

The A333 application can monitor the static pressure and enable the refill water function when the pressure is too low.


The pressure is measured by means of a pressure transmitter S10 (giving a 0 - 10 volt signal in relation to the measured pressure).

The refill water function can operate with one or two refill water pumps, P3 or P3 / P4. In addition a refill water valve V1 is controlled.

When operating with two refill water pumps, the pumps are controlled alternately, according to a time set-up.

When a too low pressure is detected the refill water pump is switched ON and, after a set time, the ON-OFF valve is activated.

The controller awaits ("Time-out") the pressure at S10 to build up. If an acceptable pressure is not achieved, an alarm is generated and the ECL Comfort controller switches OFF the pump in question.



The alarm function is disabled if the "Alarm handling" (ID no. 12316) is set to OFF.



Settings for pressure transmitter signal (0 - 10 volt) and conversion into pressure value are described in the section "S7 - S10".

MENU > Settings > Refill water

Time Left	Read-out	
<i>Circuit</i>	<i>Setting range</i>	<i>Factory setting</i>
1	-	-
<i>Number of hours before a refill water pump change-over command takes place.</i>		


Installation Guide ECL Comfort 310, application A333

MENU > Settings > Refill water

Change duration		12311
Circuit	Setting range	Factory setting
1	OFF / 1 . . . 60 days	7 days
The number of days between refill water pump change-over.		

OFF: The automatic refill water pump change-over is disabled.

1 - 60: The automatic refill water pump change-over is enabled.



X = Time

1 # = Change duration



The "Change duration" has no influence when only one refill water pump is selected in "No. of pumps" (ID no. 11326).

MENU > Settings > Refill water

Pressure des.		11321
Circuit	Setting range	Factory setting
1	0.2 . . . 25.0 bar	3.0 bar
Setting of desired pressure at S10 in order to ON / OFF control the refill pump(s) P3 / P4. See also 'Pressure diff.'		



The parameter "Pressure des." is also used in application A333.2 / A333.3 for setting desired pressure for speed controlled refill pump(s) P3 / P4.


0.2 - 25.0: Set the desired pressure at S10.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Refill water

Pressure diff.		13322
Circuit	Setting range	Factory setting
1	0.1 . . . 5.0 bar	1.5 bar
Setting of the switching difference for the measured pressure at S10. The difference is symmetrical around the 'Pressure des.' See also 'Pressure des.'		

0.1 - 5.0: Set the desired switching difference related to the pressure at S10.




X = Time
Y = Pressure
1 # = Pressure desired
2 # = Actual pressure
3 # = Pressure difference

MENU > Settings > Refill water

Max. pressure		11318
Circuit	Setting range	Factory setting
1	0.0 . . . 40.0 bar	40.0 bar
Setting of the max. acceptable pressure at S10. When the pressure at S10 gets higher than set value, the release valve V2 is opened in order to reduce the pressure. See also "Max. press. diff."		

0.0 - 40.0: Set the max. acceptable pressure at S10.



X = Time
Y = Pressure
1 # = Max. pressure
2 # = Actual pressure
3 # = Max. pressure difference

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Refill water


Max. pressure diff.		11319
<i>Circuit</i>	<i>Setting range</i>	<i>Factory setting</i>
1	-5.0 . . . -0.1 bar	-0.5 bar
<p><i>Setting of the pressure difference below "Max. pressure" to ensure an acceptable pressure in the heating system.</i></p> <p><i>When the pressure at S10 gets lower than the set difference below "Max. pressure", the release valve V2 is closed in order to stop reducing the pressure. See also "Max. pressure"</i></p>		

-5.0 - -0.1: Set the pressure difference related to "Max. pressure" at S10.


Installation Guide ECL Comfort 310, application A333

MENU > Settings > Refill water


Time-out		11323
Circuit	Setting range	Factory setting
1	1 . . . 1000 sec	100 sec
Setting of the max. time for refill. The pressure, measured by S10, must be OK within the set time. If not, the refill water function stops and an alarm is activated.		



- X = Time
- # 1 # = Pressure OK / not OK
- # 2 # = Refill pump 3 or 4
- # 3 # = Time-out



- X = Time
- # 1 # = Pressure OK / not OK
- # 2 # = Refill pump 3 or 4
- # 3 # = Time-out
- # 4 # = Alarm

 The "Time-out" function is disabled when "Alarm handling" (ID no. 12316) is set to OFF.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Refill water

P exercise (pump exercise)		11022
Circuit	Setting range	Factory setting
1	OFF / 1 ... 200 s	OFF
The time the pump is activated during exercise. Exercise takes place every day (at 12:00).		

OFF: No pump exercise.


1 ... 200: Activation time during exercise.



The feedback from the pressure at S10 is active and will activate the alarm in case that the pump does not start.

MENU > Settings > Refill water

Valve delay		11325
Circuit	Setting range	Factory setting
1	0 ... 30 s	1 sec
Setting of the time for activation of the ON/OFF valve after start of the refill water pump.		



X = Time

Y = Pressure

1 # = Max. pressure

2 # = Actual pressure

3 # = Max. pressure difference

4 # = Valve delay

MENU > Settings > Refill water

No. of pumps		11326
Circuit	Setting range	Factory setting
1	1 / 2	1
Choose the number of refill water pumps in the system.		

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Refill water

Alarm handling		12316
Circuit	Setting range	Factory setting
1	OFF / ON	OFF
Choose whether the controller must react on an unacceptable pressure at S10.		

- OFF:** Alarm function is disabled. Refill water pump is not stopped although the pressure is too low.
- ON:** Alarm function is enabled. Refill water pump is stopped if the pressure difference is too low.

Installation Guide ECL Comfort 310, application A333

5.10 Refill tank

A refill water storage tank can be controlled.


The water level at S12 is measured by means of a pressure transmitter (giving a 0 - 10 volt signal in relation to the measured pressure).

The water level is displayed in meters.

When the water level gets too low, the ON / OFF valve V3 is opened and fills refill water into the storage tank.

When the water level has reached an acceptable level, V3 is closed.

If an alarm is activated because of too high or too low level in the refill water storage tank, the refill pump(s) stop(s) and the valve V1 closes.



MENU > Settings > Refill tank

Level (A333.2 / A333.3)		Read-out
Circuit	Setting range	Factory setting
1	-	*)
<p>Level of the water in the refill water storage tank is indicated as a value in meters</p> <p>A 0 - 10 volt signal comes from a pressure transmitter and is applied to input S12 (ECA 32). This input voltage is converted to the displayed meter value. Access to conversion (scale) settings.</p>		

*) 2.0 volt = 0.0 m, 10.0 volt = 15.0 m

The water level is measured by means of a 0 - 10 volt signal.

The measured voltage must be converted to a water level value by the controller.


The following procedure sets up the conversion:
Push the dial to see the graph and enter the value sets for the 2 input voltages and related water level values.
Water level value range: 0.0 ... 20.0 m

The factory set voltage values (2.0 volt and 10.0 volt) can be changed in the following two separate menus "Low X" and "High X".

Factory settings: 2.0 , 0 (= 2.0 V / 0.0 m) and 10.0 , 15.0 (= 10.0 V / 15.0 m)

This means that the "Water level" is 0.0 m at 2.0 V and 15.0 m at 10.0 V.

Typically, the higher the voltage, the higher the displayed water level.



X = Volt

Y = Meter



This scaling menu is always displayed, regardless a water level signal is applied.
The water level is indicated as 0.0 m when the water level signal is not applied.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Refill tank


Filter constant		16113
Circuit	Setting range	Factory setting
1	1 - 250	4
The filter constant dampens the water level signal from the pressure transmitter in order to make a stable read-out and related functions.		

1: Minor dampening (low filter constant)

250: Major dampening (high filter constant)

MENU > Settings > Refill tank

Low X (A333.2 / A333.3)		16607
Circuit	Setting range	Factory setting
1	0.0 . . . 10.0 V	2.0 V
Definition of which voltage value corresponds to which water level value. The voltage (as a 0 - 10 volt signal) comes from a pressure transmitter and is applied to input S12 (ECA 32). This input voltage is converted to display a water level value (in meter). See also "Level" and "High X".		




X = Volt

Y = Level

1 # = Low X

MENU > Settings > Refill tank

High X (A333.2 / A333.3)		16608
Circuit	Setting range	Factory setting
1	0.0 . . . 10.0 V	10.0 V
Definition of which voltage value corresponds to which water level value. The voltage (as a 0 - 10 volt signal) comes from a pressure transmitter and is applied to input S12 (ECA 32). This input voltage is converted to display a water level value (in meter). See also "Level" and "Low X".		



X = Volt


Y = Level

1 # = High X

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Refill tank

Level, desired (A333.2 / A333.3)		16602
Circuit	Setting range	Factory setting
1	0.2 . . . 25.0 m	3.0 m
Setting of desired water level (measured by S12) in the refill water storage tank. See also "Stop difference" and "Start difference".		



- X = Time
- Y = Level
- # 1 # = Level, desired
- # 2 # = Actual level
- # 3 # = Stop difference
- # 4 # = Start difference

MENU > Settings > Refill tank

Stop difference (A333.2 / A333.3)		16194
Circuit	Setting range	Factory setting
1	0.1 . . . 5.0 m	0.5 m
Setting the difference above the desired water level that will stop the filling of the refill water storage tank (the valve V3 closes). See also "Level, desired" and "Start difference".		

MENU > Settings > Refill tank

Start difference (A333.2 / A333.3)		16195
Circuit	Setting range	Factory setting
1	-5.0 . . . -0.1 m	-0.5 m
Setting the difference below the desired water level that will start the filling of the refill water storage tank (the valve V3 opens). See also "Level, desired" and "Stop difference".		

Installation Guide ECL Comfort 310, application A333


5.11 Application

MENU > Settings > Application

Demand offset 11017		
Circuit	Setting range	Factory setting
1	OFF / 1 ... 20 K	OFF
The desired flow temperature in heating circuit 1 can be influenced by the demand for a desired flow temperature from another controller (slave) or another circuit.		

OFF: The desired flow temperature in circuit 1 is not influenced by the demand of any other controller (slave or circuit 2).

1 ... 20: The desired flow temperature is increased by the set value in 'Demand offset', if the demand of the slave / circuit 2 is higher.



The function of 'Demand offset' can compensate for heat losses between master and slave controlled systems.

MENU > Settings > Application

Send desired T 11500		
Circuit	Setting range	Factory setting
1	OFF / ON	ON
When the controller acts as a slave controller in a master / slave system, information about the desired flow temperature can be sent to the master controller via the ECL 485 bus.		

OFF: Information about the desired flow temperature is not sent to the master controller.

ON: Information about the desired flow temperature is sent to the master controller.



In the master controller, 'Demand offset' must be set to a value in order to react on a desired flow temperature from a slave controller.



When the controller acts as a slave, its address must be 1, 2, 3 ... 9 in order to send the desired temperature to the master (see the section 'Miscellaneous', 'Several controllers in the same system').

MENU > Settings > Application

M exercise (valve exercise) 11023		
Circuit	Setting range	Factory setting
	OFF / ON	OFF
Exercises the valve to avoid blocking in periods without heat demand.		

OFF: The valve exercise is not active.

ON: The valve opens for 7 minutes and closes for 7 minutes every third day at noon (12:00 hours).



The valve exercise is related to motorized control valves (MCV) in heating circuits.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Application

DHW priority (closed valve / normal operation)		11052
Circuit	Setting range	Factory setting
	OFF / ON	OFF
The heating circuit can be closed when the controller acts as slave and when DHW heating / charging is active in the master.		

OFF: The flow temperature control remains unchanged during active DHW heating / charging in the master controller.

ON: The valve in the heating circuit is closed* during active DHW heating / charging in the master controller.

* The desired flow temperature is set to the value set in 'Frost pr. T'



This setting must be considered if this controller is a slave.



The heating circuit can also be closed when the DHW heating is active in the same ECL controller.

MENU > Settings > Application

P frost T		11077
Circuit	Setting range	Factory setting
	OFF / -10 ... 20 °C	2 °C
When the outdoor temperature is below the set temperature in 'P frost T', the controller automatically switches ON the circulation pump to protect the system.		

OFF: No frost protection.

-10 ... 20: The circulation pump is ON when the outdoor temperature is below the set value.



Under normal conditions, your system is not frost protected if your setting is below 0 °C or OFF.

For water-based systems, a setting of 2 °C is recommended.

MENU > Settings > Application

P heat T (heat demand)		11078
Circuit	Setting range	Factory setting
	5 ... 40 °C	20 °C
When the desired flow temperature is above the set temperature in 'P heat T', the controller automatically switches ON the circulation pump.		



The valve is fully closed as long as the pump is not switched on.

5 ... 40: The circulation pump is switched ON when the desired flow temperature is above the set value.

MENU > Settings > Application

Frost pr. T (frost protection temperature)		11093
Circuit	Setting range	Factory setting
	5 ... 40 °C	10 °C
Set the desired flow temperature for example at heating cut-out, total stop etc. to protect the system against frost.		

5 ... 40: Desired frost protection temperature.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Application

Ext. input (external override)		11141
Circuit	Setting range	Factory setting
	OFF / S1 ... S10	OFF
Choose the input for 'Ext. input' (external override). By means of a switch the controller can be overridden to 'Comfort' or 'Saving' mode.		

OFF: No inputs have been selected for external override.


S1 ... S10: Input selected for external override.

If S1 ... S6 is chosen as override input, the override switch must have gold-plated contacts.

If S7 ... S10 is chosen as override input, the override switch can be a standard contact.

See the drawing for a connection example of an override switch to input S9.

The two drawings (override to comfort mode and override to saving mode) show the functionality.




Choose only an unused input for override. If an already used input is applied for override, the functionality of this input is also neglected.




See also 'Ext. mode'.

Override to 'Comfort' mode



Override to 'Saving' mode



The result of override to 'Saving' mode depends on the setting in 'Total stop'.

Total stop = OFF: Heating reduced

Total stop = ON: Heating stopped

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Application

Ext. mode (external override mode)		11142
Circuit	Setting range	Factory setting
	COMFORT / SAVING	COMFORT
Choose external override mode.		



See also 'Ext. input'.

The mode override can be activated for saving or comfort mode. For override, the controller mode must be scheduled mode.

SAVING: The controller is in saving mode when the override switch is closed.

COMFORT: The controller is in comfort mode when the override switch is closed.

Installation Guide ECL Comfort 310, application A333

5.12 Water meter


Applications A333.2 / A333.3

A water meter, F1, can measure the amount of refill water injected into the heating installation.

The water flow at F1 is measured by means of:

- * a flow meter, giving pulses to "Pulse 1" on the ECA 32 module or
- * a flow meter, connected to the M-Bus terminals

The water amount is displayed in m³.



MENU > Settings > Water meter

CW consump. (A333.2 / A333.3)		Read-out
Circuit	Setting range	Factory setting
1	-	-
Amount of refill water injected into the heating installation. The displayed value is in m ³ .		

MENU > Settings > Water meter

Pulse value (A333.2 / A333.3)		13513
Circuit	Setting range	Factory setting
1	0.1 . . . 1000.0 l	10.0 l
Setting of the value of each pulse from the water (flow) meter. This parameter is used when the water meter is connected to the "Pulse 1" on the ECA 32 module.		

MENU > Settings > Water meter

Preset (A333.2 / A333.3)		13514
Circuit	Setting range	Factory setting
1	OFF / ON	OFF
Is used for resetting the measured water consumption (registered by the cold water meter). Via the Modbus communication a value can be preset to a defined value, for example if the water meter is replaced.		

OFF: Normal status.

ON: The registered amount of refill water is reset to 0 (zero).
The setting returns to OFF.

Installation Guide ECL Comfort 310, application A333

5.13 Flow meter


Applications A333.2 / A333.3

A flow meter, F2, can measure the circulating water flow in the heating installation.

The flow at F2 is measured by means of:

- * a flow meter, giving a 0 - 10 volt signal and applied to S13 on the ECA 32 module or
- * a flow meter, giving pulses and applied to "Pulse 2" on the ECA 32 module or
- * a flow meter, connected to the M-Bus terminals.

The water flow can be displayed in l / h (liters / hour) or m³ / h (cubic meters / hour).



MENU > Settings > Flow meter

Actual (A333.2 / A333.3)		Read-out
Circuit	Setting range	Factory setting
1	-	*)
<p>Actual flow in the heating installation. The displayed value is in l / h. Flow meter F2 giving a 0 - 10 volt signal: The voltage signal is applied to the input S13 and is converted to the displayed flow value. Access to conversion (scale) settings.</p>		

*) 2.0 volt = 0 l/h, 10.0 volt = 1000 l/h

The flow is measured by means of a 0 - 10 volt signal.

The measured voltage must be converted to a flow value by the controller.


The following procedure sets up the conversion:
Push the dial to see the graph and enter the value sets for the 2 input voltages and related flow values.
Flow value range: 0 ... 1000 l/h.

The factory set voltage values (2.0 volt and 10.0 volt) can be changed in the following two separate menus "Low X" and "High X".

Factory settings: 2.0, 0 (= 2.0 V / 0 l/h) and 10.0, 1000 (= 10.0 V / 1000 l/h)

This means that the "Flow" is 0.0 l/h at 2.0 V and 1000 l/h at 10.0 V.

Typically, the higher the voltage, the higher the displayed flow.



X = Volt

Y = Liter / hour




This scaling menu is always displayed, regardless a flow signal is applied.
The flow is indicated as 0.0 l/h when the flow signal is not applied.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Flow meter


Low X (A333.2 / A333.3)		17607
Circuit	Setting range	Factory setting
1	0.0 . . . 10.0 V	2.0 V
Definition of which voltage value corresponds to which water flow value. The voltage (as a 0 - 10 volt signal) comes from a flow meter and is applied to input S13 (ECA 32). This input voltage is converted to display a water flow value (in m ³ / h). See also "Actual" and "High X".		



X = Volt
 Y = Flow (m³ / h)
 # 1 # = Low X

MENU > Settings > Flow meter

High X (A333.2 / A333.3)		17608
Circuit	Setting range	Factory setting
1	0.0 . . . 10.0 V	10.0 V
Definition of which voltage value corresponds to which water level value. The voltage (as a 0 - 10 volt signal) comes from a flow meter and is applied to input S13 (ECA 32). This input voltage is converted to display a water flow value (in m ³ / h). See also "Actual" and "Low X".		



X = Volt
 Y = Flow (m³ / h)
 # 1 # = High X

MENU > Settings > Flow meter

Input type (A333.2 / A333.3)		17109
Circuit	Setting range	Factory setting
1	AM1 / IM1 / EM1 . . . EM5 / OFF	OFF
Setting of the signal type from the flow meter F2.		

AM1: F2 sends analogue signal (0 - 10 volt), applied to S13 on ECA 32.

IM1: F2 sends pulse signal, applied to "Pulse 2" on ECA 32.

EM1 - EM5: F2 sends signal via M-Bus.

OFF: No F2 signal.

Installation Guide ECL Comfort 310, application A333

MENU > Settings > Flow meter

Pulse (A333.2 / A333.3)		17114
Circuit	Setting range	Factory setting
1	OFF / 1 . . . 9999 l	OFF
Choice of flow meter type. Setting of the value of each pulse from the flow meter. This parameter is used when the flow meter is connected to the "Pulse 2" on the ECA 32 module.		

OFF: Flow signal comes from an analogue meter or an M-bus connected meter.

1 - 9999: Setting of the value of each pulse from the flow meter.

MENU > Settings > Flow meter

Units (A333.2 / A333.3)		17115
Circuit	Setting range	Factory setting
1	l/h / m ³ /h	l/h
Setting of desired unit for the read-out of actual flow.		

Installation Guide ECL Comfort 310, application A333

5.14 S7, S8, S9, S10 pressure


Pressure measuring

The pressures at S7, S8, S9 and S10 are measured by means of pressure transmitters, all giving a 0 - 10 volt signal in relation to the measured pressure.

Alternatively, other pressure transmitter types can give a 4 - 20 mA signal in relation to the measured pressure.

As described in the section "Electrical connections, Pt 1000 temperature sensors and signals" the 4 - 20 mA can be sent through (for example) a 500 ohm resistor in order to convert the current signal to a voltage signal. (4 - 20 mA through a resistor of 500 ohm gives a voltage of 2 - 10 volt).

In this section the set-up procedure for pressure transmitters S7, S8, S9 and S10 is described commonly.



Overview, pressures in an A333 application:

Name:	Place:	Description:
S7	Primary supply	for monitoring purpose
S8	Primary return	for monitoring purpose
S9	Secondary flow	mandatory for circulation pump control
S10	Secondary return	mandatory for refill water function and circulation pump control

Installation Guide ECL Comfort 310, application A333

MENU > Settings > S7 (S8, S9, S10) pressure

Pressure (S7, S8, S9, S10)		Read-out
Circuit	Setting range	Factory setting
1	-	*)
<p>The pressure is indicated as a value measured in bar. A 0 - 10 volt signal comes directly from a pressure transmitter (voltage output) or converted by means of a resistor from a pressure transmitter (current output). The voltage signal is applied to the input in question and is converted to the displayed pressure value. Access to conversion (scale) settings.</p>		

*) 2.0 volt = 0.0 bar, 10.0 volt = 20.0 bar


The pressure is measured by means of a 0 - 10 volt signal. The measured voltage must be converted to a pressure value by the controller.

The following procedure sets up the conversion:
Push the dial to see the graph and enter the value sets for the 2 input voltages and related pressure values.
Pressure value range: 0.0 ... 25.0 bar.

The factory set voltage values (2.0 volt and 10.0 volt) can be changed in the following two separate menues "Low X" and "High X".

Factory settings: 2.0, 0 (= 2.0 V / 0 l/h) and 10.0, 1000 (= 10.0 V / 1000 l/h)

This means that the "Pressure" is 00 bar at 2.0 V and 2.0 bar at 10.0 V. Typically, the higher the voltage, the higher the displayed pressure.



X = Volt

Y = Pressure (bar)



This scaling menu is always displayed, regardless a pressure signal is applied.
The pressure is indicated as 0.0 bar when the pressure signal is not applied.

ID no. overview, S7, S8, S9 and S10 pressure:

	Filter constant	Low X	High X
S7	14113	14607	14608
S8	13113	13607	13608
S9	12113	12607	12608
S10	11113	11607	11608

MENU > Settings > S7 (S8, S9, S10) pressure

Filter constant (S7, S8, S9, S10)		1x113
Circuit	Setting range	Factory setting
1	1 - 250	4
<p>The filter constant dampens the pressure signal from the pressure transmitter in order to make a stable read-out and related functions.</p>		


1: Minor dampening (low filter constant)

250: Major dampening (high filter constant)

Installation Guide ECL Comfort 310, application A333

MENU > Settings > S7 (S8, S9, S10) pressure


Low X (S7, S8, S9, S10)		1x607
Circuit	Setting range	Factory setting
1	0.0 . . . 10.0 V	2.0 V
Definition of which voltage value corresponds to which pressure value. The voltage (as a 0 - 10 volt signal) comes from a pressure transmitter and is applied to input S7 (S8, S9, S10). This input voltage is converted to display a pressure value (in bar). See also "Pressure" and "High X".		



X = Volt
 Y = Pressure (bar)
 # 1 # = Low X

MENU > Settings > S7 (S8, S9, S10) pressure

High X (S7, S8, S9, S10)		1x608
Circuit	Setting range	Factory setting
1	0.0 . . . 10.0 V	10.0 V
Definition of which voltage value corresponds to which pressure value. The voltage (as a 0 - 10 volt signal) comes from a pressure transmitter and is applied to input S7 (S8, S9, S10). This input voltage is converted to display a pressure value (in bar). See also "Pressure" and "Low X".		



X = Volt
 Y = Pressure (bar)
 # 1 # = High X

Installation Guide ECL Comfort 310, application A333

5.15 Alarm

The alarm function activates A1 (relay 6). The alarm relay can activate a lamp, a horn, an input to an alarm transmitting device etc.

The alarm relay is activated

- as long as the alarm reason is present (automatic reset) or
- even the alarm reason has disappeared (manual reset)

Alarm, possibilities:

Name:	Description:	Reset:
Temp. monitor	Actual flow temperature differs from the desired flow temperature.	Automatic
Refill tank (A333.2, A333.3)	Too low or too high water level in refill water storage tank.	Manual
S7 . . . S10 pressure	Too low or too high pressure.	Automatic
Low pressure	Too low pressure at S10.	Automatic
Temperature sensor input	Accidently break or short-circuit of connected temperature sensor.	Manual



Resetting an alarm, in general:

MENU > Alarm > Alarm overview: Look for alarm symbol in specific line.
(Example: "3: Pump 1")
Push dial


MENU > Alarm > Temp. monitor

Upper difference 11147		
Circuit	Setting range	Factory setting
1	OFF / 1 ... 30 K	OFF
The alarm is activated if the actual flow temperature increases more than the set difference (acceptable temperature difference above the desired flow temperature). See also 'Delay'.		

OFF: The alarm function is not active.

1 ... 30 K: The alarm function is active if the actual temperature gets above the acceptable difference.

Flow temp. °C




MENU > Alarm > Temp. monitor

Lower difference 11148		
Circuit	Setting range	Factory setting
1	OFF / 1 ... 30 K	OFF
The alarm is activated if the actual flow temperature decreases more than the set difference (acceptable temperature difference below the desired flow temperature). See also 'Delay'.		

OFF: The alarm function is not active.

1 ... 30 K: The alarm function is active if the actual temperature gets below the acceptable difference.

Flow temp. °C




Installation Guide ECL Comfort 310, application A333

MENU > Alarm > Temp. monitor

Delay		11149
Circuit	Setting range	Factory setting
1	1 ... 99 m	10 m

If an alarm condition from either 'Upper difference' or 'Lower difference' is present for a longer time than the set delay (in min.), the alarm function is activated.

1 ... 99 m: The alarm function will be activated if the alarm condition remains after the set delay.



MENU > Alarm > Temp. monitor

Lowest temp.		11150
Circuit	Setting range	Factory setting
1	10 ... 50 °C	30 °C

The alarm function will not be activated if the desired flow / duct temperature is lower than the set value.



If the cause of the alarm disappears, the alarm indication and output also disappear.

MENU > Alarm > Refill tank

Alarm high (A333.2 / A333.3)		16614
Circuit	Setting range	Factory setting
1	0.0 . . . 25.0 m	25.0 m

Alarm is activated when the refill water storage tank level (in meter) gets higher than the set value.
See also: "Alarm low" (ID no. 16615) and "Alarm time-out" (ID no. 16617).

0.0 - 25.0: Set the high alarm level



When the "Alarm high" or "Alarm Low" alarm is activated:

- * the alarm symbol appears in the display
- * the refill water tank valve V3 closes
- * the refill water valve V1 closes
- * the refill water pump stops

If the alarm reason disappears:

- * the alarm must be reset manually

Resetting an alarm:


MENU > Alarm > Alarm overview > "5: Refill tank": Push dial

Installation Guide ECL Comfort 310, application A333

MENU > Alarm > Refill tank

Alarm low (A333.2 / A333.3)		16615
Circuit	Setting range	Factory setting
1	0.0 . . . 25.0 m	0.0 m
Alarm is activated when the refill water storage tank level (in meter) gets lower than the set value. See also: "Alarm high" (ID no. 16614) and "Alarm time-out" (ID no. 16617).		

0.0 - 25.0: Set the low alarm level.




- X = Time
- Y = Level
- # 1 # = Actual level
- # 2 # = Alarm high
- # 3 # = Alarm low
- # 4 # = Alarm time-out

MENU > Alarm > Refill tank

Alarm time-out (A333.2 / A333.3)		16617
Circuit	Setting range	Factory setting
1	0 . . . 250 s	15 s
If an alarm condition from either 'Alarm high' or 'Alarm low' is present for a longer time than the set Alarm time-out (in seconds), the alarm function is activated. See also: "Alarm high" (ID no. 16614) and "Alarm low" (ID no. 16615).		

0 - 250: Set the time-out time.



- X = Time
- Y = Level
- # 1 # = Actual level
- # 2 # = Alarm high
- # 3 # = Alarm low
- # 4 # = Alarm time-out

ID no. overview for S7, S8, S9 and S10 alarm:

	Alarm high	Alarm low	Alarm time-out
S7	14614	14615	14617
S8	13614	13615	13617
S9	12614	12615	12617
S10	11614	11615	11617

Installation Guide ECL Comfort 310, application A333

MENU > Alarm > S7 (S8, S9, S10) pressure

Alarm high		1x614
Circuit	Setting range	Factory setting
1	0.0 . . . 25.0 bar	25.0 bar
Alarm is activated when the pressure (in bar) gets higher than the set value.		

0.0 - 25.0: Set the high alarm level

MENU > Alarm > S7 (S8, S9, S10) pressure

Alarm low		1x615
Circuit	Setting range	Factory setting
1	0.0 . . . 25.0 bar	25.0 bar
Alarm is activated when the pressure (in bar) gets lower than the set value.		

0.0 - 25.0: Set the low alarm level.

MENU > Alarm > S7 (S8, S9, S10) pressure

Alarm time-out		1x617
Circuit	Setting range	Factory setting
1	0 . . . 100 m	10 m
If an alarm condition from either 'Alarm high' or 'Alarm low' is present for a longer time than the set Alarm time-out (in minutes), the alarm function is activated.		

0 - 100: Set the time-out time.

MENU > Alarm > Low pressure

Alarm low		15615
Circuit	Setting range	Factory setting
1	0.0 . . . 25.0 bar	25.0 bar
Alarm is activated when the pressure (in bar) at S10 gets lower than the set value. See also "Alarm time-out" (ID no. 15617).		

0.0 - 25.0: Set the low alarm level



When the "Low pressure" alarm is activated:

- * the alarm symbol appears in the display
- * the control valve M1 closes
- * the circulation pump stops

If the "Low pressure" alarm reason disappears:

- * the alarm symbol disappears in the display
- * the control valve M1 works normal
- * the circulation pump starts

Installation Guide ECL Comfort 310, application A333

MENU > Alarm > Low pressure

Alarm time-out		15617
Circuit	Setting range	Factory setting
1	0 . . . 250 s	10 s
<p><i>If the alarm condition from 'Alarm low' is present for a longer time than the set Alarm time-out (in seconds), the alarm function is activated. See also "Alarm low" (ID no. 15615).</i></p>		








0 - 100: Set the time-out time.

6.0 Common controller settings

6.1 Introduction to ‘Common controller settings’

Some general settings which apply to the entire controller are located in a specific part of the controller.

To enter ‘Common controller settings’:

Action:	Purpose:	Examples:
	Choose ‘MENU’ in any circuit	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose ‘Common controller settings’	
	Confirm	

Circuit selector



Installation Guide ECL Comfort 310, application A333

6.2 Time & Date

It is only necessary to set the correct date and time in connection with the first use of the ECL Comfort controller or after a power break of more than 72 hours.

The controller has a 24 hour clock.

Aut. daylight (Daylight saving time changeover)

YES: The controller's built-in clock automatically changes + / - one hour on the standardized days for daylight saving time changeover for Central Europe.

NO: You change manually between summer and winter time by setting the clock backward or forward.



When controllers are connected as slaves in a master / slave system (via ECL 485 communication bus), they will receive 'Time & Date' from the master.

Installation Guide ECL Comfort 310, application A333

6.3 Holiday


























This section describes the function in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

There is a holiday program for each circuit and a holiday program for the common controller.

Each holiday program contains one or more schedules. Each schedule can be set to a start date and an end date. The set period starts on the start date at 00.00 and stops on the end date at 00.00.

Selectable modes are Comfort, Saving, Frost protection or Comfort 7-23 (before 7 and after 23, the mode is scheduled).

How to set your holiday schedule:




Action:	Purpose:	Examples:
	Choose 'MENU'	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose a circuit or 'Common controller settings'	
	Heating	
	DHW	
	Common controller settings	
	Confirm	
	Go to 'Holiday'	
	Confirm	
	Choose a schedule	
	Confirm	
	Confirm choice of mode selector	
	Choose mode	
	· Comfort	
	· Comfort 7-23	
	· Saving	
	· Frost protection	
	Confirm	
	Enter the start time first and then the end time	
	Confirm	
	Go to 'Menu'	
	Confirm	
	Choose 'Yes' or 'No' in 'Save'. Choose the next schedule, if required	



The holiday program in the 'Common controller settings' is valid for all circuits. The holiday program can also be set individually in the heating or DHW circuits.



The end date must be at least be one day later than the start date.



Installation Guide ECL Comfort 310, application A333

The ECA 30 / 31 cannot override the holiday schedule of the controller temporarily.

However, it is possible to make use of the following options from the ECA 30 / 31 when the controller is in scheduled mode:



Day off



Holiday



Relaxing (extended comfort period)



Going out (extended saving period)



Energy-saving trick:
Use 'Going out' (the extended saving period) for airing purposes (e.g. for ventilating the rooms by means of fresh air from open windows).



Connections and setup procedures for ECA 30 / 31:
See section 'Miscellaneous'.



Quick guide "ECA 30 / 31 to override mode":
1. Go to ECA MENU
2. Move cursor to "Clock" symbol
3. Select the "Clock" symbol
4. Choose and select one of 4 override functions
5. Below the override symbol: Set hours or date

Installation Guide ECL Comfort 310, application A333

6.4 Input overview

This section describes the function in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The input overview is located in the common controller settings.

This overview will always show you the actual temperatures in the system (read-only).

MENU 112	
Input overview:	
► Outdoor T	7.0 °C
Outdoor acc. T	5.8 °C
Heat return T	35.5 °C
Heat flow T	67.9 °C
DHW flow T	68.6 °C



"Outdoor acc. T" means "Accumulated outdoor temperature" and is a calculated value in the ECL Comfort controller.

Installation Guide ECL Comfort 310, application A333

6.5 Log

This section describes the function in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The log function (temperature history) allows you to monitor the logs of today, yesterday, the past 2 days as well as the past 4 days for the connected sensors.

There is a log display for the relevant sensor, showing the measured temperature.

The log function is only available in the 'Common controller settings'.

Example 1:

1 day log for yesterday showing the development in outdoor temperature during the past 24 hours.

Example 2:




Today's log for the actual heating flow temperature as well as the desired temperature.

Example 3:

Yesterday's log for the DHW flow temperature as well as the desired temperature.

MENU 113
Log:
 ► Outdoor T
 Room T & desired
 Heating flow & des.
 DHW flow & des.
 Heat return T & limit

Log 113
Outdoor T:
 ► Log today
 Log yesterday
 Log 2 days
 Log 4 days




6.6 Output override

This section describes the function in general for the ECL Comfort 210 / 310 series. The shown displays are typical and not application related. They might differ from the displays in your application.

The output override is used to disable one or more of the controlled components. This could among others be useful in a service situation.

Action:	Purpose:	Examples:
	Choose 'MENU' in any of the overview displays	MENU
	Confirm	
	Choose the circuit selector at the top right corner in the display	
	Confirm	
	Choose common controller settings	
	Confirm	
	Choose 'Output override'	
	Confirm	
	Choose a controlled component	M1, P1 etc.
	Confirm	
	Adjust the status of the controlled component: Motorized control valve: AUTO, STOP, CLOSE, OPEN Pump: AUTO, OFF, ON	
	Confirm status change	



When the selected controlled component (output) is not 'AUTO', the ECL Comfort controller does not control the component in question (pump or motorized control valve e.g.). Frost protection is not active.

When output override of a controlled component is active the symbol '!' is shown to the right of the mode indicator in the enduser displays.


Application A333.3:
The motorized control valve M1 is controlled by a 0–10 volt (0–100%) signal. It can be set to AUTO or ON.
AUTO: Normal control (0–100%)
ON: The 0–10 volt signal is set to the %-value, set below the indication 'ON'.

Remember to change the status back again as soon as an override is not required any longer.

Installation Guide ECL Comfort 310, application A333

6.7 Key functions

New application	Erase application: Removes the existing application. As soon as the ECL key is inserted, another application can be chosen.
Application	Gives an overview over the application and its subtypes of the ECL key in question.
Factory setting	System settings: System settings are, among others, communication set-up, display brightness etc. User settings: User settings are, among others, desired room temperature, desired DHW temperature, schedules, heat curve, limitation values etc. Go to factory: Restores the factory settings.
Copy	To: Copy direction System settings User settings Start copying



A more detailed description of how to use the individual 'Key functions' can also be seen in 'Inserting the ECL application key'.



Key inserted / not inserted, description:

ECL Comfort 210 / 310, controller versions lower than 1.36:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; for 20 minutes settings can be changed.

ECL Comfort 210 / 310, controller versions 1.36 and up:

- Take out the application key; for 20 minutes settings can be changed.
- Power up the controller **without** the application key inserted; settings cannot be changed.

Installation Guide ECL Comfort 310, application A333

6.8 System

6.8.1 ECL version

In 'ECL version' you will always be able to find an overview of the data related to your electronic controller.

Please have this information available if you need to contact your Danfoss sales organization concerning the controller.

Information about your ECL Application Key can be found in 'Key functions' and 'Key overview'.

Code no.:	The Danfoss sales and order no. for the controller
Hardware:	Hardware version of the controller
Software:	Software version of the controller
Serial no.:	Unique number for the individual controller
Production week:	Week no. and year (WW.YYYY)

Example, ECL version

System	□□
ECL version:	
▶ Code no.	87H3040
Hardware	A
Software	P 1.01
Build no.	2693
Serial no.	123456789

6.8.2 Extension

ECL Comfort 310 only:
'Extension' will offer you information about additional modules, if any. An example could be the ECA 32 module.

6.8.3 Ethernet

The ECL Comfort 310 has a Modbus/TCP communication interface that allows the ECL controller to be connected to an Ethernet network. This allows remote access to the ECL 310 controller based on standard communication infrastructures.

In 'Ethernet' it is possible to set up the required IP addresses.

6.8.4 Portal config

The ECL Comfort 310 has a Modbus/TCP communication interface that allows the ECL controller to be connected to the internet.

Internet related parameters are set here.

6.8.5 M-bus config

The ECL Comfort 310 has an M-bus communication interface that allows energy meters to be connected as slaves.

M-bus related parameters are set here.

6.8.6 Energy Meters

The ECL Comfort 310 allows communication with up to 5 energy meters via M-bus. In 'Energy Meters' data can be read the from M-bus connected energy meters


Installation Guide ECL Comfort 310, application A333

6.8.7 Raw input overview

Measured temperatures, input status and voltages are displayed.


In addition, a detection of malfunctions can be chosen for activated temperature inputs.

Monitoring the sensors:



Choose the sensor which measures a temperature, for example the S5. When the dial is pressed, a magnifying glass  appears in the selected line. The S5 temperature is now being monitored.

Alarm indication:

Should the connection to the temperature sensor be disconnected, short-circuited or the sensor itself be defective, the alarm function is activated.

In the "Raw input overview" an alarm symbol  is shown at the defective temperature sensor in question.

Resetting the alarm:

Choose the sensor (S number) for which you want to clear the alarm. Press the dial. The magnifying glass  and alarm symbols  disappear.

When the dial is pressed again, the monitoring function is reactivated.




The temperature sensor inputs have a measuring range from -60 ... 150 °C.

If a temperature sensor or its connection breaks, the value indication is " - - ".


If a temperature sensor or its connection is short-circuited, the value indication is " - - - ".

6.8.8 Display

Backlight (display brightness)		60058
Circuit	Setting range	Factory setting
	0 ... 10	5
Adjust the brightness of the display.		

0: Weak backlight.

10: Strong backlight.

Contrast (display contrast)		60059
Circuit	Setting range	Factory setting
	0 ... 10	3
Adjust the contrast of the display.		

0: Low contrast.

10: High contrast.

Installation Guide ECL Comfort 310, application A333

6.8.9 Communication

Modbus addr.		38
Circuit	Setting range	Factory setting
	1 ... 247	1
Set the Modbus address if the controller is part of a Modbus network.		

1 ... 247: Assign the Modbus address within the stated setting range.

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Factory setting
	0 ... 15	15
This setting is relevant if more controllers are working in the same ECL Comfort system (connected via the ECL 485 communication bus) and / or Remote Control Units (ECA 30 / 31) are connected.		

- 0:** The controller works as slave.
The slave receives information about the outdoor temperature (S1), system time, and signal for DHW demand in the master.
- 1 ... 9:** The controller works as slave.
The slave receives information about the outdoor temperature (S1), system time, and signal for DHW demand in the master. The slave sends information about the desired flow temperature to the master.
- 10 ... 14:** Reserved.
- 15:** The ECL 485 communication bus is active.
The controller is master. The master sends information about the outdoor temperature (S1) and system time. Connected Remote Control Units (ECA 30 / 31) are powered.

The ECL Comfort controllers can be connected via the ECL 485 communication bus to perform a larger system (the ECL 485 communication bus can connect to max. 16 devices).

Each slave must be configured with its own address (1 ... 9).

However, more slaves can have the address 0 if they only have to receive information about outdoor temperature and system time (listeners).

Service Pin		2150
Circuit	Setting range	Factory setting
	0 / 1	0
This setting is only used in connection with set-up of Modbus communication.		
Not applicable for the time being and reserved for future use!		



The total cable length of max. 200 m (all devices incl. the internal ECL 485 communication bus) should not be exceeded.
Cable lengths of more than 200 m may cause noise sensibility (EMC).



An ECL Comfort controller 210 / 310, type B (without display and dial) cannot be assigned to the address 0 (zero).

Installation Guide ECL Comfort 310, application A333

Ext. reset		2151
Circuit	Setting range	Factory setting
<input type="checkbox"/>	0 / 1	0
This setting is only used in connection with set-up of Modbus communication.		

0: Reset not activated.

1: Reset.

6.8.10 Language

Language		2050
Circuit	Setting range	Factory setting
<input type="checkbox"/>	English / 'Local'	English
Choose your language.		



Local language is selected during installation. If you want to change to another local language, the application must be reinstalled. However, it is always possible to change between the local language and English.

Installation Guide ECL Comfort 310, application A333

7.0 Miscellaneous

7.1 ECA 30 / 31 setup procedures

ECA 30 (code no. 087H3200) is a remote control unit with built-in room temperature sensor.

ECA 31 (code no. 087H3201) is a remote control unit with built-in room temperature sensor and humidity sensor (relative humidity).

An external room temperature sensor can be connected to both types to substitute the built-in sensor.

An external room temperature sensor will be recognized at ECA 30 / 31 power-up.

Connections: See the section 'Electrical connections'.

Max. two ECA 30 / 31 can be connected to one ECL controller or a system (master-slave) consisting of several ECL controllers connected on the same ECL 485 bus. In the master-slave system only one of the ECL controllers is master. The ECA 30 / 31 can, among others, be set to:

- monitor and set the ECL controller remotely
- measure the room temperature and (ECA 31) humidity
- extend comfort / saving period temporarily

After application upload in the ECL Comfort controller, the remote control unit ECA 30 / 31 will after approx. one minute ask to 'Copy application'.

Confirm this in order to upload the application to the ECA 30 / 31.

Menu structure

The menu structure of ECA 30 / 31 is an "ECA MENU" and the ECL menu, copied from the ECL Comfort controller.

The ECA MENU contains:

- ECA settings
- ECA system
- ECA factory

ECA settings: Offset adjustment of the measured room temperature.

Offset adjustment of relative humidity (ECA 31 only).

ECA system: Display, communication, override settings and version info.

ECA factory: Erase of all applications in the ECA 30 / 31, restore to factory settings, reset of ECL address and firmware update.

Part of the ECA 30 / 31 display in ECL mode:

MENU

— □ — — —

Danfoss
087H3200/01

Part of the ECA 30 / 31 display in ECA mode:

ECA MENU

□ — — — —

Danfoss
087H3200/01



If only the "ECA MENU" is shown, it can indicate that the ECA 30 / 31 is not having correct communication address.
See ECA MENU > ECA system > ECA communication: ECL address.
In most cases the ECL address setting must be "15".



Regarding ECA settings:
When ECA 30 / 31 is not used as remote unit, the offset adjustments menu(s) are not present.

Installation Guide ECL Comfort 310, application A333

The ECL menus are as described for the ECL controller.

Most of the settings done directly in the ECL controller can be done via the ECA 30 / 31 too.



All settings can be seen even if the application key is not inserted in the ECL controller.
For changing settings, the application key must be inserted.

The Key overview (MENU > 'Common controller settings' > 'Key functions') does not show the applications of the key.



The ECA 30 / 31 will display this information (an X on the ECA 30 / 31 symbol) if the application in the ECL controller does not comply with the ECA 30 / 31:



In the example 1.10 is current version and 1.42 is desired version.



Display part of ECA 30 / 31:



This display indicates that an application has not been uploaded or the communication to the ECL controller (master) is not working properly. An X on the ECL controller symbol indicates wrong setup of communication addresses.

When ECA 30 / 31 is in ECA MENU mode, the date and measured room temperature is displayed.

ECA MENU > ECA settings > ECA sensor

Room T Offset	
Setting range	Factory setting
-10.0 ... 10.0 K	0.0 K
The measured room temperature can be corrected with a number of Kelvin. The corrected value is used by the heating circuit in the ECL controller.	

Minus

value: The indicated room temperature is lower.

0.0 K: No correction of the measured room temperature.

Plus

value: The indicated room temperature is higher.

Example:

Room T offset:	0.0 K
Displayed room temperature:	21.9 °C
Room T offset:	1.5 K
Displayed room temperature:	23.4 °C

Installation Guide ECL Comfort 310, application A333

ECA MENU > ECA settings > ECA sensor

RH offset (ECA 31 only)	
Setting range	Factory setting
-10.0 ... 10.0 %	0.0 %
The measured relative humidity can be corrected with a number of %-values. The corrected value is used by the application in the ECL controller.	

Minus value: The indicated relative humidity is lower.

0.0 %: No correction of the measured relative humidity.

Plus value: The indicated relative humidity is higher.

Example:

RH offset:	0.0 %
Displayed relative humidity:	43.4 %
RH offset:	3.5 %
Displayed relative humidity:	46.9 %

ECA MENU > ECA system > ECA display

Backlight (display brightness)	
Setting range	Factory setting
0 ... 10	5
Adjust the brightness of the display.	

0: Weak backlight.

10: Strong backlight.

ECA MENU > ECA system > ECA display

Contrast (display contrast)	
Setting range	Factory setting
0 ... 10	3
Adjust the contrast of the display.	

0: Low contrast.

10: High contrast.

ECA MENU > ECA system > ECA display

Use as remote	
Setting range	Factory setting
OFF / ON	*)
ECA 30 / 31 can act as a simple or normal remote control for the ECL controller.	

OFF: Simple remote control, no room temperature signal.

ON: Remote control, room temperature signal is available.

***):** Differently, depending on chosen application.



When set to OFF: The ECA menu shows date and time.

When set to ON: The ECA menu shows date and room temperature (and for ECA 31 relative humidity).

Installation Guide ECL Comfort 310, application A333

ECA MENU > ECA system > ECA communication

Slave addr. (Slave address)	
Setting range	Factory setting
A / B	A
<i>The setting of 'Slave addr.' is related to the setting 'ECA address' in the ECL controller. In the ECL controller it is selected from which ECA 30 / 31 unit the room temperature signal is received.</i>	

A: The ECA 30 / 31 has the address A.

B: The ECA 30 / 31 has the address B.



For installation of an application in an ECL Comfort 210 / 310 controller the 'Slave addr.' must be A.



If two ECA 30 / 31 are connected in the same ECL 485 bus system, the 'Slave addr.' must be "A" in the one ECA 30 / 31 unit and "B" in the other.

ECA MENU > ECA system > ECA communication

Connection addr. (Connection address)	
Setting range	Factory setting
1 ... 9 / 15	15
<i>Setting of the address to which ECL controller the communication must run.</i>	

1 .. 9: Slave controllers.

15: Master controller.



An ECA 30 / 31 can in an ECL 485 bus system (master – slave) be set to communicate, one by one, with all addressed ECL controllers.



Example:

Connection addr. = 15:	The ECA 30 / 31 communicates with the ECL master controller.
Connection addr. = 2:	The ECA 30 / 31 communicates with the ECL controller with address 2.



There must be a master controller present in order to broadcast time and date information.



An ECL Comfort controller 210 / 310, type B (without display and dial) cannot be assigned to the address 0 (zero).

Installation Guide ECL Comfort 310, application A333

ECA MENU > ECA system > ECA override

Override addr. (Override address)	
Setting range	Factory setting
OFF / 1 ... 9 / 15	OFF
The feature 'Override' (to extended comfort or saving period or holiday) must be addressed to the ECL controller in question.	

OFF: Override not possible.

1 .. 9: Address of slave controller for override.

15: Address of master controller for override.



Override functions:	Extended saving mode:	
	Extended comfort mode:	
	Holiday away from home:	
	Holiday at home:	



Override by means of settings in ECA 30 / 31 are cancelled if the ECL Comfort controller goes into holiday mode or is changed to another mode than scheduled mode.



The circuit in question for override in the ECL controller must be in scheduled mode.
See also the parameter 'Override circuit'.

Installation Guide ECL Comfort 310, application A333

ECA MENU > ECA system > ECA override

Override circuit	
Setting range	Factory setting
OFF / 1 ... 4	OFF
<i>The feature 'Override' (to extended comfort or saving period or holiday) must be addressed to the heating circuit in question.</i>	

OFF: No heating circuit is selected for override.

1 ... 4: The heating circuit number in question.



The circuit in question for override in the ECL controller must be in scheduled mode.
See also the parameter 'Override addr.'.



Example 1:

(One ECL controller and one ECA 30 / 31)		
Override of heating circuit 2:	Set 'Connection addr.' to 15	Set 'Override circuit' to 2

Example 2:

(Several ECL controllers and one ECA 30 / 31)		
Override of heating circuit 1 in ECL controller with the address 6:	Set 'Connection addr.' to 6	Set 'Override circuit' to 1



Quick guide "ECA 30 / 31 to override mode":

1. Go to ECA MENU
2. Move cursor to "Clock" symbol
3. Select the "Clock" symbol
4. Choose and select one of 4 override functions
5. Below the override symbol: Set hours or date
6. Below hours / date: Set desired room temperature for the override period

ECA MENU > ECA system > ECA version

ECA version (read-out only), examples	
Code no.	087H3200
Hardware	A
Software	1.42
Build no.	5927
Serial no.	13579
Production week	23.2012

The ECA version information is useful in service situations.

Installation Guide ECL Comfort 310, application A333

ECA MENU > ECA factory > ECA clear apps.

Erase all apps. (Erase all applications)
Erase all applications which are in the ECA 30 / 31. After erasing, the application can be uploaded again.

NO: The erase procedure is not done.

YES: The erase procedure is done (await 5 sec.).



After the erase procedure, a pop-up in the display indicates "Copy application". Choose "Yes". Hereafter the application is uploaded from the ECL controller. An upload bar is shown.

ECA MENU > ECA factory > ECA default

Restore factory
The ECA 30 / 31 is set back to factory settings.
Affected settings by the restore procedure:
<ul style="list-style-type: none"> • Room T offset • RH offset (ECA 31) • Backlight • Contrast • Use as remote • Slave addr. • Connection addr. • Override addr. • Override circuit • Override mode • Override mode end time

NO: The restore procedure is not done.

YES: The restore procedure is done.

ECA MENU > ECA factory > Reset ECL addr.

Reset ECL addr. (Reset ECL address)
If none of the connected ECL Comfort controllers has the address 15, the ECA 30 / 31 can set all connected ECL controllers on the ECL 485 bus back to address 15.

NO: The reset procedure is not done.

YES: The reset procedure is done (await 10 sec.).



The ECL 485 bus related address of the ECL controller is found: MENU > 'Common controller settings' > 'System' > 'Communication' > 'ECL 485 addr.'



The "Reset ECL addr." cannot be activated if one or more of the connected ECL Comfort controllers has the address 15.

Installation Guide ECL Comfort 310, application A333

ECA MENU > ECA factory > Update firmware

Update firmware

The ECA 30 / 31 can be updated with new firmware (software). The firmware comes with the ECL application key, when the key version is at least 2.xx. If no new firmware is available, a symbol of the application key is displayed with an X.

NO: The updating procedure is not done.

YES: The updating procedure is done.



The ECA 30 / 31 automatically verifies if a new firmware is present on the application key in the ECL Comfort controller. The ECA 30 / 31 is automatically updated at new application upload in the ECL Comfort controller.

The ECA 30 / 31 is not automatically updated when connected to an ECL Comfort controller with uploaded application. A manual update is always possible.



Quick guide "ECA 30 / 31 to override mode":

1. Go to ECA MENU
2. Move cursor to "Clock" symbol
3. Select the "Clock" symbol
4. Choose and select one of 4 override functions
5. Below the override symbol: Set hours or date
6. Below hours / date: Set desired room temperature for the override period

Installation Guide ECL Comfort 310, application A333

7.2 Several controllers in the same system

When ECL Comfort controllers are interconnected by means of the ECL 485 communication bus (cable type: 2 x twisted pair), the master controller will broadcast the following signals to the slave controllers:

- Outdoor temperature (measured by S1)
- Time and date
- DHW tank heating / charging activity

Furthermore, the master controller can receive information about:

- the desired flow temperature (demand) from slave controllers
- and (as from ECL controller version 1.48) DHW tank heating / charging activity in slave controllers


Situation 1:


SLAVE controllers: How to make use of the outdoor temperature signal sent from the MASTER controller

The slave controllers only receive information about outdoor temperature and date / time.

SLAVE controllers:

Change the factory set address from 15 to address 0.

- In , go to System > Communication > ECL 485 addr:




In a system with MASTER / SLAVE controllers, only one MASTER controller with address 15 is allowed.

If by mistake more MASTER controllers are present in an ECL 485 communication bus system, decide which controller is to be MASTER. Change the address in the remaining controllers. However, the system will operate but not be stable with more than one MASTER controller.



In the MASTER controller, the address in 'ECL 485 addr. (master / slave address)'; ID no. 2048, must always be 15.

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Choose
	0 ... 15	0

Installation Guide ECL Comfort 310, application A333

Situation 2:

SLAVE controller: How to react on a DHW tank heating / charging activity sent from the MASTER controller

The slave receives information about a DHW tank heating / charging activity in the master controller and can be set to close the selected heating circuit.

ECL controller versions 1.48 (as from August 2013):

The master receives information about DHW tank heating / charging activity in the master controller itself and also slaves in the system.

This status is broadcasted to all ECL controllers in the system and each heating circuit can be set to close the heating.

SLAVE controller:

Set the desired function:

- In circuit 1 / circuit 2, go to 'Settings' > 'Application' > 'DHW priority':

DHW priority (closed valve / normal operation)		11052 / 12052
Circuit	Setting range	Choose
1 / 2	OFF / ON	OFF / ON

OFF: The flow temperature control remains unchanged during active DHW heating / charging in the master / slave system.

ON: The valve in the heating circuit is closed during active DHW heating / charging in the master / slave system.

Installation Guide ECL Comfort 310, application A333

Situation 3:

SLAVE controller: How to make use of the outdoor temperature signal and send information about the desired flow temperature back to the MASTER controller



In the MASTER controller, the address in 'ECL 485 addr. (master / slave address)'; ID no. 2048, must always be 15.

The slave controller receives information about outdoor temperature and date / time. The master controller receives information about the desired flow temperature from slave controllers with an address from 1 ... 9:

SLAVE controller:

- In , go to System > Communication > ECL 485 addr.
- Change the factory set address from 15 to an address (1 ... 9). Each slave must be configured with its own address.

ECL 485 addr. (master / slave address)		2048
Circuit	Setting range	Choose
	0 ... 15	1 ... 9

Furthermore, each slave can send information about the desired flow temperature (demand) in each circuit back to the master controller.

SLAVE controller:

- In the circuit in question, go to Settings > Application > Send desired T
- Choose ON or OFF.

Send desired T		11500 / 12500
Circuit	Setting range	Choose
1 / 2	OFF / ON	ON or OFF

OFF: Information about the desired flow temperature is not sent to the master controller.

ON: Information about the desired flow temperature is sent to the master controller.

MASTER controller:

- In the circuit 1, go to Settings > Application > Demand offset
- Change OFF to a value (for example 5 K) which is added to the highest demand (desired flow temperature) from the slaves.

Demand offset		11017
Circuit	Setting range	Choose
1	OFF / 1 ... 20 K	1 ... 20 K

7.3 Frequently asked questions



The definitions apply to the Comfort 210 as well as ECL Comfort 310 series. Consequently, you might come across expressions that are not mentioned in your guide.

The time shown in the display is one hour off?

See 'Time and Date'.

The time shown in the display is not correct?

The internal clock may have been reset, if there has been a power break for more than 72 hours.

Go to the 'Common controller settings' and 'Time & Date' to set the correct time.

The ECL Application Key is lost?

Switch the power off and on again to see the system type and the software generation of the controller or go to 'Common controller settings' > 'Key functions' > 'Application'. The system type (e.g. TYPE A266.1) and the system diagram is displayed.

Order a replacement from your Danfoss representative (e.g. ECL Application Key A266).

Insert the new ECL Application Key and copy your personal settings from the controller to the new ECL Application Key, if required.

The room temperature is too low?

Make sure that the radiator thermostat does not limit the room temperature.

If you still cannot obtain the desired room temperature by adjusting the radiator thermostats, the flow temperature is too low. Increase the desired room temperature (display with desired room temperature). If this does not help, adjust the 'Heat curve' ('Flow temp.').

The room temperature is too high during saving periods?

Make sure that the min. flow temperature limitation ('Temp. min.') is not too high.

The temperature is unstable?

Check that the flow temperature sensor is correctly connected and in the right place. Adjust the control parameters ('Control par.').

If the controller has a room temperature signal, see 'Room limit'.

The controller does not operate and the control valve is closed?

Check that the flow temperature sensor is measuring the correct value, see 'Daily use' or 'Input overview'.

Check the influence from other measured temperatures.

How to make an extra comfort period in the schedule?

You can set an additional comfort period by adding new 'Start' and 'Stop' times in 'Schedule'.

How to remove a comfort period in the schedule?

You can remove a comfort period by setting start and stop times to the same value.

How to restore your personal settings?

Please read the chapter concerning 'Inserting the ECL Application Key'.

How to restore the factory settings?

Please read the chapter concerning 'Inserting the ECL Application Key'.

Why can't the settings be changed?

The ECL Application Key has been removed.

Why can't an application be selected when inserting the ECL application key into the controller?

The actual application in the ECL Comfort controller must be deleted before a new application (subtype) can be selected.

How to react on alarms?

An alarm indicates that the system is not operating satisfactorily. Please contact your installer.

What does P and PI control mean?

P control: Proportional control.

By using a P control, the controller will change the flow temperature proportional to the difference between a desired and an actual temperature, e.g. a room temperature.

A P control will always have an offset which not will disappear over time.

PI control: Proportional and Integrating control.

A PI control does the same as a P control, but the offset will disappear over time.

A long 'Tn' will give a slow but stable control, and a short 'Tn' will result in a fast control but with a higher risk of instability.

7.4 Definitions



The definitions apply to the Comfort 210 as well as ECL Comfort 310 series. Consequently, you might come across expressions that are not mentioned in your guide.

Air duct temperature

Temperature measured in the air duct where the temperature is to be controlled.

Alarm function

Based on the alarm settings, the controller can activate an output.

Anti-bacteria function

For a defined period, the DHW temperature is increased in order to neutralize dangerous bacteria, e.g. Legionella.

Balance temperature

This setpoint is the basis for the flow / air duct temperature. The balance temperature can be adjusted by the room temperature, the compensation temperature and the return temperature. The balance temperature is only active if a room temperature sensor is connected.

Comfort operation

Normal temperature in the system controlled by the schedule. During heating the flow temperature in the system is higher to maintain the desired room temperature. During cooling the flow temperature in the system is lower to maintain the desired room temperature.

Comfort temperature

Temperature maintained in the circuits during comfort periods. Normally during daytime.

Compensation temperature

A measured temperature influencing the flow temperature reference / balance temperature.

Desired flow temperature

Temperature calculated by the controller on basis of the outdoor temperature and influences from the room and / or return temperatures. This temperature is used as a reference for the control.

Desired room temperature

Temperature which is set as the desired room temperature. The temperature can only be controlled by the ECL Comfort controller if a room temperature sensor is installed.

If a sensor is not installed, the set desired room temperature however still influences the flow temperature.

In both cases the room temperature in each room is typically controlled by radiator thermostats / valves.

Desired temperature

Temperature based on a setting or a controller calculation.

Dew point temperature

Temperature at which the humidity in the air condensates.

DHW circuit

The circuit for heating the domestic hot water (DHW).

Factory settings

Settings stored on the ECL Application Key to simplify the set up of your controller the first time.

Flow temperature

Temperature measured in the flow at any time.

Installation Guide ECL Comfort 310, application A333

Flow temperature reference

Temperature calculated by the controller on basis of the outdoor temperature and influences from the room and / or return temperatures. This temperature is used as a reference for the control.

Heat curve

A curve showing the relationship between actual outdoor temperature and required flow temperature.

Heating circuit

The circuit for heating the room / building.

Holiday schedule

Selected days can be programmed to be in comfort, saving or frost protection mode. Besides this, a day schedule with comfort period from 07.00 to 23.00 can be selected.

Humidity, relative

This value (stated in %) refers to the indoor moisture content compared to the max. moisture content. The relative humidity is measured by the ECA 31 and is used for the calculation of the dew point temperature.

Limitation temperature

Temperature that influences the desired flow / balance temperature.

Log function

The temperature history is displayed.

Master / slave

Two or more controllers are interconnected on the same bus, the master sends out e.g. time, date and outdoor temperature. The slave receives data from master and sends e.g. desired flow temperature value.

Modulating control (0 - 10 V control)

Positioning (by means of a 0 - 10 V control signal) of the actuator for the motorized control valve in order to control the flow.

Pt 1000 sensor

All sensors used with the ECL Comfort controller are based on the Pt 1000 type (IEC 751B). The resistance is 1000 ohm at 0 °C and it changes with 3.9 ohm / degree.

Optimization

The controller optimizes the start time of the scheduled temperature periods. Based on the outdoor temperature, the controller automatically calculates when to start in order to reach the comfort temperature at the set time. The lower the outdoor temperature, the earlier the start time.

Outdoor temperature trend

The arrow indicates the tendency, i.e. whether the temperature rises or falls.

Refill water function

If the measured pressure in the heating system is too low (e.g. due to a leakage), water can be supplemented.

Return temperature

The temperature measured in the return influences the desired flow temperature.

Room temperature sensor

Temperature sensor placed in the room (reference room, typically the living room) where the temperature is to be controlled.

Room temperature

Temperature measured by the room temperature sensor or the Remote Control Unit. The room temperature can only be controlled directly if a sensor is installed. The room temperature influences the desired flow temperature.

Schedule

Schedule for periods with comfort and saving temperatures. The schedule can be made individually for each week day and may consist of up to 3 comfort periods per day.

Saving temperature

Temperature maintained in the heating / DHW circuit during saving temperature periods.

Pump control

One circulation pump is working and the other is the spare circulation pump. After a set time, the roles are exchanged.

Weather compensation

Flow temperature control based on the outdoor temperature. The control is related to a user-defined heat curve.


2-point control

ON / OFF control e.g. circulation pump, change-over valve or damper control.

3-point control

Opening, closing or no action of the actuator for the motorized control valve. No action means that the actuator remains in its current position.

Installation Guide ECL Comfort 310, application A333



Installer:

By:

Date:

Installation Guide ECL Comfort 310, application A333

