







Generic Dual Path
Application Block
User Manual



About this Manual

Organization and Headings

To help you quickly find information in this manual, the material is divided into sections, topics, subtopics, and details, with descriptive headings set in **red type**. Section titles appear at the top of every page in **large red type**. Topic headings appear in the left-hand column in **bold red type**. Subtopic headings appear above the body text in **bold red type** and detail headings in *italic red type*.

References (example: See *Topic xyz*, page XX) are also formatted in *red italic type*. In Portable Document Format (PDF) files, these references are hyperlinks that jump to the corresponding document pages.

Tables, Illustrations, and Complementary Information

Tables, illustrations, and graphics in this manual are identified by titles set in *blue italic type* above each item. Complementary information such as notes, captions, and drawing annotations are also set in *blue type*.

Special Text Formatting

Controls and indicators are set in **bold black type**.

Black italic type is used in the text to emphasize important information, or to set off words and terms that are used in an unconventional manner or alternative context.

Table of Contents

A Table of Contents (TOC) appears on the next page. In the PDF version of this document, the TOC entries are hyperlinked.

Revision history

Revision	Date	Comment
Rev AB	November 2009	Supports software release 1.01

©2009 Sauer-Danfoss. All rights reserved.

Sauer-Danfoss accepts no responsibility for possible errors in catalogs, brochures and other printed material. Sauer-Danfoss reserves the right to alter its products without prior notice. This also applies to products already ordered provided that such alterations can be made without affecting agreed specifications.

All trademarks in this material are properties of their respective owners.

PLUS+1, GUIDE, and Sauer-Danfoss are trademarks of the Sauer-Danfoss Group. The PLUS+1 GUIDE, PLUS+1 Compliant, and Sauer-Danfoss logotypes are trademarks of the Sauer-Danfoss Group.



Generic Dual Path Application Block User Manual


Contents

Contents	3
Introduction	4
Page Symbols	5
Page Access.....	5
Additional Documentation.....	6
GDP_Application Block Signals	7
Input Signals	7
Output Signals.....	10
GDP Application.....	13
CoreParams Page	14
About Differential Steer Percent	16
GDP_Application Page	22
How to Access Socket Pages	25
DualPathSpdCtrl Socket Page.....	26
MaxCmdScale Socket Page	27
PowerDistr Socket Page.....	28
Trackstall Socket Page	29
Index	30

Generic Dual Path Application Block

User Manual

Introduction



This manual documents the **GDP_Application** (GDP = Generic Dual Path) block, which is designed for use in dual path applications.

The **GDP_Application** block receives steering and propel inputs. Based on these inputs, this block outputs left and right speed commands.

Logic within the **GDP_Application** block provides these core dual path functions:

- Differential steering ratios.
- Ramps applied during acceleration, deceleration, and braking.
- Upshift and downshift points for two-position motors.

The **GDP_Application** block also contains “socket pages” for optional “plug-ins.”


Plug-ins are software that can be used to increase the functionality of the **GDP_Application** block.

Plug-ins are packaged in pages that can be imported into and connected to matching socket pages within the **GDP_Application** block.

The following plug-ins are available for use in the **GDP_Application** block:

- **Temp_Derate** plug-in—the **GDP_Application** block uses this plug-in’s output to scale down its propel commands when hydraulic fluid becomes too hot. Scaling down slows down temperature increases and helps prevent damage to hydraulic systems.
- **Antistall** plug-in—the **GDP_Application** block uses this plug-in’s output to scale down speed commands to prevent heavy loads from stalling the engine.
- **Trackstall** plug-in—the **GDP_Application** block uses this plug-in’s output to limit the scaling of its speed commands by the **Antistall** plug-in. This scaling limitation maintains track tension and keeps tracks from completely stopping under antistall conditions.
- **Tracker** plug-in—the **GDP_Application** block applies this plug-in’s output to correct track speed errors caused by uneven loading, hydraulic leakage, and imperfect calibration.


Page Symbols



Page symbols indicate page properties:

- Plug—the page contains a plug-in. A plug-in is software that extends the functionality of an application.
- Key—an application that contains this page can only download to similarly keyed application hardware.

Page Access



Some pages are view disabled to completely limit or partially limit access to their contents.

- The contents of a completely view-disabled page cannot be viewed.
- Some pages inside a partially view-disabled page can be viewed.

View-disabled pages display a message when you try to enter them.


Additional Documentation

- PLUS+1 Controller Family Technical Information (Sauer-Danfoss part 520L0719)
- Recommended Machine Electronic Control System Start-up Procedures (Sauer-Danfoss part 11010667)
- PLUS+1 GUIDE Service Tool User Manual (Sauer-Danfoss part 520L0899)
- Generic Dual Path Subsystem Application User Manual (Sauer-Danfoss part 11061724)
- Generic Dual Path Subsystem Application Service Tool User Manual (Sauer-Danfoss part 11058326)
- PLUS+1 GUIDE Basic Function Blocks Library User Manual (Sauer-Danfoss part 10103409)
- Plug-in documentation:
 - Antistall Plug-in GUIDE Programming User Manual (Sauer-Danfoss part 11057258)
 - How to Tune the Antistall and Tracker Plug-ins User Manual (Sauer-Danfoss part 11060612)
 - Temperature Derate Plug-in GUIDE Programming User Manual (Sauer-Danfoss part 11057257)
 - Tracker Plug-in GUIDE Programming User Manual (Sauer-Danfoss part 11057260)
 - Trackstall Plug-in GUIDE Programming User Manual (Sauer-Danfoss part 11057259)

To simplify connecting **GDP_Application** block signals, first install and connect plug-ins. Connect as many plug-in signals as possible. Then connect **GDP_Application** block signals.

Input Signals

The following tables describe input signals applied to the **GDP_Application** block.



Inputs Bus Signals

Bus/Signal	Data Type	Description
Inputs bus	---	Inputs signals required by the GDP_Application block and any plug-ins that are installed in the block.
B_Mtr2Pos signal*	BOOL	T = Configure for two-position motors. F = Configure for fixed displacement or proportional displacement motors.
B_SetDefaults signal*	BOOL	T = Set defaults in the CoreParams page.
Desired_RPM signal [†]	U16	Throttle (desired) rpm input for the Antistall plug-in.
Engine_RPM signal [†]	U16	Actual engine rpm input for the Antistall plug-in.
L_PPU_RPM signal [†]	S16	Left PPU input for the Tracker plug-in.
R_PPU_RPM signal [†]	S16	Right PPU input for the Tracker plug-in.
PhasePt_Pct2 signal*	U16	Propel command at which: <ul style="list-style-type: none"> – Two position motors shift between low and high positions. – Proportional motors shift between pump and motor phases.
Temp_C signal [†]	U16	Temperature input for the Temp_Derate plug-in.


Inputs Bus Signals

Bus/Signal	Data Type	Description
Disable sub-bus	---	Inputs required for installed plug-ins.
B_Disable_AStall signal [‡]	BOOL	T = Enable the Antistall plug-in. F = Disable the Antistall plug-in. (Enabling and disabling the Antistall plug-in also enables and disables the Trackstall plug-in.)
B_Disable_SpdCtrl signal [‡]	BOOL	T = Enable the Tracker plug-in. F = Disable the Tracker plug-in.
B_Disable_Temp signal [‡]	BOOL	T = Enable the Temp_DeRate plug-in. F = Disable the Temp_DeRate plug-in.

*You must connect this signal for a successful compile. If the **GDP_Application** block is installed in the GDP Subsystem Application, connect this signal to the appropriate Subsystem Application signal. If the **GDP_Application** block is being used "stand-alone," connect this signal to an external input, constant, or EE component as appropriate.

†You must connect this signal for a successful compile when using the plug-in associated with the signal.

‡You must connect each **B_Disable** signal to the **Disable** bus when using the plug-in associated with the signal. (Installing the **GDP_Application** block in the GDP Subsystem Application makes the **Disable** bus available.) If the **GDP_Application** block is not installed in the Subsystem Application, you must individually connect each plug-in's **B_Disable** signal.




Cmd Bus Signals

Bus/Signal	Data Type	Description
Cmd bus	—	Required command signals for the GDP_Application block.
AllowHR signal*	BOOL	Allow upshifts on two-position and proportional motors. T = Allow upshifts. F = Disable upshifts.
Propel signal*	S16	Propel input, typically from a joystick. Range: ± 10000 ($10000 = 100.00\%$)
RampMode signal*	U8	Selects a ramp time for the propel command from a three-element array output from the Ramps page. You can add more elements to this array to add more ramp times. The default selections are: 0 = Normal. 1 = Decel. 2 = Brake.
Steer signal*	S16	Steer input, typically from a joystick. 0 = Straight/ ± 10000 = Pivot Steer/ ± 20000 = Counter-rotate. Range: ± 20000 ($20000 = 200.00\%$)

*You must connect this signal for a successful compile.

Output Signals

The following tables describe the signals output by the **GDP_Application** block.




Status Bus Signals

Bus/Signal	Data Type	Description
Status bus	---	Outputs signals that report the status of the GDP_Application block and any plug-ins that are installed inside this block.
RampedPropel signal	S16	Rate-limited propel command with smoothing applied by a Soft_Ramp function block. The Soft_Ramp function block is locked inside the GDP_Application block. For more about the Soft_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409). Range: 0-±10000 (10000 = 100.00%)
UnrampedPropel signal	S16	Rate-limited propel command without any smoothing. Range: 0-±10000 (10000 = 100.00%)
Status/OL_Cmd bus	---	Outputs open-loop propel command and propel command related signals.
L_Cmd_Pct2 signal	S16	Left speed command before the Tracker plug-in applies error correction. Range: ±10000 (10000 = 100.00%)
R_Cmd_Pct2 signal	S16	Right speed command before the Tracker plug-in applies error correction. Range: ±10000 (10000 = 100.00%)
Limit_Pct2 signal	U16	Maximum possible speed command. For two-position motors in: - Low speed = PhasePt_Pct2 signal. - High speed = 10000 (100.00%). For single-speed and proportional displacement motors, always = 10000 (100.00%) unless the AllowHR signal = F. Range: 0-10000 (10000 = 100.00%)


Status Bus Signals

Bus/Signal	Data Type	Description
Status/PowerDistr bus	----	Signals from the Antistall plug-in. For more information about these signals, refer to the <i>Antistall Plug-in GUIDE Programming User Manual</i> (Sauer-Danfoss part 11057258).
Power_Pct2 signal	----	----
Status signal	----	----
Status/RampedCmd bus	----	Speed commands after ramping but before power distribution (antistall) scaling. Compare the signals in this bus with the signals in the Status/UnrampedCmd bus.
L_Cmd_Pct2 signal	S16	Left speed command after smoothing but before power distribution (antistall) scaling. Smoothing is applied by a Time_Ramp function block locked inside the GDP_Application block. For more about the Time_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409). Range: ± 10000 (10000 = 100.00%)
R_Cmd_Pct2 signal	S16	Right speed command after smoothing but before power distribution (antistall) scaling. Smoothing is applied by a Time_Ramp function block locked inside the GDP_Application block. For more about the Time_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409). Range: ± 10000 (10000 = 100.00%)
Status/SpeedControl bus	----	Signals from the Tracker plug-in. For more information about these signals, refer to the <i>Tracker Plug-in GUIDE Programming User Manual</i> (Sauer-Danfoss part 11057260).
Saturated signal	----	----
Status signal	----	----
Status/Temp_Derate bus	----	Signals from the Temp_Derate plug-in. For more information about these signals, refer to the <i>Temperature Derate Plug-in GUIDE Programming User Manual</i> (Sauer-Danfoss part 11057257).
Status signal	----	----
Temp_Derate_Pct2 signal	----	----
Status/UnrampedCmd bus	----	Speed commands without ramping and before power distribution (antistall) scaling. Compare the signals in this bus with the signals in the Status/RampedCmd bus.
L_Cmd_Pct2 signal	S16	Left speed command without smoothing and before power distribution (antistall) scaling. Range: ± 10000 (10000 = 100.00%)
R_Cmd_Pct2 signal	S16	Right speed command without smoothing and before power distribution (antistall) scaling. For more about the Time_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409). Range: ± 10000 (10000 = 100.00%)




Left and Right Signals

Signal	Data Type	Description
L_Cmd_Pct2 signal	S16	Rate-limited left speed command, after scaling by any plug-ins in use. Range: ± 10000 (10000 = 100.00%)
R_Cmd_Pct2 signal	S16	Rate-limited right speed command, after scaling by any plug-ins in use. Range: ± 10000 (10000 = 100.00%)



Phase Bus Signals

Bus/Signal	Data Type	Description
Phase bus	---	Outputs motor-related signals.
B_Mtr2Pos signal	BOOL	T = Configured for two-position motors. F = Configured for single-speed or proportional motors.
MtrPos signal	BOOL	T = Two-position motors shifted to high speed. F = Two-position motors shifted to low speed.
PhasePt_Pct2 signal	U16	Propel command at which: <ul style="list-style-type: none"> Two position motors shift between low and high positions. Proportional motors shift between pump and motor phases. Range: 0–10000 (10000 = 100.00%)



The GDP Application contains a:


- **CoreParams** page with non-volatile memory (EE) components whose output signals configure the **GDP_Application** block.
- **GDP_Application** block that is a wrapper for a keyed **GDP_Application** page. The keyed **GDP_Application** page has:
 - Logic that provides the basic functionality for this application.
 - Socket pages for optional plug-ins.

GDP Application

Callout	Item	Data Type	Description
1	Inputs bus	—	Inputs signals required by: <ul style="list-style-type: none"> – The GDP_Application block. – Any plug-in plug-ins that are installed in the GDP_Application block.
2	CoreParams page	—	Contains non-volatile memory (EE) components whose output signals define the GDP_Application block's steering, propel, shift, and braking ramp values. The CoreParams page also passes through some Inputs bus signals.
3	GDP_Application block	—	Is a wrapper page for a keyed GDP_Application page. The keyed GDP_Application page has: <ul style="list-style-type: none"> – Logic that provides the basic functionality for this application. – Socket pages for optional plug-ins. The keyed GDP_Application page can only be downloaded to similarly keyed application hardware.
4	Cmd bus	—	Inputs command signals to the GDP_Application block.
5	Status bus	—	Outputs signals that report the status of: <ul style="list-style-type: none"> – The GDP_Application block. – Any plug-ins that are installed inside the GDP_Application block.
6	Left signal	U16	Rate-limited left speed command. Range: ± 10000 (10000 = 100.00%)
7	Right signal	U16	Rate-limited right speed command. Range: ± 10000 (10000 = 100.00%)
8	Phase bus	—	Outputs motor-related signals.

CoreParams Page

Path: Top ! Application ! CoreParams



The **CoreParams** page contains:

- Two non-volatile memory (EE) components whose signals define:
 - Differential steering.
 - Shift values for two-position motors and a limit for proportional motors if the **AllowHR** signal = F.
- A **Ramps** page with EE components whose signals define propel, steering, and braking ramps.

CoreParams Page

Callout	Item	Description
1	PARAMETER OPEN component	<p>Marks the open of a location that uses values from a GDP Defaults file.</p> <p>The comma-separated file used to create the GDP Defaults file has a TypeFileName value. The TypeFileName value becomes part of the GDP Defaults file.</p> <p>PARAMETER OPEN component output signal = T when the TypeFileName value in the GDP Defaults file matches the PARAMETER OPEN component's TYPE field (GDP here).</p> <p>If the PARAMETER OPEN component signal = T, then when:</p> <ul style="list-style-type: none"> – SetDefs_AppBlock signal = T—set the EE components in this page to their default (IN) values. – B_Set_Defaults signal = T—set all the EE components in this page and elsewhere in the application to their default (IN) values.
2	PARAMETER CLOSE component	<p>Marks the close of a location that uses values from a GDP Defaults read-only parameter file.</p> <p>The COMMENT field (GDP Defaults here) is a non-compiled comment.</p>

CoreParams Page

Callout	Item	Description
3	Ramps page	Contains EE components whose signals define propel and steering ramps.
4	EE_Core_DiffSteer_Pct2 EE component	<p>Outputs the DiffSteer_Pct2 signal.</p> <p>In a turn, the inside track speed command always decreases. The outside track speed command can stay the same or increase. This signal sets how much of the decrease in the inside track speed command gets added to the outside track speed command.</p> <p>The greater the DiffSteer_Pct2 value, the greater the differential steering effect.</p> <p>In a turn, a DiffSteer_Pct2 value of</p> <ul style="list-style-type: none"> - 10000 (100.00%) adds 100% of the decrease in the inside track speed command to the outside track speed command. Enter a value of 10000 (100.00%) for full differential steering. - 6000 (60.00%) adds 60% of the decrease in the inside track speed command to the outside speed command. - 0 (0%) does not increase the outside track speed command. <p>Range: 0–10000 (10000 = 100.00%)</p>
5	EE_Core_ShiftHyst_Pct2 EE component	<p>Outputs the ShiftHyst_Pct2 signal. Applications with two-position motors use this signal.</p> <p>This signal sets the percentage that the speed command with the highest value must drop below the PhasePt_Pct2 value before the motors downshift to low-speed.</p> <p>(The ShiftHyst_Pct2 value should never be larger than the PhasePt_Pct value. Otherwise motors once shifted to high will never downshift to low.)</p> <p>Example—A machine with two-position motors has a:</p> <ul style="list-style-type: none"> - ShiftHyst_Pct2 value of 500 (5.00%). - PhasePt_Pct value of 5000 (50.00%). <p>The motors upshift when the highest speed command reaches 5000 (50.00%). The highest speed command must drop below 4500 (45.00%) before the motors downshift.</p> <p>Range: 0–10000 (100.00%)</p>



About Differential Steer Percent

In a turn, the **DiffSteer_Pct2** value sets what percentage of the decrease in the inside track speed command gets added to the outside track speed command.

The greater the **DiffSteer_Pct2** value, the greater the differential steering effect. A **DiffSteer_Pct2** value of 10000 (100.00%) gives the maximum differential steering effect.

In this example, the:

- Propel command stays constant at 4000 (40.00%).
- Steer command ranges from 0–20000 (200.00%).
 (A steer command greater than 10000 (100.00%) starts counter-rotation.)
- The **DiffSteerPct_2** values are 0 (0%), 6000 (60.00%), and 10000 (100.00%).





Propel command (input) = Constant 4000 (40.00%)

Steer command (input) = 0–20000 (200.00%)

- Left speed command (output)—**DiffSteer_Pct2** = 0 (0%)
- - - - Left speed command (output)—**DiffSteer_Pct2** = 6000 (60.00%)
- - - - Left speed command (output)—**DiffSteer_Pct2** = 10000 (100.00%)
- Right speed command (output)—at all **DiffSteer_Pct2** values

In this example, the:

- Propel command stays constant at 8000 (80.00%).
- Steer command ranges from 0–20000 (200.00%).
 (A steer command greater than 10000 (100.00%) starts counter-rotation.)
- The **DiffSteerPct_2** values are 0 (0%), 6000 (60.00%), and 10000 (100.00%).




Propel command (input) = Constant 8000 (80.00%)

Steer command (input) = 0–20000 (200.00%)

- Left speed command (output)—**DiffSteer_Pct2** = 0 (0%)
- Left speed command (output)—**DiffSteer_Pct2** = 6000 (60.00%)
- Left speed command (output)—**DiffSteer_Pct2** = 10000 (100.00%)
- Right speed command (output)—at all **DiffSteer_Pct2** values

Ramps Page

Path: Top ! Application ! CoreParams ! Ramps



The **Ramps** page contains non-volatile memory (EE) components whose signals define the ramps output by **Soft_Ramp** and **Time_Ramp** function blocks. Both of these blocks are locked inside the **GDP_Application** block.

- The **Soft_Ramp** function block smoothes propel command changes.
- The **Time_Ramp** function block smoothes the effects of steering command changes.



Keep the total of **EE_Ramp_Soft_Start** and **EE_Ramp_Soft_End** values below 100 (100%). Values greater than 100 (100%) produce erratic acceleration and deceleration behavior.

The two **Encode** components output arrays. Array elements are the propel ramp times. The **RampMode** signal (which comes from outside the **GDP_Application** block) selects ramp times by picking array elements.

By default, **RampMode** signal values of 0, 1, 2 select ramp modes (ramp times) of **Normal**, **Decel**, and **Brake**.

For more ramp modes:

- Add more EE components to increase the number of elements in the arrays.
- Add logic to increase the number of **RampMode** signal values.

Ramps Page

Callout	Item	Description
1	EE_Ramp_Normal_DecTm EE value	<p>Outputs the A_DecTm_ms signal.</p> <p>This signal applies in deceleration when the RampMode signal = 0 (the default RampMode of Normal).</p> <p>This signal sets the decrement time of a Soft_Ramp function block that is locked inside the GDP_Application block. This function block smoothes changes in propel commands.</p> <p>Decrement time is the time (in ms) that it takes for the propel command to decrease from ± 10000 to 0. Partial decreases in the propel command take a time that is proportional to the total decrement time.</p> <p>With a A_DecTm_ms value of 2000 (2000 ms):</p> <ul style="list-style-type: none"> – A 100.00% decrease in the propel command from 10000 to 0 takes 2000 ms. – A 50.00% decrease in the propel command from 7500 to 2500 takes 1000 ms. <p>For more about the Soft_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409).</p> <p>Range: Loop Time–65535 (1000 = 1000 ms)</p>
2	EE_Ramp_Brake_Tm EE value	<p>Outputs the A_DecTm_ms signal.</p> <p>This signal applies in deceleration when the RampMode signal = 2 (the default RampMode of Brake).</p> <p>This signal sets the decrement time of a Soft_Ramp function block that is locked inside the GDP_Application block. This function block smoothes changes in propel commands.</p> <p>Decrement time is the time (in ms) that it takes for the propel command to decrease from ± 10000 to 0. Partial decreases in the propel command take a time that is proportional to the total decrement time.</p> <p>With a A_DecTm_ms value of 500 (500 ms):</p> <ul style="list-style-type: none"> – A 100.00% decrease in the propel command from 10000 to 0 takes 500 ms. – A 50.00% decrease in the propel command from 7500 to 2500 takes 250 ms. <p>For more about the Soft_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409).</p> <p>Range: Loop Time–65535 (1000 = 1000 ms)</p>
3	EE_Ramp_Decel_Tm EE value	<p>Outputs the A_DecTm_ms signal.</p> <p>This signal applies in deceleration when the RampMode signal = 1 (the default RampMode of Decel).</p> <p>This signal sets the decrement time of a Soft_Ramp function block that is locked inside the GDP_Application block. This function block smoothes changes in propel commands.</p> <p>Decrement time is the time (in ms) that it takes for the propel command to decrease from ± 10000 to 0. Partial decreases in the propel command take a time that is proportional to the total decrement time.</p> <p>With a A_DecTm_ms value of 700 (700 ms):</p> <ul style="list-style-type: none"> – A 100.00% decrease in the propel command from 10000 to 0 takes 700 ms. – A 50.00% decrease in the propel command from 7500 to 2500 takes 350 ms. <p>For more about the Soft_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409).</p> <p>Range: Loop Time–65535 (1000 = 1000 ms)</p>

Ramps Page


Callout	Item	Description
4	EE_Ramp_Normal_IncTm EE value	<p>Outputs the A_IncTm_ms signal.</p> <p>This signal applies during acceleration.</p> <p>This signal sets the increment time of a Soft_Ramp function block that is locked inside the GDP_Application block. This function block smoothes changes in propel commands.</p> <p>Increment time is the time (in ms) that it takes for the propel command to increase from 0 to ± 10000. Partial increases in the propel command take a time that is proportional to the total increment time.</p> <p>With an A_IncTm_ms value of 2000 (2000 ms):</p> <ul style="list-style-type: none"> - A 100.00% increase in the propel command from 0 to 10000 takes 2000 ms. - A 50.00% increase in the propel command from 2500 to 7500 takes 1000 ms. <p>For more about the Soft_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409).</p> <p>Range: Loop Time-65535 (1000 = 1000 ms)</p>
5	EE_Ramp_Soft_Start EE value	<p>Outputs the SftStrt_Pct signal.</p> <p>This signal sets the soft start percentage of a Soft_Ramp function block that is locked inside the GDP_Application page. This function block smoothes changes in propel commands.</p> <p>Soft start percentage is the percent of total ramp time in which a soft acceleration occurs.</p> <p>For more about the Soft_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409).</p> <p>Range: 0-99 (1 = 1%)</p>
6	EE_Ramp_Soft_End EE value	<p>Outputs the SftEnd_Pct signal.</p> <p>This signal sets the soft end percentage of a Soft_Ramp function block that is locked inside the Application page. This function block smoothes changes in propel commands.</p> <p>Soft end percentage is the percent of total ramp time in which a soft deceleration occurs.</p> <p>For more about the Soft_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409).</p> <p>Range: 0-99 (1 = 1%)</p>
7	EE_PwrScdDecTm EE value	<p>T = Reduce the propel ramp decrease time by the output of the PowerDistr (antistall) page plug-in.</p> <p>F = Do not use the output of the PowerDistr to reduce the propel ramp decrease time.</p>
8	EE_Ramp_Steer_IncTm EE value	<p>Outputs the IncTm_ms signal.</p> <p>This signal sets the increment time of two Time_Ramp function blocks that are locked inside the GDP_Application page. These function blocks smooth changes in steer commands.</p> <p>Increment time is the time (in ms) that it takes for a steering multiplier to increase from 0 to ± 10000 (from pivot steer to straight ahead). Partial increases in the steering multiplier take a time that is proportional to the total increment time.</p> <p>With an IncTm_ms value of 444 (444 ms):</p> <ul style="list-style-type: none"> - A 100.00% increase in the steering multiplier from 0 to 10000 takes 444 ms. - A 50.00% increase in the steering multiplier from 2500 to 7500 takes 222 ms. <p>For more about the Time_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409).</p> <p>Range: Loop Time-65535 (1000 = 1000 ms)</p>

Ramps Page

Callout	Item	Description
9	EE_Ramp_Steer_DecTm EE value	<p>Outputs the DecTm_ms signal.</p> <p>This signal sets the decrement time of two Time_Ramp function blocks that are locked inside the GDP_Application block. These function blocks smooth changes in steer commands.</p> <p>Decrement time is the time (in ms) that it takes for the steering multiplier to decrease from ± 10000 to 0 (from straight ahead to pivot steer). Partial decreases in the steering multiplier take a time that is proportional to the total decrement time.</p> <p>With a DecTm_ms value of 444 (444 ms):</p> <ul style="list-style-type: none"> - A 100.00% decrease in the steering multiplier from 10000 to 0 takes 444 ms. - A 50.00% decrease in the steering multiplier from 7500 to 2500 takes 222 ms. <p>For more about the Time_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409).</p> <p>Range: Loop Time–65535 (1000 = 1000 ms)</p>

GDP_Application Page

Path: Top ! Application ! GDP_Application



The **GDP_Application** page has a:

- Keyed **GDP_Application** page that contains:
 - The logic that provides the basic functionality for this application. The **GDP_Application** page properties are set to disable viewing or editing this logic.
 - Socket pages for optional plug-ins. The **GDP_Application** page properties are set to enable access to these socket pages.

The keyed **GDP_Application** page only downloads to similarly keyed application hardware.

- A pass-through **Parameter** page with descriptions of the parameters that originate in the **CoreParams** page.

GDP_Application Page

Callout	Item	Data Type	Description
1	Params bus	---	Inputs signals that originate from the non-volatile memory (EE) components in the CoreParams page.
2	Parameter page	---	Passes through signals that originate in CoreParams page and contains a description of each signal.
3	Inputs bus	---	Inputs signals required by the GDP_Application block and any plug-ins that are installed in the block.
4	Cmd bus	---	Inputs command signals required by the application block.
5	Steer signal	S16	Steer input, typically from a joystick. 0 = Straight/ ± 10000 = Pivot Steer/ ± 20000 = Counter-rotate. Range: ± 20000 (20000 = 200.00%)
6	Propel signal	S16	Propel input, typically from a joystick. Range: ± 10000 (10000 = 100.00%)

GDP_Application Page

Callout	Item	Data Type	Description
7	RampMode signal	U8	Selects a ramp time for the propel command from a three-element array output from the Ramps page. You can add more elements to this array to add more ramp times. The default selections are: 0 = Normal. 1 = Decel. 2 = Brake.
8	AllowHR signal	BOOL	Allow upshifts on two-position and proportional motors. T = Allow upshifts. F = Disable upshifts.
9	GDP_Application page	---	<ul style="list-style-type: none"> - Contains the logic that provides the basic functionality of this application. (The properties of this page disable your ability to view or edit this logic.) - Provides access to socket pages where you can install optional plug-ins to extend the functionality of the application.
10	Status bus	---	Outputs signals that report the status of the application block and any plug-ins that are installed inside the application block.
11	RampedPropel signal	S16	Rate-limited propel command, after smoothing by a Soft_Ramp function block that is locked inside the GDP_Application page. For more about the Soft_Ramp function block, refer to the <i>PLUS+1 GUIDE Basic Function Blocks Library User Manual</i> (Sauer-Danfoss part 10103409). Range: 0–±10000 (10000 = 100.00%)
12	UnrampedPropel signal	S16	Rate-limited propel command without smoothing. Range: 0–±10000 (10000 = 100.00%)
13	RampedCmd bus	---	Outputs speed command signals after they have been ramped but before power distribution (antistall) scaling.
14	UnrampedCmd bus	---	Outputs speed command signals that have not been ramped and before power distribution (antistall) scaling.
15	Status/OL_Cmd bus	---	Outputs open-loop propel command and propel command related signals.
16	Left signal	U16	Rate-limited left speed command. Range: ±10000 (10000 = 100.00%)
17	Right signal	U16	Rate-limited right speed command. Range: ±10000 (10000 = 100.00%)

GDP_Application Page


Callout	Item	Data Type	Description
18	Phase bus	---	Outputs motor-related signals.
19	B_Mtr2Pos signal	BOOL	T = Configured for two-position motors. F = Configured for single-speed or proportional displacement motors.
20	PhasePt_Pct2 signal	U16	Propel command at which: <ul style="list-style-type: none"> - Two position motors shift between low and high positions. - Proportional motors shift between pump and motor phases. Range: 0-10000 (10000 = 100.00%)
21	MtrPos signal	BOOL	T = Two-position motors shifted to high speed. F = Two-position motors shifted to low speed.

How to Access Socket Pages

Socket pages are wrappers for plug-ins that extend the application's functionality.

The **GDP_Application** page contains:

- The logic that provides the core functionality for the application. The **GDP_Application** page's properties disable viewing or editing this logic.
- Socket pages for optional plug-ins that extend the application's functionality. The **GDP_Application** page's properties allow access to these socket pages.



1. Enter the **GDP_Application** page.


The **View Disabled** window displays. This window's:

- **Page(s)** list identifies the socket pages inside the **GDP_Application** page.
- View pane shows the page currently highlighted in the **Page(s)** list.

2. From the **Page(s)** list in the **View Disabled** window, click the desired socket page.
3. In the **View Disabled** window, click the View pane to go to the desired socket page.

DualPathSpdCtrl Socket Page

Path: TOP ! GDP_Application ! GDP_Application ! DualPathSpdCtrl



The **DualPathSpdCtrl** socket page is the connector page for a **Tracker** plug-in.

The **Tracker** plug-in applies closed-loop control to correct tracking errors caused by uneven track loading, hydraulic leakage, and poor calibration.

For detailed information about this plug-in, refer to the *Tracker Plug-in GUIDE Programming User Manual* (Sauer-Danfoss part 11057260).

- The “Before” portion of the preceding figure shows the socket page before its plug-in has been imported and connected.
- The “After” portion of the preceding figure shows the socket page after its plug-in has been imported and connected. (Some signals only become available after you import the **GDP Application** block into the GDP Subsystem Application.)


The folder with the **GDP_Application** block SCS file also has folders that contain the SCS files for the plug-ins shown in this manual.

To import a plug-in, use the **GUIDE** window’s **File** menu > **Block** > **Import Block** command.

For more information about importing blocks, refer to the *PLUS+1 GUIDE User Manual* (Sauer-Danfoss part 10100824).

MaxCmdScale Socket Page

Path: TOP ! GDP_Application ! GDP_Application ! MaxCmdScale



The **MaxCmdScale** socket page is the connector page for a **Temp_Derate** plug-in.

The **Temp_Derate** plug-in scales down propel commands when the hydraulic fluid becomes too hot.

Scaling down the propel command:

- Slows the rise of fluid temperatures.
- Helps protect the hydraulic system from damage.

For detailed information about this plug-in, refer to the *Temp_Derate Plug-in GUIDE Programming User Manual* (Sauer-Danfoss part 11057257).

- The “Before” portion of the preceding figure shows the socket page before its plug-in has been imported and connected.
- The “After” portion of the preceding figure shows the socket page after its plug-in has been imported and connected. (Some signals only become available after you import the **GDP Application** block into the GDP Subsystem Application.)


The folder with the **GDP_Application** block SCS file also has folders that contain the SCS files for the plug-ins shown in this manual.

To import a plug-in, use the **GUIDE** window’s **File** menu > **Block** > **Import Block** command.

For more information about importing blocks, refer to the *PLUS+1 GUIDE User Manual* (Sauer-Danfoss part 10100824).

PowerDistr Socket Page

Path: TOP ! GDP_Application ! GDP_Application ! PowerDistr



The **PowerDistr** socket page is the connector page for an **Antistall** plug-in.

The **Antistall** plug-in scales down speed commands to prevent heavy loads from stalling the engine.

For detailed information about this plug-in, refer to the *Antistall Plug-in GUIDE Programming User Manual* (Sauer-Danfoss part 11057258).


- The “Before” portion of the preceding figure shows the socket page before its plug-in has been imported and connected.
- The “After” portion of the preceding figure shows the socket page after its plug-in has been imported and connected. (Some signals only become available after you import the **GDP Application** block into the GDP Subsystem Application.)

The folder with the **GDP_Application** block SCS file also has folders that contain the SCS files for the plug-ins shown in this manual.

To import a plug-in, use the **GUIDE** window’s **File** menu > **Block** > **Import Block** command.

For more information about importing blocks, refer to the *PLUS+1 GUIDE User Manual* (Sauer-Danfoss part 10100824).

Trackstall Socket Page



The **Trackstall** socket page is the connector page for a **Trackstall** plug-in.

The **Trackstall** plug-in limits the scaling of its speed commands by the **Antistall** plug-in.

Limiting the scaling of speed commands prevents tracks from completely stopping under antistall conditions.

For detailed information about this plug-in, refer to the *Trackstall Plug-in GUIDE Programming User Manual* (Sauer-Danfoss part 11057259).

- The "Before" portion of the preceding figure shows the socket page before its plug-in has been imported and connected.
- The "After" portion of the preceding figure shows the socket page after its plug-in has been imported and connected. (Some signals only become available you import the **GDP Application** block into the GDP Subsystem Application.)

The folder with the **GDP_Application** block SCS file also has folders that contain the SCS files for the plug-ins shown in this manual.

To import a plug-in, use the **GUIDE** window's **File** menu > **Block** > **Import Block** command.

For more information about importing blocks, refer to the *PLUS+1 GUIDE User Manual* (Sauer-Danfoss part 10100824).

A

Access socket pages, how-to, **25**
Application page, about, **13**

C

CoreParams page, about, **14**

D

Differential steer percent, about, **16**
DualPathSpdCtrl socket page, about, **26**

G

GDP_Application page, about, **22**

M

MaxCmdScale socket page, about, **27**

P

Pages

Application, **13**
CoreParams, **14**
DualPathSpdCtrl socket, **26**
GDP_Application, **22**
MaxCmdScale socket, **27**
PowerDistr socket, **28**
Ramps, **18**
Trackstall socket, **29**

S

Signals, GDP_Application block
inputs, **7**
left and right, **12**
phase, **12**
status, **10**
Socket pages, access to, about, **25**



Generic Dual Path Application Block
User Manual

OUR PRODUCTS

Hydrostatic transmissions
 Hydraulic power steering
 Electric power steering
 Electrohydraulic power steering
 Closed and open circuit axial piston pumps and motors
 Gear pumps and motors
 Bent axis motors
 Orbital motors
 Transit mixer drives
 Planetary compact gears
 Proportional valves
 Directional spool valves
 Cartridge valves
 Hydraulic integrated circuits
 Hydrostatic transaxles
 Integrated systems
 Fan drive systems
 Electrohydraulics
 Microcontrollers and software
 Electric motors and inverters
 Joysticks and control handles
 Displays
 Sensors

Sauer-Danfoss Hydraulic Power Systems

- Market Leaders Worldwide

Sauer-Danfoss is a comprehensive supplier providing complete systems to the global mobile market.

Sauer-Danfoss serves markets such as agriculture, construction, road building, material handling, municipal, forestry, turf care, and many others.

We offer our customers optimum solutions for their needs and develop new products and systems in close cooperation and partnership with them.

Sauer-Danfoss specializes in integrating a full range of system components to provide vehicle designers with the most advanced total system design.

Sauer-Danfoss provides comprehensive worldwide service for its products through an extensive network of Global Service Partners strategically located in all parts of the world.

Local address:
 Sauer-Danfoss Inc.
 3500 Annapolis Lane North
 Minneapolis, MN 55447, USA
 Phone: +1 763 509-2000
 Fax: +1 763 559-5769

Sauer-Danfoss (US) Company
 2800 East 13th Street
 Ames, IA 50010, USA
 Phone: +1 515 239-6000
 Fax: +1 515 239-6618

Sauer-Danfoss GmbH & Co. OHG
 Postfach 2460, D-24531 Neumünster
 Krokamp 35, D-24539 Neumünster, Germany
 Phone: +49 4321 871-0
 Fax: +49 4321 871 122

Sauer-Danfoss ApS
 DK-6430 Nordborg, Denmark
 Phone: +45 7488 4444
 Fax: +45 7488 4400

Sauer-Danfoss-Daikin LTD
 Shin-Osaka TERASAKI 3rd Bldg. 6F
 1-5-28 Nishimiyahara, Yodogawa-ku
 Osaka 532-0004, Japan
 Phone: +81 6 6395 6066
 Fax: +81 6 6395 8585