




SET 1E
*Electronic Timeswitch
for Heating and Hot Water*

**For a large print version of these instructions
please call Marketing on 0845 121 7400.**



Certification Mark

This product complies with the following EC Directives:
Electro-Magnetic Compatibility Directive.
(EMC) (2004/108/EC)
Low Voltage Directive.
(LVD) (2006/95/EC)




Danfoss can accept no responsibility for possible errors in catalogues, brochures, and other printed material. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Installation Instructions

SET1E

Electronic Timeswitch for Heating and Hot Water

GB



Index

1.0 Installation Guide	4
2.0 System Overview	4
3.0 Installation	4
3.1 Wiring	6
3.2 Typical gravity DHW with pumped central heating	7
3.3 Typical control of pump for central heating in a solid fuel system	8
3.4 Typical control heating function only with boiler and pump	9
3.5 Typical control of a motorised zone valve requiring an open and close signal	10
3.6 Typical control of heating when used with combination type boilers	11
4.0 Replacement	11

1.0 Installation Guide

Please Note:
This product should only be installed by a qualified electrician or competent heating installer and should be in accordance with the current edition of the IEEE wiring regulations.


2.0 System Overview

GB

Specification	
Power supply	230 ± 15% Vac, 50/60Hz
Switch action	1 x SPDT voltage free Type 1B
Switch rating	Max. 264Vac, 50/60Hz, 3(1) A
Timing accuracy	± 1 min/month
Power reserve	Minimum 10 hours
Enclosure rating	IP30
Max. ambient temperature	45°C
Dimensions, mm (W, H, D)	158 x 98 x 38
Design standard	EN 60730-2-7
Control Pollution Situation	Degree 2
Rated Impulse Voltage	2.5kV
Ball Pressure Test	75°C

3.0 Installation

1. Fix the wallplate to the wall or flush mounted box as required. The connections are at the top and the vertical centre line of the unit, at the position shown on the diagram below C/L (in line with terminal \perp).
2. Surface cables can only enter from below the unit. If mounted on a flush mounted box, cables can enter from the rear through the aperture in the wallplate.
3. For mains voltage applications a link must be fitted between terminals L and 5.
4. Whilst the unit does not require an Earth connection, a terminal is provided on the wallplate for Earth continuity purposes.




5. Referring to the wiring diagrams on page 6-10, connect the unit as shown.
6. Ensure all dust and debris are cleared from the area.
7. Locate the module on the latches at the bottom of the wallplate and hinge upwards to fully engage the unit connectors into the wallplate. Tighten the two fixing screws to secure the unit to the wallplate.
8. Before setting the programme, check the unit and circuit. Switch on the mains supply and press the rocker switch to the **CONSTANT** position - the red LED should now be illuminated. Adjust any remote thermostat to check the services operate correctly.
9. Press the rocker switch to the **OFF** position and check that the system does not operate.
10. Finally, press the rocker switch to **TIMED** position prior to programming the unit.

3.1 Wiring

On the following pages are typical wiring diagrams for various types of systems.


Note: Whilst every attempt has been made to ensure the accuracy of this information it is recommended that the specific information relating to the ancillary controls is obtained from the manufacturers concerned.

GB



NOTE:
For mains voltage applications a link must be fitted between terminals L and 5.


3.2 Typical Gravity DHW With Pumped Central Heating




GB

DHW = Domestic Hot Water

3.3 Typical Control of Pump For Central Heating on a Solid Fuel System




3.4 Typical Control Heating Function Only With Boiler and Pump




GB

3.5 Typical Control of a Motorised Zone Valve Requiring an Open and Close Signal



3.6 Typical Control of Heating When Used with Combination Type Boilers














GB


















4.0 Replacement

Please see overleaf for a table containing replacement wiring information.

Some timeswitches are connected in different ways depending upon the type of system and/or the controls which are fitted. If there is any doubt about the way in which the existing timeswitch is connected, please contact our Technical Services Department before proceeding with replacement.

Note: The SET1E is a direct replacement for a Danfoss Randall SET1.

DANFOSS RANDALL SET1E	MAINS			SPARE TERMINAL Where disconnected leads should be terminated			LOAD			Additional terminal block is required where these disconnected leads (or pairs) should be terminated			
		N	L				ON	COM	OFF				
ACL LS111		N	L		2		4	5	6	A	B	C	D
		N	L		4		3	1	2				
DANFOSS RANDALL SET 1		N	L		2		4	5	6				
DANFOSS RANDALL 911		N	L		2		6	5	4				
DANFOSS RANDALL 103/103E		5	6		2		1	3	-				
DANFOSS RANDALL 3020		1,7	6		2		4	-	-	3	5		
DANFOSS RANDALL TSR2		3	2		4		5	1	-	6	7		
GRASSLIN 45, 45A, 45E		2	1				4	3	-				
HORSTMANN 424 EMERALD & PEARL AUTO RANGE		N	L1		2		4	3	-	5			
HORSTMANN 423 PEARL EMERALD & TOPAZ		N	L		1		4	3	-	2	5	6	
HORSTMANN KMK2A YMK2		3	4				2	1	-				
HONEYWELL ST6100A		N	L		3		4	1	2				
HONEYWELL ST6100C		N	L		3		4	1	2				
HORSTMANN 425 CORONET		N	L		1		4	5	6	2	3		
LANDIS & GYR RWB3		N	L		1		4	-	3	2			

LANDIS & GYR RWB30		N	L		1		4	2	3			
SANGAMO M6		4,5	6		7		1	3	2	8		
SANGAMO 410 F8		4,5	3		6		1	-	2	7	8	
SANGAMO S254 F2, S408 F5, S251 F2		N	L				LOAD	-	-			
SANGAMO S610 F2, S611 F2, S162 F2, S408 F4, S408 F6, S253 F2, S255 F2		N	MOTOR LIVE				LOAD	SWITCH LIVE	-			
SANGAMO S409 F8		3,N	5,L		1		2	6	-			
SANGAMO S263 F2, S264 F2		N	L				ON	-	OFF			
SMITH IND. MKI, MKII		N	L		P1		P3	P2	-			
SMITH IND. CENTROLLER 30		1	2		3		4,5	-	-	6		
SMITH IND. CENTROLLER 40		1	2		3		4,5	-	-			
SWITCHMASTER 300		N	L		2		1	4	-	3		
TOWERCHRON TC		2	1		3		7	4	-	8	9	10
VENNER VENNERETTE MK.IIA		N	L				LOAD	LINE	-			11
VENNER VENNERETTE MK.IVA		2	3				1	4	-			
VENNER VENOTIME (WITH NEON INDICATING CIRCUIT ON)		N	L		2		3	-	1			
VENNER VENOTIME (WITH NEON INDICATING POWER ON)		N	L				3	2	1			
VENNER VENNERON, VENNERON P		3	2				4	1				



Danfoss Ltd

Ampthill Road
Bedford MK42 9ER

Tel: 01234 364621

Fax: 01234 219705

Email: ukheating@danfoss.com

Website: www.heating.danfoss.co.uk