



Installation and user manual

DEVIreg™ 850 ground and roof sensors

Table of content

1	Sensors and control zones	3
1.1	Sensor types and function	3
1.2	Control zones.....	4
1.3	Assign sensors to control zones	5
2	Placing and installation of sensors	6
2.1	Placing ground sensors	6
2.1.1	Placing the first ground sensor in a zone	6
2.1.2	Placing the following ground sensors in a zone	6
2.1.3	Example with ground sensors	7
2.1.4	Extending the ground sensor cable	7
2.2	Installing ground sensors	8
2.3	Placing roof sensors.....	10
2.3.1	Placing the first roof sensor in a zone	10
2.3.2	Placing the following roof sensors in a zone.....	10
2.3.3	Guiding plates	10
2.3.4	Example with roof sensors.....	11
2.3.5	Extending the roof sensor cable	11
2.4	Installing roof sensors.....	12
3	Technical specifications	13
4	Appendix A	14
4.1	Sensor cable extension.....	14
4.2	Connections	15
5	Warranty	16

1 Sensors and control zones


This section guides you through a short introduction to the terms used in the manual:

- Area type
- Sensor type
- Controller
- Control Zones

Finally you will be able to assign a number of sensors to the chosen control zones.

1.1 Sensor types and function

Identify the type(s) of area prepared for the DEVI ice and snow melting system, by looking at the fig. below:



1. Walkways and parking areas
2. Steps and stairs
3. Roofs and roof edges
4. Gutters and down pipes

For ground areas like 1 and 2 you have one or more ground sensors.

For roof areas like 3 and 4 you have one or more roof sensors.



The ground and roof sensors both measure two things on the sensor surface:

- **temperature**
- **moisture** from ice, snow, hail or rain

These measurements are input to the DEVIreg™ 850, and it decides how the ice and snow melting system should control the heated areas.

Details about the setup of the controller can be found in the DEVIreg™ 850 installation manual.



1.2 Control zones

A DEVIreg™ 850 and up to 4 sensors are able to control an area as a single zone, but can also control more areas as 2 separated control zones.



2 control zones consists of minimum 2 heating elements + 2-4 sensors and can be:

Combi zones = when you have both a roof and a ground area

Dual zones = e.g. if steps should have a better performance than a walkway

If the power supply is limited, both combi and dual zones gives you the possibility to prioritize which zone to operate first.

A DEVIreg™ 850 and up to 4 sensors give the following 5 control options:



Zone type			
Single zone ground	1-4 in one zone		Maximum 4 sensors in all
Single zone roof		1-4 in one zone	
Combi zones	1-3 in one ground zone	1-3 in one roof zone	
Dual zones ground	2-4 split in two zones		
Dual zones roof		2-4 split in two zones	

1.3 Assign sensors to control zones

There are some good reasons to have **2 or more sensors** in one control zone.

- Higher degree of **detection safety**, which is relevant for larger, complex or busy roof and ground areas.
- Approx. 1 hour **faster ground system**, as one sensor measures the ground temperature and other sensors measure the moisture whereas a single sensor must switch between temperature and moisture measurements.

Now decide how the ice and snow melting system should be operated and assign the sensors to the control zones. In case of questions the system designer must be consulted.

Draw circles around Zone type and 1-4 Sensors				
Single zone ground	x	1 2 3 4		Maximum 4 sensors in all
Single zone roof	x		1 2 3 4	
Combi zones	x	1 2 3	1 2 3	
Dual zones ground	x	2 3 4		
Dual zones roof	x		2 3 4	

2 Placing and installation of sensors

At this point you must have identified and assigned sensors to the control zones as prescribed in section 1.

In this section 2 you will be guided through a correct placing and installation of the sensors:

- For placing and installation of ground sensors see section 2.1.
- For placing and installation of roof sensors see section 2.2.

2.1 Placing ground sensors

Placing ground sensors in appropriate spots is very important for the performance of the ice and snow melting system. The appropriate spot must fulfill some characteristics, where the below 2 are the most important:

**The sensors must be placed minimum 1 m within the boundaries of the heated zone.
The sensors must not be covered or prevented from being exposed to snow or rain.
This includes dirt, leaves and pebbles.**

2.1.1 Placing the first ground sensor in a zone

Find one who knows the area and make him describe the area function and weather conditions.

The first ground sensor in a zone must now be placed where the first snow appears. The appropriate spot can be found by following below steps:

- a) Where the heated area is in shade all day. Look e.g. for algae.
- b) Where e.g. a wind shield make the snow drift
- c) Where the most traffic from shoes or car wheels happens

If you have a dual zone system, the first sensor for the other zone must be placed by following the same steps above.

2.1.2 Placing the following ground sensors in a zone

The following ground sensors in a zone must be placed where the **surface dries up last**. The appropriate spot can be found by following below steps:

- a) Where the heated area is in shade all day
- b) Where the melting water accumulates e.g. due to hollows in the area
- c) So the whole zone is covered, but min. 1 meter from other sensors

If there is doubt about the appropriate spot, prepare a second spot for later use.

2.1.3 Example with ground sensors



In this example a lower step section (1), a walkway platform (2) and an upper step section (3) is heated. Depending on number of zones and detection safety, 2-3 ground sensors is installed.

Sensor no. 1 is the most important as this is placed where snow is likely to appear first due to shade and snow drift also because the spot is stepped on by pedestrians.

Sensor no. 2 is also important as the platform is object to water puddles. Here the shaded spot will dry up last. If the power supply is limited, the platform could be a low priority zone in a dual zone system.

Sensor no. 3 is relevant if more detection safety is required, as additional to sensor no. 1. Can be prepared for later installation.

2.1.4 Extending the ground sensor cable

The ground sensor consists of two parts, a sensor part with a sensor cable and a sensor tube.

A 15-meter cable is supplied with the sensor part. Approx. 0.5 m of this cable should be coiled inside the bottom of the sensor tube, leaving 14.5 meter to be connected with the DEVIreg™ 850 controller.



If the appropriate spot is located out of this range, a feeder cable extension for the sensor may be needed. This sensor cable extension must be a 4-wired cable with a diameter in accordance with the table in Appendix A – Sensor cable extension.


Note each new colour of the 4 wire cable feeder extensions (white, white, red and black). Dual zone sensors: Do NOT join feeder cable extensions from separate zones.

2.2 Installing ground sensors


At this point you must have located the appropriate spots for the ground sensors and extended the feeder cable if necessary as prescribed in section 2.1.

The sensor part and the sensor tube may now be installed in connection with the actual construction work and connected at a later date. The following applies for all types of installations.

- a) The base below the sensor tube must be hard, e.g. a concrete plate or similar, in order to ensure that the sensor is not pushed into the ground if e.g. a lorry runs over it. The tube is designed to be mounted on a plate using the two screw holes inside the tube.
- b) Place the sensor tube in between the heating cables with a minimum distance of 1 cm.





- c) The sensor tube must be positioned so that it is flush with the surrounding terrain and so that the sensor part must be placed so that the upper brass surface is horizontal.
- d) Lay a conduit for the sensor cable between the sensor tube and the DEVIREG™ 850 controller.



Installation in asphalt:

The temperature around the sensor part and sensor tube must not exceed 80°C. A wooden dummy or similar must replace the sensor while asphalt is poured and cooled down. The conduit must be a metal tube that can withstand the high temperatures.

- e) Ensure that the sensor tube is closed with the supplied cap before the concrete is poured or the bricks are laid. Make sure that air gaps are filled with cement.
- f) Coil approx. 0.5 m of the sensor cable inside the tube. If the sensor cable needs extension, see section 2.1.4.
- g) Place the sensor part inside the sensor tube until it is horizontally flush with the edge of the sensor tube and rests on the collar inside the tube.
- h) The sensor part may be inspected using the two holes around the edge of the sensor tube. The grooves on the outside of the sensor part correspond with the holes in the sensor tube.



2.3 Placing roof sensors

Placing roof sensors in appropriate spots is very important to the performance of the Ice & Snow melting system. The appropriate spot must fulfil some requirements, where the below 2 are the most important:

The sensors must be placed minimum 1 m within the boundaries of the heated zone. The sensors must not be covered and prevented from being exposed to snow or rain. This includes dirt and especially leaves in the gutters.

2.3.1 Placing the first roof sensor in a zone

Find one who knows the area and make him describe the area function and weather conditions. The first roof sensor in a zone must now be placed where **ice and snow cause most problems**.

The appropriate spot can be found by following below steps:

- a) Where the heated area is in shade or oriented to the north/west
- b) In the main gutter close to the main down pipe

If you have a dual zone system, the first sensor for the other zone must be placed by following the same steps above.

2.3.2 Placing the following roof sensors in a zone

The following roof sensors in a zone must be placed where the **surface dries up latest**.

The appropriate spot can be found by following below steps:

- c) Where the snow slides e.g. due to roof joints or gutter valleys
- d) In other gutters, close to other down pipes
- e) So the whole zone is covered, but min. 1 meter from other sensors


If there is doubt about the appropriate spot, prepare a second spot for later use.

2.3.3 Guiding plates

If a roof area is oriented to the south and the roof slope is steep it can be exposed to strong sun radiation.

In that case it can be necessary to install guiding plates above the sensor, so the slowly dripping melting water from the roof hit the roof sensor.

If there is doubt about the appropriate spot, prepare a second spot for later use.



2.3.4 Example with roof sensors

In this example a roof with several dormers is heated. Depending on the number of zones and required safety it is relevant to install 2-3 roof sensors.



Sensor no. 1 is placed in shady side of the front. It is the most important as all melting water passes the sensor until the gutter is dry. As snow is likely to slide down here, the spot is one of the last to dry up.

Sensor no. 2 is also important as the shaded dormer roof is more flat, which might cause sudden snow slides on a dry roof. The dormers could be the lower prioritized zone in a dual zone system.

Sensor no. 3 is relevant if a higher detection safety is required. It could both be placed near another down pipe or in the gutter valley. Thus it can be an additional sensor to both no. 1 and 2 and can be prepared for later installation.

2.3.5 Extending the roof sensor cable

The roof sensor is a sensor part with a sensor cable built in one.

A 15-meter cable is supplied with the roof sensor to be connected with the DEVlreg™ 850 controller.

If the appropriate spot is located out of this range, a feeder cable extension for the sensor may be needed. This sensor cable extension must be a 4-wired cable with a diameter in accordance with the table in Appendix A – Sensor cable extension.




Note each new colour of the 4 wire cable feeder extensions (white, white, red and black). Dual zone sensors: Do NOT join feeder cable extensions from separate zones

2.4 Installing roof sensors

At this point you must have selected the appropriate spots for the roof sensors and extended the feeder cable if necessary as prescribed in section 2.3.

The roof sensor may now be installed in connection with the actual construction work and connected at a later date. The following applies for all types of installations.

- a) The sensor must be placed between or next to the heating cables, with a distance of minimum 1 cm between sensor and heating cable.
- b) The sensor must be placed so that the upper brass surface is horizontal. If the sensor is placed on an angled roof, the sensor must be levelled until the surface is horizontal.
- c) Fasten the sensor by using the attachments on the sensor or glue it to the surface.



3 Technical specifications

Technical data

Type number: • Ground • Roof	D850 G1 Sensor D850 R1 Sensor
Voltage:	24VDC +10%/-20% (18-26VDC)
Power consumption: • Ground • Roof	Max. 13W Max. 8W
IP class:	IP 67
Ambient temperature: • Ground • Roof	-30°C to +70°C -50°C to +70°C
Sensor type:	Devibus connected moisture sensor(s)
Sensor lead:	15 m of 4x1 mm ² (may be extended in accordance with the table in appendix A)
Indication:	2 x 16-character illuminated display.
Measurements • Ground sensor • Sensor tube (ground) • Roof sensor	Depth = 87 mm; Height = 74 mm Depth = 93 mm; Height = 98 mm Depth = 15 mm; Height = 23,5 mm; Width 216 mm

4 Appendix A

4.1 Sensor cable extension

Ground system


Number of sensors:	1 or 2	3	4
Cable type	Max length (m)	Max. length (m)	Max length (m)
1 mm ²	300	150	80
1.5 mm ²	450	225	120
2.5 mm ²	750	380	200
4 mm ²	1200	600	310

Roof system

Number of sensors:	1	2	3	4
Cable type	Max length (m)	Max length (m)	Max length (m)	Max length (m)
1 mm ²	400	100	130	75
1.5 mm ²	600	150	200	110
2.5 mm ²	1000	250	330	190
4 mm ²	1600	400	525	300

4.2 Connections

Dual zone sensors: **Do not join sensor cable extensions from separate zones.**



Note each new colour of the 4 wire cable sensor extensions (white, white, red and black). Sensor cable extension according to above table is led to DEVIreg™ 850.

5 Warranty

A 2-year product warranty is valid for:

- DEVireg™ 850 ground and roof sensors.

Should you, against all expectations, experience a problem with your DEVI product, you will find that Danfoss offers DEVIwarranty valid from the **date of purchase** on the following conditions: During the warranty period Danfoss shall offer a new comparable product or repair the product if the product is found to be faulty by reason of defective design, materials or workmanship. The repair or replacement.

The decision to either repair or replace will be solely at the discretion of Danfoss. Danfoss shall not be liable for any consequential or incidental damages including, but not limited to, damages to property or extra utility expenses. No extension of the warranty period following repairs undertaken is granted.

The warranty shall be valid only if the WARRANTY CERTIFICATE is completed correctly and in accordance with the instructions, the fault is submitted to the installer or the seller without undue delay and proof of purchase is provided. Please note that the

WARRANTY CERTIFICATE must be filled in, stamped and signed by the authorized installer performing the installation (Installation date must be indicated). After the installation is performed, store and keep the WARRANTY CERTIFICATE and purchase documents (invoice, receipt or similar) during the whole warranty period.

DEVIwarranty shall not cover any damage caused by incorrect conditions of use, incorrect installation or if installation has been carried out by non-authorized electricians. All work will be invoiced in full if Danfoss is required to inspect or repair faults that have arisen as a result of any of the above. The DEVIwarranty shall not extend to products which have not been paid in full. Danfoss will, at all times, provide a rapid and effective response to all complaints and inquiries from our customers.

The warranty explicitly excludes all claims exceeding the above conditions.

For full warranty text visit www.devi.com.devi.danfoss.com/en/warranty/

WARRANTY CERTIFICATE

The DEVIwarranty is granted to:

Address _____ Stamp _____

Purchase date _____


Serial number of the product _____

Product _____ Art. No. _____

*Connected output [W] _____

Installation Date & Signature _____ Connection Date & Signature _____

**Not mandatory*



8095362

Danfoss A/S

Nordborgvej 81
6430 Nordborg, Syddanmark
Denmark

Danfoss A/S
DEVI • devicom • +45 7488 2222 • EH@danfoss.com

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.