

Installation Guide

Pressure Transmitters

MBS 33, MBS 33M, MBS 3000, MBS 3050, MBS 3200, MBS 3250, MBS 3300,
MBS 3350, MBS 4000, MBS 4050, MBS 4003, MBS 4010, DST P300, DST P30M
MBS 1700*, MBS 1750*

060R9348

060R9348

	<p>Elektrisk tilslutning Electrical connection: Elektrischer Anschluss: Raccordement électrique: Conexión eléctrica: Connessione elettrica:</p>		<p>Se produktskilt See product label Siehe Produktschild Voir étiquette du produit Ver la pegatina en el producto Vedi etichetta sulla confezione</p>		<p>Omgivelsestemperatur Ambient temperature Umgebungstemperatur Température ambiante Temperatura ambiente Temperatura ambiente</p>			
<p>4-20 mA: -40 – 100 °C Voltage: -40 – 114 °C Ratiom. 10-90%: -40 – 114 °C ATEX (ZONE 2) All outputs -20 – 85 °C</p>	<p>4-20 mA/Voltage/ Ratiom. 10-90%: Cable: -30 – 85 °C Wire: -30 – 100 °C ATEX (ZONE 2) All outputs -20 – 85 °C</p>	<p>4-20 mA: -30 – 100 °C Voltage: -30 – 105 °C Ratiom. 10-90%: -30 – 105 °C</p>	<p>4-20 mA: -40 – 100 °C Voltage: -40 – 125 °C Ratiom. 10-90%: -40 – 125 °C ATEX (ZONE 2) All outputs -20 – 85 °C</p>	<p>4-20 mA: -25 – 90 °C Voltage: -25 – 90 °C Ratiom. 10-90%: -25 – 90 °C</p>	<p>4-20 mA: -40 – 100 °C Voltage: -40 – 125 °C Ratiom. 10-90%: -40 – 125 °C</p>	<p>4-20 mA: -30 – 100 °C Voltage: -30 – 100 °C Ratiom. 10-90%: -30 – 100 °C</p>	<p>4-20 mA: -30 – 90 °C Voltage: -30 – 90 °C Ratiom. 10-90%: -30 – 90 °C</p>	<p>4-20 mA: -30 – 90 °C Voltage: -30 – 90 °C Ratiom. 10-90%: -30 – 90 °C</p>
<p>4-20 mA/Voltage/ Ratiometric 10-90%: -30 – 100 °C</p>	<p>4-20 mA/Voltage/ Ratiometric 10-90%: -30 – 100 °C</p>	<p>All outputs: On wire: -30 – 100 °C On cable: -30 – 85 °C ATEX (ZONE 2) All outputs -20 – 85 °C</p>	<p>4-20 mA/Voltage/ Ratiometric 10-90%: -30 – 100 °C</p>	<p>4-20 mA/Voltage/ Ratiometric 10-90%: -30 – 105 °C</p>	<p>4-20 mA: -40 – 100 °C Voltage/Ratiometric 10-90%: -40 – 114 °C</p>	<p>4-20 mA/Voltage/ Ratiometric 10-90%: -30 – 80 °C</p>	<p>4-20 mA/Voltage/ Ratiometric 10-90%: -30 – 100 °C</p>	
	<p>Pin 5: Forbundet til kapsling Pin 5: Anschluss an Gehäuse Pin 5: Broche 5: Connecté au boîtier Pin 5: Conectado a la cubierta Polo 5: Collegato al corpo</p>		<p>MBS 33, MBS 33M, MBS 3000, MBS 3200, MBS 3300, MBS 4000, MBS 4003, DST P300, DST P30M</p>	<p>MBS 3050, MBS 3250, MBS 3350, MBS 4050</p>	<p>MBS 4010</p>			
	<p>MBS 4010</p>							

		<p>Australian approvals: According to N1297.</p> <p>American and Canadian approvals:</p> <ol style="list-style-type: none"> Automatic electrical controls acc. to UL 60730-1 and part 2-6 / CAN/CSA E60730 and part 2-6, file E31024. Equipment for process measurement and control acc. to UL 61010-1 / CSA C22.2 No. 61010-12, file E494625. Nonincendive electrical equipment for use in Class I, Div. 2, Groups A, B, C, and D, hazardous locations in acc. To UL 121201 / C22.2 No. CSA-213, file E227388 and E510763. Combinations of equipment in systems are subject to investigation by the local Authority Having Jurisdiction at the time of installation. These components are to be installed within a suitable tool-secured enclosure in end application. <p>WARNING - EXPLOSION HAZRD – Do not disconnect equipment unless power has been removed or the area is known to be non-hazardous.</p> <ol style="list-style-type: none"> The MWP (max. working pressure) in the range from 1 to 600 bar depending on sensor pressure range. Refer to product lable, (E494625) Evaluated for pollution Degree 3. Altitude up to 8,000 m. Max. R.H. 95% non-condensing. Overvoltage category I. Powered by class 2 supply. <table border="1" data-bbox="400 651 1465 808"> <tr> <td>Type</td> <td>MBS 33, MBS 33M, MBS 3000 MBS 3050, MBS 4000, MBS 4003 MBS 4010</td> <td>MBS 3200, MBS 3250, MBS 3300, MBS 3350 DST P300, DST P30M</td> </tr> <tr> <td>Max ambient temperature /T-code</td> <td>85 °C / T4</td> <td>125 °C / T4</td> </tr> <tr> <td>Electrical connectors</td> <td colspan="2">For UL approved see overview page 1</td> </tr> </table> <table border="1" data-bbox="400 819 1465 891"> <tr> <td>Output signal</td> <td>Current</td> <td>Ratio-metric</td> <td>Absolute voltage</td> </tr> <tr> <td>Supply voltage</td> <td>9-32 V DC</td> <td>4,5 - 5,5 V DC (5V nom)</td> <td>9-32 V DC</td> </tr> </table>	Type	MBS 33, MBS 33M, MBS 3000 MBS 3050, MBS 4000, MBS 4003 MBS 4010	MBS 3200, MBS 3250, MBS 3300, MBS 3350 DST P300, DST P30M	Max ambient temperature /T-code	85 °C / T4	125 °C / T4	Electrical connectors	For UL approved see overview page 1		Output signal	Current	Ratio-metric	Absolute voltage	Supply voltage	9-32 V DC	4,5 - 5,5 V DC (5V nom)	9-32 V DC
Type	MBS 33, MBS 33M, MBS 3000 MBS 3050, MBS 4000, MBS 4003 MBS 4010	MBS 3200, MBS 3250, MBS 3300, MBS 3350 DST P300, DST P30M																	
Max ambient temperature /T-code	85 °C / T4	125 °C / T4																	
Electrical connectors	For UL approved see overview page 1																		
Output signal	Current	Ratio-metric	Absolute voltage																
Supply voltage	9-32 V DC	4,5 - 5,5 V DC (5V nom)	9-32 V DC																
	<p>ATEX ZONE 2</p>	<table border="1" data-bbox="400 909 1465 1032"> <tr> <td style="text-align: center;"> II 3G Ex ec IIA T4 Gc -20°C<Ta<+85°C </td> <td style="text-align: center;"> EN60079-0; EN60079-7 Applicable in Zone 2 electrical connectors see overview page 1. *Zone 2 not applicable for MBS 1700 and MBS 1750 </td> </tr> </table> <p>Applicable in ATEX Zone 2 with medias classified as IIA in accordance to EN 60079-20-1: Alle elektriske tilslutninger skal udføres iht. ATEX Zone 2 regulativet - samt EN 60079-14. All electrical connections must comply with the ATEX requirements for Zone 2 - and EN 60079-14. Alle elektrischen Anschlüsse müssen gemäß ATEX Zone2 Regeln und EN 60079-14 durchgeführt werden. Tous les raccordements électriques doivent être effectués conformément aux règles ATEX zone 2 et EN 60079-14. Todas las conexiones eléctricas deben ser realizadas de acuerdo a los requerimientos de la normativa ATEX zona 2 y EN 60079-14. Tutti i collegamenti elettrici devono essere eseguiti secondo le normative ATEX Zone e EN 60079-14.</p> <p>Tryktransmitteren skal installeres, hvor den ikke kan udsættes for stød ved normal brug The Pressure transmitter must be installed where it cannot be exposed to impact in normal use Der Drucktransmitter muss an einem Ort installiert werden, an dem er bei normalem Gebrauch keinen Stößen ausgesetzt werden kann Le transmetteur de pression doit être installé là où il ne peut pas être exposé à un impact en utilisation normale. El transmisor de presión debe instalarse donde no pueda estar expuesto a impactos en uso normal Il trasmettitore di pressione deve essere installato in posizione non esposta ad urti durante il normale utilizzo</p> <p>Note: Electrical Connector: Deutsch DT04- 4P Skal installeres i en indkapsling, der opfylder kravene til slagstyrke i henhold til EN 60079-0 Must be installed in an enclosure that complies with the impact requirements in accordance to EN 60079-0 Muss in ein Gehäuse eingebaut werden, das die Schlagfestigkeitsanforderungen nach EN 60079-0 erfüllt Doit être installé dans un boîtier conforme aux exigences en matière d'impact conformément à la norme EN 60079-0. Debe ser instalado en una cubierta que cumpla con los requisitos de impacto de acuerdo a EN 60079-0 Deve essere installato in un contenitore di protezione conforme ai requisiti di impatto secondo EN 60079-0</p>	 II 3G Ex ec IIA T4 Gc -20°C<Ta<+85°C	EN60079-0; EN60079-7 Applicable in Zone 2 electrical connectors see overview page 1. *Zone 2 not applicable for MBS 1700 and MBS 1750															
 II 3G Ex ec IIA T4 Gc -20°C<Ta<+85°C	EN60079-0; EN60079-7 Applicable in Zone 2 electrical connectors see overview page 1. *Zone 2 not applicable for MBS 1700 and MBS 1750																		
		<div style="display: flex; justify-content: space-around;"> <div data-bbox="400 1536 927 1720"> </div> <div data-bbox="927 1536 1481 1720"> </div> </div> <p>Stikket må ikke fjernes, når transmitteren er tilsluttet. Plug must not be removed when sensor is energized. Stecker darf nicht entfernt werden, wenn der sensor aktiviert ist. Le connecteur ne doit pas être retiré lorsque le capteur est encore sous tension. El conector no debe retirarse cuando el sensor esté activado. Il connettore elettrico non deve essere scollegato quando il sensore è in funzione.</p> <p>Kablet må ikke udsættes for nogen mekaniske skader, korrosion, vibration, varme eller UV stråling. Cable must neither be exposed for any mechanical damage, corrosion, vibration, heat nor UV radiation. Kabel müssen weder auf mechanische Beschädigungen, Korrosion, Vibration, Hitze noch UV-Strahlung ausgesetzt werden. Le câble ne doit être exposé à aucun dommage mécaniques, à la corrosion, aux vibrations, à la chaleur ou aux radiations UV. El cable no deber estar expuesto a ningún tipo de radiación, daños mecánicos, corrosión, vibraciones, calor ó UV. Il cavo non deve essere esposto a danni meccanici, corrosione, vibrazioni, fonti di calore o raggi UV.</p>																	

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.
 All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss Logo are trademarks of Danfoss A/S. All rights reserved.