


Service Guide

# HDU-SF (Horizontal Distribution Units - Single Flat)



Danfoss A/S is not liable or bound by warranty if these instructions are not adhered to during installation or service.

The English language is used for the original instructions.  
Other languages are a translation of the original instructions.  
(Directive 2006/42/EC)


© 2012 Copyright Danfoss A/S

## Table of Contents


<b>1</b>	<b>Introduction</b> .....	<b>3</b>
1.1	Overview .....	3
1.2	Technical Data .....	4
1.3	Accessories and Spare Parts .....	4
<b>2</b>	<b>Drain and Vent</b> .....	<b>4</b>
<b>3</b>	<b>Replacing the Strainer Filter</b> .....	<b>5</b>
<b>4</b>	<b>Shutting off the Flow</b> .....	<b>5</b>
<b>5</b>	<b>Heat Meter</b> .....	<b>5</b>
5.1	General .....	5
5.2	Power Supply .....	6
5.3	Operation .....	6
5.4	Display Indications .....	7
5.5	Error Codes .....	8
5.6	Extension Modules .....	8
<b>6</b>	<b>Replacing the Heat Meter</b> .....	<b>11</b>

## 1 Introduction

### 1.1 Overview



HDU-SF single-port



HDU-SF multi-port

1. Ball valve for in- and outlet connection to the riser.
2. Strainer to trap dirt, sand etc. from pipe water (replacement filter available as accessory).
3. AB-PM automatic balancing valve, combines three functions: differential pressure controller, control valve with linear characteristic and flow limiter.
4. Manifold for radiator connection, flow.
5. Manifold for radiator connection, return.
6. Automatic air vent and drainage (both inlet and outlet has drainage and air vent possibilities).
7. Heat meter for energy measuring, with 8-digit LCD.
8. Cabinet.

**Note!** HDU-SF are available with left or right side connections to riser. In this Service Guide all illustrations are shown for the *left side* version.

### 1.2 Technical Data

Max. temperature	90 °C
Max. working pressure	2 bar
Nominal required differential pressure over Unit (HDU-SF)	0.26 bar*
Max. differential pressure in a control loop	0.22 bar
Max. static pressure	10 bar (PN 10)
Connection to riser (in and out)	R 3/4"
Connection to radiator	3/4"
Power supply (Heat meter)	A-cell battery, 3.6 VDC

\* At differential pressure in control loop 10kPa at 100% AB-PM setting.

### 1.3 Accessories and Spare Parts


Product	Code no.
Manifold port plugs (10 pcs.)	<b>003L1246</b>
Filter for strainer	<b>065B8248</b>
Impulse tube with fittings for AB-PM	<b>003L8152</b>

## 2 Drain and Vent

For draining the inlet and outlet:


- close ball valves on supply and return inlet pipes.
- use the cap hanging on the drain to open the drain.

The HDU-SF is automatically vented, if necessary.




### 3 Replacing the Strainer Filter

1. Close ball valves on supply and return inlet pipes.
2. Close all inlet manifold circuits after the AB-PM, using a 5 mm Allen key.
3. Remove the strainer cap and replace the filter.




### 4 Shutting off the Flow

1. Close both ball valves to shut off all radiator circuits in the apartment.
2. Use the manual shut off in the manifold to close a single radiator circuit., using a 5 mm Allen key. Make sure to close both inlet and outlet for the circuit.



### 5 Heat Meter

#### 5.1 General



The following guidelines must be observed:

- The cables supplied with the meter must not be shortened or changed in any other way.
- The regulations on the use of energy meters must be observed!
- The meter installation is only to be performed by an authorized installer and/or electrical contractor using personnel trained in the installation and use of electrical equipment and familiar with the Low Voltage Directive.
- The specified operating/ambient conditions are 5 ... 55 °C; IP54; 93 % rel. humidity.

The IZAR@SET software is used for readout/parametrization.

## 5.2 Power Supply

- A 3.6 V DC lithium battery is fitted in the heat meter.
- The battery is not to be charged or short-circuited.
- Ambient temperatures below 40 °C extend the life of the battery.
- Used batteries must be disposed of according to the applicable regulations.

### Caution!


Risk of explosion if the battery is replaced by an incorrect type.

## 5.3 Operation

### Display

The meter readings are displayed with units and symbols on an 8-digit LCD.

1. Quadrant display
2. Loop display
3. Tariff energy
4. Error symbol
5. Maximum values
6. Flow rate indicator



### Simple operation


A pushbutton mounted on the front of the meter is used to switch to the various displays.

To show the data read out by the integrator in the display (e.g. amount of energy, operating hours, volume of water, current temperatures, ...), various windows that can be called up in succession are used.

The meter has 6 different display loops: main loop, set day loop, information loop, pulse input loop, tariff loop and month loop.

The window content of each loop is programmed with the standard information ex works. Various display windows comprise two (seven) displays that change successively at intervals of 2 - 4 s. The loops in the display are numbered from 1 to 6 to help the user find his way around quickly. The main loop (loop 1) is programmed with the current data as default setting, e.g. for energy, volume, flow rate.

A few fragments of the loops or even whole loops can be turned off, using the IZAR@SET software. It simplifies arrangement of the windows.



1. Loop display (for loop 1)

The pushbutton is used to switch through the various displays. The button can be pressed for a short or a long time:

Button press	Result
Short press (< 3 seconds)	Switches to the next display within a loop
Long press (> 3 seconds)	Switches to the next display loop
Button not pressed for 4 minutes	Meter switches off the display automatically (to save power, but only if no error exists)
Button pressed again	Meter shows the basic display

## 5.4 Display Indications

Loop	Sequence	Window 1	Window 2
"1" Main loop	1.1	Accumulated energy	
	1.2	Volume	
	1.3	Flow	
	1.4	Power	
	1.5	Forward temperature	Return temperature
	1.6	Difference temperature	
	1.7	Operating days	
	1.9	Error status	
	1.10	Display test	

Loop	Sequence	Window 1	Window 2	Window 3
"2" Accounting date loop	2.1	Accounting date 1 (date 1)	Accounting date 1 energy	'Accd 1A'
	2.2	Next accounting date 1 (date 1)	Next accounting date 1 energy	'Accd 1L'
	2.3	Previous accounting date 1 (date 1)	Previous accounting date 1 energy	'Accd 1'
	2.4	'Accd 1'	Date of next accounting date 1	
	2.5	Accounting date 2 (date 2)	Accounting date 2 energy	'Accd 2A'
	2.6	Next accounting date 2 (date 2)	Next accounting date 2 energy	'Accd 2L'
	2.7	Previous accounting date 2 (date 2)	Previous accounting date 2 energy	'Accd 2'
	2.8	'Accd 2'	Date of next accounting date 2	

Loop	Sequence	Window 1	Window 2
"3" Info loop	3.1	Current date	
	3.2	'SEC_Adr'	Secondary address
	3.3	'Pri_Adr 1'	Primary address 1
	3.4	'Pri_Adr 2'	Primary address 2
	3.5	Installation position	
	3.6	'Port 1'	No. of the mounted module at port 1
	3.7	'Port 2'	No. of the mounted module at port 2
	3.8	Status integrated radio	(Sequence will be shown only in meters with integrated radio)
	3.9	No. of error hours	
	3.10	'F01-001' (software version)	Checksum

Loop	Sequence	Window 1	Window 2	Window 3
"4" Pulse input loop	4.1	'In1'	Accumulated values pulse input 1	'PPI' pulse value 1
	4.2	'In2'	Accumulated values pulse input 2	'PPI' pulse value 2

Loop	Se-quence	Window 1	Window 2	Window 3	Window 4	Window 5	Window 6	Window 7
"5" Tariff loop		The tariff loop is switched off as a standard at the heat meter or meter for cooling.						

Loop	Se-quence	Window 1	Window 2	Window 3	Window 4	Window 5	Window 6
"6" Monthly value loop	6.1	'Date last month'	Accumulated energy	Energy	Tariff 1	Tariff 2	Volume
	6.2	'Date month - 1'	date month - 1	Energy	Tariff 1	Tariff 2	Volume
	6.3	'Date month - 2'	date month - 2	Energy	Tariff 1	Tariff 2	Volume
	...						
	6.24	'Date month - 23'	date month - 23	Energy	Tariff 1	Tariff 2	Volume

### 5.5 Error Codes

The error code is displayed in the main loop if an error occurs. The error display disappears automatically as soon as the cause of the error has been cleared. All errors present longer than 6 minutes are saved in the error log.

Error display	Error description
C - 1	Basic parameter error in flash or RAM
E 1	Temperature measuring error <ul style="list-style-type: none"> <li>▪ temperature range exceeds [-9.9 C...190 C]</li> <li>▪ sensor short-circuit</li> <li>▪ sensor break</li> </ul>
E 3	Forward and return sensor reversed
E 4	Hardware error in ultrasonic measurement <ul style="list-style-type: none"> <li>▪ transducer/drive defective</li> <li>▪ transducer/drive short-circuit</li> </ul>
E 5	Communication not possible (too frequent reading)
E 6	Wrong direction of flow in volume measuring component
E 7	No primary power supply (only if mains unit used)  Supply is via back-up battery
E 8	Warning! Battery almost flat. Battery should be replaced.
E 9	Warning! Battery almost flat. Battery should be replaced.
E A*	Leakage: pipe break detected
E b*	Leakage: leakage detected in energy meter
E C*	Leakage: leakage pulse input 1
E d*	Leakage: leakage pulse input 2

\* optional

### 5.6 Extension Modules


The Heat Meter has two slots for extension modules. These modules have no effect on consumption recording and can be fitted without damaging the verification mark.:

Slot 1	Slot 2
Pulse In (2x)	Pulse In (2x)
Pulse In (2x) / Out (1x)	Pulse Out (2x)
RS232	Pulse In (2x) / Out (1x)
M-Bus	RS232
RS485	M-Bus
L-BUS (for external radio)	RS485
Analogue Out (4-20 mA)	L-BUS (for external radio)



### Installation of modules

1. Open the integrator by releasing the side catches.
2. Engage the module in the relevant slot and carefully connect the pre-formed ribbon cable at both ends.
3. Close the lid and check the meter for correct operation by pressing the push button.



### Communication modules (upon order)

The meter supports two communication channels over the same or different interfaces. An additional communication module can be used in radio operation. The protocol is different for each of the two channels and is preset ex works, but can be set to customer-specific requirements using the IZAR@Set software.


Each channel has its own primary address, but only one secondary address exists, which is set to the serial number ex works.

### M-Bus

The M-Bus communication module is a serial interface for communication with external M-Bus control centre. The module contains a 2-pole terminal strip with terminals marked 24, 25, which are connected to M-Bus control centre.

M-Bus protocol to EN 1434-3 standard:

- Connection for 2 x 2.5 mm<sup>2</sup> wires
- The connection is electrically isolated
- Current drawn: one M-Bus load



### L-Bus

The L-Bus module is an adapter for an external radio module. Packet length can be configured, conforms to EN1434-3. Data reading and parametrization are carried out using two-wire scheme with different polarity.

### Communication over radio

The integrated radio module is an interface for communication with Hydrometer radio receivers.

Unidirectional communication has the following specification:


- The module sends every 6 ... 25 s (variable, depending on protocol length)
- The radio module always accesses the current meter registers
- Transmission frequency: 868 MHz or 434 MHz
- Various Hydrometer receivers are available for receiving the protocol (e.g. Bluetooth, GPRS, LAN, ...)
- The protocol corresponds to the Open Metering or HYD standard and is encrypted
- Reading modes: walk-by, drive-by, fixed network

### RS232 communication module

The RS232 communication module is a serial interface for communication with external devices, e.g. PC.

The module contains a 3-pole terminal strip with terminals marked 62(Dat), 63(Req) and 64(GND). A special adapter cable is required for connection (order no. 087H0121). The coloured wires are to be connected as shown:


- 62 = brown
- 63 = white
- 64 = green



### RS485 communication module

The RS485 communication module is a serial interface for communication with external devices, e.g. PC.

The module contains a 4-pole terminal strip with terminals marked D+, D-, and +12V-. The module needs an external power supply of 12 V DC  $\pm$ 5 V.



### Pulse input function module

Module for two additional pulse counters. The module contains a 4-pole terminal strip with pulse input 1 marked as "I1 - |\_" and input 2 as "I2 - |\_".


- Pulse inputs 1 and 2 are programmable for a value of: 1, 2.5, 10, 25, 100, 250, 1000, 2500 litres per pulse.
- Possible units are all the energy units available in the meter, the volume unit m<sup>3</sup> or no unit
- Input frequency is in the range < 8 Hz.

Min. pulse duration 10 ms.

- Input resistance 2.2 M $\Omega$ .

Terminal voltage 3 V DC.

- Data is accumulated separately in registers
- Data is readable as IN1 and IN2 in the display and can be transmitted over the communication modules
- Cable length up to 10 m



### Pulse output function module

The module contains connections for 2 pulse outputs, proportional to the flow or heat consumption. The module contains a 4-pole terminal strip with pulse output 1 marked as "O1 - |\_" and output 2 as "O2 - |\_".

External supply: Vcc = 3-30 V DC

Output current < 20 mA with a residual voltage of < 0.5 V Open collector (drain) Electrically isolated Output 1: f < 4 Hz

Pulse duration: 125 ms  $\pm$ 10 %



Pulse break: > 125 ms -10 %

Output 1:

- Output frequency: f < 4 Hz
- Pulse duration: 125 ms  $\pm$ 10 %
- Pulse break: > 125 ms -10 %


Output 2:

- Output frequency: f < 100 Hz
- Pulse duration
- Pulse break ~1:1
- Volume pulse value is programmable as desired



### Combined function module


The combined module is equipped with 2 inputs and 1 output. The pulse input specification is the same as that of the pulse input module above. The pulse output specification is the same as pulse output module above, but not electrically isolated.



### Analogue output function module

The module contains connections for 2 passive analogue outputs, which can be programmed as desired using the IZAR@SET software. The outputs are marked on the terminal strip as "1" and "2" with the respective polarity "+" and "-". When connecting to outputs, one should observe polarity.

- Passive analog output
- External power supply: 10...30 V DC
- Current loop 4 ... 20 mA
- Errors are generated at 3.5 mA or 22.6 mA (programmable)
- Output values: power, flow rate, temperatures



### Test output


This test output located on the side is intended for use by test centres. The manufacturer provides two special cables for this: 1. Volume test pulses and 2. Energy test pulses. Other specifications (pulse value, pulse duration/break, pulse frequency) can be obtained from the Inspection and Test Instruction.

## 6 Replacing the Heat Meter

### Ordering a new Heat Meter


A new Heat Meter can be ordered at Danfoss by using the informations on the existing Heat Meter:

1. Product name
2. Ordering number
3. Production year




### Removing the existing Heat Meter

1. Close both shut-off valves.
2. Manually close all ports on the return manifold with a 5 mm Allen key.
3. Loosen the Allen screw and pull out the temperature sensor from the manifold pocket.
4. Remove the Heat Meter electronic by sliding it off the bracket.
5. Remove the brass part from the return flow (remember backstop to prevent the shut-off valves from loosening).



### Installing a new Heat Meter

1. Install the brass part, use 2 new flat gaskets and remember backstop to prevent the ball valves from loosening. Make sure the arrow is placed in accordance with the flow direction.
2. Slide the Heat Meter electronic onto the bracket.
3. Handle the temperature sensors with care! Make sure that the sensor is inserted as deep as possible in the manifold pocket and secured with the Allen screw.



1. Arrow indication direction
2. Direction of flow

### Please note! Check function of the new Heat Meter

The Heat Meter will only measure energy if the pipes are completely filled with water, otherwise a corresponding error message (E - 7) is shown in the display.

Check the flow rate and temperature display for plausibility. If the flow rate display is not steady, bleed the system.

### Error messages for wrong installation

- E - 3: Temperature sensors reversed during installation or connection.
- E - 6: Heat Meter has not been installed in the intended flow direction.







Danfoss A/S  
Heating Solutions  
Haarupvaenget 11  
8600 Silkeborg  
Denmark  
Phone: +45 7488 8000  
Fax: +45 7488 8100  
Email: [heating.solutions@danfoss.com](mailto:heating.solutions@danfoss.com)  
[www.heating.danfoss.com](http://www.heating.danfoss.com)

---

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss Heating Solutions and the Danfoss Heating Solutions logotype are trademarks of Danfoss A/S. All rights reserved.

---