

ENGINEERING
TOMORROW

Danfoss

Operator's Manual

ET5025 Crimping Machine



Imprint

Manufacturer:

UNIFLEX-Hydraulik GmbH
Robert-Bosch-Strasse 50-52
D-61184 Karben
Germany

Phone: +49 (0) 60 39 / 91 71 - 0
Fax: +49 (0) 60 39 / 91 71 - 181

This Operating Manual of the machine is a translation; the original is in German.

Date of revision: 2024-07-22

Version: 1.1

© Copyright by UNIFLEX-Hydraulik GmbH

Technical modifications reserved.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without explicit authorization are prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

EC / UK - Declaration of Conformity

In accordance with EC Machinery Directive 2006/42/EC and UK-Supply of Machinery (Safety) Regulations 2008.

The following machine

ET5025

was developed, designed and manufactured in compliance with EC Directive 2006/42/EC and UK-Supply of Machinery (Safety) Regulations 2008, in the sole responsibility of

UNIFLEX-Hydraulik GmbH
Robert-Bosch-Strasse 50 - 52
D-61184 Karben

The following standards, codes and specifications have been applied:

- EC Directive 2006/42/EC
- EMC Directive 2014/30/EC
- EN ISO 12100: 2010
- EN 60204-1: 2018
- UK-Supply of Machinery (Safety) Regulations 2008
- UK-Electromagnetic Compatibility Regulations 2016

This declaration are invalid when the machine is modified or if unauthorized and unapproved third-party components are used without our prior approval.

Entity authorised for documentation: Uniflex-Hydraulik GmbH, Technical Documentation Dept.

Karben, 16.02.2022



Managing Director Harald von Waitz

Contents

1	About this document	7
1.1	Target groups	7
1.2	Storage	9
1.3	Name plate	9
1.4	Abbreviations	9
2	Safety instructions	10
2.1	Presentation of warnings	10
2.2	Intended use	10
2.3	Product-specific risks	11
2.3.1	Risks imposed by mechanical equipment	12
2.3.2	Risks imposed by electricity	12
2.3.3	Risks imposed by hydraulic equipment	12
2.3.4	Risks imposed by noise	13
2.3.5	Risks imposed by substances	13
2.3.6	Risk by hot surfaces	13
2.3.7	Risks in case of fire	13
2.4	Safety	14
2.4.1	Working area	14
2.4.2	Emergency-stop button	15
2.4.3	Protection equipment	15
2.4.4	Warning signs on the machine	16
3	Machine description	18
3.1	Design and function	18
3.2	Accessories	19
3.3	Forming process	19
3.4	Operation and display elements IPC	21
3.5	Electric sockets	22
3.6	Foot pedal (accessory)	23
3.7	Depth stop (accessory)	24
3.8	Operation modes	24
3.9	Technical data	27
4	Transport and commissioning	30
4.1	Transport	30

Contents

4.2	Intermediate storage of machine/unit.....	31
4.3	Commissioning	31
4.3.1	Filling hydraulic oil	32
4.3.2	Electrical connection.....	34
4.3.3	Bleeding the hydraulic system	36
5	Operation	37
5.1	What you have to observe	37
5.2	Activation	37
5.3	Forming the workpiece.....	38
5.3.1	Prerequisites.....	38
5.3.2	Operation mode buttons control panel.....	38
5.3.3	Remote automatic mode, via dual foot switch	40
5.3.4	Remote automatic mode, via depth stop	41
5.3.5	Changing the crimping dies with the quick die change system (only profile 239).....	42
5.4	Adjusting the depth stop	44
5.5	Setting the forming dimension	46
5.6	Stop	47
5.7	Emergency stop.....	47
5.8	Cleaning.....	48
6	Maintenance.....	49
6.1	What you have to observe	49
6.2	Maintenance schedule.....	49
6.3	Hydraulic oil change.....	51
6.4	Checking and replacing slide bearing plates.....	53
6.5	Replacement of relay/opto-coupler	55
7	Troubleshooting	56
8	Decommissioning, disposal	57
8.1	Dismantling	58
8.2	Recycling	58
8.3	Consumables and waste.....	58
9	Annex	59
9.1	Accessories (retrofitable)	59
9.2	Spare parts list.....	60
9.2.1	Mechanical equipment.....	60
9.2.2	Hydraulic system	64

Contents

9.2.3	Electric equipment.....	66
9.3	Depth stop, manual	67
9.4	Depth stop, automatic.....	68
9.5	Spare parts kit	69
9.6	Retaining bolt for standard crimping dies (depending on crimping die)	70
9.7	Hydraulic diagram.....	72
9.8	Electric diagram.....	73
9.9	Maintenance log	81
9.10	Declaration of qualified staff	82

1 About this document

1.1 Target groups

1 About this document

In this Operation Manual, the “forming machine ET5025” is consistently referred to as machine.

This Operation Manual includes important notes on how you operate your machine/unit safely, properly and economically.

Use not in compliance with the intended purpose may result in hazard to the operator's health and life and/or in the risk of damage to/the machine/unit. Consequently, please only use the machine/unit

- in good order and condition,
- in accordance with its intended purpose,
- in a safety-conscious manner, with awareness of risks and hazards,
- in compliance with all notes included in this Operation Manual.

The machine/unit may only be operated by staff who

- has read the Operation Manual,
- has understood it,
- has been instructed in the operation of the machine/unit, and
- has signed in the Annex.



Figures may include accessories/options. Customer-specific equipment may vary.

The product images shown are for reference only and may differ from the product delivered.

1.1 Target groups

The target groups of this Operation Manual are:

Owner

An owner is a natural person or entity using the device himself/herself/itself, or on whose behalf the device is used. An owner may appoint a representative to exercise the owner's rights and obligations.

The owner has to make sure that

1 About this document

1.1 Target groups

- national provisions, occupational safety regulations and applicable environmental protection regulations are fully complied with;
- persons working on the machine/unit are adequately qualified;
- persons working on the machine/unit are suitable for operating the machine/unit;
- the Operation Manual has been read and understood. One hardcopy of the Operation Manual must always be kept at a designated place where the machine/unit is used.
- persons working on the machine/unit are aware of potential risks;
- the operating staff is familiar with the location as well as with operating the fire alarm and fighting means. Free access to this equipment must be ensured.
- personal protection equipment is worn (safety footwear, protection gloves and safety glasses).

Machine/unit fitters

Machine/unit fitters must be at least 18 years old and have completed training for the task, i.e. they must have attended a specialist vocational training.

A fitter

- must observe the instructions in the Operation Manual;
- must inform the owner on failures and damage.

Operator

An operator is a person charged with and instructed in the proper operation of the machine/unit by the owner or the otherwise contractually obliged person.

The operator

- must observe the instructions in the Operation Manual;
- must inform the owner on failures and damage.
- must not perform and maintenance or repair work on the machine/unit.

1 About this document

1.2 Storage

1.2 Storage

The Operation Manual is part of the machine/unit and must be kept near the machine/unit at all times. Upon disposal of the machine/unit, the Operation Manual must also be handed over.

1.3 Name plate

The name plate is fixed near the power cable.

1.4 Abbreviations

CFM	Crimp Force Monitoring
FD	Manual Flow Divider
PB	Crimping dies
PBK	Calibration crimping dies
PFC	Pressure Force Control
PFM	Pressure Force Monitoring
QDC	Quick crimping die change system
ZWB	Intermediate dies

2 Safety instructions

2.1 Presentation of warnings

Warning notes in the Operation Manual warn against risks involved with the handling of the machine/unit. Risk levels are identified as follows:

HAZARD!

The signal word HAZARD identifies an imminent hazard resulting in serious injuries or death. This warning is supplemented by a triangular hazard symbol.

WARNING!

The signal word WARNING identifies a potentially hazardous situation, which might result in serious injuries or death. This warning is supplemented by a triangular hazard symbol.

CAUTION!

The signal word CAUTION identifies a potentially hazardous situation, which might result in light injuries. This warning is supplemented by a triangular hazard symbol.

ATTENTION!

The signal word ATTENTION identifies a potentially hazardous situation, in which the product or property in the environment may be damaged. This warning is supplemented by a hazard symbol or an exclamation mark.

2.2 Intended use

This machine is a forming machine for industrial use, only suitable for the manufacture of hose connections with a permissible diameter depending on the fitting and the hose thickness, see “Technical Data” in Section 3.

Intended purposes include:

- single workplace for one person only,
- single stroke with manual feed and withdrawal,
- for maximum hydraulic operating pressure, see “Technical Data” in Section 3.
- operating temperature between 10 °C and 35 °C,
- operation in a closed room,
- use of eight identical original UNIFLEX dies with the same label or seven dies and one associated marking crimping die.

2 Safety instructions

2.3 Product-specific risks

- The machine must not be operated by persons not capable of operating the machine without any risk. These may include:
 - persons with physical or mental disabilities;
 - children and persons under age;
 - persons with a restricted capability for the operation of machines (e.g. under the influence of drugs, alcohol or narcotics)

Use of the control in compliance with the intended purpose also includes compliance with the instructions in this Operation Manual.

Use for other than the intended purpose

Any other use is considered as being not in compliance with the intended purpose, in particular:

- design modification of the machine;
- use in explosive environments;
- forming of non-metal workpieces without specific safeguards approved by UNIFLEX;
- misuse of consumables and waste materials.

In particular non-metal workpieces may be overstressed by the forming process so that this may result in a sudden failure. Chips or seriously accelerated workpiece parts impose a high risk potential for operators, individuals and objects, even outside the working area.

WARNING!



Risk for life and health!

Use not in compliance with the intended purpose imposes risks for life and health. Consequences resulting from use for other than the intended purpose shall be under the sole responsibility of the owner.

- Always use the machine in compliance with its intended purpose.

2.3 Product-specific risks

The machine/unit is designed in accordance with the latest state of technology. Nevertheless, the machine/unit may impose risks:

2 Safety instructions

2.3 Product-specific risks

2.3.1 Risks imposed by mechanical equipment

Risk of squeezing

When the die system closes, there is a risk of getting squeezed between the die and the workpiece.

- Keep the feed opening for the workpiece as small as possible.
- Keep sufficient distance to the die system.

Tilting hazard

The risk of tilting mainly exists while the machine is being transported.

- Observe the machine's centre of gravity during transport.

2.3.2 Risks imposed by electricity

There is a risk of electrocution near the live parts!

- Work on electric systems may only be performed by qualified electricians or instructed and trained persons under the supervision of a qualified electrician.
- Deactivate the machine/unit and secure it against unintentional restart before maintenance.

2.3.3 Risks imposed by hydraulic equipment

Risks are imposed by all hydraulic lines and connections. Hydraulic systems are subject to special safety provisions. Work on hydraulic equipment may only be performed by persons with expert knowledge of and experience with hydraulic equipment.

- After the machine/unit is deactivated, the given and potentially hazardous residual energy has to be considered.
- Relieve the residual pressure in the system before performing repair or maintenance work on hydraulic systems.
- Regularly check lines and bolted connections for leaks and visible damage. Immediately remedy any damage detected.

Repair work on the hydraulic system of the machine/unit or on its components may only be performed by UNIFLEX specialist staff.

2 Safety instructions

2.3 Product-specific risks

2.3.4 Risks imposed by noise

The noise level meter acc. to IEC 804, Class 2, was calibrated before measuring.

The operation of the machine/unit causes noise emissions of 70 dB(A) at the workplace. Noise protection is not required.

Higher noise emissions may occur when other machine/unit is simultaneously used at the workplace. The machine/unit owner must provide for appropriate protection, e.g.

- instruct staff to wear ear protection,
- provide information/instructions on risks,
- identify hazardous areas,
- provide health monitoring.

2.3.5 Risks imposed by substances

Oils, greases and emulsions may penetrate the skin. When handling hazardous substances, oils and greases, the manufacturers' safety instructions have to be observed. Apply skin protection appropriate for the hazardous substances used.

2.3.6 Risk by hot surfaces

There is a risk of burning when the electric motor and/or the workpiece are touched after forming.

- Keep sufficient distance to the electric motor.
- Wear protection gloves.


2.3.7 Risks in case of fire

The operating staff has to be familiar with the location as well as with operating the fire alarm and fighting means. Free access to this equipment must be ensured.

Never use water to extinguish a fire. For appropriate fire extinguishing action, please read the safety data sheet of the hydraulic oil supplier.

2.4 Safety

2.4.1 Working area



The working area is designed as the area 1 metre all around the machine (shaded).


- Keep the working area free from trip hazards
- Use ducts for lines and cables
- Provide good illumination
- Keep access to hydraulic supply free

2 Safety instructions

2.4 Safety

2.4.2 Emergency-stop button

The machine is fitted with an emergency-stop button on the control panel.



Immediately activate the emergency-stop button (1) in cases of emergency.

Remedy the cause of the emergency stop first before unlocking the emergency-stop button.

Do not pull the emergency-stop button for unlocking it, but release it by rotating it.

2.4.3 Protection equipment

Due to the variety of customer-specific workpieces, UNIFLEX is not capable of supplying additional standard protection equipment together with the machine for the prevention of potential residual risks imposed by the machine.

The necessity of additional, workpiece-specific protection equipment may for instance arise for angled workpiece geometries needing a large opening for being inserted into the forming machine. The pressure joining of insulators, structural steel and steel ropes, too, may require special safeguards.

The owner has to consider the need for adapted protection equipment before commissioning. If such need exists, the relevant protection equipment has to be mounted before commissioning of the machine.


UNIFLEX will provide you with customized solutions for protection equipment upon request. Please do not hesitate to address your personal contact for consultation.




2 Safety instructions

2.4 Safety

Mounted safety equipment must not be removed, bypassed or avoided.

2.4.4 Warning signs on the machine



	Hand injury on the die system
	Risk of squeezing on the die system
	Hot surface on the electric motor
	Oiling / greasing prohibited on the die system

2 Safety instructions


2.4 Safety

Illegible or missing warning signs must immediately be replaced by the owner.

3 Machine description

3.1 Design and function

Basic machine



- (1) Crimping tool
- (2) Control cabinet
- (3) Unit (comprising electric motor, pump, control block)
- (4) Position encoder system
- (5) Control panel with buttons and control system IPC

The crimping tool (1) is closed hydraulically, whereby the workpiece is formed. The pressure needed for this purpose is built up by the electrically driven pump (3) in the cylinders.

The position encoder system (4) records the current position of the die system and transfers the value to the control system.


Data records may be saved in the item memory and recalled at any time in the control system. Depending on the operation mode, the

3 Machine description

3.2 Accessories

actual forming process is controlled via the buttons on the control panel (5), the depth stop or the dual foot switch.

Crimping tool



The die system comprises basic dies and crimping dies.

All basic dies (4) are supported on sliding plates (3). The crimping dies (1) are plugged onto the basic dies (4).

After the forming process, the basic dies (4) are pressed apart by the springs (5) when the tool opens. The holding plates (2) guide the basic dies axially in the tool.

3.2 Accessories

The machine may be fitted with accessories. A list of the available accessories is included in the Annex, Section "Accessories".

3.3 Forming process

There are two types of forming process with different target parameters:

- Forming to a defined diameter

3 Machine description

3.3 Forming process

- Forming to a defined pressure

Forming to a defined diameter

This is the standard process for forming to produce hydraulic hoses. The crimping tool closes until it reaches a pre-set diameter, regardless of the required forming force. The required forming force may be up to the machine's maximum capacity.

Optionally, it is possible to monitor the required forming pressure (= forming force) at the time when the pre-set diameter is reached, in order to detect workpiece deviations (PFM option: Pressure Force Monitoring).

Forming to a defined pressure

This process is used for special applications, e.g. insulators with a fibreglass rod, which are pressure-sensitive. Due to the workpiece tolerances, forming to a specific diameter could result in the destruction of the workpiece. The crimping tool closes until the pre-set pressure value is reached; there is no pressure control.

Optionally, it is possible to monitor the obtained forming diameter at the time when the pre-set pressure is reached, in order to detect workpiece deviations (PFM option: Pressure Force Monitoring).

Optional pressure control to the requested pre-set pressure, including the possibility to vary the pressure built-up speed and soft approach of the pre-set pressure (PFC function: Pressure Force Control).

WARNING!



Risk of injuries!

In particular non-metal workpieces may be overstressed by the forming process so that this may result in a sudden failure. Chips or seriously accelerated workpiece parts impose a high risk potential for operators, individuals and objects, even outside the working area!

- Relevant workpieces should only be formed using specific safeguards.

3 Machine description

3.4 Operation and display elements IPC

ATTENTION!




Risk of damage to machinery!

The machine lifetime is reduced with a high permanent load, while wear increases disproportionately.

- When using the machine in series production, it must not permanently be loaded with over 2/3 of the maximum operating pressure.
- The especially high load during pressure joining of isolators, structural steel as well as steel ropes (PFC applications) necessitates machine overhauls after 150,000 forming processes, each. Please contact our Service department in due time: +49 (0)6039 9171-0.

3.4 Operation and display elements IPC



- (1) RFID-Reader
- (2) Illuminated Close tool button [→|←]
- (3) Illuminated Open tool button [←|→]
- (4) Illuminated foot switch [↖]
- (5) Motor off button [0]
- (6) Illuminated Motor on button [I]
- (7) 2 x USB sockets


3 Machine description

3.5 Electric sockets

- (8) Emergency-stop button
- (9) Control panel of CONTROL IPC




The operation of the control system CONTROL IPC is described in a separate Operation Manual. This description is supplied with the machine.



- (1) LAN socket for connection with a network. Network connection options are set out in the description of the relevant optional packages.
- (2) USB socket (for the use of memory media, callipers or bar-code scanners certified by UNIFLEX, only)

3.5 Electric sockets



- (1) Main power switch
- (2) Socket for single foot switch

3 Machine description

3.6 Foot pedal (accessory)

- (3) Power cable screw connection
- (4) Socket for depth stop / dual foot switch
- (5) Control panel connection

3.6 Foot pedal (accessory)



- (1) Close machine pedal [→|←]
- (2) Open machine pedal [←|→]

WARNING!




Risk by fatiguing posture!

A static posture may result in work-related musculoskeletal disorders and reduce productivity.

- Make sure that operators have sufficient periods of relief and recreation.

3.7 Depth stop (accessory)




- (1) Angle clamp
- (2) Stop disc
- (3) Pressure spring
- (4) Clamp lever
- (5) Sleeve
- (6) Connection cable with plunger switch
- (7) Foot clamp
- (8) Clamp lever
- (9) Pipe
- (10) Cross clamp
- (11) Hollow profile

3.8 Operation modes

The control unit provides for the following operation modes for operating the forming tool:

- Manual operation

C.2  / IPC  is activated in the control. The forming

3 Machine description



3.8 Operation modes

process is controlled manually via the buttons on the control panel or external buttons (depth stop or dual foot switch):

- Activate the [↔] button for closing and forming. The [↔] button is used for opening.
- Dual foot switch
The right foot switch is used for closing and forming. The left foot switch is used for opening.
- Depth stop
The tool is closed automatically when the workpiece activates the depth stop by pressure. Press the [↔] button to open the tool.

As soon as the pre-set forming diameter or forming pressure is reached in the control, the tool stops and opens automatically.

- Semi-automatic operation

C.2  / IPC  is activated in the control. The forming process is started manually via the buttons on the control panel or external buttons, e.g. the dual foot switch:

- Activate the [↔] button for closing and forming.
- Dual foot switch
The right foot switch is used for closing.
- Depth stop
The tool is closed automatically when the workpiece activates the depth stop by pressure.


As soon as the forming diameter or forming pressure as defined in the control is reached, the tool stops and opens automatically after the preset holding time.

Production is possible in any operation mode.



The operation mode selected before deactivating the machine will be active upon a restart. The operation modes are set on the control panel.



When the Foot switch button  is activated, the Close tool button [↔] is inoperative, even if the button is illuminated. The Open tool button [↔] is always active independently.

3 Machine description

3.8 Operation modes



The operation of the control system is described in a separate Operation Manual. This description is supplied with the machine.

3 Machine description

3.9 Technical data

3.9 Technical data

Machine

Dimensions L x W x H	645 x 560 x 1470 mm
Weight	approx. 470 kg
Control	IPC
Operation mode	S6-70 %
Noise level	70 dB(A)*
Protection class	IP 40

Function

Forming force	1600 kN / 160 t
Forming force is adjustable on C.2 control	750 kN / 75 t
Max. forming range	Ø dies + 12 mm (max. outer diameter of the fittings before forming)
Maximum Ø dies	+ 70 mm
Opening size without dies	+ 110 mm
Opening distance	+ +40 mm
Closing speed	18.5 mm/s
Forming speed	1.5 mm/s
Forming speed is adjustable on C.2 control	3.5 mm/s
Opening speed	18.5 mm/s

3 Machine description

3.9 Technical data

Workpiece capacity

SAE R13 1 Part Fitting	1 1/2", depending on the fitting
SAE R13 2 Part Fitting	1", depending on the fitting
SAE R12 2 Part Fitting	1 1/4", depending on the fitting
SAE R15 2 Part Fitting	1", depending on the fitting
Industry	2", without flange, depending on fitting
Die type	239

Electric connection

Connection power	4 kW
Supply voltage adjustable	380 V 50/60 Hz, 3 phases+PE
Back-up fuse	400 V: 16 A delayed, preferably thermal fuses, if circuit breakers are used these should be of the class C type

Hydraulic system

Oil volume	approx. 80 l
Oil type	HLP 46, DIN 51524, 10 μ filtered
System pressure	max. 280 bar

Building prerequisites

Permanent floor loading	Approx. 0.07 kg/mm ²
Floor carrying capacity	Min. 2500 kg/m ²
Floor quality	B25
Evenness	Max. unevenness 5 mm/m
Inclination	max. 5 mm/m

3 Machine description

3.9 Technical data

Ambient conditions

Ambient temperature 10 °C – 35 °C

Air humidity 45 % – 65 %

The *data are theoretical/computed values, or values measured on a prototype. Actual values may vary slightly, depending on the machine.


4 Transport and commissioning

4.1 Transport

4 Transport and commissioning

4.1 Transport

The goods should be transported in the original packaging. During transport, the goods must be secured safely within the packaging. All applicable laws and regulations relating to securing loads shall be observed during transport.



The machine/unit may only be unloaded and transported by means of a forklift, a lift truck or a crane. When a crane is used for transport, lifting gear with a sufficient length and lifting capacity has to be used. For machine/unit weight, please refer to "Technical data" in Section 3.

WARNING!



Danger from falling loads!

Risk of injury from falling loads.

- Do not stand under suspended loads.

4 Transport and commissioning

4.2 Intermediate storage of machine/unit

WARNING!



Danger from tilting machine/unit!

The machine/unit may tilt if it is transported improperly. There is a risk of being injured.

- Consider the machine/unit's centre of gravity (1).
- Only lift the machine/unit at the designated points.

1. Lift the machine/unit with a forklift, lift truck or crane at the designated points (2) and transfer it to the location of installation.

4.2 Intermediate storage of machine/unit

If the machine/unit cannot be mounted immediately upon delivery, it must be protected against:

- Contamination,
- Weather influences,
- Mechanical damage.

The machine/unit components may only be stored in closed rooms and under the following conditions:

- temperature between 10°C and 35°C,
- maximum air humidity 80% (non-condensating).

4.3 Commissioning

The machine is commissioned by the customer's fitter.

1. Place the machine on an even ground at the place of installation.

WARNING!



Risk by tilting machine!

If not bolted to the floor, the machine may tilt. There is a risk of being injured.

- Fix the machine on the floor.

4 Transport and commissioning

4.3 Commissioning

2. Use suitable bolts to fix the machine legs on the floor.



Place the machine in a way so that it is easily accessible for maintenance work from all sides.

3. Check the machine for damage.
4. Check the electric cables for damage.
5. Train the operating staff and record training sessions in “Declaration of trained staff”, Section 9.

WARNING!



Risk of injuries!

Machine components might loosen during transport. Such components might be flung out during to the forming process. There is a risk of being injured.


- Open and close the machine several times without any work-piece.
- Check the machine for atypical noise.

4.3.1 Filling hydraulic oil

If the UNIFLEX forming machine was purchased without hydraulic oil filling, the appropriate new, clean and pre-filtered hydraulic oil has to be filled before commissioning (for oil type, please refer to "Technical data" in Section 3).

4 Transport and commissioning

4.3 Commissioning



CAUTION!



Risk of injuries!

Contact with hydraulic oil and other consumables imposes a risk of injuries for the skin, eyes, respiratory and intestinal tracts! Hydraulic liquid spills impose danger of slipping and falling!

- Observe supplier's protection and safety instructions (see data sheet).
- Wear personal protection equipment.
- Do not eat, drink or smoke in the working area and when handling consumables.
- Ensure good ventilation.
- Avoid floor contamination.

ATTENTION!



Risk of fire!

Hydraulic liquid spray or spills imposes a risk of fire.

- Avoid ignition sources (welding, cutting and soldering work) near the hydraulic oil filling.

1. Dismantle the grating (1).
2. Open the bleed screw (2).
3. Fill in hydraulic oil; for quantity and type, please refer to "Technical data" in Section 3.
The oil level can be read on the fill level indicator (3). The oil level should be at the centre of the fill level indicator.
4. Close the bleed screw (2).
5. Mount grating.

4 Transport and commissioning

4.3 Commissioning

6. Do not operate the machine for a minimum of four hours so that the dirt particles in the system may settle.

4.3.2 Electrical connection

ATTENTION!



Risk of damage to machinery

The voltage range described in this Section is only permissible for multi-voltage machines (MVA). Reconnecting the machine with a fixed input voltage will result in the destruction of the machine.

- Do not reconnect machines with fixed input voltage.

WARNING!




Risk by electrical voltage!

There is a risk of electrocution near the live parts!

- Work on electric systems may only be performed by qualified electricians or instructed and trained persons under the supervision of a qualified electrician.
- Do not operate the machine without a sufficiently rated ground wire.
- Deactivate the machine and secure it against unintentional restart before maintenance.

4 Transport and commissioning

4.3 Commissioning



1. Connect the voltage selection plug to the correct slot in the control cabinet - Δ 230 V on connection (3), Y 400 V on connection (2).
2. Set the motor protection switch (1) as specified in Section 3, "Technical data".




The permissible voltage frequency ranges and the relevant motor protection setting are also indicated on the sticker in the control cabinet door.

3. Have the power cable of the machine connected to the local mains by a qualified electrician according to the regulations of the Electricity Board.

4 Transport and commissioning

4.3 Commissioning



4. Dismantle the control cabinet cover and check the electric motor rotational direction according to the arrow through the inspection window. Exchange outer cable (phases) of the connection, if required.

ATTENTION!



Risk of damage to machinery!

Extended operation of the motor with an incorrect rotational direction or operating the machine without oil will destroy the hydraulic pump.

- Make sure that the hydraulic oil filling in the machine is sufficient before starting the machine.
- Ensure that the rotational direction of the motor is correct. Observe the red arrow on the motor cover.

4.3.3 Bleeding the hydraulic system

1. Switch on the machine.
2. Operate the machine in the idle mode for two minutes in order to fill the pump with oil.
3. Open and close the tool several times.
4. Check oil level, add hydraulic oil if required.

5 Operation

5.1 What you have to observe

5 Operation

5.1 What you have to observe

The operator has received the Operation Manual from the owner, has read and understood it and will observe it.


Before starting and/or re-starting

- Ensure sufficient illumination of the working area of the machine/unit.

During operation

- Observe the safety instructions on the machine/unit.
- Make sure that no other persons stay in the working area.
- Use appropriate aids to handle heavy workpiece.
- Each movement of the hand must be observed.
- The control cabinet must be closed securely.
- Eating, drinking and smoking at the workplace is prohibited.
- Wear close-fitting clothes.
- Do not wear watches or jewellery.

5.2 Activation



1. Check that there is no emergency-stop situation.
2. Activate the power switch (1). The control starts the operating system; the starting screen showing the UNIFLEX logo will appear after a few seconds.

5 Operation

5.3 Forming the workpiece


5.3 Forming the workpiece

5.3.1 Prerequisites

Prerequisites for a correct forming process:

- The die system and the workpiece match each other.
- The proper jaw system is correctly mounted in the tool.
- The forming dimension and the dies have been entered in the control system, please also refer to "Setting the forming dimension" in Section 5.
- Preferably form the workpiece in the centre of the crimping die length. Eccentric forming leads to a conical forming result and an increased one-sided wear of the die system and the bearing plates.

5.3.2 Operation mode buttons control panel



5 Operation

5.3 Forming the workpiece

WARNING!



Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the die and the workpiece.

- Keep the feed opening for the workpiece as small as possible.
- Keep a minimum distance of 120 mm (A) to the die system.

1. Manually position the pre-mounted workpiece in the tool.
2. Hold the workpiece with one hand during the forming process.
3. Press and hold the button [↔] to close the tool; the forming process starts and ends when the pre-set diameter/pressure is reached.
4. **Manual operation mode:** Press the [↔] button upon completion of the forming process to open the tool.
5. **Semiautomatic operation mode:** Wait until the hold time defined in the control has expired; the tool will then open automatically.
6. Remove the workpiece from the tool.
7. Check the forming dimension after the first forming process. Correct the forming dimension in case of deviations between the actual dimension and the specified dimension (see “Setting the forming dimension” in Section 5).




Open the crimping tool only so much that the hose may be placed and/or removed easily. Excessive opening means risk of squeezing and time loss.

5 Operation

5.3 Forming the workpiece

5.3.3 Remote automatic mode, via dual foot switch




WARNING!



Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the die and the workpiece.

- Keep the feed opening for the workpiece as small as possible.
- Keep a minimum distance of 120 mm (A) to the die system.

1. Press [


5 Operation

5.3 Forming the workpiece



The operation mode Remote automatic via the dual foot switch is only functional if the plug of the dual foot switch is connected to the control cabinet.

5.3.4 Remote automatic mode, via depth stop





WARNING!



Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the die and the workpiece.

- Keep the feed opening for the workpiece as small as possible.
- Keep a minimum distance of 120 mm (A) to the die system.

1. Switch on the  button to activate the depth stop.
2. Insert the pre-assembled workpiece into the machine manually and press it against the depth stop.
3. Hold the workpiece with one hand during forming; the workpiece must continuously activate the depth stop during forming.
4. **Manual operation mode:** Press the  button to open the machine when the forming process is completed.

5 Operation


5.3 Forming the workpiece

5. **Semi-automatic operation mode:** Wait until the hold time defined in the control has expired; the tool will then open automatically.
6. Remove the workpiece from the tool.
7. Check the forming dimension after the first forming process. Correct the forming dimension in case of deviations between the actual dimension and the specified dimension (see "Setting the forming dimension" in Section 5).



The Automatic External mode with the depth stop is only functional if the connection of the depth stop is established in the control cabinet.

5.3.5 Changing the crimping dies with the quick die change system (only profile 239)



1. Select the change position for crimping dies in the control by activating the button [QDC].
2. Press the [←|→] button to open the crimping tool so that the dies type PB239 can just be inserted.
3. Push the eight pins of the quick die change system (1) into the front holes of the crimping dies (2).
4. Rotate anti-clockwise and remove the crimping dies (2) from the deposit.
5. Check the retaining bolts (3) of the crimping dies for damage.

5 Operation

5.3 Forming the workpiece

6. Hold the quick die change system with crimping dies in the centre of the crimping tool.

WARNING!



Risk of squeezing!

When the die system closes, there is a risk of getting squeezed between the dies.

- Take care that no parts of your body are inside the forming area when the crimping dies close.

ATTENTION!



Risk of damage to machinery!

The retaining bolts and the crimping dies will be destroyed if the retaining bolts do not fit in the mounting hole of the base dies or intermediate dies.

- Pay attention to the correct position of the quick die change system with crimping dies.


7. Press the [→|←] button to close the tool.
All retaining bolts (3) must slide into the relevant mounting hole (4) of the basic or intermediate dies, and the spring-mounted pressure pieces must engage into the retaining bolts.
8. Remove the quick die change system (1) and check that the crimping dies fit tightly.
9. Proceed in reverse order to remove the crimping dies.



Always use a complete set of equal crimping dies with the same identification and diameter. One set comprises eight crimping dies or seven crimping dies and one matching marking die.

5 Operation

5.4 Adjusting the depth stop



ATTENTION!



Risk of damage to machinery!

If the crimping dies protrude beyond the basic and intermediate dies, the crimping dies, the intermediate dies and the machine will be damaged (see (X) in the figure). In the figure, the crimping die (2) is placed incorrectly.


- Place the crimping die (2) in the base and/or intermediate die (3) so that it does not protrude.
In the figure, the crimping die (1) is placed correctly.

5.4 Adjusting the depth stop

The depth stop must be specifically adjusted according to the workpiece. When inserting the workpiece, the crimping process is triggered by touching the stop plate. After reaching the defined forming diameter or forming pressure, the crimping tool stops automatically. For special applications, such as pipe bends, the depth stop must be removed.

5 Operation

5.4 Adjusting the depth stop



1. Mount the foot clamp (7) on the rear of the machine using cylinder screw (6).

WARNING!




Risk of squeezing!

There is risk of getting squeezed between the depth stop and the machine chassis when positioning the depth stop

- Do not touch the stop in.
- Do not reach into the opening of the crimping tool.

2. Loosen clamping lever (1) and clamping lever (4).
3. Move the sleeve (2) and/or stop disc (3) into the desired position.
4. Tighten clamping lever (1) and clamping lever (4)
5. Plug the connection cable (5) into the socket for the depth stop.

Adjusting the control unit:

1. Activate the illuminated  foot pedal. The machine is closed automatically when the workpiece is pressed against the depth stop.

5 Operation


5.5 Setting the forming dimension

2. Form the workpiece.
3. Press the [←|→] button to open the tool.
4. Check the workpiece.
5. If the workpiece meets the requirements: produce other identical workpieces.
6. If the dimension is not reached: Adjust difference on the control unit, form again and check the workpiece.



Activate automatic opening in the control for series production.

5.5 Setting the forming dimension



The forming dimension (X) must be set specifically for the workpiece.


1. Read the forming dimension in the forming dimension table of the system supplier, e.g. $\text{Ø } 17.4 \text{ mm}$.
2. Select crimping dies with a smaller or the same diameter, e.g. $\text{Ø } 17 \text{ mm}$,
3. Place the crimping dies in the tool.
4. Set the control and/or micrometer to the requested dimension:
Control system: Forming dimension diameter
Micrometer: Workpiece forming dimension less crimping die diameter
5. Form the workpiece.
6. Check the workpiece.
7. If the dimension is reached: manufacture other identical workpieces.

5 Operation

5.6 Stop

8. If the dimension is not reached: Adjust difference on control and/or in the micrometer, repeat the forming process and check the workpiece.

5.6 Stop



1. Complete the forming process.
2. Deposit the work piece outside the machine.
3. Deactivate the main switch (1).
4. Check the machine for contamination, leaks and external damage.
5. Check the crimping tool and retaining bolts for contamination, damage and secure fitting.
6. Check the oil level.
7. Remove contamination, dust and chips using a vacuum.



Inform the fitter in case of damage or other irregularities.

5.7 Emergency stop

In case of an emergency

Immediately press the emergency-stop button (1) in cases of emergency. The crimping tool movement will be stopped. The drive unit is shut down.

Restart after and emergency

WARNING!



Risk of injuries!

The emergency-stop button was probably activated due to the occurrence of a hazardous situation. A restart of the machine may cause injuries if the hazardous situation has not yet been remedied!

- Remedy the hazardous situation before a restart.

1. Remedy the cause of the emergency stop.
2. Unlock the emergency-stop button.
3. Reset the error messages on the control.

5.8 Cleaning

ATTENTION!



Risk of damage to machinery!

If the machine is cleaned with a steam jet or compressed air, dirt and water may ingress in the machine and cause serious damage.

- Do not use a steam jet to clean the machine.
- Do not use compressed air to clean the machine.

1. Vacuum the machine from metal abrasion (crimping scale) in the opened crimping tool, or use a soft cloth to clean it. For this purpose, remove the crimping dies and the intermediate dies.

6 Maintenance

6.1 What you have to observe

6 Maintenance

Regular maintenance will ensure the continuous operation reliability of the device.

6.1 What you have to observe

This Section describes action to be taken by you as the fitter regularly to ensure the troublefree use of the machine/unit.

- Maintenance work may only be performed by qualified maintenance staff (machine/unit fitters).
- Repair work on the machine/unit or components may only be performed by appropriately qualified expert staff or UNIFLEX experts!
- The machine/unit must always be deactivated during maintenance work (see "Deactivation" in Section 5). Use the lock to prevent the main switch from being switched on and also attach a sign. Example text:

Machine/unit out of service for
maintenance work!
Do not switch on!

- Welding, flame-cutting and grinding work on and in the machine/unit and its environment must be approved in advance. There is a risk of fire. The machine/unit must be cleaned from dust and inflammable substances. Adequate ventilation must be ensured.

6.2 Maintenance schedule

If not specified otherwise, inspections listed in the maintenance schedule are visual inspection. Replace defective parts.

If you work in 2 shifts, the check frequency has to be doubled. If you work in 3 shifts, you proceed as with 2-shift operation.

Record maintenance work performed in the maintenance log.

6 Maintenance

6.2 Maintenance schedule

Maintenance item	Weekly	Monthly	Every 6 months	Number of years
Hydraulic system				
Hydraulic energy lines – hoses: Check for porosity and leaks.		X		
Hydraulic energy lines - bolted connections of hoses and pipes: Check for leaks.		X		
Hydraulic oil: Check oil level, add oil if required (see “Replacing hydraulic oil” in Section 6).				
Hydraulic oil filter: Change according to control display.				
Hydraulic oil: Replace				1
Hydraulic hoses: Have replaced (DIN 20066) no later than six years after manufacture (see label). Make sure that replacement hoses are of equivalent quality (high-pressure hoses).				6
Crimping tool				
Crimping tool: Check for damage and wear.		X		
Retaining bolt: Check for damage.		X		
Slide bearing plates: Check for wear (see “Checking and replacing slide bearing plates” in Section 6).			X	
Pressure springs between base dies: Check for damage.			X	
Guiding plates: Check for wear (visible grooves, unevenness).			X	
Hexagon socket screws in the base dies: retighten after 1,000 crimping cycles for the first time; subsequently retighten after 50,000 crimping cycles, each (HM 2xx M5, tightening torque MA = 8 Nm).				1
Check all bolted connections for secure fitting and retighten if necessary.				1
Complete crimping tool: overhaul after 150,000 crimping cycles. Only in case of extreme loads when insulators, structural steel as well as steel ropes (PFC applications) are pressure-joined.				1.5

6 Maintenance

6.3 Hydraulic oil change

Maintenance item	Weekly	Monthly	Every 6 months	Number of years
Safety equipment				
Emergency-stop button: Check function	X			
Check permanently installed partitioning protection equipment and covers for completeness and correct installation.		X		
Check case foot switch for completeness. The case protects the pedals against unintentional activation.		X		
Warning signs on the machine: Check legibility (see "Warning signs on the machine" in Section 2)			X	



Hydraulic oil changes and wear part replacements must be recorded in the maintenance log!

6.3 Hydraulic oil change

CAUTION!



Risk of injuries!

Contact with hydraulic oil and other consumables imposes a risk of injuries for the skin, eyes, respiratory and intestinal tracts! Hydraulic liquid spills impose danger of slipping and falling!

- Observe supplier's protection and safety instructions (see data sheet).
- Wear personal protection equipment.
- Do not eat, drink or smoke in the working area and when handling consumables.
- Ensure good ventilation.
- Avoid floor contamination.

6 Maintenance

6.3 Hydraulic oil change


ATTENTION!



Risk of fire!

Hydraulic liquid spray or spills imposes a risk of fire.

- Avoid ignition sources (welding, cutting and soldering work) near the hydraulic oil filling.



1. Deactivate the machine on the main switch and secure it against unintentional restart.
2. Let the hydraulic oil cool down until the tank enclosure is warm to the touch.
3. Dismantle the grating (1).
4. Open the air ventilation cap (2).
5. Pump out hydraulic oil using an external pump.
6. Add new hydraulic oil (see “Technical Data” in Section 3).
7. Check oil level.
8. Close the air ventilation cap (2).
9. Mount grating (1).
10. Do not operate the machine for a minimum of four hours so that the dirt particles in the system can settle.
11. Switch on the machine.
12. Operate the machine in the idle mode for two minutes.
13. Run the tool several times to bleed the hydraulic oil system.
14. Check oil level. The oil level should be at the centre of the fill level indicator; refill hydraulic oil, if required.

6 Maintenance


6.4 Checking and replacing slide bearing plates



Dispose of the oil in compliance with the applicable local environmental protection regulations.

6.4 Checking and replacing slide bearing plates

Checking slide bearing plates



Check slide bearing plates for wear, replace defective parts. The slide bearing plate (1) is new, the slide bearing plate (2) is worn.

ATTENTION!



Risk of damage to machinery!

Worn slide bearing plates may cause damage to the machine and lead to inaccuracies of the forming dimension.

- Replace worn slide bearing plates in good time.

Replacing slide bearing plates




The following spare parts sets are required for replacing the slide bearing plates:

- Spare parts set 239.2 (HM 220.3)
- Spare parts set 255.1 (HM 225.3)
- Spare parts set 778.1 (shims)

6 Maintenance

6.4 Checking and replacing slide bearing plates



1. Open the crimping tool fully.
2. Deactivate the machine on the main switch and secure it against unintentional restart.
3. Loosen the hexagon socket screws (1) (four at the front and the back, each) and remove the protective plates (2).
4. Loosen the hexagon socket screws (3) (eight at the front and the back, each) with adjusting washers and remove the guiding plates (4).
5. Slightly loosen both inside hexagon socket screws (5) in the 3, 6, 9 and 12 o'clock base dies by two revolutions.



The new slide bearing plates have two different surfaces. The side with the white, grey or red coating is the slide bearing plates surface for the dies.

The shiny metal side of the slide bearing plates is the back side.

6. Replace the four secondary bearing plates (7) by new ones. In doing so, use the new secondary bearing plates to push out the old secondary bearing sheets, each.
7. Slightly lift the master dies (6) using a screw driver (10) and press the eight master bearing plates (9) against the old slide bearing plate at the front.
This will push the old slide bearing plates out of the tool.
8. Replace hexagon socket screw (5) in the base dies and tighten them to the torque for M5 MA = 8 Nm.
9. Reassemble guiding plates and protective plates in the reverse order.

6 Maintenance

6.5 Replacement of relay/opto-coupler

10. For this purpose, use grease to fix one adjusting washer, each, on the basedies before the guiding plates (4) are screwed on.
11. Perform a forming test run and check the formed sleeve.




Shims, if any, have to be placed at the same location as before.



After replacement of the slide bearing plates, the machine has to be recalibrated (see CONTROL C.2 / IPC Operation Manual).

6.5 Replacement of relay/opto-coupler



1. Deactivate the machine on the power switch and secure it against unintentional restart.
2. Open the control cabinet.
3. Open the flap 90° and press down on the hinge with the opened flap (1).
The relay/opto-coupler (2) will spring up.
4. Remove the relay/opto-coupler and replace it by a new one.
5. Close flap.

7 Troubleshooting

Error	Cause	Remedy
Machine does not close/open	Main switch is OFF	Activate the main switch
	Voltage incorrect	Check voltage supply
	Power plug defective	Check power plug and replace if necessary
	Rotational direction of electric motor incorrect	Check rotation direction, correct electrical connection
	Insufficient amount of hydraulic oil	Refill oil
	Power unit defective	Check power unit
Machine forms unevenly/conically	Operation buttons defective	Check operation buttons and replace, if required
	Bearing plates worn	Check bearing plates for wear and replace if necessary
	Base dies damaged	Check base dies for damage and replace if necessary
	Crimping dies damaged	Check crimping dies for damage and replace if necessary
	Crimping area not centred	Preferably form the workpiece in the centre of the crimping die length.
Crimping dimension not achieved	Bearing plates worn	Check bearing plates for wear and replace if necessary
	Oil pressure too low	Check oil pressure at the MP measuring point, pump or pipe may be leaking or defective, repair or replace
	Incorrect crimping dies used	Check crimping die diameter and profile and exchange, if required (see "Technical data", Section 3, for crimping die profile)

Error messages displayed on the control panel are described in the separate operating instructions of the control system.

8 Decommissioning, disposal

WARNING!



Risk by electrical voltage!

There is a risk of electrocution near the live parts!

- Shut down the machine/unit.
- Disconnect the machine/unit from the power supply.

CAUTION!



Risk of injuries!

Contact with hydraulic oil and other consumables imposes a risk of injuries for the skin, eyes, respiratory and intestinal tracts! Hydraulic liquid spills impose danger of slipping and falling!

- Observe supplier's protection and safety instructions (see data sheet).
- Wear personal protection equipment.
- Do not eat, drink or smoke in the working area and when handling consumables.
- Ensure good ventilation.
- Avoid floor contamination.

ATTENTION!



Risk of fire!

Hydraulic liquid spray or spills imposes a risk of fire.

- Avoid ignition sources (welding, cutting and soldering work) near the hydraulic oil filling.

CAUTION!



Risk of injuries!

Parts of the machine/unit may be under pressure and/or tension. Loosening components may impose a risk of injuries!

- De-pressurize the machine/unit before performing any work and check for potential sources of hazard.

8 Decommissioning, disposal

8.1 Dismantling

8.1 Dismantling

This section describes activities to be performed by you as the operator to ensure the safe dismantling of the machine/unit.

- The machine/unit may only be dismantled by entrusted and qualified staff.
- Open the machine/unit completely.
- Depressurise the machine/unit before dismantling it (deactivate the hydraulic pump and secure it against restart; operate valve manually, if any; open bolted hydraulic connections slowly and carefully).
- Check the machine/unit for mechanical tension and consider it during dismantling.
- Empty the machine/unit of all consumables, see “Maintenance”, Section 6.

8.2 Recycling

The machine/unit contains metal, hydraulic hoses, electric cables and electronic components, depending on the type.

As regards disposal, the applicable national environmental protection and waste disposal regulations have to be complied with.

8.3 Consumables and waste

Observe applicable national environmental protection and waste disposal regulations.

Return consumables, e.g. oils, greases, test media, to supplier - they are hazardous waste. Also observe the information given on the safety data sheet.

9 Annex

9.1 Accessories (retrofitable)

9 Annex



Individual machine/unit components may deviate in their features. Please indicate the serial number of the machine for spare part orders.

9.1 Accessories (retrofitable)


Accessories	Part code
Quick die change system	QDC 239.5
Die deposit	QDS 239 B QDS 239 C QDS 239 R
TU-QDS crimping die deposit system	QDS-S.2 single row TU-QDS F Shelf TU-QDS F 239 I
End stop	TA 220 TA HM 22x.3 C A
Mirror	SHS 220/290 (HM 220.3) SHS 225 (HM 225.3)
Camera set	OCS 10.3 retro
Lamp with magnetic base	LUS
Die wrench	239.017.4
Oil cooler	OC HM2xx MVA
Crimping dies system	PB 239

Please contact our Sales department for ordering accessories.

For more control accessories, please refer to the Control C.2 / IPC Operation Manual.

9.2 Spare parts list

9.2.1 Mechanical equipment



Item	Quantity	Part code	Designation
1	1	255.018.1	Upper yoke
2	1	255.016.1	Lower yoke
3	1	255.023.3	Beam
4	2	255.035.3	Tension rod
5	1	255.1110.1	Hydraulic cylinder


9 Annex

9.2 Spare parts list

Item	Quantity	Part code	Designation
6	1	255.030.3	Tool plate
7	8	255.061.2	Base dies
8	8	239.151	Pressure piece, spring-loaded
9	32	249.140	Pressure spring
10	2	255.004.3	Lateral dies
11	4	255.036.3	Yoke disc
12	1	255.050.3	Oil collecting ring
13	4	8060 DU	DU sleeves
14	8	255.033.4	Protective plate
15	4	255.011.4	Side bearing plate
16	8	255.027.4	Basic bearing plate
17	4	798.320004	Hexagon nut
18	1	798.120104	Head screw with hexagon socket
19	24	798.220016	Adjusting washer
20	4	255.031.4	Lateral guard plate
21	4	798.320006	Hexagon nut
22	8	798.110234	Head screw with hexagon socket

9 Annex

9.2 Spare parts list



Item	Quantity	Part code	Designation
23	1	255.1320.0	Chassis
24	1	255.103.4	Front panel HM 225
25	1	255.054.2	Cover
26	1	255.104.3	Protecting grating
27	2	255.034.4	Side cover HM 225
28	1	255.028.2	Protective cover
29	1	266.353	Oil inspection glass
30	1	239.121.4	Position encoder angle
31	1	239.122.4	Position encoder angle
32	1	777.919.3	Danfoss sign
33	1	255.069.3	Vacuum plate

9 Annex


9.2 Spare parts list

Item	Quantity	Part code	Designation
34	1	255.063.2	Gasket for vacuum plate
35	1	241.500	Holder IPC
315	2	578.4	Oil prohibition sign
316	2	715.4	Squeezing risk warning sign
317	6	716.4	Warning of hand injuries sign
1000	1	255.1520	Crimping tool, complete
1001	1 set	255.061.2	Base dies HM225

9 Annex

9.2 Spare parts list

9.2.2 Hydraulic system



Item	Quantity	Article code	Designation
1	1	255.055.3	Tank plate
2	1	255.320.3	Control block
3	1	227.001	Control valve
No fig.	1	220.916	Pressure sensor
5	1	24/30N2a-28	Hydraulic coupling

9 Annex


9.2 Spare parts list

Item	Quantity	Article code	Designation
6	1	239.352	Pump
7	1	777.300	Pump carrier
8	1	777.301.3	Gasket
9	1	GN 552-R3/4	Bleed screw
10	1	239.517	Suction filter
11	1	N-0	Re-suction filter
12	1	239.518	Double pipe nipple
13	1	238.604	Hydraulic hose
14	1	239.332	Hydraulic hose
15	1	255.062.2	Tank seal
16	2	238.619	Hose line
17	1	239.331	Hose line
18	1	255.602	Hose line
19	1	255.121.3	Hydraulic pipe
20	1	255.122.3	Hydraulic pipe
21	1	239.516	Suction filter
22	1	239.515	Double pipe nipple
23	1	239.521	Angle
24	1	239.531	Double pipe nipple
25	1	239.529	Angle

9 Annex

9.2 Spare parts list

9.2.3 Electric equipment




Item	Quantity	Article code	Designation
1	1	807.880	IPC.2
2	1	807.415	Position encoder
3	1	8.06.100	Main power switch
4	1	888.621	Voltage selection unit
5	1	888.014	Motor protection combination

9 Annex

9.3 Depth stop, manual

Item	Quantity	Article code	Designation
6	1	807.318	Switching power supply
7	1	888.406 888.411 888.410	Passive interface Relay Opto-coupler
8	1	807.375	CPU
9	1	807.601	Electric cabinet
10	1	807.468	Outside cable kit
11	1	232.011	Electric motor

9.3 Depth stop, manual




Item	Quantity	Part code	Designation
1	1	TA 220	Depth stop, manual, complete
2	1	239.008	Cross clamping piece with two clamping levers
3	1	239.009	Foot clamp
4	1	239.010	Angle clamp
5	1	239.011	Hollow profile 30x30x2

9 Annex

9.4 Depth stop, automatic

Item	Quantity	Part code	Designation
6	1	239.012	Pipe Ø 30x2
7	1	239.013	Circular plug
8	1	239.014	Square plug

9.4 Depth stop, automatic



Item	Quantity	Part code	Designation
1	1	TA HM 22x.3 C A	Depth stop, automatic; complete
2	1	807.430	Plunger switch, complete
3	1	239.008	Cross clamping piece with two clamping levers
4	1	239.009	Foot clamp
5	1	239.010	Angle clamp
6	1	239.011	Hollow profile 30x30x2
7	1	239.012	Pipe Ø 30x2
8	1	239.013	Circular plug
9	1	239.014	Square plug

9 Annex

9.5 Spare parts kit









9.5 Spare parts kit

Quantity	Part code	Designation
1	255.1520	Replacement tool HM 220.3
32	255.5	Pressure spring set
8	239.041.4 sw	Retaining bolt, plastic (profile: 239 / 239L)
8	239.041.4	Retaining bolt, steel (profile: 239 / 239L)
1	239.151	Pressure spring screw(profile: 239)
1	255.4	Guiding plate set
1	255.3	Lateral die set
1	255.2	Basic die set
1	255.1	Slide bearing plate set
1	255.8	Gasket set
1	VK 252	Standard packagings (single machines)
1	800.605	Interface calliper cable
1	800.609	Calliper
1	800.610	Single foot switch

9 Annex

9.6 Retaining bolt for standard crimping dies (depending on crimping die)

9.6 Retaining bolt for standard crimping dies (depending on crimping die)

Retaining bolt	Crimping die profile									
	262	263	239	266	232	237	554	245	246	247
 262.104.4	x									
 262.129.3		x								
 239.041.4			x							
 239.041.4 (sw)			x							
 232.504.4				x	x	x				
 232.505.4					Ø96 / Ø103					
 220.502.4							x			
 245.114.4								x	x	x


9 Annex

9.6 Retaining bolt for standard crimping dies (depending on crimping die)

9 Annex

9.7 Hydraulic diagram


9.7 Hydraulic diagram



9 Annex


9.8 Electric diagram

9.8 Electric diagram




9 Annex

9.8 Electric diagram



9 Annex


9.8 Electric diagram



Zustand	Änderung	Datum	Name	Norm	Uspcr.	Ers. für	Uniflex-Hydraulik GmbH Proj.Titel: SPS		Table.Nr.: 807.601 Ausgabe: N Auflage: A 0.0/0.0	Anlage: UNIMATIC C Blatt-Nr.: 3 Bl. von/Anz. 3/8
		08.10.2014	IW.David				Proj.Titel: SPS Ers. durch:			
		Datum	Name	Norm	Uspcr.	Ers. für	Uniflex-Hydraulik GmbH Proj.Titel: SPS		Table.Nr.: 807.601 Ausgabe: N Auflage: A 0.0/0.0	Anlage: UNIMATIC C Blatt-Nr.: 3 Bl. von/Anz. 3/8


9 Annex

9.8 Electric diagram




9 Annex

9.8 Electric diagram



9 Annex


9.8 Electric diagram



Zustand	Änderung	Datum	Name	Uspz.	Erz. für	Erz. durch	Proj./Titel:	UNIMATIC C	Table Nr.:	807.601	Anlage
		25.07.2014	W.David						Source	N	
		06.09.2013	W.David						Blatt-Nr.	6	
			Gspz.	H.Fröh					Blatt-Anz.	6/8	


9 Annex

9.8 Electric diagram



9 Annex


9.8 Electric diagram



Zustand		Änderung		Datum		W.David		Datum		26.08.2013		Uniflex-Hydraulik GmbH		ESt. für		ESt. drinn		Proj. Titel		HMI		Teile Nr		807 600-602		Anlage					
						W.David						PCB								Doc.Nr.		N		Art.Nr.		ESt.Nr.		1			
						W.David																						ESt.Nr.		102	

9 Annex

9.9 Maintenance log



Zuständig		Anlage	
Anwendung	Datum	Teil-Nr.	807.600-602
Name	28.11.2014	Locazione	N
Name	IW David	Aut. Nr.	2
Name	Objekt	Aut. Nr.	292
Name	Norm	Hersteller	
Umfang		Proj. Titel	
Umfang		HMI	
Umfang		com./settings	
Umfang		Ers. für	
Umfang		Ers. durch	
Uniflex-Hydraulik GmbH			

9.9 Maintenance log

9 Annex

9.10 Declaration of qualified staff

Hydraulic oil	Hose assembly	Retaining bolt	Slide bearing plate	Pressure springs	Guiding plate	Relay	Remark	Date	Signature
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			

9.10 Declaration of qualified staff

I herewith declare that I have attended an internal training for the operation of the UNIFLEX machine and have been informed on all

9 Annex

9.10 Declaration of qualified staff

safety-related details. In addition I declare that I have read and understood this Operation Manual completely.

City	Date	Name	Signature

City	Date	Name	Signature

City	Date	Name	Signature

City	Date	Name	Signature

City	Date	Name	Signature

City	Date	Name	Signature

9 Annex

9.10 Declaration of qualified staff

9 Annex

9.10 Declaration of qualified staff

About Danfoss Power Solutions FC

We sincerely appreciate your choice in selecting this product as part of the range of tooling products distributed by Danfoss.

Danfoss hoses, fittings, and tooling provide the ultimate fluid conveyance solutions for a variety of equipment and applications around the world. We proudly engineer to support a sustainable future for tomorrow.

To learn more please visit: <http://www.danfoss.com/en/about-danfoss/our-businesses/power-solutions>

Danfoss Power Solutions

14615 Lone Oak Road
Eden Prairie, MN 55344, USA
Phone: 952-937-9800

Danfoss Power Solutions II GmbH

Fluid Conveyance
Dr. -Reckeweg-Str. 1
DE-76532 Baden-Baden
Tel.: +49 7221 6820
Machine and tooling selection hotline: FcMachineSupportEMEA@danfoss.com
Service and repair Hotline: FcMachineRepairsEMEA@danfoss.com

Danfoss Power Solutions (US) Company

2800 East 13th Street
Ames, IA 50010, USA
Phone: +1 515-239-6000

Danfoss Power Solutions GmbH & Co.OHG

Krokamp 35
D-2439 Neumünster, Germany
Phone: +49 4321 871 0

Danfoss Power Solutions ApS

Nordborgvej 81
DK-6430 Nordborg, Denmark
Phone: +45 7488 2222

Danfoss Power Solutions Trade (Shanghai) Co. Ltd.

Building #22, No 1000 Jin Hai Rd
Jin Qiao, Pudong New District
Shanghai, China 201206
Phone: +86 21 3418 5200w

Thank you for participating in the Danfoss tooling program. We are pleased to offer you high-quality tooling machines manufactured by our trusted partner, Uniflex. These machines are designed to meet the rigorous standards of our industry, ensuring reliability, precision, and efficiency in your operations. We are committed to providing you with the best tools to support your success.

Danfoss can accept no responsibility for possible errors in catalogs, brochures, and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are the property of the respective companies.

Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.