

## Installation guide – spare parts and accessories


**Cover spare part kit for solenoid valve**

Types EV220A 18-22 and EV220B 25

032R9243


## Spare part EV220A

1: Cover  
2: O-ring, Pilot  
3: Screw, Pilot  
4: O-ring, Cover  
5: Screw, Cover




2


1A




2A




3A




4A



5A





6A




032R9243

## Spare part EV220B


1: Cover  
 2: O-ring, Pilot  
 3: Screw, Pilot  
 4: O-ring, Cover  
 5: Screw, Cover




1B




2B




3B



4B



5B



6B

