


## Data sheet – Spare parts and accessories

### Gas detecting sensors

#### Types GDA, GDC, GDHC, GDHF, GDH



| Description                                                        | Fig. # | Qty. | Code no. |
|--------------------------------------------------------------------|--------|------|----------|
| GD Tester all models. To test mother PCB at Sensor PCB replacement |        |      |          |
| Beaker M42                                                         | 1      | 1    | 148H5230 |
| EC/SC/CT-Adapter. Fit Beaker M42                                   | 1      | 1    |          |
| M35 Adapter. Fit Beaker M42                                        | 1      | 1    |          |
| GD Ampoules                                                        |        |      |          |
| GD Ampoules 100 ppm ammonia                                        | 1      | 10   | 148H5234 |
| GD Ampoules 1000 ppm ammonia                                       | 1      | 10   | 148H5235 |
| GD Ampoules 2000 ppm CO <sub>2</sub>                               | 1      | 10   | 148H5236 |
| Remote LCD display                                                 |        |      |          |
| Remote LCD display IP 41                                           | 2      | 1    | 148H5238 |

| Description                          | Fig. # | Qty. | Code no. |
|--------------------------------------|--------|------|----------|
| <b>GD mother PCB</b>                 |        |      |          |
| GD mother PCB all models             | 3      | 1    | 148H5232 |
| <b>GD Tester for mother PCB</b>      |        |      |          |
| GD Tester for mother PCB, all models | 3      | 1    | 148H5239 |