


Installation Guide / Instruktion

ECA 32 (code no. 087H3202)
ECA 35 (code no. 087H3205)



ENGLISH

Please note when using the applications P348 and P318:

- ECA 32 must have version code 1.60 as a minimum
- ECA 35 must have version code 1.60 as a minimum

DEUTSCH

Bitte beachten Sie folgenden Hinweis bei der Verwendung der Applikationen P348 und P318:

- ECA 32 muß mind. die Version 1.60 besitzen
- ECA 35 muß mind. die Version 1.60 besitzen

Label on ECA (example):

Danfoss
ECA 32
087H3202
A01.6000-2016-33
01.60 = Version 1.60

Typenschild auf ECA (Beispiel):

Danfoss
ECA 32
087H3202
A01.6000-2016-33

 01.60 = Version 1.60

Installation guide / Instruktion ECA 32, ECA 35

?   **ECA 32, ECA 35: www.heating.danfoss.com**

?   **<https://www.youtube.com/user/DanfossHeating>**
-> **Playlists** -> **How-to Videos** -> **District Energy installation videos**



Danfoss A/S

Heating Segment • danfoss.com • +45 7488 2222 • E-Mail: heating@danfoss.com

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.
All trademarks in this material are property of the respective companies. Danfoss and all Danfoss logotypes are trademarks of Danfoss A/S. All rights reserved.