

Installation guide

Premium

Uninstall/install display of Premium GD unit

148R9655

148R9655

1 Disassembly

- Ensure the cover height is correct



Figure 1: Different cover heights

- Ensure gas-free environment
- Disconnect from voltage
- Unscrew the cover in all 4 corners and keep the plastic screws in a safe place
- Open the cover



Figure 1: Closed Premium Device

- Disconnect the display PCB from the main board (white plug of display cable)



Figure 2: Unplug of the display PCB

- Unscrew the 2 cylinder screws (M4x10), which connect the hinges with the cover (on the side of the cover)
- Keep the 2 cylinder screws in a safe place




Figure 3: Remove cylinder screws

2 Assembly

- fasten the new cover, with display PCB, to the hinges of the housing using the 2 cylinder screws




Figure 4: Install the new cover

- Connect the display PCB via the display cable with the white plug to the main board



Figure 5: Plug-in the display connector

- Close the cover
- Secure the cover with the 4 plastic corner screws
- Connect to voltage
- Wait until the LED is green



Figure 6: Closed Premium device with new cover and display PCB