






6.





7.



8.



9.



❄ = 5°C

13656 000 03 Manual Installation WRT Dial 230 F86 IW

ENGINEERING
TOMORROW



Installation & User Guide

Danfoss *Icon*™ Dial Room Thermostat

VICUW40F/088N3651

www.icon.danfoss.com