

Opty™ Slim Spare parts & accessories - MBP

Spare Parts

Unit	Compressor					Contactor	Service valve		Oil	Crankcase Heater	Acoustic hood
	Model no	Code number	Start capacitor	Run Capacitor	Start Relay		Suction	Discharge			
HJZM0150	MTZ18-1 MTZ18-3	MTZ018-1VI MTZ018-3VI	119-4654	119-5617	119-5616	119-5640	119-4551	119-4545	120Z0648	120Z0459	120Z0575
HNXM0200	MLZ15T1 MLZ15T2	121U8709 121U8711	120Z0399	8173231	120Z0396	119-5640	119-4548	119-4545	120Z0648	120Z5040	120Z5083
HNXM0250	MLZ19T1 MLZ19T2	121U8719 121U8723	120Z0399	120Z0051	120Z0396	119-5640	119-4548	119-4545	120Z0648	120Z5040	120Z5083
HNXM0300	MLZ21T1 MLZ21T2	121U8737 121U8739	120Z0399	120Z0051	120Z0396	119-5640	119-4548	119-4545	120Z0648	120Z5040	120Z5083
HNXM0350	MLZ26T1 MLZ26T2	121U8751 121U8753	120Z0399	120Z0051	120Z0397	N: 119-4553 Q: 119-5640	119-4548	119-4551	120Z0648	120Z5040	120Z5083
HNXM0400	MLZ30T1 MLZ30T2	121U8763 121U8765	120Z0400	8173233	120Z0397	N: 119-5639 Q: 119-5640	119-4548	119-4551	120Z0648	120Z5040	120Z5084
HRXM0500	MLZ38T1 MLZ38T2	121U8775 121U8777	8173001	8173234	120Z0398	N: 119-4553 Q: 119-5639	119-4548	119-4551	120Z0648	120Z5040	120Z5084
HRXM0600	MLZ45T2	121U8797	----	----	----	119-5639	119-4548	119-4551	120Z0648	120Z5040	120Z5084
HRXM0700	MLZ48T2	121U8807	----	----	----	119-5639	119-4548	119-4546	120Z0648	120Z5040	120Z5084
HRXM0750	MLZ58T2	121U8817	----	----	----	119-4553	119-4550	119-4548	120Z0648	120Z5040	120Z5085
HRXM1000	MLZ76T2	121U8835	----	----	----	119-4553	119-4550	119-4548	120Z0648	120Z5040	120Z5085

Unit	Condenser	Defrost timer	Dual pressure switch	Fan	Fan capacitor	Fan speed controller	Filter drier	Receiver	Receiver valve	Sight glass	Sequence phase relay
HJZM0150	119-4536	119-4552	060-5253	119-4526	119-4529	061H3140	023Z5040	119-4531	119-4544	014L0022	----
HNXM0200	119-4537	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5041	119-4532	119-4545	014L0022	119-4567
HNXM0250	119-4537	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5041	119-4532	119-4545	014L0025	119-4567
HNXM0300	119-4537	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5041	119-4532	119-4545	014L0025	119-4567
HNXM0350	119-4538	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4533	119-4545	014L0025	119-4567
HNXM0400	119-4538	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4533	119-4545	014L0025	119-4567
HRXM0500	119-4539	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4534	119-4545	014L0025	119-4567
HRXM0600	119-4539	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4534	119-4545	014L0025	119-4567
HRXM0700	119-4539	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4534	119-4545	014L0025	119-4567
HRXM0750	119-4540	119-4552	060-5253	119-4528	119-4530	061H3140	023Z5045	119-4535	119-4551	014L0026	119-4567
HRXM1000	119-4540	119-4552	060-5253	119-4528	119-4530	061H3140	023Z5045	119-4535	119-4551	014L0026	119-4567

Optyma™ Slim Spare parts & accessories - LBP

Spare Parts

Unit	Compressor					Contactor	Service valve		Oil	Crankcase Heater	Acoustic hood
	Model no	Code number	Start capacitor	Run Capacitor	Start Relay		Suction	Discharge			
LJHM0150	NTZ048-1 NTZ048-3	120F0293 120F0279	119-4654	119-5617	119-5616	119-5640	119-4546	119-4545	7754019	120Z0459	120Z0575
LJHM0200	NTZ068-1 NTZ068-3	120F0294 120F0280	119-5636	119-5619	119-5616	119-5640	119-4546	119-4545	7754019	120Z0459	120Z0575
LN YM0400	LLZ013T2	121L9545	----	----	----	119-5640	119-4548	119-4551	120Z5035	120Z5040	120Z5052
LN YM0500	LLZ015T2	121L9547	----	----	----	119-5640	119-4548	119-4551	120Z5035	120Z5040	120Z5052
LR YM0600	LLZ018T2	121L9549	----	----	----	119-5639	119-4549	119-4546	120Z5035	120Z5040	120Z5052
LR YM0800	LLZ024T2	121L9551	----	----	----	119-5639	119-4549	119-4546	120Z5035	120Z5040	120Z5053

Unit	Condenser	Defrost timer	Dual pressure switch	Fan	Fan capacitor	Fan speed controller	Filter drier	Receiver	Receiver valve	Sight glass	Sequence phase relay	Suction accumulator
LJHM0150	119-4536	119-4552	060-5253	119-4526	119-4529	061H3140	023Z5040	119-4531	119-4544	014L0022	----	119-4541
LJHM0200	119-4536	119-4552	060-5253	119-4526	119-4529	061H3140	023Z5040	119-4531	119-4544	014L0022	----	119-4541
LN YM0400	119-4538	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4533	119-4545	014L0025	119-4567	119-4542
LN YM0500	119-4538	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4533	119-4545	014L0025	119-4567	119-4542
LR YM0600	119-4539	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4535	119-4551	014L0025	119-4567	119-4543
LR YM0800	119-4539	119-4552	060-5253	119-4527	119-4530	061H3140	023Z5044	119-4535	119-4551	014L0025	119-4567	119-4543

Unit	LI valve		Solenoid Coil	
LN YM0400	068F4079	AKVH10-1	018F4135	BX240BS
LN YM0500	068F4079	AKVH10-1	018F4135	BX240BS
LR YM0600	068F4079	AKVH10-1	018F4135	BX240BS
LR YM0800	068F4080	AKVH10-2	018F4135	BX240BS