

---

## AB-QM Neck Version

- Distinguishable neck design
- If adapter is missing valve will not fully close or loose mounting of actuator to valve



*1<sup>st</sup> Gen*

*2<sup>nd</sup> Gen*

---

# Adapter Combination Comparison




1<sup>st</sup> Gen

*Actuator*  
AME15QM  
AME25SU/SD

No Adapter  
Required

*Actuator*  
AME435QM  
AMV435


Adapter  
Required  
**065Z0313**



2<sup>nd</sup> Gen

*Actuator*  
AME15QM  
AME25SU/SD

Adapter  
Required  
**003Z0694**



*Actuator*  
AME435QM  
AMV435

No Adapter  
Required