


013R9468

Danfoss

**Instructions
RTD-BR
By-pass Restrictor**

013R9468




**013L1915 (DN 15/10)
013L1916 (DN 20/15)**

013R9468

Danfoss

**Instructions
RTD-BR
By-pass Restrictor**

013R9468



**013L1915 (DN 15/10)
013L1916 (DN 20/15)**

