



082R9181



082R9181




RAV
VMT
VMA
VMV




VMS
VMV




DANFOSS
AB2F4B.11




DANFOSS
AG2F04.11



DANFOSS
AB2F14.12




DANFOSS
AB2F09.13




DANFOSS
AB2F36.11

DANFOSS
AB2F37.11



Indstilling med reguleringsautomatik uden k_v -begrænsning

Setting: automatic control without k_v limitation
 Einstellung mit Regelautomatik ohne k_v -Begrenzung
 Réglage: Régulation automatique sans limitation de k_v
 Ajuste: Control automático sin limitación k_v
 Controllo automatico senza limitazione di k_v
 Inställning med reglerautomatik utan k_v -begränsning:
 Automatische regelung zonder minimum k_v -begrenzing
 Säätöautomatiikka, jossa ei k_v rajoitusta, asettelu
 Nastawa: regulacja automatyczna bez ograniczenia współczynnika k_v



Skalainstilling
 Scale setting
 Skaleneinstellung
 Position sur l'échelle
 Rango de ajuste
 Scala di regolazione
 Skalinställning
 Schaalinstelling
 Säätöasteikko
 Skala



DANFOSS
 AB2F20.11



Indstilling med reguleringsautomatik med k_v -begrænsning eller håndbetjening

Setting: automatic control with k_v limitation or manual operation
 Einstellung mit Regelautomatik mit k_v -Begrenzung oder Bedienung von Hand
 Réglage: Régulation automatique avec limitation de k_v ou commande manuelle
 Ajuste: Control automático con limitación k_v o funcionamiento manual
 Controllo automatico con limitazione di k_v o comando manuale
 Inställning med reglerautomatik med k_v -begränsning eller handmanöver:
 Automatische regelung met minimum k_v -begrenzing of handbediening bij spanningloze motor 0 → 100% open.
 Säätöautomatiikka, jossa k_v rajoitus tai käsikäyttö, asettelu
 Nastawa: regulacja automatyczna z ograniczeniem współczynnika k_v lub ręczna obsługa

Ventiltype
 Valve type
 Ventiltyp
 Type de vanne
 Válvula tipo
 Tipo valvola
 Ventiltyp
 Kleptype
 Venttiilimalli
 Typ zaworu



Ventiltype
 Valve type
 Ventiltyp
 Type de vanne
 Válvula tipo
 Tipo valvola
 Ventiltyp
 Kleptype
 Venttiilimalli
 Typ zaworu



Skalainstilling
 Scale setting
 Skaleneinstellung
 Position sur l'échelle
 Rango de ajuste
 Scala di regolazione
 Skalinställning
 Schaalinstelling
 Säätöasteikko
 Skala

Skalainstilling
 Scale setting
 Skaleneinstellung
 Position sur l'échelle
 Rango de ajuste
 Scala di regolazione
 Skalinställning
 Schaalinstelling
 Säätöasteikko
 Skala

