About the hot water in your home....



Temporary Override Buttons

Your timeswitch has two override buttons which you can use if you need to temporarily change the way you use your timeswitch.

+1HR Boost Button

Press once and system will come on immediately for 1 hour. If pressed while system is already on, the system will stay on for an extra hour.

Manual Override Button

If pressed when the system is on, the system will turn off and remain off until it is next due to come on again. If pressed when the system is off, the system will come on until it is next due to off again.

Running your System?

Select Button

Press the **SELECT** button to run your system. With each press of the **SELECT** button the display will change between **ON**, **OFF**, **ALLDAY** and **AUTO**.

AUTO	the system will come on and go off at the programmed times
ON	the system will remain on constantly
OFF	the system will not come on
ALLDAY	the clock will turn the system on at the first programmed ON and will leave it on until your last programmed OFF

Select the option your require depending on your lifestyle and time of year.

TS715Si Timeswitch



Boiler Service

If your property is owned by a landlord he may have set the boiler service timer for gas safety reasons. If this has been set you will hear an alarm when your boiler needs servicing.

Contact your landlord immediatley to arrange the boiler service.

Failure to do so will result in your heating and hot water system operating at a reduced level.

What is a Timeswitch?

Your timeswitch allows you to set the times you would like your hot water to come on and go off.

About your Timeswitch?

Your timeswitch comes pre-programmed with set of times for hot water to suit the average household.

Hot Water	Mon-Fri	Sat-Sun
1st ON	6:30	7:30
1st OFF	8:30	10:00
2nd ON	12:00	12:00
2nd OFF	12:00	12:00
3rd ON	17:00	17:00
3rd OFF	22:30	22:30

Should you wish to alter theses times to suit your own lifestyle please refer to the instruction booklet (pages 12-19).

RESET Button

If it is necessary to fully reset the unit, including the date and time, press and hold the +1HR and MAN buttons on the left hand side of the product. Press the RESET button, using a non-metallic object such as a pencil or end of a bic biro pen top), and hold for 3 seconds. Release the RESET button. The display will change to show the current time. Finally, release both the +1HR and MAN buttons.

The unit is now fully reset and must be re-programmed, please refer to the instruction booklet.

Installer Details