





Icon™ Dial 230V	
Max. load: 10W/50mA	
Danfoss A/S 6430 Nordborg Denmark	







6.





7.



8.



9.



❄ = 5°C

13655 000 03 Manual Installation WRT Dial 230 F80 IW

ENGINEERING
TOMORROW

Danfoss

Installation & User Guide

Danfoss *Icon*™ Dial
Room Thermostat

VICUV40F/088N3650

www.icon.danfoss.com