

Installation guide

Thermostatic element


AVTA / AVTB

003R9303

003R9303


009100

Spare Part
AVTA - AVTB
 Range AVTA: +50/+90°C
 Range AVTB: +50/+90°C
 Cap. tube: 2m
 Max. sensor temp: 125°C




DANFOSS
3N863.10FW

AVTA



DANFOSS
3N863.10FW

AVTB



DANFOSS
3N863.10FW