

Data sheet - Spare parts and accessories

# Safety relief valves SFA and SFV

## Compressor overflow valve POV + BSV

Size	Description	Pos. #	Qty.	Code no.
<b>Fig. 1 - SFA 10 Repair kit</b>				
SFA 10	Repair Kit 10 – 27 bar*	all pos.	1	<b>148F3069</b>
SFA 10H	Repair Kit 28 – 65 bar*	all pos.	1	<b>148F3070</b>
SFA 10(H)	SFA 10(H) G Inlet weld connector	-	1	<b>148F3075</b>
SFA 10(H)	SFA 10(H) NPT Inlet weld connector	-	1	<b>148F3076</b>
<b>Fig. 2 - SFA 15 Repair kit</b>				
15	Cone complete	1	1	<b>148F3036</b>
15	Gaskets	2, 3, 4	4	
<b>Fig. 2 - SFA 15-50 Repair kit</b>				
15	Cone complete	1	1	<b>148F3150</b>
15	Gaskets	2, 3, 4	4	
<b>SFA 10, SFA 15/SFV 15 - Nipples and gaskets</b>				
10, 15	Nipples + gaskets set for SFA 10, SFA 15/SFV 15**	-	2	<b>148F3019</b>
<b>Fig. 3 - SFV Repair kit</b>				
20	Cone complete	1	1	<b>2453+082</b>
20	Gaskets	2, 3, 4	4	
25	Cone complete	1	1	<b>2453+083</b>
25	Gaskets	2, 3, 4	4	
<b>SFV - Flanges and gaskets</b>				
20	Flanges + gaskets set for SFV 20	-	1	<b>148F3020</b>
25	Flanges + gaskets set for SFV 25	-	1	<b>148F3021</b>
<b>POV+BSV fittings</b>				
Set of fittings for system POV+BSV		-	1	<b>148H3453</b>

\* Inspection kit 148F3068 (see DSV 10) should be ordered with any SFA 10 repair kit.  
\*\* Weld nipple for SFA 10 inlet (G ½") not included in 148F3019.  
(additional order 148F3075 needed).