



Installation guide - Spare parts and accessories

Solenoid valve - Spare part

Type EV245B

032R9306

032R9306




A




Total no. = 1

B




Total no. = 1

C



Total no. = 1



Visit www.products.danfoss.com for further technical data
 Para más información, visite www.products.danfoss.es
 Rendez-vous sur le site www.products.danfoss.fr pour plus de données techniques