


Installation Guide

Adapters AMV(E) 25, 35, 55, 56, 323, 423, 523 / VRB, VRG, VF, VL (Gen. 2009)






DN 15-50	AMV(E) 25, 35, 323, 423, 523	065Z0311
DN 65, 80	AMV(E) 55, 56, 323, 423, 523	065Z0312



DN 15-50 (VRB, VRG, VF, VL)





DN 65, 80 (VF, VL) 065Z0312

AMV(E) 55, 56 AMV 323, 423, 523 ③ < 30sec. ⑤ 1×13mm 5-7 Nm 1×6mm 🗌 MV.B.002.1/02 7.5 mm 4×2mm Instructions

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.

All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

73691300/VI.BL.C4.00 Produced by Danfoss A/S © 02/2014