


Installation guide – Spare parts and accessories

Overhaul kit | Code number 032F2322
EVRAT, size 15 (previous design)



Danfoss
32F376_0_2011

<p>1</p> <p>Total no. = 1</p>	<p>2</p> <p>Total no. = 1</p>	<p>3</p> <p>Total no. = 1</p>	<p>4</p> <p>Total no. = 4</p>	<p>5</p> <p>Total no. = 1</p> <p>▨ = Rubber</p>	<p>6</p> <p>Total no. = 4</p>
<p>7</p> <p>Total no. = 1</p>	<p>8</p> <p>Total no. = 1</p> <p>▨ = Rubber</p>	<p>9</p> <p>Total no. = 2</p> <p>— = Fibre</p>	<p>10</p> <p>Total no. = 1</p>	<p>11</p> <p>Total no. = 1</p>	<p>12</p> <p>Total no. = 1</p>