



# **Thermal Actuator TWA-Z**

# Description



Danfoss thermal actuator TWA-Z is used with Danfoss automatically balanced combination valves type AB-QM.

The actuator can be controlled with an on/off controller, pulse width modulation (PWM), or switch.

These provide a cost effective solution for the control of hot and /or chilled water for fan coil units, small reheaters and recoolers in temperature control systems.

# Main features:

- 24 V AC/DC or 230 V AC supply
- Position indicator
  Normally opened (N)
  - Normally opened (NO) or normally closed (NC) version
- Max. medium temperature 120 °C
- Cable included

# Ordering

Туре	Supply voltage	Cable length	Code No.
TWA-Z NO		- 1.2 m	082F1260
TWA-Z NC	24 V AC/DC		082F1262
TWA-Z NO	2201/ AC		082F1264
TWA-Z NC	230 V AC		082F1266
TWA-Z NC	24 V AC/DC	5 m	082F1268
TWA-Z NC	230 V AC		082F1272
TWA-Z NC	24 V AC/DC	10 m	082F1270
TWA-Z NC	230 V AC		082F1274

#### Service kits - combination with old AB-QM

Туре	Code No.
TWA-Z adapter for AB-QM, DN 10-32	003Z0239

#### Disposal

The actuator must be dismantled and the elements sorted into various material groups before disposal.



### **Thermal Actuator TWA-Z**

## **Technical Data**

Power supply	V	24 AC/DC, ± 25%	230 AC, ± 25%	
Max. inrush current	mA	< 350	< 250	
Power consumption W		2		
Frequency H		50/60		
Control input		On/off and PWM		
Closing force N		90		
Min. stroke	. stroke mm		2.8	
Full stroke time <sup>1)</sup> min.		3		
Max. medium temperature		1.	20	
Ambient temperature ° C		2 60		
Storage and transport temperature		-40 70		
Ambient humidity		95% r.h., non-condensing		
Protection class		III	11	
Grade of enclosure		IP 41		
Cable length m		1.2, 5 or 10		
Weight kg		0.15		

1) When heating the actuator full stroke time increases up to some minutes – it depends on the ambient temperature.

#### Operation

TWA-Z actuator works on the thermal expansion principle:

- moves actuator stem in one direction in case of heating of the actuator and
- moves actuator stem in another direction in case of no heating of the actuator

Two versions of actuators are available:

- TWA-Z NO version, in the non-energized state actuator's stem is retracted
- TWA-Z NC version, in the non-energized state actuator's stem is extracted

Both versions are available in 24V (SELV) or 230V.

The TWA-Z NC has an internal spring, which is factory fixed with a split ring (*Fig.1*) to hold the spring retracted in its off -the-shelf state. The use of split ring allows the actuator to be mounted to the valve. Once mounted, the split ring has to be removed.

#### Note:

In case the actuator has been dismounted and split ring removed, split ring can be added back to the actuator after the heating of the actuator.

The actuator is equipped with a position indicator to show the position of the actuator stem (*Fig.2*).

The AB-QM valve is closed in stem down position. Without actuator force the internal spring opens the valve.

#### Combination, TWA-Z NO & AB-QM (Fig.3)

- in the non-energized state the valve is open
- in the energized state the valve is closed

#### Combination, TWA-Z NC & AB-QM (Fig.4)

• in the non-energized state the valve is closed in the energized state the valve is opened.











#### **Thermal Actuator TWA-Z**

Installation

Mechanical

Installation of the valve with the actuator is allowed in horizontal position or upwards.



#### Actuator / Valve Combinations



#### Dimensions





**Thermal Actuator TWA-Z** 

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and all Danfoss logotypes are trademarks of Danfoss A/S. All rights reserved.